

INVERTER

Plug-in option

A7NETH-V2

INSTRUCTION MANUAL

Ethernet multiprotocol communication interface



PRE-OPERATION INSTRUCTIONS	1
INSTALLATION	2
INVERTER SETTINGS	3
REGISTER NUMBERING	4
CONFIGURATION STUDIO	5
WEB SERVER	6
FILESYSTEM	7
FIRMWARE	8

Thank you for choosing this inverter plug-in option for the Mitsubishi 700 Series Inverter. This instruction manual provides handling information and precautions for use of this equipment. Incorrect handling may cause unexpected failures or damage. In order to ensure optimal performance, please read this manual carefully prior to use of the equipment. Please forward this manual to the end user of the equipment.

This section pertains specifically to safety issues

Do not attempt to install, operate, maintain or inspect this product until you have read through this instruction manual and any related documents carefully, and can use the equipment properly. Do not use this product until you have a full working knowledge of the equipment, safety information and instructions. In this instruction manual, the safety instruction levels are classified into "WARNING" and "CAUTION" levels.



Assumes that incorrect handling may cause hazardous conditions resulting in death or severe injury.



Assumes that incorrect handling may cause hazardous conditions resulting in moderate or slight injury, or may cause physical damage only.



Please note that even the **CAUTION** level may lead to serious consequence depending on conditions. Please be sure to follow the instructions of both levels as they are critical to personnel safety.

SAFETY INSTRUCTIONS

1. Electrical Shock Prevention



- Do not open the front cover of the inverter while power is on or while the inverter is running, as an electrical shock may result.
- Do not operate the inverter with the front cover or wiring cover removed, as accidental contact with exposed high-voltage terminals and internal components may occur, resulting in an electrical shock.
- If power is off, do not remove the front cover except when necessary for wiring or periodic inspection. While the front cover is removed, accidental contact with exposed high-voltage terminals and internal components may occur, resulting in an electrical shock.
- Prior to starting wiring or inspection, confirm that input power to the inverter has been switched off via observation of the inverter's display panel. Additionally, wait for at least 10 minutes after removal of input power, and then confirm that all residual voltage has been dissipated by using a voltage meter. Internal DC bus capacitors may contain high voltages for several minutes after removal of input power, resulting in a dangerous situation should anything come into contact with them.
- All personnel involved in the installation or inspection of this equipment should be fully competent to perform the required work.
- Always install plug-in options prior to wiring main power.
- Do not touch the plug-in option with wet hands.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching.

2. Injury Prevention



CAUTION

- To prevent explosions or similar damage, apply only the voltages specified in the instruction manual to each terminal.
- To prevent explosions or similar damage, ensure that all cables are properly connected to the correct terminals.
- To prevent explosions or similar damage, observe all wiring polarity indicators.
- To prevent burns from hot components, do not touch the inverter while power is on, or for some time after power is removed.

3. Additional Instructions

Please note the following points to prevent equipment damage, injury or electrical shock.

1) Transportation and Mounting



CAUTION

- Do not install or operate the plug-in option if it is damaged or has parts missing.
- Do not stand on or rest heavy objects on the equipment.
- Check that the mounting orientation is correct.
- Prevent conductive items such as screws and metal fragments, or flammable substances such as oil from entering the inverter.

2) Trial Run



CAUTION

- To prevent unexpected equipment movement, confirm and adjust all required parameters prior to starting operation.

3) Usage



WARNING

- Do not modify the equipment.
- Do not remove any inverter or option parts unless specifically instructed to do so in this manual.



CAUTION

- Performing a “parameter clear” or “all parameter clear” will reset all inverter parameters to their factory default settings. After performing one of these operations, remember to reenter any custom parameter values prior to starting operation.
- To prevent damage from electrostatic discharge, always touch a grounded piece of metal prior to touching any equipment.

4) Maintenance, Inspection and Parts Replacement



CAUTION

- Do not perform hi-pot tests on the equipment.

5) Disposal



CAUTION

- Contact the local or state environmental agency in your area for details on the disposal of electrical components and packaging.

6) General Instructions

For clarity purposes, illustrations in this manual may be drawn with covers or safety guards removed. Ensure all covers and safety guards are properly installed prior to starting operation.

– CONTENTS –

1	PRE-OPERATION INSTRUCTIONS	1
1.1	Product Overview	1
1.2	Features and Specifications	3
1.3	Inverter Compatibility	17
1.4	Unpacking and Product Confirmation	19
1.4.1	Shipment Confirmation	19
1.4.2	Component Overview	21
1.5	LED Indicators	22
1.5.1	Port Status LED Description	22
1.5.2	Standard LED Description.....	23
2	INSTALLATION	24
2.1	Pre-Installation Instructions	24
2.2	A700 & F700 Installation Procedure	26
2.2.1	Installation of the Communication Option LED Display Cover	26
2.2.2	Installation of the Communication Option on Control Board	27
2.3	E700 Installation Procedure	29

2.4	Wiring	30
3	INVERTER SETTINGS	31
<hr/> <hr/>		
3.1	Network Setting	32
3.2	Operation Mode Setting	34
3.2.1	Operation Mode Indication	34
3.2.2	Operation Mode Switching & Comm. Startup Mode (Pr. 79, Pr. 340).....	35
3.3	Operation & Speed Command Source (<i>Pr. 338, Pr. 339, Pr. 550</i>)	39
3.4	Communication EEPROM Write Selection (<i>Pr. 342</i>)	43
4	REGISTER NUMBERING AND BEHAVIOR	44
<hr/> <hr/>		
4.1	Register Numbers.....	44
4.2	Scanned Registers	47
4.3	Inverter Command Register.....	49
4.4	Frequency Command Register.....	50
4.5	Operation Mode Register	51
4.6	Inverter Reset Register	51
4.7	Alarm History Clear Register.....	52

4.8	All Parameter Clear Register	52
4.9	Inverter Status Register	53
4.10	Operation Mode Status Register	54
4.11	Alarm History Codes	54
5	MITSUBISHI CONFIGURATION STUDIO	55
<hr/> <hr/>		
5.1	Overview	55
5.2	General Object Editing Activities	60
5.3	Ethernet Settings.....	63
5.3.1	Authentication	63
5.3.2	Network Configuration	64
5.4	Internal Logic Settings.....	64
5.4.1	Fail-safe Values	64
5.4.1.1	Overview	64
5.4.2	Timeout Time.....	65
5.4.2.1	Timeout Object Configuration	65
5.5	Discovery over Ethernet	67
5.6	Manage Device Parameters	68
5.7	Backup and Restore Parameters	70

5.8	Restore Factory Settings	73
5.9	Database	73
5.10	Diagnostic Object	73
5.11	Help.....	74
6	EMBEDDED WEB SERVER	76
<hr/>		
6.1	Overview	76
6.2	Monitor Tab	78
6.2.1	Information Window	78
6.2.2	Parameter Group Selection List	78
6.2.3	Parameter List	79
6.2.4	Parameter List Filter.....	81
6.2.5	Radix Selection.....	81
6.3	Dashboard Tab	83
6.3.1	Information Window	84
6.3.2	Gauge Window Navigation.....	84
6.3.3	Gauge Window Configuration	85
6.3.4	Submitting Changes.....	90
6.4	Customizing the Embedded Web Server.....	91
6.4.1	Customization Overview	91

6.4.2	XTPro Overview.....	92
6.4.3	XTPro Web Browser-Based Implementation.....	92
6.4.4	XTPro HMI-Based Implementation.....	94
6.4.5	XTPro Supported Commands.....	95
7	FILESYSTEM	96
<hr/> <hr/>		
7.1	Overview.....	96
7.2	USB with Windows Explorer.....	97
7.3	FTP With Windows Explorer.....	98
7.4	Loading New Web Server Content.....	100
8	FIRMWARE	101
<hr/> <hr/>		
8.1	Overview.....	101
8.2	Update Procedure.....	101
9	PROTOCOL-SPECIFIC INFORMATION	103
<hr/> <hr/>		
9.1	Modbus/TCP Server.....	103
9.1.1	Overview.....	103
9.1.2	Holding & Input Registers.....	104
9.1.3	Coil & Discrete Input Mappings.....	105

9.1.4	Connection Timeout Options.....	106
9.1.5	Node Settings	108
9.1.6	Holding/Input Register Remap Settings	108
9.2	EtherNet/IP Server	110
9.2.1	Overview.....	110
9.2.2	Server Settings	112
9.2.3	Connection Timeout Options.....	112
9.2.4	Generic Class 1 I/O Produced and Consumed Data Settings	114
9.2.5	Generic Class 1 (I/O) Connection Access	116
9.2.6	AC/DC Drive Profile Class 1 (I/O) Connection Access	116
9.2.7	Explicit Messaging Via Get/Set Attribute Single Services.....	123
9.2.8	Explicit Messaging Via Data Table Read/Write Services.....	124
9.2.9	Inverter Register Access Tag Format.....	124
9.2.10	ControlLogix Examples: Setup.....	126
9.2.11	ControlLogix Example: EDS Add-On Profile (AOP).....	127
9.2.11.1	<i>ControlLogix Example: EDS Add-On Profile (AOP) Generic I/O Messaging</i>	133
9.2.11.2	<i>ControlLogix Example: EDS Add-On Profile (AOP) AC/DC Drive Profile</i>	136
9.2.12	ControlLogix Example: I/O Messaging	139
9.2.12.1	<i>ControlLogix Example: Generic Default I/O Add-On Instruction</i>	144
9.2.12.2	<i>ControlLogix Example: AC/DC Drive Profile Add-On Instruction</i>	147
9.2.13	ControlLogix Example: Read Registers.....	151
9.2.14	ControlLogix Example: Reading and Writing Multiple MSG Instructions	157

9.3	Allen Bradley CSP (PCCC) Server.....	160
9.3.1	Overview.....	160
9.3.2	Explicit Messaging Via Read/Write Services.....	160
9.3.3	Inverter Register File Number Offset Format	161
9.3.4	SLC-5/05 Example: Read Registers	164
9.3.5	SLC-5/05 Example: Reading and Writing.....	171
9.4	BACnet/IP Server.....	173
9.4.1	Protocol Implementation Conformance Statement.....	173
9.4.2	Default Supported Objects	183
9.4.3	Default Supported Object Details	187
9.4.4	Server Settings	191
9.4.5	Node Settings	191
9.4.6	Device Object Settings.....	191
9.4.7	BACnet Object Settings	192
9.4.7.1	<i>Analog Input Object Settings</i>	<i>192</i>
9.4.7.2	<i>Analog Output Object Settings</i>	<i>193</i>
9.4.7.3	<i>Analog Value Object Settings</i>	<i>194</i>
9.4.7.4	<i>Binary Input Object Settings</i>	<i>195</i>
9.4.7.5	<i>Binary Output Object Settings</i>	<i>197</i>
9.4.7.6	<i>Binary Value Object Settings.....</i>	<i>199</i>
9.4.7.7	<i>Multi-state Input Object Settings.....</i>	<i>201</i>
9.4.7.8	<i>Multi-state Output Object Settings.....</i>	<i>201</i>
9.4.7.9	<i>Multi-state Value Object Settings.....</i>	<i>202</i>

9.5	MELSEC / SLMP Server	203
9.5.1	Overview.....	203
9.5.2	Read/Write Commands.....	204
9.5.3	Server Settings	205
9.5.4	Connection Timeout Options.....	206
9.6	CC-Link IE Field Basic Server	208
9.6.1	Overview.....	208
9.6.2	Server Settings	209
9.6.3	Produced and Consumed Data Settings	209
9.7	MELSEC Client.....	212
9.7.1	Overview.....	212
9.7.2	Read/Write Commands.....	213
9.7.3	Connection Timeout Options.....	213
9.7.4	Remote Device Settings.....	214
9.7.5	Command and Monitor Data Object Settings	215
9.7.6	Diagnostic Objects	217
9.8	SLMP Client.....	218
9.8.1	Overview.....	218
9.8.2	Read/Write Commands.....	219
9.8.3	Connection Timeout Options.....	219
9.8.4	Remote Device Settings.....	220

9.8.5	Command and Monitor Data Object Settings	221
9.8.6	Diagnostic Objects	223
9.9	PROFINET IO.....	224
9.9.1	Overview.....	224
9.9.2	Device Settings.....	225
9.9.3	Connection Timeout Options.....	225
9.9.4	Cyclic I/O Produced and Consumed Data Access Settings.....	226
9.9.5	PROFIdrive Profile	229
9.9.5.1	<i>PROFIdrive Standard Telegram 1</i>	229
9.9.5.2	<i>PROFIdrive Control and Status Words</i>	230
9.9.5.3	<i>PROFIdrive Reference Speed Setpoint and Actual Speed</i>	234
9.9.5.4	<i>PROFIdrive-Specific Parameters</i>	237
9.9.5.5	<i>PROFIdrive State Diagram</i>	238
9.9.6	Acyclic Data Access.....	239
9.9.7	TIA Portal (STEP 7) Hardware Configuration Example	239
9.9.7.1	<i>Register the GSDML File</i>	239
9.9.7.2	<i>Add the Device to the Configuration</i>	241
9.9.7.3	<i>Select the IO Controller</i>	242
9.9.7.4	<i>Assign the I/O Module</i>	242
9.9.7.5	<i>Configure the Device Properties</i>	243
9.9.7.6	<i>Online Device Discovery and Configuration</i>	246
9.9.7.7	<i>Save the Configuration</i>	248
9.9.8	GE Proficy Configuration Example.....	248
9.9.8.1	<i>Register the GSDML File</i>	248

9.9.8.2	<i>Add the Device to the Configuration</i>	250
9.9.8.3	<i>Configure the Device Properties</i>	252
9.9.8.4	<i>Save the Configuration</i>	253
9.10	IEC 61850 Server	254
9.10.1	Overview	254
9.10.2	Server Settings	254
9.10.3	GOOSE Communication Parameters	255
9.10.4	Generic Process I/O Status and Control Object Settings	256
10	TROUBLESHOOTING	258

1 PRE-OPERATION INSTRUCTIONS

1.1 Product Overview

The A7NETH-V2 Ethernet multiprotocol communication interface allows information to be transferred seamlessly between a 700-series inverter and several different Ethernet-based fieldbus networks with minimal configuration requirements. The interface installs directly onto the inverter's control board, and presents two RJ-45 jacks with an embedded 10BASE-T/100BASE-TX Ethernet switch for connection to the Ethernet network. In addition to the supported fieldbus protocols, the interface also hosts a fully customizable embedded web server, which provides access to inverter information via a standard web browser for remote monitoring and control.

2

Before using the interface, please familiarize yourself with the product and be sure to thoroughly read the instructions and precautions contained in this manual. In addition, please make sure that this instruction manual is delivered to the end user of the interface, and keep this instruction manual in a safe place for future reference or unit inspection.

Note that different interface firmware versions may provide varying levels of support for the various protocols. When using this manual, therefore, always keep in mind that the release date of the firmware version running on your interface as it must match this manual's respective release date in order for all documented aspects to apply.

The A7NETH-V2 may be referred to throughout the remainder of the manual as the device, interface, card, and option or any combination thereof.

**Supported Protocols**

The interface currently provides support for the following fieldbus protocols:

- Modbus/TCP Server
- EtherNet/IP Server (DLR node)
- Allen Bradley CSP Server (also known as “PCCC” and “AB Ethernet”)
- BACnet/IP Server
- Mitsubishi MELSEC / SLMP Server (also known as “MC protocol”)
- CC-Link IE Field Basic Server
- Mitsubishi MELSEC Client
- SLMP Client
- PROFINET IO Device (MRP client)
- IEC 61850 Server

1.2 Features and Specifications

Table 1: Features

Item	Description
Simultaneous Protocols	Supports all standard unmodified Ethernet (SUE) protocols simultaneously
Mitsubishi Configuration Studio	Graphical user interface for discovery, configuration, and firmware update
WEB Server (HTTP)	Access all parameters, dashboard with gauges, customizable with XTPro
Communication Loss Detection	Configurable actions for “fail-safe” conditions
Field Upgradeable	Firmware updates automatically handled by the studio
Parameter Management	Advanced management of parameter access and scan priority
Parameter Backup and Restore	Drive cloning

**Table 2: General Hardware Specifications**

Item	Description
Power Supply	Directly powered by the inverter
Grounding	Referenced to inverter's 5V power supply / isolated from inverter control power common
LED Indicators	Module Status, Network Status, 2 x Ethernet Link/Activity
USB Port	USB 2.0, mini-B 5-pin

Table 3: Ethernet Hardware Specifications

Item	Description
Number of Ports	2 (internal switch)
Standard	IEEE 802.3 10BASE-T/100BASE-TX Ethernet compliant
Communication Speed and Duplex	10Mbps half/full, 100Mbps half/full (auto sense optimal speed and duplex)
Connector Type	RJ-45 Shielded
Auto MDI-X	Yes (supports all straight-through and cross-over cables)
Cable Type	CAT5-type 8-conductor UTP patch cables
Cable Length	100m per segment max
Topologies	Star/Tree, Linear/Bus/Daisy-chain, Ring (MRP / DLR)

Table 4: Modbus/TCP Server Specifications

Item	Description
Conformance Class	Class 0, Class 1 (partial), Class 2 (partial)
Read Function Codes	Read coils (1), Read input status (2), Read multiple registers (3), Read input registers (4), Diagnostics (8)
Write Function Codes	Write coil (5), Write single register (6), Force multiple coils (15), Write multiple registers (16)
Number of Connections	8
Max Read Register Size	125 registers
Max Write Register Size	123 registers
Register Data Type	16-bit integer
Unit (slave) ID	Ignored, echoed in response
TCP Port	502
Response Time	Min 160us, Typically less than 1ms

**Table 5: EtherNet/IP Server Specifications**

Item	Description
Conformance Tested	ODVA EtherNet/IP Conformance Test Software Version CT-13
Product Type Code	2 (AC Drive)
AC/DC Drive Profile	Yes
UCMM	Yes
Class 3 (Explicit) Messaging	Yes
Class 1 (Implicit I/O) Messaging	Yes
Class 1 Unicast T→O	Yes
Class 1 Multicast T→O	Yes
Number of Connections	16 (Total for both Class 1 and Class 3)
RPI	Min 1ms
I/O Input Size	Max 32 input words, user configurable
I/O Output Size	Max 32 output words, user configurable
Generic (User Configurable) Assembly Instances	100 (input) and 150 (output)

Item	Description
AC/DC Drive Profile Assembly Instances	20 (input) and 70 (output), 21 (input) and 71 (output)
Data Table Read/Write	Yes
DLR	Device Level Ring Node
Class 1 UDP Port	2222 (0x08AE)
Explicit Messaging Port	44818 (0xAF12)
Explicit Messaging Response Time	Min 160us, Typically less than 1ms

**Table 6: Allen Bradley CSP (PCCC) Server Specifications**

Item	Description
Read Services	PLC5 Read (DF1 protocol typed read, 0x68), PLC5 Word Range Read (DF1 protocol word range read, 0x01), SLC Read (DF1 protocol protected typed logical read with three address fields, 0xA2)
Write Services	PLC5 Write (DF1 protocol typed write, 0x67), PLC5 Word Range Read (DF1 protocol word range write, 0x00), SLC Read (DF1 protocol protected typed logical write with three address fields, 0xAA)
Data Type	16-bit Integer
File Type	N (Integer)
Logical ASCII Addressing	Yes
Logical Binary Addressing	Yes
Max Read Size	240 bytes (120 16-bit Integers)
Max Write Size	240 bytes (120 16-bit Integers)

Table 7: MELSEC MC Protocol / SLMP Server Specifications

Item	Description
Frame Types	4E (MT), 3E (ST), 1E
Transport Types	TCP/IP, UDP/IP
3E/4E Frame Read Function Codes	CPU Model Name Read (0x0101), Device Memory Batch Read (0x0401, Word units), Device Memory Random Read (0x0403, Word units), Node Search (0x0E30), Device Info Compare (0x0E32), Status Read (0x0E44), Communication Setting Get (0x0E45)
3E/4E Frame Write Function Codes	Device Memory Batch Write (0x1401, Word units), Device Memory Random Write (0x1402, Word units), IP Address Set (0x0E31)
1E Frame Read Function Codes	Device Memory Batch Read (0x01, Word units)
1E Frame Write Function Codes	Device Memory Batch Write (0x03, Word units)
Number of Connections	8
Max Read Points	724 points (varies with function code and frame type)
Max Write Points	719 points (varies with function code and frame type)
3E Device Types	Data Register (0xA8), Link Register (0xB4), Index Register (0xCC), File Register (0xAF and 0xB0)
1E Device Types	Data Register (0x4420), Link Register (0x5720), File Register (0x5220 and 0x5A52)
TCP Port	2009 (Configurable)



Item	Description
UDP Port	2009 (Configurable)
Response Time	Min 160us, Typically less than 1ms

Table 8: CC-Link IE Field Basic Server Specifications

Item	Description
Max Occupied Stations	1
RWw Cyclic Size	Max 32 command words, user configurable
RWr Cyclic Size	Max 32 status words, user configurable
UDP Port	61450
Response Time	Min 160us, Typically less than 1ms

Table 9: MELSEC MC Protocol Client Specifications

Item	Description
Frame Types	4E (MT), 3E (ST), 1E, Auto-Detect
Transport Types	TCP/IP, UDP/IP
3E/4E Frame Read Function Codes	Device Memory Batch Read (0x0401, Word units)
3E/4E Frame Write Function Codes	Device Memory Batch Write (0x1401, Word units)
1E Frame Read Function Codes	Device Memory Batch Read (0x01, Word units)
1E Frame Write Function Codes	Device Memory Batch Write (0x03, Word units)
Number of Connections	8
Max Read Points	719 points (varies with frame type)
Max Write Points	719 points (varies with frame type)
3E Device Types	Any
1E Device Types	Any

**Table 10: SLMP Client Specifications**

Item	Description
Frame Types	4E (MT), 3E (ST), Auto-Detect
Transport Types	TCP/IP, UDP/IP
3E/4E Frame Read Function Codes	Device Memory Batch Read (0x0401, Word units)
3E/4E Frame Write Function Codes	Device Memory Batch Write (0x1401, Word units)
Number of Connections	8
Max Read Points	719 points (varies with frame type)
Max Write Points	719 points (varies with frame type)
3E Device Types	Any

Table 11: PROFINET IO Specifications

Item	Description
Protocol Level	RT (real-time)
RT Conformance Class	Class B
Netload Class	III
I/O Cycle Time	Min 1ms
I/O Input Size	Max 32 input words, user configurable
I/O Output Size	Max 32 output words, user configurable
MRP	Media Redundancy Protocol Client
DCP	Discovery, set station name, set IP address
LLDP	Yes
I&M	I&M0
Alarms	Plug, Pull
Number of Controllers	Allows access to only 1 controller

**Table 12: BACnet/IP Server Specifications**

Item	Description
BACnet IP	Annex J
Protocol Revision	2
Standard Device Profile (Annex L)	BACnet Application Specific Controller (B-ASC)
BACnet Interoperability Building Blocks (BIBB)	ReadProperty-B (DS-RP-B), ReadPropertyMultiple-B (DS-RPM-B), WriteProperty-B (DW-WP-B), Dynamic Device Binding-B (DM-DDB-B), Dynamic object Binding-B (DM-DOB-B)
Segmentation	Not supported
Max APDU Length	1444 bytes
Character Sets	ANSI X3.4
Object Types	Analog Output, Analog Input, Analog Value, Binary Output, Binary Input, Binary Value, Multi-state Output, Multi-state Input, Multi-state Value
Priority Array	Yes
UDP Port	47808 (0xBAC0, configurable)
Response Time	Min 160us, Typical less than 1ms

Table 13: IEC 61850 Server Specifications

Item	Description
Unbuffered Reports	Yes, writeable
GOOSE	Type 1, data set writeable
Dynamic Data Sets	Yes, maximum of 10 data sets
Generic Status Objects	100 MV (Measured Value integers)
Generic Control Objects	100 APC (Controllable Analog Process Value integers)
Authentication	None/Password, configurable

**Table 14: Environmental Specifications**

Item	Specification
Operating Environment	Indoors, less than 1000m above sea level, do not expose to direct sunlight or corrosive / explosive gasses
Operating Temperature	-10 ~ +50°C (+14 ~ +122°F)
Storage Temperature	-40 ~ +85°C (-40 ~ +185°F)
Relative Humidity	20% ~ 90% (without condensation)
Vibration	5.9m/s ² (0.6G) or less (10 ~ 55Hz)
Cooling Method	Self-cooled
RoHS (Lead free)	Yes

1.3 Inverter Compatibility

This product is a plug-in option for the A700, F700, and E700 series inverters. The A700 and F700 inverter model numbers of 55K and 75K stated in this Instruction Manual differ according to -NA, -EC, -CH(T) versions. Refer to the inverter manual to determine the inverter model and confirm that the model is compatible according to the following table. For example, "75K or larger" applies to "FR-A740-01440-NA or higher" in the case of the FR-A740 series of the NA version.

		NA	EC	CH
F700	FR-F720-55K	FR-F720-02330-NA	-	-
	FR-F720-75K	FR-F720-03160-NA	-	-
	FR-F740-55K	FR-F740-01160-NA	FR-F740-01160-EC	FR-F740-55K-CH(T)
	FR-F740-75K	FR-F740-01800-NA	FR-F740-01800-EC	FR-F740-S75K-CH(T)
A700	FR-A720-55K	FR-A720-02150-NA	-	-
	FR-A720-75K	FR-A720-02880-NA	-	-
	FR-A740-55K	FR-A740-01100-NA	FR-A740-01800-EC	FR-A740-55K-CHT
	FR-A740-75K	FR-A740-01440-NA	FR-A740-02160-EC	FR-A740-75K-CHT

This option can be used on FR-F700 series inverters assembled in and after the date indicated below. Check the serial number indicated on the rating plate or package.

- FR-F700 series 55K or lower...in and after October 2004
- FR-F700 series 75K or higher...in and after December 2004



This option can be used with all FR-E700 inverters.

Model	Description	Compatibility
FR-E710W	Single phase 100V, all capacities	December 2008 or later
FR-E720S	Single phase 200V, all capacities	December 2008 or later
FR-E720 (NA)	3-phase, 200V models, all capacities	December 2008 or later
FR-E740 (NA)	3-phase, 400V models, all capacities	December 2008 or later
FR-E720 (SC)	3-phase, safety enabled, 200V models, all capacities	August 2009 or later
FR-E740 (SC)	3-phase, safety enabled, 400V models, all capacities	August 2009 or later

Serial Number Check

Refer to the inverter manual for the location of the rating plate.

Rating plate example

□ Z Y 000000
Symbol Year Month Control number
Serial Number

The serial number consists of 1 Symbol, 2 characters (Year and Month), and 6 numeric characters indicating Control Number. The last digit of the production year is indicated as the Year, and the Month is indicated as 1 to 9, X (October), Y (November), and Z (December).

1.4 Unpacking and Product Confirmation

1.4.1 Shipment Confirmation

Check the enclosed items. Confirm that the correct quantity of each item was received, and that no damage occurred during shipment.



Plug-in option: qty. 1



Communication option LED display cover: qty. 1
(only included in certain kits)



M3x10mm hex head
standoff: qty. 1



M3x20mm flat head
mounting screw: qty. 1



M3x6mm pan head
mounting screw: qty. 1



M3x6mm flat head
mounting screw: qty. 1




Installation on an E700 series inverter requires an optional A7A-EKITCVR-SC cover. Please contact your local distributor for more information.

The included M3x20mm flat head screw is required only when using the interface card on an E700 safety inverter with the A7A-EKITCVR-SC extended cover kit. The A7A-EKITCRV-SC kit includes an M3x20mm pan head screw that incorporates a captive washer. Due to the additional height of the captive washer, however, this screw may result in clearance issues with the overmolding of certain Ethernet cables connected to the interface card's "PORT1" jack. Therefore, the flat head M3x20mm screw included with the interface card kit should be used in this scenario to minimize the possibility of clearance issues.



Optional A7A-EKITCVR-SC Cover

1.4.2 Component Overview

**2**

1.5 LED Indicators

The upper right-hand corner of the option board contains several bi-color LEDs (when included, visible on the LED display cover after mounting) that provide a visual indication of the unit's overall status.



1.5.1 Port Status LED Description

Ethernet Port 1 (P1 LNK/ACT) and Ethernet Port 2 (P2 LNK/ACT)

LED Activity	Status	Note
Green Off	No Link	A valid Ethernet link does not exist: communication is not possible on this port
Green On	Link	A valid Ethernet link exists: communication is possible on this port
Green Blink	Activity	Indicates when a packet is transmitted or received on this port

1.5.2 Standard LED Description

Module Status (MOD STATUS)

LED Activity	Status	Note
Off	Device Off	The inverter power is off
Green Blink, Red Blink	Startup	Startup blink sequence
Green On	Device On	Normal status
Green Blink	Discovery Identification	PROFINET discovery and identification (DCP)
Red Blink	Error Code	Refer to the TROUBLESHOOTING section

2

Network Status (NET STATUS)

LED Activity	Status	Note
Off	Device Off	The inverter power is off
Green Blink, Red Blink	Startup	Startup blink sequence
Green Blink	No Cnxn	EtherNet/IP connection is not established
Green Off	No Cnxn	PROFINET connection is not established
Green On	Cnxn Established	EtherNet/IP or PROFINET connection is established



2 INSTALLATION

2.1 Pre-Installation Instructions

Make sure that the inverter's input power is off.



CAUTION



To avoid damage to the inverter or plug-in option card, never install or remove a plug-in option card while the inverter's input power is on.

Security information

Mitsubishi provides products and solutions that support the operation of plants, systems, machines and networks. In order to protect these critical assets against cyber threats, it is necessary to implement and continuously maintain a holistic, state-of-the-art industrial security concept. Mitsubishi's products and solutions comprise only one element of such a concept.

Customers are solely responsible for preventing unauthorized access to their plants, systems, machines and networks. Systems, machines and components should be connected to the enterprise network or the internet only if appropriate security measures (such as the use of firewalls and network segmentation) are employed to the extent necessary.

Mitsubishi's products and solutions undergo continuous development to make them more secure. Mitsubishi strongly recommends the application of product updates as soon as they are available. The use of product versions that are no longer supported, and the failure to apply the latest available updates may increase the customer's exposure to cyber threats.





2.2 A700 & F700 Installation Procedure

2.2.1 Installation of the Communication Option LED Display Cover

When included in the kit, mount the LED display cover on the inverter front cover.


- 1) Cut off the tabs on the backside of the inverter front cover with a nipper, etc. and open the knockout for the LED display cover.
- 2) Fit the LED display cover into the knockout on the front of the inverter front cover and push it until the tabs lock into place.



⚠ CAUTION

To prevent hand injury, avoid contacting the tabs on the backside of the front cover.

2.2.2 Installation of the Communication Option on Control Board



1) Remove the inverter's front cover.

2) Locate option connector 3 (lowermost connector) and screw the included M3x10mm hex standoff into the corresponding ground plate screw hole (rated torque 0.56Nm to 0.75Nm).

3) Securely attach the option card to the inverter's option connector. Ensure that the option card is fully seated on the inverter's option connector and the hex standoff.

4) Secure the upper-right corner of the option card with the included M3x6mm pan head mounting screw. Secure the lower-left corner of the option card with the included M3x6mm flat head mounting screw. If the screw holes do not line up, the option card connector may not be fully seated on the inverter's option connector and the hex standoff.

2

INSTALLATION




5) Tighten both mounting screws to a torque setting of 0.33 N·m to 0.40 N·m.

REMOVAL

First remove the two M3x6mm mounting screws. Lastly, remove the option board by grasping it on its left and right side and pulling it straight away from the inverter. Note that the removal process may be easier by first removing the inverter's control circuit terminal block.

2.3 E700 Installation Procedure



- 1) Remove the inverter's front cover.
- 2) Securely attach the option card to the inverter's option connector. Ensure that the option card is fully seated on the option connector.
- 3) Secure the upper-left corner of the option card with the included M3x6mm pan head mounting screw. Secure the lower-right corner of the option card with the included M3x20mm flat head mounting screw.
- 4) Tighten both mounting screws to a torque setting of 0.33 N·m to 0.40 N·m.


REMOVAL

First remove the M3x6mm and M3x20mm mounting screws. Lastly, remove the option board by grasping it on its left and right side and pulling it straight away from the inverter.


2

2.4 Wiring


When installing the option card into an FR-A720-00900-NA (FR-A740-00440-NA) or smaller inverter, remove the wiring access knockout on the front cover and route the network cable through the opening. When installing the option card into an FR-A720-01150-NA (FR-A740-00570-NA) or larger inverter, route the network cable through the space adjacent to the control circuit terminal block.



FR-A720-00900-NA (FR-A740-00440-NA)
and smaller



Remove front cover wiring access knockout and trim any excess flashing that may cause cable damage



FR-A720-01150-NA (FR-A740-00570-NA)
and larger

NOTE: If the front cover wiring access knockout is removed, the protective structure (JEM1030) changes to open type (IP00).

CAUTION

Use caution during wiring to prevent any cable fragments and wire strands from falling into the inverter. Equipment damage may result if power is applied to the inverter in the presence of conductive debris.

3 INVERTER SETTINGS

The inverter parameters listed in Table 15 are critical for overall operation of the end-to-end communication system. Some of these parameters must be set to specific values, and some may have multiple allowable settings depending on the desired operation of the overall application. Although there may be many other inverter parameters that will require configuration for your specific application, it is important to understand the manner in which the following parameters will impact successful communications with, and control of the inverter.

Table 15: Inverter Settings

Parameter Number	Name	Refer to Page
79	Operation mode selection	35
338	Communication operation command source	39
339	Communication speed command source	39
340	Communication startup mode selection	35
342	Communication EEPROM write selection	43
550	NET mode control source selection	39
232, 233, 234, 235	IP address	32
236, 237, 238, 239	Subnet mask	32
888, 889	Default gateway address	32



3.1 Network Setting

The network settings can **optionally** be set using the inverter parameters described in the Table 16. An invalid parameter value will void the inverter network parameters and fallback to the network settings created by the Configuration Studio or the default network settings (IP address = 192.168.16.100, Subnet mask = 255.255.255.0, and Default gateway = 192.168.16.3). To avoid invalid configuration, it is therefore recommended to use the configuration studio to modify the network settings. Please consult with your network administrator for the proper settings of these fields.

Table 16: Inverter Network Parameters

Parameter Number	Name
232	IP address (and default gateway address) most significant octet
233	IP address (and default gateway address) high octet
234	IP address low octet
235	IP address least significant octet
236	Subnet mask most significant octet
237	Subnet mask address high octet
238	Subnet mask address low octet
239	Subnet mask address least significant octet
888	Default gateway address low octet
889	Default gateway address least significant octet

IP Address

The IP address is created from the octet values specified in *Pr. 232*, *Pr. 233*, *Pr. 234*, and *Pr. 235*. The value after the decimal point for each parameter value must be 0.

Subnet Mask

The subnet mask is created from the octet values specified in *Pr. 236*, *Pr. 237*, *Pr. 238*, and *Pr. 239*. The value after the decimal point for each parameter value must be 0.

Default Gateway Address

The IP address is created from the octet values specified in *Pr. 232*, *Pr. 233*, *Pr. 888*, and *Pr. 889*. The default gateway address can be “disabled” by setting *Pr. 888* = 0 and *Pr. 889* = 0. If the desired default gateway address cannot be created using *Pr. 888* and *Pr. 889*, the configuration studio must be used to configure the network settings.

Example:

IP address = 192.168.16.100, Subnet mask = 255.255.255.0, Default gateway = 192.168.16.1

Set *Pr. 232* = 192.00, *Pr. 233* = 168.00, *Pr. 234* = 16.00, *Pr. 235* = 100.00, *Pr. 236* = 255.00, *Pr. 237* = 255.00, *Pr. 238* = 255.00, *Pr. 239* = 0.00, *Pr. 888* = 16, and *Pr. 889* = 1.




3.2 Operation Mode Setting

Three operation modes are available when a communication option card is installed into an inverter.

1. PU operation [PU]..... The inverter is controlled by the operating panel (FR-DU07).
2. External operation [EXT] ... The inverter is controlled by the ON/OFF switching of external signals connected to the control circuit terminals (factory default.)
3. Network operation [NET] ... The inverter is controlled from the network via the communication option card (the operating commands and frequency command can be input via the control circuit terminals depending on the settings of *Pr. 338 Communication operation command source* and *Pr. 339 Communication speed command source*. Refer to page 40.)

3.2.1 Operation Mode Indication

FR-DU07



Operation mode indication (the inverter operates in accordance with the indicated LED.)

PU: PU operation mode

EXT: External operation mode

NET: Network operation mode

3.2.2 Operation Mode Switching & Comm. Startup Mode (Pr. 79, Pr. 340)

(1) Operation mode switching conditions

Prior to switching the operation mode, confirm that:

- 1) The inverter is stopped
- 2) Both the STF and STR signals are off
- 3) The *Pr. 79 Operation mode selection* setting is correct. Refer to the appropriate inverter *user's manual (applied)* for further information regarding *Pr. 79*.

(2) Operation mode selection at power on and after recovery from a momentary power failure

The operation mode at power on and after recovery from a momentary power failure can be selected via *Pr. 340*. A value other than "0" will select network operation mode. After activating network operation mode, parameter writes from the network are enabled.

REMARKS

1. When *Pr. 340* is changed, the new setting is validated after powering on or resetting the inverter.
2. *Pr. 340* can be changed via the operation panel regardless of the operation mode.


INVERTER SETTINGS



Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power-On or Power Recovery	Operation Mode Switchover
0 (default)	0 (default)	External operation mode	Switching among external, PU, and NET operation modes is enabled ^{*1}
	1	PU operation mode	PU operation mode fixed
	2	External operation mode	Switching between external and NET operation modes is enabled, switching to PU operation mode is disallowed
	3, 4	External/PU combined operation mode	Operation mode switching is disallowed
	6	External operation mode	Switching among external, PU, and NET operation modes is enabled while running.
	7	X12 (MRS) signal ON.....external operation mode	Switching among external, PU, and NET operation modes is enabled ^{*1}
		X12 (MRS) signal OFF...external operation mode	External operation mode fixed (forcibly switched to external operation mode.)
1, 2	0	NET operation mode	Same as when Pr. 340 = "0"
	1	PU operation mode	
	2	NET operation mode	
	3, 4	External/PU combined operation mode	
	6	NET operation mode	
	7	X12 (MRS) signal ON....NET operation mode	
		X12 (MRS) signal OFF...external operation mode	
10, 12	0	NET operation mode	Switching between PU and NET operation modes is enabled ^{*3}
	1	PU operation mode	Same as when Pr. 340 = "0"
	2	NET operation mode	NET operation mode fixed
	3, 4	External/PU combined operation mode	Same as when Pr. 340 = "0"
	6	NET operation mode	Switching between PU and NET operation modes is enabled while running ^{*3}
	7	External operation mode	Same as when Pr. 340 = "0"


^{*1} The operation mode cannot be directly changed between PU mode and NET mode.

^{*2} *Pr. 340* settings "2" and "12" are mainly used for communication operation using the inverter's RS-485 port. When a value other than "9999" (automatic restart after momentary power failure) is set in *Pr. 57 Restart coasting time*, the inverter will resume the same operation state which it was in prior to a momentary power failure is such a failure occurs. When *Pr. 340* is set to "1" or "10" and a start command is active, then the start command will be deactivated if a momentary power failure occurs.


^{*3} The operation mode can be changed between PU mode and NET mode with the  key on the operating panel (FR-DU07) and X65 signal.

(3) Operation mode switching method

When "0, 1, or 2" is set in Pr. 340



When "10 or 12" is set in Pr. 340



For a switching method via external terminal input signals, refer to the inverter's *user's manual (applied)*.



- When starting the inverter in NET mode upon powering-up or after an inverter reset, set a value other than 0 in Pr. 340. (Refer to page 35).
- When setting a value other than 0 in Pr. 340, make sure that the initial settings of the inverter are correct.

3.3 Operation & Speed Command Source (Pr. 338, Pr. 339, Pr. 550)

(1) Select control source for NET mode (Pr. 550)

The control location for NET mode can be selected to be from either the inverter's RS-485 port or a plug-on communication option card. Therefore, to control the inverter via the option card, Pr. 550 must be set to either "9999" (default) or "0" (Communication option input valid).

Parameter Number	Name	Default Value	Setting Range	Description
550	NET mode operation command source selection	9999	0	Communication option card control is valid (A7NETH-V2 control is valid.)
			1	Control via the inverter's RS-485 port (A7NETH-V2 control is invalid.)
			9999	Communication option automatic recognition. Normally, control via the inverter's RS-485 port is valid. When an A7NETH-V2 communication option card is installed, that communication option card's control is made valid instead of the inverter's RS-485 port.

Refer to the inverter's *user's manual (applied)* for further details.


(2) Selection of control source for NET mode (Pr. 338, Pr. 339)

Control sources can be subdivided into two separate realms: 1) operation commands such as start/stop signals, etc. and 2) the speed command source that determines the inverter's frequency command. The various combinations of these realms that can be configured are summarized in the following table.

Control Location Selection	<i>Pr. 338 Communication operation command source</i>		0:NET			1:External			Remarks		
	<i>Pr. 339 Communication speed command source</i>		0:NET	1: External	2: External	0:NET	1: External	2: External			
Fixed functions (Functions equivalent to terminals)	Running frequency from communication		NET	—	NET	NET	—	NET			
	Terminal 2		—	External	—	—	External	—			
	Terminal 4		—	External		—	External				
	Terminal 1		Compensation								
Selective functions <i>Pr. 178 to Pr. 189 settings</i>	0	RL	Low-speed operation command/remote setting clear		NET	External		NET	External	<i>Pr. 59 = "0" (multi-speed) Pr. 59 = "1, 2" (remote)</i>	
	1	RM	Middle-speed operation command/remote setting deceleration		NET	External		NET	External		
	2	RH	High-speed operation command/remote setting acceleration		NET	External		NET	External		
	3	RT	Second function selection			NET		External			
	4	AU	Terminal 4 input selection			—	Combined		—	Combined	
	5	JOG	Jog operation selection			—		External			
	6	CS	Automatic restart after instantaneous power failure selection			External					
	7	OH	External thermal relay input			External					
	8	REX	15-speed selection			NET	External		NET	External	<i>Pr. 59 = "0" (multi-speed)</i>
	9	X9	Third function			NET		External			
10	X10	Inverter operation enable signal			External						

Control Location Selection	Pr. 338 Communication operation command source		0:NET			1:External			Remarks	
	Pr. 339 Communication speed command source		0:NET	1: External	2: External	0:NET	1: External	2: External		
Selective functions Pr. 178 to Pr. 189 settings	11	X11	FR-HC connection, instantaneous power failure detection		External					
	12	X12	PU operation external interlock		External					
	13	X13	External DC injection brake operation is started		NET		External			
	14	X14	PID control valid terminal		NET	External		NET	External	
	15	BRI	Brake opening completion signal		NET		External			
	16	X16	PU operation-external operation switching		External					
	17	X17	Load pattern selection forward rotation reverse rotation boost		NET		External			
	18	X18	V/F swichover		NET		External			
	19	X19	Load torque high speed frequency		NET		External			
	20	X20	S-pattern acceleration/deceleration C switching terminal		NET		External			
	22	X22	Orientation command *1		NET		External			
	23	LX	Pre-excitation		NET		External			
			Output stop		Combined		External		Pr. 79 ≠ "7"	
	24	MRS	PU operation interlock		External				Pr. 79 = "7" When the X12 signal is not assigned	
	25	STOP	Start self-holding selection		—		External			
	26	MC	Control mode swichover		NET		External			
	27	TL	Torque limit selection		NET		External			
	28	X28	Start time tuning		NET		External			
	37	X37	Traverse function selection		NET		External			
	42	X42	Torque bias selection 1 *1		NET		External			
43	X43	Torque bias selection 2 *1		NET		External				
44	X44	P/PI control swichover		NET		External				



Control Location Selection	Pr. 338 Communication operation command source		0:NET			1:External			Remarks	
	Pr. 339 Communication speed command source		0:NET	1: External	2: External	0:NET	1: External	2: External		
Selective functions Pr. 178 to Pr. 189 settings	50	SQ	Sequence start	Combined			External			
	60	STF	Forward rotation command	NET			External			
	61	STR	Reverse rotation command	NET			External			
	62	RES	Reset	External						
	63	PTC	PTC thermistor selection	External						
	64	X64	PID forward rotation action switchover	NET	External		NET	External		
	65	X65	PU/NET operation switchover	External						
	66	X66	NET/external operation switchover	External						
	67	X67	Command source switchover	External						
	68	NP	Conditional position pulse train sign *1	External						
	69	CLR	Conditional position droop pulse clear *1	External						
	70	X70	DC feeding operation permission	NET			External			
71	X71	DC feeding cancel	NET			External				

*1: Available only when used with the FR-A7AP.

[Table explanation]

External..... Only external terminal input control is valid.

NET Only network control is valid.

Combined..... Either external terminal input control or network control is valid.

- Both external terminal input control and network control are invalid.

Compensation..... External terminal input control is only valid if Pr. 28 Multi-speed input compensation is set to "1".

3.4 Communication EEPROM Write Selection (*Pr. 342*)

When parameters are written via communications, by default both volatile RAM and nonvolatile EEPROM contents are modified. Due to the limited write cycle lifetime of EEPROM memory, however, it may be desirable to modify only the contents of RAM when frequent parameter writes via communications are necessary.

Parameter Number	Name	Default Value	Setting Range	Description
342	Communication EEPROM write selection	0	0	Parameter values modified via communications are written to both EEPROM and RAM.
			1	Parameter values modified via communications are written only to RAM.

When frequently modifying parameter values via communications, change the value of *Pr. 342* to a "1" in order to write them only to RAM. Performing frequent parameter writes to EEPROM will shorten the lifetime of the component.

REMARKS

When *Pr. 342* is set to a value of "1" (write to RAM only), powering off the inverter will erase the changed parameter values. Therefore, the parameter values available when power is switched on again are those that were previously stored in EEPROM.



4 REGISTER NUMBERING AND BEHAVIOR

4.1 Register Numbers

All accessible inverter parameters are referenced by their register number as defined in Table 17 and can be conveniently referenced in the configuration studio (section 5.6) and the embedded web server (section 6.2.3). Note that the register list is not exhaustive, the registers may not exist for all inverters, and the register data contents may vary depending on the inverter. The register numbers are used when accessing and configuring registers via an Ethernet protocol. Information regarding the command registers (1 to 7) and monitor registers (100 and 101) are included in this manual for user convenience, but more information can be found in the inverter user manual “Mitsubishi inverter protocol” section. Monitor registers 201 to 254 are documented in the inverter user manual “Monitor description list”. For information regarding the remaining inverter parameters, refer to the inverter user manual “Parameter List”.

Note that not all of the available registers that exist in the interface card’s register map have corresponding parameters that exist in the inverter. In other words, if a read from or write to a register that does not correspond to an existing inverter register/parameter takes place, the read/write may be successful (depending on the specific register accessed; refer to section 4.2), but the data will have no meaning. This feature is beneficial in situations where the accessing of non-contiguous registers can be made more efficient by accessing an all-inclusive block of registers (some of which correspond to inverter parameters and some of which do not), while only manipulating those in your local programming that are known to exist.

**Table 17: Register Parameter List**

Register	Description
1	Command register (refer to section 4.3)
2	Frequency command (RAM) (refer to section 4.4)
3	Frequency command (EEPROM) (refer to section 4.4)
4	Operation mode setting (refer to section 4.5)
5	Inverter reset (refer to section 4.6)
6	Alarm history clear (refer to section 4.7)
7	All parameter clear (refer to section 4.8)
100	Inverter status (refer to section 4.9)
101	Operation mode status (refer to section 4.10)
201	Output frequency
202	Output current
203	Output voltage
205	Frequency setting
206	Running speed
207	Motor torque
208	Converter output voltage
209	Regenerative brake duty
210	Electronic thermal relay function load factor
211	Output current peak value
212	Converter output voltage peak value



Register	Description
213	Input power
214	Output power
215	Input terminal status
216	Output terminal status
217	Load meter
218	Motor excitation current
219	Position pulse
220	Cumulative energization time
222	Orientation status
223	Actual operation time
224	Motor load factor
225	Cumulative power
226	Torque command
227	Torque current command
228	Motor output
229	Feedback pulse
250	Power saving effect
251	Cumulative saving power
252	PID set point
253	PID measured value
254	PID deviation value
501	Alarm history 1 – Most recent alarm (refer to Table 22)



Register	Description
502	Alarm history 2 (refer to Table 22)
503	Alarm history 3 (refer to Table 22)
504	Alarm history 4 (refer to Table 22)
505	Alarm history 5 (refer to Table 22)
506	Alarm history 6 (refer to Table 22)
507	Alarm history 7 (refer to Table 22)
508	Alarm history 8 – Least recent alarm (refer to Table 22)
1000 to 1889	<i>Pr. 0 to Pr. 889.</i> To calculate the register number, add 1000 to the parameter number. For example, <i>Pr. 123</i> is register 1123 (123 + 1000).

4.2 Scanned Registers

All registers are constantly being “scanned” by the interface card, which is to say that they are constantly being read and/or written (as applicable), and their current values are therefore mirrored in the interface card’s internal memory.

The principle disadvantage of scanned registers is that write data checking is not available. This means that when the value of a scanned register is modified via a network protocol or via the web browser’s monitor tab, the interface card itself is not able to determine if the new value will be accepted by the inverter (the value may be out-of-range, or the inverter may be in a state in which it will not accept new values being written via communications, etc.) For example, if a write is performed to a scanned command register with a data value that is out-of-range, the interface card will not generate a



corresponding error. However, the register can be read over the network at a later time to confirm whether or not that the written value “took hold” in the inverter.

Even if an inverter parameter corresponding to a given scanned register does not exist, the interface card still maintains a placeholder location in its internal mirroring memory for that register. This feature allows for the block access of non-contiguous registers as described in section 4.1.



4.3 Inverter Command Register

The command word is register 1 and the bit-mapping is described in Table 18. Refer to the specific inverter user manual to confirm the bit-mapping and signal settings.

Table 18: Inverter Command Register

Item	Description	Example
Run command (extended)	b0:AU (current input selection) ⁻¹ b1:Forward rotation command b2:Reverse rotation command b3:RL (low speed operation command) ⁻¹ b4:RM (middle speed operation command) ⁻¹ b5: RH (high speed operation command) ⁻¹ b6:RT (second function selection) ⁻¹ b7:MRS (output stop) ⁻¹ b8:JOG (Jog operation) ⁻² b9:CS (selection of automatic restart after instantaneous power failure) ⁻² b10: STOP (start self-holding) ⁻² b11:RES (reset) ⁻² b12:— b13:— b14:— b15:—	[Example 1] H0002 Forward rotation b15 b0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 [Example 2] H0800 low speed operation (When Pr. 189 RES terminal function selection is set to "0") b15 b0 0 0 0 0 0 1 0 0 0 0 0 0 0 0 0 0 0 0

⁻¹ The signal within parentheses is the initial setting. The description changes depending on the setting of Pr. 180 to Pr. 184, Pr. 187 (input terminal function selection).

⁻² The signal within parentheses is the initial setting. Since jog operation/selection of automatic restart after instantaneous power failure/start selfholding/reset cannot be controlled by the network, bit 8 to bit



11 are invalid in the initial status. When using bit 8 to bit 11, change the signals with *Pr. 185*, *Pr. 186*, *Pr. 188*, *Pr. 189* (input terminal function selection).

4.4 Frequency Command Register

The frequency command (RAM) is register 2 and the frequency command (EEPROM) is register 3. The frequency is in 0.01Hz increments. If *Pr. 37* = 1 to 9998 or *Pr. 144* = 2 to 10, 102 to 110, these registers will specify the speed (in 1RPM increments.)



4.5 Operation Mode Register

The operation mode is register 4 and the modes are described in Table 19. Because this write-only inverter register cannot be read by the interface card, there are no guarantees that the interface card's local value matches the current mode command value in the inverter. Resetting a faulted inverter, for example, may change its internal operation mode (commanded), but the operation mode (commanded) residing in the interface card's memory will be unchanged from the last written value in such a scenario. It is important to remember, therefore, that the interface card only has knowledge of the last written operation mode (commanded), which may or may not equal the inverter's current internal operation mode (commanded). The operation mode status register can be read at any time to confirm the inverter's current operation mode (refer to section 4.10).

Table 19: Inverter Operation Mode Register

Item	Data Description
Operation mode	H0000: Network operation H0001: External operation H0002: PU operation (RS-485 communication operation via PU connector)

4.6 Inverter Reset Register

The inverter reset register is register 5. A value of 0x9696 or 0x9966 will reset the inverter.



4.7 Alarm History Clear Register

The alarm history clear is register 6. A value of 0x9696 will clear the alarm history.

4.8 All Parameter Clear Register

The all parameter clear is register 7. Refer to Table 20 for the appropriate value.

Table 20: All Parameter Clear Register

Pr. Data	Communi- cation Pr. *1	Calibration Pr. *2	Other Pr. *3	HEC HF3 HFF
H9696	○	×	○	○
H9966	○	○	○	○
H5A5A	×	×	○	○
H55AA	×	○	○	○

*1 Refer to communication related parameters.

*2 Refer to the list of calibration parameters.

*3 *Pr. 75* is not cleared.

4.9 Inverter Status Register

The inverter status is register 100 and the bit-mapping is described in Table 21. Refer to the specific inverter user manual to confirm the bit-mapping and signal settings.

Table 21: Inverter Status Register

Item	Instruction Code	Bit Length	Description	Example																																		
Inverter status monitor (extended)	H79	16bit	b0:RUN (inverter running) * b1:Forward rotation b2:Reverse rotation b3:SU (up to frequency) * b4:OL (overload) * b5:IPF (instantaneous power failure) * b6:FU (frequency detection) * b7:ABC1 (alarm) * b8:ABC2 (—)* b9:— b10:— b11:— b12:— b13:— b14:— b15: Alarm occurrence	[Example 1] H0002...During forward rotation b15 <table border="1" style="width:100%; text-align:center;"> <tr> <td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td> </tr> </table> b0 [Example 2] H8080...Stop at alarm occurrence b15 <table border="1" style="width:100%; text-align:center;"> <tr> <td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td> </tr> </table> b0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0																						
1	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0																						

* The signal within parentheses is the initial setting. The description changes depending on the setting of Pr. 190 to Pr. 196 (output terminal function selection).



4.10 Operation Mode Status Register

The operation mode status is register 101 and the bit-mapping is described in Table 19.

4.11 Alarm History Codes

The alarm history codes are listed in Table 22. The alarm codes are described in the inverter user manual “List of alarm display” section.

Table 22: Alarm History Codes

Value	Code	Value	Code	Value	Code	Value	Code	Value	Code
0x00	No Alarm	0x51	E.UVT	0xB0	E.PE	0xC8	E.USB	0xDB	E.MB7
0x10	E.OC1	0x52	E.ILF	0xB1	E.PUE	0xD0	E.OS	0xD9	E.MB5
0x11	E.OC2	0x60	E.OLT	0xB2	E.RET	0xD1	E.OSD	0xDC	E.EP
0x12	E.OC3	0x70	E.BE	0xB3	E.PE2	0xD2	E.ECT	0xF1	E.1
0x20	E.OV1	0x80	E.GF	0xC0	E.CPU	0xD3	E.OD	0xF2	E.2
0x21	E.OV2	0x81	E.LF	0xC1	E.CTE	0xD5	E.MB1	0xF3	E.3
0x22	E.OV3	0x90	E.OHT	0xC2	E.P24	0xD6	E.MB2	0xF5	E.5
0x30	E.THT	0x91	E.PTC	0xC4	E.CDO	0xD7	E.MB3	0xF6	E.6
0x31	E.THM	0xA0	E.OPT	0xC5	E.IOH	0xD8	E.MB4	0xF7	E.7
0x40	E.FIN	0xA1	E.OP1	0xC6	E.SER	0xD9	E.MB5	0xFB	E.11
0x50	E.IPF	0xA3	E.OP3	0xC7	E.AIE	0xDA	E.MB6	0xFD	E.13

5 MITSUBISHI CONFIGURATION STUDIO

5.1 Overview




Figure 1: Mitsubishi Configuration Studio



The card is discovered, configured and updated by the Mitsubishi Configuration Studio PC application. The studio must be installed prior to connecting a card to ensure that the appropriate USB drivers are installed. The studio will typically require a USB connection for reading/writing a configuration and updating the firmware. Depending on the currently-active drivers, remote discovery, network setting, and firmware updates are also possible via Ethernet. The latest release of the Configuration Studio can be downloaded from the [product web page](#). The remainder of this section will provide only a brief introduction to the configuration concepts. For protocol-specific configuration, refer to the relevant protocol section.

Creating a Device Configuration

A device can be added to the **Project** panel for configuration by first selecting the **Device Configurations** list heading and then:

- Double-clicking on the device in the **Available Devices** panel.
- Right-clicking on the device in the **Available Devices** panel and choosing **Add** from the context-sensitive menu.
- Hitting the <ENTER> key on the keyboard when the device is selected in the **Available Devices** panel.
- Dragging the device from the **Available Devices** panel into the **Project** panel.
- Selecting it and selecting **Add Selected Device** from the **Edit** menu.
- Selecting it and clicking the **Add** button in the toolbar.

The device will then be added to the list of **Device Configurations**.

Going Online with a Device

All connected devices are automatically added to the **Discovered Devices** panel. This panel is shown by selecting the **Online Devices** list heading in the **Project** panel. To go online with a device:

- Double-click on it in the **Discovered Devices** panel.
- Right-click on it in the **Discovered Devices** panel and choose **Go Online** from the context-sensitive menu.
- Hit the <ENTER> key on the keyboard when the device is selected in the **Discovered Devices** panel.
- Drag it from the **Discovered Devices** panel into the **Project** panel.
- Select it and select **Go Online with Device** from the **Edit** menu.
- Select it and click the **Go Online** button in the toolbar.

When the studio goes online with a device, its configuration is automatically read. While the studio is online with a device, it will appear in green text in the **Discovered Devices** panel. The studio may be online with multiple devices simultaneously.

Uploading a Device's Configuration into a Project

The current configuration of an online device can be uploaded into the **Project** panel by selecting a device under the **Online Devices** list heading and then:

- Right-clicking on it and choosing **Upload Configuration** from the context-sensitive menu.
- Dragging it from the **Online Devices** heading into the **Device Configurations** heading.
- Selecting it and selecting **Upload Configuration to Project** from the **Device** menu.



- Selecting it and clicking the **Upload Configuration** button in the toolbar.

The device's configuration will then be added to the list of **Device Configurations**. Once the configuration is uploaded into the project, it may be modified.

Removing a Device Configuration from a Project

A configuration can be removed from a project by:

- Selecting the device in the **Project** panel and dragging it. A trash can icon will appear at the bottom of the **Project** panel, and dragging and dropping the device in the trash will remove it from the project.
- Hitting the <DELETE> key on the keyboard when the device is selected in the **Project** panel.
- Right-clicking on the device in the **Project** panel and choosing **Remove** from the context-sensitive menu.
- Selecting **Remove Selected Item** from the **Edit** menu when the device is selected.
- Clicking on the **Remove** button in the toolbar when the device is selected.

Going Offline with a Device

To go offline with a device:

- Select the device in the **Project** panel and drag it. A trash can icon will appear at the bottom of the **Project** panel, and dragging and dropping the device in the trash will go offline with it.
- Hit the <DELETE> key on the keyboard when the device is selected in the **Project** panel.

- Right-click on the device in the **Project** panel and choose **Go Offline** from the context-sensitive menu.
- Select **Go Offline with Device** from the **Edit** menu when the device is selected.
- Click on the **Go Offline** button in the toolbar when the device is selected.

Downloading a Configuration to a Device

To download a configuration to an online device, first select the device under the **Device Configurations** heading in the **Project** panel, and then navigate to **Device...Download Configuration to Device**. If the studio is currently online with only one compatible device, then the configuration will be downloaded to the online device. Otherwise, a device selection prompt is displayed to select which device to download the configuration to. Do not power off the device or interrupt the connection once the download is in progress as this may corrupt the firmware and/or the configuration.

Updating Firmware

The studio automatically manages firmware updates when going online with a device and downloading a configuration to a device. Download the latest studio from the [product web page](#) to obtain the latest firmware. Do not power off the device or interrupt the connection once the update is in progress as this may corrupt the firmware and/or the configuration.

Resetting an Online Device

To reset an online device, first select the device in the **Project** panel and then navigate to **Device...Reset Device**.



General Configuration Process

To configure a device, add the desired protocol(s) and configure any objects associated with the respective protocol(s). Any changes will take effect once the configuration is downloaded to a device.

Note that numeric values can be entered not only in decimal but also in hexadecimal by including “0x” before the hexadecimal number.

5.2 General Object Editing Activities

The following editing activities apply for all types of configuration objects and project elements.

Adding an Object

To add an object, click on an item (protocol driver or Node, for example) in the **Project** panel. Any available objects for that item will be listed in the **Available Objects** panel (the panel title depends on the currently-selected item). An object can then be added to the item by:

- Double-clicking on it.
- Right-clicking on it and choosing **Add** from the context-sensitive menu.
- Hitting the <ENTER> key on the keyboard when the object is selected.
- Dragging it into the **Project** panel.
- Selecting it and selecting **Add Selected Device** from the **Edit** menu.
- Selecting it and clicking the **Add** button in the toolbar.

The object's configurable fields can then be populated with valid values (where applicable).

Viewing an Object

In the **Project** panel, select a parent object to display a summary of all its child objects. For example, selecting a protocol driver will display the driver's configuration in the **Summary** panel and list of current objects in the **Object List** panel.

Updating an Object

To update an object, select the object in the **Project** panel and make any required changes in the **Settings** panel.

Deleting an Object

An object can be deleted by performing one of the following actions:

- Selecting the object in the **Project** panel and dragging it. A trash can icon will appear at the bottom of the **Project** panel, and dragging the object to the trash will then delete it from the project.
- Hitting the <DELETE> key on the keyboard when the object is selected in the **Project** panel.
- Right-clicking on the object in the **Project** panel and choosing **Remove** from the context-sensitive menu.
- Selecting **Remove Selected Item** from the **Edit** menu when the object is selected.
- Clicking on the **Remove** button in the toolbar when the object is selected.

Note that this action cannot be undone. Deleting an object will also delete all of its child objects.



Copying and Pasting an Object

To copy an object, first click on an item in the **Project** panel. An object can then be copied by:

- Right-clicking on it and choosing **Copy** from the context-sensitive menu.
- Pressing the <CTRL+C> keys on the keyboard.
- Holding the <CTRL> key and dragging the item to the desired location in the **Project** panel.
- Dragging the item to a new location under a different parent object in the **Project** panel.
- Selecting **Copy Selected Item** from the **Edit** menu.
- Clicking on the **Copy** button in the toolbar.

To paste an object, first click on an item at the desired location in the **Project** panel. An object can then be pasted by:

- Right-clicking on it and choosing **Paste** from the context-sensitive menu.
- Pressing the <CTRL+V> keys on the keyboard.
- Dropping an item onto the desired location in the **Project** panel after holding the <CTRL> key and dragging the item.
- Dropping an item onto a new location under a different parent object in the **Project** panel after dragging the item.
- Selecting **Paste Item** from the **Edit** menu.
- Clicking on the **Paste** button in the toolbar.

After pasting an object, the object's configurable fields can then be modified with valid values (where applicable).

Note that the studio allows you to copy and paste items between different locations, including different devices. This is useful for copying partial configurations from one device to another.

Reordering Objects

Objects can be reordered in the **Project** panel by dragging the item to the desired location. If the item is dragged outside of the items in the project tree, it will be moved to the end.

5.3 Ethernet Settings

The **Ethernet Settings** panel contains Ethernet-related items that are not specific to any given protocol. These settings must be appropriately configured regardless of any Ethernet control protocols that may be enabled. The **Ethernet Settings** panel is then available whenever the **Ethernet** port is selected in the **Project** panel.

5.3.1 Authentication

Be sure to make a note of the new settings whenever authentication credentials are changed, as they must be entered whenever the web page is accessed or an FTP session is initiated.

User Name

The username is case-sensitive and can contain letters (“a...z” and “A...Z”) and numbers (“0...9”).



Password

The password is case-sensitive and can contain letters (“a...z” and “A...Z”) and numbers (“0...9”).

5.3.2 Network Configuration

The card supports a static IP address. The IP Address, Subnet Mask and Default Gateway fields must be configured. Please consult with your network administrator for the proper settings of these fields.

5.4 Internal Logic Settings

5.4.1 Fail-safe Values

5.4.1.1 Overview

The card can be configured to perform a specific set of actions when network communications are lost (timeout event). This allows each inverter parameter to have its own unique “fail-safe” condition in the event of network interruption. Support for this feature varies depending on the protocol: refer to the protocol-specific section of this manual for further information.

There are two separate elements that comprise the timeout configuration:

- The timeout time
- Timeout Object configuration

5.4.2 Timeout Time

The timeout time is the maximum number of milliseconds for a break in network communications before a timeout will be triggered. This timeout setting is configured at the protocol level as part of a driver's configuration, and used by the protocol drivers themselves to determine abnormal loss-of-communications conditions. These conditions then trigger timeout processing events. If it is not desired to have a certain protocol trigger timeout processing events, then the protocol's timeout time may be set to 0 (the default value) to disable this feature.

For some protocols, the timeout time is set by the master device (PLC, scanner, etc.), and a timeout time setting is therefore not provided in the Configuration Studio's driver configuration. Additionally, not all protocols support timeout detection: refer to the protocol-specific sections of this manual for more information.

5.4.2.1 Timeout Object Configuration

A timeout object is used as part of the timeout processing to set certain parameters to "fail-safe" values. When a timeout event is triggered by a protocol, the timeout objects are parsed and written to the corresponding parameter(s). To add a timeout object, select the device in the **Project** panel, then add **Internal Logic...Fail-safe Values...Timeout Object**. The following paragraphs describe the configurable fields of a timeout object:

Description

This field is strictly for user reference: it is not used at any time by the device.



Register

Enter the register number (refer to section 4) corresponding to the inverter parameter.

Data Type

This is the size of valid values and is fixed to “16-Bit Unsigned” allows for a range of timeout values between 0 and 65535.

Value

Enter the “fail-safe” timeout value that the register encompassed by this timeout object will be automatically written with upon processing a timeout event triggered by a protocol.

5.5 Discovery over Ethernet

Depending on the currently-enabled driver, the Configuration Studio will automatically discover the device on the current Ethernet network, regardless of whether or not the card's network settings are compatible with the subnet upon which they reside. All connected devices are automatically added to the **Discovered Devices** panel. This panel is shown by selecting the **Online Devices** list heading in the **Project** panel. In the **Discovered Devices** panel, discovered Ethernet devices will be listed under **Ethernet** and will display the firmware version in brackets and the current IP address in parentheses to the right of the device name, similar to Figure 2.




Figure 2: Studio Discovery over Ethernet

In order for the studio to discover devices, certain UDP Ethernet traffic (port 4334) must be allowed in and out of the computer, and firewall applications (such as Windows Firewall) are often configured to block such traffic by default. If the studio is unable to discover any devices on the current subnet, be sure to check the computer's firewall settings during troubleshooting, and add the studio as a program exception to the firewall configuration if necessary. It may be necessary to restart your PC before the new firewall configuration can take effect.



The network settings of a discovered card can be configured remotely by:

- Right-clicking on the device in the **Project** panel and choosing **Configure Network Settings...** from the context-sensitive menu.
- Selecting the device in the **Project** panel and navigating to **Device...Configure Network Settings...**

The network settings pop-up should appear similar to Figure 3. Modify the network settings as necessary and click the OK button for the changes to take effect. Note that this will cause the device to become temporarily inaccessible and may fault the inverter.




Figure 3: Remotely Configure Network Settings

5.6 Manage Device Parameters

The accessibility and scan priority of the inverter parameters can be adjusted (refer to Figure 4). This is an advanced feature and must only be used after consulting technical support to determine the appropriate settings for the target application. The **Manage Device Parameters** configuration window is found by:

- Right-clicking on the device in the **Project** panel and choosing **Manage Parameters...** from the context-sensitive menu.
- Selecting the device in the **Project** panel and navigating to **Device...Manage Device Parameters...**

A parameter is accessible and actively scanned (read from and written to the inverter) only if its corresponding checkbox is enabled. Likewise, a parameter is inaccessible if its checkbox is disabled.

Parameters that are accessed more frequently or require a faster update rate should be set to high priority. All other parameters should be set to low priority.





Figure 4: Manage Device Parameters




5.7 Backup and Restore Parameters

The parameter values can be backed up from the inverter and restored to the inverter (refer to Figure 5 and Figure 6). This allows for easy inverter cloning. The backup parameter values are stored as a CSV file. A parameter value can be excluded by disabling the corresponding checkbox. The parameter value can also be modified before the backup and restore is executed. Note that backup and restore does not modify the parameter list (refer to section 5.6). The backup and restore parameter configurations are found by:

- Right-clicking on the device in the **Project** panel and choosing **Backup Parameters...** or **Restore Parameters...** from the context-sensitive menu.
- Selecting the device in the **Project** panel and navigating to **Device...Backup Parameters from Device...** or **Restore Parameters to Device...**


Figure 5: Backup Parameters


Figure 6: Restore Parameters

5.8 Restore Factory Settings

The interface card (connected via USB) can be restored to the factory settings. Note that the filesystem will be reformatted, which will destroy all custom modifications and configurations. Please backup the configuration before executing this feature. The factory settings can be restored by:

- Right-clicking on the device in the **Project** panel and choosing **Restore Factory Settings**.
- Selecting the device in the **Project** panel and navigating to **Restore Factory Settings**.

5.9 Database

To interact in real-time with inverter parameters, select the online device in the **Project** panel and then select the **Database** panel. Parameter values can be edited by double-clicking the desired location in the database. If the **Database** panel is not visible, it can be enabled via **View...Database**.

5.10 Diagnostic Object

Diagnostic objects are optional and can only be added to specific protocol objects.

TX Counter

A 32-bit counter that increments when the driver transmits a packet.

RX Counter

A 32-bit counter that increments when the driver receives a valid packet.

RX Error Counter

A 32-bit counter that increments when the driver receives an error response packet, or when an error occurs upon reception of a packet.

Current Status

Indicates the status of the most-recently received packet. This field is updated each time the “RX Counter” or “RX Error Counter” increments. Refer to Table 23 for a list of supported codes.

Last Error

Indicates the last reception error that occurred. This field is updated each time the “RX Error Counter” increments. Refer to Table 23 for a list of supported codes.

5.11 Help

For assistance in understanding configuration objects and fields, simply hover the mouse over the object or text to display a useful tooltip. Ensure that the **Help...Show Help Tooltips** option is checked.

Table 23: Diagnostic Codes

Diagnostic Code (Hex)	Description
0x00	No Error
0xE0	No Connection
0xF0	Invalid Data Address
0xF1	Data Error
0xF2	Write To Read-Only
0xF3	Read From Write-Only
0xF4	Target Busy
0xF5	Target Error
0xF6	Cannot Execute
0xF7	Mode Error
0xF8	Other Error
0xF9	Memory Error
0xFA	Receive Error
0xFB	Invalid Function
0xFC	Invalid Packet
0xFD	Security Error
0xFE	Checksum Error
0xFF	Timeout Error

Links to videos and documents can be found in the **Help** menu. Please review the tooltips and links before contacting technical support for more in-depth assistance.




6 EMBEDDED WEB SERVER

6.1 Overview

The interface contains an embedded (HTTP) web server, which allows users to access the inverter's internal data in a graphical manner with web browsers such as Microsoft Internet Explorer or Mozilla Firefox. In this way, the inverter can be monitored and controlled from across the room or from across the globe. To access an interface's embedded web server, directly enter the target unit's IP address into the address (URL) field of your web browser. Refer to Figure 7 for a representative screenshot of the web server interface. In order to access the web server and view the parameter values, destination TCP ports 80 and 843 must be accessible from the client computer.

Note that in order to view the interface's web page, the free Adobe Flash Player browser plug-in is required. The plug-in can be downloaded from <http://www.adobe.com>.


Figure 7: Embedded Web Server



6.2 Monitor Tab

6.2.1 Information Window



Figure 8: Monitor Tab Information Window

Figure 8 shows the Information Window, which displays messages regarding the status of the interface card or web browser session. There is also an “ACTIVITY” indicator which blinks periodically to show the status of data communication between the web browser and the interface card. If you do not observe the activity indicator blink at all for several seconds or more, it is possible that the web browser may have lost contact to the web server. To reestablish communications, “refresh” your web browser.

6.2.2 Parameter Group Selection List

The Parameter Group Selection List is shown in Figure 9. Individual groups can be selected by clicking on the group name. Multiple groups may also be selected by holding down the CTRL key while clicking on the group names, or a range of groups can be selected by first selecting the starting




Figure 9: Parameter Group Selection List

group, and then holding down the SHIFT key while selecting the last group in the range. When a parameter group is selected, the parameters contained in that parameter group are displayed in the Parameter List (refer to section 6.2.3).

6.2.3 Parameter List

The parameter list is shown in Figure 10. The parameters that are displayed in the list at any given time depend on the parameter groups that are currently selected (refer to section 6.2.2) and the filter (refer to section 6.2.4).

The first column of the Parameter List shows the inverter parameter (*Pr. XXX*) number that is normally used when accessing a given register via the inverter's keypad. Note that not all registers will have parameter number entries: command and monitor registers, for example, are not accessed via the inverter's keypad by entering a "*Pr. XXX*" number, and their associated parameter column fields on the Monitor tab are therefore empty. Also note that this column is for user convenience and inverter user's manual cross-reference only: parameters are not referenced through the interface card by their parameter numbers, but by their register numbers.

The second column of the Parameter List shows the register number that provides network access to each parameter (refer to section 4). The third column contains the parameter descriptions, which are used by the filter function. The last column performs two functions: it displays the current value of the parameter, and (for writable parameters) also allows changing the parameter's value by clicking on the number in the value column and entering the new value.



Parameter	Register	Description	Value (Decimal)
0	1000	Torque boost	40
1	1001	Maximum frequency	12000
2	1002	Minimum frequency	0
3	1003	Base frequency	6000
4	1004	Multi-speed setting (high speed)	6000
5	1005	Multi-speed setting (middle speed)	3000
6	1006	Multi-speed setting (low speed)	1000
7	1007	Acceleration time	50
8	1008	Deceleration time	50
9	1009	Electronic thermal O/L relay	1100
10	1010	DC injection brake operation frequency	300
11	1011	DC injection brake operation time	5
12	1012	DC injection brake operation voltage	40
13	1013	Starting frequency	50
14	1014	Load pattern selection	0
15	1015	Jog frequency	500
16	1016	Jog acceleration/deceleration time	5
17	1017	MRS input selection	0

Figure 10: Parameter List

Some items to keep in mind when interacting with the Parameter List are:

- When entering new parameter values, be sure that the number being entered is appropriate for the currently-selected radix (refer to section 6.2.5).
- The column widths can be changed by dragging the vertical bars that separate the header row's cells.

- If you begin changing a parameter value and then decide to abandon the change, pressing the ESC key on your keyboard will abandon the change and redisplay the current parameter value.
- When editing a parameter value, clicking someplace off the entry cell is equivalent to hitting the ENTER key.

6.2.4 Parameter List Filter

A filter function provides Parameter List search capabilities. To use the filter function, simply type a word into the filter entry box and then click the “filter” button. Refer to Figure 11. The filter will then display only those parameters currently available in the Parameter List that satisfy the search criteria. Once a filter has been entered, it will continue to be applied to all information normally displayed in the Parameter List. To remove the filter, delete all characters contained in the filter entry box and then click the “filter” button.




Figure 11: Parameter List Filter

6.2.5 Radix Selection

Figure 12 shows the radix selection buttons that allow changing the Parameter List “value” column data display and entry radix between decimal and hexadecimal formats.

When “DEC” is selected, the “value” column heading will be “Value (Decimal)”, current parameter values will be displayed in decimal, and values to be written to parameters must be entered in decimal format. For example, to change the inverter’s frequency command to 40.00Hz, enter the decimal value 4000.



Figure 12: Radix Selection



Similarly, when “HEX” is selected, the “value” column heading will be “*Value (Hexadecimal)*”, current parameter values will be displayed in hexadecimal, and values to be written to parameters must be entered in hexadecimal format.

6.3 Dashboard Tab




Figure 13: Dashboard Tab



The Dashboard Tab provides access to a variety of gauges, meters and graphs that can be configured to provide an at-a-glance graphical overview of application variables in real-time. A total of 10 gauge windows are available (four at a time), and each gauge window can be configured to display any register's value via one of six different gauge types. User-defined engineering units, scaling and range limits are also configurable. Refer to Figure 13.

6.3.1 Information Window

Figure 14 shows the Information Window, which displays messages regarding the status of the Dashboard configuration parameters (loading or submitting).



Figure 14: Dashboard Tab Information Window

6.3.2 Gauge Window Navigation

Figure 15 shows the two buttons that provide for navigation of the gauge windows. Clicking the “Up” or “Down” buttons will scroll the gauge windows.




Figure 15: Gauge Window Navigation

6.3.3 Gauge Window Configuration

Each of the gauge windows can be independently configured to display a user-defined register with a variety of flexible configuration options. While the behavior and presentation may vary slightly depending on the specific gauge chosen, all of the gauges share the following common elements (refer to Figure 16 for an example):

Gauge Selector: A drop-down selection box in the upper left-hand corner of the gauge window, which allows the user to select the type of gauge that will be displayed.

Title: A text entry box located above the gauge, in which the user can enter a descriptive gauge title comprised of up to 16 characters.

Units: A text entry box in which the user can enter an engineering units string comprised of up to 8 characters. This units string will be appended to all locations in the gauge window that display the designated register's current value.

Register: The designated register whose value is to be reflected on the gauge.

Multiplier: The multiplier value is a floating-point number that is used to scale the raw value of a register. As its name suggests, the multiplier value is multiplied by the designated register's current raw value in order to calculate the gauge's indicated value. Negative values can also be used if desired.

Min Value: The gauge's minimum indicated value. Negative values can be used if desired (e.g. if a negative Multiplier attribute is used to generate a negative indicated value). Not all gauges allow adjustment of the min value.



Max Value: The gauge's maximum indicated value. Similar to the Min Value attribute, negative values can be used if desired. Indicated value characteristics can even be inverted by setting the Max Value attribute to a value less than the Min Value attribute.

Update Button: Clicking the update button will apply the current configuration attribute settings to the gauge. Note, however, that simply updating the gauge's current display properties does not write these settings to the interface card's filesystem. To save the current configuration of all the gauge windows to the filesystem, the Dashboard tab's "submit" button must be selected (refer to section 6.3.4).

Current Value: The current indicated value of the designated register is numerically displayed with the configured Units string at the bottom of each gauge window.

The following is a summary of the different available gauge types:

Gauge: Refer to Figure 16. This type of meter implements a rotary dial-type display format. The indicated value and units are shown numerically on the face of the gauge, and via the red indicator needle. The yellow needle shows the previous indicated value, thereby providing a simple historical reference. The "Min Value" attribute is not configurable; this gauge always starts at 0.




Figure 16: Gauge

BarGraph: Refer to Figure 17. This type of meter implements a linear bar graph display format. Hovering the mouse pointer over the red portion of the graph pops up a tooltip which displays the current indicated value and units.




Figure 17: BarGraph

Meter: Refer to Figure 18. This type of meter implements a common panel meter-type display format. The units string is shown on the face of the meter. All raw register values are interpreted as positive numbers (i.e. 0...0xFFFF equates to 0...65535₁₀.)




Figure 18: Meter



Pos/Neg Meter: Refer to Figure 19. Similar to the “meter” gauge, this type of meter also implements a common panel meter-type display format, but in this instance the indicated value can be positive or negative (two’s complement interpretation). In other words, raw register values of $0 \dots 0x7FFF$ equate to $0 \dots 32767_{10}$, and values of $0x8000 \dots 0xFFFF$ equate to $-32768 \dots -1$. Because the meter placard is always centered around zero, the “Min Value” attribute is not configurable, and the “Max Value” attribute is used for both the maximum positive indicated value as well as the maximum negative indicated value.




Figure 19: Pos/Neg Meter

Thermometer: Refer to Figure 20. This type of meter implements the universally-identifiable thermometer display format. Hovering the mouse pointer over the red “mercury” portion of the graph pops up a tooltip which displays the current indicated value and units.




Figure 20: Thermometer

Line Graph: Refer to Figure 21. This type of graph implements a continuously-scrolling historical data logging line graph. Up to 80 seconds worth of historical data is available. Hovering the mouse pointer anywhere on the graph displays a vertical reference line at the corresponding time, and pops up a tooltip which displays the current indicated value at that time.




Figure 21: Line Graph




Figure 22: Zooming



**Gauge
Usage
Tip**

At times, it may be convenient to zoom in on a particular gauge or meter in order to more clearly see the indicator, or to fill the computer screen with a particular gauge's image. This can be easily accomplished with the web browser's Flash Player plug-in by right-clicking on the gauge and selecting the desired zoom level (refer to Figure 22).



6.3.4 Submitting Changes

Whenever any of the gauge window configuration items in the Dashboard Tab have been changed, the “submit” button located on the right-hand portion of the web page must be selected in order to write these settings to the interface card’s filesystem. Refer to Figure 23. Note that submitting the Dashboard Tab configuration does not require rebooting of the interface card: the changes take effect immediately, and the interface card continues its operation without interruption.



Figure 23: Submit Dashboard Changes

6.4 Customizing the Embedded Web Server

6.4.1 Customization Overview

It is possible for end-users to customize the embedded web server in order to create their own application-specific or corporate “look and feel”. Knowledge of authoring dynamic web content is required. Using windows explorer, it is possible to load customized web server content into the “WEB” folder on the interface card’s file system (refer to section 7.2). Usually, this web server content contains programming which implements the XML socket-based XTPro protocol (refer to section 6.4.2). Via XTPro, the embedded web server can gain access to any inverter register and the interface card file system resources, and manipulate them as required.

Notes

- All files in the “WEB” folder may be deleted or replaced if desired by the user.
- The default HTML file targeted by the web server is “index.htm”. Therefore, when customizing the web server content, ensure that initial file “index.htm” exists.
- All files accessed by the web server itself must reside in the “WEB” folder. Note that this does not restrict active web server content to using only the “WEB” folder, however, as XTPro “read_file” and “write_file” commands can access any existing location on the file system.
- If the factory-default “WEB” folder contents need to be recovered (if they are accidentally deleted, for example), they can be downloaded from the [product web page](#) on the internet.
- Two simultaneous web server sessions are supported. Note that the number of available simultaneous web server sessions is independent of the number of available simultaneous XTPro XML sockets.



6.4.2 XTPro Overview

XTPro is an acronym for **XML TCP/IP Protocol**. The XTPro specification is an application-layer (positioned at level 7 of the OSI model) messaging protocol that provides XML-based client/server communication via TCP port 843. Typically, XTPro is used for the implementation of graphical user interfaces (GUIs), such as advanced web servers or HMIs that have the ability to request information via XML sockets, and then manipulate and/or display the information in a rich application-specific manner.

XTPro is a request/response protocol that provides services specified by commands. For more information on XTPro, refer to the separate [XTPro Specification](#). This section will cover the device-specific implementation of the XTPro protocol.

6.4.3 XTPro Web Browser-Based Implementation

A representative implementation based upon using a web browser as the client is detailed in Figure 24. In this scenario, the client application is developed by using an active web server authoring tool (such as Adobe Flash®). The active content is then embedded into one or more HTML files and loaded onto the device's file system (refer to section 6.4.1 for detailed information regarding customization of the web server content). Accessing the device's web server via a standard web browser then loads the active content, which initiates communication with the server.




Figure 24: Web Browser-Based Implementation

6.4.4 XTPro HMI-Based Implementation

A representative implementation based upon a stand-alone HMI client is detailed in Figure 25. In this scenario, the client application is developed by using tools provided by the HMI manufacturer, and is hosted independently of the actual server device.




Figure 25: HMI-Based Implementation

6.4.5 XTPro Supported Commands

For a summary of the supported XTPro commands, refer to Table 24. Note that two simultaneous XTPro connections are available.

Table 24: Supported XTPro Commands

Command	Supported	Notes
noop	Yes	-
vzn	Yes	Supports XTPro specification version 1
id	Yes	-
read_data	Yes	“reference” is the inverter’s register (e.g. “2” for frequency command), while “data_value” is a 16-bit hexadecimal value (e.g. “1F4” for a decimal value of 500)
write_data	Yes	
load_file	Yes	The absolute file path must start with a forward slash ‘/’
store_file	Yes	
reinit	No	Reinitializes only the configurable drivers and services (does not perform a complete device soft reboot)
auth	Yes	Authorization is not required
cov	Yes	COV notification messages are sent every 200ms

7 FILESYSTEM

7.1 Overview

The interface card's on-board filesystem is used by the application firmware. Currently, the application firmware's main use of the filesystem is to store XML-encoded configuration files and the embedded web server. The studio must be used to manage the configuration via USB or FTP. Do not manually access the configuration files unless instructed by technical support.

The configuration is only read at unit boot-up. Therefore, if a new configuration file is loaded, that unit must be rebooted for the new configuration take effect. Rebooting a unit can be performed by power-cycling the inverter in which the card is installed.

The embedded web server is customizable and is located in the "*WEB*" folder. All web page related items should reside in the "*WEB*" folder.

Interacting with the filesystem can be performed via USB (using a mini-B USB cable) as the interface card enumerates as a standard USB mass storage device "flash drive". The file system can also be accessed via FTP if the card has compatible network settings. Users can interact with the files on the interface card's filesystem in the same manner as though they were traditional files stored on a local or remote PC.

Note that the USB and FTP connection will prevent the file system from being accessed by other interfaces, such as the web server. Therefore, USB and FTP should only be connected when performing

maintenance and configuration. USB and FTP should be disconnected while the card is running normally in a production environment.

7.2 USB with Windows Explorer

To use Microsoft Windows Explorer, first open either “Windows Explorer” or “My Computer”. Refer to Figure 26. Note that the indicated procedure, prompts and capabilities outlined here can vary depending on such factors as the installed operating system and service packs.

The interface card will typically be displayed as a removable medium such as a Removable Disk. Refer to Figure 27.




Figure 26: Accessing Windows Explorer




Figure 27: Removable Disk with Windows Explorer

Windows Explorer will then display the filesystem's contents (refer to Figure 28.) You can now perform normal file manipulation actions on the available files and folders (cut, copy, paste, open, rename, drag-and-drop transfers etc.) in the same manner as though you were manipulating any traditional file and folder stored on your computer's hard drive.




Figure 28: USB File Access via Windows Explorer

7.3 FTP With Windows Explorer

To use FTP with Microsoft Windows Explorer, first open either "Windows Explorer" or "My Computer". Please note that the indicated procedure, prompts and capabilities outlined here can vary depending on such factors as the installed operating system, firewalls and service packs.

In the “Address” field, type in “ftp://admin:admin@” and then the IP address of the target interface card (if the user name and password have been changed from its default, then replace the first “admin” with the new user name and the second “admin” with the password.) Refer to Figure 29.




Figure 29: FTP via Windows Explorer

Note that the behavior of Windows Explorer FTP will vary from PC to PC. If you are having issues connecting FTP, there are other FTP client tools available such as Windows Command Prompt, Core FTP, FileZilla, SmartFTP etc. that can also be used to reliably access the card’s file system.

7.4 Loading New Web Server Content

The interface card's web server resides in the file system and can be updated in the field (refer to section 6.4). This section will discuss how to update the default web server. The update procedure similarly applies to a custom web server. Web server updates may be released for a variety of reasons, such as improvements and added functionality. When using the default web server, it is always recommended to use the latest release.

Treat web server updates independently of firmware updates since web server updates may or may not be related to firmware updates. The latest default web server can be downloaded from the [product web page](#). It is suggested that users first check this website during commissioning, and then periodically afterwards to determine if a new default web server has been released and is available to update their units.

Besides the new "WEB" folder containing the new web server, the update requires a USB or FTP connection as described earlier in this section. To update the web server, complete the following steps:

1. Navigate to the card's file system (see section 7.2 or section 7.3).
2. Backup the "WEB" folder if desired by copying it to the local computer.
3. Delete the "WEB" folder from the card's file system.
4. Copy the new "WEB" folder to the card's file system.
5. Power-cycle or reset the card.
6. Clear your internet browser's cache to ensure that the new web server content will be properly loaded from the interface card.

8 FIRMWARE

8.1 Overview

The interface card's embedded firmware can be updated in the field. Firmware updates may be released for a variety of reasons, such as custom firmware implementations, firmware improvements and added functionality as a result of user requests. Additionally, it may be necessary to load different firmware onto the unit in order to support various protocols. In order to ensure that the firmware update is successful, and in the interest of equipment and personnel safety, it is strongly recommended to stop all of the card's production activities prior to initiating the firmware update procedure. **Failure to follow the firmware update procedure could result in corrupt firmware!**

8.2 Update Procedure

Firmware update steps:

1. Always back up your configuration to a PC for later recovery if necessary.
2. Download and install the latest Configuration Studio, which can be obtained from the [product web page](#).
3. Please be sure to read the firmware release notes and updated user's manual for any important notices, behavior precautions or configuration requirements prior to updating your firmware.



4. Ensure that the device is in a safe state prior to initiating the firmware update. The card may be temporarily inaccessible during the firmware update process.
5. Locally via USB: Connect a USB cable between the card and the PC and open the studio. If the studio contains newer firmware, it will automatically prompt you to update the firmware. Proceed with the firmware update.
6. Remotely via FTP: Connect an Ethernet cable and ensure that the card has compatible network settings.
7. Once the firmware update process has started, do not interrupt the card as this may corrupt the firmware. Do NOT manually power-cycle the inverter or reboot the card. Do NOT disturb the USB or Ethernet (FTP) connection.
8. After the firmware update has been completed, the card will reset automatically. When the card boots up again, it will be running the new application firmware, which can be confirmed by observing the version displayed in the **Device...Device Info** or the web server's information window (refer to section 6.2.1).
9. If new default web server content is available, load the new web server (refer to section 7.4).

9 PROTOCOL-SPECIFIC INFORMATION

This section will discuss topics that are specific to each of the supported protocols.

9.1 Modbus/TCP Server

9.1.1 Overview

The interface card supports Schneider Electric's Modbus/TCP protocol, release 1.0. The interface is conformance class 0 and partial class 1 and class 2 compliant, and allows up to 8 simultaneous Modbus/TCP client connections (sockets).

Other notes of interest include:

- Supported Modbus/TCP functions are indicated in Table 25.
- The register mapping is provided in section 4.1.

Table 25: Supported Modbus/TCP Functions

Function Code	Function	Modbus/TCP Class
1	Read coils	1
2	Read input status	1
3	Read multiple registers	0
4	Read input registers	1
5	Write coil	1
6	Write single register	1
8	Diagnostics (subfunction 0 only)	-
15	Force multiple coils	2
16	Write multiple registers	0



- Inverter registers can be addressed as holding registers (4X references) and input registers (3X references).
- Specific bits within inverter registers can be accessed as either coils (0X references) or discrete inputs (1X references).
- Write data checking is not available (refer to section 4.2.) For example, if a write is performed to a register with a data value that is out-of-range of the corresponding parameter object, no Modbus exception will be immediately returned.
- The “unit identifier” (UI) field of the request packets is ignored and is echoed in the response.
- Modbus/TCP should not be confused with Modbus (serial) over TCP. Modbus over TCP is not compatible with Modbus/TCP and is not supported.
- The driver can be configured to detect a timeout (communication loss) and perform a timeout action.

9.1.2 Holding & Input Registers

The inverter registers by default are mapped as both holding registers (4X) and input registers (3X), and are accessed by using the inverter register numbers described in section 4.1. The 4X and 3X only serve as a naming convention for holding register and input register respectively, and should NOT be included as part of the actual on-the-wire register number. To further clarify, Modbus register 40201 is the same as Modbus holding register 201. The same description applies to input registers (3X).

For example, from a Modbus/TCP master’s point of view, in order to access the output frequency (register 201) as a holding register, the Modbus/TCP master must execute the Read Multiple Registers function code and target register 201. This will similarly apply when accessing an inverter register as an Input Register.

9.1.3 Coil & Discrete Input Mappings

The Modbus/TCP driver provides read/write support for coils (0X references) and read-only support for discrete inputs (1X references). These will collectively be referred to from here on out as simply “discretes”. Accessing discretes does not reference any new physical data: discretes are simply indexes into various bits of existing registers. What this means is that when a discrete is accessed, that discrete is resolved by the interface into a specific register, and a specific bit within that register. The pattern of discrete-to-register/bit relationships can be described as follows:

Discrete 1...16 map to register #1, bit0...bit15 (bit0=LSB, bit15=MSB)

Discrete 17...32 map to register #2, bit0...bit15, and so on.

Arithmetically, the discrete-to-register/bit relationship can be described as follows: For any given discrete, the register in which that discrete resides can be determined by:

$$\text{register} = \left\lfloor \frac{\text{discrete} + 15}{16} \right\rfloor \quad \text{Equation 1}$$

Where the bracket symbols “ $\lfloor \]$ ” indicate the “floor” function, which means that any fractional result (or “remainder”) is to be discarded, with only the integer value being retained.

Also, for any given discrete, the targeted bit in the register in which that discrete resides can be determined by:

$$\text{bit} = (\text{discrete} - 1) \% 16 \quad \text{Equation 2}$$



Where “discrete” $\in [1 \dots 65535]$, “bit” $\in [0 \dots 15]$, and “%” is the modulus operator, which means that any fractional result (or “remainder”) is to be retained, with the integer value being discarded (i.e. it is the opposite of the “floor” function).

For clarity, let’s use Equation 1 and Equation 2 in a calculation example. Say, for instance, that we are going to read coil #34. Using Equation 1, we can determine that coil #34 resides in register #3, as $\lfloor 3.0625 \rfloor = \lfloor 3 r_1 \rfloor = 3$. Then, using Equation 2, we can determine that the bit within register #3 that coil #34 targets is $(34-1)\%16 = 1$, as $33\%16 = \text{mod}(2 r_1) = 1$. Therefore, reading coil #34 will return the value of register #3, bit #1.

9.1.4 Connection Timeout Options

In the studio’s Project panel, navigate to **A7NETH-V2...Ethernet...Modbus/TCP Server**. The following configuration options will determine the actions to be taken if the connection is abnormally terminated or lost. While this feature provides an additional level of fail-safe functionality for those applications that require it, there are several ramifications that must be understood prior to enabling this capability. Note that a certain degree of caution must be exercised when using the timeout feature to avoid “nuisance” timeouts from occurring.

Enable Supervisory Timer

This timer provides the ability for the driver to monitor timeout occurrences on the overall receive activity for all connections.

- The timer will start after receiving the first request. Once the timer is started, it cannot be disabled.

- If the driver experiences no receive activity for more than the **Timeout** time setting, then the driver assumes that the client or network has experienced some sort of unexpected problem, and will perform the **Timeout Action**.

Enable Connection Timer

This timer provides the ability for the driver to monitor timeout occurrences and errors within the scope of each client connection.

- If a particular open socket experiences no activity for more than the **Timeout** time setting, then the driver assumes that the client or network has experienced some sort of unexpected problem, and will close that socket and perform the **Timeout Action**.
- If a socket error occurs (regardless of whether the error was due to a communication lapse or abnormal socket error), the driver will perform the **Timeout Action**. Specifically, do not perform inadvisable behavior such as sending a request from the client device, and then closing the socket prior to successfully receiving the server's response. The reason for this is because the server will experience an error when attempting to respond via the now-closed socket. Always be sure to manage socket life cycles "gracefully", and do not abandon outstanding requests.

Timeout

Defines the maximum number of milliseconds for a break in network communications before a timeout event will be triggered.

Timeout Action

Select an action from the drop down menu:



“None”.....No effect. The inverter will continue to operate with the last available settings.

“Apply Fail-safe Values”Apply the fail-safe values as described in section 5.4.1.

9.1.5 Node Settings

There are no node settings. A node is simply a container for objects.

9.1.6 Holding/Input Register Remap Settings

In the studio's **Project** panel, add **A7NETH-V2...Ethernet...Modbus/TCP Server...Holding/Input Register Remap**.

Holding/input register remap objects are **OPTIONAL**. By default, all inverter registers are already mapping as both holding (4X) and input (3X) registers (refer to section 9.1.2). For user convenience, register remap objects can be created to map any inverter register to holding/input register 2001 to 2050.

At times, it may be convenient to access inverter registers in bulk Modbus transactions. This may be especially true in situations where it is desired to access certain registers that are non-contiguous. For example, if it were desired to read the inverter's output frequency (register 201), converter output voltage (register 208), and PID deviation value (register 254), this could be accomplished in two different ways:

1. Implement three separate Modbus read transactions, each one reading one register only, or

2. Implement one single Modbus read transaction, starting at register 201 for a quantity of 54 registers. Then, pick out the registers of interest and ignore the rest of the response data.

While both of these methods will certainly work, neither one of them is optimized for the task at hand, which is to access three specific register values. A fully optimized solution can be realized by making use of the register remap objects. Non-contiguous inverter registers can be grouped together in any order and accessed efficiently via the Modbus/TCP “read multiple registers” and “write multiple registers” function codes. The net effect is one of being able to transfer larger blocks of registers using fewer Modbus transactions, which results in improved network utilization and simpler data manipulation code on the Modbus master device.

Description

This 32-character (max) field is strictly for user reference: it is not used at any time by the driver.

Remap Register

Remap register that maps to the specified inverter register. Select from 2001 to 2050.

Register

Inverter register (refer to section 4) that is accessed by the **Remap Register**.

Data Type

Fixed to 16-Bit Unsigned. This is equivalent to two bytes.



9.2 EtherNet/IP Server

9.2.1 Overview

EtherNet/IP is a network adaptation of ODVA's Common Industrial Protocol (CIP). The card supports the EtherNet/IP server protocol, including the CSP server variant.

The interface card supports both implicit (class 1 I/O) and explicit (UCMM and class 3) messaging. Class 1 connections support two different types of I/O messaging. One type is the generic I/O assembly instances 100 and 150, which is entirely user-configurable (refer to section 9.2.5). The other type is the AC/DC drive profile assembly instances 20 & 70 or 21 & 71, which requires no user configuration (refer to section 9.2.6). With I/O messaging, the data field contains only real-time I/O data. The meaning of the data is pre-defined at the time the connection is established. I/O messages are short and have low overhead, and therefore minimize the processing time and allow for time-critical performance.

With explicit messaging (refer to section 9.2.7), nodes must interpret each message, execute the requested task and generate responses. These types of messages can be used to transmit configuration, control and monitor data.

The following sections demonstrate specific examples of how to use EtherNet/IP to transfer data between the inverter and Allen-Bradley Logix-brand PLCs.

Other notes of interest include:

- The interface card supports the EtherNet/IP protocol, as administered by the Open DeviceNet Vendor Association (ODVA).

- This product has been self-tested and found to comply with ODVA EtherNet/IP Conformance Test Software Version CT-13.
- The interface card's product type code is 2 (AC Drive).
- The EDS file can be obtained from the included CD-ROM or downloaded from the [product web page](#) on the internet.
- Supports DLR (Device Level Ring) node.
- Supports unconnected messages (UCMM), and up to 16 simultaneous class 1 (I/O) or class 3 (explicit) connections.
- Class 1 implicit I/O supports both multicast and point-to-point (unicast) when producing data in the T→O direction.
- Point-to-point class 1 connected messages will be produced targeting the IP address of the device that instantiated the connection, UDP port 0x08AE (UDP port 2222).
- If a class 1 point-to-point connection is established in the (T→O) direction, no more class 1 connections can be established.
- If a class 1 connection's consuming half (O→T) times out, then the producing half (T→O) will also time-out and will stop producing.
- If a class 1 or class 3 connection timeout (communication loss) occurs, the driver can be configured to perform a timeout action. For class 1 connections, the timeout value is dictated by the scanner/client and is at least four times the RPI (Requested Packet Interval). For class 3 connections, the timeout value is also dictated by the scanner/client, but is typically a much larger value than for class 1 connections.



9.2.2 Server Settings

In the studio, navigate to **A7NETH-V2...Ethernet...EtherNet/IP Server**.

Device Name

The device name is used for identification of a device on the EtherNet/IP network. This string is accessible as the “product name” attribute of the identity object. Enter a string between 1 and 32 characters in length.

DLR

Device Level Ring is a ring redundancy protocol. All devices in a DLR ring must support DLR.

- If the checkbox is cleared (default setting), the card will not operate correctly in a DLR ring. By disabling this option, the card should not be installed in a DLR ring.
- If the checkbox is checked, the card can participate and will operate correctly in a DLR ring. By enabling this option, the card can be installed successfully in a DLR ring.

9.2.3 Connection Timeout Options

In the studio’s Project panel, navigate to **A7NETH-V2...Ethernet...EtherNet/IP Server**. The following configuration options will determine the actions to be taken if the connection is abnormally terminated or lost. While this feature provides an additional level of fail-safe functionality for those applications that require it, there are several ramifications that must be understood prior to enabling this capability. Note that a certain degree of caution must be exercised when using the timeout feature to avoid “nuisance” timeouts from occurring.

Run/Idle Flag Behavior

EtherNet/IP clients (such as PLCs) have the option of adding a 32-bit “run/idle” header to all class 1 (I/O) data packets sent to devices. Bit 0 of this header is called the “run/idle flag” by the EtherNet/IP specification, and is intended to signify when the client is in a “running” state or an “idle” state. A running state (run/idle flag = Run) is indicated whenever the client is performing its normal processing (e.g. scanning its ladder logic). An idle state (run/idle flag = Idle) is indicated otherwise. For example, Allen Bradley ControlLogix PLCs will set their run/idle flag to Idle whenever their processor keyswitch is placed in the “PROG” position, presumably in preparation to receive a new application program from RSLogix 5000.

The behavior of EtherNet/IP devices when they receive I/O data from a controller with the run/idle flag set to Idle is not defined in the EtherNet/IP specification. The driver allows the option of two different behavioral responses when a run/idle flag = Idle condition is received, depending on the state of the *Invoke Timeout When Run/Idle Flag = Idle* checkbox.

- If the checkbox is cleared (default setting), then the driver will maintain the last I/O data values received from the client. For example, if a device mapped to the database was being commanded to run prior to the run/idle flag being set to Idle by the client, then it will continue to run.
- If the checkbox is checked, then the driver will perform the **Timeout Action**.

Timeout Action

Select an action from the drop down menu:

“None”.....No effect. The inverter will continue to operate with the last available settings.

“Apply Fail-safe Values”.....Apply the fail-safe values as described in section 5.4.1.



9.2.4 Generic Class 1 I/O Produced and Consumed Data Settings

In the studio's **Project** panel, add **A7NETH-V2...Ethernet...EtherNet/IP Server...Produced I/O Data...Produced Data Word** and/or **Consumed I/O Data...Consumed Data Word**.

The Produced Data Word and Consumed Data Word objects are only applicable when connecting to assembly instances 100 and 150 (generic I/O), which is typically the case. The Produced Data Word defines the structure of status data sent from the inverter back to the controller. The Consumed Data Word objects will define the structure of the command data sent from the EtherNet/IP controller (for example, a ControlLogix PLC) to the inverter. These objects allow the creation of custom-built I/O data. Up to 32 “command” register values can be sent to the inverter, and up to 32 “status” register values can be sent back to the controller. Therefore, up to 32 Produced and 32 Consumed Data Word objects can be created. If a consumed word offset is not defined, that data will be ignored by the inverter. If a produce word offset is not defined, the value will default to 0. The size of the actual I/O produced and consumed data is determined by the client upon initial connection establishment. Since a data word utilizes 2 bytes, the size must be an even number of bytes. The I/O data format is summarized in Table 26.

Description

This 32-character (max) field is strictly for user reference: it is not used at any time by the driver.

Produced Data Word Offset

The value from the associated inverter register will populate this word offset of the produced data that is to be sent to the client. It is recommend to start at word offset 0.

Consumed Data Word Offset

The consumed data received from the client at this word offset will contain the value to be written to the associated inverter register. It is recommend to start at word offset 0.

Register

The inverter register (refer to section 4) associated with the word offset. For the Produced Data Word object, enter a “status” register to be monitored. For the Consumed Data Word object, enter a “command” register that can be written.

Data Type

Each data word is fixed to 16-Bit Unsigned. This is equivalent to two bytes.

Table 26: EtherNet/IP User-Configurable I/O Data Format

Consumed Data (PLC to Inverter)		Produced Data (Inverter to PLC)	
Word Offset	Register	Word Offset	Register
0	Any	0	Any
1	Any	1	Any
:	Any	:	Any
30	Any	30	Any
31	Any	31	Any



The default I/O configuration is described in Table 27. Always use the studio to confirm the configuration before commissioning the device.

Table 27: EtherNet/IP Default User-Configurable I/O Data Format

Consumed Data (PLC to Inverter)		Produced Data (Inverter to PLC)	
Word Offset	Register	Word Offset	Register
0	1	0	100
1	2	1	201
:	None	:	None

9.2.5 Generic Class 1 (I/O) Connection Access

Clients may access the class 1 endpoint by opening a connection to assembly instances 100 and 150. The structure of I/O consumed and produced data for this assembly instance pair is entirely user-configurable (refer to section 9.2.4). The generic class 1 I/O connection is mutually exclusive of the AC/DC drive profile class 1 I/O connection. For a generic class 1 I/O application example, refer to section 9.2.11.

9.2.6 AC/DC Drive Profile Class 1 (I/O) Connection Access

The interface card supports the ODVA AC/DC drive profile. No special EtherNet/IP configuration of the interface card is required when using the AC/DC drive profile: all that is needed is that the controller must target either assembly instances 20 & 70 or 21 & 71 in its connection parameters. The structure of I/O consumed and produced data for the AC/DC drive profile class 1 I/O is predefined and fixed (refer to

Table 29 and Table 32) to 4 input bytes and 4 output bytes. It is highly recommended to complete the reading of this section to understand the data mapping and the implications of using the AC/DC drive profile. Note that when using the AC/DC drive profile class 1 I/O, the produced word and consumed word configuration do not apply (refer to section 9.2.4). For an AC/DC drive profile class 1 I/O application example, refer to section 9.2.12.2.

The AC/DC drive profile implementation provides support for several required CIP objects, which are specified in Table 28. While the various supported attributes of all of these objects are accessible via explicit messaging, the main intent of using the AC/DC drive profile is to interact with the predefined input and output assembly instances via an I/O connection. The structure of these assembly instances is defined by the EtherNet/IP specification in order to engender interoperability among different vendor's products. This section will focus primarily on the format of the AC/DC drive profile I/O assemblies supported by the interface card, and the inverter data which their various constituent elements map to.

Table 28: AC/DC Drive Profile-Related Objects

Class Code	Object Name
0x04	Assembly Object
0x28	Motor Data Object
0x29	Control Supervisor Object
0x2A	AC Drive Object


Table 29: Output Instances 20 and 21 Detail

Instance	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
20	0						Fault Reset		Run Fwd
	1								
	2	Speed Reference (Low Byte)							
	3	Speed Reference (High Byte)							
21	0		NetRef	NetCtrl			Fault Reset	Run Rev	Run Fwd
	1								
	2	Speed Reference (Low Byte)							
	3	Speed Reference (High Byte)							

Mapping Detail

Run Fwd: forward rotation command (0=forward rotation off, 1=forward rotation on). Maps to inverter register 1, bit 1 (forward rotation command).

Run Rev: reverse rotation command (0=reverse rotation off, 1=reverse rotation on). Maps to inverter register 1, bit 2 (reverse rotation command).

Fault Reset: Inverter reset command (0=no action, 0→1 rising edge=reset value 0x9966). Maps to inverter register 5 (inverter reset).

NetCtrl: Run/stop control source selection (0=local control, 1=network control). Maps to inverter register 4 (operation mode).

NetRef: Speed reference source selection (0=local control, 1=network control). Maps to inverter register 4 (operation mode).

NetCtrl and NetRef explanation: Although the intent of these bits is to be able to independently separate the inverter’s run/stop command source and speed reference source, the inverter only has one externally-accessible “operation mode” command register, which controls both the run/stop source and speed reference source simultaneously. Therefore, Table 30 can be used to determine the resultant value of the “operation mode” register based on the various combinations of NetCtrl and NetRef.

Table 30: NetCtrl/NetRef Behavior

NetCtrl	NetRef	“Operation Mode” Register Value
0	0	0x0010 (EXT mode)
0	1	No change from current value
1	0	
1	1	0x0014 (NET mode)

Speed Reference: Inverter speed reference in RPM. Maps to inverter register 14 (frequency command). The frequency command value written to the inverter depends on the settings of parameters *Pr. 37* and *Pr. 144* (refer to Table 31). The speed reference component of the AC/DC drive profile output instances is always in units of RPM. With certain combinations of *Pr. 37* and *Pr. 144*, however, the inverter interprets its incoming frequency command either as an actual frequency command (with units of Hz) or as a speed reference (with units of RPM). Therefore, the interface card will apply an RPM-to-Hz conversion equation when necessary, or will pass the consumed speed reference value directly on to the inverter as-is when the inverter is already expecting the frequency command to be in units of RPM.



The RPM-to-Hz conversion equation is $[RPM \times \text{number of motor poles} / 120]$. Table 31 indicates the scenarios under which the conversion equation is and is not applied, and the value used for the “number of motor poles” component in the numerator of the conversion equation. For more information on the manners in which *Pr. 37* and *Pr. 144* affect the inverter’s operation, please refer to the appropriate inverter user’s manual. Note that the values of *Pr. 37* and *Pr. 144* are read by the interface card only at boot-up, so if these parameter values are changed, then the interface card must be rebooted in order for it to recognize the new values and once again determine the required conversion scenarios.

Table 31: Inverter Speed Reference and Speed Actual Conversion Scenarios

<i>Pr. 37</i>	<i>Pr. 144</i>	Conversion Applied?	Number of Motor Poles Used in Conversion Equation
0 (default value)	0	Yes	4
	2..10	Yes	2..10
	102..110	No	N/A
1..9998	0	Yes	4
	2..10	No	N/A
	102..110	Yes	2..10

Table 32: Input Instances 70 and 71 Detail

Instance	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
70	0						Running1		Faulted
	1								
	2	Speed Actual (Low Byte)							
	3	Speed Actual (High Byte)							
71	0	At Reference	Ref From Net	Ctrl From Net	Ready	Running2 (REV)	Running1 (FWD)	Warning	Faulted
	1	Drive State							
	2	Speed Actual (Low Byte)							
	3	Speed Actual (High Byte)							

Mapping Detail

Faulted: Inverter fault signal (0=not faulted, 1=faulted). Maps to inverter register 100 (status word), bit 15 (alarm occurrence).

Warning: This bit is not used (it is always 0).

Running1 (FWD): Running forward status signal (0=not running forward, 1=running forward). Maps to inverter register 100 (status word), bits 0 and 1. The Running1 bit will be 1 whenever bit 0 (inverter running) and bit 1 (forward rotation) of the status word are both 1, and will be 0 otherwise. Note that if



the setting of inverter parameter *Pr. 190* (RUN terminal function selection) is changed from its factory-default value, the indicated status of the Running1 bit will no longer be accurate.

Running2 (REV): Running reverse status signal (0=not running reverse, 1=running reverse). Maps to inverter register 100 (status word), bits 0 and 2. The Running2 bit will be 1 whenever bit 0 (inverter running) and bit 2 (reverse rotation) of the status word are both 1, and will be 0 otherwise. Note that if the setting of inverter parameter *Pr. 190* (RUN terminal function selection) is changed from its factory-default value, the indicated status of the Running2 bit will no longer be accurate.

Ready: Inverter ready signal (0=not ready, 1=ready). The Ready bit will be 1 whenever the Drive State attribute (see below) is in the Ready, Enabled or Stopping state.

CtrlFromNet: Inverter command reference status (0=command reference is not from network, 1=command reference is from network). Maps to inverter register 101 (operation mode status). CtrlFromNet will be 1 whenever the operation mode status is a value of 0x0000 (NET mode), and will be 0 otherwise.

RefFromNet: Inverter speed reference status (0=speed reference is not from network, 1=speed reference is from network). Maps to inverter register 101 (operation mode status). RefFromNet will be 1 whenever the operation mode status is a value of 0x0000 (NET mode), and will be 0 otherwise.

AtReference: Up-to-speed signal (0=not up-to-speed, 1=up-to-speed). Maps to inverter register 100 (status word), bit 3 (SU/up to frequency). Note that if the setting of inverter parameter *Pr. 191* (SU terminal function selection) is changed from its factory-default value, the indicated status of the AtReference bit will no longer be accurate.

Drive State: Indicates the current state of the Control Supervisor Object state machine. Refer to the ODVA EtherNet/IP specification (object library) for detailed information on the Control Supervisor Object state machine.

Speed Actual: Inverter operating speed in RPM. Maps to inverter register 201 (output frequency). The output frequency value read from the inverter depends on the settings of parameters *Pr. 37* and *Pr. 144* (refer to Table 31). The speed actual component of the AC/DC drive profile input instances is always in units of RPM. With certain combinations of *Pr. 37* and *Pr. 144*, however, the inverter provides its output frequency either as an actual frequency (with units of Hz) or as a speed (with units of RPM). Therefore, the interface card will apply a Hz-to-RPM conversion equation when necessary, or will pass the inverter's output frequency value directly on to the network as-is when the inverter is already providing the output frequency in units of RPM.

The Hz-to-RPM conversion equation is $[output\ frequency \times 120 / number\ of\ motor\ poles]$. Table 31 indicates the scenarios under which the conversion equation is and is not applied, and the value used for the “number of motor poles” component in the denominator of the conversion equation. For more information on the manners in which *Pr. 37* and *Pr. 144* affect the inverter's operation, please refer to the appropriate inverter user's manual. Note that the values of *Pr. 37* and *Pr. 144* are read by the interface card only at boot-up, so if these parameter values are changed, then the interface card must be rebooted in order for it to recognize the new values and once again determine the required conversion scenarios.

9.2.7 Explicit Messaging Via Get/Set Attribute Single Services

Get attribute single (0x0E) and set attribute single (0x10) are common services that can access the inverter registers by specifying the appropriate class code, instance number and attribute identifier. The



class code is 0xA2. The instance number is the targeted register number (refer to section 4.1). The attribute identifier is 1, which is the 16-bit value of the register being accessed.

For example, a get attribute single request with a class code of 0xA2, instance number of 201, and attribute identifier of 1 will return the 16-bit value of the output frequency.

9.2.8 *Explicit Messaging Via Data Table Read/Write Services*

Data table read (0x4C) and data table write (0x4D) services provide a direct method of accessing the inverter registers by reference to “tag names”. Tags are read via the EtherNet/IP “data table read” service, and written via the EtherNet/IP “data table write” service. Note that an underscore (“_”) is used to separate fields in the tag names.

To read data, the client must reference a starting “source element” and the “number of elements” to read. Similarly, to write data, the client must reference a starting “destination element” and the “number of elements” to write. The “number of elements” can be any quantity from 1 to the maximum allowable length, while the “source element” and “destination element” must be tag names constructed according to the naming conventions shown in section 9.2.9. The elements are 16-bit values.

9.2.9 *Inverter Register Access Tag Format*

Any inverter register (refer to section 4) can be accessed with its own unique tag name, or an array tag can be used to access a group of registers with one PLC instruction. Tag names are generated according to the following structure:

[reg]_[register number]

Where

[reg] is just the 3-character sequence “reg”.

[register number] is a 1- to 4-character field (“1”, “2”...“507”, “508”, “1000”, “1001”... etc.) corresponding to the inverter register number.

Examples

“Output voltage” (register #203).....	reg_203
“Frequency command” (register #2)	reg_2
“Inverter status” (register #100)	reg_100
“Acceleration time” (<i>Pr. 7</i> / register #1007)	reg_1007

For explicit messaging examples, refer to sections 9.2.13 and 9.2.14.



9.2.10 ControlLogix Examples: Setup

This section will demonstrate how to initially setup a ControlLogix PLC (such as a 1756-L61) coupled with a 1756-ENBT communication interface (adjust this procedure according to your specific equipment). Later sections will provide specific read/write examples using this configuration with I/O or explicit messaging.

- 1) Run RSLogix 5000, and create a new configuration.
- 2) To add a 1756-ENBT to your I/O configuration, first switch to offline mode.
- 3) Right click on the I/O Configuration node in the controller organizer view and choose “New Module...”
- 4) The “Select Module” window will open.
- 5) Select the “1756-ENBT”, and click “Create”. Refer to Figure 30.
- 6) The “New Module” window will open. Refer to Figure 31.




Figure 30: Adding a New Module

- 7) Assign the Ethernet module a name (we will use “EIP”) and an IP address, deselect “Open Module Properties”, and click OK.
- 8) Download the configuration.
- 9) Switch to online mode. Right click on the 1756-ENBT module in the I/O Configuration and choose “Properties”.
- 10) Select the Internet Protocol tab from the Module Properties dialog box and confirm that the IP Settings are configured correctly.




Figure 31: Identifying the New Module

9.2.11 ControlLogix Example: EDS Add-On Profile (AOP)

This section will demonstrate how to setup and use an EtherNet/IP I/O connection via EDS Add-On Profile. This example only applies to RSLogix5000 V20 (and later) that support EDS Add-On Profile.



Otherwise, refer to the I/O examples in section 9.2.12. This section must be completed prior to attempting any of the following AOP example(s).

EtherNet/IP I/O messaging allows the inverter's parameter to be directly mapped into tags in the ControlLogix PLC. Once an I/O connection is established, it is automatically synchronized at an interval defined by the Requested Packet Interval (RPI).

- 1) Register the interface card's EDS file. In the menu bar, navigate to Tools...EDS Hardware Installation Tool. Refer to Figure 32.




Figure 32: EDS Hardware Installation Tool Menu

- 2) This will start the "EDS Wizard". Click "Next".

- 3) Select “Register an EDS file(s)” and click “Next”.
- 4) The “Registration” dialog will appear. Refer to Figure 33. Click “Browse”, select the interface card’s EDS file, and click “Next”.




Figure 33: EDS Registration

- 5) Ensure that there are no errors in the test results. Click “Next”.
- 6) A graphic image of the interface card is displayed. Click “Next”.

- 7) The task summary will list the interface card as the device to register. Click “Next”.
- 8) “You have successfully completed the EDS Wizard”. Click “Finish”.
- 9) The interface card is now available as a module.
- 10) Right click on the 1756-ENBT/A node under the “I/O Configuration” in the controller organizer view and choose “New Module...”
- 11) Find the interface card in the “Select Module” dialog box as shown in Figure 34.




Figure 34: Adding a New Interface Card Module

12) The “New Module” properties dialog box will open as shown in Figure 35.




Figure 35: AOP Interface Card Module Properties



13) Click on the “Connection” tab. Refer to Figure 36.




Figure 36: AOP New Module Properties Connection Tab

Confirm the setting of the “Requested Packet Interval (RPI)”. The RPI defines the amount of time (in milliseconds) between data exchanges across an I/O connection. The smallest RPI supported by the interface card is 1ms. Click “OK” when done.

- 14) You should now see the interface card in the 1756-ENBT/A branch under the I/O Configuration in the controller organizer view. The full I/O Configuration tree should appear similar to Figure 37.




Figure 37: AOP Interface Card I/O Configuration

- 15) Continue with the AOP Generic I/O Messaging example in section 9.2.11.1 or AOP AC/DC Drive Profile example in section 9.2.11.2.

9.2.11.1 ControlLogix Example: EDS Add-On Profile (AOP) Generic I/O Messaging

This section will demonstrate how to configure the EtherNet/IP Generic I/O connection.

- 1) Complete all steps in section 9.2.11.
- 2) Locate the interface card in the 1756-ENBT/A branch under the “I/O Configuration” in the controller organizer view. Right click on the interface card, choose “Properties”, and select the “General” tab.

3) Configure the Generic I/O connection. Refer to Figure 38.




Figure 38: AOP Generic I/O Module Definition

In the “Connection” portion of the dialog box, enter the following information:

Name: In this example, select Generic I/O.

Size: Because all inverter data is stored as 16-bit function codes, change the data type to “INT array”.

Input: The Input is the collection of monitor data that is produced by the interface card and is received as an input to the PLC. Its structure is defined by the Produced Data Configuration as described in section 9.2.4. The Input Size must be set to the number of 16-bit function codes that we wish to receive from the interface card. For the purposes of this example, we are assuming that the default produced data word configuration, with 2 relevant registers (1 and 2). We therefore set the Input Size to 2 Words.

Output: The Output is the collection of command & configuration data that is sent as an output from the PLC and consumed by the interface card. Its structure is defined by the Consumed Data Configuration as described in section 9.2.4. The Output Size must be set to the number of 16-bit function codes that we wish to send to the interface card. For the purposes of this example, we are assuming that the default consumed data word configuration, with 2 relevant registers (100 and 201). We therefore set the Output Size to 2 Words.

When done, click “OK”.


- 4) Switch to online mode and download the project to the PLC. Verify that the newly-added inverter is available and operating correctly by observing any indications shown on the inverter’s icon. When the inverter’s icon is selected, its status and any available error messages will be displayed in the area below the project tree. Also confirm that the interface card’s “Network Status” LED should be solid green, indicating an “online/connected” state.
- 5) By double-clicking “Controller Tags” in the project tree, it is possible to view the newly-added tags. The Interface_Card:I tag allows viewing of the input data, and the Interface_Card:O tag allows modification of the output data. These tags will be synchronized with the inverter at whatever rate was established for the module’s RPI. We can directly interact with these tags in order to control and monitor the inverter.



9.2.11.2 ControlLogix Example: EDS Add-On Profile (AOP) AC/DC Drive Profile

This section will demonstrate how to configure the EtherNet/IP AC/DC drive profile I/O connection.

- 1) Complete all steps in section 9.2.11.
- 2) Locate the interface card in the 1756-ENBT/A branch under the “I/O Configuration” in the controller organizer view. Right click on the interface card, choose “Properties”, and select the “General” tab.
- 3) Configure the AC/DC Drive Profile connection. Refer to Figure 39.



Module Definition*

Revision: 1

Electronic Keying: Compatible Module

Connections:

Name		Size		Tag Suffix
AC/DC Drive Profile 21 71	Input:	2	INT	Interface_Card:I1
	Output:	2		Interface_Card:O1
Select a connection				

OK Cancel Help

Figure 39: AOP AC/DC Drive Profile Module Definition

In the “Connection” portion of the dialog box, enter the following information:

Name: In this example, select AC/DC Drive Profile 21 71.

Size: Because all inverter data is stored as 16-bit function codes, change the data type to “INT array”.



When done, click “OK”.

- 4) Switch to online mode and download the project to the PLC. Verify that the newly-added inverter is available and operating correctly by observing any indications shown on the inverter’s icon. When the inverter’s icon is selected, its status and any available error messages will be displayed in the area below the project tree. Also confirm that the interface card’s “Network Status” LED should be solid green, indicating an “online/connected” state.
- 5) By double-clicking “Controller Tags” in the project tree, it is possible to view the newly-added tags. The Interface_Card:I tag allows viewing of the input data, and the Interface_Card:O tag allows modification of the output data. These tags will be synchronized with the inverter at whatever rate was established for the module’s RPI. We can directly interact with these tags in order to control and monitor the inverter. The AC/DC drive profile I/O data is described in section 9.2.6.

9.2.12 ControlLogix Example: I/O Messaging

This section will demonstrate how to setup and use an EtherNet/IP I/O connection via vendor-specific assembly instances 100 & 150 or 20 & 70 or 21 & 71. EtherNet/IP I/O messaging allows the inverter's registers to be directly mapped into tags in the ControlLogix PLC. Once an I/O connection is established, it is automatically synchronized at an interval defined by the Requested Packet Interval (RPI).

- 16) Switch to offline mode.
- 17) Right click on the 1756-ENBT node under the I/O Configuration in the controller organizer view and choose "New Module..."
- 18) Choose "Generic Ethernet Module" in the Select Module dialog box and click "Create". Refer to Figure 40.
- 19) The module properties dialog box will open (refer to Figure 41). Enter a Name which will allow easy identification of the inverter on the network (the tags created in RSLogix 5000 will be derived from this Name). Because all inverter data is stored as 16-bit registers,




Figure 40: Adding a New Generic Ethernet Module

change the “Comm Format” selection to “Data-INT”. Enter the IP address of the targeted interface card.

In the “Connection Parameters” portion of the dialog box, enter the following information:

Input: The Input Assembly is the collection of monitor data that is produced by the interface card and is received as an input to the PLC. Its structure is defined by the Produced Register Configuration as described in section 9.2.4. The Input Assembly Instance must be set to 150 when connecting to the generic I/O assembly instances (or 70/71 when using the ODVA AC/DC drive profile), and the size must be set to the number of 16-bit registers that we wish to receive from the interface card. For the purposes of this example, we are assuming that the default produced data word configuration, with two relevant registers (100 and 101). We therefore set the Input Size to 2.

Output: The Output Assembly is the collection of command & configuration data that is sent as an output from the PLC and consumed by the interface card. Its structure is defined by the Consumed Register Configuration as described in section 9.2.4. The Output Assembly Instance must be set to




Figure 41: Interface Card Module Properties

100 when connecting to the generic I/O assembly instances (or 20/21 when using the ODVA AC/DC drive profile), and the size must be set to the number of 16-bit registers that we wish to send to the interface card. For the purposes of this example, we are assuming that the default consumed data word configuration, with two relevant registers (1 and 2). We therefore set the Output Size to 2.

Configuration: The Configuration Assembly Instance is unused, and its instance number and size are therefore irrelevant (you can just enter “1” and “0”, respectively).

When done, click “OK”.

- 20) You should now see the new module (named “ETHERNET-MODULE Interface_Card”) in the 1756-ENBT branch under the I/O Configuration in the controller organizer view. Right click on this new module, choose “Properties”, and select the Connection tab. Refer to Figure 42.

Confirm the setting of the Requested Packet Interval (RPI). The RPI defines the amount of time (in milliseconds) between data exchanges across an I/O connection. The smallest RPI supported by the




Figure 42: Module Properties Connection Tab

interface card is 1ms. Click OK when done.

- 21) After adding the I/O Module to the configuration, the full I/O Configuration tree should appear similar to Figure 43.
- 22) Switch to online mode and download the project to the PLC. Verify that the newly-added inverter is available and operating correctly by observing any indications shown on the inverter's icon. When the inverter's icon is selected, its status and any available error messages will be displayed in the area below the project tree. Refer to Figure 44. Also confirm that the interface card's "Network Status" LED should be solid green, indicating an "online/connected" state.
- 23) By double-clicking "Controller Tags" in the project tree, it is possible to view the newly-added tags. Refer to Figure 45. The Interface_Card:C configuration tag is unused, the Interface_Card:I tag allows viewing of the input data, and the Interface_Card:O tag allows modification of the output data. These tags will be synchronized with the inverter at the rate that was established for the module's RPI.

We can directly interact with these tags in order to control and monitor the inverter. In Figure 45, for example, we can see that the first 16-bit word of output data (Interface_Card:O.Data[0]) has been set to a hexadecimal value of 0x0002. The default consumed data word configuration word offset 0 references register 1, which is the






Figure 43: I/O Configuration Tree



Module Defined Tags	
Interface_Card:I	
Interface_Card:O	
Interface_Card:C	
Description	
Status	Running
Module Fault	

Figure 44: Online Module Status

inverter's command register. A value of 0x0002, therefore, means that the run forward bit has been turned ON.



Name	Value	Force Mask	Style	Data Type
+ Interface_Card:C	{ ... }	{ ... }		AB:ETHERNET_MODULE:C:0
- Interface_Card:I	{ ... }	{ ... }		AB:ETHERNET_MODULE_INT_4Bytes:I:0
- Interface_Card:I.Data	{ ... }	{ ... }	Decimal	INT[2]
+ Interface_Card:I.Data[0]	16#004b		Hex	INT
+ Interface_Card:I.Data[1]	6000		Decimal	INT
- Interface_Card:O	{ ... }	{ ... }		AB:ETHERNET_MODULE_INT_4Bytes:O:0
- Interface_Card:O.Data	{ ... }	{ ... }	Decimal	INT[2]
+ Interface_Card:O.Data[0]	16#0002		Hex	INT
+ Interface_Card:O.Data[1]	6000		Decimal	INT

Figure 45: Controller Tags for I/O Access

Similarly, we can see that the second 16-bit word of output data (Interface_Card:O.Data[1]) has been set to a decimal value of 6000. The default consumed data word configuration word offset 1 references register 2, which is the inverter's frequency command register. A value of 6000, therefore, equates to a frequency command of 60.00Hz.

The input data from the inverter shows similar expected results. Values of 0x004B and 6000 corresponding to registers 100 (status register) and 101 (output frequency), respectively, are consistent with the inverter running at the parameter values commanded by the output tag.



9.2.12.1 ControlLogix Example: Generic Default I/O Add-On Instruction

The generic default I/O add-on instruction is a simple interface to command and monitor the inverter. It is based on the vendor-specific assembly instances 100 & 150 and the default produce and consume data configuration (refer to section 9.2.4).

- 1) Complete all the steps in section 9.2.12.
- 2) Right click on “Add-On Instructions” in the controller organizer view and select “Import Add-On Instruction”. Browse and import the generic default I/O add-on instruction. Refer to Figure 46.
- 3) Double click “Controller Tags” in the controller organizer view and select the “Edit Tags” tab at the bottom.
- 4) Create the tags shown in Figure 47.




Figure 46: Generic Default IO Add-On Instruction

Scope: logix5561		Show: All Tags					
Name	Value	Force Mask	Style	Data Type	Description	Constant	
+ A7NETH_V2:C	{...}	{...}		AB:ETHERNET_...		<input type="checkbox"/>	
+ A7NETH_V2:I	{...}	{...}		AB:ETHERNET_...		<input type="checkbox"/>	
+ A7NETH_V2:O	{...}	{...}		AB:ETHERNET_...		<input type="checkbox"/>	
+ freq_cmd	0		Decimal	INT	Frequency comm...	<input type="checkbox"/>	
fwd	0		Decimal	BOOL	Forward direction	<input type="checkbox"/>	
+ generic_aoi	{...}	{...}		A7NETHV2_Gen...	Simple interface f...	<input type="checkbox"/>	
reset	0		Decimal	BOOL	Reset alarm or fault	<input type="checkbox"/>	
rev	0		Decimal	BOOL	Reverse direction	<input type="checkbox"/>	
run_stop	0		Decimal	BOOL	0 = Run, 1 = Stop	<input type="checkbox"/>	

Figure 47: Create Generic Default AOI Tags

- 5) Double click “MainRoutine” under Tasks...MainTask...MainProgram in the controller organizer view.
- 6) Right click on the first ladder logic rung in the MainRoutine window and select “Add Ladder Element...”
- 7) The “Add Ladder Element” window appears.
- 8) Select the generic default I/O add-on instruction in the Add-On folder. Refer to Figure 48.
- 9) Click OK.
- 10) Edit the add-on instruction according to Figure 49.
- 11) The program is now complete.

12) Save, download and run the program.




Figure 48: Add Generic Default Add-On Instruction




Figure 49: Configure Generic Default AOI

9.2.12.2 ControlLogix Example: AC/DC Drive Profile Add-On Instruction

The AC/DC drive profile add-on instruction is a simple interface to command and monitor the inverter. It is based on the assembly instances 21 & 71.

- 1) Complete all the steps in section 9.2.12. Please note that the Assembly Input Instance must be changed to 71 and the Assembly Output Instance must be changed to 21. Refer to Figure 50.




Figure 50: AC/DC Drive Profile Generic Ethernet Module Configuration

- Right click on “Add-On Instructions” in the controller organizer view and select “Import Add-On Instruction”. Browse and import the AC/DC drive profile add-on instruction. Refer to Figure 51.
- Double click “Controller Tags” in the controller organizer view and select the “Edit Tags” tab at the bottom.
- Create the tags shown in Figure 52.
- Double click “MainRoutine” under Tasks ...MainTask ...MainProgram in the controller organizer view.




Figure 51: AC/DC Drive Profile Add-On Instruction

Scope: logix5561		Show: All Tags		Enter Name Filter...					
	Name	Alias For	Base Tag	Data Type	Description	External Access	Constant	Style	
+	A7NETHV2:C			AB:ETHERNET_MODULE:C:0		Read/Write	<input type="checkbox"/>		
+	A7NETHV2:I			AB:ETHERNET_MODULE_INT_4Bytes:I:0		Read/Write	<input type="checkbox"/>		
+	A7NETHV2:O			AB:ETHERNET_MODULE_INT_4Bytes:O:0		Read/Write	<input type="checkbox"/>		
+	acdc_aoi			A7NETHV2_ACDC_Drive_Profile	Interface for AC/DC Drive Pr...	Read/Write	<input type="checkbox"/>		
	net_ctrl			BOOL	Control from network	Read/Write	<input type="checkbox"/>	Decimal	
	net_ref			BOOL	Speed reference from network	Read/Write	<input type="checkbox"/>	Decimal	
	reset			BOOL	Fault reset	Read/Write	<input type="checkbox"/>	Decimal	
	run_fwd			BOOL	Run forward direction	Read/Write	<input type="checkbox"/>	Decimal	
	run_rev			BOOL	Run reverse direction	Read/Write	<input type="checkbox"/>	Decimal	
+	speed_ref			INT	Speed reference (RPM)	Read/Write	<input type="checkbox"/>	Decimal	

Figure 52: Create AC/DC Drive Profile AOI Tags

- 6) Right click on the first ladder logic rung in the MainRoutine window and select “Add Ladder Element...”
- 7) The “Add Ladder Element” window appears.
- 8) Select the AC/DC drive profile add-on instruction in the Add-On folder. Refer to Figure 53.
- 9) Click OK.
- 10) Edit the add-on instruction according to Figure 54.
- 11) The program is now complete.
- 12) Save, download and run the program.




Figure 53: Add AC/DC Drive Profile Add-On Instruction




Figure 54: Configure AC/DC Drive Profile AOI

9.2.13 ControlLogix Example: Read Registers

This example program will show how to continuously read a block of registers from the inverter with a single MSG instruction. Only one read request is outstanding at any given time.

1) Create new Tags.

- a) Double click “Controller Tags” in the controller organizer view.
- b) The “Controller Tags” window appears. Refer to Figure 55.
- c) Select the “Edit Tags” tab at the bottom.
- d) Create a new tag by entering “connection” in the first blank Name field, and change its Data Type to “MESSAGE”. This tag will contain configuration information for the MSG instruction.
- e) Select the “Monitor Tags” tab. Expand the “connection” tag by clicking on the “+” sign next to the tag name. Scroll down to the connection.UnconnectedTimeout field and change its value from the default 30000000 (30s in 1uS increments) to 1000000 (1s). This value determines how long to wait before timing out and retransmitting a connection request if a connection failure occurs.
- f) Collapse the “connection” tag again by clicking on the “-” sign next to the tag name.




Figure 55: Create New Tags



- g) Select the “Edit Tags” tab again. Create another new tag by entering “data_array” in the next blank Name field, and change its Data Type by typing in “INT[62]” in the Data Type field. This tag is an array of INTs that will be able to hold up to 62 16-bit registers from the inverter. Always make sure that the destination tag size is large enough to hold all elements to be read.

2) Add a MSG instruction to the main program.

- a) Double click “MainRoutine” under Tasks ...MainTask ...MainProgram in the controller organizer view.
- b) Right click on the first ladder logic rung in the MainRoutine window and select “Add Ladder Element...”
- c) The “Add Ladder Element” window appears.
- d) Select the “MSG” instruction in the Input/Output folder. Refer to Figure 56.
- e) Click OK.




Figure 56: Adding a MSG Instruction

3) Add an XIO element to the main program.

- a) Right click on the ladder logic rung containing the MSG instruction in the MainRoutine window and select “Add Ladder Element...” again.
- b) The “Add Ladder Element” window appears.

- c) Select the “XIO” element in the Bit folder. Refer to Figure 57.
 - d) Click OK.
- 4) Configure the MSG instruction.**
- a) Edit the “Message Control” field on the MSG instruction to use the previously-created “connection” tag. Refer to Figure 58.
 - b) Click the message configuration button (“...”) in the MSG instruction. The “Message Configuration” window will open. Refer to Figure 59.
 - c) “Configuration” tab settings:
 - i) Change the “Message Type” to “CIP Data Table Read”.
 - ii) In the “Source Element” field, enter the read tag you wish to access (refer to section 9.2.9). In this example, we will be reading a total of 25 registers beginning at reg_201 (output frequency).




Figure 57: Adding an XIO Element




Figure 58: MSG Instruction Tag Assignment

- iii) Enter the Number Of Elements to read. In this example, we will read 25 registers.
 - iv) For the Destination Element, select “data_array”.
- d) “Communication” tab settings (refer to Figure 60):
- i) Enter the Path to the interface card. A typical path is formatted as “*Local_ENB,2,target_IP_address*”, where:
 - *Local_ENB* is the name of the 1756-ENBx module in the local chassis (we named ours “EIP” in section 9.2.10),
 - 2 is the Ethernet port of the 1756-ENBx module in the local chassis, and
 - *target_IP_address* is the IP address of the target node.

In our example, this path would be entered as “EIP,2,192.168.16.163”.




Figure 59: MSG Instruction Configuration

- ii) If “Cache Connections” is enabled (checked), the connection remains open after transmission. If disabled (unchecked), the connection is opened before and closed after every transmission. For efficiency, it is recommended to enable “Cache Connections”.
- e) Click “OK” to close the MSG Configuration dialog. At this stage, MainRoutine should look like Figure 61.

5) Assign a tag to the XIO element.

- a) Double-click on the XIO element located to the left of the MSG block. In the drop-down box, double-click on the “connection.EN” field. Refer to Figure 62. This configuration causes the MSG instruction to automatically retrigger itself when it completes. While this is acceptable for the purposes of this example, it can produce high network utilization. In actual practice, it may be desirable to incorporate additional logic




Figure 60: Setting the Communication Path




Figure 61: MainRoutine

elements to allow triggering the MSG instruction at a specific rate or under specific conditions.

- 6) The program is now complete. Refer to Figure 63.
- 7) Save, download and run the program.
 - a) To view the values of the registers being read from the interface card, double-click “Controller Tags” in the controller organizer view.
 - b) Select the “Monitor Tags” tab and expand the data_array tag.
 - c) 25 register values starting at register #201 are being continuously read from the interface card and placed in the 25 sequential offsets of data_array starting at the 0th offset.




Figure 62: Configure XIO Element




Figure 63: Complete Program

9.2.14 ControlLogix Example: Reading and Writing Multiple MSG Instructions

Often times, applications may need to both read data from and write data to the inverter. To accomplish this task, multiple MSG instructions will need to be implemented in the PLC program. The configuration and execution for implementing multiple MSG instructions is in general identical to that required for implementing just one MSG instruction. Each MSG instruction will require its own message controller tag.




Figure 64: Reading and Writing via MSG Instructions



Figure 64 shows an example of three MSG instructions, one for reading and two for writing (the inverter's frequency command and command word). Note the addition of the en_xx_wr XIC elements. The reason for the addition of these elements is that while reading from a remote device is often continuously performed (monitoring), data is typically written to the remote device only when necessary (i.e. when the value to write has changed). This conserves both network bandwidth and potentially EEPROM lifespans on the target device. The en_xx_wr elements in this example, therefore, would typically be replaced in an actual application program by user-provided logic that controls the conditions under which write operations would be performed.

Figure 65 shows the configuration details of the example fc_wr_connection MSG instruction. Note that the chosen "Message Type" is "CIP Data Table Write", and that this instruction will only be writing to one inverter register: namely, the frequency command (Destination Element is reg_2). The Source Element in this case is the 2nd element (starting from index 0) of an INT array tag named "wr_data".

Note that when writing data via explicit messaging, use caution to ensure that the commanded registers are not also




Figure 65: MSG Configuration for Writing

simultaneously being commanded in the background via I/O messaging. Indeterminate behavior can occur if MSG instructions and background I/O data transfers are both writing to the same registers. In other words, if the I/O messaging example procedure detailed in section 9.2.12 has already been implemented, and the same program is now being modified to implement explicit messaging, then it is recommended to inhibit the target module by selecting the “Inhibit Module” checkbox in the Connection tab of the Module Properties dialog.



9.3 Allen Bradley CSP (PCCC) Server

9.3.1 Overview

Ethernet-enabled Allen-Bradley legacy PLCs (such as the PLC5E, SLC-5/05, and MicroLogix series) use a protocol called CSP (Client Server Protocol) to communicate over the Ethernet network. The flavor of CSP used by these PLCs is also known as “PCCC” (Programmable Controller Communication Commands) and “AB Ethernet”. The interface card supports CSP for direct connectivity to these PLCs. Note that CSP runs under EtherNet/IP and is enabled by default when EtherNet/IP is added to the configuration.

If a connection timeout or socket-level error occurs, the driver can be configured to perform a timeout action as described in section 9.2.3.

9.3.2 Explicit Messaging Via Read/Write Services

Register contents are read from and written to the interface card via CSP by reference to an integer “file/section number” and an “offset/element” within that file. The supported read and write services are listed in Table 33. To read and write data, the client must reference a “target address” and the “size of elements”. The target address is constructed according to the conventions shown in section 9.3.3.

Table 33: CSP (PCCC) Read/Write Services

Service	Code
PLC5 Typed Read	0x68
PLC5 Typed Write	0x67
PLC5 Word Range Read	0x01
PLC5 Word Range Write	0x00
SLC Typed Read	0xA2
SLC Typed Write	0xAA

9.3.3 Inverter Register File Number Offset Format

The formula to calculate which register is targeted in the interface card is provided in Equation 3.

$$\text{target register} = (\text{file number} - 10) \times 100 + \text{offset} \quad \text{Equation 3}$$

In Equation 3, “target register” $\in [1 \dots 1899]$, “file number” $\in [10 \dots 28]$ (which means N10...N28), and “offset” is restricted only by the limitations of the programming software (but is a value of 1899 max). Refer to section 4.1 for the register list. Table 34 provides some examples of various combinations of file/section numbers and offsets/elements which can be used to access inverter registers. Note that there are multiple different combinations of file/section numbers and offsets/elements that will result in the same inverter register being accessed.


Table 34: CSP Target Register Examples

Target Register	File/Section Number	Offset/Element	Address Format
1	N10	1	N10:1
7	N10	7	N10:7
100	N11	0	N11:0
201	N12	1	N12:1
254	N12	54	N12:54
501	N15	1	N15:1
508	N15	8	N15:8
1000	N20	0	N20:0
1899	N28	99	N28:99

In addition to providing access to the inverter registers in their “standard” numerical locations as mentioned above, the registers can also be accessed in a special “assembly object” type format by targeting integer file N50. What this means is that when N50 is targeted for reading, what is actually returned by the interface card is the user-defined register data as ordered by the EtherNet/IP produced data word configuration (refer to section 9.2.4). Similarly, when N50 is targeted for writing, the written data is disseminated to the inverter’s registers according to the definition contained in the EtherNet/IP consumed data word configuration. By appropriate configuration of the EtherNet/IP consumed and produced data word configuration, therefore, bulk access to non-contiguous but frequently-used inverter registers can be conveniently provided by performing only one read and/or write instruction targeting file N50.

Because both the EtherNet/IP consumed and produced data word configurations are comprised of 32 register definitions, the targeted “offset/element” must be within the range of 0 to 31 inclusive. Refer to Table 35 for some examples of N50 accesses.

Table 35: Examples of EtherNet/IP-Style Bulk Access via File N50

File/Section Number	Offset/Element	Address Format	Start Target Register of Configuration Array	Max Number of Accessible Elements
N50	0	N50:0	1st	32
N50	:	:	:	:
N50	15	N50:15	16th	16
N50	:	:	:	:
N50	31	N50:31	32nd	1

The application PLC program uses a MSG instruction that is configured with a “Data Table Address” from which to start the access and a “Size in Elements” which determines the number of items to access (read or write). The “Data Table Address” is constructed by selecting a “File/Section Number” and an “Offset/Element” according to Equation 3. For example, a “File/Section Number” of N11 and “Offset/Element” of 0 = N11:0, which corresponds to register 100 (the inverter’s status register).



9.3.4 SLC-5/05 Example: Read Registers

This example program will show how to continuously read a block of registers from the inverter with a single MSG instruction. This action is performed via the Typed Read (a.k.a. “PLC5 Read”) message type. Only one read request is outstanding at any given time. Note that the steps for the MicroLogix and PLC5E may vary slightly, but in general are similar.

- 1) **Run RSLogix 500, and create a new configuration.**
- 2) **Create a control and a data file.**
 - a) Right click Data Files and select New... The “Create Data File” dialog box appears (refer to Figure 66).
 - b) To create a control file, enter a file number (e.g. 20), set the type to “Integer”, enter a descriptive name (e.g. “CONTROL”), and enter a number of elements (e.g. 100). Click OK to create the file. The control file is used to store configuration information pertaining to the functionality of the MSG instruction which will perform the data read.
 - c) Follow the same procedure to create a data file. This file will be used to store the incoming data read from the interface card. Enter a file number (e.g. 18), set the type to “Integer”, enter a




Figure 66: Creating a Control File

descriptive name (e.g. “DATA”), and enter a number of elements (e.g. 200). Refer to Figure 67. Click OK to create the file.

3) Add a MSG instruction to the program.

- If not already visible, double-click “LAD2” under Project...Program Files in the controller organizer view to bring up the ladder logic program.
- Right click on the default rung number on the left-hand side of the LAD2 window and select “Insert Rung”.
- Right click on the rung number of the new editable rung and select “Append Instruction”.
- Select the “MSG” instruction from the “Input/Output” classification, then click OK. Refer to Figure 68.

4) Add an XIO element to the program.

- Right click on the rung number of the rung currently being edited and select “Append Instruction” again.
- Select the “XIO” instruction from the “Bit” classification, then click OK. Refer to Figure 69.




Figure 67: Creating a Data File




Figure 68: MSG Instruction Selection




Figure 69: XIO Instruction Selection

5) Configure the MSG instruction.

- a) Set the “Read/Write” field to “Read”, “Target Device” field to “PLC5”, “Local/Remote” field to “Local”, and “Control Block” to “N20:0”.
- b) Upon hitting the <ENTER> key while in the “Control Block” entry box, the MSG Properties dialog box should appear (or it can be opened by clicking on the “Setup Screen” button at the bottom of the MSG instruction). Refer to Figure 70.




Figure 70: MSG Configuration, "General" Tab

- c) In this example, we will be reading a total of 25 registers beginning at N12:1 (register 201, the inverter's "output frequency" register). To configure this, under "This Controller" set the "Data Table Address" field to N18:1, set the "Size in Elements" field to 25, and set the "Channel" field to 1 (Ethernet).

- d) Under “Target Device”, set the “Data Table Address” field to N12:1 (starting target register=201) and set the “MultiHop” field to Yes to cause the “MultiHop” tab to appear.
- e) Under the “MultiHop” tab settings, set the “To Address” in the first row to the inverter’s IP address, and the “To Address” in the second row to 0. Refer to Figure 71.
- f) Close the dialog box. At this point, the program should appear as shown in Figure 72.

6) Assign a tag to the XIO element.

- a) Double-click on the XIO element located to the left of the MSG block. Type in N20:0/15 (MSG instruction’s enable bit). This configuration causes the MSG instruction to automatically retrigger itself when it completes. While this is acceptable for the purposes of this example, it can produce high network utilization. In




Figure 71: MSG Configuration, "MultiHop" Tab




Figure 72: PLC Program after MSG Instruction Configuration

actual practice, it may be desirable to incorporate additional logic elements to allow triggering the MSG instruction at a specific rate or under specific conditions.

- 7) **The program is now complete. Refer to Figure 73.**
- 8) **Save, download, and run the program.**

- a) To view the registers being read from the interface card, double-click the data file N18 under “Data Files” in the controller organizer view. 25 register values starting at register #201 are being continuously read from the interface card and placed in the 25 sequential offsets of N18 starting at N18:1. Refer to Figure 74. We can see that N18:1 (output frequency) has a value of 2000 (20.00Hz), N18:3 (output voltage) has a value of 255 (25.5V), etc.




Figure 73: Completed PLC Program

Offset	0	1	2	3	4	5	6	7	8	9
N18:0	0	2000	0	255	0	2000	600	0	3087	0
N18:10	0	0	3140	0	0	0	19	0	0	0
N18:20	5492	0	0	1619	0	0	0	0	0	0
N18:30	0	0	0	0	0	0	0	0	0	0
N18:40	0	0	0	0	0	0	0	0	0	0
N18:50	0	0	0	0	0	0	0	0	0	0

Symbol: Radix:
 Columns:
 Desc:

Figure 74: Monitoring the Data Being Read from the Inverter

9.3.5 SLC-5/05 Example: Reading and Writing

Often times, applications may need to both read data from and write data to the inverter. To accomplish this task, multiple MSG instructions will need to be implemented in the PLC program. The configuration and execution for implementing multiple MSG instructions is in general identical to that required for implementing just one MSG instruction. Each MSG instruction will require its own message control file.

Figure 75 shows an example of two MSG instructions, one for reading and one for writing. It is evident from this logic that N20 and N21 are the two independent message control files created for these instructions. Note that the “Read/Write” field of each of the MSG instructions is set according to their function.

Figure 76 shows the configuration details of the “write” MSG instruction. Note that this instruction will only be writing to one inverter register: namely, the command word (Target Data Table Address is N10:1, which equates to inverter register 1). The source Data Table Address in this case is N18:30.




Figure 75: Reading and Writing via MSG Instructions

The screenshot shows a configuration window titled "MSG - Rung #2:1 - N21:0". The "General" tab is selected, and the "MultiHop" option is checked. The configuration is divided into several sections:

- This Controller:**
 - Communication Command:
 - Data Table Address:
 - Size in Elements:
 - Channel:
- Target Device:**
 - Message Timeout:
 - Data Table Address:
 - Local / Remote:
 - MultiHop:
- Control Bits:**
 - Ignore if timed out (TO):
 - To be retried (NR):
 - Awaiting Execution (EW):
 - Continuous Run (CO):
 - Error (ER):
 - Message done (DN):
 - Message Transmitting (ST):
 - Message Enabled (EN):
 - Waiting for Queue Space:
- Error:**
 - Error Code(Hex): 0
- Error Description:**
 - No errors

Figure 76: MSG Configuration for Writing

9.4 BACnet/IP Server

- The interface card supports the BACnet/IP (Annex J) protocol over Ethernet via a configurable UDP port.
- The BACnet driver does not trigger timeout events (section 5.4.1).

9.4.1 Protocol Implementation Conformance Statement

BACnet Protocol

Date:	May 13, 2019
Vendor Name:	ICC, Inc.
Product Name:	Mitsubishi Inverter FR-700
Product Model Number:	A7NETH-V2
Applications Software Version:	V1.1.26
Firmware Revision:	V1.1.26
BACnet Protocol Revision:	2
Product Description:	

The Mitsubishi 700-series inverter family represents inverters featuring reduced high-frequency noise, reduced harmonics, and high-precision and high-speed torque control with or without sensors.



BACnet Standard Device Profile (Annex L):

- BACnet Operator Workstation (B-OWS)
- BACnet Building Controller (B-BC)
- BACnet Advanced Application Controller (B-AAC)
- BACnet Application Specific Controller (B-ASC)
- BACnet Smart Sensor (B-SS)
- BACnet Smart Actuator (B-SA)

BACnet Interoperability Building Blocks Supported (Annex K):

- Data Sharing – ReadProperty-B (DS-RP-B)
- Data Sharing – ReadPropertyMultiple-B (DS-RPM-B)
- Data Sharing – WriteProperty-B (DS-WP-B)
- Device Management – Dynamic Device Binding-B (DM-DDB-B)
- Device Management – Dynamic Object Binding-B (DM-DOB-B)

Segmentation Capability:

None

- Segmented requests supported Window Size _____
- Segmented responses supported Window Size _____

Standard Object Types Supported:

See “Object Types/Property Support Table”.

Data Link Layer Options:

- BACnet IP, (Annex J)
- BACnet IP, (Annex J), Foreign Device
- ISO 8802-3, Ethernet (Clause 7)
- ANSI/ATA 878.1, 2.5 Mb. ARCNET (Clause 8)
- ANSI/ATA 878.1, RS-485 ARCNET (Clause 8), baud rate(s) _____
- MS/TP master (Clause 9), baud rate(s): 9600, 19200, 38400, 76800
- MS/TP slave (Clause 9), baud rate(s): _____
- Point-To-Point, EIA 232 (Clause 10), baud rate(s): _____
- Point-To-Point, modem, (Clause 10), baud rate(s): _____
- LonTalk, (Clause 11), medium: _____
- Other: _____

Device Address Binding:

Is static device binding supported? (This is currently for two-way communication with MS/TP slaves and certain other devices.) Yes No



Networking Options:

- Router, Clause 6 - List all routing configurations
- Annex H, BACnet Tunneling Router over IP
- BACnet/IP Broadcast Management Device (BBMD)
 - Does the BBMD support registrations by Foreign Devices? Yes No

Character Sets Supported:

Indicating support for multiple character sets does not imply that they can all be supported simultaneously.

- ANSI X3.4
- IBM™/Microsoft™ DBCS
- ISO 8859-1
- ISO 10646 (UCS-2)
- ISO 10646 (UCS-4)
- JIS C 6226

If this product is a communication gateway, describe the types of non-BACnet equipment/networks(s) that the gateway supports: N/A

Datatypes Supported:

The following table summarizes the datatypes that are accepted (in the case of a write property service) and returned (in the case of a read property service) when targeting the present value property of each supported object type.

Object Type	Service	
	Read Property	Write Property
Analog Output	Real	Real, Unsigned, Integer, Null
Analog Input	Real	N/A
Analog Value	Real	Real, Unsigned, Integer, Null
Binary Output	Enumerated	Enumerated, Boolean, Real, Unsigned, Integer, Null
Binary Input	Enumerated	N/A
Binary Value	Enumerated	Enumerated, Boolean, Real, Unsigned, Integer, Null
Multi-state Output	Unsigned	Enumerated, Real, Unsigned, Integer, Null
Multi-state Input	Unsigned	N/A
Multi-state Value	Unsigned	Enumerated, Real, Unsigned, Integer, Null

Notes:

- The Null data type is used to relinquish a previously-commanded entry at the targeted priority in the priority array.

**Object Types/Property Support Tables:****Table 36: BACnet Device Object Types /Properties Supported**

Property	Object Type
	Device
Object Identifier	R
Object Name	R
Object Type	R
System Status	R
Vendor Name	R
Vendor Identifier	R
Model Name	R
Firmware Revision	R
Appl Software Revision	R
Protocol Version	R
Protocol Revision	R
Services Supported	R
Object Types Supported	R
Object List	R
Max APDU Length	R
Segmentation Support	R
APDU Timeout	R



Property	Object Type
	Device
Number APDU Retries	R
Device Address Binding	R
Database Revision	R

R – readable using BACnet services

W – readable and writable using BACnet services



Table 37: BACnet Binary Object Types /Properties Supported

Property	Object Type		
	Binary Input	Binary Output	Binary Value
Object Identifier	R	R	R
Object Name	R	R	R
Object Type	R	R	R
Present Value	R	W	W
Status Flags	R	R	R
Event State	R	R	R
Out-of-Service	R	R	R
Priority Array		R	R
Relinquish Default		R	R
Polarity	R	R	
Active Text	R	R	
Inactive Text	R	R	

R – readable using BACnet services

W – readable and writable using BACnet services

Table 38: BACnet Analog Object Types /Properties Supported

Property	Object Type		
	Analog Input	Analog Output	Analog Value
Object Identifier	R	R	R
Object Name	R	R	R
Object Type	R	R	R
Present Value	R	W	W
Status Flags	R	R	R
Event State	R	R	R
Out-of-Service	R	R	R
Units	R	R	R
Priority Array		R	R
Relinquish Default		R	R

R – readable using BACnet services

W – readable and writable using BACnet services



Table 39: BACnet Multi-state Object Types /Properties Supported

Property	Object Type		
	Multi-state Input	Multi-state Output	Multi-state Value
Object Identifier	R	R	R
Object Name	R	R	R
Object Type	R	R	R
Present Value	R	W	W
Status Flags	R	R	R
Event State	R	R	R
Out-of-Service	R	R	R
Number of States	R	R	R
Priority Array		R	R
Relinquish Default		R	R

R – readable using BACnet services

W – readable and writable using BACnet services

9.4.2 Default Supported Objects

This section will describe the default objects. Since the objects are configurable, the system integrator is responsible for managing, maintaining, and documenting the actual configuration. Always use the studio to confirm the configuration before commissioning the device.

Table 40: Binary Input Object Instance Summary

Instance ID	Object Name	Description	Active/ Inactive Text
BI1	RUN_STATUS	Run status	running/stopped
BI2	FOR_ROT_STATUS	Forward rotation status	forward/off
BI3	REV_ROT_STATUS	Reverse rotation status	reverse/off
BI4	SU_STATUS	Up to frequency	on/off
BI5	OVERLOAD_STATUS	Overload status	on/off
BI6	IPF_STATUS	Instantaneous power failure	on/off
BI7	FU_STATUS	Frequency detection	on/off
BI8	ABC1_STATUS	Terminal function selection status	on/off
BI9	ABC2_STATUS	Terminal function selection status	on/off
BI10	ALARM_OCC_STATUS	Alarm occurrence status	on/off


Table 41: Binary Output Object Instance Summary

Instance ID	Object Name	Description	Active/ Inactive Text
BO1	AU_SEL	Current input selection	on/off
BO2	FOR_ROT_CMD	Forward rotation command	forward/off
BO3	REV_ROT_CMD	Reverse rotation command	reverse/off
BO4	RL_CMD	Low speed operation command	on/off
BO5	RM_CMD	Medium speed operation command	on/off
BO6	RH_CMD	High speed cooperation command	on/off
BO7	RT_SEL	Second function selection	on/off
BO8	MRS	Output stop	on/off
BO9	JOG_OP	Jog	on/off
BO10	CS_SEL	Auto restart selection after IPF	on/off
BO11	STOP_HOLDING	Start self-holding	on/off
BO12	RESET	Reset	on/off

Table 42: Analog Input Object Instance Summary

Instance ID	Object Name	Description	Units
AI1	OUTPUT_FREQ	Output frequency	Hz
AI2	OUTPUT_CURRENT	Output current	Amps
AI3	OUTPUT_VOLTAGE	Output voltage	Voltage
AI4	INPUT_POWER	Input power	kW
AI5	OUTPUT_POWER	Output power	kW
AI6	CUMULATIVE_POWER	Energy consumption	kWh
AI7	OP_MODE_STATUS	Operation mode status	None
AI8	PID_SET_POINT	PID set point	%
AI9	PID_MEASURED_VALUE	PID measured value	%
AI10	PID_DEVIATION_VALUE	PID deviation value	%

**Table 43: Analog Output Object Instance Summary**

Instance ID	Object Name	Description	Units
AO1	FREQ_CMD_REG	Frequency command register	Hz
AO2	FREQ_CMD_EEPROM_REG	EEPROM Frequency command register	Hz
AO3	OPERATION_MODE	Operation mode register	None
AO4	INVERTER_RESET	Reset	None
AO5	ALARM_CLEAR	Clear alarm	None
AO6	ALL_PARAM_CLEAR	Clear all parameters	None

9.4.3 Default Supported Object Details

This section will describe the default objects details. Since the objects are configurable, the system integrator is responsible for managing, maintaining, and documenting the actual configuration.

Binary Input Objects

- BI1 Indicates the status of the RUN output terminal function configured by *Pr. 190 RUN terminal function selection*. Corresponds to register 100, bit 0 (bitmask 0x0001).
- BI2 Indicates whether the inverter is running forward. Corresponds to register 100, bit 1 (bitmask 0x0002).
- BI3 Indicates whether the inverter is running reverse. Corresponds to register 100, bit 2 (bitmask 0x0004).
- BI4 Indicates the status of the SU output terminal function configured by *Pr. 191 SU terminal function selection*. Corresponds to register 100, bit 3 (bitmask 0x0008).
- BI5 Indicates the status of the OL output terminal function configured by *Pr. 193 OL terminal function selection*. Corresponds to register 100, bit 4 (bitmask 0x0010).
- BI6 Indicates the status of the IPF output terminal function configured by *Pr. 192 IPF terminal function selection*. Corresponds to register 100, bit 5 (bitmask 0x0020).
- BI7 Indicates the status of the FU output terminal function configured by *Pr. 194 FU terminal function selection*. Corresponds to register 100, bit 6 (bitmask 0x0040).



- BI8 Indicates the status of the ABC1 output terminal function configured by *Pr. 195 ABC1 terminal function selection*. Corresponds to register 100, bit 7 (bitmask 0x0080).
- BI9 Indicates the status of the ABC2 output terminal function configured by *Pr. 196 ABC2 terminal function selection*. Corresponds to register 100, bit 8 (bitmask 0x0100).
- BI10 Indicates whether or not the inverter is in an alarm condition. Corresponds to register 100, bit 15 (bitmask 0x8000).

Binary Output Objects

- BO1 Activates the AU input terminal function configured by *Pr. 184 AU terminal function selection*. Corresponds to register 1, bit 0 (bitmask 0x0001).
- BO2 Forward command. Corresponds to register 1, bit 1 (bitmask 0x0002).
- BO3 Reverse command. Corresponds to register 1, bit 2 (bitmask 0x0004).
- BO4 Activates the RL input terminal function configured by *Pr. 180 RL terminal function selection*. Corresponds to register 1, bit 3 (bitmask 0x0008).
- BO5 Activates the RM input terminal function configured by *Pr. 181 RM terminal function selection*. Corresponds to register 1, bit 4 (bitmask 0x0001).
- BO6 Activates the RH input terminal function configured by *Pr. 182 RH terminal function selection*. Corresponds to register 1, bit 5 (bitmask 0x0001).

- BO7 Activates the RT input terminal function configured by *Pr. 183 RT terminal function selection*.
Corresponds to register 1, bit 7 (bitmask 0x0001).
- BO8 Activates the MRS input terminal function configured by *Pr. 187 MRS terminal function selection*.
Corresponds to register 1, bit 10 (bitmask 0x0001).
- BO9 Activates the JOG input terminal function configured by *Pr. 185 JOG terminal function selection*.
Corresponds to register 1, bit 6 (bitmask 0x0001).
- BO10 ... Activates the CS input terminal function configured by *Pr. 186 CS terminal function selection*.
Corresponds to register 1, bit 9 (bitmask 0x0001).
- BO11 ... Activates the STOP input terminal function configured by *Pr. 188 STOP terminal function selection*.
Corresponds to register 1, bit 11 (bitmask 0x0001).
- BO12 ... Activates the RES input terminal function configured by *Pr. 189 RES terminal function selection*.
Corresponds to register 1, bit 12 (bitmask 0x0001).

Analog Input Objects

- AI1 The output frequency of the inverter in 0.01 Hertz units (6000=60.00Hz). Corresponds to register 201.
- AI2 The output current of the inverter in 0.1 or 0.01 Amp units (depends on inverter capacity).
Corresponds to register 202.
- AI3 The output voltage of the inverter in 0.1 Volt units (1000=100.0V). Corresponds to register 203.



- AI4 Input power of the inverter in 0.1 or 0.01 kW units (depends on inverter capacity). Corresponds to register 213.
- AI5 Output power of the inverter in 0.1 or 0.01 kW units (depends on inverter capacity). Corresponds to register 214.
- AI6 Energy consumption in kWh. Corresponds to register 225.
- AI7 Inverter operation mode status. Corresponds to register 101.
- AI8 PID set point monitor in 0.1% units. Corresponds to register 252.
- AI10 PID measurement value monitor in 0.1% units. Corresponds to register 253.
- AI11 PID deviation value monitor in 0.1% units. Corresponds to register 254.

Analog Output Objects

- AO1 The frequency command (RAM) of the inverter in 0.01 Hertz units. Corresponds to register 2.
- AO2 The frequency command (EEPROM) of the inverter in 0.01 Hertz units. Corresponds to register 3.
- AO3 Selects the operation mode of the inverter. Corresponds to register 4.
- AO4 Inverter fault reset command. Corresponds to register 5.
- AO5 Alarm clear command. Corresponds to register 6.
- AO6 All parameter clear command. Corresponds to register 7.

9.4.4 Server Settings

In the studio's **Project** panel, navigate to **A7NETH-V2...Ethernet...BACnet/IP Server**.

UDP Port

This is the UDP port on which to transmit and receive BACnet/IP packets on the local subnet. The default value is 47808 (0xBAC0). To ensure successful communications, use caution when using a port setting other than the default value.

9.4.5 Node Settings

There are no node settings. A node is simply a container for objects.

9.4.6 Device Object Settings

In the studio's **Project** panel, navigate to **A7NETH-V2...Ethernet...BACnet/IP Server...Node...Device Object**.

A Device Object is automatically added to every node, and cannot be removed. The Device Object contains several configurable fields that must be appropriately set for each device residing on a BACnet network.

Device Name

Defines the node's name. The device name must be unique across the entire BACnet network. Enter a string of between 1 and 32 characters in length.



Instance Number

Defines the node's instance number. The instance number must be unique across the entire BACnet network. Enter a value between 0...4194302 (0x0...0x3FFFFE).

9.4.7 BACnet Object Settings

In the studio's **Project** panel, navigate to **A7NETH-V2...Ethernet...BACnet/IP Server...Node** and add an object from the **Available Objects** panel.

The BACnet server hosts BACnet objects which contain many different properties for any BACnet client on the network to access. The driver supports a variety of different BACnet objects. All supported properties of these objects are readable, while only the present value property is writable (for Outputs and Values only).

9.4.7.1 Analog Input Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object's instance number. Enter a value between 0...4194302 (0x0...0x3FFFFE).

Register

The inverter register number (refer to section 4) that the BACnet object's present value will access.

Units

Select the desired units from this dropdown menu. If the desired units are not available in the dropdown menu, select “Other Units” and enter the appropriate enumerated value (as defined by the BACnet Specification) in the “Unit Value” field.

Unit Value

This field is enabled only when the “Units” selection is set to “Other Units”. Enter the appropriate enumerated value (as defined by the BACnet Specification.)

9.4.7.2 Analog Output Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object’s instance number. Enter a value between 0...4194302 (0x0...0x3FFFFE).

Register

The inverter register number (refer to section 4) that the BACnet object’s present value will access.



Units

Select the desired units from this dropdown menu. If the desired units are not available in the dropdown menu, select “Other Units” and enter the appropriate enumerated value (as defined by the BACnet Specification) in the “Unit Value” field.

Unit Value

This field is enabled only when the “Units” selection is set to “Other Units”. Enter the appropriate enumerated value (as defined by the BACnet Specification.)

Relinquish Default

Defines the default value to be used for an object’s present value property when all entries in the object’s priority array are NULL.

9.4.7.3 Analog Value Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object’s instance number. Enter a value between 0...4194302 (0x0...0x3FFFFFFE).

Register

The inverter register number (refer to section 4) that the BACnet object’s present value will access.

Units

Select the desired units from this dropdown menu. If the desired units are not available in the dropdown menu, select “Other Units” and enter the appropriate enumerated value (as defined by the BACnet Specification) in the “Unit Value” field.

Unit Value

This field is enabled only when the “Units” selection is set to “Other Units”. Enter the appropriate enumerated value (as defined by the BACnet Specification.)

Relinquish Default

Defines the default value to be used for an object’s present value property when all entries in the object’s priority array are NULL.

9.4.7.4 Binary Input Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object’s instance number. Enter a value between 0...4194302 (0x0...0x3FFFFE).



Register

The inverter register number (refer to section 4) that the BACnet object's present value will access.

Bitmask

Specifies which bit(s) in the 16-bit value designated by the "Register" that the binary object will map to. This mechanism allows up to 16 binary objects to be simultaneously assigned to one register (each binary object mapping to a single bit of that 16-bit word). It is possible to map binary objects to multiple bits within the designated register.

The effect of the "Bitmask" field when reading: When the present value property of a binary object is read by a BACnet client, the bitmask is used to determine the active/inactive state of the object by inspecting the value in the designated register at the bit location(s) indicated in the bitmask. If all of the bit locations at the designated register are set, then the object's state will be returned as "active". Else, the object's state will be returned as "inactive". This resultant state is reversed prior to being placed on the network if the object's "Polarity" is set to "Reverse".

Active Text

Specifies the description of the object's "active" state. Enter a string of up to 32 characters in length. This field is optional and may be left blank.

Inactive Text

Specifies the description of the object's "inactive" state. Enter a string of up to 32 characters in length. This field is optional and may be left blank.

Polarity

Indicates the relationship between the physical state of the object (as stored in the register) and the logical state represented by the object's present value property. If the physical state is active high, select "Normal" from this dropdown menu. If the physical state is active low, select "Reverse" from this dropdown menu. For further detail, refer to the "Bitmask" behavioral description.

9.4.7.5 Binary Output Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object's instance number. Enter a value between 0...4194302 (0x0...0x3FFFFFFE).

Register

The inverter register number (refer to section 4) that the BACnet object's present value will access.

Bitmask

Specifies which bit(s) in the 16-bit value designated by the "Register" that the binary object will map to. This mechanism allows up to 16 binary objects to be simultaneously assigned to one register (each binary object mapping to a single bit of that 16-bit word). It is possible to map binary objects to multiple bits within the designated register.



The effect of the “Bitmask” field when writing: When the present value property of a binary object is set to “active” by a BACnet client, then the bit(s) in the designated register indicated by the bitmask are set. Similarly, when the present value property of the object is set to “inactive”, then the bit(s) in the designated register indicated by the bitmask are cleared. This setting/clearing behavior is reversed if the object’s “Polarity” is set to “Reverse”.

The effect of the “Bitmask” field when reading: When the present value property of a binary object is read by a BACnet client, the bitmask is used to determine the active/inactive state of the object by inspecting the value in the designated register at the bit location(s) indicated in the bitmask. If all of the bit locations at the designated register are set, then the object’s state will be returned as “active”. Else, the object’s state will be returned as “inactive”. This resultant state is reversed prior to being placed on the network if the object’s “Polarity” is set to “Reverse”.

Active Text

Specifies the description of the object’s “active” state. Enter a string of up to 32 characters in length. This field is optional and may be left blank.

Inactive Text

Specifies the description of the object’s “inactive” state. Enter a string of up to 32 characters in length. This field is optional and may be left blank.

Polarity

Indicates the relationship between the physical state of the object (as stored in the register) and the logical state represented by the object’s present value property. If the physical state is active high, select

“Normal” from this dropdown menu. If the physical state is active low, select “Reverse” from this dropdown menu. For further detail, refer to the “Bitmask” behavioral description.

Relinquish Default

Defines the default value to be used for an object’s present value property when all entries in the object’s priority array are NULL.

9.4.7.6 Binary Value Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object’s instance number. Enter a value between 0...4194302 (0x0...0x3FFFFFFE).

Register

The inverter register number (refer to section 4) that the BACnet object’s present value will access.

Bitmask

Specifies which bit(s) in the 16-bit value designated by the “Register” that the binary object will map to. This mechanism allows up to 16 binary objects to be simultaneously assigned to one register (each binary object mapping to a single bit of that 16-bit word). It is possible to map binary objects to multiple bits within the designated register.



The effect of the “Bitmask” field when writing: When the present value property of a binary object is set to “active” by a BACnet client, then the bit(s) in the designated register indicated by the bitmask are set. Similarly, when the present value property of the object is set to “inactive”, then the bit(s) in the designated register indicated by the bitmask are cleared.

The effect of the “Bitmask” field when reading: When the present value property of a binary object is read by a BACnet client, the bitmask is used to determine the active/inactive state of the object by inspecting the value in the designated register at the bit location(s) indicated in the bitmask. If all of the bit locations at the designated register are set, then the object’s state will be returned as “active”. Else, the object’s state will be returned as “inactive”.

Active Text

Specifies the description of the object’s “active” state. Enter a string of up to 32 characters in length. This field is optional and may be left blank.

Inactive Text

Specifies the description of the object’s “inactive” state. Enter a string of up to 32 characters in length. This field is optional and may be left blank.

Relinquish Default

Defines the default value to be used for an object’s present value property when all entries in the object’s priority array are NULL.



9.4.7.7 Multi-state Input Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object's instance number. Enter a value between 0...4194302 (0x0...0x3FFFFFFE).

Register

The inverter register number (refer to section 4) that the BACnet object's present value will access.

9.4.7.8 Multi-state Output Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object's instance number. Enter a value between 0...4194302 (0x0...0x3FFFFFFE).

Register

The inverter register number (refer to section 4) that the BACnet object's present value will access.



Relinquish Default

Defines the default value to be used for an object's present value property when all entries in the object's priority array are NULL.

9.4.7.9 Multi-state Value Object Settings

Object Name

The name of the BACnet object. Enter a string of between 1 and 32 characters in length. All object names must be unique within a node.

Instance

The BACnet object's instance number. Enter a value between 0...4194302 (0x0...0x3FFFFE).

Register

The inverter register number (refer to section 4) that the BACnet object's present value will access.

Relinquish Default

Defines the default value to be used for an object's present value property when all entries in the object's priority array are NULL.

9.5 MELSEC / SLMP Server

9.5.1 Overview

The Mitsubishi MELSEC communication protocol (MC protocol) is also known as SLMP (Seamless Messaging Protocol). It is an application-level protocol implemented on top of the Ethernet TCP/IP and UDP/IP layers that is typically used to read and write data from/to devices supporting compatible 4E (MT), 3E (ST) and 1E frame types. As a server device, the interface card is waiting for a client device to initiate a request. The interface card will then respond with the appropriate data.

For more information regarding the MELSEC protocol, refer to the Mitsubishi MELSEC Communication Protocol reference manual. The SMLP specification is available from CLPA (CC-Link Partner Association).

Other notes of interest include:

- Supports both TCP and UDP simultaneously.
- Supports up to 8 simultaneous TCP connections.
- The TCP port is user-configurable.
- The UDP port is user-configurable and defines both the local source port as well as the remote destination port.
- The max frame size is 1460 bytes.



- The 3E/4E Device Memory Random Write command will attempt to write to all requested device points even if an error is encountered. Ensure that all requested device points are valid before using Device Memory Random Write.
- The driver can be configured to detect a timeout (communication loss) and perform a timeout action.

9.5.2 Read/Write Commands

If applicable, the network number is 0, the PC number (node number) is 0xFF, the module I/O number (process number) is 0x3FF, and the module station number is 0.

Table 44 lists the supported commands. Device read/write commands only support 16-bit word access.

Table 44: MELSEC / SLMP Server Commands

Frame Type	Command Name	Command Code	Subcommand Code	Max Points
3E/4E	CPU Model Read	0x0101	0x0000	-
3E/4E	Node Search	0x0E30	0x0000	-
3E/4E	IP Address Set	0x0E31	0x0000	-
3E/4E	Device Info Compare	0x0E32	0x0000	-
3E/4E	Status Read	0x0E44	0x0000	-
3E/4E	Communication Setting Get	0x0E45	0x0000	-
3E/4E	Device Memory Batch Read	0x0401	0x0000	724 (3E) / 722 (4E)
3E/4E	Device Memory Batch Write	0x1401	0x0000	719 (3E) / 717 (4E)
3E/4E	Device Memory Random Read	0x0403	0x0000	360 (3E) / 359 (4E)

3E/4E	Device Memory Random Write	0x1402	0x0000	360 (3E) / 358 (4E)
1E	Device Memory Batch Read	0x01	-	256
1E	Device Memory Batch Write	0x03	-	256

Table 45 lists the supported internal device memory types. There is no functional difference between the device types. All device types are equal and simply provide access to the register mapping.

Table 45: MELSEC / SLMP Server Device Types

Device Type	3E/4E Device Code	1E Device Code	Data Type
Data Register	0xA8	0x4420	16-Bit Word
Link Register	0xB4	0x5720	16-Bit Word
Index Register	0xCC	-	16-Bit Word
File Register	0xAF, 0xB0	0x5220, 0x5A52	16-Bit Word

The device point is the register number (refer to section 4.1).

9.5.3 Server Settings

In the studio's Project panel, navigate to **A7NETH-V2...Ethernet...MELSEC/SLMP Server**.

TCP Port

Defines the local TCP port (1025...65534) on which the driver will listen for connections from the client. Ensure that this port assignment is unique, and does not conflict with ports utilized by other drivers.



UDP Port

Defines the local UDP port (1025...65534) on which the driver will listen for requests from the client. Ensure that this port assignment is unique, and does not conflict with ports utilized by other drivers.

9.5.4 Connection Timeout Options

In the studio's Project panel, navigate to **A7NETH-V2...Ethernet...MESLEC/SLMP Server**. The following configuration options will determine the actions to be taken if the connection is abnormally terminated or lost. While this feature provides an additional level of fail-safe functionality for those applications that require it, there are several ramifications that must be understood prior to enabling this capability. Note that a certain degree of caution must be exercised when using the timeout feature to avoid "nuisance" timeouts from occurring.

Enable Supervisory Timer

This timer provides the ability for the driver to monitor timeout occurrences on the overall receive activity for all connections.

- The timer will start after receiving the first request. Once the timer is started, it cannot be disabled.
- If the driver experiences no receive activity for more than the **Timeout** time setting, then the driver assumes that the client or network has experienced some sort of unexpected problem, and will perform the **Timeout Action**.

Enable Connection Timer

This timer provides the ability for the driver to monitor timeout occurrences and errors within the scope of each client connection.



- If a particular open socket experiences no activity for more than the **Timeout** time setting, then the driver assumes that the client or network has experienced some sort of unexpected problem, and will close that socket and perform the **Timeout Action**.
- If a socket error occurs (regardless of whether the error was due to a communication lapse or abnormal socket error), the driver will perform the **Timeout Action**. Specifically, do not perform inadvisable behavior such as sending a request from the client device, and then closing the socket prior to successfully receiving the server’s response. The reason for this is because the server will experience an error when attempting to respond via the now-closed socket. Always be sure to manage socket life cycles “gracefully”, and do not abandon outstanding requests.

Timeout

Defines the maximum number of milliseconds for a break in network communications before a timeout event will be triggered.

Timeout Action

Select an action from the drop down menu:

“None”.....No effect. The inverter will continue to operate with the last available settings.

“Apply Fail-safe Values”Apply the fail-safe values as described in section 5.4.1.



9.6 CC-Link IE Field Basic Server

9.6.1 Overview

CC-Link IE Field Basic (CCIEF Basic) is an application-level protocol implemented on top of the Ethernet UDP/IP layer. As a server device, the interface card is waiting for a client device to initiate cyclic communication containing the cyclic RWw (command) data. The interface card will then respond with cyclic RWr (status) data.

For more information regarding the CC-Link IE Field Basic protocol and specification, contact the CLPA (CC-Link Partner Association).

Other notes of interest include:

- The UDP port is 61450.
- Occupies 1 station.
- Supports up to 32 cyclic RWw (command) words and 32 cyclic RWr (status) words.
- The cyclic RX and RY points are not used and can be ignored.
- The driver can be configured to detect a timeout (communication loss) and perform a timeout action.

9.6.2 Server Settings

In the studio's Project panel, navigate to **A7NETH-V2...Ethernet...CC-Link IE Field Basic Server**.

Timeout Action

Select an action from the drop down menu:

“None”.....No effect. The inverter will continue to operate with the last available settings.

“Apply Fail-safe Values”.....Apply the fail-safe values as described in section 5.4.1.

9.6.3 Produced and Consumed Data Settings

In the studio's **Project** panel, add **A7NETH-V2...Ethernet...CC-Link IE Field Basic Server ...Produced I/O Data...Produced Data Word** and/or **Consumed I/O Data...Consumed Data Word**.

The Produced Data Word objects defines the structure of cyclic RWr status words sent from the inverter back to the controller. The Consumed Data Word objects will define the structure of the cyclic RWw command words sent from the CC-Link IE Field Basic controller to the inverter. These objects allow the creation of custom-built I/O data. Up to 32 “command” register values can be sent to the inverter, and up to 32 “status” register values can be sent back to the controller. Therefore, up to 32 Produced and 32 Consumed Data Word objects can be created. If a consumed word offset is not defined, that data will be ignored by the inverter. If a produce word offset is not defined, the value will default to 0. The I/O data format is summarized in Table 46.

Description

This 32-character (max) field is strictly for user reference: it is not used at any time by the driver.



Produced Data Word Offset

The value from the associated inverter register will populate this word offset of the produced data that is to be sent to the client. It is recommend to start at word offset 0.

Consumed Data Word Offset

The consumed data received from the client at this word offset will contain the value to be written to the associated inverter register. It is recommend to start at word offset 0.

Register

The inverter register (refer to section 4) associated with the word offset. For the Produced Data Word object, enter a “status” register to be monitored. For the Consumed Data Word object, enter a “command” register that can be written.

Data Type

Each data word is fixed to 16-Bit Unsigned. This is equivalent to two bytes.

Table 46: CC-Link IE Field Basic User-Configurable I/O Data Format

Consumed Data (PLC to Inverter)		Produced Data (Inverter to PLC)	
Word Offset	Register	Word Offset	Register
0	Any	0	Any
1	Any	1	Any
:	Any	:	Any
30	Any	30	Any
31	Any	31	Any

The default I/O configuration is described in Table 47. Always use the studio to confirm the configuration before commissioning the device.

Table 47: CC-Link IE Field Basic Default User-Configurable I/O Data Format

Consumed Data (PLC to Inverter)		Produced Data (Inverter to PLC)	
Word Offset	Register	Word Offset	Register
0	1	0	100
1	2	1	201
:	None	:	None



9.7 MELSEC Client

9.7.1 Overview

The Mitsubishi MELSEC communication protocol (MC protocol) is an application-level protocol implemented on top of the Ethernet TCP/IP and UDP/IP layers that is typically used to read and write data from/to devices supporting compatible 4E (MT), 3E (ST) and 1E frame types. As a client device, the interface card will initiate a read/write request to a server device. The server device will then respond with the appropriate data.

For more information regarding the MELSEC protocol, refer to the Mitsubishi MELSEC Communication Protocol reference manual.

Other notes of interest include:

- Supports both TCP and UDP transport layers.
- Target up to 8 remote server devices.
- Supports option to auto-detect the frame type. The frame type is prioritized in the following order: 3E, 4E, and 1E. Otherwise the frame type can be manually selected (refer to the server equipment user's manual).
- User-specified device codes allow the ability to target any device type, even if the device is not explicitly supported by the driver.
- The driver can be configured to perform a timeout action.

9.7.2 Read/Write Commands

Table 48 lists the supported commands. Device read/write commands only support 16-bit word access.

Table 48: MELSEC Client Commands

Frame Type	Command Name	Command Code	Subcommand Code	Max Points
3E/4E	Device Memory Batch Read	0x0401	0x0000	719
3E/4E	Device Memory Batch Write	0x1401	0x0000	719
1E	Device Memory Batch Read	0x01	-	256
1E	Device Memory Batch Write	0x03	-	256

9.7.3 Connection Timeout Options

In the studio's Project panel, navigate to **A7NETH-V2...Ethernet...MELSEC Client**. The following configuration options will determine the actions to be taken if the connection is abnormally terminated or lost. While this feature provides an additional level of fail-safe functionality for those applications that require it, there are several ramifications that must be understood prior to enabling this capability. Note that a certain degree of caution must be exercised when using the timeout feature to avoid "nuisance" timeouts from occurring.

Timeout Action

Select an action from the drop down menu:

"None".....No effect. The inverter will continue to operate with the last available settings.



“Apply Fail-safe Values”Apply the fail-safe values as described in section 5.4.1.

9.7.4 Remote Device Settings

In the studio’s Project panel, navigate to **A7NETH-V2...Ethernet...MELSEC Client...Remote Device**.

Name

This 32-character (max) field is strictly for user reference: it is not used at any time by the driver.

IP Address

Defines the destination IP address. This is the IP address of the targeted remote server device.

Transport Type

Select TCP or UDP.

TCP Port

This field is only enabled only if the **Transport Type** is set to TCP. Defines the destination TCP port (1...65535). This is the “listening” port on the server.

UDP Port

This field is only enabled only if the **Transport Type** is set to UDP. Defines the destination UDP port (1...65535). This is the “listening” port on the server. This also defines the local source port. Ensure that this port assignment is unique, and does not conflict with ports utilized by other drivers.

Response Timeout

Defines the time in milliseconds to wait for a response from the server, after sending a request. If a response is not received within this time, the **Timeout Action** is performed.

Request Delay

Defines the time in milliseconds to wait before sending the next request.

Frame Type

This field designates the frame type to use when communicating with the server. If the required Frame Type is unknown, Auto-Detect can be selected to automatically determine the frame type when the driver establishes initial contact with the server. In this case, once the frame type has been successfully detected, the driver will then remember this type and use it as the initial preference for subsequent connection attempts. The frame type is prioritized in the following order: 3E, 4E and 1E. Note that the auto-detection procedure may cause a communication error to be indicated on the server during the initial connection attempt, but this error can be cleared by power-cycling the server. To determine the required Frame Type for your equipment, please consult the server device documentation.

9.7.5 Command and Monitor Data Object Settings

In the studio's **Project** panel, add **A7NETH-V2...Ethernet...MELSEC Client...Command Data** and/or **Monitor Data**. The **Command Data** object will execute the Device Batch Read command to read command data from the targeted remote server device. The **Monitor Data** object will execute the Device Batch Write command to write status data to the targeted remote server device.



Description

This 32-character (max) field is strictly for user reference: it is not used at any time by the driver.

Device Code

For user convenience, a selection of well-known device codes are provided. However, this in no way limits the variety of device codes that can be targeted. Any device code that is supported by the server device can be specified by choosing “Other Device Code” from the drop-down box, and then entering the code in the **Code Value** field.

Code Value

This field is enabled only if **Device Code** is set to “Other Device Code”. If the desired device code is not available in the **Device Code** drop-down, then choose “Other Device Code” and enter the appropriate code in this field.

Starting Point

Specifies the initial point in a device's range of points. Enter a value from 0...16777215 (0x0...0xFFFFFFFF). If the connection uses 1E frames and the **Device Code** or **Code Value** targets a bit device, then the starting point should be a multiple of 16.

Number of Words

Specifies the number of words (1...719) from the **Starting Point** that are to be accessed. If the connection uses 1E frames, then the maximum value should be limited to 256 words: if a larger value is entered, the value will be internally limited to 256. The server may also impose additional device-specific limitations (please consult the server device's documentation).

Register

The inverter register (refer to section 4) associated with the word offset. For the Monitor Data object, enter a “status” register to be monitored. For the Command Data object, enter a “command” register that can be written.

Network Number

Specifies the network number of the target station. Fixed to 0.

PC/Station Number

Specifies the PC/station number of the target station. Fixed to 0xFF.

Module IO Number

Specifies the module I/O number (also known as the processor number) of the target station. Fixed to 0x3FF.

9.7.6 Diagnostic Objects

Each command and monitor data object can optionally include a diagnostics object for debugging and diagnostics. Refer to section 5.9.

Diagnostic Index

Enter the diagnostic index at which to store the diagnostics information.



9.8 SLMP Client

9.8.1 Overview

SLMP (Seamless Messaging Protocol) is an application-level protocol implemented on top of the Ethernet TCP/IP and UDP/IP layers that is typically used to read and write data from/to devices supporting compatible 4E (MT) and 3E (ST) frame types. As a client device, the interface card will initiate a read/write request to a server device. The server device will then respond with the appropriate data.

For more information regarding the SLMP, the specification is available from CLPA (CC-Link Partner Association).

Other notes of interest include:

- Supports both TCP and UDP transport layers.
- Target up to 8 remote server devices.
- Supports option to auto-detect the frame type. The frame type is prioritized in the following order: 3E and 4E. Otherwise the frame type can be manually selected (refer to the server equipment user's manual).
- User-specified device codes allow the ability to target any device type, even if the device is not explicitly supported by the driver.
- The driver can be configured to perform a timeout action.

9.8.2 Read/Write Commands

Table 48 lists the supported commands. Device read/write commands only support 16-bit word access.

Table 49: MELSEC Client Commands

Frame Type	Command Name	Command Code	Subcommand Code	Max Points
3E/4E	Device Memory Batch Read	0x0401	0x0000	719
3E/4E	Device Memory Batch Write	0x1401	0x0000	719

9.8.3 Connection Timeout Options

In the studio's Project panel, navigate to **A7NETH-V2...Ethernet...SLMP Client**. The following configuration options will determine the actions to be taken if the connection is abnormally terminated or lost. While this feature provides an additional level of fail-safe functionality for those applications that require it, there are several ramifications that must be understood prior to enabling this capability. Note that a certain degree of caution must be exercised when using the timeout feature to avoid "nuisance" timeouts from occurring.

Timeout Action

Select an action from the drop down menu:

"None".....No effect. The inverter will continue to operate with the last available settings.

"Apply Fail-safe Values"Apply the fail-safe values as described in section 5.4.1.



9.8.4 Remote Device Settings

In the studio's Project panel, navigate to **A7NETH-V2...Ethernet... SLMP Client...Remote Device**.

Name

This 32-character (max) field is strictly for user reference: it is not used at any time by the driver.

IP Address

Defines the destination IP address. This is the IP address of the targeted remote server device.

Transport Type

Select TCP or UDP.

TCP Port

This field is only enabled only if the **Transport Type** is set to TCP. Defines the destination TCP port (1...65535). This is the "listening" port on the server.

UDP Port

This field is only enabled only if the **Transport Type** is set to UDP. Defines the destination UDP port (1...65535). This is the "listening" port on the server. This also defines the local source port. Ensure that this port assignment is unique, and does not conflict with ports utilized by other drivers.

Response Timeout

Defines the time in milliseconds to wait for a response from the server, after sending a request. If a response is not received within this time, the **Timeout Action** is performed.

Request Delay

Defines the time in milliseconds to wait before sending the next request.

Frame Type

This field designates the frame type to use when communicating with the server. If the required Frame Type is unknown, Auto-Detect can be selected to automatically determine the frame type when the driver establishes initial contact with the server. In this case, once the frame type has been successfully detected, the driver will then remember this type and use it as the initial preference for subsequent connection attempts. The frame type is prioritized in the following order: 3E and 4E. Note that the auto-detection procedure may cause a communication error to be indicated on the server during the initial connection attempt, but this error can be cleared by power-cycling the server. To determine the required Frame Type for your equipment, please consult the server device documentation.

9.8.5 Command and Monitor Data Object Settings

In the studio's **Project** panel, add **A7NETH-V2...Ethernet... SLMP Client...Command Data** and/or **Monitor Data**. The **Command Data** object will execute the Device Batch Read command to read command data from the targeted remote server device. The **Monitor Data** object will execute the Device Batch Write command to write status data to the targeted remote server device.



Description

This 32-character (max) field is strictly for user reference: it is not used at any time by the driver.

Device Code

For user convenience, a selection of well-known device codes are provided. However, this in no way limits the variety of device codes that can be targeted. Any device code that is supported by the server device can be specified by choosing “Other Device Code” from the drop-down box, and then entering the code in the **Code Value** field.

Code Value

This field is enabled only if **Device Code** is set to “Other Device Code”. If the desired device code is not available in the **Device Code** drop-down, then choose “Other Device Code” and enter the appropriate code in this field.

Starting Point

Specifies the initial point in a device's range of points. Enter a value from 0...16777215 (0x0...0xFFFFFFFF). If the connection uses 1E frames and the **Device Code** or **Code Value** targets a bit device, then the starting point should be a multiple of 16.

Number of Words

Specifies the number of words (1...719) from the **Starting Point** that are to be accessed. The server may also impose additional device-specific limitations (please consult the server device's documentation).

Register

The inverter register (refer to section 4) associated with the word offset. For the Monitor Data object, enter a “status” register to be monitored. For the Command Data object, enter a “command” register that can be written.

Network Number

Specifies the network number of the target station (0x0...0xEF).

Node Number

Specifies the node number of the target station (0x1...0x78, 0x7D, 0x7E, 0xFF).

Processor Number

Specifies the processor number of the target station (0x3D0...0x3D3, 0x3E0...0x3E3, 0x3FF).

9.8.6 Diagnostic Objects

Each command and monitor data object can optionally include a diagnostics object for debugging and diagnostics. Refer to section 5.9.

Diagnostic Index

Enter the diagnostic index at which to store the diagnostics information.



9.9 PROFINET IO

9.9.1 Overview

The PROFINET IO device driver allows a controller to interact with the interface card via cyclic data exchange and acyclic read/write requests. The I/O data is entirely user-configurable, and is utilized when a standard I/O module is chosen during network configuration.

Other notes of interest include:

- Allows simultaneous access to only 1 PROFINET controller.
- Supports conformance class B and real time (RT) communication.
- Supports the highest Netload Class III.
- Supports MRP (Media Redundancy Protocol) client.
- Supports DCP (Discovery Control Protocol).
- Supports alarms.
- Supports I&M.
- The lowest supported I/O Cycle Update Time (via STEP 7 or an equivalent hardware configuration tool) is 1ms.
- The GSDML file can be obtained from the [product web page](#).
- Supports several user configurable I/O modules with up to 32 input words and 32 output words.
- Supports the PROFIdrive profile version 4.1.

- No explicit module selection is required on the interface card: the module will be selected automatically according to the controller's configuration.
- If a timeout (communication loss) occurs on the RT connection, the driver can be configured to perform a timeout action. The timeout value is dictated by the PROFINET controller and is at least three times the IO Cycle update time. The timeout value is also known as the "IO Cycle Watchdog" time.

9.9.2 Device Settings

In the studio's **Project** panel, navigate to **A7NETH-V2...Ethernet...PROFINET IO**.

Device Name

The device name / station name must be unique across the entire PROFINET network, because it is used by controllers to uniquely identify PROFINET devices. This string must conform to the device name requirements contained in the PROFINET specification.

9.9.3 Connection Timeout Options

In the studio's **Project** panel, navigate to **A7NETH-V2...Ethernet...PROFINET IO**. The following configuration options will determine the actions to be taken by the card if the PROFINET IO connection is abnormally terminated or lost.

Timeout Action

Select an action from the drop down menu:



“None”.....No effect. The inverter will continue to operate with the last available settings.

“Apply Fail-safe Values”.....Apply the fail-safe values as described in section 5.4.1.

9.9.4 Cyclic I/O Produced and Consumed Data Access Settings

In the studio’s **Project** panel, navigate to **A7NETH-V2...Ethernet...PROFINET IO...Produced Data Word** and/or **Consumed Data Word**.

The Produced Data Word and Consumed Data Word objects are only applicable when using the I/O module “IN: 32 WORDS, OUT: 32 WORDS”, which is typically the case. The Produced Data Word defines the structure of status data sent from the inverter to the controller. The Consumed Data Word objects will define the structure of the command data sent from the controller (for example, a Siemens PLC) to the inverter. These objects allow the creation of custom-built I/O data. Up to 32 “command” register values can be sent to the inverter, and up to 32 “status” register values can be sent back to the controller. Therefore, up to 32 Produced and 32 Consumed Data Word objects can be created. If a consumed word offset is not defined, that data will be ignored by the inverter. If a produce word offset is not defined, the value will default to 0. The size of the actual I/O produced and consumed data is determined by the PROFINET controller. The I/O data format is summarized in Table 50.

Description

This 32-character (max) field is strictly for user reference: it is not used at any time by the driver.

Produced Data Word Offset

The value from the associated inverter register will populate this word offset of the produced data that is to be sent to the controller. It is recommended to start at word offset 0.

Consumed Data Word Offset

The consumed data received from the controller at this word offset will contain the value to be written to the associated inverter register. It is recommended to start at word offset 0.

Register

The inverter register (refer to section 4) associated with the word offset. For the Produced Data Word object, enter a “status register to be monitored. For the Consumed Data Word object, enter a “command” register that can be written.

Data Type

Each data word is fixed to 16-Bit Unsigned. This is equivalent to two bytes. The data word is transferred in little endian format.



Table 50: PROFINET User Configurable Module I/O Data Format

Consumed Data (PLC to Inverter)		Produced Data (Inverter to PLC)	
Word Offset	Inverter Register	Word Offset	Inverter Register
0	Any	0	Any
1	Any	1	Any
:	Any	:	Any
30	Any	30	Any
31	Any	31	Any

The default I/O configuration is described in Table 51. Always use the studio to confirm the configuration before commissioning the device.

Table 51: PROFINET Default User Configurable Module I/O Data Format

Consumed Data (PLC to Inverter)		Produced Data (Inverter to PLC)	
Word Offset	Inverter Register	Word Offset	Inverter Register
0	1	0	100
1	2	1	201
:	None	:	None

9.9.5 PROFdrive Profile

For optimal interoperability, the interface card supports the PROFdrive profile version 4.1. Use of the PROFdrive profile is optional and is not recommended unless specifically required in the PROFINET system specification. No explicit configuration of the interface card is necessary in the studio when using the PROFdrive profile. The controller **must** support the PROFdrive profile and **must** be configured to use the “Standard Telegram 1” module on the interface card. If the controller does not support the PROFdrive profile, use the configurable I/O “IN: 32 WORDS, OUT: 32 WORDS” module. The PROFdrive profile is only partially described in this manual due to its complexity. The complete PROFdrive profile specifications can be obtained from <http://www.profibus.com/>.

- Implements Application Class 1 (standard drive)
- Supports only Standard Telegram 1 (ST1, PZD-2/2) on slot 1 (similar to PROFIBUS PPO type 3)
- Supports only Speed Control Mode

9.9.5.1 PROFdrive Standard Telegram 1

The standard telegram 1 mapping is described in Table 52.

Table 52: Standard Telegram 1

IO Data Word Offset	Setpoint (PLC to Inverter)		Actual Value (Inverter to PLC)	
	Significance	Description	Significance	Description
0	STW1	Control word 1	ZSW1	Status word 1
1	NSOLL_A	Reference speed setpoint	NIST_A	Speed actual



9.9.5.2 PROFIdrive Control and Status Words

The control word, STW1, is the principal means for controlling the drive. It is sent by the controller (PLC) to the device (inverter). The bitmapping for the control word is described in Table 53. The status word, ZSW1, returns status information from the inverter to the controller. The bitmapping for the status word is described in Table 54.

Table 53: STW1 Control Word Mapping

Bit	Value	Significance	Description
0	1	ON	Run command ON
	0	OFF	Run command OFF
1	1	ON2	No coast stop
	0	OFF2	Coast to a stop
2	1	ON3	No quick stop
	0	OFF3	Quick stop
3	1	Enable Operation	Enable inverter operation
	0	Disable Operation	Disable inverter operation
4	1	Enable Ramp Generator	Enable the ramp frequency generator (RFG)
	0	Disable Ramp Generator	Hold the output frequency to 0 Hz
5	1	Unfreeze Ramp Generator	Unfreeze the RFG
	0	Freeze Ramp Generator	Freeze the RFG with the current output frequency

Bit	Value	Significance	Description
6	1	Enable Setpoint	Enable command
	0	Disable Setpoint	Disable command
7	1	Fault Acknowledge	Reset the alarm on a positive edge (0→1 transition)
	0	No significance	Do not reset the alarm
8 - 9	Not used	---	---
10	1	Control By PLC	Enable remote control. The IO process data is valid.
	0	No Control By PLC	Disable remote control. The IO process data is not valid.
11 - 15	Not used	---	---


Table 54: ZSW1 Status Word Mapping

Bit	Value	Significance	Description
0	1	Ready To Switch ON	Ready to run command ON
	0	Not Ready To Switch ON	Not ready to run command ON
1	1	Ready to Operate	Ready to run
	0	Not Ready To Operate	Not ready to run
2	1	Operation Enabled	Running
	0	Operation Disabled	Running disabled
3	1	Fault Present	Inverter tripped as indicated by register 100 bit 15
	0	No Fault	No trip present as indicated by register 100 bit 15
4	1	Coast Stop Not Activated	Follows STW1 bit 1, ON2 active
	0	Coast Stop Activated	Follows STW1 bit 1, OFF2 active
5	1	Quick Stop Not Activated	Follows STW1 bit 2, ON3 active
	0	Quick Stop Activated	Follows STW1 bit 2, OFF3 active
6	1	Switch ON Inhibited	Not ready to run command ON
	0	Switch ON Not Inhibited	Ready to run command ON
7	Not used	---	---
8	1	Speed Within Tolerance	Actual value equals the reference value and is within the tolerance as indicated by SU. Refer to register 100 bit 3.

Bit	Value	Significance	Description
	0	Speed Out Of Tolerance	Actual value differs from the reference value or is outside of the tolerance as indicated by SU. Refer to register 100 bit 3.
9	1	Control Requested	Control by PLC is possible when the operation mode status (register 101) is reporting network operation.
	0	No Control Requested	Control is not possible by the controller when the operation mode status (register 101) is not reporting network operation mode. The inverter must be explicitly set to network operation mode.
10	1	Frequency Reached Or Exceeded	The actual value \geq max reference value. Refer to <i>Pr. 1</i> (maximum frequency).
	0	Frequency Not Reached	The actual value $<$ max reference value. Refer to <i>Pr. 1</i> (maximum frequency).
11 - 15	Not used	---	---



9.9.5.3 PROFIdrive Reference Speed Setpoint and Actual Speed

The speed setpoint value, NSOLL_A, is the commanded speed reference (normalized) sent from the controller to the inverter. Similarly, the speed actual value, NIST_A, is the actual operating speed (normalized) of the inverter sent back to the controller. As the inverter natively operates in units of Hz or RPM depending on certain combinations of *Pr. 37* and *Pr. 144*, the interface card must apply conversion equations to and from the normalized values. Refer to Table 55 to determine the appropriate conversion equations. For more information on the manners in which *Pr. 37* and *Pr. 144* affect the inverter's operation, please refer to the appropriate inverter user's manual.

Table 55: Inverter Speed Setpoint and Speed Actual Conversion Scenarios

<i>Pr. 37</i>	<i>Pr. 144</i>	Inverter Unit	Number of Motor Poles	NSOLL_A Conversion	NIST_A Conversion
0 (default value)	0, 2..10	Hz	N/A	Equation 5	Equation 6
	102..110	RPM	2..10	Equation 7	Equation 8
1..9998	0, 102..110	Hz	N/A	Equation 5	Equation 6
	2..10	RPM	2..10	Equation 7	Equation 8

The "Max Frequency" equates to the value of *Pr. 1* (register 1001, maximum frequency).



$$\text{Max RPM} = \frac{\text{Max Frequency} \times 120}{\text{Number of Motor Poles}} \quad \text{Equation 4}$$

$$\text{Hz} = \frac{\text{NSOLL_A} \times \text{Max Frequency}}{0x4000} \quad \text{Equation 5}$$

$$\text{NIST_A} = \frac{\text{Hz} \times 0x4000}{\text{Max Frequency}} \quad \text{Equation 6}$$

$$\text{RPM} = \frac{\text{NSOLL_A} \times \text{Max RPM}}{0x4000} \quad \text{Equation 7}$$

$$\text{NIST_A} = \frac{\text{RPM} \times 0x4000}{\text{Max RPM}} \quad \text{Equation 8}$$

NSOLL_A: The reference speed setpoint is a normalized value. The interface card applies the Normalize-to-Hz or Normalize-to-RPM conversion indicated by Equation 5 or Equation 7 respectively. The resulting value is written to inverter register 2 (frequency command).

NIST_A: The inverter operating actual speed is a normalized value that is calculated from inverter register 201 (output frequency). The interface card applies the Hz-to-Normalize or RPM-to-Normalize conversion indicated by Equation 6 or Equation 8 respectively.

PROTOCOL-SPECIFIC INFORMATION



A normalized value of 0x4000 corresponds to 100% of the maximum frequency. A positive normalized value indicates forward rotation and a negative normalized value indicates reverse rotation.

Note that the values of *Pr. 1*, *Pr. 37*, and *Pr. 144* are read by the interface card only at boot-up. If the values of these function codes are changed, then the interface card must be rebooted in order for it to read the new values and once again determine the required conversion scenarios.

9.9.5.4 PROFIdrive-Specific Parameters

The PROFIdrive-specific parameters are shown in Table 56. The parameters are read-only.

Table 56: PROFIdrive-Specific Parameters

PNU	Index	Description
711	None	NSOLL_A – Speed setpoint A
712	None	NIST_A – Speed actual A
833	None	STW1 – Control word 1
834	None	ZSW1 – Status word 1
922	None	Telegram selection = 1 (Standard telegram 1)
923	1,2,5,6	List of all parameters for signals
944	None	Fault message counter
947	0..7	Fault number (Alarm history registers 501..508)
964	0..6	Drive Unit identification
965	None	Profile identification number = Profile 3, Version 4.1
975	0..7	DO identification
980	0..5	Number list of defined parameter
1401	None	DO IO Data reference parameter

9.9.5.5 PROFdrive State Diagram

The state diagram is displayed in Figure 77.




Figure 77: PROFdrive State Diagram

9.9.6 Acyclic Data Access

Any inverter register can be accessed via PROFINET acyclic services. To accomplish this, set the API to 0, Slot to 1, and SubSlot to 1. The record number/index value is equivalent to the desired register number described in section 4.1. The length is specified according to the number of bytes to access. Because each register corresponds to 2 bytes of data, the length must be an even number.

9.9.7 TIA Portal (STEP 7) Hardware Configuration Example

The following example will use TIA Portal V13 (STEP 7) to demonstrate the basic hardware configuration procedure to configure a PROFINET device. The procedure, in general, will apply to similar configuration software. The example will not cover all features of TIA Portal. Any questions regarding TIA Portal (or similar configuration software) must be directed to the vendor of the software.

This example assumes that there is already an existing TIA Portal project with the desired PLC.

9.9.7.1 Register the GSDML File

1. Open the TIA Portal project. Navigate to **Options...Manage general station description files (GSD)** as shown in Figure 78.
2. Locate and select the GSDML file and click the **Install** button. Confirm that the installation was completed successfully as shown in Figure 79 and click the




Figure 78: Install GSD File Menu Option

Close button. It is recommended to use the latest GSDML file, which is available via the [product web page](#) on the internet.

- This will update the **Hardware catalog**. Locate the device in the **Hardware catalog**. In the **Project tree**, double-click on **Device & networks**. Select the **Network view** tab and locate the device in the **Hardware catalog** as shown in Figure 80.




Figure 79: Successfully Installed GSDML File




Figure 80: Updated Hardware Catalog

9.9.7.2 Add the Device to the Configuration

Select the device in the device tree and drag the device onto the PROFINET IO system in the configuration as shown in Figure 81.




Figure 81: Add Device to Configuration

9.9.7.3 Select the IO Controller

On the device, click “Not assigned” and select the appropriate PLC PROFINET interface as shown in Figure 82. This will assign the device to the PROFINET IO system as shown in Figure 83.




Figure 82: Select IO Controller




Figure 83: PROFINET IO System

9.9.7.4 Assign the I/O Module

Click on the device and then click on the **Device view** tab. In the **Hardware catalog**, expand **Module** and add a module “IN: XX WORDS, OUT: YY WORDS” into **Slot 1**. The module will determine the input and output sizes. In this example, the module “IN: 02 WORDS, OUT: 02 WORDS” is selected. Select a module with the appropriate input and output sizes for your specific application. Refer to Figure 84.




Figure 84: Add IO Module

9.9.7.5 Configure the Device Properties

1. Select the device and navigate to the **Properties** tab. Select the **PROFINET interface [X1]** node. Assign a unique and compatible **IP address** for this device as shown in Figure 85.
2. Assign a unique **PROFINET device name** as shown in Figure 86.
3. Set the I/O cycle **Update time** and **Watchdog time** as shown in Figure 87.




Figure 85: Assign Unique Compatible IP Address




Figure 86: Assign Unique Device Name




Figure 87: Set I/O Cycle Update Time

9.9.7.6 Online Device Discovery and Configuration

In the **Project tree**, expand **plc1...Distributed I/O...PROFINET IO-System (100):PN/IE_1**. Expand the device and double-click **Online & diagnostics**. In the next panel, expand **Functions** and select the **Assign IP address** node. Click the **Accessible devices** button. Select the appropriate **PG/PC interface** and click the **Start search** button to discover and display the PROFINET devices on the network as shown in Figure 88. Select the device and click the **Apply** button.




Figure 88: Discover PROFINET Devices on the Network

If the **IP address** does not match the values set in the configuration, click the **Assign IP address** button as shown in Figure 89.

Navigate to **Functions...Assign name**. If the **PROFINET device name** does not match, select the device and click the **Assign name** button as shown in Figure 90.



Figure 89: Assign IP Address




Figure 90: Assign Name

9.9.7.7 Save the Configuration

The hardware configuration is now complete. Save and perform any necessary compilation of the configuration. Download the application and configuration to the PLC. The PLC application program can then be started. Please consult with the vendor of your PROFINET PLC software for additional programming and configuration details.

9.9.8 GE Proficy Configuration Example

The following example will use GE Proficy Machine Edition SIM11 to demonstrate the basic procedure for configuring a PROFINET device. The example will not cover all features of Proficy. Any questions regarding Proficy (or similar configuration software) must be directed at the vendor of the software.

This example assumes that there is already an existing Proficy project with the desired PLC.

9.9.8.1 Register the GSDML File

Open the Proficy project. In the **Navigator** panel, right-click **Profinet Controller** and select **Add IO-Device...** as shown in Figure 91.




Figure 91: Add IO-Device

Click the **Have GSDML...** button as shown in Figure 92.




Figure 92: Have GSDML

Locate and select the GSDML file. Click the **Open** button to register the GSDML as shown in Figure 93. It is recommended to use the latest GSDML, which is available via the [product web page](#) on the internet.



Figure 93: Registered GSDML

9.9.8.2 Add the Device to the Configuration

In the **Navigator** panel, right-click on the device and select **Change Module List...** as shown in Figure 94.




Figure 94: Change Module List

Select a module and drag the module into the available slot. The available slots and modules will vary depending on the specific device. Select a module appropriate for your application. Click the **OK** button as shown in Figure 95.

The module will be reflected in the **Navigator** panel, under the device as shown in Figure 96.




Figure 95: Add IO Module




Figure 96: Added IO Module

9.9.8.3 Configure the Device Properties

In the **Navigator** panel, right-click on the device and select **Properties** as shown in Figure 97.




Figure 97: Select Device Properties

Set the properties to match the configuration on the device. The properties must be appropriate for the application and the PROFINET network.

Set the **Update Rate (ms)**. For this example, the **Update Rate (ms)** is set to “8” ms.


Assign a unique **Device Name**. For this example, the **Device Name** is set to “interfacecard”.

Assign a unique and compatible **IP Address**. For this example the **IP Address** is set to “192.168.17.102”.

The resulting properties are shown in Figure 98.

9.9.8.4 Save the Configuration

The device configuration is now complete. Save and perform any necessary compilation of the configuration. Download the application and configuration to the PLC. The PLC application program can then be started. Please consult with the vendor of your PROFINET PLC software for additional programming and configuration details.



Inspector	
IO-Device	
Device Number	1
Update Rate (ms)	8
Reference Variable	<None>
<input type="checkbox"/> Network Identification	
IO LAN	LAN01
Device Name	interfacecard
Device Description	
IP Address	192.168.17.102

Figure 98: Set Device Properties



9.10 IEC 61850 Server

9.10.1 Overview

The IEC 61850 server driver allows an IEC 61850 client to interact with the interface card via GGIO (generic process I/O) objects, unbuffered reports and GOOSE messages. The GGIO process data is entirely user-configurable. The unbuffered report control block can be configured with any IEC 61850 configuration tool. The GOOSE communication parameters are also user-configurable.

Some other notes of interest are:

- The ICD file can be obtained from the included CD-ROM or downloaded from the [product web page](#) on the internet.
- The CID file is generated by the studio. In the studio, navigate to **File...Generate File...Generate IEC 61850 CID File.**

9.10.2 Server Settings

In the studio, navigate to **A7NETH-V2...Ethernet...IEC 61850 Server.**

IED Name

The IED name is used for identification of this device on the IEC 61850 network. Enter a string between 1 and 32 characters in length.

Subnetwork Name

The name of the station "subnetwork" on which this device resides but it is not relevant to the operation of this device. This name is only meaningful for SCD files and is used when merging CID files to build a substation-wide SCD file.

TCP Port

The TCP listening port for accepting connections and receiving requests.

Authentication

Enable or disable password authentication. If authentication is enabled, the client must provide a valid password when attempting to connect to this device. The password is defined in section 5.3.1.

9.10.3 GOOSE Communication Parameters

In the studio's Project panel, navigate to **A7NETH-V2 ...Ethernet...IEC 61850 Server**. The following configuration options will determine the values used in the GOOSE message.

Priority

802.1Q priority level encoded in the Ethernet frame as the Priority Code Point (PCP) that can be used for QoS.

VLAN ID

802.1Q virtual LAN (VLAN) ID that can be used in a VLAN-aware network.



Application ID

The client will only process GOOSE messages with a matching application ID.

Destination Multicast Address

The GOOSE message will be sent to the specified destination multicast address.

9.10.4 Generic Process I/O Status and Control Object Settings

The Generic Status objects define the structure of “status” data, which are typically read-only registers. The Generic Control objects will define the structure of the “command” data, which are writeable registers. These objects allow the creation of custom-built GGIO process I/O. Up to 100 Generic Status and 100 Generic Control objects can be created. Note that the inverter register value is a 16-bit integer, so only the lower 16-bits of the object’s 32-bit integer value is useful.

Name

The name of this object as discovered by the client. The name is automatically generated depending on the instance.

Instance

The instance number of this object. It is recommend to start at 0.

Register

The inverter register (in section 4) associated with this object. For the Generic Status object, enter a “status” register to be monitored. For the Generic Control object, enter a “command” register that can be written.

Data Type

Each data word is fixed to 16-Bit Unsigned. This is equivalent to two bytes.

Include in DataSet

Include or exclude this object from the fixed dataset.

The default configuration is described in Table 57. Always use the studio to confirm the configuration before commissioning the device.

Table 57: IEC 61850 Server User-Configurable I/O

Type	Name	Instance	Register
Generic Status	Status0	0	100
Generic Status	Status1	1	201
Generic Control	Control0	0	1
Generic Control	Control1	1	2



10 TROUBLESHOOTING

Although by no means exhaustive, the following table provides possible causes behind some of the most common errors experienced when using this option card.

Problem	Symptom	Solution
Inverter displays E.1, E.2, or E.3 alarm, or the card is unresponsive	Inverter cannot recognize the option	<ul style="list-style-type: none">• Confirm that the interface card connector is properly seated. Refer to section 2.• Check the inverter serial number to determine the manufacture date and confirm that the inverter is compatible. Refer to section 1.3.• Rebooting the interface card via the studio disrupts the communication with the inverter. Reset the fault.• If the card is connected in a ring topology, all devices in the ring must be configured with the same ring redundancy protocol (i.e. MRP, DLR). The appropriate ring redundancy protocol must also be enabled on the card. Otherwise a ring topology will create an Ethernet loop and produce undefined/erratic behavior.

Problem	Symptom	Solution
<p>No communications between the network and the card</p>	<p>Communications cannot be established, the Ethernet "link" LED is off, or the Ethernet "activity" LED flashes only infrequently or not at all</p>	<ul style="list-style-type: none"> • Confirm that the card is running normally (Module Status LED is not blinking red) and connected to the local Ethernet network. • Ensure that the card's is programmed with compatible network settings. Consult with your network administrator to determine the compatible settings. • Confirm that the destination IP address programmed into the controller equipment or computer matches that of the interface card, as displayed by the studio. • Confirm that intermediate firewalls or routers have been configured to allow access to the interface via the applicable TCP/UDP ports. • Try a known working Ethernet cable and switch. • If attempting to access the web server on a computer whose web browser is configured to use a proxy server, ensure that the proxy server is accessible to the computer, and that the interface card is accessible to the proxy server.



Problem	Symptom	Solution
No PROFINET communication	PROFINET I/O communication cannot be established. The "Network Status" LED is not solid green.	<ul style="list-style-type: none"> • Confirm that the card's PROFINET device name matches the name assigned in the controller's configuration. • Confirm that the card's network settings match the settings assigned in the controller's configuration. • Confirm that the I/O cycle update time is set to 1ms or larger. • Ensure that the card is connected to a 100Mbps full duplex capable switch. • Ensure that the card can be discovered using the controller's discovery tool.
Unable to control the inverter via network communications	Cannot write to command parameters via network communications, or writing to these parameters has no apparent effect	<ul style="list-style-type: none"> • Set the inverter to NET mode. The inverter will reject all command and parameter write requests from the network if it is not in NET mode. Refer to section 3.2. • If using the inverter's terminal contacts, refer to the inverter's instruction manual to determine the appropriate behavior and priority • Clear all parameter settings to default and reconfigure the parameters.
XML socket connection failed	Message on web server tab information window	TCP port 843 is blocked by a firewall, router or some other intermediate network equipment.
New web server content not loading after web server update	Old web server content is displayed	The internet browser has cached the old web server content. Clear the internet browser's cache before attempting to load the new web server content.

Problem	Symptom	Solution
Web page does not display properly	Corrupt web server or outdated flash player plug	<ul style="list-style-type: none"> • Ensure that USB and FTP are disconnected. • Download and install the latest flash player plug from Adobe. • Delete the "WEB" folder from the card's file system and copy a valid default "WEB" folder to the card's file system.
Studio cannot discover the card	The studio does not display the card under "Online Devices"	<ul style="list-style-type: none"> • Confirm that the card is running normally and connected via USB or to the local Ethernet network. It is preferable to connect via USB as there are scenarios in which the Ethernet discovery is not available or disabled. • Confirm that the module and network status LEDs blink the green/red startup sequence when power is first applied. • Add the studio as an exception to the computer's firewall. • Add UDP port 4334 as an exception to the firewall. • Temporarily disable the computer's firewall.
Studio cannot access file system	The studio displays an error when uploading and downloading the configuration.	If the studio continually displays an error regarding access to the file system, the card's file system may be corrupt. Please format the card's file system and then restore the configuration (refer to section 5.8). If the card cannot be formatted, please contact technical support for instructions to manually format the card's file system.
Firmware-generated error	"MODULE STATUS" LED is flashing red. The number of times the LED flashes indicates an error code.	Record the error code blinking pattern and contact technical support for further assistance.

REVISIONS

Date	Details
May 2019	Initial release