

## **Programmable Controller**

# MELSEC iQ-R

## MELSEC iQ-R Serial Communication Module User's Manual (Application)

-RJ71C24 -RJ71C24-R2 -RJ71C24-R4

## SAFETY PRECAUTIONS

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions for the programmable controller system, refer to the user's manual for the module used and the MELSEC iQ-R Module Configuration Manual. In this manual, the safety precautions are classified into two levels:" (!) WARNING" and " (!) CAUTION".

Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "A CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

### [Design Precautions]

- Configure safety circuits external to the programmable controller to ensure that the entire system
  operates safely even when a fault occurs in the external power supply or the programmable controller.
  Failure to do so may result in an accident due to an incorrect output or malfunction.
  - (1) Emergency stop circuits, protection circuits, and protective interlock circuits for conflicting operations (such as forward/reserve rotations or upper/lower limit positioning) must be configured external to the programmable controller.
  - (2) When the programmable controller detects an abnormal condition, it stops the operation and all outputs are:
    - Turned off if the overcurrent or overvoltage protection of the power supply module is activated.
    - Held or turned off according to the parameter setting if the self-diagnostic function of the CPU module detects an error such as a watchdog timer error.
  - (3) All outputs may be turned ON if an error occurs in a part, such as an I/O control part, where the CPU module cannot detect any error. To ensure safety operation in such a case, provide a safety mechanism or a fail-safe circuit external to the programmable controller. For a fail-safe circuit example, refer to "General Safety Requirements" in the MELSEC iQ-R Module Configuration Manual.
  - (4) Outputs may remain ON or OFF due to a failure of a component such as a relay and transistor in an output circuit. Configure an external circuit for monitoring output signals that could cause a serious accident.
- In an output circuit, when a load current exceeding the rated current or an overcurrent caused by a load short-circuit flows for a long time, it may cause smoke and fire. To prevent this, configure an external safety circuit, such as a fuse.
- Configure a circuit so that the programmable controller is turned on first and then the external power supply. If the external power supply is turned on first, an accident may occur due to an incorrect output or malfunction.
- For the operating status of each station after a communication failure, refer to manuals relevant to the network. Incorrect output or malfunction due to a communication failure may result in an accident.
- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
- Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.

## [Design Precautions]

## 

- Do not write any data to the "system area" and "write-protect area" of the buffer memory in the module. Also, do not use any "use prohibited" signals as an output signal from the CPU module to each module. Doing so may cause malfunction of the programmable controller system. For the "system area", "write-protect area", and the "use prohibited" signals, refer to the user's manual for the module used.
- If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Configure an interlock circuit in the program to ensure that the entire system will always operate safely even if communications fail. Incorrect output or malfunction due to a communication failure may result in an accident.
- To maintain the safety of the programmable controller system against unauthorized access from external devices via the network, take appropriate measures. To maintain the safety against unauthorized access via the Internet, take measures such as installing a firewall.

### [Design Precautions]

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100mm or more between them. Failure to do so may result in malfunction due to noise.
- During control of an inductive load such as a lamp, heater, or solenoid valve, a large current (approximately ten times greater than normal) may flow when the output is turned from OFF to ON. Therefore, use a module that has a sufficient current rating.
- After the CPU module is powered ON or is reset, the time taken to enter the RUN status varies depending on the system configuration, parameter settings, and/or program size. Design circuits so that the entire system will always operate safely, regardless of the time.
- Do not power OFF the programmable controller or do not reset the CPU module while the settings are being written. Doing so will make the data in the flash ROM and SD memory card undefined. The values need to be set in the buffer memory and written to the flash ROM and SD memory card again. Doing so may cause malfunction or failure of the module.
- When changing the operating status of the CPU module from external devices (such as remote RUN/ STOP functions), select "Do Not Open in Program" for "Open Method Setting" in the module parameters. If "Open in Program" is selected, an execution of remote STOP causes the communication line to close. Consequently, the CPU module cannot reopen the communication line, and the external device cannot execute the remote RUN.

## 

• Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may result in electric shock or cause the module to fail or malfunction.

## [Installation Precautions]

## 

- Use the programmable controller in an environment that meets general specifications written in Safety Guidelines included in the base unit. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- To mount a module, place the concave part(s) located at the bottom onto the guide(s) of the base unit, and push in the module until the hook(s) located at the top snaps into place. Incorrect interconnection may cause malfunction, failure, or drop of the module.
- To mount a module with no module fixing hook, place the concave part(s) located at the bottom onto the guide(s) of the base unit, push in the module, and fix it with screw(s). Incorrect interconnection may cause malfunction, failure, or drop of the module.
- When using the programmable controller in an environment of frequent vibrations, fix the module with a screw.
- Tighten the screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- When using an extension cable, connect it to the extension cable connector of the base unit securely. Check the connection for looseness. Poor contact may cause malfunction.
- When using an SD memory card, fully insert it into the memory card slot. Check that it is inserted completely. Poor contact may cause malfunction.
- Securely insert an extended SRAM cassette into the cassette connector of a CPU module. After insertion, close the cassette cover and check that the cassette is inserted completely. Poor contact may cause malfunction.
- Do not directly touch any conductive parts and electronic components of the module, SD memory card, extended SRAM cassette, or connector. Doing so may cause malfunction or failure of the module.

## [Wiring Precautions]

- Shut off the external power supply (all phases) used in the system before installation and wiring. Failure to do so may result in electric shock or cause the module to fail or malfunction.
- After installation and wiring, attach the included terminal cover to the module before turning it on for operation. Failure to do so may result in electric shock.

- Individually ground the FG and LG terminals of the programmable controller with a ground resistance of 100 ohms or less. Failure to do so may result in electric shock or malfunction.
- Use applicable solderless terminals and tighten them within the specified torque range. If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Check the rated voltage and signal layout before wiring to the module, and connect the cables correctly. Connecting a power supply with a different voltage rating or incorrect wiring may cause fire or failure.
- Connectors for external devices must be crimped or pressed with the tool specified by the manufacturer, or must be correctly soldered. Incomplete connections may cause short circuit, fire, or malfunction.
- Securely connect the connector to the module. Poor contact may cause malfunction.
- Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100mm or more between them. Failure to do so may result in malfunction due to noise.
- Place the cables in a duct or clamp them. If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact. Do not clamp the extension cables with the jacket stripped. Doing so may change the characteristics of the cables, resulting in malfunction.
- Check the interface type and correctly connect the cable. Incorrect wiring (connecting the cable to an incorrect interface) may cause failure of the module and external device.
- Tighten the terminal screws or connector screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, fire, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, fire, or malfunction.
- When disconnecting the cable from the module, do not pull the cable by the cable part. For the cable with connector, hold the connector part of the cable. For the cable connected to the terminal block, loosen the terminal screw. Pulling the cable connected to the module may result in malfunction or damage to the module or cable.
- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring. Do not remove the film during wiring. Remove it for heat dissipation before system operation.

## [Wiring Precautions]

## 

- Programmable controllers must be installed in control panels. Connect the main power supply to the power supply module in the control panel through a relay terminal block. Wiring and replacement of a power supply module must be performed by qualified maintenance personnel with knowledge of protection against electric shock. For wiring, refer to the MELSEC iQ-R Module Configuration Manual.
- For Ethernet cables to be used in the system, select the ones that meet the specifications in the user's manual for the module used. If not, normal data transmission is not guaranteed.

## [Startup and Maintenance Precautions]

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
- Correctly connect the battery connector. Do not charge, disassemble, heat, short-circuit, solder, or throw the battery into the fire. Also, do not expose it to liquid or strong shock. Doing so will cause the battery to produce heat, explode, ignite, or leak, resulting in injury or fire.
- Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws, connector screws, or module fixing screws. Failure to do so may result in electric shock.

### [Startup and Maintenance Precautions]

- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
- Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
- Do not disassemble or modify the modules. Doing so may cause failure, malfunction, injury, or a fire.
- Use any radio communication device such as a cellular phone or PHS (Personal Handy-phone System) more than 25cm away in all directions from the programmable controller. Failure to do so may cause malfunction.
- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may cause the module to fail or malfunction.
- Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- After the first use of the product, do not mount/remove the module to/from the base unit, and the terminal block to/from the module, and do not insert/remove the extended SRAM cassette to/from the CPU module more than 50 times (IEC 61131-2 compliant) respectively. Exceeding the limit may cause malfunction.
- After the first use of the product, do not insert/remove the SD memory card to/from the CPU module more than 500 times. Exceeding the limit may cause malfunction.
- Do not touch the metal terminals on the back side of the SD memory card. Doing so may cause malfunction or failure of the module.
- Do not touch the integrated circuits on the circuit board of an extended SRAM cassette. Doing so may cause malfunction or failure of the module.
- Do not drop or apply shock to the battery to be installed in the module. Doing so may damage the battery, causing the battery fluid to leak inside the battery. If the battery is dropped or any shock is applied to it, dispose of it without using.
- Startup and maintenance of a control panel must be performed by qualified maintenance personnel with knowledge of protection against electric shock. Lock the control panel so that only qualified maintenance personnel can operate it.

## [Startup and Maintenance Precautions]

## 

• Before handling the module, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Failure to do so may cause the module to fail or malfunction.

## [Operation Precautions]

## 

- When changing data and operating status, and modifying program of the running programmable controller from an external device such as a personal computer connected to an intelligent function module, read relevant manuals carefully and ensure the safety before operation. Incorrect change or modification may cause system malfunction, damage to the machines, or accidents.
- Do not power OFF the programmable controller or do not reset the CPU module while the setting values in the buffer memory are being written to the flash ROM in the module. Doing so will make the data in the flash ROM and SD memory card undefined. The values need to be set in the buffer memory and written to the flash ROM and SD memory card again. Doing so may cause malfunction or failure of the module.

### [Disposal Precautions]

## 

- When disposing of this product, treat it as industrial waste.
- When disposing of batteries, separate them from other wastes according to the local regulations. For details on battery regulations in EU member states, refer to the MELSEC iQ-R Module Configuration Manual.

## [Transportation Precautions]

- When transporting lithium batteries, follow the transportation regulations. For details on the regulated models, refer to the MELSEC iQ-R Module Configuration Manual.
- The halogens (such as fluorine, chlorine, bromine, and iodine), which are contained in a fumigant used for disinfection and pest control of wood packaging materials, may cause failure of the product. Prevent the entry of fumigant residues into the product or consider other methods (such as heat treatment) instead of fumigation. The disinfection and pest control measures must be applied to unprocessed raw wood.

## **CONDITIONS OF USE FOR THE PRODUCT**

(1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;

i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and

ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.

(2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries. MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.

("Prohibited Application")

- Prohibited Applications include, but not limited to, the use of the PRODUCT in;
- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTs are required. For details, please contact the Mitsubishi representative in your region.

## INTRODUCTION

Thank you for purchasing the Mitsubishi Electric MELSEC iQ-R series programmable controllers.

This manual describes the functions and programming to use the module listed below.

Before using the product, please read this manual and relevant manuals carefully and develop familiarity with the performance of MELSEC iQ-R series programmable controller to handle the product correctly.

When applying the example programs provided in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

Please make sure that the end users read this manual.

#### Point P

The program examples shown in this manual are the examples in which C24 is assigned to the input/output No. X/Y0 to X/Y1F unless otherwise specified. To use the program examples shown in this manual, the input/ output number assignment is required. For details on the assignment of input/output number, refer to the following manual.

L MELSEC iQ-R Module Configuration Manual

#### **Relevant products**

RJ71C24, RJ71C24-R2, RJ71C24-R4

## CONTENTS

SAFETY PRECAUTIONS	1
CONDITIONS OF USE FOR THE PRODUCT	9
INTRODUCTION	.10
RELEVANT MANUALS	.18
TERMS	.18

## PART 1 BASIC FUNCTIONS

CHA	APTER 1 DATA COMMUNICATION USING MC PROTOCOL	22
1.1	Accessing to CPU Module Using MC Protocol.	
	File access method	23
1.2	Data Communication	23
	Formats and codes	23
	Frames	24
	Parameter settings for MC protocol communication	24
	Applicability of multiple CPU systems	24
	Applicability of remote password function	25
	Using MX Component	25
СНА	APTER 2 DATA COMMUNICATION USING PREDEFINED PROTOCOL	26
2.1	Data Communication Procedure	27
2.2	Communication Type of Protocols	34
2.3	Packet	35
	Packet elements	35
2.4	Execution Condition of Predefined Protocol Communication	48
СН	APTER 3 DATA COMMUNICATION USING NONPROCEDURAL PROTOCOL	52
2.4	Pensiving Data from Target Davise	52
3.1		<b></b>
		61
	Reception error detection and check methods	65
	Receive data clear	67
	Receive and data quantity and receive end code settings	74
3.2	Transmitting Data to Target Device	
0.2	Sending methods	
	Send area and send data arrangement.	
	Program for data transmission	
	Transmission error detection and check methods.	
3.3	Considerations for Data Communication	85
СНА	APTER 4 DATA COMMUNICATION USING BIDIRECTIONAL PROTOCOL	86
4.1	Receiving Data from Target Device	87
	Receiving methods	87
	Receive area, receive data arrangement and contents	88
	Program for data reception	92
	Reception error detection and check methods	95

СПУ		100
4.4	Considerations for Data Communication	
	Processing of transmitted/received data when simultaneous transmissions occur	105
	Processing when simultaneous transmissions occur	104
4.3	Processing when Simultaneous Transmission is Performed during Full-Duplex Community	cations104
	Transmission error detection and check methods	103
	Program for data transmission	
	Send area and send data arrangement	
	Sending methods	
4.2	Transmitting Data to Target Device	96
	Receive data clear	

5.1	Circuit Trace	
	Procedure for the circuit trace	
	Performing circuit trace	
	Circuit trace option setting	
5.2	Protocol Execution Log Storage Function (for Predefined Protocol only)	
	Checking with Engineering tool	
	Checking with the buffer memory	

## PART 2 ADDITIONAL FUNCTIONS

## CHAPTER 6 USING THE PROGRAMMABLE CONTROLLER CPU MONITORING FUNCTION

6.1	Overview.	
6.2	Programmable Controller CPU Monitoring Function	
	Data registration for using the programmable controller CPU monitoring function	
	CPU module monitoring information	
	Monitoring timing of CPU module	
	Timings of transmitting monitoring results to the target device	
	Transmission methods of monitoring results and data transmitted to the target device	
	Data arrangement of device information and programmable controller CPU status information	130
	Execution order for using the programmable controller CPU monitoring function	137
6.3	Settings for Using the Programmable Controller CPU Monitoring Function	138
	Parameter setting items for the programmable controller CPU monitoring function	138
	How to register and cancel the programmable controller CPU monitoring function	
6.4	Considerations for Using the Programmable Controller CPU Monitoring Function	
6.4	Considerations for Using the Programmable Controller CPU Monitoring Function	146
6.4 CH/	Considerations for Using the Programmable Controller CPU Monitoring Function	146 148
6.4 CH/ 7.1	Considerations for Using the Programmable Controller CPU Monitoring Function	146 148 148
6.4 CH/ 7.1	Considerations for Using the Programmable Controller CPU Monitoring Function APTER 7 COMMUNICATIONS BY THE MODEM FUNCTION Overview	
6.4 CH/ 7.1	Considerations for Using the Programmable Controller CPU Monitoring Function APTER 7 COMMUNICATIONS BY THE MODEM FUNCTION Overview. Features Function list	
6.4 CH/ 7.1 7.2	Considerations for Using the Programmable Controller CPU Monitoring Function         APTER 7       COMMUNICATIONS BY THE MODEM FUNCTION         Overview.       Features         Function list       System Configuration	
6.4 CH/ 7.1 7.2	Considerations for Using the Programmable Controller CPU Monitoring Function         APTER 7       COMMUNICATIONS BY THE MODEM FUNCTION         Overview.       Features         Function list       System Configuration         System configuration when performing data communication with target device       System configuration	
6.4 <u>CH/</u> 7.1 7.2	Considerations for Using the Programmable Controller CPU Monitoring Function         APTER 7       COMMUNICATIONS BY THE MODEM FUNCTION         Overview.       Features         Function list.       System Configuration.         System configuration when performing data communication with target device.       Considerations for system configurations	
6.4 <u>CH/</u> 7.1 7.2 7.3	Considerations for Using the Programmable Controller CPU Monitoring Function         APTER 7       COMMUNICATIONS BY THE MODEM FUNCTION         Overview.       Features         Function list       System Configuration         System configuration when performing data communication with target device       Considerations for system configurations         Specifications of Modem Function       Supervision	
6.4 <b>CH</b> / 7.1 7.2 7.3	Considerations for Using the Programmable Controller CPU Monitoring Function         APTER 7       COMMUNICATIONS BY THE MODEM FUNCTION         Overview.       Features         Function list.       System Configuration         System configuration when performing data communication with target device.       Considerations for system configurations         Specifications of Modem Function       Applicability of remote password function	
6.4 <u>CH/</u> 7.1 7.2 7.3	Considerations for Using the Programmable Controller CPU Monitoring Function APTER 7 COMMUNICATIONS BY THE MODEM FUNCTION Overview. Features Function list. System Configuration System configuration when performing data communication with target device Considerations for system configurations Specifications of Modem Function List of input/output signals for the modem function	
6.4 <u>CH/</u> 7.1 7.2 7.3	Considerations for Using the Programmable Controller CPU Monitoring Function APTER 7 COMMUNICATIONS BY THE MODEM FUNCTION Overview. Features Function list System Configuration System configuration when performing data communication with target device. Considerations for system configurations Specifications of Modem Function Applicability of remote password function List of input/output signals for the modem function. Buffer memory.	

СНА	PTER 8 RECEIVING DATA WITH AN INTERRUPT PROGRAM	219
	Program for data communication	
7.5	Sample program	
	Line disconnection	
	Data communication	
	Line connection	
	Initialization of modem/TA (terminal adapter)	
	Register/read/delete data for connection	
	Register/read/delete data for initialization	
	Initial settings of Serial communication module	
	Startup procedure of the modem function	

7.4

8.1	Settings for Receiving Data Using an Interrupt Program	219
8.2	Interrupt Program Startup Timing	219
8.3	Reception Control Method Using an Interrupt Program	220
8.4	Program Example	221
8.5	Considerations when Receiving Data with an Interrupt Program	223

#### CHAPTER 9 CHANGING DATA LENGTH UNITS TO BYTE UNITS (WORD/BYTE **UNITS SETTING)**

CHAPTER 10 CHANGING DATA COMMUNICATION MONITORING TIME		227
10.1	No-reception Monitoring Time (timer 0) Setting	
	C24 operation by no reception monitoring time (timer 0)	
	Changing the no-reception monitoring time (timer 0)	
10.2	Response Monitoring Time (timer 1) Setting	
	C24 operation by response monitoring time (timer 1)	
	Changing the response monitoring time (timer 1)	
10.3	Send Monitoring Time (timer 2) Setting	
	C24 operation by send monitoring time (timer 2)	
	Changing the send monitoring time (timer 2)	
10.4	Transmission Wait Time Setting	
	C24 operation by transmission wait time	
	Changing the transmission wait time	

#### CHAPTER 11 DATA COMMUNICATIONS USING DC CODE TRANSMISSION CONTROL

	CONTROL	236
11.1	Control Contents of DTR/DSR (ER/DR) Signal Control	
	C24 DTR control contents and free OS area specification	
	C24 DSR control	
11.2	Control Contents of DC Code Control	
	DC1/DC3 transmission control, DC1/DC3 reception control	
	DC2/DC4 transmission control, DC2/DC4 reception control	
11.3	Considerations for Using Transmission Control Functions	

#### **CHAPTER 12 DATA COMMUNICATIONS USING HALF-DUPLEX** COMMUNICATIONS

•••••	COMMUNICATIONS	243
12.1	Half-duplex Communications	243
12.2	Data Transmission and Reception Timing	244

12.3	Changing the Communication Method	248
12.4	Connector Connections for Half-duplex Communications	248
12.5	Considerations for Half-duplex Communications	249
СНА	PTER 13 CONTENTS AND REGISTRATION OF USER FRAMES FOR DATA COMMUNICATION	250
13.1	User Frame Types and Contents During Communication	250
	User frames to be registered and used by the user	250
	Default registration frame (read only)	258
13.2	Transmission/Reception Processing Using User Frame Registration Data	259
	Transmitting data	259
	Receiving data	260
13.3	Considerations for Registering, Reading, and Deleting User Frames	262
13.4	Registering/Reading/Deleting User Frames	264
СНА	PTER 14 ON-DEMAND DATA COMMUNICATIONS USING USER FRAMES	267
14.1	Data Communication Function Using User Frame	267
14.2	User Frame On-Demand Data Transmission and Buffer Memory Used	268
14.3	On-Demand Function Control Procedure During User Frame Use	270
	Data communication using the ASCII code	270
	Data communications using the binary code	272
14.4	Example of On-Demand Data Transmission Program Using User Frames	274
СНА	PTER 15 DATA COMMUNICATIONS USING USER FRAMES	276
15.1	Procedure of Data Communication	277
15.2	Data Reception	278
	Receive data	278
	Timing for start/completion of data reception.	284
	Reception procedure	288
	Setting of receive user frames	289
15.3	Program for Data Reception with User Frame	295
	Application program for data reception using a combination that specifies the start frame	303
	Application program for data reception using a combination that does not specify the start frame $\ldots$ .	310
15.4	Data Transmission.	313
	Send data	313
	Transmission procedure	314
	Settings of send user frames	315
15.5	Application Program for Data Transmission using a Combination that does not Specify the Star	t
	Frame	318
СНА	PTER 16 TRANSPARENT CODES AND ADDITIONAL CODES	326
16.1	Handling Transparent Code and Additional Code Data	326
16.2	Registering Transparent Codes and Additional Codes	327
16.3	Handling Transparent and Additional Codes for Nonprocedural Protocol Data Communication.	328
16.4	Data Communication Using Nonprocedural Protocol	331
	Example of data reception	332
	Example of data transmission	335
16.5	Handling Transparent and Additional Codes for Bidirectional Protocol Data Communication	339
16.6	Data Communication Using Bidirectional Protocol	342
	Example of data reception	343

	Example of data transmission	345
СНА	PTER 17 COMMUNICATING WITH ASCII CODE (ASCII-BIN CONVERSION)	347
17.1	ASCII-Binary Conversion	347
17.2	Settings for ASCII-BIN Conversion	347
17.3	ASCII-BIN Conversion for Data Communicated with Nonprocedural Protocol	348
17.4	Data Communication Using Nonprocedural Protocol	350
	Example of data reception.	351
	Example of data transmission	355
17.5	ASCII-BIN Conversion for Data Communicated with Bidirectional Protocol.	359
17.6	Data Communication Using Bidirectional Protocol	361
	Example of data reception	362
	Example of data transmission	364
СНА	APTER 18 DATA COMMUNICATIONS BETWEEN TARGET DEVICE AND CPU MODULE IN M:N BASIS	366
18 1	Considerations on Data Communications	366
18.2	Arrangement for Interlock among Target Devices	368
10.2	Maximum communication time per target device station	368
	Message structure when communicating data among target devices	
18.3	Examples of Procedure for Data Communications with CPU Module	
	Sequential data communications between target devices and the CPU module	371
	Data communications between target devices and CPU module by designating a master station and sla	ve
	stations	374
СНА	PTER 19 SWITCHING THE MODE AFTER STARTING	377
19.1	Mode Switching Operation and Contents that can be Changed	378
	Settings that can be changed with mode switching.	378
	Operation for mode switching	378
19.2	Considerations for Mode Switching	379
19.3	I/O Signals for Handshake with CPU Module and Buffer Memory	380
19.4	Mode Switching Method by Program	383
19.5	How to Switch Mode from Target Device	385
СНА	PTER 20 USING SEND/RECEIVE DATA MONITORING FUNCTION	387
20.1	Send/receive Data Monitoring Function	387
	Overview	387
	Send/receive data monitoring operation	388
20.2	Send/receive Data Monitoring Function Settings	390
	Buffer memory for send/receive data monitoring function	391
20.3	Send/receive Data Monitoring Example	394
СНА	PTER 21 INDEPENDENT/LINKED OPERATION OF INTERFACE	397
21.1	Setting and Data Flow of Independent Operation	397
21.2	Setting and Data Flow of Interlink Operation	398
	Setting example for MELSOFT connection via C24	400
СНА	<b>APTER 22 PARAMETER REGISTRATION TO CPU MODULE</b>	401

#### CHAPTER 23 RS-422/485 INTERFACE ECHO BACK ENABLE/PROHIBIT SPECIFICATION

#### CHAPTER 24 ERRONEOUS NOISE SIGNAL RECEPTION PREVENTION FUNCTION

C		
24.1	Erroneous Noise Signal Reception Prevention Function	405
24.2	Setting for the Erroneous Noise Signal Reception Prevention Function	406

403

405

407

#### CHAPTER 25 AUTOMATIC REMOVAL OF NULL CHARACTERS INCLUDED IN SEND DATA

25.1	Automatic Removal of NULL Characters during Data Transmission	
25.2	Setting for NULL Character Automatic Removal Function	
25.3	NULL Character Removal to Send Data using Nonprocedural Protocol	
25.4	Program Example	
	Program example of data communication using the nonprocedural protocol	
25.5	NULL Characters Removal for Send Data using Bidirectional Protocol	
25.6	Program Example	
	Program example of data communication using the bidirectional protocol	

### PART 3 PARAMETER SETTINGS AND TROUBLESHOOTING

#### CHAPTER 26 PARAMETER SETTING 422 26.1 26.2 26.3 CHAPTER 27 TROUBLESHOOTING 440 27.1 Error information 440 How to Clear Programmable Controller CPU Information......455 27.2 27.3 Troubleshooting by Symptom .......457 SD LED does not flash even after a send request was made......459 No response message is returned even though the target device transmitted a message and the RD LED Read request signal does not turn ON even though the target device transmitted a message and the RD

Fixed cycle send is not performed normally	
Communication is not established via modem	
Whether the communication error is caused on C24 or target device is unclear	
Communication is intermittent	
Hardware information communication error "NAK" occurs	
Hardware information communication error "C/N" occurs	
Hardware information communication error "P/S" occurs	
Hardware information communication error "PRO." occurs	
Hardware information communication error "SIO" occurs	
ERR LED flashes.	
RUN LED turns OFF	
The CPRTCL instruction execution is not completed although the RD LED flashes	

#### APPENDIX

Appendix 1 Module Label
Appendix 2 Input/Output Signal List
Appendix 3 Buffer Memory
Buffer memory list
Appendix 4 Dedicated Instructions
Dedicated instruction list
Appendix 5 Operation Image and Data Structure of Predefined Protocol
Operation image of each communication type of protocol
Verification operation of receive packet
Data examples of packet elements
Appendix 6 Processing Time
Appendix 7 When Connecting the Module to a Remote Head Module
Restrictions
Communication example
Appendix 8 Added and Changed Functions
INDEX 565

REVISIONS	 	
WARRANTY	 	
TRADEMARKS	 	

## **RELEVANT MANUALS**

Manual name [manual number]	Description	Available form
MELSEC iQ-R Serial Communication Module User's Manual (Application) [SH-081251ENG] (this manual)	Functions, input/output signals, buffer memory, parameter setting, and trouble shooting of Serial communication module	Print book e-Manual PDF
MELSEC iQ-R Serial Communication Module User's Manual (Startup) [SH-081250ENG]	Specifications, procedures prior to operation, system configurations, wring, and data communication examples of Serial communication module	Print book e-Manual PDF
MELSEC Communication Protocol Reference Manual [SH-080008]	Specifications, accessible range, message protocols, and functions of MELSEC Communication Protocol	Print book e-Manual PDF

#### Point P

e-Manual refers to the Mitsubishi FA electronic book manuals that can be browsed using a dedicated tool. e-Manual has the following features:

- Required information can be cross-searched in multiple manuals.
- Other manuals can be accessed from the links in the manual.
- The hardware specifications of each part can be found from the product figures.
- Pages that users often browse can be bookmarked.

## TERMS

Unless otherwise specified, this manual uses the following terms.

Terminology	Description
3C frame (Formats 1 to 4) 4C frame (Formats 1 to 4)	A message format for C24 for data communications with ASCII code data using the MC protocol This is the same message format as the communication frame using the dedicated protocol for the QnA series Serial Communication Module. • QnA compatible 3C frame (Formats 1 to 4): QnA frame (Formats 1 to 4) • QnA compatible 4C frame (Formats 1 to 4): QnA extension frame (Formats 1 to 4)
4C frame (Format 5)	A message format for C24 for data communication with binary code data using the MC protocol This is the same message format as the communication frame using the dedicated protocol for the QnA series Serial Communication Module. • QnA compatible 4C frame (Format 5): QnA extension frame (Format 5)
Bidirectional protocol	A data communication function to communicate any data between a CPU module and the target device using the communication procedure for C24
Buffer memory	A memory of an Intelligent function module to store data (including setting value and monitored value) sent to/ receive from CPU module
BUFRCVS	An abbreviation for Z.BUFRCVS
C24	Another term for the MELSEC iQ-R series Serial Communication Module
CPRTCL	An abbreviation for G.CPRTCL or GP.CPRTCL
CPU module	A generic term for MELSEC iQ-R series CPU module
CSET	An abbreviation for ZP.CSET
Data communication function	A generic term for MC protocol, predefined protocol, nonprocedural protocol, and bidirectional protocol
Engineering tool	A tool for setting, programming, debugging, and maintaining programmable controllers. For the supported tools, refer to the following manual. I MELSEC iQ-R Module Configuration Manual
GETE	An abbreviation for G.GETE or GP.GETE
Independent operation	A mode of interface operation to communicate data with the target device with a function specified in each communication protocol setting without interaction between two interfaces of C24
INPUT	An abbreviation for G.INPUT
Intelligent function module	A generic term for modules which has functions other than input and output, such as A/D converter module and D/A converter module
Interlink operation	A mode of interface operation to communicate data with the target device with the two interfaces linked one another when two interfaces of C24 are connected to target devices respectively. The two interfaces communicate data with the same data communication function (MC protocol (identical format) or nonprocedural protocol) and the same transmission specifications. (Interlink operation of the predefined protocol and the bidirectional protocol is not allowed.)

Terminology	Description
MC protocol	An abbreviation for MELSEC communication protocol, which is a name of communication method to access a CPU module form a target device using the communication procedure for Serial communication modules or Ethernet communication modules
Multidrop connection	A name of connection when more than one target devices or other C24s are connected on a 1:n basis or an m:n basis using the RS-422/485 interface of C24
Nonprocedural protocol	A data communication function to communicate any data between a CPU module and the target device using user's communication procedure
ONDEMAND	An abbreviation for G.ONDEMAND or GP.ONDEMAND
OUTPUT	An abbreviation for G.OUTPUT or GP.OUTPUT
Packet	A data string used for communication with a target device by predefined protocol
Predefined protocol	A data communication function to send/receive data using a protocol of the target device for data communication between C24 and the target device This setting is configured with GX Works3 (the predefined protocol support function).
Predefined protocol support function	<ul> <li>A function available using GX Works3 (the predefined protocol support function)</li> <li>The function includes the following:</li> <li>Setting the protocol appropriate to respective target devices</li> <li>Writing or reading the protocol setting data to/from CPU module or C24</li> <li>Debug support function</li> </ul>
PRR	An abbreviation for G.PRR or GP.PRR
PUTE	An abbreviation for G.PUTE or GP.PUTE
Remote head module	An abbreviation for RJ72GF15-T2 CC-Link IE Field Network remote head module.
SPBUSY	An abbreviation for G.SPBUSY or GP.SPBUSY
Target device	A generic term for GOT, measuring instruments, ID modules, barcode readers, regulators, and other C24s connected to this C24 for data communication
UINI	An abbreviation for ZP.UINI
User frame	A data name used to send/receive data by registering the fixed format part of messages to be sent/received between C24 and the target device to the module (The contents of a user frame data should conform to the specifications of the target device.) The data array of the head and tail sections in messages to be sent/received (transmission control code, C24 station number, sum check, fixed data, etc.) are registered to C24 respectively before use. This is used for the on-demand function of MC protocol and the data transmit/receive function by nonprocedural protocol.

# PART 1 BASIC FUNCTIONS

This part explains the basic functions of C24.

1 DATA COMMUNICATION USING MC PROTOCOL

2 DATA COMMUNICATION USING PREDEFINED PROTOCOL

3 DATA COMMUNICATION USING NONPROCEDURAL PROTOCOL

4 DATA COMMUNICATION USING BIDIRECTIONAL PROTOCOL

**5 DEBUG SUPPORT FUNCTION** 

# 1 DATA COMMUNICATION USING MC PROTOCOL

MC protocol is a communication method for the programmable controller. Using this protocol, the target devices can read or write device data and programs from or to the CPU module via a C24.

C24 returns a response message automatically based on requests from the target devices. Thus, programs for response messages are not required.

For details of the MC protocol, refer to the following manual.

MELSEC Communication Protocol Reference Manual



## **1.1** Accessing to CPU Module Using MC Protocol

This section explains how to access to a CPU module using MC protocol.

#### Reading/writing device memory of CPU module

Read/write data from/to the device memory of the access target CPU or intelligent function module buffer memory. For the accessible range, refer to the following manual.

MELSEC Communication Protocol Reference Manual

#### Reading/writing programs and parameters

This function reads and writes program files and parameter files stored in the CPU module.

#### Remote control of CPU module

This function performs remote RUN/STOP/PAUSE/latch clear/reset operations.

#### Monitoring of CPU module

This function monitors the operation status and data in the device memory of the CPU module.

#### Transmitting data to a target device from a CPU module

This function requests data transmission from a CPU module to a target device, and transmits on-demand data to the target device.

### File access method

To access to a file, which the password setting is configured, from external devices using the MC protocol, specifying the command for file password is required.

- **1.** Specify the password with a request message.
- 2. Perform the password authentication by using the specified password.

For command requiring the password authentication, specify "0040" with the setting value of "subcommand" in the request message.

Function	Command (subcommand)
Deleting file	1822 (0040)
Copying file	1824 (0040)
Changing file attribute	1825 (0040)
Opening file	1827 (0040)

For more details on the commands, refer to the following manual.

MELSEC Communication Protocol Reference Manual

## **1.2** Data Communication

MC protocol uses the following communication frames for data communication.

Transmit/receive data from the target device in the data format corresponding to the MC protocol.

For details on the communication frames format, refer to the following manual.

MELSEC Communication Protocol Reference Manual

### Formats and codes

There are five formats for the data communication frames:

Setting value	format	Code of communication data	Remarks	Reference
1	Format 1	ASCII code	-	MELSEC Communication
2	Format 2	ASCII code	A format that a block number is added	Protocol Reference Manual
3	Format 3	ASCII code	A format enclosed with STX and ETX	
4	Format 4	ASCII code	A format that CR and LF are added at the end	
5	Format 5	Binary code	This can be used only for 4C frame.	

Set the format in the Communication protocol setting of an Engineering tool.



Communication using binary code shortens the communication time since the amount of communication data is about a half of the one in data communications using ASCII code.

### Frames

The following explains the types of frame (data communication message) used for a target device to access a supported equipment using the MC protocol, and the purpose of each frame.

The data communication frames are as shown below.

Frame	Feature and purpose	Compatible message format	Format
4C frame	Accessing from a target device to the maximum access range is available.	Dedicated protocol for C24 (QnA extension frame)	Formats 1 to 5
3C frame	The message format of access route is more simple than	Dedicated protocols for C24 (QnA frame)	Formats 1 to 4
2C frame	4C frame. Data communication software for MELSEC-QnA series programmable controller can be used.	Dedicated protocols for C24 (QnA simplified frame)	
1C frame	1C frame is the same message structure as when accessing using MELSEC-A series computer link modules. Data communication software for MELSEC-A series programmable controller can be used.	Dedicated protocols for A series Computer link modules.	

### Parameter settings for MC protocol communication

Set the transmission specification, and the communication protocol with target devices.

Select the communication protocol setting from MC protocol (from Format 1 to 5).

Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings"

Configure other settings according to the system being used.

For details of the setting content, refer to the following chapter.

Page 422 PARAMETER SETTING

### Applicability of multiple CPU systems

When a target device accesses to RCPU, which is a multiple CPU system, accessing to the control CPU or Non-control CPU of the multiple CPU system is available by specifying the target RCPU in "Request destination module I/O number" of MC protocol 4C frame.

	E N Q	Frame ID	No.	Ctation No		N - Freedow N	Network No.		PC No.		Request	module I/O No.	1	Request destination	module station No.	Self-station No.				Command				Sub command			Device code		I	Handler have	неад деисе	I	I		Number of device	points		Sum check	code
		Н	L	н	L	н	L	н	L	н	—	_	L	н	L	н	L	н	_	—	L	н	—	—	L	н	L	н	_	_	_	_	L	н	—	—	L	н	L
		F	8	0	5	0	7	0	3	0	3	Е	0	0	0	0	0	0	4	0	1	0	0	0	1	Х	*	0	0	0	0	4	0	0	0	0	5	3	6
k	)5н	46н	38н	30H	<b>3</b> 5н	30	<b>1</b> 37н	30H	<b>1</b> 33н	30+	133н	<b>4</b> 5н	<b>30</b> н	30н	30н	30н	30н	30H	<b>3</b> 4H	30H	31н	30н	30H	30H I	31н	58H	<b>1</b> 2Ан	30н	<b>1</b> 30н	<b>1</b> 30н	<b>1</b> 30н	<b>1</b> 34∺	<b>3</b> 0н	30н	30н	30н	35н	33н	36н

### Applicability of remote password function

The remote password function prevents unauthorized access to a CPU module from a remote location. By setting a remote password to the CPU module, this function can be applicable.

For the method for setting remote password, refer to the following manual.

GX Works3 Operating Manual

## **Using MX Component**

MX Component is an ActiveX control library that supports various types of communication paths between a personal computer and CPU module.

By using MX Component, an arbitrary system can be configured. Furthermore, the communication program for the target device can be created without considering the content of MC protocol (transmission/reception procedures). For details, refer to the following manuals.

MX Component Version 4 Operating Manual

MX Component Version 4 Programming Manual

# 2 DATA COMMUNICATION USING PREDEFINED PROTOCOL

Data can be transmitted and received between the CPU module and an target device with a protocol appropriate to the target device (such as a measuring instrument and a barcode reader).

Since devices or buffer memory data can be taken into communication packets, this protocol communication is suitable for data that may change every transmission.

The protocol setting required to communicate with the target device is configured in Engineering tool.

Protocols can be selected from the predefined protocol library offered or can be arbitrarily created and edited.

In addition, since the registered setting data is written to the CPU built-in memory, SD memory card, or flash ROM, the program size in the CPU module can be reduced.

For an example of data communication using the predefined protocol, refer to the following manual.

MELSEC iQ-R Serial Communication Module User's Manual (Startup)

#### Data communication using communication protocol



#### Point P

The number of protocols and packets that can be registered are as follows:

- Protocols: Up to 128
- Packets: Up to 256

Depending on the packet to be registered, the maximum numbers of packets above may not be registered. The usage rate of the packet data area differs depending on the types of protocol.

It can be confirmed on the status bar of the "Protocol Setting" screen displayed by following the procedure as follows:

• Select [Tool] ⇒ [Predefined Protocol Support Function] of Engineering tool, and set "Module Type" and "Connection Destination CPU" on the "Predefined Protocol Support Function" window. And, add the protocol on the "Predefined Protocol Support Function" screen.

## 2.1 Data Communication Procedure

By using the Predefined protocol support function, data can be communicated with a target device in the following procedure.

#### Operating procedure

- **1.** Select a protocol in "Predefined Protocol Support Function", and write the protocol setting data.
- Page 28 Creating protocol setting data
- 2. Set the module parameter to "Predefined protocol".
- Page 33 Setting method
- 3. Execute the protocol written with the dedicated instruction (CPRTCL).
- L MELSEC iQ-R Serial Communication Module User's Manual (Startup)
- 4. Monitor the executed protocol in the Protocol execution log. The transmitted/received data and the communication control signal status can also be checked using the Circuit trace function.
- MELSEC iQ-R Serial Communication Module User's Manual (Startup)

#### Restriction (")

Communication using the modem function is not available for the predefined protocol.

#### Creating protocol setting data

Create a protocol setting data using the Predefined protocol support function.

#### Selecting target module of a protocol setting data

Select a target module of the protocol setting data.

C Engineering tool [Tool] ⇒ [Predefined Protocol Support Function]



#### ■Creating new protocol setting data

Create a new protocol setting data.

D	[File]	⇔[N	lew]
	[·•]		

🗐 MELSOFT Series <predefin< th=""><th>ed Protocol Supp</th><th>ort Function-Serial Commu</th><th>unication Module&gt; - [Protocol Setti</th><th>ing - Untitled]</th><th></th><th></th></predefin<>	ed Protocol Supp	ort Function-Serial Commu	unication Module> - [Protocol Setti	ing - Untitled]		
Eile Edit Online	ool De <u>b</u> ugging	Support Function Wind	ow			_ 8 ×
🗄 🖻 🖪 I 🖻 🖪 🕞	49 AU					
Protocol Manufacturer	Model	Protocol Name	Communication Type	-> Send <-Receive	Packet Name	Packet Setting
AUG						
			III			F
Protocol in Predefined Protoco Protoco Send F Receive	otocol Library ol Line 'acket Line e Packet Line	Editable Protocol Prot Sen Reco	iocol Line d Packet Line eive Packet Line			
Protocols 0/128 Packe	ts 0/256 Pa	icket Data Area Usage 0.0	% Module for Debugging		Kana characte	s CAP NUM SCRL

Item	Description
Protocol No.	Displays the protocol number to be used for a predefined protocol dedicated instruction in programs.
Manufacturer	Displays the manufacture's name of a device to which a protocol to be set is applied.
Model	Displays the model name of a device to which a protocol to be set is applied.
Protocol Name	Displays the name of a protocol to be set.
Communication Type	<ul> <li>Displays the communication type in a protocol to be set.</li> <li>Send Only: Send one send packet once.</li> <li>Receive Only: Receive a packet if it matches any of up-to-16 registered receive packets.</li> <li>Send&amp;Receive: Send one send packet, and receives a packet if it matches any of up-to-16 registered receive packets.</li> </ul>
→Send/←Receive	Displays the packet direction. • →: For 'Send' • ←(1) to (16): For 'Receive', a receive packet number is displayed in ().
Packet Name	Displays the packet name.
Packet Setting	<ul> <li>Displays the existence or non-existence of variables in an element, and set or unset of the variables.</li> <li>With 'Variable Unset', 'Element Unset', or 'Element error', the settings cannot be written to a CPU module or C24.</li> <li>No Variable: There is no variable in the element.</li> <li>Variable Set: All variables are set.</li> <li>Variable Unset: There are one or more unset variables.</li> <li>Element Unset: There is no element in the editable protocol.</li> <li>Element error: The element does not meet requirement.</li> </ul>

#### ■Adding protocols

Add a protocol.

C [Edit] ⇒ [Add Protocol]

Add Ph	otocol				<u> </u>					
Add	ls new proto	col.								
	Selection of	Protocol Type to Add								
	<u>T</u> ype :	Predefined Protoco	Library	Refere	nce					
	rotocol Kis new protoc Selection of F Type : Protocol to Av Protocol to Av No.	* Select from Prede Please select manuf Add. Add	* Select from Predefined Protocol Library. Please select manufacturer, model and protocol name from Protocol to Add.							
	Protocol No.	Manufacturer	Model	Protocol Name						
	1	MITSUBISHI ELECTRIC	FREQROL Series	H7B:RD Operation Mode						
	,									

Item	Description	Setting range
Туре	Select a protocol type to be added.	<ul> <li>Predefined Protocol Library</li> <li>User Protocol Library</li> <li>Add New</li> </ul>
Protocol No.	Set the number of the protocol to be added.	1 to 128
Manufacturer <sup>*1</sup>	Set a manufacturer's name of the protocol to be added.	—
Model <sup>*1</sup>	Set a model of the protocol to be added.	—
Protocol Name <sup>*1</sup>	Set a name of the protocol to be added.	—

\*1 These items can be set only when "Predefined Protocol Library" is selected in "Type".

#### Configuring detailed setting of protocols

Set the transmission/reception parameters of the protocol.

℃ Select a row of any protocol on the "Protocol Setting" screen ⇔ [Edit] ⇔ [Protocol Detailed Setting].

tocol Detailed Setting				
Connected Device Informat	ion			
<u>M</u> anufacturer	MITSUBISHI	ELECTRIC		
Туре	Inverter			
Model	FREQROL Se	ries		
Version	0001			(0000 to FFFF)
Explanation	General-Purp	ose Inverte	r	
Protocol Setting Information	n			
Protocol No.	1			
Protocol Name	H7B:RD Ope	ration Mode	•	
Communication Type	Send&Receiv	e		
Receive Setting Glear OS area (receive data <u>R</u> eceive Wait Time	a area) before pri	otocol exec	ution ⓒ Enable [Setting Range] O to	O Disable 30000 (0: Infinite Wait )
Send Setting	,			
Number of Send Retries	0	Times	[Setting Range] O to	10
Send Retry Interval	500	× 10ms	[Setting Range] O to	30000
Standby Time	0	x 10ms	[Setting Range] O to	30000
Monitorina Time	200	x 100ms	[Setting Range] O to	3000 (O: Infinite Wait )
Communication Parameter	Batch Setting			

Item		Description
Connected Device	Manufacturer	Set a manufacturer's name of the connected device.
Information '	Туре	Set a device type of the connected device.
	Model	Set a model of the connected device.
	Version	Set a device version of the connected device.
	Explanation	Set equipment description for the connected device.
Protocol Setting	Protocol No.	Displays a protocol number of the selected protocol.
Information '	Protocol Name	Set a protocol name of the protocol.
	Communication Type	Select a communication type of the protocol.
Receive Setting	Clear OS area (receive data area) before protocol execution	Select whether to clear the OS area (receive data area) of the module before the protocol execution. If 'Disable' is selected, the data received in the module before the protocol execution also become a receive target of the protocol.
	Receive Wait Time	Set waiting time after the module turns to the 'waiting for reception' status. If the communication with target devices is not available due to such as a cable disconnection and no matched packet can be received within the set time, the module determines an error and cancels the 'waiting for reception' status.
Send Setting	Number of Send Retries	Set the number of times the module retries to send when the sending from the module has not been completed within the set time of "Monitoring Time". The module determines an error if the sending has not been completed despite the specified number of times of sending retries.
	Send Retry Interval	Set the interval between the failure of sending from the module and the retry when the sending from the module has not been completed within the set time of "Monitoring Time".
	Standby Time	Set standby time between when a protocol set to the module turns to the execution status and when it actually sends the data. By setting this item, the send timing of the module can be adjusted to readiness of target devices to receive data.
	Monitoring Time	Set waiting time between when the module turns to the 'sending' status and when the sending is completed. If the communication with target devices is not available due to such as a cable disconnection and the sending cannot be completed within the set time, the module determines an error and cancels the 'sending' status.
	Standby Time Monitoring Time	Set standby time between when a protocol set to the module turns to the execution status and when it actually sends the data. By setting this item, the send timing of the module can be adjusted to readines target devices to receive data. Set waiting time between when the module turns to the 'sending' status and when the sending is completed to be the communication with target devices is not available due to such as a cable disconnection and the sending cannot be completed within the set time, the module determines an error and cancels the 'sentistatus.

\*1 For a protocol selected from the predefined protocol library, "Connected Device Information" and "Protocol Setting Information" cannot be modified.

●Processing when the data transmitted error occurred (when the number of send retries is set to '2')

When the set value of "Number of Retries" is 2, the module determines an error at the following timing if it cannot send the data.



Point P

The communication parameters can be set for multiple protocols by clicking the [Communication Parameter Batch Setting] button and setting "Setting Protocol No. Range", "Receive Setting", or "Send Setting".

Communication Parameter Batch Sett	ing							×
Setting Protocol No. Range								
Distant No. 1		7						
	- 11 -	1						
Receive Setting								
🔽 Clear OS area (receive dat	a area) before pro	otocol exe	cution	Enable	e O Dis	able		
Receive Wait Time	× 1	.00ms [S	etting Ran	ge]0 to	30000 (0	): Infi	inite Wait	)
Send Setting								
✓ Number of Send Retries	0	Times	[Setting	Range](	) to 10			
🔽 Send Retry Interval	500	x 10ms	[Setting	Range]C	) to 3000	0		
✓ Standby Time	0	x 10ms	[Setting	Range](	) to 3000	0		
Mgnitoring Time	200	x 100ms	Setting	Range]C	) to 3000	0 (0:	Infinite W	ait )
					ОК	1	Can	el l
							<u></u>	

#### ■Setting packets

Set the packet elements to be transmitted/received on the "Packet Setting" screen.

"The protocol setting" screen ⇒ desired packet setting"

acket Setting				×
Protocol No.	1	Protocol Na	me H7B:RD Operation Mode	
Packet Type	Send Packet	Packet Nam	e H7B:RD Operation Mode	
Element List				
Element No.	Element Type	Element Name	Element Setting	
1	Header	ENQ	(ENQT1Byte)	
2	Conversion Variable	Inverter Station Number	Variable unset error(->HEX/Fixed Number of Data/Number of data (1)/Digit (2)/Padded (0)/Word/Delimiter [none])	
3	Static Data	Instruction Code	"78"[28yte]	
4	Static Data	Waiting Time	"0"[18yte]	
5	Check Code	Sum Check	(Object element2-4/Sum Check/HEX/No calculation/Forward/28yte)	
6	Terminator	CR	(CR)(18ve)	
Chang <u>e</u> Typ	e <u>A</u> dd New	<u>C</u> opy <u>P</u> as	te Delete	Close

The screen above is an example when "Predefined Protocol Library" is selected on the "Add protocol" screen.

When "Add New" or "User Protocol Library" is selected, press the [Change Type] button or [Add New] button to configure the packet.

For details on the packet elements, refer to the following section.

🖙 Page 35 Packet

#### Writing protocol setting data

Write data of the protocol settings to a CPU module or C24.

$\bigtriangledown$	[Online] ⇒	[Module	Write]
--------------------	------------	---------	--------

Module Write		×
Target Module Select	lion	
Module Selection	0000:RJ71C24 •	
Target <u>M</u> emory	CPU Built-in Memory	
Please save in the prot because the data to be information. [Non-written Data in T Manufacturer Packet Name Protocol Detailed Settii	ocal setting file (*.pf2) a written to module does not include the following arget Memory] ng Type, Version, Explanation ration, Element Name.	
Packet Setting Lontidu		

Write the protocol setting data after selecting the module to be written and memory.

When writing data to the CPU module, the protocol setting data is written to "Module Extended Parameter".

#### Point P

The following data is not displayed even when reading from CPU module because it will not be written as a protocol setting data. However, the protocol selected from the predefined library is displayed.

- Manufacturer
- Packet name
- Type, Version, Explanation in the protocol detailed setting
- · Element name in the packet setting

The operation when the predefined protocol setting is written to a multiple target memory is as follows:

• When the predefined protocol setting is written to both CPU built-in memory and an SD memory card The CPU module operates according to the settings of "Memory Card Parameter". For details on the "Memory Card

Parameter", refer to the following manual.

MELSEC iQ-R CPU Module User's Manual (Application)

• When the predefined protocol setting is written to a CPU built-in memory or an SD memory card, and C24 The predefined protocol settings of the CPU built-in memory or SD memory card is enabled in the following timing. (If the predefined protocol settings are written both CPU built-in memory and SD memory card, the CPU module operates according to the settings of "Memory Card Parameter".

When the predefined protocol is enabled, the predefined protocol settings of C24 will be overwritten with the predefined protocol of CPU built -in memory or SD memory card.

- When the power is turned OFF $\rightarrow$ ON
- · When the CPU module is reset

#### Setting method

Set the predefined protocol settings in "Various control specification" of "Basic Settings". (SP Page 422 PARAMETER SETTING)

Navigation window ⇒ [Parameters] ⇒ [Module Information] ⇒ Module Name ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

1. Set the "Communication Protocol Setting" in "Various control specification" to "Predefined Protocol".

2. Set the required parameters other than above.

#### Dedicated instruction to be used

Use the CPRTCL instruction.

## 2.2 Communication Type of Protocols

A send packet to the target devices and a receive packet from the target devices at the time of process execution are registered in a protocol.

The packet elements which are set to the Predefined protocol support function is applied to the actual data portion of the packet to be transmitted.

For details of packet elements, refer to the following section.

Page 35 Packet elements

Ex.

Example of a packet configuration

	Data area						
Header	Station No.	Command	Number of byte to be read	Read data	Check code	Terminator	
Maximum data length: 2048 bytes							

With the Predefined protocol support function, communications with target devices are performed using the following procedures (communication types).

Communication	Processing	
type name		
Send Only	Sends a send packet once. One send packet is required.	
Receive Only	Receives a packet if it matches any of up to 16 defined receive packets. One or more receive packets are required.	
Send & Receive	Sends a send packet, and then receives a packet if it matches any of up to 16 defined receive packets. One send packet and one or more receive packets are required.	

For the operation of each operation type, refer to the following section.

Page 521 Operation Image and Data Structure of Predefined Protocol
# 2.3 Packet

A packet consists of packet elements.

Up to 32 elements can be set in a packet, and the maximum data length is 2048 bytes per packet.

## **Packet elements**

The following explains the details of the packet elements.

For data examples on packet elements, refer to the following section.

I Page 527 Data examples of packet elements

#### Header

Use this element when a specific code or character string exists at the head of a packet.

- When sending: Sends a specified code and character string.
- · When receiving: Verifies a header and received data.

Element Setting - He	ader(Send)		×
Element <u>N</u> ame	STX		1
Code <u>Lype</u>			
Setting <u>V</u> alue	[STX]		(1 byte)
	Input Control Code	[Setting Range] 1 to 50	
		ОК	Iancel

Item	Description	Remarks
Element Name	Set a name of the element.	—
Code Type	Select a data type of the setting value. ASCII String/ASCII Control Code/HEX	—
Setting Value	Set data within 1 to 50 bytes. The setting ranges that can be set for each code type are as follows: • ASCII String: 20H to 7EH • ASCII Control Code: 00H to 1FH, and control code of 7FH • HEX: hexadecimal data of 00H to FFH	Setting example • ASCII String: 'ABC' • ASCII Control Code: STX • HEX : FFFF

Point P

• Only one header can be used in a packet.

• A header can be set only at the head of a packet.

#### Static Data

Use this element when a specific code or character string such as command exists in a packet.

- When sending: Sends a specified code and character string.
- · When receiving: Verifies the received data.



Item	Description	Remarks
Element Name	Set a name of the element.	—
Code Type	Select a data type of the setting value. ASCII String/ASCII Control Code/HEX	_
Setting Value	Set data within 1 to 50 bytes. The setting ranges that can be set for each code type are as follows: • ASCII String: 20H to 7EH • ASCII Control Code: 00H to 1FH, and control code of 7FH • HEX: hexadecimal data of 00H to FFH	Setting example • ASCII String: 'ABC' • ASCII Control Code: US • HEX : FFFF

Point P

Multiple static data elements can be placed to desired positions in the data portion.

#### Terminator

Use this element when a code or character string indicating the end of the packet is included.



Item	Description	Remarks
Element Name	Set a name of the element.	—
Code Type	Select a data type of the setting value. ASCII String/ASCII Control Code/HEX	_
Setting Value	Set data within 1 to 50 bytes. The setting ranges that can be set for each code type are as follows: • ASCII String: 20H to 7EH • ASCII Control Code: 00H to 1FH, and control code of 7FH • HEX: hexadecimal data of 00H to FFH	Setting example • ASCII String: 'ABC' • ASCII Control Code: ETX • HEX : FFFF

Point *P* 

• Only one terminator can be used in a packet.

• Only a check code and static data can be placed after a terminator.

#### Length

Use this element when an element indicating the data length is included in a packet.

- When sending: Calculates the data length of a specified range, and adds the result to a send packet.
- When receiving: Verifies the data (value) corresponds to the length in the received data as the data length of a specified range.

Element Setting - Length(Send)	×
Element <u>N</u> ame	Data Length
Code <u>T</u> ype	ASCII Hexadecimal
Data Length	2
Data Fl <u>o</u> w	Forward Direction (Upper Byte -> Lower Byte)
Calculating Range (Start)	2
Calculating Range (End)	4
	OK Cancel

Item		Description	Remarks		
Element Nan	ne	Set a name of the element.		—	
Code Type		Select a format of the data ler ASCII Hexadecimal/ASCII De	Select a format of the data length. ASCII Hexadecimal/ASCII Decimal/HEX		
Data Length		Select the data length on the The range is 1 to 4.	_		
Data Flow		Forward Direction (Upper Byte $\rightarrow$ Lower Byte)	<ul><li>When sending: Sends a calculated length from the upper byte.</li><li>When receiving: Receives data from the upper byte.</li></ul>	Cannot be set when "Data Length" is 1 byte.	
		Reverse Direction (Lower Byte $\rightarrow$ Upper Byte)	<ul><li>When sending: Sends a calculated length from the lower byte.</li><li>When receiving: Receives data from the lower byte.</li></ul>		
		Byte Swap (by Word)	<ul> <li>When sending: Sends a calculated length swapping the upper byte and lower byte by word.</li> <li>When receiving: Receives data swapping the upper byte and lower byte by word.</li> </ul>		
Calculating Range	Start	Select the start packet element numbers for the calculating range. The range is 1 to 32.		_	
	End	Select the last packet elemen The range is 1 to 32.			

#### Point P

- Only one length can be used in a packet.
- When there is no element other than a length, an element error occurs.
- When the number of digits of calculation result is greater than that specified in "Data Length", digits greater than the specified digit are omitted (ignored).

Example) When "2 bytes" is specified in "Data Length" and the calculation result is "123 bytes", the data length is considered as "23".

 When any of a Non-conversion variable (Variable length), Conversion variable (Variable number of data), Conversion variable (Fixed number of data/Variable number of digits<sup>\*1</sup>), and Non-verified reception (Variable number of characters) is placed behind a Length and they are not included in the calculating range of the Length, place any of the following data immediate after the Non-conversion variable (Variable length), Conversion variable (Variable length) or Non-verified reception.

Static Data

Terminator

Check code + Static Data

Check code + Terminator

- When "Code Type" is "ASCII Hexadecimal", a corresponding packet is regarded as a mismatch packet if a string except for '0' to '9', 'A' to 'F', and 'a' to 'f' is received.
- When "Code Type" is "ASCII Decimal", a corresponding packet is regarded as a mismatch packet if a string except for '0' to '9' is received.

37

<sup>\*1</sup> Excluding a case where "Number of Send Data" is '1' and "Delimiter" is not 'No delimiter'.

#### Non-conversion Variable

Use this element to send the data in the device memory of a CPU module or buffer memory as a part of a send packet, or store a part of a receive packet to the device memory of a CPU module or buffer memory.

Element Setting - Non-conversion Variable(Send)			
Element Name	Slave Address		
Fixed Length/Variable Length	Fixed Length		
Data Length/Maximum Data Length	1 [Setting Range] 1 to 2048		
Unit of Stored Data	Lower Byte + Upper Byte 🔹		
Byte Swap	Disable (Lower -> Upper)		
Data Storage Area Specification			
Send Data Storage Area	D1 (1 Word)		
[Specifiable Device Symbol] X, Y, M, L, B, D, W, R, ZR, G (Buffer	Memory)		
	OK Cancel		

Item	Description		
Element Name	Set a name of the element.		
Fixed Length/Variable	Fixed Length	Sends and receives the data whose length is fixed.	
Length	Variable Length	<ul> <li>When sending: Specifies the data length at the time of the protocol execution and sends data.</li> <li>When receiving: Receives data whose data length is variable.</li> </ul>	
Data Length/ Maximum Data Length	Set the length of data to be transmitted and received. (For the variable length data, set the maximum data length that can be specified to the data length storage area.) The range is 1 to 2048.		
Unit of Stored Data	Lower Byte + Upper Byte	<ul> <li>When sending: Sends each one word (2 bytes) data in the data storage area in the order of the lower byte to the upper byte.</li> <li>When receiving: Stores the received data to the data storage area in the order of the lower byte to the upper byte.</li> </ul>	
	Lower Bytes Only	<ul> <li>When sending: Sends only lower byte of data in the data storage area. C24 ignores data in the upper byte.</li> <li>When receiving: Stores the received data in the only lower byte of the data storage area. C24 stores 00H in the upper byte.</li> </ul>	
Byte Swap	Disable (lower -> upper)/ Enable (upper -> lower)	<ul> <li>When sending: When "Enable" is selected, sends data swapping the upper byte and lower byte by word (2 bytes).</li> <li>When "Unit of Stored Data" is "Lower Byte + Upper Byte" and "Data Length" is an odd number of bytes, sends the upper byte at transmission of the last byte.</li> <li>When "Unit of Stored Data" is "Lower Bytes Only" and "Data Length" is an odd number of bytes, sends data without any byte swap at transmission of the last byte.</li> <li>When receiving: When 'Enable' is selected, receives data swapping the upper byte and lower byte by word (2 bytes).</li> <li>When "Unit of Stored Data" is "Lower Byte + Upper Byte" and "Data Length" is an odd number of bytes, stores the last byte to the upper byte.</li> <li>When "Unit of Stored Data" is "Lower Byte + Upper Byte" and "Data Length" is an odd number of bytes, stores the last byte to the upper byte.</li> <li>When "Unit of Stored Data" is "Lower Bytes Only" and "Data Length" is an odd number of bytes, stores the last byte to the upper byte.</li> <li>When "Unit of Stored Data" is "Lower Bytes Only" and "Data Length" is an odd number of bytes, stores the last byte without any byte swap.</li> </ul>	
Data Storage Area Specification	Specify a start device to ste Settable devices Internal user <sup>*1*2</sup> • Input (X) • Output (Y) • Internal relay (M) • Latch relay (L) • Link relay (B) • Data register (D) • Link register (W) File register <sup>*2</sup> • File register (R,ZR) Buffer memory • G device (G)	ore variable value.	

\*1 Do not set local devices.

\*2 Set within the device range specified in the following screen.

Project window ⇒ [Parameter] ⇒ CPU module type ⇒ [CPU Parameter] ⇒ [Memory/Device Setting]

The following explains the configuration of the data storage area.

#### When "Fixed Length/Variable Length" is "Fixed Length"

An area starting from the device number which is specified on the "Element Setting" screen is considered as the data storage area.

The data storage area to be occupied varies depending on the setting of "Unit of Stored Data".

- When "Lower Byte + Upper Byte" is selected, the same size as the data length is occupied. (However, when the data length of a send packet is an odd number, the upper byte (lower byte for "Byte Swap") of the last device is not sent. When the data length of a receive packet is an odd number, the last data is stored with one byte of 00H added.)
- When "Lower Bytes Only" is selected, twice the size of the data length is occupied.



#### When "Fixed Length/Variable Length" is "Variable Length"

An area starting from the device number which is specified on the "Element Setting" screen +1 is considered as the data storage area.

The data storage area to be occupied varies depending on the setting of "Unit of Stored Data".

• When "Lower Byte + Upper Byte" is selected, the same size as the data length + one word (length for the data length storage area) are occupied.

(However, when the data length of a send packet is an odd number, the upper byte (lower byte for "Byte Swap") of the last device is not transmitted. When the data length of a receive packet is an odd number, one byte of 00H is added to the last data and stored.)

• When "Lower Bytes Only" is selected, twice size of the data length + one word (length for the data length storage area) are occupied.



\*1 The unit of data length is byte.

#### Precautions

• When receiving variable length data whose length exceeds the "Maximum data length", C24 stores data as long as the maximum data length and omits the rest. (A protocol completes successfully.)

• Out of packet data received from target devices, the data corresponding to variable needs to be discriminated from a terminator or a static data immediately after non-conversion variable. The reception processing may not be performed normally if they cannot discriminated.

#### Ex.

When value of a terminator or value of a static data following a non-conversion variable is used in a non-conversion variable, C24 recognizes it as data of a terminator or a static data following a non-conversion variable and performs the verification/ reception processing.

• Multiple Non-conversion variable (Fixed length) elements can be placed in a packet, and multiple Non-conversion variable (Variable length) elements can also be placed in a send packet. However, only one Non-conversion variable (Variable length) can be placed in a receive packet, and any of the following requirements need to be met.

· Place any of the following items immediate after the non-conversion variable.

Static Data

Terminator

Check code + Static Data

Check code + Terminator

• Place a Length before a Non-conversion variable and include the Non-conversion variable in the calculating range.

In addition, two or more of the following four elements cannot be placed in the same packet.

- Variable number of data [Conversion variable]
- Fixed number of data and variable number of digits [Conversion variable] (Excluding a case where "Number of Send Data" is '1' and "Delimiter" is not 'No delimiter'.)
- Variable length [Non-conversion variable]
- Variable number of characters [Non-verified reception]

#### **Conversion Variable**

This element converts the numerical data in the device memory of a CPU module or buffer memory to an ASCII string and sends it, or converts the received data (ASCII string) to the numerical data and stores it to the device memory of a CPU module or buffer memory.

Element Setting - Conversion Variable(Send)		×
Element Name	Read Data	
Conversion	HEX->ASCII Decimal	•
Fixed Number of Data/Variable Number of Data	Variable Number of Data	•
Number of Send Data	80	[Setting Range] 1 to 25
Number of Send Digits of Data	4	•
Blank-padded Character at Send	0	•
Conversion Unit	Word	•
Sign	Signed	•
Sign Character	None	•
Number of Decimals	No Decimal Point	•
Delmiter	No Delimiter	•
Data Storage Area Specification		
Data Count Storage Area	DO	(1 Word)
Send Data Storage Area	D1	(80 Word)
	080	
[Specifiable Device Symbol] X, Y, M, L, B, D, W, R, ZR, G (Buffer Memo	ry)	
		OK Cancel

Item	Description		
Element Name	Set a name	e of the element	
Conversion	When	$HEX \to ASCII \ Decimal$	Converts numeric value stored in the data storage area to ASCII decimal.
	sending	$\begin{array}{l} HEX \to ASCII \\ Hexadecimal \end{array}$	Converts numeric value stored in the data storage area to ASCII hexadecimal.
	When receiving	ASCII Decimal→ HEX	Treats received data as ASCII decimal, converts it to numeric value, and stores it to the data storage area.
		ASCII Hexadecimal→ HEX	Treats received data as ASCII hexadecimal, converts it to numeric value, and stores it to the data storage area.
Fixed Number of Data/	Fixed Num	ber of Data	Fixes the number of data to be sent and received.
Variable Number of Data	Variable Number of Data		<ul> <li>When sending: Specifies the number of data to be sent at the time of the protocol execution and sends the data.</li> <li>When receiving: Receives data of which the number is variable.</li> </ul>
			For variable number of digits, delimiters are required.
Number of Send Data/ Maximum Number of Data	Set the nur specified to The range	nber of data to be transmitte o the data quantity storage a is 1 to 256.	d and received. (For "Variable Number of Data", set the maximum number of data that can be rea.)
Number of Send Digits 1 to 10 of Data			Set the number of digits per one transmitted and received data. When the number of send digits of data is less than the specified number of digits of data, upper digits are filled with blank-padded characters.
	Variable Number of Digits		<ul> <li>When sending: Sends only the data portion converted to an ASCII string in variable length.</li> <li>When receiving: Receives only an ASCII string of the data portion in variable length. When the number of send data/maximum data length is set to 2 or greater, blank-padded characters are required.</li> </ul>
Blank-padded Character at Send	0/Space		Select a character used to fill upper digits when the number of digits of data is not "Variable Number of Digits" and the number of digits of transmitted/received data is less than the specified number of send digits of data.
Conversion Unit	Select how many words are manipulate For 'Word', converts data manipulating For 'Double word', converts data manip		ed as one data in the data storage area. one word as one data. ulating two words as one data.
Sign	Unsigned/Signed		Select whether to add signs to date in the data storage area. This item can be set when "Conversion" is "HEX $\rightarrow$ ASCII Decimal" or "ASCII Decimal $\rightarrow$ HEX".
Sign Character	None/+/0/Space		Select the sign character for positive value on line. This item can be set when "Conversion" is "HEX $\rightarrow$ ASCII Decimal" or "ASCII Decimal $\rightarrow$ HEX", and "Sign" is "Signed". The sign character for negative value is fixed to "-".
Number of Decimals	No Decimal Point/Variable Point/1 to 9		Select the decimal point position of data on line. This item can be set when "Conversion" is "HEX $\rightarrow$ ASCII Decimal" or "ASCII Decimal $\rightarrow$ HEX".

Item	Description	
Delimiter	No Delimiter/Comma/Space	Select the delimiter inserted after one data. A delimiter is not added to the end of data when the number of data is 2 or more.
Data Storage Area Specification	Specify a start device to store variable value.	

The following explains the configuration of the data storage area.

#### When "Fixed Number of Data/Variable Number of Data" is "Fixed Number of Data"

An area starting from the device number which is specified on the "Element Setting" screen is considered as the data storage area.



#### When "Fixed Number of Data/Variable Number of Data" is "Variable Number of Data"

An area starting from the device number which is specified on the "Element Setting" screen +1 is considered as the data storage area.



#### ■Occupied size in data storage area

The size occupied in the data storage area varies depending on the settings of "Conversion Unit" and "Number of Decimals".

Setting item		Occupied size in data storage area per one data
Conversion Unit	Number of Decimals	
Word	No Decimal point/Fixed point	1 word
	Variable point	2 words
Double Word	No Decimal point/Fixed point	2 words
	Variable point	4 words

#### Data storage area configuration per one data

The following shows the data storage area configuration per one data.

Conversion Unit": Word, "Number of Decimals": No decimal Point/Fixed point

	Data storage area
OН	Numeric data

Conversion Unit": Word, "Number of Decimals": Variable point

For 'Variable Point', the decimal point position is set in the data storage area.

	Data storage area
0H	Numeric data
1H	Decimal point position

In the decimal point position area, the decimal point position is set as follows.

Send/receive data (number of digits of data is 5)	Numeric data	Decimal point position
12345	12345 (3039H)	1 (1H)
1234.5	12345 (3039H)	10 (0AH)
123.45	12345 (3039H)	100 (64H)
12.345	12345 (3039H)	1000 (3E8H)
1.2345	12345 (3039H)	10000 (2710H)

Conversion Unit": Double word, "Number of Decimals": No Decimal Point/Fixed point

	Data storage area	
он	Numeric data	(L)
1H		(H)

Conversion Unit": Double word, "Number of Decimals": Variable Point

For 'Variable Point', the decimal point position is set in the data storage area.



In the decimal point position area, the decimal point position is set as follows.

Send/receive data (number of digits of data is 10)	Numeric data	Decimal point position
1234567890	1234567890 (499602D2H)	1 (1H)
123456789.0	1234567890 (499602D2H)	10 (0AH)
12345678.90	1234567890 (499602D2H)	100 (64H)
1234567.890	1234567890 (499602D2H)	1000 (3E8H)
:	:	:
1.234567890	1234567890 (499602D2H)	100000000 (3B9ACA00H)

#### **■**Range of value that can be used in the data storage area

The following table shows the range of value that can be used in the data storage area.

Conversion	Sign	Conversion unit	Range of value
HEX $\rightarrow$ ASCII decimal	Unsigned	Word	0 to 65535 (0H to FFFFH)
ASCII decimal $\rightarrow$ HEX		Double word	0 to 4294967295 (0H to FFFFFFFH)
	Signed	Word	-32768 to 32767 (8000H to FFFFH, 0H to 7FFFH)
		Double word	-2147483648 to 2147483647 (80000000H to FFFFFFFH, 0H to 7FFFFFFH)
$HEX\toASCII$	—	Word	0H to FFFFH
hexadecimal ASCII hexadecimal → HEX		Double word	0H to FFFFFFFH

43

#### ■Considerations for configuring packet element

To place a Conversion variable in a packet, the following requirements need to be met.

To place Conversion variable in send packet

Multiple Conversion variable elements can be placed in one packet, and they can be placed in desired positions in the data portion.

To place Conversion variable in receive packet

Multiple Conversion variable elements can be placed in one packet in the cases other than "Variable number of data" and (3) of "Fixed number of data".

Variable numbe ( Only one Conv variable can be packet, and eith following (1) or ( met. )	r of data version placed in one er of the 2) need to be	(1)	<ul> <li>For discriminating the data length of a Conversion variable, any of the following items is placed immediate after the Conversion variable.</li> <li>Static data</li> <li>Terminator</li> <li>Check code + Static data</li> <li>Check code + Terminator</li> </ul>
		(2)	A "Length" is placed before a Conversion variable. (The Conversion variable needs to be included in the calculating range.)
Fixed number of data	Variable number of	(3)	When the number of data is 2 or more, or the number of data is 1 with no delimiter, only one Conversion variable can be placed in a packet and it needs to be placed in the order mentioned in [Variable number of data].
	digits	(4)	<ul> <li>When a Conversion variable (the number of data is 1, with delimiter, and variable number of digits) and the following four elements are placed in the same packet, these four elements need to be placed behind the Conversion variable (the number of data is 1, with delimiter, and variable number of digits).</li> <li>"Conversion Variable" (variable number of data)</li> <li>Conversion variable (fixed number of data and variable number of digits) (The case of (3). Excluding a case where "Number of Send Data" is '1' and "Delimiter" is not "No Delimiter".)</li> <li>Non-conversion variable (variable number of characters)</li> <li>Note that two or more of these four elements cannot be placed in the same packet.</li> </ul>
	Fixed number of	(5)	■When a Conversion variable (variable decimal point) and the four elements mentioned in (4) are placed in the same packet, these elements need to be placed behind the Conversion variable (variable decimal point).
	digits (1 to 10)	(6)	When a Conversion variable (unsigned) and the four elements mentioned in (4) are placed in the same packet, these elements need to be placed behind the Conversion variable (unsigned).

#### Precautions

An error may occur on C24 in any of the following cases.

• A string other than '0'-'9', 'A'-'F', or 'a'-'f' is received

When "Conversion" is "ASCII Hexadecimal $\rightarrow$ HEX", an ASCII  $\rightarrow$  BIN conversion error (7F20H) may occur if a string other than '0'-'9', 'A'-'F', or 'a'-'f' is received.

• A string other than '0'-'9' is received

When "Conversion" is "ASCII Decimal $\rightarrow$ HEX", an ASCII  $\rightarrow$  BIN conversion error (7F20H) may occur if a string other than '0'-'9' is received. However, the error does not occur in the following cases.

Item	C24 operation
Sign/Sign Character	When "Signed" is selected, a signed character can be received. However, when a signed character which is not at the head of data is received, an ASCII $\rightarrow$ BIN conversion error (7F20H) may occur.
Number of Decimals	When any other than "No decimal point" is selected, '. ' (a period) can be received. However an ASCII $\rightarrow$ BIN conversion error (7F20H) may occur when '. ' (a period) which is not at the specified number of digits of data is received. An ASCII $\rightarrow$ BIN conversion error (7F20H) may also occur when "Variable point" is selected and '. ' (a period) which is at the head or end of a unit of data is received.
Delimiter	When any other than "No delimiter" is selected, a delimiter can be received. However an ASCII $\rightarrow$ BIN conversion error (7F20H) may occur when a delimiter which is not at a boundary of data is received.

A data of which number of digits exceeds the upper limit is received

When "Number of Send Digits of Data" is "Variable Number of Digits", an abnormal digit number error (7D19H) may occur if the number of digits of received data exceeds the upper limit shown below.

Conversion unit	Conversion content	Upper limit of number data to be received
Word	ASCII Decimal→HEX	5 digits
	ASCII Hexadecimal→HEX	4 digits
Double word	ASCII Decimal→HEX	10 digits
	ASCII Hexadecimal→HEX	8 digits

• A data whose decimal point position is greater than the number of digits is specified When "Number of Decimals" is 'Variable Point' in a send packet, a decimal point place specification error (7D21H) may occur if the decimal point position is greater than the number of digits.

- A data whose number of digits is '0' is received When "Number of Send Digits of Data" is "Variable Number of Digits", an abnormal digit number error (7D19H) may occur if the number of digits of received data is '0'.
- A data whose number of digits are fewer than the digits specified in "Number of Send Digits of Data" are received An insufficient digit number error (7D18H) may occur if data whose number of digits are fewer than the digits specified in "Number of Send Digits of Data" are received.

Example) When "Number of Send Digits of Data" is set to 4 digits



A data whose number exceeds "Maximum number of data" is received
 When receiving data of which the number exceeds the "Maximum number of data", C24 stores data as many as the maximum number of data and omits the rest. (A protocol completes successfully.)

· A data that cannot be distinguished between Terminator or a Static data

In received packet data from target devices, C24 needs to be able to discriminate data corresponding to a Conversion variable from those of a Terminator or a Static data following a Conversion variable.

The reception processing may not be performed normally if they cannot be distinguished.

Example) When the value of Terminator or a Static data following the Conversion variable is used as a Conversion variable, C24 recognized it as a fixed data following the Conversion variable, verify, and perform reception processing.

#### **Check Code**

Use this element when an element indicating check code data is included in a packet.

C24 automatically calculates a specified check code at timing of sending/receiving, and adds it to a send packet or detects an error of a receive packet.

Element Setting - Check Code(	Send) 🗾
Element <u>N</u> ame	Sum Check
Processing Method	Sum Check
Code <u>T</u> ype	ASCII Hexadecimal
Data Length	2
Data Fl <u>o</u> w	Forward Direction (Upper Byte -> Lower Byte)
Complement Calculation	No Complement Calculation
Calculating Range (Start)	2
Calculating Range (End)	3
	OK Cancel

Item		Description		Remarks
Element Name		Set a name of the element.		_
Processing Metho	bd	Select a calculating method. Horizontal parity/Sum check/	16-bit CRC (for MODBUS)	—
Code Type		ASCII Hexadecimal ASCII Decimal HEX	<ul> <li>When sending: Select a format in which a calculated check code is sent.</li> <li>When receiving: Select a format in which data are received.</li> </ul>	Not settable when "Processing Method" is "16-bit CRC (for MODBUS)"
Data Length		Select the data length on the The range is 1 to 4.	line (byte).	Not settable when "Processing Method" is "16-bit CRC (for MODBUS)"
Data Flow		Forward Direction (Upper byte $\rightarrow$ Lower byte)	<ul> <li>When sending: Sends a calculated check code, from the upper byte.</li> <li>When receiving: Handles received data as a check code, from the upper byte.</li> </ul>	Not settable when "Processing Method" is "16-bit CRC (for MODBUS)", or when the "Data Length" is set to "1 (byte)".
		Reverse Direction (Lower byte $\rightarrow$ Upper byte)	<ul> <li>When sending: Sends a calculated check code, from the upper byte.</li> <li>When receiving: Receives data from the lower byte. Effective when the data length is 2 to 4 (bytes).</li> </ul>	
		Byte Swap (by word)	• When sending: Sends a calculated check code by swapping the upper byte and lower byte by word. When receiving: Receives data by swapping the upper byte and lower byte by word, and handles as a check code. Effective when the data length is 4 bytes.	
Complement Calo	culation	Select the complement calcu No complement calculation/C	lation. Dne's complement/Two's complement	Not settable when "Processing Method" is "16-bit CRC (for MODBUS)"
Calculating Range	Start	Select the starting element nu The range is 1 to 32.	umber of the calculating range.	_
	End	Select the ending element nu The range is 1 to 32.	imber of the calculating range.	

#### Precautions

- When "Code Type" is "ASCII Hexadecimal", an ASCII → BIN conversion error (7F20H) may occur if a string except for '0' to '9' 'A' to 'F' 'a' to 'f' is received.
- When "Code Type" is "ASCII Decimal", an ASCII → BIN conversion error (7F20H) may occur if a string except for '0' to '9' is received.
- · Only one check code can be placed in a packet.
- Packet elements placed behind a check code cannot be included in the calculating range.
- A check code cannot be included in the calculated range.
- When a calculated check code (Sum check/Horizontal parity/16-bit CRC) does not match a received check code, a sum check error (7F24H) may occur.
- One or more elements are required before a check code.

#### Non-verified reception

Use this element when received data includes unnecessary data while receiving data.

C24 skips characters as many as the specified number if a receive packet includes a non-verified reception.

Element Setting - Non-verified F	eception(Receive)	
Element <u>N</u> ame		
Data Length 0	[Setting Range] 0 to 2048 (0: Variable)	
	OK Cancel	
Item	Description	
Element Name	Set a name of the element.	
Data Length	0 (variable number of	Set this item when the number
	characters)	
	1 to 2048 (specified	Set the number of characters not to
	number of characters)	

#### Precautions

- · When "Data Length" is '0', the following requirements need to be met.
  - ■Only one Non-verified reception can be placed in a packet.

Include a Non-verified reception in the calculating range of a Length. Otherwise, place any of the following data immediate after a Non-verified reception.

- Static Data
- Terminator
- Check code + Static Data
- Check code + Terminator
- Two or more of the following four elements cannot be placed in the same packet.
- Conversion variable (Variable number of data)
- Conversion variable (Fixed number of data and Variable number of digits) (Excluding a case when the number of data is '1' with delimiter.)
- Non-conversion variable (Variable length)
- Non-verified reception (Variable number of characters)
- In received packet data from target devices, C24 needs to be able to discriminate data corresponding to a Non-verified

reception from those of a Terminator or a Static Data following a Non-verified reception. The receive processing may not be performed normally if they cannot be distinguished.

Ex.) When value of a Terminator or value of a Static Data following a Non-verified reception is used in a Non-verified reception, C24 recognizes it as data of a Terminator or a Static Data following a Non-verified reception and performs the verify/receive process.

# 2.4 Execution Condition of Predefined Protocol Communication

The predefined protocol communication can be performed when the 'predefined protocol ready' (X1D) is ON.

When executing the predefined protocol communication in the program, use the 'predefined protocol ready' (X1D) as an interlock signal.

This signal turns ON only when the communication protocol setting is set to predefined protocol

#### ON/OFF timing of predefined protocol ready (X1D)

After the protocol setting data is written to a flash ROM, 'predefined protocol ready' (X1D) turns OFF while checking the written data.

When the written data is normal, 'predefined protocol ready' (X1D) turns ON.



#### Execution timing for mode switching request signal (Y2/Y9) or UINI instruction

It is assumed that the protocol setting data written to the flash ROM is normal, or the protocol setting data is not written to the flash ROM.

#### Execution timing for mode switching request signal (Y2/Y9)

Communication protocol before change:CH1 and CH2 are other than the predefined protocol mode. Communication protocol after change:CH1 or CH2 is the predefined protocol mode.



Communication protocol before change:CH1 or CH2 is the predefined protocol mode. Communication protocol after change:CH1 or CH2 is the predefined protocol mode.



Communication protocol before change:CH1 or CH2 is the predefined protocol mode.

Communication protocol after change:CH1 and CH2 are other than the predefined protocol mode.



49

#### Execution timing for UINI instruction

Communication protocol before change:CH1 and CH2 are other than the predefined protocol mode. Communication protocol after change:CH1 or CH2 is the predefined protocol mode.



Communication protocol before change:CH1 or CH2 is the predefined protocol mode. Communication protocol after change:CH1 or CH2 is the predefined protocol mode.



Communication protocol before change: CH1 or CH2 is the predefined protocol mode. Communication protocol after the change: CH1 and CH2 are other than the predefined protocol mode.



# **3** DATA COMMUNICATION USING NONPROCEDURAL PROTOCOL

Nonprocedural protocol enables to transmit and receive data between a CPU module and target device by setting a data format and transmission control procedure arbitrarily.

A program for data communication is required for the CPU module.

Use this protocol for data communication with any given data format.



Point P

The predefined protocol is recommended for data communication appropriate to the protocol of the target device, such as a measuring instrument or barcode reader.

Communication using the nonprocedural protocol can be replaced with that of the predefined protocol.

The predefined protocol support function of Engineering tool allows the easy replacement.

With the predefined protocol, the required program is only for starting communication according to the specified protocol, and this can reduce the number of steps considerably.

For the communication using the predefined protocol, refer to the following chapter.

Page 26 DATA COMMUNICATION USING PREDEFINED PROTOCOL

#### Parameter settings of data communication using nonprocedural protocol

Set the transmission specification, the communication protocol with target devices, and others. Set the "Nonprocedural protocol" for "Communication protocol setting".

Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings" ⇔ "Various control specification"

Configure other settings according to the system being used.

For details on the settings, refer to following section.

Page 422 PARAMETER SETTING

# 3.1 Receiving Data from Target Device

This section explains data reception from a target device.

## **Receiving methods**

The following shows the methods for receiving data in any format using the nonprocedural protocol.

There are three methods for receiving data: the "reception by the receive end code" for receiving variable length messages, and the "reception by the receive end data quantity" for receiving fixed length messages, and the "reception by a timeout of the no-reception monitoring time (timer 0)" for the case when the receive end code and receive end data quantity have not been determined.

The receive end code and receive end data quantity used for data reception can be changed to any setting values by the user using Engineering tool.

C24 turns the 'CHD reception data read request' (X3/XA) ON when it receives the receive end code before data equivalent to the receive end data quantity has been received.

Therefore, when receiving data using the receive end code, set a value which is bigger than the maximum number of data sent from the target device in the receive end data quantity designation.

For the changing methods for the receive end code and receive end data quantity, refer to the following section.

Page 74 Receive end data quantity and receive end code settings

Method	Application
Reception by the receive end code	Receives variable length messages.
Reception by the receive end data quantity	Receives fixed length messages.
Reception by a timeout of the no-reception monitoring time (timer 0)	Receives a message of which the receive end code and receive end data quantity have not been determined. For a specification of the non-reception monitoring time (timer 0), refer to the following section.



• When data is received from the target device using either 'reception by receive end code' or 'reception by receive end data quantity' method, the CHD reception data read request' (X3/XA) turns ON.

53

**2** Control data is stored in the device designated with the INPUT instruction.

3 When the INPUT instruction is executed, received data is read from the receive data storage area of the buffer memory.

#### Data reception by receive end code (for variable length reception)

This method is used to transmit data by adding the receive end code set in C24 at the end of a message transmitted from a target device.

The receive end code can be changed according to the specifications of the target device. Arbitrary 1-character (1-byte) code within the range of 00H to FFH can be designated.

Setting	Description	Remarks
0D0AH (default)	The receive end code is not changed.	CR, LF is added to the end of the message and sent from the target device.
DOH	Arbitrary code is designated for the receive end code. (00H to FFH)	The designated receive end code data is added to the end of the message and sent from the target device.
FFFFH	No receive end code	Data reception by receive end data quantity is available.

When C24 receives the receive end code data preset with Engineering tool by the user, it issues a reception data read
request to the program.

The read request from C24 allows the program to read the received data up to the receive end code received from the target device.

• C24 issues a reception data read request to the CPU module in the cases below, according to the setting value of the receive end code.

#### When receive end code is not changed (Default value: 0D0AH)

(CR+LF is added to the end of the message and sent from the target device.)

• When LF is received within the time set in the no-reception monitoring time (timer 0) after CR is received, C24 stores the receive data up to CR+LF to the receive data storage area in the buffer memory and turns ON the 'CH□ reception data read request' (X3/XA) to the CPU module.



• If LF is not received within the time set in the no-reception monitoring time (timer 0) after CR is received, C24 stores the received data up to CR to the receive data storage area on the buffer memory, and turns ON the following signals to the CPU module.

Nonprocedural and no-reception monitoring time

Method 0 :'CHD reception abnormal detection' (X4/XB)

Method 1 :'CHD reception data read request' (X3/XA)\*1

		I		
	Target device	C R	Timer 0 setting time	
	C24	(*2)		
[Format is 0]	Reception abnormal detection (X4/XB)			
[Format is 1]	Reception data read request (X3/XA)			

\*1 It is used to receive a message of which the receive end code and receive end data quantity have not been determined by a timeout of the non-reception monitoring time (timer 0) in the nonprocedural protocol. (SP Page 229 Nonprocedural no-reception monitoring time method designation (Method 0/1))

\*2 CR is handled as 1-byte data in the message.

55

# ■When the receive end code is changed and an arbitrary code is designated (designate from 0000H to 00FFH)

(User defined receive end code data is added to the end of the message and transmitted from the target device).

When C24 receives the receive end code data changed by the user, it stores the received data up to the receive end code in the receive area on the buffer memory and turns ON the 'CH□ reception data read request' (X3/XA) to the CPU module.

Target device		•	Receive complete code data
C24	•		
Reception data read request (X3/XA)			

#### When the receive end code is not designated (FFFFH designated)

Reading by the receive end data quantity is enabled.

For more information on reading by the receive end data quantity, refer to the following section.

Page 56 Data reception by receive end data quantity (for fixed length reception)

#### Data reception by receive end data quantity (for fixed length reception)

- This method is used to receive messages of the same length (size) from the target device every time.
- When C24 receives data equivalent to the receive end data quantity preset with Engineering tool by the user, it issues a reception data read request to the program.

Upon the read request by the C24, the program reads the data equivalent to the receive end data quantity from the target device.

• The receive end data quantity default value is set to 511 (words). However, it can be changed within the receive data storage area depending on the data contents exchanged with the target device.

### Receive area and receive data arrangement

The following shows the receive area and the receive data arrangement for performing data reception using the nonprocedural protocol.

#### Receive area

The receive area is a memory area for storing the data received from the target device, and the receive data quantity to read the received data to the CPU module.

By default, the receive area is assigned to the addresses, Un\G1536 to 2047 (CH1 side) and Un\G2560 to 3071 (CH2 side).



The position and size of the receive area in the buffer memory can be changed with Engineering tool in accordance with the specifications of the target device and the receive data length. ( Page 422 PARAMETER SETTING) Configure the settings as follows:

- Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings"
  ⇒ "Various control specification"
- Designate the start address for the area to be used as receive area in the user setting area (Un\G1024 to 6911, Un\G9728 to 16383) to "Receiving buffer memory start address designation".
- Designate the length of area to be used as the receive area in the user setting area (Un\G1024 to 6911, Un\G9728 to 16383) by address count (0001H to 1A00H) to "Receiving buffer memory size specification".

When changing the position and size of the receive area in the buffer memory, if any of the functions below are used concurrently, make sure that the addresses of the receive area do not overlap with the buffer memory addresses assigned for storing send/receive data with the functions.

- · MC protocol buffer memory read/write function
- MC protocol on-demand function
- Predefined protocol function (Send/receive data storage area)
- · Nonprocedural protocol transmission/reception function
- · Bidirectional protocol transmission/reception function
- · Send/receive data monitoring function

Set the size of data per data transmission from the target device to C24 so that it is equal to or smaller than the size of the receive data storage area in the buffer memory.

• (Receive data storage area) ≥ (Amount of data in any data portion to be transmitted from the target device)

To transmit data whose size is larger than the receive data storage area, increase the receive area, or divide the send data before sending.

#### Point P

The position and size of the receive area can be changed in the buffer memory.

- 'Receiving buffer memory start address designation' (Un\G166/326)
- 'Receive buffer memory length designation' (Un\G167/327)

#### Receive data arrangement

The following explains the data arrangement when data received from a target device is stored to the receive area.

- The received message is stored to the C24 buffer memory (Receive data storage area).
- The data is stored to the receive data storage area in the order of data reception from (L)→(H) of the low address to (L)→(H) of the next address.
- Under the following conditions, when the receive end data quantity is an odd byte, 00H is stored in the upper byte of the last data storage position:
- When the unit for the receive end data quantity is designated in bytes.

When data reception is performed using the receive end code.

#### Ex.

When receive data "ABCDEFG123" was stored (The receive area is the default value.)



\*1 The OS area of C24 is the memory (8448 bytes) that temporarily stores the data to be received while a reception data read request is being issued to the CPU module. (Reading received data in the OS area cannot be performed by the user.)

When the program finishes reading the received data in the buffer memory in response to the current read request, the received data in the OS area, and any succeeding received data, is stored successively in the receive area in the buffer memory when the next read request is issued.

Also, when the free OS area, which stores the received data, is reduced to 64 bytes (default value) or less, a request to discontinue data transmission from the target device is issued by the following transmission control (The RS (RTS) signal does not turn OFF): ·When DTR control is set, the ER(DTR) signal turns OFF.

·When DC1/DC3 control is set, DC3 is sent.

When there is no more free OS area to store received data, SIO error occurs and the SIO information bit of the 'CH□ side LED lighting status and communication error status' (Un\G513/514) turns ON. In that case, succeeding received data is discarded until a free area becomes available in the OS area.

For more details on the transmission control, refer to the following section.

IP Page 236 DATA COMMUNICATIONS USING DC CODE TRANSMISSION CONTROL

#### **Reception operation**

#### Data reception when the receive data storage area > receive data length

## Ex.

When data of 511 words or less is received by the CH1 side interface on the condition that the receive area for the CH1 interface is Un\G1536 to 2047 (default value)



# Data reception when the receive data storage area < receive data length (Reception using the receive end code)</p>

The data link processing is required in the program.

Ex.

When data of 534 words is received by the CH1 side interface on the condition that the receive area for the CH1 interface is Un\G1536 to 2047 (default value).



# ■Data reception when the receive data storage area < receive data length (Reception by receive end data quantity)

If a specified receive end data quantity is bigger than the receive data storage area, the 'receive buffer memory length designation' (Un\G167/327, default: 512) minus 1 is used as the receive end data quantity instead. (Receive data storage area) > (Data length transmitted from the target device)

#### Ex.

When 550 words of data is received by the CH1 interface three times on the condition that the receive area for the CH1 interface is Un\G1536 to 2047 (default value).



#### Program example for data reception

The following shows the program for data reception using the nonprocedural protocol and its example. For details on the INPUT instruction, refer to the dedicated instructions. (See Page 520 Dedicated Instructions)



\*1 When the completion device is OFF, execute the INPUT instruction. When INPUT instruction is executed when the completion device is ON, data may not be received properly.



• Start the programmable controller of the host station. The setting values specified with an Engineering tool are stored to C24.

**2** When the amount of data specified by the receive end data quantity or data containing the receive end code is received from the target device, the 'CH1 reception data read request' (X3) turns ON.

3 After the control data for the INPUT instruction is stored in the device, the program executes the INPUT instruction and reads the received data.

Before executing the INPUT instruction, check that the INPUT instruction completion device (M0) is OFF.

Once reading of the received data is completed, the INPUT instruction completion device turns ON.

When the completion device + 1 (abnormal completion signal) turns ON, the error code is stored in the control data completion status (S1 + 1).

#### ■Program example

Category	Label name		Description	Device		
Module label	C24_1		Target module		-	
	C24_1.stnCH1.bSet_Req_ReceptionF	CH1 Reception	data read request	X3		
	C24_1.stnCH1.bSts_ReceptionAbnorr	malDetection	CH1 Reception	X4		
Label to be defined	Define the global label as shown below.					
	Label Name	Data Type	Class	Assign (Device/Label)		

	Laberhame	Data Type	Cidaa		Assign (Device/Label)
1	bINPUTInstructionExecutionStatusDevice	Bit	 VAR_GLOBAL	•	MO
2	bINPUTInstructionNormalCompleteDevice	Bit	 VAR_GLOBAL	Ŧ	M1
3	bINPUTInstructionAbnormalCompleteDevice	Bit	 VAR_GLOBAL	•	M2
4	bReq_INPUTInstructionExecution	Bit	 VAR_GLOBAL	Ŧ	M10
5	wReceiveChannel	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D1
6	wAllowableReceiveDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	Ŧ	D2
7	wErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D3
8	wReceiveDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	¥	D4
9	wnReceiveData	Word [Unsigned]/Bit String [16-bit](015)	 VAR_GLOBAL	•	D110

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference



Data received prior to an error will be stored in the received data storage device.

to

Dx

Receive data

to



• Received data can also be read using interrupt programs. ( Figure 219 RECEIVING DATA WITH AN INTERRUPT PROGRAM)

Note that if the reading of data received from the same interface is performed, it is not possible to combine the reading of data received by the main program and reading of data received by the interrupt program. Accordingly, use either of the above program to read the data received.

• The SPBUSY instruction is used to read the execution status when using a dedicated instruction. ( Frage 520 Dedicated Instructions)

#### Restriction ("

- More than one INPUT instruction cannot be executed simultaneously on the same interface. Execute the next INPUT instruction only after the execution of the first INPUT instruction is completed.
- When the send/receive data quantity is set in word units and the receive data quantity is an odd byte when requesting the reading of received data to the CPU module, the receive data quantity is processed as follows:

Receive data quantity = Receive data byte count/ $2 \cdots$ Round up after the decimal point. Also, 00H is stored in the higher byte of the last data storage position in the receive area where received data is stored.

## **Reception error detection and check methods**

The following explains how to detect and confirm errors that may occur when receiving data from target devices. The possible primary causes of errors during data reception are shown below.

Cause of reception error	Reference
A transmission error occurred due to noise.	MELSEC iQ-R Serial Communication Module User's Manual (Startup)
A timeout occurred for the no-reception monitoring (timer 0).	Page 228 No-reception Monitoring Time (timer 0) Setting
Data that could not be converted using the ASCII-BIN conversion is included.	Page 348 ASCII-BIN Conversion for Data Communicated with Nonprocedural Protocol
Data larger than the size that could be stored in the OS area of C24 is received.	Page 58 Receive data arrangement

#### Detection/checking of reception error by a program

#### ■Detecting a reception error

- The following device and input signals turn ON.
- INPUT instruction completion device + 1
- 'CH□ reception abnormal detection' (X4/XB)
- 'CH□ Error occurrence' (XE/XF)

#### Checking a reception error

The reception error code can be checked using the INPUT instruction control data ((S1) + 1).

Or, it can be checked by reading the 'data reception result' (Un\G600/616).

For details on how to check the error code contents and corrective actions, refer to the following section.

Page 473 Error Code List

#### Detection/checking of reception error with module and Engineering tool

#### Confirmation using the indicator LED

When C24 detects an error, including a transmission error, the ERR LED turns ON.

#### Confirmation using Engineering tool

Monitor the 'data reception result' (Un\G600/616) to check the error code.

#### Considerations

The following describes the considerations for received data in case of errors.

#### Storing received data

The received data for which an error was detected is discarded and only the normally received data is stored in C24. Thus, there may be missing data among the data that has been read to the CPU module when a reception error occurs.

#### ■Reading received data

When receive data is read to the CPU module by turning the 'CHD reception abnormal detection' (X4/XB) ON, the data that was normally received prior to the error detection is read.

Read and discard received data as needed.



Data reception

When the data of "G" or later in the reception message shown in the above figure is received normally, the data is stored in the C24 OS area.

The received data stored in the OS area will be read to the CPU module in the next read operation.

## **Receive data clear**

For the data reception using the nonprocedural protocol, if the transmission of data from a transmitting device is interrupted due to any trouble, clearing the data received up to the present time on the receiving device side and receiving again from the first data may be required.

The methods for clearing received data in the C24 are shown below.

Use any of the methods to clear received data as necessary.

- Receive data clear request by the dedicated instruction "CSET" ( SPage 67 Receive data clear with dedicated instruction "CSET")
- Write to/read from the 'receive data clear request' (Un\G168/328). (MOV instruction) ( Page 69 Receive data clear with MOV instruction)
- Receive data clear request with Engineering tool. ( Frage 73 Receive data clear request procedure using Engineering tool)

#### Precautions

When transmitting data to a target device from C24, do not execute a clear request of the receive data with Engineering tool. If a receive data clear request is executed when transmitting data to a target device, C24 stops data transmission and terminates the dedicated instruction for transmission abnormally. (The transmission completion signal does not turn ON.) If a receive data clear request is executed during data reception, the data received up to that point are cleared.

#### Receive data clear processing

C24 performs the following processing when the receive data clear is performed.

- · C24 regards the received data up to the present time as invalid data.
- C24 clears the receive data quantity up to the present time to "0". (The receive area in the buffer memory is not initialized).
- C24 sets the status in the one prior to the start of data reception.

#### Procedure for clearing the received data by the program

Using the following instructions, clear the received data by a program.

- Dedicated instruction "CSET"
- MOV instruction

For the procedure to clear received data by a program, refer to the following.

#### Receive data clear with dedicated instruction "CSET"

This instruction clears the received data up to the present time without interrupting the data transmission processing. For details on CSET instruction, refer to the dedicated instruction. ( Page 520 Dedicated Instructions)

#### ■Procedure for clearing (For the CH1 side interface)

If the CSET instruction is executed while the 'CH□ reception data read request' (X3/XA) or 'CH□ reception abnormal detection signal' (X4/XB) is ON, the CSET instruction is kept waiting until the signal is turned OFF.

2 The receive data clear processing is executed to the OS area of the C24. ( 🖙 Page 58 Receive data arrangement)

#### ■Program example

The following shows the CH1 receive data clear program example using CSET instruction.

Category	Se	etting content							
Label to be defined	De	fine	ine the global label as shown below.						
			Label Name	Data Type		Class		Assign (Device/Label)	
		1	bReq_ReceiveDataClear	Bit		VAR_GLOBAL	Ŧ	X20	
		2	wnCSETInstructionControlData	Word [Unsigned]/Bit String [16-bit](0111)		VAR_GLOBAL	•	DO	
		3	wErrorCodeStorageDevice	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D300	
		4	bnCSETInstructionCompleteDevice	Bit(01)		VAR_GLOBAL	•	MO	
		5	bCSETInstructionNormalCompleteFlag	Bit		VAR_GLOBAL	•	M100	
		6	bCSETInstructionAbnormalCompleteFlag	Bit		VAR_GLOBAL	•	M101	
		7	wDummy	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D200	
				•	-			•	

(0)	bReq_ReceiveDataCle ar X20					MOVP	КО	wnCSETInstructionContr olData[0] D0
						MOVP	К4	wnCSETInstructionContr olData[2] D2
			ZP.CSET	U0	K1	wnCSETInstruction ControlData[0] D0	wDummy D200	bnCSETInstructionCompl eteDevice M0
(17)	bnCSETInstructionCo mpleteDevice[0] M0	bnCSETInstructionC ompleteDevice[1] M1					SET	bCSETInstructionNormal CompleteFlag M100
		bnCSETInstructionC ompleteDevice[1] M1					SET	bCSETInstructionAbnor malCompleteFlag M101
						MOV	wnCSETInstructionCo ntrolData[1] D1	wErrorCodeStorageDevi ce D300
(26)								{END }

(0) Set the execution type. Set the request type (receive data clear). Execute receive data clear.

(17) Processing for normal completion and abnormal completion

#### **Receive data clear with MOV instruction**

Write to/read from the 'receive data clear request' (Un\G168/328) in the procedure below with the MOV instruction. When resuming data communication with a target device, resume it after completing the receive data clear processing with C24.

Depending on the data communication system, it may be necessary to restart data communications with the target device after notifying the target device from the CPU module that resumption of communications is possible.

#### Restriction (??

Create a program including contacts indicating the following status (such as flag for the user) in MOV instruction.

- Contacts indicating that the 'CH□ reception data read request' (X3/XA) and 'CH□ reception abnormal detection' (X4/XB) are OFF
- · Contact indicating that no dedicated instruction (OUTPUT/PRR/INPUT) is currently being executed
- · Contact indicating that receive data clear processing is not currently being performed

#### ■Clear Procedure (When the CH1 side interface is used)



• Write "1" to the 'receive data clear request' (Un\G168) with the MOV instruction when no data reception, data transmission, or receive data clearing processing is being performed.

2 The receive data clear processing is executed to the OS area of the C24.( SP Page 58 Receive data arrangement)

When receive data clear processing is completed, the 'receive data clear request' (Un\G168) becomes "0".

#### ■Program example

The following shows the CH1 receive data clear program example using MOV instruction.

The dedicated instructions (OUTPUT/INPUT) is used for data transmission/reception. (

Category	Label name	Description	Device
Module label	C24_1	Target module	—
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
	C24_1.stnCH1.bSet_Req_ReceptionRead	CH1 Reception data read request	Х3
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4
	C24_1.stnCH1.uSet_Request_ReceiveDataClear_D	CH1_Receive data clear request	U0\G168

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class		Assign (Device/Label)
1	bReq_Transmission	Bit	 VAR_GLOBAL	•	×20
2	bOUTPUTInstructionNormalAndAbnormalCompleteFlagReset	Bit	 VAR_GLOBAL	•	X21
3	bReq_ReceiveDataClear	Bit	 VAR_GLOBAL	•	X23
4	bBUTPUTInstructionExecutionCompleteDevice	Bit	 VAR_GLOBAL	٠	мо
5	bOUTPUTInstructionAbnormalCompleteDevice	Bit	 VAR_GLOBAL	٠	M1
6	bReceivingFlag	Bit	 VAR_GLOBAL	•	M11
7	bReq_Transmission2	Bit	 VAR_GLOBAL	•	M12
8	bReqPulse_ReceiveDataClear	Bit	 VAR_GLOBAL	٠	M15
9	bReceiveD ataClearReceptionFlag	Bit	 VAR_GLOBAL	٠	M16
10	bReceiveDataClearingFlag	Bit	 VAR_GLOBAL	•	M17
11	bReqPluse_Transmission	Bit	 VAR_GLOBAL	•	M20
12	bReq_Transmission3	Bit	 VAR_GLOBAL	٠	M21
13	bReq_OUTPUTInstructionTransmission	Bit	 VAR_GLOBAL	•	M101
14	bOUTPUTInstructionNormalCompleteFlag	Bit	 VAR_GLOBAL	•	M102
15	bOUTPUTInstructionAbnormalCompleteFlag	Bit	 VAR_GLOBAL	•	M103
16	wTransmissionChannel	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	٠	D1
17	wTransmissionDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D2
18	wErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D3
19	wnTransmissionData	Word [Signed][04]	 VAR_GLOBAL	٠	D11
20	bUnitReadyFlag	Bit	 VAR_GLOBAL	•	M200
21	wReceiveDataClearStatus	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D100
22	wErrorCodeStorageDevice	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D101

For information on the module FB to be used, refer to the following manual. MELSEC iQ-R Serial Communication Module Function Block Reference
	C24_1.bSts_UnitRead	C24_1.bSts_Watc hdogTimerError									bUnitReadyFlag
(0)	X1E	X1F									M200
		14									U
(3)	bReq_ReceiveDataCl ear X23									PLS	bReqPulse_ReceiveD ataClear M15
(6)	bReqPulse_ReceiveD ataClear M15									SET	bReceiveDataClearR eceptionFlag M16
(8)	bReceiveDataClearR eceptionFlag M16	bUnitReadyFlag M200	bReceivingFl ag M11	bReq_Transmi ssion2 M12	bReceiveDataC learingFlag M17	C24_1 stnCH1 bSet_Req_Recep tionRead X3	C24_1.stnCH1.bSts_ReceptionAbno rmalDetection X4	0	MOV	К1	C24_1.stnCH1.uSet_ Request_ReceiveDat aClear D
	<u>├</u> ──1 ⊢──		—V—	—V—	—-V—	И	V				U0¥G168
										PLS	gFlag
										-	M17
	hReceiveDataClearin										
(21	gFlag M17	bUnitReadyFlag M200							MOV	C24_1 stnCH1 uSe t_Request_Receiv eDataClear_D U0¥G168	wReceiveDataClear Status D100
			-								
			= <u>_</u> U	K0	wReceiveData ClearStatus					RST	bReceiveDataClearR eceptionFlag
					D100					-	M16
											bReceiveDataClearin
										RST	gFlag M17
	bReq_Transmission										bReqPluse_Transmis
(32)	x20									PLS	M20
	bRegPluse Transmis									-	
(35	sion M20									SET	bReq_Iransmission3
(37	bReq_Transmission3 M21	bReceiveDataCl earReceptionFla M16							MOV	К1	wTransmissionChan nel
									MOV	К5	wTransmissionData Count
											52
									\$MOV	"ABCDEFG"	wnTransmissionData [0]
											D11
										100.000	<b>.</b>
									MOV	HUA0D	wn I ransmissionData [4] D15
										ļ	
										SET	bReq_Transmission2
											M12

(63)			M_RJ/1C24_Output_00C_1 ( M Output FB	+RJ71C24_Output_00C )		
	bReq_Transmission2 M12 		Bijben	o.bENO:B		bReq_OUTPUTIns ctionTransmissio M101
-		C24_1	]- DUT:i_stModule	о_ЬОКВ		bOUTPUTInstruc nNormalComplete M <sup>1</sup> 02
		wTransmissi nChannel [ D1	io }_UWi_uCh	o,bErr:B		bOUTPUTInstruc nAbnormalComple Flag M103
		wTransmissi nDataCount [ D2	o ]- UWi_uSendDataLength	o uErrid:UW		
_		wnTransmiss onData[0] [ D11	si ]- UW:i_uSendData			
(108)	oOUTPUTInstruction NormalCompleteFlag M102				SET	bOUTPUTInstruct nExecutionComp Device M0
(110)	SOUTPUTInstruction AbnormalCompleteFl ag M103 I				SET	bOUTPUTInstruc nAbnormalCompl Device M1
112)	bReq_OUTPUTInstru ctionTransmission M101				RST	bReq_Transmissi M12
					RST	bReq_Transmissi M21
(115)	sOUTPUTInstruction NormalAndAbnormal CompleteFlagReset X21				RST	bOUTPUTInstrue nExecutionComp Device M0
					SET	bOUTPUTInstruc nAbnormalCompl Device M1
(118)						

 (8) Execute receive data clear processing.
 (21) Read receive data clear status. Reset the receive data clear acknowledgement flag. Reset the receive data clear in progress flag.

(35) Set the transmission request.

 (37) Designate the transmission channel. Set the send data quantity.
 Set the send data (string).
 Set the send data (numeric value).
 Set the transmission request.

(108) OUTPUT instruction normal completion

(110) OUTPUT instruction abnormal completion

- (112) Reset the transmission processing request. Reset the transmission request.
- (115) Reset the OUTPUT instruction execution completion flag. Reset the OUTPUT instruction abnormal completion flag.

#### Receive data clear request procedure using Engineering tool

The following shows the method which uses "Intelligent Function Module Monitor" of Engineering tool. For the operation method of the Intelligent Function Module Monitor function, refer to the following manual.

#### Operating procedure

- 1. Register C24 in "Intelligent Function Module Monitor".
- 2. Set "CHD Receive data clear request" of "Receiving end specification" to "Requested".
- **3.** The received data is cleared.

3

# Receive end data quantity and receive end code settings

#### Setting method before receiving data

The following default values have been set for the receive end data quantity and receive end code that are used for data reception with the nonprocedural protocol.

Setting data	Default value	Allowable range	Buffer memory address where the setting value is stored	Remarks
Receive end data quantity	511 (1FFH)	Less than the size of the receive data storage area	Un\G164/324	Unit is in accordance with the word/byte units designation.
Receive end code	0D0AH	0000H to 00FFH	Un\G165/325	When any code is set.
	(CR+LF)	FFFFH		When there is no receive end code.

The receive end data quantity and the receive end code setting value can be changed by the program before data reception processing.

The default value can be changed in the following unit parameter of Engineering tool.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

For details, refer to the following section.

Page 422 PARAMETER SETTING

#### Setting method after receiving data

Other than through the setting using Engineering tool or the MOV instruction at the startup of the C24, the receive end data quantity and receive end code setting values can be changed even after data communication has started if the timing is as shown below.

The following describes the restriction of the module, and the timing and procedure for changing setting values to continue the data receive processing by changing the setting values for data reception using the nonprocedural protocol after the start of data communication.

#### ■How to receive data

Reception using an interrupt program <sup>\*1</sup> cannot be performed. (Transmission using a dedicated instruction (OUTPUT) can be performed.)

Data must be received by the main program.

The following shows the I/O signals.

- \*1 For details on the data reception using interrupt programs, refer to the following section.
  - Page 219 RECEIVING DATA WITH AN INTERRUPT PROGRAM

Туре	e Input/Output Signals		Signal name	Device that turns ON/OFF		
	CH1 side	CH2 side		CPU module	C24	
Reception	Х3	ХА	Reception data read request		0	
	X4	ХВ	Reception abnormal detection		0	

Restriction ("

When the 'CH□ reception abnormal detection' (X4/XB) turns ON, read the error code from the buffer memory below, and then check the type of error and take corrective actions.( Page 473 Error Code List)
• 'Data reception result' (Un\G600/616)

#### Setting values that can be changed

Of the initial settings from Engineering tool stored in the buffer memory, only the following setting values can be changed after data communication has started.

- 'Receive end data quantity designation' (Un\G164/324)
- 'Receive end code designation' (Un\G165/325)

#### Timing and procedure for changing the setting values

• Timing of change

To change the receive end code and receive end data quantity after data communication has started, change the setting when the status of the I/O signals relating to the reading of received data is as shown below.

- 'CHI Reception data read request' (X3/XA) or 'CHI reception abnormal detection' (X4/XB): ON
- Change procedure

When the 'CH reception data read request' (X3/XA)/'CH reception abnormal detection' (X4/XB) turns ON upon data reception from the target device, perform the following and execute the INPUT instruction.

· Change the setting values for the receive end code and the receive end data quantity.

### Ex. When reading data received in the CH1 side interface



#### ■Program example

Category	Lab	oel name			Description	I	Device
Module label	C24_1				Target module	)	-
	C24_1.stnCH1.bSet_Req_ReceptionRead				CH1 Reception	n data read request	X3
	C24	_1.stnCH1.bSts_Reception	AbnormalDetection		CH1 Reception	n abnormal detection	X4
	C24	_1.stnCH1.uSet_ReceivedE	DataCount_Reception_	CH1_'Receive designation	e end data quantity	U0\G164	
	C24	_1.stnCH1.uSet_ReceiveCo	ompleteCode_Reception	on_D	CH1_Receive	end code designation	U0\G165
Label to be defined	Defi	ne the global label as show	n below.				
		Label Name	Data Type	Class	Assign (Device/Label)		
	1	bINPUTInstructionExecutionStatusDevice	Bit	VAR_GLOBAL	✓ M0		
	2	bINPUTInstructionNormalCompleteDevice	NormalCompleteDevice Bit VAR_GLOBAL				
	3	binPUTInstructionAbnormalLompleteDevice	BR Da	WAR_GLOBAL	▼ M2 - M10		
	4	bINPLITInstructionNormalCompleteElag	Bi	VAB GLOBAL	<ul> <li>M100</li> </ul>		
	6	bINPUTInstructionAbnormalCompleteFlag	Bit	VAR GLOBAL	↓ M101		
		5.01	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		0.0		

For information on the module FB to be used, refer to the following manual.

rmalCompleteFlagReset

MELSEC iQ-R Serial Communication Module Function Block Reference

3

	C24_LstnCHLbSet_Req_Recep tionRead					K1	wReceiveChapped
(0)	X3				MOV		D1
	C24_1.stnCH1.bSts_ReceptionA					1640	
	X4				MOV	KIU	WAllowableReceiveDataGount D4
					MOVP	К20	C24_1.stnCH1.uSet_ReceivedDa aCount_Reception_D U0¥G164
					MOVP	H3	C24_1.stnCH1.uSet_ReceiveCor pleteCode_Reception_D U0¥G165
							bReq_INPUTInstructionExecutio
						SET	Device M10
(17)			M_RJ71C24_Input_00C_1 (M+RJ71C24_Input_00C) Input FB				
	bReq_INPUTInstructionExecuti onDevice M10		Bilen stenob				bINPUTInstructionExecutionSta usDevice M0
							bINPUTInstructionNormalComp
		C24_1	DUT:LstModule o_bOK:B				teDevice M1
		wReceiveCha nnel					bINPUTInstructionAbnormalCon pleteDevice M2
		[ D1 ]	- UW:LuCh o_bErr:B				0
		wAllowableRe ceiveData… [ D4 ]	- UW:LuMaxRecvDataLength وuErrld:UW	wErrorCode -{ D3 }			
				wAllowableRece iveDataCount			
			o_uRecvDataLength:UW	-L D4 -			
			o_uRecvData:UW	wnReceiveData [0] -{ D10 }			
	bINPUTInstructionNormalComp						
(63)	M1					RST	Device M10
						057	bINPUTInstructionNormalComp
						SET	М100
(66)	bINPUTInstructionAbnormalCo mpleteDevice M2					SET	bINPUTInstructionAbnormalCor pleteFlag M101
	bInstructionNormalAndAbnorm						
(68)	aiGompleteFlagReset X100					RST	bINPUTInstructionAbnormalCon pleteFlag M101
(70)							[END ]

 Specify the reception channel. Specify the allowable number of data to be received. Set the receive end data quantity. Set the receive end code.
 Normal completion

(66) Abnormal completion

# 3.2 Transmitting Data to Target Device

This section explains data transmission from the CPU module to a target device.

# Sending methods

The following shows how to send data in any format using the nonprocedural protocol.



Send data is stored in the device designated with the OUTPUT instruction.

**2** Control data is stored in the device designated with the OUTPUT instruction.

• When the OUTPUT instruction is executed, C24 transmits the amount of data designated by the send data quantity from the send data area in ascending order of the send data area addresses.

## Send area and send data arrangement

This section explains the send area and the send data arrangement for performing data transmission using the nonprocedural protocol.

#### Send area

The send area is a memory to write data and the data quantity that are transmitted from the CPU module to a target device via C24.

The send area is assigned to the address, Un\G1024 to 1535 (CH1 side), Un\G2048H to 2559 (CH2 side) by default.



#### (Default)

The position and size of the send area in the buffer memory can be changed with Engineering tool in accordance with the specifications of the target device and the send data length. (F Page 422 PARAMETER SETTING) Configure the settings as follows:

- 🯹 Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings" ⇒ "Various control specification"
- Designate the start address for the area to be used as the send area in the user setting area (Un\G1024 to 6911, Un\G9728 to 16383) to "Send buffer memory start address designation".
- Designate the length of the area to be used as the send area in the user setting area (Un\G1024 to 6911, Un\G9728 to 16383) by address count (0001H to 1A00H) to "Send buffer memory size specification".

When changing the position and size of the send area in the buffer memory, if any of the functions below are used concurrently, make sure not to overlap with the buffer memory addresses assigned for storing send/receive data handled with the functions.

- MC protocol buffer memory read/write function
- MC protocol on-demand function
- Predefined protocol function (Send/receive data storage area)
- · Nonprocedural protocol transmission/receive function
- · Bidirectional protocol transmission/receive function
- · Send/receive data monitoring function

Set the size of data per data transmission from the target device to C24 to be equal to or smaller than the size of the send data storage area in the buffer memory.

(Send data storage area) ≥ (Amount of data in any data portion to be transmitted from C24)

To transmit data whose size is larger than the send data storage area, increase the send area, or divide the send data before sending.

#### Point P

The position and size of send area can be changed in the buffer memory.

- 'Send buffer memory start address designation' (Un\G162/322)
- 'Send buffer memory length designation' (Un\G163/323)

#### Send data arrangement

The arrangement of data to be stored in the send area when transmitted to the target device is as shown in the example below.

#### Ex.

When transmitting 'ABCDEFG123' (The send area is the default value.)



#### Program example for data transmission

The following shows the program for data transmission using nonprocedural protocol and its example.

For details on OUTPUT instructions, refer to the dedicated instruction. (SP Page 520 Dedicated Instructions)



OStart the programmable controller on the host station.

The value set with Engineering tool is stored in the C24.

Input the user data transmission command signal.

**③** Executes the OUTPUT instruction after storing the send data and the control data for the OUTPUT instruction in the device.

Data is sent when the OUTPUT instruction is executed.

O C24 transmission processing completes and the OUTPUT instruction completion device turns ON.

When the completion device +1 (abnormal completion signal) turns ON, the error code is stored in the control data completion status (S1+1).

#### ■Program example

Category	Labe	Label name							Device
Module label	C24_	-	Target module				_		
Label to be defined	Defin	efine the global label as shown below.							
		Label Name	Data Type		Class		Assign (Device/Label)		
	1	bReq_Transmission	Bit		VAR_GLOBAL	•	×20		
	2	bReq_CompletionFlagReset	Bit		VAR_GLOBAL	•	X21		
	3	bRegPluse_Transmission	Bit		VAR_GLOBAL	•	M50		
	4	bOUTPUTInstructionExecutionFlag	Bit		VAR_GLOBAL	•	M100		
	5	b0UTPUTInstructionNormalCompleteFlag	Bit		VAR_GLOBAL	•	M101		
	6	b0UTPUTInstructionAbnormalCompleteFlag	Bit		VAR_GLOBAL	•	M102		
	7	bOUTPUTInstructionExecutingFlag	Bit		VAR_GLOBAL	•	M104		
	8	wTransmissionChannel	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D1		
	9	wTransmissionDataCount	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D2		
	10	wnTransmissionData	Word [Signed](04)		VAR_GLOBAL	•	D11		
	11	wErrorCodeStorageDevice	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D101		
	12	b0UTPUTInstructionNormalCompleteFlag2	Bit		VAR_GLOBAL	٠	M111		
	13	b0UTPUTInstructionAbnormalCompleteFlag2	Bit		VAR_GLOBAL	-	M112		

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	bReq_Transmission							hBaaDhaa Transmission
(0)	) X20						PLS	brede luse_transmission
								MOU
	bReqPluse_Transmission						"ABODEEG"	umTronomicoionDoto[0]
(3)	M50					\$MOV	ABODELLA	D11
								011
							H0A0D	wnTransmissionData[4]
						MOV		D15
							К1	wTransmissionChannel
						MOV		D1
							K5	wTransmissionDataCount
						MOV		D2
								bOUTPUTInstructionExecutio
							SET	nFlag M100
(18)			M_RJ71C24_Output_00C Ou	1 (M+RJ71C24_Output_00C) tout FB				
(10)								
	bOUTPUTInstructionExecutionF							bOUTPUTInstructionExecutin
	ู่ Miloo							M104
			B:i_bEN	o_bENO:B				0
								bOUTPUTInstructionNormalC
		C24_1						M101
			- DUT: <u>i_</u> stModule	o_bOK:B				0
								bOUTPUTInstructionAbnorma
		nel						M102
			- UW:i_uCh	o_bErr:B				0
		TaranaiasianData						
		Count			Device			
	· · · · · · · · · · · · · · · · · · ·	L D2 ]	Uw:LuSendDataLength	o_uematuw	1 DIOI J			
		wnTransmissionDat						
		wnTransmissionDat a						
		wnTransmissionDat a [ D11 ]	UW:i_uSendData					
	bOUTPUTInstructionNormalCom peteFlag	wnTransmissionDat a [ D11 ]	UW <u>i</u> uSendData					bOUTPUTInstructionNormalC
(63)	bOUTPUTInstructionNormalCom pleteFlag J	wnTransmissionDat [ D11 ]	UWi_uSendData				SET	bOUTPUTInstructionNormalC ompleteFlag2 M111
(63)	bOUTPUTInstructionNormalCom pletsFlag M01	wnTransmissionDat a [ D11 ]	UWi_uSendData				SET	bOUTPUTInstructionNormalC ompletoFlag2 M111
(63)	bOUTPUTInstructionNormalCom pleteFlag hT D bOUTPUTInstructionAbnormalC bOUTPUTInstructionAbnormalC	wnTransmissionDat a D11 ]	UW:LuSendData				SET	bOUTPUTInstructionNormalC ompleteFlag2 Milli bOUTPUTInstructionAbnorma
(63)	bOUTPUTInstructionNormalCom pleteFlag MI01 UTI bOUTPUTInstructionAbnormalC ompleteRag UTI bOUTPUTInstructionAbnormalC	wnTransmissionDat a D11 ]	UW:LuSendData				SET	bOUTPUTInstructionNormalC ompleteFlag2 M111 bOUTPUTInstructionAbnorma ICompleteFlag2
(63)	bOUTPUTInstructionNormalCom pleteFlag M101 	wnTransmissionDat	UW.iµSendData				SET SET	bOUTPUTInstructionNormalC ompleteFlag2 M111 bOUTPUTInstructionAbnorma ICompleteFlag2 M112
(63)	bOUTPUTInstructionNormalCom pleteFlag MI01 bOUTPUTInstructionAbnormalC ompleteFlag MI02 bOUTPUTInstructionAbnormalC ompleteFlag MI02 bOUTPUTInstructionExecutingFl - 45	wnTransmissionDat	UWiuSendData				SET SET	bOUTPUTInstructionNormalC omplete/lag2 Milli bOUTPUTInstructionAbnorma (Complete/lag2 bOUTPUTInstructionExecutio
(63) (65) (67)	bOUTPUTInstructionNormalCom pleteFlag DOUTPUTInstructionAbnormalC ompleteFlag M102 d I bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl d I	wnTransmissionDat	UWi_USendData				SET SET RST	bOUTPUTInstructionNormalC ompleteFlag2 M111 bOUTPUTInstructionAbnorma ICompleteFlag2 M112 bOUTPUTInstructionExecution rFlag M100
(63) (65) (67)	bOUTPUTInstructionNormalCom pleteFing MT01 bOUTPUTInstructionAbnormalC bOUTPUTInstructionAbnormalC MT02 d MT02 d bOUTPUTInstructionExecutingFI amT04 MT04	wnTransmissionDat	UW:LuSendData				SET SET RST	bOUTPUTInstructionNormalC ompleteFlag2 bOUTPUTInstructionAbnorma ICompleteFlag2 M112 bOUTPUTInstructionExecutio nFlag M100
(63) (65) (67)	bOUTPUTInstructionNormalCom pleteFlag MI01 bOUTPUTInstructionAbnormalC ompleteFlag MI02 bOUTPUTInstructionAbnormalC ompleteFlag MI02 bOUTPUTInstructionExecutingFl ag MI04 bOUTPUTInstructionExecutingFl deg MI04 bBreg_CompletionFlagReset	omTransmissionDat	UW.juSendData				SET SET RST	bOUTPUTInstructionNormalC ombitsFlag2 bOUTPUTInstructionAbnorma ICompleteFlag2 M112 bOUTPUTInstructionExecutio nFlag M100 bOUTPUTInstructionNormalC
(63) (65) (67) (69)	bOUTPUTInstructionNormalCom pleteFlag MI01 bOUTPUTInstructionAbormalC ompleteFlag MI02 bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 bOUTPUTInstructionExecutingFl AMT04 A	vnTransmissionDat	UWijuSendData				SET SET RST RST	bOUTPUTInstructionNormalC ompleteFlag2 M111 bOUTPUTInstructionAbnorma CompleteFlag2 bOUTPUTInstructionExecutio nFlag M100 bOUTPUTInstructionExecutio ompleteFlag2 M112
(63) (65) (67) (69)	bOUTPUTInstructionNormalCom pletFlag M100 I boUTPUTInstructionAbnormalC ompletFlag M102 I bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl boUTPUTInstructionExecutingFl M104 bReg.CompletionFlagReset X21 I bReg.CompletionFlagReset	vnTransmissionDat	UW:LuSendDeta				SET SET RST RST	bOUTPUTInstructionNormalC ompleteFlag2 M111 bOUTPUTInstructionAbnorma GM112 bOUTPUTInstructionExecution nFlag M100 bOUTPUTInstructionNormalC ompleteFlag2 M111
(63) (65) (67) (69)	bOUTPUTInstructionNormalCom pleteFlag MID bOUTPUTInstructionAbnormalC mID2 bOUTPUTInstructionAbnormalC mID2	wnTransmissionDat	UW:LuSendData				SET SET RST RST	bOUTPUTInstructionAbnorma organization bOUTPUTInstructionAbnorma CompleteFlag2 Mi12 bOUTPUTInstructionExecution rflag Mi00 bOUTPUTInstructionNormaC official bOUTPUTInstructionAbnorma
(63) (65) (67) (69)	bOUTPUTInstructionNormalCom pleteFing MT01 bOUTPUTInstructionAbromalC bOUTPUTInstructionAbromalC MT02 MT02 MT04 bOUTPUTInstructionExecutingFI age MT04 bReq_CompletionFingReset X21 I	wiTransmissionDat	UW.juSendData				SET SET RST RST	bOUTPUTInstructionNormalC ompleteFlag2 Mi11 bOUTPUTInstructionAbnorma bOUTPUTInstructionExecutio nf1ag Mi12 bOUTPUTInstructionExecutio nf1ag Mi10 bOUTPUTInstructionNormalC ompleteFlag2 Mi11 bOUTPUTInstructionAbnorma GompleteFlag2
(63) (65) (67) (69)	bOUTPUTInstructionNormalCom pleteFlag M010 bOUTPUTInstructionAbormalC ompleteFlag M02 bOUTPUTInstructionAbormalC ompleteFlag M04 bOUTPUTInstructionExecutingFl bActionPletionFlagReset X21 k k k k k k k k k k k k k k k k k k k	vnTransmissionDat	UW.i_uSendData				SET SET RST RST RST	bOUTPUTInstructionNormalC ompleteFlag2 M111 bOUTPUTInstructionAbnorma CompleteFlag2 bOUTPUTInstructionExecutio nFlag M100 bOUTPUTInstructionExecutio ompleteFlag2 M111 bOUTPUTInstructionAbnorma ICompleteFlag2 M112
(63)	bOUTPUTInstructionNormalCom pletFlag M101 bOUTPUTInstructionAbnormalC ompleteFlag M102 bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl bOUTPUTInstructionExecutingFl x1 bReq_CompletionFlagReset x21 l	vnTransmissionDat	UW:juSendDeta				SET SET RST RST	bOUTPUTInetructionNormalC ompleteFlag2 M111 bOUTPUTInetructionAbnorma CompleteFlag2 M112 bOUTPUTInetructionExecutio nFlag M100 bOUTPUTInetructionNormalC ompleteFlag2 M111 bOUTPUTInetructionAbnorma bOUTPUTInetructionAbnorma M12 bOUTPUTInetructionExecutio
(63)	bOUTPUTInstructionNormalCom pleteFlag MIQ2 bOUTPUTInstructionAbnormalC mIQ2 MIQ2 bOUTPUTInstructionExecutingFl MIQ4 bOUTPUTInstructionExecutingFl MIQ4 bFleq_CompletionFlagReset X21 L	wnTransmissionDat	UW:LuSendData				SET SET RST RST RST	bOUTPUTInetructionAbnorma bOUTPUTInetructionAbnorma CompleteFlag2 M111 bOUTPUTInetructionAbnorma CompleteFlag2 bOUTPUTInetructionExecution bOUTPUTInetructionAbnorma bOUTPUTInetructionAbnorma bOUTPUTInetructionAbnorma bOUTPUTInetructionAbnorma bOUTPUTInetructionAbnorma bOUTPUTInetructionAbnorma M111 bOUTPUTInetructionAbnorma M111 bOUTPUTInetructionAbnorma M111
(63) (65) (69)	bOUTPUTInstructionNormalCom pleteFlag MI01 bOUTPUTInstructionAbnermalC ompleteFlag MI04 bOUTPUTInstructionExecutingFl MI04 bOUTPUTInstructionExecutingFl MI04 bEreq.CompletionFlagReset X21 L	wiTransmissionDat	UWLuSendData				SET SET RST RST RST	bOUTPUTInstructionNormalC ompleteFlag2 Mi11 bOUTPUTInstructionAbnorma Mi12 bOUTPUTInstructionExecutio nFlag Mi00 bOUTPUTInstructionNormalC ompleteFlag2 Mi11 bOUTPUTInstructionAbnorma ICompleteFlag2 Mi12 bOUTPUTInstructionAbnorma ICompleteFlag2 Mi12 bOUTPUTInstructionAbnorma ICompleteFlag2
(63)	bOUTPUTInstructionNormalCom plateFlag M010 bOUTPUTInstructionAbormalC ompleteFlag M102 bOUTPUTInstructionAbormalC ompleteFlag M104 bOUTPUTInstructionExecutingFl bBerq_CompletionFlagReset X21 }	vnTransmissionDat	UW.iuSendData				SET SET RST RST RST	bOUTPUTInstructionNormalC ompleteFlag2 Mill bOUTPUTInstructionAbnorma ICompleteFlag2 bOUTPUTInstructionExecutio nFlag Mill bOUTPUTInstructionExecutio ompleteFlag2 Mill bOUTPUTInstructionAbnorma ICompleteFlag2 Mill bOUTPUTInstructionAbnorma ICompleteFlag2 Mill bOUTPUTInstructionExecutio nflag
(63) (65) (69) (69)	bOUTPUTInstructionNormalCom pleteFlag bOUTPUTInstructionAbornalC bOUTPUTInstructionAbornalC bOUTPUTInstructionSecutingFl bOUTPUTInstructionSecutingFl bOUTPUTInstructionFlagReset X21	vnTransmissionDat	UW:LuSendDeta				SET SET RST RST RST	bOUTPUTInetructionNormalC ompleteFlag2 M111 bOUTPUTInetructionAbnorma ICompleteFlag2 M112 bOUTPUTInetructionExecutio nFlag M110 bOUTPUTInetructionNormalC ompleteFlag2 M111 bOUTPUTInetructionAbnorma bOUTPUTInetructionAbnorma ILI bOUTPUTInetructionExecutio nFlag M112

(0) Convert the transmission command into pulse.

(3) Store the data to be transmitted.
 Designate the transmission channel.
 Designate the send data quantity.
 Set the instruction execution flag.

(69) Reset the completion flag by an external command.



C24

Execute the next OUTPUT instruction cannot be executed simultaneously on the same interface.

# Transmission error detection and check methods

The following explains how to detect and confirm errors that may occur when sending data to target devices.

The possible primary causes of errors during data transmission are shown below.						
Cause of transmission error	Reference					
A timeout occurred for the send monitoring time (timer 2).	Page 233 Send Monitoring Time (timer 2) Setting					
The send data quantity exceeding the size that can be stored in the send area is designated.	Page 78 Send area and send data arrangement					

#### Detection/checking of transmission error by a program

#### ■Detecting a transmission error

The following device and input signal turn ON.

- OUTPUT instruction completion device + 1
- 'CH□ Error occurrence' (XE/XF)

#### ■Checking a transmission error

The transmission error code can be checked using the OUTPUT instruction control data ((S1) + 1).

Or, it can be checked by reading the 'data transmission result' (Un\G599/615).

For details on how to check the error code contents and corrective actions, refer to the following section.

Page 473 Error Code List

#### Detection/checking of transmission error with module and Engineering tool

#### Confirmation using the indicator LED

When C24 detects an error, including a reception error, the ERR LED turns ON.

#### Confirmation using Engineering tool

Monitor the 'data transmission result' (Un\G599/615) to check the error code.

Point P

When a transmission error occurs, the CPU module may not transmit all the designated data. Establishing any communication procedure by the user so that normal transmission can be checked by receiving a response to data transmission is recommended.

# **3.3** Considerations for Data Communication

The following describes considerations for data communications using the nonprocedural protocol.

#### Factors that initialize the C24 transmission sequence

The initial status means the status where transmission has stopped and received data has been discarded. C24 transmission sequence initialization factors are as follows.

- When the power is turned ON, the CPU module is reset, or the C24 mode is switched.
- When the received data was cleared.
- When the CD (DCD) signal turns OFF when data is communicated with the full-duplex communications on the RS-232 side with the CD terminal check enabled.

#### Generation of framing error on target device

When nothing is transmitted from C24 to a target device through the RS-422/485 interface, a framing error may be generated by the noise etc, on the target device side.

Send an arbitrary code first so that the target device identifies the head of the data transmitted from C24. Check the C24 interface specifications before data communication.

#### Data communications with target device using the multidrop connection

When communicating data by the multidrop connection between the target device and the CPU module in a 1:n basis, data transmitted by the target device is received by C24.

For the multidrop connection, data reception using a user frame should be performed. (EP Page 278 Data Reception) If data is not received by user frame, create a program that ignores (reads and discards) the received data other than the received data addressed to the host station, including the data indicating the target CPU module in the message.

|--|

STX	Space	Station No. 0	Station No. 2	Data length (BIN data)	Data	CR	LF
(02н)	(20н)	(30н)	(32н)			(0Dн)	(0Ан)

#### Retry processing for data reception errors

The data when reception error occurred is discarded and only the data for the normal reception is taken into the C24. For this reason, the received message may be missing data if reception error occurs.

To assure the correct transmission and reception of data, it is recommended that a normal/error response message is received and a response message reception timeout check is conducted for the data transmitted between the CPU module and the target device, and that measures such as retransmitting the data (transmission retry) is taken when an abnormal response is received or when an error timeout occurs.

# **4** DATA COMMUNICATION USING BIDIRECTIONAL PROTOCOL

This communication enables data transfer between a target device and a CPU module using the data format and transmission control procedure for the bidirectional protocol.

The feature of this data communication is that a response message is sent from the data receiving side to the data sending side to inform whether the communication has been completed.

Use this to check if the data communication has been completed normally.

Programs for transmitting and receiving data are required on the CPU module side.





Communication using the bidirectional protocol can be replaced with those of the predefined protocol. The Predefined protocol support function of Engineering tool allows the easy replacement.

With the predefined protocol, the required program is only for starting communication according to the specified protocol, and this can reduce the number of steps considerably.

For the communication using the predefined protocol, refer to the following chapter.

IP Page 26 DATA COMMUNICATION USING PREDEFINED PROTOCOL

#### Parameter setting for data communication using bidirectional protocol

Set the transmission specification, the communication protocol with target devices, and others. Set "Bidirectional protocol" for "Communication protocol setting".

Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings"
⇒ "Various control specification"

Configure other settings according to the system being used.

For details of the settings, refer to the following section.

Page 422 PARAMETER SETTING

# 4.1 Receiving Data from Target Device

This section explains the data reception from a target device.

# **Receiving methods**

The following shows how to receive data sent from the target device using the bidirectional protocol.

Since the size of each message to be received is recognized using the "data length" information contained in the message, messages of any size can be sent from the target device.



When the control code ENQ is received, C24 starts data reception processing.

When data portion for the data length is received, C24 ends the reception processing of arbitrary data portion.

- When sum check code is enabled in the transmission setting of Engineering tool, C24 checks whether the message is
  normal or abnormal using the sum check code received immediately after the message and the sum check code calculated
  by internal processing.
- When sum check code is disabled in the transmission setting of Engineering tool, messages are not checked using the sum check codes.
- Ø When the message has normally been received, the 'CH□ reception data read request' (X3/XA) turns ON.
- If an error has been detected when receiving the message, C24 transmits an abnormal completion response message (NAK message) to the target device.
- The reception data read request will not be sent to the CPU module. (The 'CH□ reception abnormal detection' (X4/XB) does not turn ON.)
- O C24 stores the control data in the device designated with the BIDIN instruction, and then executes the BIDIN instruction.
- Received data is read from the receive area in the buffer memory.

**4** When the BIDIN instruction has been executed, C24 transmits a normal completion response (ACK message) to the target device.

## Receive area, receive data arrangement and contents

This section shows the receive area and the receive data arrangement for performing data reception using the bidirectional protocol.

#### Receive area

The receive area is a memory that stores the data length (receive data quantity) and data portion received from a target device.

By default, the receive area is assigned to the addresses, Un\G1536 to 2047 (CH1 side) and Un\G2560 to 3071 (CH2 side).



The position and size of the receive area in the buffer memory can be changed with Engineering tool in accordance with the specifications of the target device and the receive data length. ( I Page 422 PARAMETER SETTING)

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings"
⇒ "Various control specification"

Configure the settings as follows:

- Designate the start address for the area to be used as receive area in the user setting area (Un\G1024 to 6911, Un\G9728 to 16383) to "Receiving buffer memory start address designation".
- Designate the length of area to be used as the receive area in the user setting area (Un\G1024 to 6911, Un\G9728 to 16383) by address count (0001H to 1A00H) to "Receiving buffer memory size specification".

When changing the position and size of the receive area in the buffer memory, if any of the functions below are used concurrently, make sure that the addresses of the receive area do not overlap with the buffer memory addresses assigned for storing send/receive data with the functions.

- · MC protocol buffer memory read/write function
- MC protocol on-demand function
- Predefined protocol function (Send/receive data storage area)
- · Nonprocedural protocol transmission/receive function
- · Bidirectional protocol transmission/receive function
- · Send/receive data monitoring function

Set the amount of data per data transmission from the target device to C24 to be smaller than the size of the receive data storage area in the buffer memory.

• (Receive data storage area) ≥ (Amount of data in any data portion to be transmitted from the target device)

To transmit data whose size is larger than the receive data storage area, increase the receive area, or divide the send data before sending.

#### Point P

The position and size of the receive area can be changed in the buffer memory.

- · 'Receiving buffer memory start address designation' (Un\G166/326)
- 'Receive buffer memory length designation' (Un\G167/327)

#### **Receive data arrangement**

The following shows the example of the arrangement of data received from the target device when it is stored in the receive area.

- The received message is stored to the C24 buffer memory (Receive data storage area).
- The data is stored in the receive data storage area in the order of the data reception from low address, (L) → (H), to next address, (L) → (H).



When received data "ABCDEFG123" was stored (for the CH1 side)



When the data length unit is in bytes, 00H is stored in the higher byte of the last data storage position in the receive area when the data length of the message is an odd byte.

#### Contents of received data

The following shows the contents of data to be received, including data to be transmitted. (EP Page 97 Send area and send data arrangement)

#### ■Control codes

The types of control codes are shown in the table below.

Signal name	Code (hexadecimal)	Description	Application
ENQ	05H	Enquiry	Code for starting data transmission
ACK	06H	Acknowledge	Response code to the target side when data was received normally
NAK	15H	Negative Acknowledge	Response code to the target side when data could not be received normally (Error code is sent immediately after the response code.)

\* Target device  $\rightarrow$  C24

C24 checks and processes the control code received. It cannot be read from the program.

C24 → target device

C24 adds the control code to be transmitted.

#### ■Data length

This indicates the number of bytes or words for the data portion of the message.

The unit of data length (words/bytes) is in accordance with the word/byte units designation with Engineering tool.

\* Target device  $\rightarrow$  C24

C24 checks the length of the data received.

When the reception is normal, C24 stores the received data in the receive data storage area in the C24 buffer memory, assigning the first byte as the lower byte (L).

• C24  $\rightarrow$  target device

The length of data to be transmitted is the send data quantity designated by the program using the BIDOUT instruction. C24 transmits this value as is from the lower byte (L).

#### ■Data portion

This consists of an array of original one-byte data to be transmitted to the target device side, which can handle 00H to FFH code data.

Target device→C24

If the receive data portion is normal, C24 takes the codes as is and stores them in the receive data storage area in sequence, beginning with the lowest address.

The storage size is in accordance with the data length in the message and the word/byte units designation with Engineering tool.

• C24  $\rightarrow$  target device

The portion of data to be transmitted is the send data designated by the program using the BIDOUT instruction. C24 transmits the data for the send data quantity according to the word/byte units designation with Engineering tool from the lowest address in the send data specification area using the code as is.

#### Sum check code

The sum check code expresses the numeric value for the lower two bytes (16 bits) of the results (sum) from the addition of the data length and the data portion in the message as binary code data.

When sum check code is enabled in the transmission setting of Engineering tool, it is necessary to add a sum check code at the end of the message.

• Target device  $\rightarrow$  C24

C24 checks and processes the sum check code received. It cannot be read from the program. When "None" is specified for "Sum check code", once data portion of message corresponding to the data length is received, the succeeding data received will be ignored up to the control code that follows.

• C24  $\rightarrow$  target device

C24 calculates and adds the sum check code to be transmitted.

When "None" is specified, no sum check code is transmitted.



#### Error code

The error code indicates the definition of the error during NAK response.

For details on the error codes, refer to the following section.

Page 473 Error Code List

\* Target device  $\rightarrow$  C24

For error codes from the target device, transmit the codes specified by the user.

The error codes (0022H to 005FH) that are not used by C24 can be used.

C24 stores the received error codes as a completion status in the control code for the BIDOUT instruction. They are also stored in the 'data transmission result' (Un\G599).

\* C24  $\rightarrow$  target device

C24 adds an error code.

When an error code is transmitted, C24 writes the same error code in the 'data reception result' (Un\G600).

#### Program example for data reception

The following shows the program for data reception using the bidirectional protocol and program example. For details on the BIDIN instruction, refer to the dedicated instructions. ( 🖅 Page 520 Dedicated Instructions)



Start the programmable controller on the host station. The value set with Engineering tool is stored in C24.

When data is received from the target device, the 'CH1 reception data read request' (X3) turns ON.

3 After the control data for the BIDIN instruction is stored in the device, the sequence program executes the BIDIN instruction and reads the receive data.

**4** When the reading of receive data is completed, a response message (ACK message when the operation was completed normally) is sent and the device that has completed the BIDIN instruction turns ON.

#### ■Program example

Category	Label name	1	Descriptio	n	Device					
Module label	C24_1	٦	arget modu	le	-					
	C24_1.stnCH1.bSet_Req_Reception	0	CH1 Recept	ion	X3					
Label to be defined	ed Define the global label as shown below.									
	Label Name bBIDINInstructionExecutionCompleteDevice bBIDINInstructionExecutionCompleteDevice bBIDINInstructionExecutionStatusDevice bBReg_BIDINInstructionExecution wReceiveChannel bReg_BIDINInstructionExecution bread	Data Type Bit Bit Bit Bit Word [Unsigned]/Bit String [16-bit]		Class VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL	4 4 4 4	Assign (Device/Label) M0 M1 M2 M10 D1				
	6 wAllowableReceiveDataCount 7 wReceiveBesult 8 wReceiveDataCount 9 wmReceiveData 10 bBIDINInstructionAbnormalCompleteDevice2 11 bExternalCommand	Word [Unsigned]/Bit String [16-bit] Word [Unsigned]/Bit String [16-bit] Word [Unsigned]/Bit String [16-bit] Word [Unsigned]/Bit String [16-bit][015] Bit Bit		VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL	4 4 4 4 4 4	D2 D3 D4 D10 M100 X100				

For information on the module FB to be used, refer to the following manual.



Specify the receive data quantity.

Set the BIDIN instruction execution direction.

(54) Abnormal completion

(56) Reset the abnormal completion flag by an external command.



C24

storage position in the receive area where received data is stored.

## **Reception error detection and check methods**

The following explains how to detect and confirm errors that may occur when receiving data from target devices. The following items are considered as the primary causes of errors that may occur during data reception.

Cause of reception error	Reference
A transmission error occurred due to noise.	MELSEC iQ-R Serial Communication Module User's Manual (Startup)
A timeout occurred for the no-reception monitoring time (timer 0).	Page 228 No-reception Monitoring Time (timer 0) Setting
A timeout occurred for the send monitoring time (timer 2).	Page 233 Send Monitoring Time (timer 2) Setting
Data that could not be converted with the ASCII-BIN conversion was included.	Page 359 ASCII-BIN Conversion for Data Communicated with Bidirectional Protocol
The receive data length was too long to be stored in the receive area.	Page 88 Receive area, receive data arrangement and contents
Simultaneous transmissions occurred.	Page 104 Processing when Simultaneous Transmission is Performed during Full-Duplex Communications

#### Confirmation using a program

#### Detecting a reception error

'CHD Error occurrence' (XE/XF) turns ON.

#### ■Confirming a reception error

Read the 'data reception result' (Un\G600/616), and check it.

For details on how to check the error code contents and corrective actions, refer to the following section.

Page 473 Error Code List

#### Confirmation using the module and Engineering tool

#### Confirmation using the indicator LED

When C24 detects an error, including a transmission error, the ERR LED turns ON.

#### Confirmation using Engineering tool

Read the 'data reception result' (Un\G600/616), and check the error code.

#### Considerations

 All of the received data for which an error was detected is ignored and a response message indicating an abnormal completion (NAK message) is transmitted to the target device. The 'CH<sup>I</sup> reception abnormal detection' (X4/XB) does not turn ON.

When an error is detected during a message reception, C24 does not request the CPU module to read the received data.

• The receive area in the buffer memory will contain the data received normally just before the error occurrence. (Data will not be rewritten.)

## **Receive data clear**

Data communications using the bidirectional protocol must be performed after a response message is received in reply to the preceding data transmission.

If C24 detects an error while receiving data, it transmits an NAK message (response message) to the target device after the completion of the data reception and ignores the data being received when the error was detected.

Therefore, the received data does not have to be cleared.

# 4.2 Transmitting Data to Target Device

This section explains the data transmission from the CPU module to a target device.

# Sending methods

The following shows the method of transmitting data to the target device through data communication using the bidirectional protocol.



• Data such as control data and send data are stored in the device designated with the BIDOUT instruction, and then the BIDOUT instruction is executed.

2 The send data quantity and send data are written into the send area in the buffer memory.

C24 transmits data by adding the control code ENQ to the head of the data.

• When sum check code is enabled in the transmission setting with Engineering tool, C24 adds the sum check code calculated by internal processing to the end of the message and then transmits the message.

• When sum check code is disabled in the transmission setting with Engineering tool, sum check code is not transmitted.

• A response for the data transmission (for normal completion: ACK message; for abnormal completion: NAK message) is received.

Once the transmission processing of C24 is completed, the execution of the BIDOUT instruction is completed.

## Send area and send data arrangement

This section explains the send area and the send data arrangement for performing data transmission using the bidirectional protocol.

For details on the contents of send data, refer to the following section.

Page 90 Contents of received data

#### Send area

The send area is a memory area for storing the data and the data quantity that are transmitted from the CPU module to a target device via C24.

The send area is assigned to the address, Un\G1024 to 1535 (CH1 side), Un\G2048H to 2559 (CH2side) by default.



The position and size of the send area in the buffer memory can be changed with Engineering tool in accordance with the specifications of the target device and the send data length. ( I Page 422 PARAMETER SETTING)

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

Configure the settings as follows:

- Designate the start address for the area to be used as the send area in the user setting area (Un\G1024 to 6911, Un\G9728 to 16383) to "Send buffer memory start address designation".
- Designate the length of the area to be used as the send area in the user setting area (Un\G1024 to 6911, Un\G9728 to 16383) by address count (0001H to 1A00H) to "Send buffer memory size specification".

When changing the position and size of the send area in the buffer memory, if any of the functions below are used concurrently, make sure not to overlap with the buffer memory addresses assigned for storing send/receive data handled with the functions.

- · MC protocol buffer memory read/write function
- MC protocol on-demand function
- · Predefined protocol function (Send/receive data storage area)
- Nonprocedural protocol transmission/receive function
- · Bidirectional protocol transmission/receive function
- · Send/receive data monitoring function

Set the size of data per data transmission from the target device to C24 to be equal to or smaller than the size of the send data storage area in the buffer memory.

• (Send data storage area) ≥ (Amount of arbitrary data portion to be transmitted from the CPU module)

To transmit data whose size is larger than the send data storage area, increase the send area, or divide the send data before sending.

Point P

The position and size of send area can be set in the buffer memory.

- 'Send buffer memory start address designation' (Un\G162/322)
- Send buffer memory size specification (Un\G163/323)

#### Send data arrangement

The following example shows an arrangement of the send data to be sent to the target device when storing it in the send area.

# Ex. When transmitting "ABCDEFG123"



#### Program example for data transmission

The following shows the program for data transmission and program example.

For details on the BIDOUT instruction, refer to the dedicated instructions. (SP Page 520 Dedicated Instructions)



**1** Start the programmable controller on the host station.

The values specified with Engineering tool are stored in C24.

Inputs the user data transmission command signal.

Secure the BIDOUT instruction after storing the send data and the control data for the BIDOUT instruction in the device.
Data is sent when the BIDOUT instruction is executed.

• A response for the data transmission (for normal completion: ACK message; for abnormal completion: NAK message) is received.

**3** When the response is received, C24 transmission processing completes and the device that has completed the BIDOUT instruction turns ON.

When the BIDOUT instruction ends abnormally due to the reception of an NAK message, the complete device +1 (abnormal completion signal) turns ON and the error code is stored in the control data completion status (S1+1).

#### ■Program example

Category	Label name					tion	Device		
Module label	C24_	1		Target module			—		
Label to be defined	Defin	Define the global label as shown below.							
		Label Name	Data Tura	Class	Assign (Deuise / shell	1			
	1	bBeg Transmission	Bit			<ul> <li>Assign (Device/Label)</li> <li>X20</li> </ul>			
	2	bReg CompletionFlagReset	Bit		VAR GLOBAL	• X21			
	3	bRegPluse Transmission	Bit		VAR GLOBAL	• M50			
	4	bBIDOUTInstructionNormalCompleteFlag	Bit		VAR_GLOBAL	<ul> <li>M100</li> </ul>			
	5	bBIDOUTInstructionAbnormalCompleteFlag	Bit		VAR_GLOBAL	<ul> <li>M101</li> </ul>			
	6	bBIDOUTInstructionExecutionStatusDevice	Bit		VAR_GLOBAL	<ul> <li>M102</li> </ul>			
	7	bReq_BIDOUTInstructionExecution	Bit		VAR_GLOBAL	• M110			
	8	wTransmissionChannel	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	r D1			
	9	wTransmissionDataCount	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	- D2			
	10	wnTransmissionData	Word [Signed](04)		VAR_GLOBAL	• D11			
	11	wErrorCodeStorageDevice	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	<ul> <li>D101</li> </ul>			
	12	bBIDOUTInstructionNormalCompleteFlag2	Bit		VAR_GLOBAL	M120			
	13	bBIDOUTInstructionAbnormalCompleteFlag2	Bit		VAR_GLOBAL	• M121			

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	bReg Transmission							
(0)	X20						PLS	bReqPluse_Transmission
(0)								M50
	bRegPluse Transmissio							5
(0)	n M50					6140V	"ABCDEFG"	wnTransmissionData[0]
(3)						\$MOV		D11
							H0AC0	wnTransmissionData[4]
						MOV		D15
							K1	wTransmission@hannel
						MOV	N1	wiransmissiononannei
				-			L	D1
						MOV	K5	wTransmissionDataCount
						mov		D2
								bReg_BIDOUTInstructionExe
							SET	cution M110
			M_RJ71C24_BidirectionalOutput_00C_1	(M+RJ71C24_BidirectionalOutput_00C				
(18)			Bidirection	al Output FB				
	bRes BIDOLITInstructi							hBIDOLITInetructionExecutio
	onExecution							nStatusDevice
			BibEN	a bENO:E				M102
								bBIDOUTInstructionNormalC ompleteFlag
	_C24_1	_						M100
		1	- DUT:i_stModule	o_bOK:E				0
						1	1	bBIDOUTInstructionAbnorm
	wTransmiss hannel	sionC						alCompleteFlag M101
	D1	]	H UW:LuCh	o_bErr:E				O
			-					
	wTransmiss	sionD						
	ataCount	1	LIW-iuSendDatal ength	o uErrid: IV				
	•	-	· · · · · · · · · · · · · · · · · · ·					
	wnTransmi	sion						
	Data[0]	-						
		-	- UW:i_uSendData					
	bBIDOUTInstructionNo					Î		
(63)	malCompleteFlag M100						SET	bBIDOUTInstructionNormalC ompleteFlag2
							-	M120
	bBIDOUTInstructionAb							
(05)	normalCompleteFlag M101						OFT	bBIDOUTInstructionAbnorm
(65)							SEI	alCompleterlagz M121
	- Dec Occurate for D							
	eset							bBIDOUTInstructionNormalC
(67)	X21						RST	ompleteFlag2 M120
							1	MILO
							RST	alCompleteFlag2
								M121
						1		
							DOT	bReq_BIDOUTInstructionExe
					<u> </u>			M110
(71)								
(0)	Convert the transmission command into	nule	20					

Convert the transmission command into pulse. (0)

Store the data to be transmitted. (3) Designate the transmission channel. Designate the send data quantity. Set the instruction execution flag.

(67) Reset the completion flag by an external command.



Restriction (")

More than one BIDOUT instruction cannot be executed simultaneously on the same interface. Execute the next BIDOUT instruction only after the execution of the first BIDOUT instruction is completed.

## Transmission error detection and check methods

The following explains how to detect and confirm errors that may occur when transmitting data to target devices. The following items are considered as the primary causes of errors that may occur during data transmission.

Cause of transmission error	Reference
A transmission error occurred due to noise.	MELSEC iQ-R Serial Communication Module User's Manual (Startup)
A timeout occurred for the no-reception monitoring time (timer 0).	Page 228 No-reception Monitoring Time (timer 0) Setting
A timeout occurred for the response monitoring time (timer 1).	Page 231 Response Monitoring Time (timer 1) Setting
A timeout occurred for the send monitoring time (timer 2).	Page 233 Send Monitoring Time (timer 2) Setting
Data that could not be converted with the ASCII-BIN conversion was included.	Page 359 ASCII-BIN Conversion for Data Communicated with Bidirectional Protocol
The send data quantity that exceeded the send area size was designated.	Page 97 Send area and send data arrangement
Simultaneous transmissions occurred.	Page 104 Processing when Simultaneous Transmission is Performed during Full-Duplex Communications

#### Confirmation using a program

#### ■Detecting a transmission error

The following device and input signal turn ON.

- BIDOUT instruction completion device + 1
- 'CH□ Error occurrence' (XE/XF)

#### ■Confirming a transmission error

The transmission error code can be checked using the BIDOUT instruction control data ((S1) + 1).

Or, it can be checked by reading the 'data transmission result' (Un\G599/615).

For details on how to check the error code contents and corrective actions, refer to the following section.

Page 473 Error Code List

#### Confirmation using the module and Engineering tool

#### ■Confirmation using the indicator LED

When C24 detects an error, including a reception error, the ERR LED turns ON.

#### Confirmation using Engineering tool

Monitor the 'data transmission result' (Un\G599/615) to check the error code.

# 4.3 Processing when Simultaneous Transmission is Performed during Full-Duplex Communications

This section explains the processing when simultaneous transmission is performed during full-duplex communications.

## Processing when simultaneous transmissions occur

The following explains the processing by C24 when the target device and C24 transmit data at the same time during data communications using the bidirectional protocol.

Note that transmission from a target device and from C24 are not performed simultaneously for data communication by halfduplex communications. ( SP Page 243 DATA COMMUNICATIONS USING HALF-DUPLEX COMMUNICATIONS)

The processing on the C24 side differs depending on the settings with Engineering tool when transmission from a target device and C24 is performed at the same time.

Set "Send data enable/disable" and "Receive data enable/disable" to "Enable" or 'Disable" with Engineering tool.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

The setting value for "Send data enable/disable" and "Receive data enable/disable" is stored in the following area on the buffer memory.

For processing of transmitted/received data on the C24 side for each setting of the 'simultaneous transmitted data valid/invalid designation' (Un\G155/315), refer to the "Processing of transmitted/received data when simultaneous transmission occur".

Setting contents with	Value stored to buffer	C24 processing contents					
Engineering tool	memory (Un\G155/315)	Processing related to message transmission	Processing related to massage reception				
Send data enable/disable: Enable Receive data enable/disable: Enable	0000H	Waits to receive the response message( <b>①</b> -2) while checking time-out after data transmission ( <b>①</b> -1) is complete. Notifies normal completion or abnormal completion according to whether or not the response message is received to the CPU module via the buffer memory.	Transmits a response message ( <b>9</b> -2) after data reception ( <b>9</b> -1) is complete. Notifies the received data and reception result to the CPU module via the buffer memory.				
Send data enable/disable: Disable Receive data enable/disable: Enable	0100H	Notifies a simultaneous transmission error to the CPU module via the buffer memory after data transmission( <b>0</b> -1). Does not wait for a response massage ( <b>0</b> -2) in reply to data transmission ( <b>0</b> -1).	Transmits a response message ( <b>2</b> -2) after data reception ( <b>2</b> -1) is completed. Notifies the received data and reception result to the CPU module via the buffer memory.				
Send data enable/disable: Enable Receive data enable/disable: Disable	0001H	Waits to receive the response message ( <b>1</b> -2) while checking time-out after data transmission ( <b>1</b> -1) is complete. Notifies normal completion or abnormal completion according to whether or not the response message is received to the CPU module via the buffer memory.	Ignores data reception ( <b>2</b> -1) and discards the received data. Does not transmit a response message ( <b>2</b> -2). Does not inform the CPU module that data was received.				
Send data enable/disable: Disable Receive data enable/disable: Disable	0101H	Notifies a simultaneous transmission error to the CPU module via the buffer memory after data transmission( <b>1</b> -1). Does not wait for a response massage ( <b>1</b> -2) in reply to data transmission ( <b>1</b> -1).	Ignores data reception ( <b>Q</b> -1) and discards the received data. Does not transmit a response message ( <b>Q</b> -2). Does not inform the CPU module that data was received.				

(O-m) is the number showing the correspondence with the messages in the figures below.

IP Page 105 Processing of transmitted/received data when simultaneous transmissions occur

# Processing of transmitted/received data when simultaneous transmissions occur

The following shows the C24 communication data processing based on the settings of 'Send data' and 'Receive data' with Engineering tool by using the examples.

For details on the time check timer 1 (response monitoring time) shown in the figures, refer to the following section.

#### Send data: Enable, Receive data: Enable



#### Send data: Disable, Receive data: Disable



#### Send data: Enable, Receive data: Disable



#### Send data: Disable, Receive data: Disable



4.3 Processing when Simultaneous Transmission is Performed during Full-Duplex Communications



When the transmission control is performed with "Send data" set to "Enable" and "Receive data" set to "Enable", C24 performs message transmission and message reception processing as described below. (Improved Page 239 Control Contents of DC Code Control)

During message transmission processing, time check by timer 1 (response monitoring time) is performed.

- Message transmission (**1**-1 in the figure)
- When C24 receives a transmission terminate request (receiving DC3/DR(DSR) signal OFF) from the target device during message transmission, C24 terminates data transmission.
- When the C24 receives a reception available signal (receiving DC1/DR(DSR) signal ON), C24 restarts data transmission.
- Message reception
- If C24 cannot send a response message to the target device in response to message reception because the target device issued a transmission terminate request (receiving DC3/DR(DSR) signal OFF), C24 transmits the response message after it's in the data transmission available state (receiving DC1/DR(DSR) signal ON).
## **4.4** Considerations for Data Communication

The following describes the considerations for data communications using the bidirectional protocol.

#### Factor of C24 transmission sequence initialization

The initial status means the status where transmission has stopped and received data has been discarded. C24 transmission sequence initialization factors are as follows.

- When the power is turned ON, or the CPU module is reset.
- When some operation is performed, or the mode is being switched.
- · When a response message (ACK, NAK, etc.) was received in reply to data transmission.
- · When a response message (ACK, NAK, etc.) was transmitted in reply to data reception.
- When the CD (DCD) signal was turned OFF during data communications with the CD terminal check enabled for full-duplex communications via the RS-232 interface.

#### Data transmission procedure

As a data transmission procedure, data transmission from the target device or C24 should be performed after a response message for the immediately preceding data transmission has been received.

#### Units of data length (word/byte) in message to be transmitted/received

Specify the same units of data length (words/bytes) of the messages to be transmitted/received between a target device and the CPU module.

The word/byte units designation can be set with Engineering tool for the CPU module.

Make the length of the data portion in the message to be transmitted and received as long as the size of the send data specification area and the receive data storage area, or less.

#### NAK code response

#### ■Response from C24 to target device

After the completion of error detection message reception, it transmits the NAK code to the target device.

#### ■Response from target device to C24

Transmit the error code (0022H to 005FH) immediately after the NAK response.

Point P

 Perform error processing according to the error code received immediately after the NAK message at the device that received NAK as the response message after data transmission.

For more details on error codes that are transmitted from C24, refer to the following section. (

- If C24 receives an NAK response while transmitting data to a target device, it completes data transmission, then reads the NAK to complete the processing abnormally.
- If C24 detects an error while receiving data, it ignores the received data equivalent to the data length. If the data length is abnormal, C24 ignores all the data up to the head data for reception message (ENQ, etc.) received thereafter.

#### Target device time-out check

When checking time-out up to reception of the response message at the target device during data transmission from the target device to C24, set the timeout time to the time shown below, or longer.

• (CPU module maximum scan time×2) + 100 ms

#### Framing error on the target device side

While nothing is being transmitted from C24 to the target device though the RS-422/485 interface, a framing error may be generated in the target device.

Make the target device skip the data up to transmission of the head data (ENQ, NAK, etc.) of the message from C24. Before communicating data through the RS-422/485 interface, check the interface specifications on the C24 side. MELSEC iQ-R Serial Communication Module User's Manual (Startup)

#### Data bit settings

When adding a sum check code to a message, set "Data bit" to "8".

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

## **5** DEBUG SUPPORT FUNCTION

The debug support function is designed to support the debugging of communication processing between C24 and target device. The following functions are available to ease system startup work.

- · Circuit trace
- · Protocol execution log storage function (for predefined protocol only)

## 5.1 Circuit Trace

The communication data and communication control signal between C24 and target device are traced.



### Procedure for the circuit trace

The following shows the procedure for the circuit trace.

#### Operating procedure

- 1. Start circuit trace from Engineering tool.
- **2.** Perform communications with the target device.
- 3. Stop circuit trace in Engineering tool.
- 4. Circuit trace results are displayed.
- 5. Confirm the send/receive packet data and communication control signal.

5

### Performing circuit trace

The trace data is stored in the monitor buffer to trace the communication data and communication control signal status.

#### Operating procedure

- **1.** Select [Tool]⇔[Intelligent Function Module Tool]⇔[Serial Communication Module]⇔[Circuit Trace] in Engineering tool.
- 2. Click the [Module Selection] button to select the module to be traced in the "Module Selection (Circuit Trace)" screen.

Mod	Module Selection (Circuit Trace)						
м	Module Selection						
			_				
	Start XY	Module Name					
	0000	RJ71C24					
	OK	Cancel					

3. Select the channel to be traced from "Channel Selection", and click the [Start Trace] button.

Circuit Trace			×
Operation Flow			
Target Module Type 0000:RJ71C24 Mod <u>u</u> le Selection	CH1 CH1	 Trace stopped	Stop Trace
Trace Result			
$\checkmark$			
Qpen Trace File		Save Tra	→ Time ce File Close

- 4. When the monitor buffer is full, or the [Stop Trace] button is clicked, the trace data are displayed.
- 5. Confirm the send/receive packets and communication control signals from the displayed trace result.

Window

Target Module Type 0000:RJ71C24		Chan CH1	nel Selec	tion	Option		→ (	Sta	rt <u>T</u> race	;	<b>→</b>	Trace s	topped	<b>→</b>		Stop Tj	iace	
ace Result	n													_				
Currently Displayed	Data						Cont		7					Re	ception	Error		
Module Name	0000:RJ	71C24(C	H1)				rina							1	N Ove	arun erro	ır	
Measurement Tim	e 21980 m	\$				Send	/Receiv	e Packe						8	🖉 Pari	tv error		
Extracted Date	2014/06	/18 19:5	9:33			0	uisplay s	ena/rec	eive pac	ket in <u>H</u> E	^							
Displaying	the latest tr	ace resu	łt –			۲	Display s	end/rec	eive pac	ket in <u>A</u> S	CII				Fran	ning erro	ſ	
_	-				1		1	1	1									
Send Packet	ENQ								CR									
Receive Packe										NAK	0	0	7	в	0	6	CR	LF
RS signal	-																	
DTR signal																		
DSR signal																		
CS signal																		
LU signal																		
neception entit						_			_			_	_	_				_

#### **Displayed items**

Item		Display/setting content			
Trace Result	Currently Displayed Data	Displays the model name, measurement time, and extraction date/time of the module on which the circuit trace is executed.			
	[Find] button	Searches the trace data.			
	Send/Receive Packet	Select the display format of the send/receive packets. The hexadecimal or ASCII code can be selected.			
	Communication control signals	The RS(RTS), ER(DTR), DR(DSR), CS(CTS), and CD(DCD) signal status and reception error are displayed as described below. ■RS, ER, DSR, CS, and CD signals All signals are displayed with blue lines —. When signal is ON: When signal is OFF: When the obtained data does not have signal information, the signal is displayed as an OFF status. ■Reception Error Three different errors of overrun error, parity error, and framing error are displayed. Overrun error: \$\overline{C}\$ (Green) Parity error : ■ (Light Blue) Framing error: ■ (Purple)			
[Open Trace File] butt	on	Reads and displays the trace data saved in a personal computer.			
[Save Trace File] butto	on	Saves the trace data obtained by the circuit trace to a personal computer.			
[Close] button		Closes the Circuit Trace screen.			

### Circuit trace option setting

In the circuit trace option setting, the following two items can be set.

- Setting a start address and size of buffer area of C24 in which circuit trace data is stored (hereinafter, 'monitor buffer area')
- · Setting whether the circuit trace is stopped or continued when the timer 0 error occurs

#### Operating procedure

- **1.** Select ⇔ [Tool] ⇔ [Intelligent Function Module Tool] ⇔ [Serial Communication Module] ⇔ [Circuit Trace] in Engineering tool.
- **2.** Click the [Options] button.

Circuit Trace Operation Flow				<b>•</b>
Target Module Type 0000:RJ71C24 Mod <u>u</u> le Selection	CH1 Option	Start <u>Trace</u>	Trace stopped 🔶	Stop T <u>r</u> ace
Trace Result				
Open Trace File			Save Trace Fi	→ Time

**3.** On the "Circuit Trace Option" screen, set "Start Address", "Size", and "Stop Setting" of the buffer memory of C24, and click the [OK] button.

Circui	it Trace Option				×
	Circuit Trace Data S	itorage Are	a Setting		
	Start <u>A</u> ddress	2600	(HEX)		
	Size	0D00	(HEX)		
	Ston Setting				
	Chan bu accurre	nso of times (	time out a		
	Stop by occurre	nce or unier c	une-ouc ș	arror	
	Explanation				
	Set the start buffer m trace data. Range: 0x0C00 to ( 0x2600 to 0: Set one of the two ar These areas cannot b	nemory addre Dx1AFD (3FFD eas. e overlapped	ss to store	the circuit	*
					Ŧ
		OK		Cance	el

#### **Displayed** items

Item		Display/Setting content
Circuit Trade Data Storage Area Setting	Start Address	Set the start address of the C24 buffer memory. Input the setting in hexadecimal. Input range CH1/CH2: 2600H to 3FFDH (C00H to 1AFDH for the user setting area)
	Size	Set the size of the C24 buffer memory. Input the setting in hexadecimal. Input range CH1/CH2: 3 to 1A00 words (3 to F00 words for the user setting area) Set the maximum address <sup>*1</sup> for the trace data storage area to be in the range between 2602H to 3FFFH (C02H to 1AFFH for the user setting area). Note that the range of this value is checked at start of the circuit trace when using the user setting area.
Stop Setting	Stop by occurrence of timer 0 timeout error	Set whether or not the circuit trace is stopped when the timer 0 timeout error occurs.

\*1 The maximum address for the trace data storage area is calculated by the following formula. Maximum address for the trace data storage area = "Start Address" + "Size" – 1

### 5.2 Protocol Execution Log Storage Function (for Predefined Protocol only)

This function checks the detailed predefined protocol execution status and results for each channel. Up to 32 protocol execution logs can be checked.

If the number of the stored logs exceeds 32, the oldest log will be overwritten.

The protocol execution log can be checked in the following method.

- · Checking with Engineering tool
- Checking with the buffer memory



#### Precautions

Do not perform the above two methods at the same time.

The latest execution logs are not stored in the buffer memory while they are being updated with the predefined protocol support function of Engineering tool.

### **Checking with Engineering tool**

Check the protocol execution logs and protocol execution results in the "Protocol Execution Log" screen of Engineering tool.

#### Operating procedure

- **1.** Select a module to be debugged.
- Display the "Protocol Setting" screen. ( 🖙 Page 27 Data Communication Procedure)
- Select "Protocol Setting" ⇒ [Debugging Support Function] ⇒ [Module Selection].
- Select the I/O address and channel of the module to be debugged, and click the [Set] button.
- · As the [OK] button is clicked, the module information is set.

Module Selection	x
The Present Target Module	
Module Selection Module List I/O Address Type Channel Specification QD R37/1C24 CH1 V	
OK Cancel	

- **2.** Execute the CPRTCL instruction.
- 3. Select "Protocol Setting" ⇒ [Debugging Support Function] ⇒ [Protocol Execution Log].

#### Window

Prot	cocol Execution Log										
Tai	get Module:	I/O Address(00) Typ	ie(RJ71C24) Char	nnel(CH2)							
N	D. Start Time and Date	End Date	Model	Protocol No.	Protocol Name	Туре	Execution Result	Error Code	Retry	Packet No.	
1	2014-09-02 17:56:05	2014-09-02 17:56:05	FREQROL Series	1	H7B:RD Operation	Send&Receive	Normal completion		0	1	
											1
	Update Log										Save CSV File
										[	Close
										-	

Point P

The logs displayed in the "Protocol Execution Log" screen can be selected from the following two items, according to the log registration condition.

- Displaying only protocol that completed abnormally.
- Displaying all protocol execution status and execution logs.

The log registration condition can be set in "Execution log options" in the "Various control specification" screen of Engineering tool.

### Checking with the buffer memory

Check the protocol execution logs in the execution log storage area.

#### Operating procedure

1. The log registration condition can be set by the 'Execution log options' in the buffer memory (Un\G16610/16626).



**2.** Execute the CPRTCL instruction.

3. Check the protocol execution logs stored in the execution log storage area (Un\G16643 to 18177/18435 to 19969).

For details, refer to the following section.

Page 498 Buffer memory list

## PART 2

## ADDITIONAL FUNCTIONS

This part explains the additional functions of C24.

6 USING THE PROGRAMMABLE CONTROLLER CPU MONITORING FUNCTION

7 COMMUNICATIONS BY THE MODEM FUNCTION

8 RECEIVING DATA WITH AN INTERRUPT PROGRAM

9 CHANGING DATA LENGTH UNITS TO BYTE UNITS (WORD/BYTE UNITS SETTING)

10 CHANGING DATA COMMUNICATION MONITORING TIME

11 DATA COMMUNICATIONS USING DC CODE TRANSMISSION CONTROL

12 DATA COMMUNICATIONS USING HALF-DUPLEX COMMUNICATIONS

13 CONTENTS AND REGISTRATION OF USER FRAMES FOR DATA COMMUNICATION

14 ON-DEMAND DATA COMMUNICATIONS USING USER FRAMES

15 DATA COMMUNICATIONS USING USER FRAMES

16 TRANSPARENT CODES AND ADDITIONAL CODES

17 COMMUNICATING WITH ASCII CODE (ASCII-BIN CONVERSION)

18 DATA COMMUNICATIONS BETWEEN TARGET DEVICE AND CPU MODULE IN M:N BASIS

19 SWITCHING THE MODE AFTER STARTING

20 USING SEND/RECEIVE DATA MONITORING FUNCTION

21 INDEPENDENT/LINKED OPERATION OF INTERFACE

22 PARAMETER REGISTRATION TO CPU MODULE

23 RS-422/485 INTERFACE ECHO BACK ENABLE/PROHIBIT SPECIFICATION

25 AUTOMATIC REMOVAL OF NULL CHARACTERS INCLUDED IN SEND DATA

## **6** USING THE PROGRAMMABLE CONTROLLER CPU MONITORING FUNCTION

This chapter explains the programmable controller CPU monitoring function with which the C24 monitors the programmable controller CPU based on the monitoring information reregistered by the user.

## 6.1 Overview

This section explains an overview of the programmable controller CPU monitoring function.

#### Transmitting data without a program

- The programmable controller CPU monitoring function enables C24 to monitor the CPU module on the host station at time intervals set by the user by reregistering data to be used for the programmable controller CPU monitoring function. Data transmission to the target device communicating with the MC or nonprocedural protocol is possible without a program.
- The following monitoring information selected by the user can be sent to the target device as the CPU module monitoring results.

Transmiss ion method	Monitoring result		Without the modem function	Combined use of the modem function (modem communication)	
Data	Devices on the host station CPU module	Numeric value stored in a word device	0	0	
transmission	(information of the device to be monitored)	ON/OFF status of a bit device			
	Status of module of the host station CPU module	•			

• There are two timings for transmitting the programmable controller CPU monitoring results to the target device; fixed cycle send and condition match send.

The fixed cycle send transmits the programmable controller CPU monitoring results each time when CPU module is monitored.

The condition match send transmits when the information read from the CPU module satisfies the defined conditions and when an error is detected in the CPU module.

#### Simplifying device monitoring procedure

When device monitoring is performed by communication using the MC protocol, the target device must repeatedly perform monitor request transmission and monitor data reception processing after it executes monitor registration.

By designating the fixed cycle send for the programmable controller CPU monitoring function, the device data can be monitored without performing the monitor request reception processing.

#### Notifying programmable controller CPU error

In the condition match send, error information can be transmitted to the target device whenever CPU module error occurs without any programming.



6

## 6.2 Programmable Controller CPU Monitoring Function

This section explains the programmable controller CPU monitoring function.

## Data registration for using the programmable controller CPU monitoring function

The following explains the data registration by the user to use the programmable controller CPU monitoring function.

#### Registration procedure for the Programmable Controller CPU monitoring function

Programmable controller CPU monitor registration for C24 that is required to use the programmable controller CPU monitoring function is described in the following sections. The registration can be performed using one of the following methods:

- · Registration with an Engineering tool
- Registration using the programmable controller CPU monitoring registration command (0630) for communication with the MC protocol (LIMELSEC Communication Protocol Reference Manual)
- Registration using the programmable controller CPU "CSET" instruction ( MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks)

#### Combination with modem function

Before transmitting the CPU module monitoring result when used in conjunction with the modem function, register the data for connection of the modem function.

Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ Module Name ⇔ [Module Parameter] ⇔ "Application Settings" ⇔ "Modem function setting"

#### Starting programmable controller CPU monitoring function

By registering the data for using the programmable controller CPU monitoring function, C24 begins monitoring the programmable controller CPU.

### **CPU** module monitoring information

The following explains the monitoring target information used to perform the programmable controller CPU monitoring function.

#### Target of programmable controller CPU monitoring function

The following information can be registered as the target of the programmable controller CPU monitoring function.

- Device monitoring for the host station CPU module Monitoring of the numeric values stored in the word device Monitoring of bit devices ON/OFF status
- · Monitoring status of the host station CPU module

#### Registering word devices and bit devices

For monitoring word and bit devices, up to 960 device points (up to 15360 bits for only bit devices) in total, which is equivalent to 10 blocks in total when any continuous device range comprised one block, can be registered.

Since monitoring of the CPU module status on the host station will be also registered as one block, up to 11 blocks can be registered.

- 11 ≥ (Number of registered word device blocks + Number of registered bit device blocks) + CPU status monitoring (1 block)
- 960 points ≥ (Total number of all word device block points (1 point = 1 word) + Total number of all bit device block points (1 point = 16 bits))

#### Point P

To register the device memory to monitor, designate the word device blocks for the registered word blocks, then designate the bit device blocks for the registered bit blocks.

#### Example for registering word devices and bit devices

The start device of each block is the monitoring target for device monitoring of the blocks for which the word and bit devices are registered.

Ex.

For a block in which 10 points of word devices from D100 to D109 are registered Monitoring target: Numeric value to be stored in D100 Data transmission: Numeric values to be stored in D100 to D109

Ex.

For a block in which two points of bit devices from M100 to M131 are registered Monitoring target: ON/OFF status of M100 Data transmission: ON/OFF status of M100 to M131

#### List of device code

The word and bit devices that can be designated as the monitoring targets and the device codes that are used to register the monitoring devices are listed in the table below.

Register the device	s using the devic	e ranges existing	in the CPU module
---------------------	-------------------	-------------------	-------------------

Category	Device		Device typ	)e	Device co	de	Device range (Default)
			Bit	Word	ASCII	Binary	
Internal system	Special relay		0	—	SM	91H	0 to 4096
	Special register		—	0	SD	A9H	
Internal user	Input		0	—	X*	9CH	0 to 2FFFH
	Output		0	—	Y*	9DH	
	Internal relay		0	—	M*	90H	0 to 12287
	Latch relay	Latch relay Annunciator		—	L*	92H	0 to 8191
	Annunciator			—	F*	93H	0 to 2047
	Edge relay		0	—	V*	94H	
	Link relay		0	—	В*	A0H	0 to 1FFFH
	Data register		—	0	D*	A8H	0 to 18431
	Link register		—	0	W*	B4H	0 to 1FFH
	Timer	Contact	0	—	TS	C1H	0 to 1023
		Coil	0	—	тс	СОН	
		Current value	—	0	TN	C2H	
	Retentive timer	Contact	0	—	SS	C7H	0
		Coil	0	—	SC	C6H	
		Current value	—	0	SN	C8H	
	Counter	Contact	0	—	CS	C4H	0 to 511
		Coil	0	—	СС	СЗН	
		Current value	—	0	CN	C5H	
	Link special relay		0	—	SB	A1H	0 to 7FFH
	Link special register		—	0	SW	B5H	
	Direct input		0	—	DX	A2H	0 to 2FFFH
	Direct output		0	—	DY	A3H	
	Index register		—	0	Z*	ССН	0 to 20
Register	File register		—	0	R*	AFH	0 to 32767
			—	0	ZR	B0H	-



• Designating a non-existent device code will result in an error.

• When the device range in the parameter setting has been changed, the new device range can be set as the programmable controller CPU monitoring target.

### Monitoring timing of CPU module

The following explains the timing for programmable controller CPU monitoring when the programmable controller CPU monitoring function is performed.

To monitor the CPU module, C24 reads the monitoring information (device information and CPU module status information) from the CPU module at the set interval.

#### Cycle time

1 to 65535 (unit: 100 ms/s/min) can be registered.

Use the following formula as a reference when registering the cycle time.

#### When transmitting device data or the programmable controller CPU status

• Cycle time designation > K + SST + PT + DTT

#### When transmitting data in conjunction with the modem function

Cycle time designation > K + SST + PT + DTT + DTTm + MCDT + CDWT
 When modem initialization has not been performed, the modem initialization time will be added. (Performing modem initialization in advance is recommended.)

The items in the formula above is as follows:

- K: 60 ms constant (C24 internal processing time)
- · SST (Sequence scan time): Time required for one scan
- PT (Processing time): Processing time for the "Multiple block batch read word unit command 0406"

For 1 point : 10.2 ms

For 480 points: 21.1 ms

For 960 points: 32.6 ms

 DTT (data transmission time) = 1 ÷ Transmission rate × Number of bit for one byte during transmission × Number of byte for send data

Number of bit for one byte portion during transmission = 1 + Data bit count + Parity bit + Stop bit count (parity bit: Yes = 1, None = 0)

- DTTm (Data transmission delay time by the modem): Depends on the modem specification, line specification, and line status.
- MCDT (modem connection and disconnection time): Depends on the modem specifications, line specifications, and line status.
- · CDWT (Line disconnection wait time): Wait time for disconnecting line
- · Modem initialization time: Depends on the modem specifications.

#### Point P

Since C24 reads the monitoring information (device data, programmable controller CPU status) at the time of the next END process of the CPU module after the cycle time elapses, make the cycle time as long as possible.

The following phenomenon may be occurred if the cycle time is short.

- The number of scan of which CPU module scan time gets longer will be increased.
- The processing time for other data communication functions will be increased due to the increase of the C24 programmable controller CPU monitoring function processing time.
- · The load on the target device will be increased.

### Timings of transmitting monitoring results to the target device

The following explains the timings for the transmission of CPU module monitoring results.

There are two transmission methods for transmitting the monitoring results of the CPU module on the host station to the target device; fixed cycle send and condition match send. One of these methods must be selected by the user during programmable controller CPU monitoring registration.

#### Fixed cycle send

The monitoring results are transmitted each time the monitoring information is read from the CPU module. (Timing to transmit data)



#### **Condition match send**

#### ■Transmission of monitoring results

For device monitoring, the monitoring conditions registered by the user (conditions for sending monitoring results), the monitoring condition values and the monitoring information read from the CPU module are compared. The monitoring results are transmitted when there is a block where the monitoring conditions match.

For programmable controller CPU status monitoring, the monitoring results are transmitted only once when an error is detected for the first time from the status information read from the CPU module. (This corresponds to the edge triggered transmission described below.)

#### Edge triggered/level triggered transmission

Two transmission methods of the monitoring results are available for the condition match send for device monitoring: edge triggered transmission and level triggered transmission.

· Edge triggered transmission

The monitoring conditions registered by the user (conditions for transmitting monitoring results), the monitoring condition values and the monitoring information read from the CPU module are compared. Then, the monitoring results are transmitted only once when a satisfaction of the monitoring conditions is detected for the first time.

After that, when the monitoring information read from the CPU module does not match the monitoring conditions and then it matches the monitoring conditions once again, the monitoring results are transmitted.

· Level triggered transmission

The monitoring conditions registered by the user (conditions for transmitting monitoring results), the monitoring condition values and the monitoring information read from the CPU module are compared. While the monitoring conditions are satisfied, the monitoring results are transmitted at each cycle time.

(Timing to transmit data)



#### ■Monitoring condition

In the condition match send for device monitoring, the start device for each block is the monitoring target for condition monitoring of each block device.

For the condition match send, the monitoring conditions that can be designated for the device to be registered by the user and the registration values when designating the monitoring condition are listed in the table below.

Register the monitoring conditions for the start device of each block using the following table.

Monitoring cond	ition	Registration value	Valid designated device		
		For edge triggered transmissions	For level triggered transmissions	Bit	Word
Device value or statu	us = device monitoring condition value or status	0001H	0101H	0	0
Device value or statu	us ≠ device monitoring condition value or status	0002H	0102H	1	-
Unsigned	Monitoring device ≤ monitoring condition value	0003H	0103H	×	
	Monitoring device < monitoring condition value	0004H	0104H		
	Monitoring device ≥ monitoring condition value	0005H	0105H		
	Monitoring device > monitoring condition value	0006H	0106H		
Signed	Monitoring device ≤ monitoring condition value	0007H	0107H		
	Monitoring device < monitoring condition value	0008H	0108H		
	Monitoring device ≥ monitoring condition value	0009H	0109H		
	Monitoring device > monitoring condition value	000AH	010AH		

#### Monitoring condition value, status

In device monitoring, register the monitoring condition value or status for C24 to judge that the numeric value/status of the monitoring device for condition match send (start device of each block) satisfy the condition with numeric values listed below.

Type of monitoring device	Monitoring condition value or status	Registration value
Bit device	OFF	0000H
	ON	0001H
Word device	Numerical value	0000H to FFFFH

Ex.

Condition satisfies when M0 = ON

Registration value for the monitoring condition: 0001H

Registration value for the monitoring condition value or status: 0001H

Ex.

Condition satisfies when D0 > 100 (signed)

Registration value for the monitoring condition: 000AH

Registration value for the monitoring condition value or status: 100 (64H)

#### Point P

In status monitoring for the CPU module, the monitoring conditions and condition values for condition match send are not registered.

Instead, it is registered whether or not the status monitoring of CPU module will be performed.

Monitoring results in the condition match send are transmitted only once when an error is detected by the status information read from the CPU module for the first time.

## Transmission methods of monitoring results and data transmitted to the target device

This section explains the transmission method of the CPU module monitoring results and the data to be transmitted to the target device.

#### Data transmission to target device communicating with MC protocol

Data is transmitted in the same format as that for a message transmitted with the on-demand function with the on-demand data portion replaced with the device information and programmable controller CPU status information, as explained in "When sending the monitoring results as data during fixed cycle send" or "When sending the monitoring results as data during condition match send" below. (LAMELSEC Communication Protocol Reference Manual)

#### When the interface that uses the modem function is set to the MC protocol

The connection processing and disconnection processing to the modem are performed when the programmable controller CPU monitoring results are transmitted.



#### When the transmission of on-demand data using user frames is designated

Data is transmitted in the transmission format for on-demand data using a user frame with the on-demand data portion replaced with the device information and programmable controller CPU status information, as explained in "When sending the monitoring results as data during fixed cycle send" and "When sending the monitoring results as data during condition match send" below.

See the following explanation for data reception for the target device side.

- Device information, programmable controller CPU status information arrangement (LD MELSEC Communication Protocol Reference Manual)
- Arrangement of data in the user frame portion to be transmitted (SP Page 267 ON-DEMAND DATA COMMUNICATIONS USING USER FRAMES)

#### When transmitting the monitoring results as data during fixed cycle send

Data equivalent to the entire blocks of the monitoring target device information and programmable controller CPU status information is transmitted in batch.

#### When transmitting the monitoring results as data during condition match send

The device information for a block which the monitoring conditions are matched and the programmable controller CPU status information at an occurrence of an error are transmitted with the head data (header) and last data (footer) for the on-demand function added for each block.

Transmission is performed in the order of the programmable controller CPU status information, the device information registered in the word block, and then the device information registered in the bit block.

#### Point P

When data is communicated using the MC protocol format 1 to 4, all of the device monitoring start device number is converted to hexadecimal ASCII data and transmitted. (The same conversion is performed during either fixed cycle send or condition match send.)

#### Data transmission to target device communicating with nonprocedural protocol

The device information and CPU information are transmitted by the word/byte unit designation.

#### When ASCII-BIN conversion for communication data is designated

Data is converted to ASCII code data and transmitted. (The transmission example is shown in the "Device information and programmable controller CPU status information".)

- · When the word/byte units designation is set to word
- The device information and CPU information is transmitted by 1-word in the order of (H) and (L).
- When the word/byte units designation is set to byte
   The device information and CPU information is transmitted by 1-word in the order of (L) and (H).

#### When the interface that uses the modem function is set to the nonprocedural protocol

The connection processing and disconnection processing to the modem are performed when the programmable controller CPU monitoring results are transmitted.



#### When transmitting monitoring results as data during fixed cycle send

The device information of one or more user frame numbers and programmable controller CPU status information that have been currently designated for the fixed cycle send in C24 is transmitted in batch.

#### When transmitting the monitoring results as data during condition match send

The device information of one or more user frame numbers and programmable controller CPU status information that have been currently designated for the condition match send of the block where the monitoring conditions satisfied in C24 is transmitted in batch.

When the monitoring conditions of two or more blocks match, the device information and programmable controller CPU status information are transmitted for each block.

#### Point P

When the ASCII-BIN conversion for the communication data using the nonprocedural protocol is performed, all of the device monitoring start device number is converted to hexadecimal ASCII data and transmitted. (The same conversion is performed during either fixed cycle send or condition match send.)

## The user frame numbers that can be designated for data transmission of programmable controller CPU monitoring results

- 1H to 3E7H (Default registration frame numbers)
- 3E8H to 4AFH (Frame numbers registered by the user in the flash ROM)
- 8001H to 801FH (Frame numbers registered by the user in the buffer memory)
- B001H to B01FH (Dedicated frame numbers for this function) ( Page 129 Transmission instruction of device information and programmable controller CPU status information when transmitting the monitoring results)

For details on how to designate user frame numbers, refer to the following section.

Page 276 DATA COMMUNICATIONS USING USER FRAMES

## Transmission instruction of device information and programmable controller CPU status information when transmitting the monitoring results

Use the following dedicated user frame numbers.

Frame No.	Information to be transmitted		Valid function	
			Fixed cycle send	Condition match send
B001H	Device information for the block registered in	Number 1	0	0
B002H	number n	Number 2		
B003H		Number 3		
B004H		Number 4		
B005H		Number 5		
B006H		Number 6		
B007H		Number 7		
B008H		Number 8		
B009H		Number 9		
B00AH		Number 10		
B061H	Programmable controller CPU status informati monitoring data)	ion (CPU error	0	0
B080H	Number of blocks to be sent		0	0
B081H	Monitoring result information for all blocks			
B082H	Monitoring result information for blocks satisfy	ing the conditions	×	0

#### Device information and programmable controller CPU status information

It is transmitted in the order of data shown below.

IP Page 130 Data arrangement of device information and programmable controller CPU status information

For ASCII-BIN conversion, set "ASCII-BIN conversion designation" to "ON".

When user frame is designated with the number, of which bit 14 for the numeric value indicating the user frame number is ON, ASCII-BIN conversion of the corresponding send data is not performed. It will be transmitted as binary data. (

ASCII-BIN Conversion for Data Communicated with Nonprocedural Protocol)

6

## Data arrangement of device information and programmable controller CPU status information

#### When user frame numbers B001H to B00AH are designated (example for one block)

#### When word device data (W100 to W103, (4 points)) is transmitted

When the word/byte units designation is set to word unit, the device data will be transmitted in the order of  $(H) \rightarrow (L)$ . The number of registered points is the number of points in word units.

• (When ASCII-BIN conversion is not performed)

The total number of bytes for the device data portion is the number of device points  $\times$  2. When the word/byte units designation is byte When the word/byte units designation is word





• (When ASCII-BIN conversion is performed)

The total number of bytes for the device data portion is the number of device points  $\times$  4.

When the word/byte units designation is byte



When the word/byte units designation is word



#### When data for bit device (M16 to M175, (10 point)) is transmitted

When the word/device units designation is set to word unit, the device data will be sent in the order of  $(H) \rightarrow (L)$ . The number of registered points is the number of points in word units.

• (When ASCII-BIN conversion is not performed)

The total number of bytes for the device data portion is the number of device points  $\times$  2.

When the word/byte units designation is byte





• (When ASCII-BIN conversion is performed)

The total number of bytes for the device data portion is the number of device points  $\times 4$ .

When the word/byte units designation is byte

Device code	Monitoring start device	Number of registered points	Device data		Device data
H L M *	H <u> </u>	H <u>—</u> — L O O O A	L <u>—</u> — H 3 0 1 1		L <u>—</u> H 1 2 3 4
4Dн 2Aн	30н 30н 30н 30н 31н 30н	30н 30н 30н 41н	33н 30н 31н 31н	·//	31н 32н 33н 34н



When the word/byte units designation is word



6

#### When user frame No. B061H is designated

Programmable controller CPU status information (for one block) is transmitted as the following data:

Item		Communicating with ASCII code	Communicating with binary code	Remarks
Device code		'01'	01H	All fixed value
Number of registere	d points	'0001'	0001H	
Monitoring start dev	ice	'000000'	000000H	
Device data	During normal operation	'0000'	0000H	Ì
	Module warning occurring	'0001'	0001H	
	Module error/module system error occurring	'0002'	0002H	

Device

Moni

• (When ASCII-BIN conversion is not performed)

The total number of bytes for the device data portion is the number of device points  $\times$  2. When the word/byte units designation is byte When the word/byte units designation is word



· (When ASCII-BIN conversion is performed)

The total number of bytes for the device data portion is the number of device points × 4. When the word/byte units designation is byte When the word/byte units designation is word

Device code				Monitoring start	device	Ι			Number of	registered points	I		etch echica C	Device data	
н	L	н	—	—	—	—	L	н	—	—	L	L	—	—	н
0	1	0	0	0	0	0	0	0	0	0	1	0	1	0	0
30н	31н	30н	30н	30н	30н	30н	30н	30н	30н	30н	31н	30н	31н	30н	30н

١	Vhe	en	th	e v	voi	rd/	byt	eı	uni	ts	de	sig	Ina	itio	n is	5
	Device code			Ι	Monitoring start	device	I			Number of	registered points	I		Device data		
	н	L	н	—	—	—	—	L	н	—	—	L	н	—	—	
	0	1	0	0	0	0	0	0	0	0	0	1	0	0	0	

registered point:

Number of

Device (

н

30H31H 30H30H30H30H30H30H30H30H30H30H31H

#### When user frame No. B080H is designated

The transmission block is transmitted as follows.

#### Ex.

Number of registered word blocks: 2 (D0 to D3 (4 points), W100 to W107 (8 points))

Number of registered bit blocks : 1 (M0 to M31 (2 points))

(When ASCII-BIN conversion is not performed)



Number of registered	word blocks	Number of registered	bit blocks	CPU abnomal	monitoring
н	L	н	L	н	L
0	2	0	1	0	0
30H	32H	30H	31H	30H	30H

(When ASCII-BIN conversion is performed)

#### When user frame No. B081H is designated

The information on monitoring results for all blocks are sent as shown below.

Results are transmitted in the order of the device information registered in the word block, the device information registered in the bit block, and the programmable controller CPU status information.

#### Ex.

Number of registered word blocks: 1 (W100 to W103 (4 points))

Number of registered bit blocks : 1 (M0 to M15 (1 point))

Perform CPU status monitoring : 1 (1 point)

(When ASCII-BIN conversion is not performed)

The total number of bytes for the device data portion is the number of device points  $\times$  2.

When the word/byte units designation is byte





When the word/byte units designation is word

001011001         000100100         000100100         000100100         000100100         000100100           000100100         000100100         000100100         000100100         000100100         000100100         000100100           000100100         000100100         000100100         000100100         000100100         000100100         000100100           000100100         0001000         0001000         0001000         0001000         0001000         0001000           0001000         0001000         0001000         0001000         0001000         0001000         0001000           0001000         0001000         0001000         0001000         0001000         0001000         0001000           0001000         0001000         0001000         0001000         0001000         0001000         0001000           0001000         0001000         0001000         0001000         0001000         0001000         0001000           0001000         0001000         0001000         0000000         0000000         0000000         0000000           0001000         0000000         00000000         00000000         000000000         00000000         00000000           0000000000000         00000000000000000000000000000	C			
Monitoring start         Monitoring start           01100         H00         H0	00H	L		
ненист         Повиденсе содение           000	01H		Monitoring start device	
ННЯ         Овечисе собе           041100         НО         НО         Почисе собе           040100         НО         Н         Почисе собе           040100         Н         Н         Н           040100         Н         Н         По           040100         Н         Н         Н           040100         Н         Н         Н           040100         Н         Н         Н           040100         Н         Н         Н      <	00H	Н		
Онноо         Нитирег of registered points           1         1	B4H	(W)	Device code	
000         000 <td>04H</td> <td>L</td> <td>Number of</td> <td>   </td>	04H	L	Number of	
000         000 <td>00H</td> <td>Н</td> <td>registered points</td> <td></td>	00H	Н	registered points	
000         00         00         00	00H	н		
100 H00 H00 H00 H00 H00 H00 H00 H00 H00	00H	L		
100 H00 H00 H10 H10 H10 H00 H00 H100 H1	00H	Н		
оон ноо ноо ноо ноо ноо ноо ноо ноо ноо	01H	L	ateb active C	
100 H00 H00 H00 H00 H00 H00 H00 H00 H00	00H	Н	Device data	
100 H00 H10 H10 H10 H00 H00 H00 H00 H00	02H	L		
000 H000 H000 H000 H000 H000 H000 H000	00H	Н		
100         100           100         100	03H	L		I I
Монионистия start         Монионистия start           Половина         Н         Монионистия start           Половина         Н         Вейсе           Половина         П         Вейсе           Половина         Половина         Половина	00	L		
1         1	1 00H	_	Monitoring start device	1
PH06         WM         Device code           1110         1         Number of sistered points         1           1111         1         Number of of sistered points         1           1111         1         1         Number of of sistered points         1           111         1         1         1         1         1           111         1         1         1         1         1           111         1         1         1         1         1           111         1         1         1         1         1         1           111         1	00H	н		
110     110       1110     1       1110	90H	(M)	Device code	
1         1	01H	L	Number of	
НПГ         Device data           111         00           100         000           111         0           111	00H	н	registered points	
100         100         100         100           100         100         100         100         100           100         100         100         100         100           100         100         110         110         110           1         1         1         1         1           100         100         100         110         110	11H	н	Device data	
1000 1000	30H	L		
Monitoring start         Monitoring start           device         device           device         Device code           H         Number of           H         Pevice code           H         Device code	00H	L		
1         1         1         1           1         1         Device code         1           1         1         Number of         1           1         1         1         1           1         1         1         1           1         1         1         1           100         1400         1400         1400	00H	_	Monitoring start device	
Device code Device code H Number of H registered points H Device data H 000 H 0110 H 0100 H 01000 H 0100 H 0100 H 01000 H 0100 H 0100 H 0100 H	00H	Н		
Number of Number of H registered points H H C Device data	01H		Device code	
100 H Registered points Pevice data – Device data –	01H	L	Number of	
1 H Device data	00H	Н	registered points	
L L	00H	Н	Device data	
	001	L	Device data	

W100 W101 W102 W103

1									-						
	1	I	_			1	_,		3	3	_		(	)	_,
0	0	0	1	0	0	0	0	0	0	1	1	0	0	0	0
Μ	М	Μ	М	Μ	Μ	М	Μ	Μ	Μ	Μ	Μ	Μ	М	Μ	Μ
1	1	1	1	1	1	0	0	0	0	0	0	0	0	0	0
5	4	3	2	1	0	9	8	7	6	5	4	3	2	1	0

• (When ASCII-BIN conversion is performed)

The total number of bytes for the device data portion is the number of device points  $\times 4$ .

When the word/byte units designation is byte



#### When user frame No. B082H is designated

Information on the monitoring results for the condition matched blocks are transmitted for each block.

Results are transmitted in the order of the programmable controller CPU status information, the device information registered in the word block and then the device information registered in the bit block.

#### Ex.

Number of registered word blocks: 2 (D0 to D3 (4 points), W100 to W103 (4 points))

Number of registered bit blocks : 1 (M0 to M15 (1 point))

When the condition satisfied monitoring device is W100 = 0 and M0≠ON

· (When ASCII-BIN conversion is not performed)

The total number of bytes for the device data portion is the number of device points  $\times$  2. When the word/byte units designation is byte

For W100 to W103 block data





3 0 0 0 1 1 0 0 0 0 0 0 1 0 0 0 1 

#### When the word/byte units designation is word For W100 to W103 block data





For M0 to M15 block data



• (When ASCII-BIN conversion is performed)

The total number of bytes for the device data portion is the number of device points  $\times 4$ .

When the word/byte units designation is byte For W100 to W103 block data

For M0 to M15 block data



## When the word/byte units designation is word For W100 to W103 block data

For M0 to M15 block data



## Execution order for using the programmable controller CPU monitoring function

This section explains the execution order to use the programmable controller CPU monitoring function.

• When transmitting the monitoring results with the modem function, configure the following settings in order to use the modem function.

Setting item	Reference
Initial setting using the Engineering tool	Page 174 Initial settings of Serial communication module
Registration of data number for initialization and data number for connection	Page 177 Register/read/delete data for initialization Page 181 Register/read/delete data for connection
Initialization of C24 modem/TA	Page 185 Initialization of modem/TA (terminal adapter)

• Register programmable controller CPU monitoring for C24 using one of the methods shown below. Registration with Engineering tool

Registration using the programmable controller CPU monitoring registration command (0630) for communication with the MC protocol (L) MELSEC Communication Protocol Reference Manual)

Registration by the dedicated instruction for the CPU module (CSET) (LMELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks))

- By registering programmable controller CPU monitoring, C24 monitors the CPU module on the host station regardless of the RUN/STOP status and sends the monitoring information to the target device.
- When reregistering programmable controller CPU monitoring in order to change the registration data for the programmable controller CPU monitoring, reregister after canceling the programmable controller CPU monitoring.
   When registering with communication using the MC protocol (L MELSEC Communication Protocol Reference Manual) When registering by "CSET" instruction for the CPU module (L MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks))

To cancel by using Engineering tool, set the CPU module in the STOP status first to configure the settings again, and then restart the CPU module.

# 6.3 Settings for Using the Programmable Controller CPU Monitoring Function

This section describes system settings required for fixed cycle send and condition match send.

## Parameter setting items for the programmable controller CPU monitoring function

The following explains parameter setting items for the programmable controller CPU monitoring function. Configure the parameter settings.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module Name ⇒ [Module Parameter] ⇒ "Application Settings" ⇒ "Programmable Controller CPU monitoring function setting"

#### Point P

- Register send user frames by Engineering tool, after checking the specifications and setting methods explained in the following sections. (SP Page 250 CONTENTS AND REGISTRATION OF USER FRAMES FOR DATA COMMUNICATION, Page 276 DATA COMMUNICATIONS USING USER FRAMES)
- Register connection data for the modem function by Engineering tool, after checking the specifications in the following section. (Section Page 182 Method to register/read/delete data for connection)

#### Setting items and requirement for communication using the MC protocol

#### $\bigcirc$ : Required, $\times$ : Not required

Setting item			Fixed cycle send	Condition match send	Reference
Programmable controller	rogrammable controller CPU monitoring function designation			0	Page 139 Programmable controller CPU monitoring function designation
Cycle time units designat	ion		0	0	Page 139 Cycle time units designation
Cycle time designation (Programmable controller CPU monitoring interval time)			0	0	Page 139 Cycle time designation (Programmable controller CPU monitoring interval time)
Send pointer designation	Send pointer designation Dutput quantity designation Block monitoring device Registered word block quantity designation Registered bit block quantity designation		×	×	Page 141 Setting items for
Output quantity designation					transmitting monitoring results
Block monitoring device			0	0	Page 140 Registered word block
					quantity designation, Registered bit block quantity designation
	CPU error monito	ring designation			Page 140 CPU error monitoring designation
	n-th block	Monitoring device designation	_		Page 140 Monitoring device
	monitoring	Start device No. specification			designation, start device number
	device	Number of read points specification			designation, number of read points designation
Monitoring condition value designation (judgment condition designation) Monitoring condition specification Send pointer designation		Monitoring condition value designation (judgment condition designation)	×		Page 140 Monitoring condition specification (Judgment condition specification)
		Monitoring condition specification			Page 140 Monitoring condition value designation
			×	Page 141 Setting items for	
	Output quantity designation				transmitting monitoring results
	CPU error	Send pointer designation			Page 141 Setting items for
	monitoring designation	Output quantity designation			transmitting monitoring results

\*1 n=1 to 10

#### Setting items and requirement for communication using the nonprocedural protocol

○: Required, ×: Not required

Setting item			Fixed cycle send	Condition match send	Reference	
Programmable controller CPU monitoring function designation			0	0	Page 139 Programmable controller CPU monitoring function designation	
Cycle time units designat	ion		0	0	Page 139 Cycle time units designation	
Cycle time designation (programmable controller CPU monitoring interval time)			0	0	Page 139 Cycle time designation (Programmable controller CPU monitoring interval time)	
Send pointer designation			0	×	Page 141 Setting items for	
Output quantity designation	on				transmitting monitoring results	
Block monitoring device	Registered word block quantity designation		0	0	Page 140 Registered word block quantity designation, Registered bit block quantity designation	
	Registered bit block quantity designation					
	CPU error monitoring designation				Page 140 CPU error monitoring designation	
	n-th block monitoring device <sup>*1</sup>	Monitoring device designation			Page 140 Monitoring device designation, start device number designation, number of read points	
		Start device No. specification				
		Number of read points specification			designation	
		Monitoring condition value designation (judgment condition designation)	×		Page 140 Monitoring condition specification (Judgment condition specification)	
		Monitoring condition specification			Page 140 Monitoring condition value designation	
		Send pointer designation			Page 141 Setting items for transmitting monitoring results	
		Output quantity designation				
	CPU error	Send pointer designation			Page 141 Setting items for	
	monitoring designation	Output quantity designation			transmitting monitoring results	

\*1 n=1 to 10

#### **Contents of setting items**

The following shows the data setting items with Engineering tool and the setting contents to use the programmable controller CPU monitoring function.

#### ■Programmable controller CPU monitoring function designation

Designate the timing (fixed cycle send or condition match send) when transmitting information on the programmable controller CPU monitoring results (device information/CPU status information) to the target device.

• The conditions for condition match send are designated using data items in "Monitoring condition specification (Judgment condition specification)" and "Monitoring condition value designation".

#### ■Cycle time units designation

- Designate the unit for cycle time for reading information from the CPU module using the programmable controller CPU monitoring function.
- The time designated by "Cycle time units designation" and "Cycle time designation (programmable controller CPU monitoring interval time)" is also used as the transmission time interval for fixed cycle send.

#### **Cycle time designation (Programmable controller CPU monitoring interval time)**

Designate the time for one cycle when reading information from the CPU module in order to perform programmable controller CPU monitoring function.

• The time designated for "Cycle time designation (Programmable controller CPU monitoring interval time)" is also used as the transmission time interval for fixed cycle send.

#### ■Registered word block quantity designation, Registered bit block quantity designation

Designate the number of word device blocks (number of registered word blocks) and the number of bit device blocks (number of registered bit blocks) registered in C24 as the target when performing device data monitoring or transmission.

#### ■CPU error monitoring designation

Designate whether or not C24 monitors abnormality of the CPU module on the host station (status monitoring) in the programmable controller CPU monitoring.

## Monitoring device designation, start device number designation, number of read points designation

When performing device data monitoring or transmission, designate the device range for each block for the number of blocks designated by "Registered word block quantity designation" and "Registered bit block quantity designation".

The target of device data monitoring for condition match send is the start device for each block.

Word device designated block: Head word device (for one word)

Bit device designated block : Head bit device (for one bit)

- The monitored device is the item that indicates the target device of the corresponding block and designated with the codes below. (
- The start device is the data that designates the head of the target device range for the corresponding block.
- The number of read points (number of registered point) is the item that indicates the target device range for the corresponding block which designate points from the start device number.
   The bit device designates points in word units (1 point = 16 bits).
- The methods for designating these data are the same as the designation methods used when reading from or writing to the device memory, which are described in the following manual.

(CD MELSEC Communication Protocol Reference Manual)

#### Point *P*

When the user performs the programmable controller CPU monitoring registration, the device No. will designated in either a decimal or hexadecimal depending on devices. The number of read points (number of registered points) are designated in hexadecimal.

However, for data communication using either MC protocol (format 1 to 4) or nonprocedural protocol, when ASCII-BIN conversion of the communication data has been designated, the start device number for all devices to be transmitted to target devices as the monitoring results will be converted to hexadecimal ASCII data and transmitted.

#### Monitoring condition specification (Judgment condition specification)

When the condition match send is designated by the "Programmable controller CPU monitoring function designation", designate the conditions for transmitting information for the "Monitoring condition value designation".

#### Monitoring condition value designation

When the condition match send is designated by the "Programmable controller CPU monitoring function designation", this data designates the status/numeric value for "Monitoring condition specification (Judgment condition specification)".

- When the monitoring device is a word device: Designate the monitoring condition value with a numeric value
- When the monitoring device is a bit device : Designate the monitoring condition with a numeric value (1/0) corresponding to ON/OFF.

#### Setting items for transmitting monitoring results

The following shows an example of setting items and data transmission when sending the monitored results of the programmable controller CPU monitoring function to the target device using the nonprocedural protocol.

#### Ex.

This example shows when the D0 to D3 device information and user frame data are transmitted by the edge triggered transmission method with a condition of D0 = 0.

The setting is configured in the parameters of Engineering tool.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module Name ⇒ [Module Parameter] ⇒ "Application Settings" ⇒ "Programmable Controller CPU monitoring function setting"

Setting item		Setting content	Remarks	
Programmable controller CPU m	onitoring function design	Condition match send	Settings other than those listed at left are not required	
Cycle time units designation		min		
Cycle time designation (Program	mable controller CPU me	3		
Block monitoring device	Registered word block	quantity designation	1	
	Registered bit block qu	antity designation	0	
	CPU error monitoring d	esignation	Do not monitor	
	1st block monitoring device	Monitoring device designation	D	
		Start device number designation	0	
		Number of read points specification	4	
		Monitoring condition specification (Judgment condition specification)	=(Edge)	
		Monitoring condition value designation	0	
		Send pointer designation	49	
		Output quantity designation	3	

#### · Setting the send user frames

Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ Module Name ⇔ [Module Parameter] ⇔ "Application Settings" ⇔ "User frame specification"

Transmission frame No. designation 46th	User frame number	
Transmission frame No. designation 47th	User frame number	
Transmission frame No. designation 48th	User frame number	
Transmission frame No. designation 49th	User frame number (02H)	<ul> <li>Set the user frame data (STX)</li> </ul>
Transmission frame No. designation 50th	User frame number (B001H)	<ul> <li>Set the first block (from D0 to D3)</li> </ul>
Transmission frame No. designation 51th	User frame number (03H)	<ul> <li>Set the user frame data (ETX)</li> </ul>
Transmission frame No. designation 52th	User frame number	
Transmission frame No. designation 53th	User frame number	
Transmission frame No. designation 54th	User frame number	
Transmission frame No. designation 55th	User frame number	
Transmission frame No. designation 56th	User frame number	
Transmission frame No. designation 57th	User frame number	

Data sent when the condition D0 = 0 is satisfied

ETX	Device data (D3)	Device data (D2)	Device data (D1)	Device data (D0)	STX		Target device
-----	------------------------	------------------------	------------------------	------------------------	-----	--	---------------

## How to register and cancel the programmable controller CPU monitoring function

The following shows the method to register/cancel the programmable controller CPU monitoring function from the CPU module.

Point P

• For details on the method for registering or canceling the programmable controller CPU monitoring with a command of MC protocol, refer to the following manual.

(C MELSEC Communication Protocol Reference Manual)

#### When registering or canceling from the CPU module

For details on the CSET command, refer to the following section.

Page 520 Dedicated Instructions

Registering programmable	controller Creat	e control co	ode data from D0	0		
Program	Scan	END processing	Scan	END processing	Scan	END processing
CSET instruction		struction ex	ecution	1       	1       	1         
Completion device				•	1 1 1 1	
Completion device +1			)	At abno	ormal completion	
CPU module		Settin	ng processing			

- Store the data for programmable controller CPU monitoring registration in the device that designates the control data for the CSET instruction.
- Execute the CSET instruction.

At the end of the scan in which the CSET instruction was completed, the completion device (M0) designated by (D2) turns ON and then turns OFF at the next END processing.

• When an error occurs, (D2) + 1 turns ON and the error code is stored in the completion status (S2) + 1.
#### ■Program example for performing programmable controller CPU monitoring registration

This example shows a program that registers programmable controller CPU monitoring for the CH1 side interface. This registration is for transmitting the contents of M0 to M15 and D100 to D109 to the target device using the fixed cycle send (cycle time is 3 min).

Category	Setti	etting content							
Label to be defined	Define	e the global label as shown belo	ow.						
		Label Name	Data Type		Class		Assign (Device/Label)		
	1 bRegistrationCommand		Bit		VAR_GLOBAL	•	X24		
	2 bnCSETInstructionCompleteDevice		Bit(01)		VAR_GLOBAL	•	MO		
	3	bRegistrationCommandDevice	Bit		VAR_GLOBAL	•	M30		
	4	bReq_CSETInstructionExecution	Bit		VAR_GLOBAL	•	M31		
	5	bCSETInstructionNormalCompleteFlag	Bit		VAR_GLOBAL	•	M35		
	6	bCSETInstructionAbnormalCompleteFlag	Bit		VAR_GLOBAL	•	M36		
	7	wnCSETInstructionControlData	Word [Signed](025)		VAR_GLOBAL	•	DO		
	8	wDummy	Word [Signed]		VAR_GLOBAL	Ŧ	D200		

(0)	bRegistrationComm and X24					PLS	bRegistrationCommar Device M30
(3)	bRegistrationComm andDevice M30	bCSETInstructionN ormalCompleteFlag M35			MOV	КО	wnCSETInstructionCo
(0)		<u>17</u>			WOV		D0
					 MOV	К2	wnCSETInstructionC trolData[2] D2
					MOV	K2	wnCSETInstructionC trolData[3] D3
		*****			MOV	КЗ	wnCSETInstructionC
			 		MOV		troiData[4] D4
					 MOV	K1	wnCSETInstructionC trolData[5] D5
					MOV	KO	wnCSETInstructionC trolData[6] D6
					MOV	K1	wnCSETInstructionC trolData[7]
		-			MOV	К2	wnCSETInstructionC trolData[8] D8
					MOV	К1	wnCSETInstructionC trolData[10]
					 MOV	K1	wnCSETInstructionC troIData[11] D11
					MOV	H0A8	wnCSETInstructionC troIData[13]
			 	 			D13
					 MOV	K100	wnCSETInstructionC troIData[14] D14
					MOV	КО	wnCSETInstructionC trolData[15]
				 			D15
		·			MOV	K10	wnCSETInstructionC trolData[16] D16

	1	1	1							
				 	 			MOV	H90	wnCSETInstructionCon trolData[22] D22
								MOV	К0	wnCSETInstructionCon trolData[23] D23
				 	 			MOV	К0	wnCSETInstructionCon trolData[24] D24
								-		
				 				MOV	K1	wnCSETInstructionCon trolData[25] D25
				 					SET	bReq_CSETInstructionE xecution M31
									RST	bRegistrationCommand Device M30
(43)	onExecution M31				ZP.CSET	U0	К1	wnCSETInstructi onControlData[0] D0	wDummy D200	bnCSETInstructionCom pleteDevice[0] M0
(54)	bnCSETInstruction CompleteDevice[0] M0	bnCSETInstruction CompleteDevice[1] M1							SET	bCSETInstructionNorm alCompleteFlag M35
		hnCSETInstruction		 	 					
		CompleteDevice[1] M1		 					SET	bCSETInstructionAbnor malCompleteFlag M36
									RST	bReq_CSETInstructionE xecution M31
(63)										
										(END.)

(0) Convert the registration command into pulse.

#### (3) Set the execution type.

Set the execution type (Programmable controller monitoring registration).

Set the unit of the cycle time to 'Minute'.

Set the cycle time to three minutes.

Set the monitoring function to fixed cycle send.

Set the transmission method to data transmission.

Set the output start pointer.

Set the number of the user frame to be transmitted.

Set the number of registered word blocks designation to '1'.

Set the number of registered bit blocks designation to '1'.

Register the device of D100 to D109 as the first block.

Register the device of M0 to M15 as the second block.

(43) Execute the programmable controller CPU monitoring registration.

#### (54) Processing for normal completion or abnormal completion

#### ■Program example for performing programmable controller CPU monitoring cancellation

This example shows a program that cancels programmable controller CPU monitoring for the CH1 side interface

Category	Setti	tting content					
Label to be defined	Defin	e the global label as shown bel	ow.				
		Label Name	Data Type		Class		Assign (Device/Label)
	1	bRegistrationCommand	Bit		VAR_GLOBAL	-	X25
	2	bnCSETInstructionCompleteDevice	Bit(01)		VAR_GLOBAL	-	MO
	3	bReq_CSETInstructionExecution	Bit		VAR_GLOBAL	-	M37
	4	bCSETInstructionNormalCompleteFlag	Bit		VAR_GLOBAL	-	M35
	5 bCSETInstructionAbnormalCompleteFlag		Bit		VAR_GLOBAL	٠	M36
	6	wnCSETInstructionControlData	Word [Unsigned]/Bit String [16-bit](02)		VAR_GLOBAL	٠	DO
	7	wDummy	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D200

(0)	bRegistrationComm and X25							PLS	bReq_CSETInstructio nExecution M37
(3)	bReq_CSETInstruct ionExecution M37	bCSETInstructionNor malCompleteFlag M35					MOV	KO	wnCSETInstructionC ontrolData[0] D0
							MOV	K3	wnCSETInstructionC ontrolData[2] D2
				ZP.CSET	U0	K1	wnCSETInstruction ControlData D0	wDummy D200	bnCSETInstructionC ompleteDevice M0
(19)	bnCSETInstruction CompleteDevice[0] M0	bnCSETInstructionC ompleteDevice[1] M1						SET	bCSETInstructionNor malCompleteFlag M35
		bnCSETInstructionC ompleteDevice[1] M1						SET	bCSETInstructionAb normalCompleteFlag M36
(26)						5			(END )

(0) Set the command pulse.

(3) Execute the programmable controller CPU monitoring registration.

(19) Processing for normal completion or abnormal completion

6

## 6.4 Considerations for Using the Programmable Controller CPU Monitoring Function

#### Influence on the cycle time

The cycle time will be affected by the following factors.

Keep these in mind when setting the cycle time.

- When the programmable controller CPU is accessed by a module other than C24.
- When a data communication function other than the programmable controller CPU monitoring function is used.
- When transmission interruption occurs by DTR/DSR control.

#### Mixing of fixed cycle send and condition match send

Both of the fixed cycle send and the condition match send cannot be designated together for the same interface.

#### Target CPU module

Only the CPU module on the host station can be the target for the programmable controller CPU monitoring function.

#### **Registration during operation**

A new programmable controller CPU monitoring registration cannot be performed while the programmable controller CPU monitoring function is in operation.

- Perform the new programmable controller CPU monitoring registration after canceling the programmable controller CPU monitoring.
- If the programmable controller CPU monitoring registration is performed without canceling the monitoring, an error will occurs.

Before performing the programmable controller CPU monitoring registration with Engineering tool, set the CPU module in the STOP state, and then restart the CPU module.

#### Error during operation

While the programmable controller CPU monitoring function is in operation, even if an error occurs in transmission of the CPU module monitoring results or reading of data from the CPU module, the programmable controller CPU monitoring function operation will not stop.

#### System configuration

The programmable controller CPU monitoring function can be used when the system configuration is in a 1:1 basis.

#### Operation when information cannot be transmitted to target device

The following describes how C24 operates when the information of the programmable controller CPU monitoring results cannot be sent to the target device due to line disconnection or other reasons.

Even if an error occurs while the programmable controller CPU monitoring function is in operation, the ERR LED does not turn ON. (This is the same as when using the on-demand function of the MC protocol.)

#### When the setting for the send monitoring time designation (timer 2) is 'Unlimited wait' (0H)

- Reading of monitoring data from the CPU module stops until the transmission of the monitoring data is completed.
- When transmission resumes, reading of monitoring data from the CPU module resumes and monitoring data and information are transmitted.
- ■When the setting for the send monitoring time designation (timer 2) is other than 'Unlimited wait' (0H)
- A transmission timeout error occurs. Reading of monitoring information from the CPU module and transmission of the information resumes.
- The error code is stored in the 'programmable controller CPU monitoring function execution result (current)' (Un\G8709/ 8965).

#### When CPU module error occurs

When device data for the programmable controller CPU cannot be read because of a CPU module error (hardware failure, etc.), the error code is stored in the programmable controller CPU monitoring function error code storage area and C24 performs the monitoring processing based on previously read data.

#### Modem connection error

When the monitoring information is transmitted with the modem function, a modem connection error will occur if a modem connection request is issued for the following reason.

Connection request by the 'connection request' (Y11)

If possible, provide a dedicated C24 for using the programmable controller CPU monitoring function.

When using both the programmable controller CPU monitoring function and data communication function with a single C24 and one of the above modem connection errors occurs, re-execute a connection request in consideration of the transmission timing set by the user for the programmable controller CPU monitoring function.

# 7 COMMUNICATIONS BY THE MODEM FUNCTION

This chapter explains the overview and how to use the modem function, which can be used for data communication with remote target devices.

For the transmission specification on C24 side, connectable modems/TA's (terminal adapter) for the usage of the modem function, refer to the following manual.

MELSEC iQ-R Serial Communication Module User's Manual (Startup)

## 7.1 Overview

The modem function easily performs data transmission/reception to remote devices via public lines/office telephone systems/ digital lines (ISDN) by connecting a modem or TA (terminal adapter) to RS-232 interface of C24.

Initialization of the modem or TA, line connection (dialing), and modem disconnection are performed by CPU module.

Once the line is connected, data communication with the target device via public line/office telephone system/digital line can be performed.



\*1 TA indicates the abbreviation for the terminal adapter.

Point P

The modem function does not support dedicated lines.

When transmitting/receiving data via dedicated line, prepare a modem having an automatic connection function and supporting dedicated lines.

Since the data can be transmitted/received without using the modem function when transmitting/receiving data via a modem having an automatic connection function and supporting dedicated lines, this chapter can be skipped.

Automatic connection function: Indicates a function for connecting to the modem of the target device automatically. (The function name varies depending on the manufacturer of the modem.)

## Features

The following explains the features of the modem function.

#### Interface that can use the modem function

- The modem function can be used with an RS-232 interface of C24.
- For the RJ71C24-R2, the modem function can be used for only one of the two RS-232 interfaces. With the other interface of C24, direct data communication with a target device can be performed using MC protocol, nonprocedural protocol, or bidirectional protocol (independent operation).

0	← Communication using the modem function
	← Communication without using the modem function

#### Initialization/connection/disconnection of modem or TA

• The following setting value for line connection can be used by registering in the module extended parameter or flash ROM of C24 in multiple sets.

Data for Modem/TA initialization (AT command)

User setting: 30 sets (78 bytes/set), default value: 13 sets

Data for connection

User setting: 30 sets (80 bytes/set) (display message to telephone number of the connection destination, line type, etc.)

- By registering the above data to C24 in advance, the modem/TA (terminal adapter) initialization, line connection (dialing), and line disconnection can be performed easily.
- When the no-communication interval time (1 min to 120 min) is set, C24 disconnects the line when a no-communication condition continues for the set period of time following the line connection.

#### Communication between remote device and CPU module

- · Data communication can be performed via full-duplex communication.
- From the target device to the CPU module, communication using the MC protocol, nonprocedural protocol, or bidirectional protocol can be performed.
- From the CPU module to the target device, communication using the MC protocol (transmission by the on-demand function only), the nonprocedural protocol, or bidirectional protocol can be performed.

#### Remote password check

If the remote password check has been set for C24, the C24 performs a remote password check when accessing to the programmable controller from a target device using the C24 modem function.

The following is an overview of the CPU module remote password function.

Page 155 Applicability of remote password function

#### ■Remote password function

The remote password function allows/prohibits access to the CPU module from a target device via the following modules.

- C24
- Ethernet module
- Built-in Ethernet port CPU

In the case of the Ethernet module, the remote password function can be used for data communications connections with a target device. For details, refer to following manual.

MELSEC iQ-R Ethernet User's Manual (Application)

#### Station to which the remote password and remote password check are set

· When a programmable controller system with one CPU module station



When a programmable controller system consisted of multiple CPU module stations
 Set to the CPU module station (the CPU module on the host station in the figure below) which is the entrance of the programmable controller system as viewed from the target device.



When set to a station other than the CPU module which is the entrance of the programmable controller system (relay station or access station in the above figure), access to other stations beyond the set station is prohibited.

## **Function list**

Function	Overview					
Modem/TA initialization	Initializes the modem/TA using the user-designated initialization data (AT command). (Auto initialization of the modem/TA is possible.)					
Line connection (dialing)	Dials the target telephone number according to the user-designated data for connection and enables data communication after establishing the line connection. When the modem/TA is not initialized, performs the initialization.					
Data communication	Performs communication with a target device using the MC protocol, nonprocedural protocol, or bidirectional protocol.	Communication method: full- duplex communication				
	Performs communication with the target C24-installed station by modem/TA connection using nonprocedural protocol or bidirectional protocol. (Station-to-station communication)	Synchronization method: Asynchronous communication (asynchronous)				
Modem disconnection	Disconnects forcefully the line to the connected target device.					
Flash ROM reading, writing (registration), and deletion	eads, writes (registers) and deletes the initialization data (AT command) and data for connection from/to the flash ROM in 24 according to the request from CPU module.					
Remote password check Allows C24 to execute the check of the remote password set in the CPU module when communication from a target of to C24 is performed using the MC protocol.						

The overview of the modem function are as follows.

## 7.2 System Configuration

This section explains the system configurations when the modem function is used to perform data communication with a target device via public lines.

# System configuration when performing data communication with target device

The following shows the system configuration examples used for data communications between a target device and CPU module using the MC protocol/nonprocedural protocol/bidirectional protocol of C24.

#### Connection example to a target device



#### Connection example to C24



- The public lines indicated above are compatible with the office telephone system as well.
- For connection to a target device or C24, the digital line (ISDN) can be replaced by the public line.
   When connecting via a digital line, a TA (terminal adapter) and a DSU (digital service module) are used instead of a modem.

## **Considerations for system configurations**

The following shows considerations for the system configurations to perform data communication with a target device via public line, an office telephone system or digital line (ISDN) using the modem function.

#### Usable C24 interface

- The modem function can be used for the RS-232 interface only.
- For the RJ71C24-R2, the modem function can be used for only either one of the two RS-232 interfaces.
- Interactive data communication via two interface of C24 (interlink operation) is not available.

#### Connectable modem/TA

Only the modems/TA shown below can be used for the C24 RS-232 interface to use the modem function. MELSEC iQ-R Serial Communication Module User's Manual (Startup)

#### Number of connectable modems/TAs

Only one modem/TA can be connected to the C24 RS-232 interface to use the modem function.

#### Modem/TA connection cables

- Perform the wiring connection as designated on the modem/TA side for connection between C24 and modem/TA.
- For the RS-232 interface of C24, a D-sub 9-pin connector (female) is used.

For the connection cable of C24 side, refer to the following manual.

(CMELSEC iQ-R Serial Communication Module User's Manual (Startup))

#### Modem/TA installation

- Install the modem/TA according to the modem/TA manual. Installing it in an area where a lot of noises are generated may cause malfunctions.
- In order to prevent the effects of noise and power surges, do not connect near or tie the cable together with a main circuit line, high-voltage line or load line other than for the programmable controller with the modem/TA connection cable.

#### **Connectable lines**

- The connections with the following lines, which are equivalent to NTT communication protocol are available.
   Perform connection tests beforehand and confirm that connection is possible.
   Public line or office telephone system of analog two-line method
   Digital line (ISDN)
- It is not possible to connect to call-waiting lines, in order to avoid data errors or automatic line disconnection due to the callwaiting interrupt tone.
- · Avoid connections with party-line telephones to avoid interrupted calls during communication.
- If an alert sound is sent at fixed intervals from the communication machine to prevent long-term calls, data corruption may occur.

Transmitting a response for normal/abnormal data reception between devices, and performing transmission retry processing when any abnormality is detected is recommended.

• Refer to the manuals for a modem/TA for connection from a modem to public line/office telephone system, or for connection from a TA to a digital line.

#### **Communication method**

Communication via the modem function is performed using full-duplex communication. Connections to devices designed for half-duplex communication is not available.

#### Data communication to target devices

• Data communication with target devices is performed using the public line or electric wave transmitted from the electric wave transmission base.

In some conditions, normal data communication may not be carried out due to the system installation environment, electric-wave transmission status, error in the target device, or other reasons.

Perform a connection test beforehand, and confirm that connection is possible.

## 7.3 Specifications of Modem Function

This section explains the applicability to the remote password function, input/output signals and buffer memory related to the modem function.

### Applicability of remote password function

The following explains C24 data communication for the remote password function of the CPU module. For an overview of the C24 check function for the CPU module remote password, refer to the following section.

#### Precautions

The remote password function cannot prevent improper access completely.

Incorporate the user's own safeguards when it is necessary to protect the security of the programmable controller system from improper access from an external device.

The company cannot assume any responsibility for any problems that may arise from system troubles caused by improper access.

#### Countermeasures for preventing unauthorized access

- · Set the firewall.
- Install a personal computer as a relay station and control the relay station of the transmission/receive data using application programs.
- · Install an external device whose access authority can be controlled.

For the external devices whose access authority can be controlled, contact the network provider or distributor of devices.

#### Data communication when remote password is set

This section explains how to use and set the CPU module remote password function, and data communication between the target device and the CPU module when a remote password has been set.

#### ■Permitting/prohibiting access from target device to programmable controller

Access permission processing (unlock processing)

- To access to the specified CPU module, the target device performs the remote password unlock processing to the C24<sup>\*1</sup> on the directly connected station (host station) after line connection for the modem function.
- If the unlock processing has not been performed, accessing to the specified station is prohibited by the remote password check performed by C24<sup>\*1</sup>, which received the communication request.

( Page 158 Remote password check processing performed by C24)

- · All received data before the unlock processing is performed will be processed as an error.
- \*1 It indicates the C24 on the CPU module station to which a remote password is set.
- Access processing
- · Normal completion of the remote password unlock processing allows the access to the specified station.
- Perform communication using the MC protocol.
- O Access prohibition processing (lock processing)
- To complete the access to the specified station, perform the line disconnection processing for the modem function in order to disable further access.
- · When the modem disconnection is completed, the remote password lock processing is performed automatically.



- \*1 Unlock and lock processing of the remote password for the host station is possible. Remote password unlock and lock processing for the relay station and access station cannot be performed.
- \*2 Lock processing is performed when a line for the modem function is disconnected.
- \*3 For an Ethernet module which transmits a communication request to other Ethernet, the unlock and lock processing is not necessary even it is set as the subject of remote password check.

#### Restriction (")

The remote password unlock and lock processing can be performed to the C24 on the host station directly connected to the target device.

The remote password unlock and lock processing cannot be performed for the Ethernet module of the other stations (relay station and access station).

Point P

- The remote password unlock processing from a target device is performed using dedicated commands for MC protocol communication.
- For corrective actions for abnormal completion of the remote password unlock processing, refer to the following section.
  - ( Page 166 Considerations for using the modem function)

#### Remote password check processing performed by C24

#### Communication in which a remote password check is performed

• When the following parameters are set for the C24 mounted on the host station CPU module, the C24 performs a remote password check for communication requests listed below.

- · When a remote password is set in the CPU module.
- When C24 that is communicating data with the target device has been set as a module subject to the remote password check.

• C24 performs a remote password check with respect to a communication request to the host station/other station received from the target device.

- O C24 does not perform a remote password check for the following communication requests.
- Transmission request from the CPU module on the host station (such as transmission using nonprocedural protocol)
- Communication request from the target device (including Engineering tool connected to the CPU module on the host station) transmitted to other station upon request from the CPU module.



\*1 In the above figure, a communication request from the target device cannot be received since the remote password check setting has been configured.

If the remote password check setting has not been configured, a communication request can be received and data communication from the target device is possible.

#### Selecting modules to which remote password check is performed

C24 to which the remote password check is performed can be selected by the user, and it will be set by the parameters of the CPU module.

(This is set on the "Remote Password Setting" screen of Engineering tool.)

#### Stations that can be accessed when the remote password check is performed

- The remote password unlock processing to the C24 on the directly connected station (host station) after line connection for the modem function enables the target device to access to the CPU module on the host station.
- When accessing the programmable controller on other stations via the Ethernet module on a relay station or access station, the access is allowed/prohibited by the settings below.

To prohibit access to other station from a target device using the IP packet transfer function of the Ethernet module, select the checkbox for "MELSOFT Transmission Port (UDP/IP)" on the "Remote Password Detail Setting" screen for the relay station or access station.

For the stations that can be accessed when accessing to the CPU module on the other stations via Ethernet module, refer to the following manual.

(Refer to it by substituting the station connected to a target device with C24.)

(C MELSEC iQ-R Ethernet User's Manual (Application))

#### Data communication procedure

The following shows the procedure when a target device performs data communication via C24 to which the remote password check is performed.

- **1.** Initialization of the modem on the C24 side and target device side is performed at each device sides.
- **2.** The line is connected from the target device.
- The target device performs the remote password unlock (release) processing for the CPU module on the station where C24 is mounted using dedicated commands for MC protocol communication.
   (The unlock processing cannot be performed for the CPU module of other station.)

For what to do when the remote password unlock processing is completed abnormally, refer to the following section. (SP Page 150 Remote password check)

- **4.** Data communication is performed from the target device using MC protocol.
- **5.** When data communication using MC protocol is completed, a line for the modem is disconnected from the target device. When line disconnection is completed, the remote password lock processing is performed automatically.

#### Remarks

• For more details on the unlock processing command to the remote password, refer to the following manual. (CMMELSEC Communication Protocol Reference Manual)

#### How to set the remote password

For the remote password setting method, refer to the following manual.

## List of input/output signals for the modem function

The input/output signals to/from the CPU module for the modem function are shown below. For information on the input/output signals not related to the modem function, refer to the following section.

Page 493 Input/Output Signal List

#### Ex.

The start I/O number of C24 is '0030'. ('n' indicates start I/O number of C24.) Xn0 to X(n+1)F  $\rightarrow$  X30 to X4F, Yn0 to Y(n+1)F  $\rightarrow$  Y30 to Y4F

#### Function and description of input/output signal

I/O signal	Signal name	Function/description	Description
X10	Modem initialization completion	Indicates the normal completion of the initialization for the modem/ TA connected to the host station side by C24 according to the initialization data designated.	Page 185 Initialization of modem/TA (terminal adapter)
X11	Dialing	Indicates that C24 is dialing (performing connection processing) the target device side according to the data for connection designated.	Page 190 Line connection
X12	Connection	<ul> <li>Indicates normal completion of the line connection processing from or to the target side.</li> <li>When this signal is ON, data communication with the target device is possible.</li> </ul>	
X13	Initialization/connection abnormal completion	<ul> <li>Indicates abnormal completion of the modem/TA initialization or line connection processing (dialing) to the target device.</li> <li>Check the cause of the abnormal completion in the modem-error code storage area (address: 221H) and take corrective actions.</li> </ul>	Page 185 Initialization of modem/TA (terminal adapter) Page 190 Line connection
X14	Modem disconnection completion	Indicates that the line for data communication with the target device has been disconnected.	Page 202 Line disconnection
Y10	Modem initialization request (standby request)	<ul> <li>Indicates the initialization request to the modem connected to the C24 on the host station.</li> <li>Turn ON the initialization request signal after designating the data for initialization to the buffer memory when it is not set with Engineering tool.</li> </ul>	Page 185 Initialization of modem/TA (terminal adapter)
Y11	Connection request	<ul> <li>Indicates the connection request (dialing) to enable data communication with the target device.</li> <li>Turn ON the connection request signal after designating the data for connection to the buffer memory when it is not set with Engineering tool.</li> <li>If the modem/TA connected to the host station is not initialized, the C24 side modem is initialized as well prior to dialing, according to the designated data for initialization.</li> </ul>	Page 190 Line connection
Y12	Modem disconnection request	Indicates a line disconnection request to the target device upon completion of data communication.	Page 202 Line disconnection
Point			

The descriptions hereafter show an example in which I/O numbers of the C24 are assigned to X/Y00 to X/Y1F.

### **Buffer memory**

The buffer memory to be used for the modem function is shown below.

For the buffer memory that are not related to the modem function, refer to the following section.

Page 498 Buffer memory list

#### Point P

Read/write the setting values from/to the buffer memory using Engineering tool.

This section provides supplementary explanations on setting values used to perform settings and monitoring with an Engineering tool.

#### Precautions

Do not write data in the system area of the buffer memory.

If data is written in the system area, the programmable controller system may operate abnormally.

The system area exists in the user area partially. Therefore, take caution when reading from/writing to the buffer memory.

#### Details of the buffer memory (for modern function)

#### ■Modem connection CH specification (Un\G46)

Designate the interface on the C24 side to which a modem/TA is connected.

#### ■Connection retry count designation (Un\G48)

- Designate the number of retries for the connection request when the connection could not be made to the target device by the connection request.
- · Using the default value for the connection re-try count is recommended.

#### ■Connection retry interval designation (Un\G49)

- Designate the interval time of the retry processing for the connection request when the connection could not be made to the target device by the connection request.
- The default value is recommended to use for the connection retry interval.

#### ■Initialization/connection timeout designation (Un\G50)

· Designate the following wait time:

Wait time until the modem/TA initialization is complete

Wait time per wait when the connection could not be made to the destination by the connection request

· The default value is recommended to use for the initialization/connection retry timeout.

#### ■Number of initialization retries designation (Un\G51)

Designate the number of retries when the initialization by the initialization request to the modem on the C24 side has failed.

#### Data No. for initialization designation (Un\G52)

• Designate the registration number of data for initialization which is transmitted by the initialization request to the modem on the C24 side.

The registration number is the number registered in C24.

· For details on the designation by program, refer to the following section.

( I Page 185 Initialization of modem/TA (terminal adapter))

#### Data No. for connection designation (Un\G53)

• Designate the registration number of the data for connection used by C24 for the connection processing to the target device in order to perform data communication.

The registration number is the number registered in C24.

For details on the designation by program, refer to the following section.

( Page 190 Line connection)

#### ■No-communication interval time designation (Un\G55)

- Designate the wait time until the line is closed when the data communication has ceased with the target device after the line connection.
- C24 automatically performs the line disconnection processing when no data communication is performed with the target device for a designated time.

The 'Connection' (X12) and the 'Modem initialization completion' (X10) are turned OFF and the 'Modem disconnection completion' (X14) is turned ON when the line disconnection processing is performed.

#### ■RS/CS control enable/disable designation (Un\G56)

- Designate whether or not the control to notify the data reception capability on the host station to the target side with the RS/ CS signal during data communication between C24 and modem/TA.
- This setting is for the interface designated for the modem connection channel indicated in the 'Modem connection CH specification' (Un\G46).

The control of the other interface that does not use the modem function is performed by the settings in the 'DTR/DSR (ER/ DR), DC control designation' (Un\G147/307).

#### Point P

The overview of the RS/CS control is shown below.

- When transmitting data
- C24 detects the modem/TA data reception capability by ON/OFF of the CS (CTS) signal.
- When the CS (CTS) signal is ON, data transmission from C24 starts or continues. When the CS (CTS) signal is OFF, data transmission from C24 is interrupted.
- When receiving data
- The C24 side reception capability is notified to the modem/TA by ON/OFF of the RS (RTS) signal.
- When the RS (RTS) signal is ON, C24 can receive data. Start/continue data transmission from the modem/ TA to C24.

When the RS (RTS) signal is OFF, C24 cannot receive data. Cancel data transmission from the modem/TA to C24.

- C24 turns ON/OFF the RS (RTS) signal in the following conditions:
  - $\text{ON} \rightarrow \text{OFF}$  control of the RS (RTS) signal

C24 turns OFF the RS (RTS) signal when the free OS area for receive data storage becomes 64 bytes (default) or less.

 $\text{OFF} \rightarrow \text{ON}$  control of the RS (RTS) signal

C24 turns ON the RS (RTS) signal when the free OS area for receive data storage becomes 263 bytes (default) or more.

#### ■Modem function error code (Un\G545)

- Error code for an error occurred while the modem function is used or when abnormal signal ('Initialization/connection abnormal completion' (X13)) turns ON is stored.
- For information on error codes, refer to the following section.
   (IP Page 473 Error Code List)

#### ■Modem function sequence status (Un\G546)

- The current status while the modem function is used is stored as a number.
- For information on the storage value of the modem function sequence status when using the modem function, refer to the following section.
  - ( Page 172 Startup procedure of the modem function)

#### ■Number of data registration for connection (Un\G547)

- The number of registered data for connection, which has been registered in the flash ROM, used by C24 for connection processing with the target device to perform data communication is stored. The number of registration is the number of data for connection registered in the flash ROM by the user.
- For details on registration of data for connection, refer to the following section.
   (IST Page 181 Register/read/delete data for connection)

#### ■Data registration status for connection (for confirmation of registration No.) (Un\G548 to 549)

- The registration status of data for connection, which has been registered in flash ROM, used by C24 for the connection processing with the target device to perform data communication is stored.
- The registration status of each data for connection with registration numbers, No.BB8H to BD5H (3000 to 3029), is indicated in the corresponding bit in the range shown in the figure below.



#### ■Number of data registration for initialization (Un\G550)

The number of registered data for initialization, which has been registered in the flash ROM, transmitted to the modem connected to the C24 side for initialization request.

The number of registrations is the number of data for initialization registered in the Flash ROM by the user.

#### ■Data registration status for initialization (for confirmation of registration No.) (Un\G551 to 552)

- The registration status of data for initialization, which has been registered in flash ROM, transmitted to the modem connected to the C24 side for initialization request.
- The registration status of each data for initialization with registration numbers, No.9C4H to 9E1H (2500 to 2529), is indicated in the corresponding bit in the range shown in the figure below.
- For details on registration of data for initialization, refer to the following section.
- (SP Page 177 Register/read/delete data for initialization)



163

#### ■For user frame registration: Registration data byte count designation area (Un\G6912, 6953…)

• The initialization data or data for connection can be registered in the buffer memory as well as the flash ROM of C24.

Data type	Registration destination	Registration number (Decimal (Hex.))	
Initialization data	Flash ROM	Data registered by the operating system	2000 to 2013 (7D0H to 7DDH)
		User-registered data	2500 to 2529 (9C4H to 9E1H)
	Buffer memory	(All registered by user)	-32767 to -32737 (8001H to 801FH)
Data for connection	Flash ROM	(All registered by user)	3000 to 3029 (BB8H to BD5H)
	Buffer memory	(All registered by user)	-32767 to -32737 (8001H to 801FH)

A registration number to register data for initialization or data for connection to the buffer memory is in the range of -32767 to -32737 (8001H to 801FH) respectively, which is determined by the area to be used.

- In this area, the number of bytes for the data for initialization or data for connection (for 1 data) to be registered in the buffer memory is designated.
- For more information on how to register data for initialization or data for connection in the buffer memory, refer to the following sections.

( 🖙 Page 177 Register/read/delete data for initialization, 🖙 Page 181 Register/read/delete data for connection)



#### ■For user frame registration: User frame specification area (Un\G6913 to 6952, 6954 to 6993 …)

- Designate the applicable data (for 1 data) for the above registration data byte count when registering the data for initialization or data for connection in the buffer memory.
- For more information on how to register data for initialization or data for connection in the buffer memory, refer to the following sections.
  - ( Page 177 Register/read/delete data for initialization, Page 181 Register/read/delete data for connection)



#### ■Auto modem initialization designation (Un\G8199)

- Designate whether the modem on the C24 side is initialized automatically or not.
- Registration in this area is performed with Engineering tool.

The modem is initialized automatically when C24 starts up after the CPU module restarts.

#### Modem initialization DR (DSR) signal enable/disable designation (Un\G8200)

Set "DR signal enabled" for this setting.

This setting is used to designate how the DR (DSR) signal is treated only when modem initialization is performed. Following the completion of modem initialization, data is sent according to the status of the DR (DSR) signal.

#### Complete signal handling for modem function designation (Un\G8201)

Set "Turn ON/OFF X13, X14" (default value) for this setting.

#### Line disconnection wait time (for PLC CPU monitor) (Un\G8206)

- When transmitting data using the programmable controller CPU monitoring function, designate the time between data transmission from C24 and completion of data transmission from the modem on the host station side to the target device side (wait time to disconnect the line).
- · Specify the line disconnection wait time in accordance with the specifications of the modem to be used.

#### Details of buffer memory (for the remote password function)

Each of the areas described below is valid when C24 performs the remote password check.

#### ■Remote password mismatch notification count designation (Un\G8204)

- Designate the count that will be the timing to notify the CPU module that a remote password mismatch occurred during the unlock processing by the user/target device after the modem line has been connected with 0 to FFFFH.
- Confirming the accumulated number of times of occurred remote password mismatch up to the present time after the line connection is not available.

#### ■Remote password mismatch notification accumulated count designation (Un\G8205)

- Designate the accumulated count that will be the timing to notify the CPU module that a remote password mismatch occurred during the unlock processing by the user/target device after C24 has been started up with 0 to FFFFH.
- The accumulated number of times remote password mismatch occurred up to the present time from C24 startup (accumulated count value by C24) can be checked in the 'Accumulated count of unlock process abnormal completion' (Un\G8956).

#### ■Accumulated count of unlock process normal completion (Un\G8955)

The accumulated number of times the remote password unlock process has been completed normally is stored.

#### ■Accumulated count of unlock process abnormal completion (Un\G8956)

The accumulated number of times the remote password unlock process has been completed abnormally is stored.

#### ■Accumulated count of lock process by line disconnection (Un\G8959)

The accumulated number of times C24 has automatically performed the lock processing due to a modern line disconnection is stored.



The supplemental information for each of the accumulated count stored in Un\G8955, 8956, and 8959 is shown below:

- The value can be cleared by writing "0" to the corresponding area of the buffer memory.
- The accumulated count will be stored as  $0H \rightarrow 1H \rightarrow 2H \dots \rightarrow FFFFH \rightarrow 0H \rightarrow 1H \rightarrow \dots$ .

### Considerations for using the modem function

Considerations for using the modem function to perform data communication with a target device via public line are shown below.

#### Modem connection and disconnection

When performing data communication with a target device, it must be predetermined which station is to perform the line connection (dialing) and disconnection processing with the target device as well as the timings.

#### Reception data before connection completion

Until the connection processing to the modem is completed, the received data other than modem commands is ignored (read and discarded) at the interface that uses the modem function.

(Example) C24 will ignore the data even when an MC protocol command message is received.

#### Transmission control

Delays may occur in transmission controls to notify the data reception capability at the host station to the target device. The amount of transmitted/received data and the interval must be determined beforehand in order to prevent any conditions in which the target device cannot receive transmitted data.

When transmitting/receiving data in the nonprocedural protocol, the procedure must also be predetermined.

#### Priority of data communication

The data transmission/reception processing with the target device after line connection has been established is performed in the order of the processing request occurrence.

At the same time, when the line disconnection processing or data transmission/reception (including data transmission processing, reception processing and flash ROM access processing) occurs, the line disconnection processing has the priority.

#### Data communication time

The data transmission/reception time after line connection has been established with the target device is the total time of the transmission time between C24 and modem/TA, between modem and TA, and between modem/TA and target device. When communicating via the MC protocol, the transmission time (such as T0 and T3) must include the transmission time between the modem/TA on the C24 side and the target device.

For details, refer to the following manual.

MELSEC Communication Protocol Reference Manual

#### **Initial Settings**

The data for connection, which is used for the modem function, can be registered as follows depending on how to set. Set the telephone number and message within the allowable number of registration characters for modem/TA.

#### ■Registering using Engineering tool

- Up to 254 bytes can be set for comments. (Not used for control.)
- Up to 62 bytes can be set for telephone number.

#### Registering by the CPU module (program)

- Comments cannot be set.
- Up to 18 bytes can be set for telephone number.

#### Programmable controller CPU monitoring function

For considerations for transmitting monitored results with the modem function, refer to the following section.

Page 147 Modem connection error

#### Remote password check

#### How to unlock the remote password

- When C24 has been set as a subject to the remote password check with the CPU module parameter, a remote password unlock processing must be performed from the target device after line connection before starting data communication.
- The unlock processing for the CPU module remote password is performed as follows: When communicating using MC protocol: Perform the unlock processing from the target device using dedicated commands.

#### When the remote password unlock processing is completed abnormally

- · Repeat the unlock processing after checking the remote password set in the CPU module.
- Start with the line connect processing again if C24 'Connection' (X12) turns OFF due to the unlock processing abnormal completion.
- Perform the line connect processing again after clearing the accumulated count stored in the following buffer memory when the 'CH□ Error occurrence' (XE/XF) of C24 turns ON and the ERR LED lights up due to the unlock processing abnormal completion.

(Target buffer memory)

'Accumulated count of unlock process abnormal completion' (Un\G8956)

(How to clear)

Write "0" to the relevant area of the buffer memory.

#### When the number of times remote password mismatch occurs is large

 When the number of times notification of a remote password mismatch is received exceeds the 'Remote password mismatch notification count designation' (Un\G8204), C24 disconnects the line automatically. (The 'Connection' (X12) turns OFF.)

After confirming the remote password registered in the CPU module and the remote password specified in the target device, restart form the line connection.

- When the count exceeds the 'Remote password mismatch notification accumulated count designation'(Un\G8205), C24 performs the following processing every time the mismatch occurs (The line to the modem is not disconnected.) An error code (7FE8H) is stored in the 'MC protocol send error code' (Un\G602/618) on the buffer memory. The 'CH□ Error occurrence' (XE/XF) turns ON and the ERR LED turns ON.
- The accumulated number of times remote password mismatch occurred up to the present time (accumulated count value by C24) can be checked in the 'Accumulated count of unlock process abnormal completion' (Un\G8956).
- The accumulated number of times up to the present time should be cleared by writing "0" to the 'Accumulated count of unlock process abnormal completion' on the buffer memory (Un\G8956).

Point P

 If the 'CH□ Error occurrence' (XE/XF) for C24 turns ON and the ERR LED turns ON, this may indicate improper access from the target device. Refer to "CPU module side countermeasures against improper access from a target device".

(EP Page 168 CPU module side countermeasures against unauthorized access from a target device)

• For details on how to turn OFF the ERR LED of C24, refer to the following manual.

( I Page 448 Turning OFF the ERR LED and initializing the error codes)

#### CPU module side countermeasures against unauthorized access from a target device

The following is an example of performing, on the programmable controller CPU side, the line disconnect processing against the target device and prohibiting receive via a modem when the number of "remote password mismatch" detected by the C24 remote password check function exceeds the number set by the user.

- Determine at the user side the count and accumulated count for notification when a remote password mismatch occurs in the unlock processing from external devices with respect to the remote password set in the CPU module.
   (CF Page 165 Details of buffer memory (for the remote password function))
- Set the above counts to the items below for the module parameters in order for C24 to operate, and register them in C24. Set in "Remote password mismatch notification count."

Set in "Remote password mismatch notification accumulated count."

- In addition to initialization commands used in normal modem initialization, specify "No automatic receive" and additionally register the modem initialization command for this step to C24. (No automatic receive: This is the setting to prohibit line connection from the target device.)
- Constantly monitor the rise (OFF → ON) of the 'CH□ Error occurrence' (XE/ XF) when connecting the line to the target device using the modem function after the system begins operating.
- Monitor the following buffer memory when the error occurred signal turns ON. 'MC protocol send error code' (Un\G602)
- Perform the line disconnect processing to the target device when the error code stored in the above buffer memory is 7FE8H.

(Use the 'Modem disconnection request' (Y12).)

- After the above line disconnection processing is completed, specify the modem initialization command for which "No automatic receive" has been specified and perform modem initialization only. (
- Describe the above occurrence to the system manager and take necessary measures.

#### ■Program example

When the number of times a remote password mismatch occurred exceeds the notification accumulated count setting value during the remote password unlock processing in communication using MC protocol with the C24 CH1 side interface used.

Category	Label name	Description	Device
Module label	C24_1.stnCH1.bSts_Error	CH1 Error occurrence	X0E
	C24_1.bSts_ModemInitializationCompletion	Modem initialization completion	X10
	C24_1.bSts_ConnectionProcessing	Connection	X12
	C24_1.bSts_Initialization_Connection_AbnormalCompletion	Initialization/connection abnormal completion	X13
	C24_1.bSts_DisconnectionCompletion	Modem disconnection completion	X14
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
	C24_1.bSet_Req_ModemInitialization	Modem initialization request	Y10
	C24_1.bSet_Req_Disconnection	Modem disconnection request	Y12
	C24_1.uSet_DataNum_Initialization_ModemFunction1_D	Data No. for initialization designation	U0\G52
	C24_1.uErrorCode_ModemFunction_D	Modern function error code	U0\G545
	C24_1.stnCH1.uErrorCode_MC_ProtocolTransmissionErrCode_ D	Protocol transmission error code	U0\G602
	C24_1.wnForUserRegistrationNo8005H_D[0]	User registration number 8005H	U0\G7076
	C24_1.uCount_RemotePasswordAccumulatedUnlockProcNormal _D	Accumulated count of unlock process normal completion	U0\G8955

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class	Assign (Device/Label)
1	bReq_ProcessCompletion	Bit	 VAR_GLOBAL 👻	X27
2	bUnitAccessibleFlag	Bit	 VAR_GLOBAL 👻	MO
3	bCH1_ErrorOccur	Bit	 VAR_GLOBAL 👻	M201
4	bReq_ModemDisconnection	Bit	 VAR_GLOBAL 👻	M203
5	bReq_ModemInitializationDataSetting	Bit	 VAR_GLOBAL 💌	M204
6	bReq_UnlockCumulativeNumberClear	Bit	 VAR_GLOBAL 👻	M205
7	bModemInitializationNormalCompletion	Bit	 VAR_GLOBAL 👻	M207
8	wModemFunctionErrorCode	Word [Signed]	 VAR_GLOBAL 👻	D100
9	wnUserFlameNo_8005SettingData	Word [Signed](05)	 VAR_GLOBAL 👻	D200
10	wCH1_ErrorCode	Word [Signed]	 VAR_GLOBAL 👻	D250
11	bModemFunctionErrorFlag	Bit	 VAR_GLOBAL 👻	M206

(0)	C24_1.bSts_U nitReady X1E	C24_1.bSts_Wa tchdogTimerEr ror X1F								bUnitAccessibleFI ag M0
								MOVP	K6	wnUserFlameNo_8 005SettingData[0] D200
									K5	wnUserFlameNo 8
								MOVP		005SettingData[1] D201
									"ATS0=0"	wnUserFlameNo_8
								\$MOVP		005SettingData[2] D202
							вмоу	wnUserFlameN o_8005SettingD ata D200	C24_1.wnForUserRegist rationNo8005H_D[0] U0¥G7076	К5
(21)	C24_1.stnCH 1.bSts_Error X0E								PLS	bCH1_ErrorOccur
	$\vdash$					 				M201
		111.3.4				 				
(24)	M201	eFlag M0						MOV	C24_1.stnCH1.uErrorCo de_MC_ProtocolTransm issionErrCode_D U0¥G602	wCH1_ErrorCode
		• •				 				
			-	H7FE8	wCH1_ErrorCode				SET	bReq_ModemDisc onnection
					D250	 			021	M203
									SET	C24_1.bSet_Req_D isconnection
						 				Y12
	1									

	bReq_Modem	bUnitAccessib <b>l</b>	C24_1.bSet_Req_Disco	C24_1.bSts_Mod	C24_1.bSts_Conne	C24_1.bSts_Disc					C24 1 hSat Bag D
(35)	n M203	eFlag M0	nnection	ompletion	ctionProcessing	etion				RST	isconnection
				Î/Î		î î		 			Y12
			004 1 kG at Day Diago	C24_1.bSts_Mod	024 1 6 6 4 0	C24_1.bSts_Disc					
			nnection	emInitializationC ompletion	ctionProcessing	onnectionCompl etion			1101/	H8005	C24_1.uSet_Data
			Y12	X10	X12	X14			MOV		odemFunction1_D
			21	1	1	21					00#G52
											C24 1.bSet Reg M
										SET	odemInitialization
								 			Y10
											bReq_ModemInitia
										SET	MOOA
											WI204
											bReg ModemDisc
										RST	onnection
							L	 			M203
	bReq_ModemI	C24_1.bSet_Re	024 1 hSto MadamIniti								
()	nitializationD ataSetting	q_ModemInitiali zation	alizationCompletion								bReq_UnlockCumu
(55)	M204	Y10	X10							SET	M205
	1 1										WIZ03
											C24 1.bSet Reg M
										RST	odemInitialization
					0			 			Y10
											bReq_ModemInitia
										RST	M204
											WI204
			C24_1.bSts_Initializatio	MO						C24 1 uErrorCode Mod	wModemFunction
			alCompletion X13						MOV	emFunction_D	ErrorCode
			L Î	<u> </u>	0			 		U0¥G545	D100
					K0	wModemFunctio nErrorCode				OFT	bModemFunction ErrorFlag
				$\diamond$	ко	wModemFunctio nErrorCode				SET	bModemFunction ErrorFlag M206
					КО	wModemFunctio nErrorCode D100				SET	bModemFunction ErrorFlag M206
				<	ко	wModemFunctio nErrorCode D100				SET	bModemFunction ErrorFlag M206 C24_1.bSet_Req_N
				<	К0	wModemFunctio nErrorCode D100				SET	bModemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization
				<	ко	wModemFunctio nErrorCode D100				SET	bModemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10
				<	ко	WModemFunction nErrorCode D100				SET RST	bModemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10
				<	ко	WModemFunction nErrorCode D100				SET RST	bModemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10 bReq_ModemInitia
				<>	ко	wModemFunction nErrorCode D100				SET RST RST	bModemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10 bReq_ModemInitia izationDataSetting M204
					ко	wModemFunctio nErrorCode D100				SET RST RST	bModemFunction ErrorFlag M206 C24_1.bSet.Reg_N odemInitialization Y10 bReg_ModemInitia izationDataSettiny M204
	bReq_Unlock CumulativeN	C24_1.bSts_Mo deminitializatio	C24_1bSet_Reg_Mode	•	ко	WMddemFunctio nErrorCode D100			КО	SET RST RST C24 1.uCount Remote	bMdemFunction ErrorFlag M206 C24_1bSet.Req.M odemInitialization Y10 bReq_ModemInitia izationDataSetting M204 K2
(78)	bReq_Unlock CumulativeN umberClear M205	C24_1.bSts_Mo deminitializatio nCompletion X10	C24_1.bSet_Req_Mode mlnitialization Y10	•	ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccumulated LinlorePresNormal D	bMdemFunction ErrorFlag M206 C24_1.bSet.Reg.M odemInitialization Y10 bReg.ModemInitia izationDataSetting M204 K2
(78)	bReq_Unlock CumulativeN umberClear M205 — ↓ ↓ —	C24_15Sts_Mo deminitializatio nCompletion X10 1	C24_1.bSet_Req_Mode minitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccumulated UnlockPrecNormaLD U0¥G8955	bMdemFunction ErrorFlag M206 C24_1.bSet.Req.M odemInitialization Y10 bReq.ModemInitia izationDataSetting M204 K2
(78)	bReq_Unlock CumulativeN umberClear M205 ─────────────────────	C24.1.bSts.Mo embilializatio nCompletion X10	C24_1.bSet_Req_Mode mInitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccumulated UnlockProcNormaLD UUVG8955	bMdemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10 bReq_ModemInitia izationDataSetting M204 K2
(78)	bReq_Unlock CumulativeN umberClear M205 ☐ 1	C24.1.bSts.Mo demInitializatio nCompletion X10 I	C24_1.bSet_Req_Mode mlnitialization Y10 ¥1		ко	WMddemFunctio nErrorCode D100		FMOV	KO	SET RST RST C24_1uCount_Remote PasswordAccumulated UnlockProcNormaLD UUWG8955	bMdemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10 bReq_ModemInitia izationDataSetting M204 K2 bModemInitializati
(78)	bReq_Unlock CumulativeN umberOlear M205	C24_1.bSts_Mo dernInitializatio nCompletion X10 I	C24_1.bSet_Req_Mode minitialization Y10 		ко	WMddemFunctio nErrorCode D100		FMOV	К0	SET RST RST C24_1.uCount_Remote PasswordAccumulated UnlockProcNormal_D UUVG8855 SET	bMdemFunction ErrorFlag M206 C24_1.bSet_Req_M odeminitialization Y10 bReq_ModemInitialization M204 K2 bModemInitialization K2 bModemInitialization M204
(78)	bReq_Unlock CumulativeN umberClear M205	C24_1.bSts_Mo dernInitialization nCompletion X10	C24_1.bSet_Req_Mode minitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccumulated UnlockProcNormal_D U0¥G8955 SET	bMdemFunction ErrorFlag M206 C24_1.bSet_Req_M odeminitialization Y10 bReq_ModemInitialization DataSetting M204 K2 bModemInitializati onNormalComplet onMormalComplet
(78)	bReq_Unlock CumulativeN umberOlear M205	C24_1.bSts_Mo dernhitialization nCompletion X10	C24_1bSet_Req_Mode mInitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccumulated UnlockProcNormal_D U04G8955 SET	bMddemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10 bReq_ModemInitialization DataSetting M204 K2 bModemInitialization K2 bModemInitialization M207 bReq_UnlockCumt
(78)	bReq_Unlock CumulativeN umberClear M205	C24_1.bSts_Mo dernInitializatio nCompletion X10	C24_1bSet_Req_Mode mInitialization Y10		ко	WMdemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccumulated UnlockProcNormal_D U0¥G8955 SET RST	bMdemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10 bReq_ModemInitialization M204 K2 bModemInitialization K2 bModemInitialization M207 bReq_UnlockCumt lativeNumberClean
(78)	bReq_Unlock CumulativeN umberClear M205	C24_1.bSts_Mo demInitializatio nCompletion X10	C24_1.bSet_Req_Mode mInitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccound.ated UnlockProcNormal_D UN0KS855 SET RST	bModemFunction ErrorFlag M206 C24_1.bSet_Req_M odemInitialization Y10 bReq_ModemInitialization DataSetting M204 K2 bModemInitializationNorma(Complet on M207 bReq_UnlockCump lativeNumberCleal M205
(78)	bReq_Unlock CumulativeN umberClear M205	C24_1.bSts_Mo demInitializatio nCompletion X10	C24_1.bSet_Req_Mode mInitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST C24_1.uCount_Remote PasswordAccount_ated UnlockProceNormaLD UNOKG8955 SET SET	bMdemFunction ErrorFlag M206 C24_1bSet.Req.M odemInitialization Y10 bReq.ModemInitia izationDataSetting M204 K2 K2 bModemInitializati onNormaComplet onM207 bReq.UnlockCumt EtriveNumberCleat M205
(78)	bReq_Unlock CumulativeN umberClear M205 bReq_Proces sCompletion	C24_1.bSts_Mo demInitializatio nCompletion XII	C24_1bSet_Req_Mode mInitialization 10		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1_uCount_Remote PasswordAccound_ated UnlockProcNormaLD UNocRProcNormaLD U0VG8955 SET RST	bMdemFunction ErrorFlag M206 C24_1bSet.Req.ModemInitialization Y10 bReq.ModemInitialization DataSetting M204 K2 bModemInitialization M207 bReq.UnlockCumm. lativeNumberClear M205
(78)	bReq_Unlock CumulativeN umberClear M205 bReq_Proces sCompletion X27	C24_1.bSts_Mo deminitializatio nCompletion X10	C24_1.bSet_Req_Mode mInitialization YI0		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccumulated UnlockProcNormal_D U0VG8955 SET RST RST	bMdemFunction ErrorFlag M206 C24_1L5Gt_Req_N odemInitialization Y10 bReq_ModemInitialization DataSettiny M204 K2 K2 bModemInitializat onNormaComplet on M207 bReq_UnlockCumi lativeNumberClea M205 bModemFunction ErrorFlag M206
(78)	bReq_Unlock CumulativeN umberClear M205 I bReq_Proces sCompletion X27	C24_1.bSts_Mo deminitializatio nCompletion X10 	C24_1.bSet_Req_Mode minitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST 024_1.uCount_Remote PasswordAccumulated UnlockProcNormal_D U0VG8955 SET RST RST	bMdemFunction ErrorFlag M206 C24_1.bSet_Req.ModemInitialization Y10 bReq_ModemInitialization DataSetting M204 K2 bModemInitializat onNormaCiomplet on M207 bReq_UnlockCumu lativeNumberClea M205 bModemFunction ErrorFlag M206
(78)	bReq_Unlock CumulativeN umberClear M205 	C24_1bSts_Mo deminitializatio nCompletion X10 	C24_1.bSet_Req_Mode minitialization Y10 Y1		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST RST C24_1.uCount_Remote PasswordAccumulated UnlockProcNormaLD U0¥G8955 SET RST RST	bMdemFunction ErrorFlag M206 C24_1.bSet.Req.M odemInitialization Y10 bReq_ModemInitialization DataSetting M204 k2 k2 bModemInitializati onNormalComplet on M207 bReq_UnlockCumu lativeNumberCleau M205 bModemFunction ErrorFlag M206
(78)	bReq_Unlock CumulativeN umberClear M205 I bReq_Proces sCompletion X27	C24_1.bSts_Mo derminitializatio nompletion X10	C24_1.bSet_Req_Mode minitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	K0	SET RST RST C24_1_uCount_Remote PasswordAccumulated UnlockProcNormaLD U0VG89555 SET RST RST RST	bMdemFunction ErrorFlag M206 C24_1.bSet_Req.M odemInitialization Y10 bReq.ModemInitialization M204 k2 k2 bModemInitialization NormaComplet on M205 bReq.UnlockCumt lativeNumberClear M205 bReq.UnlockCumt lativeNumberClear M205 bReq.UnlockCumt lativeNumberClear M205 bReq.UnlockCumt lativeNumberClear M205 bReq.UnlockCumt lativeNumberClear M205 bReq.UnlockCumt lativeNumberClear M205
(78)	bReq_Unlock CumulativeN umberClear M205 I BReq_Proces sCompletion X27	C24_1.bSts_Mo demInitializatio nCompletion X10 I	C24_1.bSet_Req_Mode mlnitialization Y10		ко	WMddemFunctio nErrorCode D100		FMOV	KO	SET RST RST C24_1_uCount_Remote PasswordAccumulated UnlockPrecNormaLD U0¥G8955 SET RST RST	bMdemFunction ErrorFlag C24_1.bSet_Reg_M odemInitialization Y10 bReg_ModemInitialization M204 k2 bModemInitializat onNormalComplet on M205 bReg_UnlockCumt lativeNumberClea M205 bRodemFunction ErrorFlag M206
(78)	bReq_Unlock CumulativeN umberClear M205 I BReq_Proces sCompletion X27	C24.1.bSts.Mo demInitializatio nCompletion X10 I	C24_1.bSet_Req_Mode mlnitialization Y10 Y10		ко	WMddemFunctio nErrorCode D100		FMOV	K0	SET RST RST C24_1_uCount_Remote PasswordAccumulated UnlockPrecNormaLD U0¥G8955 SET RST RST RST	bMdemFunction ErrorFlag M206 C24_1.bSet_Req_M odeminitialization Y10 bReq_ModemInitialization M204 K2 k2 bModemInitialization M204 k2 bModemInitialization M205 bReq_UnlockCum, lativeNumberClear M205 bModemFunction ErrorFlag M206 bModemInitialization onNormalComplet onNormalComplet M207
(78)	bReq.Unlock CumulativeN umberOlear M205 I BReq.Proces sCompletion X27	C24_1.bSts_Mo dernInitializatio nCompletion X10 I	C24_1.bSet_Req_Mode mlnitialization Y10 Y1		ко	WMddemFunctio nErrorCode D100		FMOV	К0	SET RST RST C24_1_uCount_Remote PasswordAccumulated UviG8955 SET RST RST RST RST	bMdemFunction ErrorFlag M206 C24_1.bSet_Req_M odeminitialization Y10 bReq_ModemInitialization M204 K2 bModemInitialization M204 K2 bModemInitialization M207 bReq_UnlockCumn lativeNumberClean M205 bModemFunction ErrorFlag M206 bModemInitialization conformalComplet on m205
(78)	bReq_Unlock CumulativeN M205 I BReq_Proces sCompletion X27	C24_1.bSts_Mo dernInitializatio nCompletion X10 I	C24_1.bSet_Req_Mode minitialization Y10 		ко	WMddemFunctio nErrorCode D100		FMOV	КО	SET RST C24_1.uCount_Remote PasswordAccound.ated UnlockProcNormalD UV04G8955 SET RST RST RST	bMddemFunction ErrorFlag M206 C24_1.bSet_Req_M odeminitialization Y10 bReq_ModemInitialization M204 K2 bModemInitialization M204 k2 bModemInitialization bReq_UnlockCumt lativeNumberClear M205 bModemFunction ErrorFlag M206 bModemInitialization onNormalComplet on

#### Number of modules for which the remote password check can be set

Up to eight modules can be registered as the remote password applicable module in the CPU module. \*1

For the settings of the remote password applicable module, use the "Remote Password Setting" screen of Engineering tool. \*1 The remote password applicable modules are as follows:

- · C24
- · Ethernet module
- · Built-in Ethernet port CPU module

## 7.4 Startup of the Modem Function

This section explains the startup procedures, processing methods and programming when the modem function of C24 is used.

## Startup procedure of the modem function

The following shows the procedure to start the modem function and start data communications.

#### Procedure up to initialization of C24 modem/TA

Initialize the modem/TA connected to C24 in order to use the modem function. Initialization of the modem/TA enables respective communications.



- \*3 Page 449 Individual station test
- \*4 SP Page 174 Initial settings of Serial communication module
- \*5 SPage 422 PARAMETER SETTING
- \*6 Page 177 Register/read/delete data for initialization
- \*7 Series Page 181 Register/read/delete data for connection
- \*8 SPage 185 Initialization of modem/TA (terminal adapter)
- \*9 Series Page 173 Procedure for data communication



\*1 Page 190 Line connection

\*2 Page 199 Data communication

\*3 Page 202 Line disconnection

## Initial settings of Serial communication module

This section explains the initial settings of C24 for data communication with a target device by using the modem function.

### Communication protocol setting, Communication speed setting, Transmission setting

Setting item		Data communication		
Test mode setting		No specification		
Communication proto	col setting	MC protocol (Formats 1 to 5)     Nonprocedural protocol     Bidirectional protocol		
Communication speed	d setting	(Set according to modem/TA on the host station)		
Transmission setting	Operation setting	Independent		
	Data bit	(Set according to modem/TA on the host station)		
	Parity bit			
	Odd/even parity			
	Stop bit			
	Sum check code	(Set according to system specification)		
	Online change			
	Setting change			
Station number setting	g (CH1, 2 in common: 0 to 31)	0 to 31		

#### Initial settings with Engineering tool

#### Initial settings for the side of interface that uses the modem function

Perform initial settings on the side of interface that uses the modem function.

- Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ Module Name ⇔ [Module Parameter] ⇔ "Application Settings" ⇔ "Modem function setting"
- •: Required, O: Configurable, X: Not required

Setting item		Data communication (MC, Nonprocedural ,Bidirectional)
Modem function specification 1	Modem connection CH specification	•
	Connection re-try count designation	0
	Connection retry interval designation	0
	Initialization/connection timeout designation	0
	Number of initialization retries designation	0
	Data No. for initialization designation <sup>*1</sup>	•
	Data No. for connection designation <sup>*1</sup>	•
	No-communication interval time designation <sup>*2</sup>	0
	RS/CS control enable/disable designation	0
Modem function specification 2	Auto modem initialization designation	0
	Modem initialization DR (DSR) signal enable/disable designation*3	0
Modem function specification 3	Line disconnection wait time (for PLC CPU monitor)	0
For remote password function	Remote password mismatch notification count designation	0
	Remote password mismatch notification accumulated count designation	0

\*1 For details on how to register the data No. for initialization, refer to the following section.

Page 177 Register/read/delete data for initialization

For details on how to register the data No. for connection, refer to the following section.

Page 181 Register/read/delete data for connection

\*2 Even if the CPU module on the station with C24 (host station) becomes STOP status under the following circumstances, the line (telephone) with the target devices will be left connected.

To prevent the line from being left connected when the line is not in use, be sure to make the appropriate settings.

 $\cdot$  When the CPU module is stopped when the 'Connection' (X12) is in the ON status. (This occurs because the program write after remote stop is enabled.)

 $\cdot$  When the CPU module stops abnormally during self-diagnosis, etc.

\*3 The "Modem initialization DR (DSR) signal enable/disable designation" designates whether the status of the DR (DSR) signal output is valid or invalid at the startup of C24.

When the DR (DSR) signal = ON is output from the modem, register "valid" for this item.

· When the DR (DSR) signal = ON is not output from the modem, register "invalid" for this item.

#### Precautions

- When setting the no-communication interval time to 'Infinite wait' (setting value = 0), be sure to perform line disconnection processing after the data has been communicated.
- Leaving the line connected for long periods of time without performing line disconnection after data communication has been completed not only will run up a large telephone bill but also may violate electronic communication business laws.

#### ■Transmissions using the modem function

All communications using the modem function are performed in full-duplex communications. Leave the following initial settings for the interface side that uses the modem function as default.

- CD terminal check : Do not check
- · Communication method: Full-duplex communications

#### Processing that corresponds to output signals

The processing to the following output signals cannot be aborted.

Output signal	Request processing name
Y10	Initialization request (standby request)
Y11	Connection request
Y12	Modem disconnection request

Using the following initial settings for the modem function as default is recommended. (When any error occurred, it will end due to the time-out.)

- Connection re-try count: 3 times
- · Connection retry intervals : 180 s
- Initialization/connection timeout : 60 s

Also configure the settings for a remote password check when the remote password check is executed to the remote password set in the module CPU. ( I Page 165 Details of buffer memory (for the remote password function))

## Register/read/delete data for initialization

The section explains the registration/reading/deletion of the data for initialization such as initialization commands for the modem/TA connected to the C24 side for data communication with the target device using the modem function.

#### Details of the data for initialization

The following shows the registration destination and type of the data for initialization, registration number, and registration count.

Up to 78 bytes of initialization commands can be registered as one data for initialization. (For 78 characters)

Registration destination of data for initialization		Types of data for initialization that is registered	Registration number of data for initialization	Number of registrations	Remarks
CPU module	Built-in memory	Arbitrary data for initialization registered by the user <sup>*1</sup>	2500 to 2529 (9C4H to 9E1H)	30	<ul> <li>Register the data for initialization after the debug process has been completed.</li> <li>By registering data in this area, replacing C24 can be performed easily.</li> </ul>
	SD memory card	Arbitrary data for initialization registered by the user <sup>*1</sup>	2500 to 2529 (9C4H to 9E1H)	30	<ul> <li>Register the data for initialization after the debug process has been completed.</li> <li>By registering data in this area, replacing C24 can be performed easily.</li> </ul>
C24	Flash ROM	Data for initialization that is registered before shipment	2000 to 2013 (7D0H to 7DDH)	13	<ul> <li>▷ Page 178 Registration contents before shipment</li> </ul>
		Arbitrary data for initialization registered by the user <sup>*1</sup>	2500 to 2529 (9C4H to 9E1H)	30	<ul> <li>Register the data for initialization after the debug process has been completed.</li> </ul>
	Buffer memory	Arbitrary data for initialization registered by the user	–32767 to –32737 (8001H to 801FH)	31	<ul> <li>Register the data for initialization before the debug process has been completed.</li> </ul>

#### Considerations for registration of data for initialization

Do not include CR/LF (data code : 0DH/0AH) in the data for initialization to be registered to C24.
 The CR/LF is output at the end of the AT command by C24 at the time of the initialization processing (automatically added).

• The registration status of the data for initialization stored in the flash ROM may be checked in the buffer memory (Un\G550 to 552).

For initial registration, register by designating an unregistered number.

When designating a registration number that has already been registered, first delete the registration data for the designated number prior to registration.

#### **Registration contents before shipment**

Registration number		Initialization command	Devices		
Hexadec imal	Decimal		Manufacturer	Model	
7D0H	2000	ATQ0V1E1X1\J0\Q2\V2\N3S0=1	Iwa Corporation	PV-AF2881WW, PV-BF288M2	
7D1H	2001	ATQ0V1E1X1\Q2\V2\N3S0=1	Micro Research Institute, Inc.	MC288XE, MC288X1	
7D2H	2002	ATQ0V1E1X1&K3\N3S0=1	Microcom Technologies, Inc.	DESKPORTE22.8S, DESKPORTE33.6S	
7D3H	2003	ATQ0V1E1X1&H1&R2&A3&D2S0=1	OMRON Corporation	ME3314B	
7D4H	2004	ATQ0V1E1X1\J0\Q2\N3S0=1	Sun Electronics Int., Inc.	MS336AF	
7D5H	2005	ATE1Q0V1&C1&D2&H1&I0&R2&S0S0 =1	OMRON Corporation	ME5614B	
7D6H	2006	ATE1Q0V1&C1&D2&K3&S0S0=1	Sun Electronics Int., Inc.	MS56KAF	
			Micro Research Institute, Inc.	MRV56XL	
			Matsushita Electric Industrial Company,	VS-2621A	
7D7H	2007	ATE1Q0V1&C1&D2&K3&S1S0=1	Ltd.	VC-173	
7D8H	2008	ATE1Q0V1&C1&D2&K3&S0S0=1	OMRON Corporation	MT128BII-D	
7D9H	2009	ATE1Q0V1&C1&D1\Q2&S0S0=1	Sun Electronics Int., Inc.	TS128JXI	
7DAH	2010	ATE1Q0V1&C1&D2\Q3&S0S0=1	Sharp Electronics Corporation.	DN-TA1	
7DCH	2012	AT&S0S0=1	General devices		
7DDH	2013	ATX1&S0S0=1	<ul> <li>Use the general devices for checking the modem/TA does not work, create modem specification.</li> </ul>	ne operation. an initialization command appropriate for the	

• The data for initialization registered in the flash ROM of C24 are listed below:

• If initialization commands other than listed above are needed, register the data for initialization in the flash ROM or the buffer memory of the C24 and use it.

#### Remarks

• Perform the following setting to the modem/TA connected to the C24 side.

For settings other than listed below, configure the setting in accordance with the modem/TA specifications. Refer to the instruction manual for the model to be used for details.

Setting content	Setting command example
_	AT
Display the result code (or, return the result code).	Qn
Set the result code to a word.	Vn
Perform character echo.	En
Dial tone and busy tone detection + X1	Xn
Set register 0 to 2.	Sr=n
The modem and the serial speed are not equal.	\Jn
Control RTS/CTS.	\Qn
Control DSR.	&Sn
Control DTR.	&Dn
Enable extension result code (display MNP class).	١Vn
MNP mode/normal mode auto selection	\N3
## Method to register/read/delete data for initialization

Applicable area	Method	Remarks
Flash ROM in C24	Register/read/delete operations are executed with Engineering tool.	The data for initialization, which is stored in the flash ROM of C24 before shipment, cannot be deleted. Designated with "\\" to a field to register "\" when Engineering tool is used to register the modem initialization data. (Example) To register the data of \Q2: \\Q2
CPU module built-in memory	Register/read/delete data with Engineering tool.	—
SD memory card for the CPU module	Register/read/delete data with Engineering tool.	_
Buffer memory of C24	Designate the applicable area corresponding to the registration No. 8001H to 801FH, and write (register)/ read the data for initialization.	<ul> <li>For the buffer memory address for user frames and data for initialization, refer to the following section. (にデ Page 498 Buffer memory list)</li> </ul>

The applicable registration area is shown below.

### ■Setting with Engineering tool

Set with the module extended parameters of C24.

Navigation window ⇒ [Parameters] ⇒ [Module Information] ⇒ Module Name ⇒ [Module Extended Parameter] ⇒ [Modem initialization data]

### ■For the buffer memory of the C24

- Designate the applicable area corresponding to the registration No., 8001H to 801FH in respect to the area for user frame registration (Un\G6912 to 8128), and write (register)/read the data for initialization.
   When deleting the data for initialization, write "0" to the registration data byte count designation area of the applicable number.
- The following shows the overview of buffer memory that are used for writing/reading/deleting processing for data initialization and the setting value of each area.

For more details, refer to the following section. (Refer to it by substituting the user frame to data for initialization.) (SP Page 250 CONTENTS AND REGISTRATION OF USER FRAMES FOR DATA COMMUNICATION)

Address		Name		Designated/stored value	Designation required ( $\bigcirc$ )/ not required ( $\times$ )				
Hexade cimal	Decimal				Write	Read	Delete		
1B00H	6912	Registratio n No.8001H	Registration data byte count designation	0 : When deleting 1 to 78: Number of registered data bytes (Only for the initialization command section)	0	× (Read processin	0		
1B01H	6913		User control data Any data used by the user to control data to be registered (manufacturer code, control number, etc.)			g not required)	×		
1B02H to 1B28H	6914 to 6952		Initialization command	Data code for the initialization command for registration					
1B29H	6953	Registratio n No. 8002H	Registration data byte count designation	0 : When deleting 1 to 78: Number of registered data bytes (Only for the initialization command section)	0	× (Read processin	0		
1B2AH	6954		User control data	User control data Any data used by the user to manage the registration data (manufacturer code, control number, etc.)		g not required)	×		
1B2BH to 1B51H	6955 to 6993		Initialization command	Data code for the initialization command for registration					
÷									
1FCEH	8142	Registratio n No. 801FH	Registration data byte count designation	0 : When deleting 1 to 80: Number of registered data bytes (Only for the initialization command section)	0	× (Read processin	0		
1FCFH	8143		User control data Any data used by the user to manage the registration data (manufacturer code, control number, etc.)			g not required)	×		
1FD0H to 1FF6H	8144 to 8182		Initialization command	Data code for the initialization command for registration					

### ■Program example

The following shows an example of a program used to write (register) data for initialization.

Writing data for initialization to the area of which registration number 8001H

Category	Label name	Description	Device
Module label	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
	C24_1.wnForUserRegistrationNo8001H_D[0]	For user registration number 8001H	U0\G6912

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class		Assign (Device/Label)
1	bReq_InitializationDataRegistration	Bit	 VAR_GLOBAL	•	X23
2	bUnitAccessibleFlag	Bit	 VAR_GLOBAL	•	MO
3	bInitializationCompletion	Bit	 VAR_GLOBAL	•	M1
4	bReq_InitializationDataRegistration2	Bit	 VAR_GLOBAL	٠	M10
5	wRegistrationDataByteCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	DO
6	wUserControlData	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D1
7	wnInitializationCommand	String(32)(011)	 VAR_GLOBAL	¥	D2

(0)	C24_1.bSts_UnitR eady X1E	C24_1.bSts_Watc hdogTimerError X1F					bUnitAccessibleFI ag M0
(3)	bReq_Initialization DataRegistration X23					PLS	bReq_Initialization DataRegistration2 M10
(6)	bReq_Initialization DataRegistration2 M10				MOV	K30	wRegistrationData ByteCount D0
					MOV	К1	wUserControlData D1
					\$MOV	"ATE1Q0V1&C1&D2& K3&S0S0="	wnInitializationCo mmand D2
		bUnitAccessible Flag M0		 BMOV	D0	C24_1.wnForUserRegi strationNo8001H_D[0] U0¥G6912	K17
						SET	bInitializationComp letion M1
(33)							(END )

(6) Set the registration data byte count.

Set the user control data (control number).

Set the AT command for initialization to buffer memory.

Set the initialization flag.



# Register/read/delete data for connection

This section explains the registration/reading/deletion of data for connection such as the telephone number of the target device that are used for communicating data with target devices using the modem function.

### Details of the data for connection

The following shows the registration destination and type of the data for connection, registration number, and registration count.

The maximum number of bytes for data that can be registered as one data for connection is 80 bytes. (Connection data portion: 44 bytes, free: 36 bytes)

Registration data for con	destination of nection	Types of data for connection that is registered	Registration number of data for connection	Number of registrations	Remarks		
CPU module	Built-in memory	Data registered by the user*1	3000 to 3029 (BB8H to BD5H)	30	<ul> <li>Register the data for connection after the debug process has been completed.</li> <li>Registration in this area enables easy replacement of C24.</li> </ul>		
	SD memory card	Data registered by the user <sup>*1</sup>	3000 to 3029 (BB8H to BD5H)	30	<ul> <li>Register the data for connection after the debug process has been completed.</li> <li>Registration in this area enables easy replacement of C24.</li> </ul>		
C24	Flash ROM	Data registered by the user <sup>*1</sup>	3000 to 3029 (BB8H to BD5H)	30	<ul> <li>Register the data for connection after the debug process has been completed.</li> </ul>		
	Buffer memory	Data registered by the user	–32767 to –32737 (8001H to 801FH)	31	<ul> <li>Register the data for connection after the debug process has been completed.</li> </ul>		

\*1 For the priority of the registered data, refer to the following section.  $\square$  Page 401 PARAMETER REGISTRATION TO CPU MODULE

# Considerations for registration of data for connection

• The registration status of the data for connection stored in the flash ROM can be checked in the buffer memory (Un\547 to 549).

For initial registration, register by designating an unregistered number.

When designating a registration number that has already been registered, first delete the registration data for the designated number prior to registration.

## Method to register/read/delete data for connection

### Setting with Engineering tool

Set the data using the C24 module extended parameter.

- Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module Name ⇒ [Module Extended Parameter] ⇒ [Modem connection data]
- $\bullet$ : Required,  $\bigcirc$ : Configurable,  $\times$ : Not required

Setting item		Data communication (MC, nonprocedural, bidirectional)
Modem connection data 1 to 30	Telephone number	•
	External line outgoing number	0
	Line type	0
	Wait time for message transmission (unit: s)	×
	Message	×
	Comment	0

### ■For the buffer memory of C24

Designate the applicable area corresponding to the registration No., 8001H to 801FH in respect to the area for user frame registration (Un\G6912 to 8128), and write (register)/read the data for connection.

When deleting the data for connection, write "0" to the registration data byte count designation area of the applicable number.

• The following shows the overview of buffer memory that are used for writing/reading/deleting processing for data connection and the setting value of each area.

For more details, refer to the following section. (Refer to it by substituting the user frame to data for connection.) (IPP Page 250 CONTENTS AND REGISTRATION OF USER FRAMES FOR DATA COMMUNICATION)

Delete
0
<sup>1</sup> ×
0
۱ ×
sir :d) sir ed)

1FCEH	8142	Registration No.801FH	Registration data byte count designation	0 : When deleting 80: Number of registered data bytes	0	× (Read	0
1FCFH to 1FF6H	8143 to 8182		Data for connection	Data for connection that is registered		processin g not required)	×

• The following shows the data arrangement of the area for data for connection (area corresponding to registration numbers 8001H to 801FH) in the buffer memory that is used to register, read and delete data for connection, as well as the designated values and stored values.



#### Connection data portion (44 bytes)

Data name	Designated/stored value and contents	Number of bytes	Data type
(Open)	Designate "0".	2	Binary
Telephone number	<ul> <li>Designate the telephone number of the target device side to establish the line connection to the target device side with which data are communicated.</li> <li>When the phone number is less than 18 characters, a space (code:20H) must be entered for the remainder.</li> </ul>	18	ASCII
External line outgoing number	Designate the external line outgoing number on the C24 side to establish the line connection to the target device with which data is communicated. External line outgoing number on the C24 side • 0 to 9 • 10(*) • 11(#) No external line outgoing number required on the C24 side • 255	2	Binary
Line type	Designate the line type used to perform data communication with the target device. • 0 : Pulse • 1 : Tone • 2 : ISDN	2	Binary
(Open)	Designate "0".	20	Binary
(Open)	Designate "0".	36	Binary

### ■Program example

An example of a program used for writing data for connection is shown below.

Example of writing data for connection to the registration number 8002H area

Label name	Description	Device
C24_1.bSts_UnitReady	Module READY	X1E
C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
C24_1.wnForUserRegistrationNo8002H_D[0]	For user registration number 8002H	U0\G6953
	Label name         C24_1.bSts_UnitReady         C24_1.bSts_WatchdogTimerError         C24_1.wnForUserRegistrationNo8002H_D[0]	Label nameDescriptionC24_1.bSts_UnitReadyModule READYC24_1.bSts_WatchdogTimerErrorWatchdog timer errorC24_1.wnForUserRegistrationNo8002H_D[0]For user registration number 8002H

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class		Assign (Device/Label)
1	bReq_InitializationDataRegistration	Bit	 VAR_GLOBAL	•	X27
2	bUnitAccessibleFlag	Bit	 VAR_GLOBAL	•	MO
3	bConnectionDataRegistrationCompletion	Bit	 VAR_GLOBAL	•	M2
4	wRegistrationDataByteCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	DO
5	wnConnectionData	Word [Signed](021)	 VAR_GLOBAL	•	D1
6	bReq_ConnectionDataRegistration	Bit	 VAR_GLOBAL	•	M20

(0)	C24_1.bSts_UnitR eady X1E	C24_1.bSts_Watc hdogTimerError X1F		 				bUnitAccessibleFlag M0 O
(3)	bReq_Initialization DataRegistration X27						PLS	bReq_ConnectionDataRe gistration M20
(6)	bReq_Connection DataRegistration M20					ΜΟΥ	K80	wRegistrationDataByteC ount D0
				 	FMOV	КО	wnConnectionData[0] D1	K40
			 	 		\$MOV	″052nnnnnn ″	wnConnectionData[1]
						\$100		D2
				 		MOV	H0	wnConnectionData[10] D11
						MOV	K1	wnConnectionData[11] D12
		bUnitAccessibleF lag M0			BMOV	wRegistrationDat aByteCount D0	C24_1.wnForUserRegi strationNo8002H_D[0] U0¥G6953	K41
				 			SET	bConnectionDataRegistr ationCompletion M2
(25)								(END )

(0) Turn the READY flag ON.

(3) Issue the registration command of data for connection.

(6) Set the number of registered data bytes.

Clear the storage device of data for connection.

Set the connection target telephone number.

Set the external line outgoing number (send 0).

Set the line type to 'Tone'.

Write the data for connection to buffer memory.

Turn the data for connection registration completion flag ON.

(Item name)		Data register		(Address)	Buffer memory Area for registration No	. 8002H
Number of registration	D0	80	<b>→</b>	Un\G6953	80	rer memory egistration No. 8002H 80 ction data) /pen)
data bytes	D1			Un\G6954		
	to	(Connection data)		to	(Connection data)	
Data far connection	D22			Un\G6975		
Data for connection	D23			Un\G6976		
	to	(Open)		to	(Open)	
	D40			Un\G6993		

# Initialization of modem/TA (terminal adapter)

This section explains the initialization of the modem/TA connected to C24, used for communicating data with the target device with the modem function.

## **Requirements for initialization**

Complete the following settings and registration beforehand.

- C24 initial settings ( I Page 174 Initial settings of Serial communication module)
- Registration of data for initialization when initializing with the data for initialization set by the user ( Page 177 Register/ read/delete data for initialization)

Initialization and connection can be performed at the same time by performing the connection processing by designating data for initialization and connection. ( 🖙 Page 190 Line connection)

# Registering data for initialization using Engineering tool

Registration of the number of data for initialization to initialize the modem connected to the C24 side is performed with Engineering tool.

The following explains the number designated by the "Initialization data number" item and the related buffer memory when "0" is designated as the number of data for initialization.

Used buffer r	nemory			The number of data for initialization used and buffer memory designate				
Name		Address (C	H1/CH2)	value				
		Hexadeci mal	Decimal	When number of data used = 1	When number of data used = 2 or more			
Data No. for initi designation	alization	34H	52	7D0H to 801FH :Registration number of data for initialization <sup>*3</sup>	ОН			
Sending user fra	ame number	B6H/156H	182/342	(Not used)	(During initialization, the registration number of data currently being transmitted is stored.)			
CR/LF output de	esignation	B7H/157H 183/343			0 (default value)			
Output start poir designation <sup>*1</sup>	nter	B8H/158H	184/344		1 to 100 <sup>*1</sup>			
Output quantity	designation <sup>*2</sup>	B9H/159H	185/345		1 to 100 <sup>*2</sup>			
Send frame	1st	BAH/15AH	186/346		7D0H to 801FH :Registration number of data			
number designation	2nd	BBH/15BH	187/347		for initialization <sup>"3</sup>			
acoignation	to	to	to					
	100th	11DH/1BDH	285/445					

- \*1 'Output start pointer designation' (Un\G184/344) The head position (nth) in the send frame number designation area to write the registration number of data for initialization to be transmitted is designated.
  1 (transmitting from the 1st) to 100 (transmitting from the 100th)
- \*2 'Output quantity designation' (Un\G185/345)
  How many data for initialization is transmitted form the designated position in the output start pointer designation area is designated.
  1 (transmitting 1) to 100 (transmitting 100)
- \*3 The registration number of data for initialization to be used is designated.
  •7D0H to 7DDH (2000 to 2013) : Data registered by the operating system
  •9C4H to 9E1H (2500 to 2529) : Data registered in the flash ROM by the user
  •8001H to 801FH (-32767 to -32737): Data registered in the buffer memory by the user

# Considerations for modem/TA initialization

If the DSR signal from the modem/ TA turns OFF when modem/TA initialization is completed (X10 turns ON), C24 executes initialization processing automatically in accordance with the following.

· When the auto modem initialization is specified

Modem/TA initialization processing is executed in the initialization/connection timeout time interval while the DSR signal is OFF regardless of the ON/OFF status of the 'Modem initialization request' (Y10).

· When the auto modem initialization is not specified

The modem/TA initialization processing is executed when the DSR signal restarts regardless of the ON/OFF status of the 'Modem initialization request' (Y10).

# Automatic modem/TA initialization (Setting with Engineering tool)

By configuring the settings for automatic modem initialization with Engineering tool, modem initialization is executed automatically when C24 starts up.

The 'Modem initialization completion' (X10) turns ON.

# Settings for auto initialization of the modem / TA

Select "Automatically initialize" for the auto modem initialization designation of Engineering tool.

### Considerations for initializing the modem / TA automatically

- If the modem's initialization processing is completed abnormally, C24 executes the following processing.
- C24 does not turn ON the 'Initialization/connection abnormal completion' (X13).
- C24 stores an error code in the 'Modem function error code' (Un\G545).
- C24 retries the modem initialization automatically by using the initialization/connection timeout time stored in the 'Initialization/connection timeout designation' (Un\G50), and repeats it until the initialization is completed normally. When modem initialization is not completed normally, perform the following, and restart the station where C24 is installed. Check the set initialization data number.

Check the registered contents of the initialization data corresponding to the set initialization data number. (If any abnormal, correct them and register them again.) Check if the power of the modem is turned ON.

• When the 'Modem disconnection request' (Y12) is used from the C24 side, the 'Modem initialization completion' (X10) turns OFF together with the 'Connection' (X12).

When connecting to the line again, start from the modem initialization.

### Point *P*

When the line to C24 is disconnected from the target device side, the C24's 'Modem initialization completion' (X10) does not turn OFF.

When desiring to disable reception by the C24 side's modem, execute line disconnect by the 'Modem disconnection request' (Y12).

# Modem/TA initialization with a program

### ■I/O signals used for initialization

The 'Modem initialization request' (Y10), 'Modem initialization completion' (X10) and 'Initialization/connection abnormal completion' (X13) are used.

## Ex.

When initializing the modem connected to CH1 of C24 using two set of data for initialization (registration numbers 8001H and 8002H) that are registered in the buffer memory



### ■Program example

An example of the modem/TA initialization program on the C24 side by the CPU module is shown below.

(When the data for initialization has been registered with Engineering tool or from the CPU module)

Category	Label name	Description	Device
Module label	C24_1.bSts_ModemInitializationCompletion	Modem initialization completion	X10
	C24_1.bSts_ConnectionProcessing	Connection	X12
	C24_1.bSts_Initialization_Connection_AbnormalCompletion	Initialization/connection abnormal completion	X13
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
	C24_1.bSet_Req_ModemInitialization	Modem initialization request	Y10
	C24_1.uErrorCode_ModemFunction_D	Modern function error code	U0\G545
I abel to be defined	Define the global label as shown below		

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class		Assign (Device/Label)
1	bReq_Initialization	Bit	 VAR_GLOBAL	-	×20
2	bReq_Clear	Bit	 VAR_GLOBAL	•	X27
3	bUnitAccessibleFlag	Bit	 VAR_GLOBAL	•	MO
4	bInitializationDataRegistrationCompletion	Bit	 VAR_GLOBAL	•	M1
5	bInitializationCompletion	Bit	 VAR_GLOBAL	•	М3
6	wInitializationErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D100
7	bInitializationPossibleFlag	Bit	 VAR_GLOBAL	•	M30
8	bReqPulse_Initialization	Bit	 VAR_GLOBAL	•	M31
9	bReg Initialization2	Bit	 VAR GLOBAL	•	M39

(0)	C24_1.bSts_U nitReady X1E	C24_1.bSts_Watchdog TimerError X1F								bUnitAccessibleFla g M0
(3)	bUnitAccessi bleFlag M0	bInitializationDataRegi strationCompletion M1	bInitializatio nCompletion M3	C24_1.bSts_Mode mInitializationCom pletion X10	C24_1.bSts_C onnectionPro cessing X12	C24_1.bSts_Initialization_ Connection_AbnormalCo mpletion X13	C24_1.bSet_Req_ ModemInitializatio Y10			bInitializationPossi bleFlag M30
(11)	bReq_Initializa tion X20								PLS	bReqPulse_Initializ ation M31
(14)	bReqPulse_Ini tialization M31	bInitializationPossibleF lag M30							SET	C24_1.bSet_Req_M odemInitialization Y10
									SET	bReq_Initialization2 M39
(18)	C24_1.bSet_R eq_ModemIniti alization Y10	C24_1.bSts_ModemIniti alizationCompletion X10							SET	bInitializationComp letion M3
									RST	C24_1.bSet_Req_M odemInitialization Y10
		C24_1.bSts_Initializatio n_Connection_Abnorm alCompletion X13	bUnitAccess ibleFlag M0					MOVP	C24_1.uErrorCod e_ModemFunctio n_D U0¥G545	wInitializationError Code D100
									RST	C24_1.bSet_Req_M odemInitialization Y10
(34)	bReq_Clear X27								RST	bReq_Initialization2 M39
									RST	bInitializationComp letion M3
(37)										
(=))				<u> </u>						{END }
(0) (3) (11)	Turn the Turn the Issue the	READY flag ON. modem initializat modem initializa	ion applic	able flag ON. nand.			<u>.</u>	 		5

(14) Set the initialization request signal.

Set the initialization request flag.

Set the initialization completion flag.
 Read the error code at initialization abnormal completion.

(34) Reset the flag with the clear command.

# Line connection

The following explains the connection (dialing) with target devices for data communication with target devices using the modem function.

### **Requirements for connection**

Complete the following settings and registration in advance.

- The initial settings for C24 (FP Page 174 Initial settings of Serial communication module)
- The registration of the data for initialization ( I Page 177 Register/read/delete data for initialization)
- The registration of data for connection ( I Page 181 Register/read/delete data for connection)
- The initialization of the modem/TA connected to C24 side ( IP Page 185 Initialization of modem/TA (terminal adapter))

In addition, both the initialization and line connection can be conducted simultaneously by designating the data for initialization and data for connection to perform connection processing.

For setting of data for initialization to perform initialization and line connection simultaneously, refer to the following sections. It is not explained in this section.

Page 174 Initial settings of Serial communication module

Page 185 Initialization of modem/TA (terminal adapter)

# Registering the data for connection using Engineering tool

The number for the data for connection that is used for line connection in order to perform data communication with the target device is registered with Engineering tool.

### ■When line connecting from the C24 side

Designate the registration number of the data for connection to be used for "Data No. for connection designation".

- Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ Module Name ⇔ [Module Parameter] ⇔ "Application Settings" ⇔ "Modem function setting"
- BB8H to BD5H (3000 to 3029) : Data registered in the flash ROM by the user
- 8001H to 801FH (-32767 to -32737): Data registered in the buffer memory by the user

### ■When line connecting from the target device

Since the line connection processing is not necessary on the C24 side, registration of data for connection to connect the line and number setting of data for connection are not required.

### Input/output signals used for line connection

'Connection request' (Y11), 'Dialing' (X11), 'Connection' (X12) and 'Initialization/connection abnormal completion' (X13) are used.

# Ex.

When performing the line connection only from the C24 side after the completion of initialization



\* Connection channel and retry operation are performed using the buffer memory setting.

### **Ex.** When performing the initialization and the line connection from the C24 side simultaneously



\* Connection channel and retry operation are performed using the buffer memory setting.

\*1 Page 185 Initialization of modem/TA (terminal adapter)

### **Ex.** When performing the line connection from the target device after the completion of initialization

Buffer memor connec (Un\0	y for ction 353)	0
Connection request	Y11 _	(OFF)
Modem initialization completion	X10	(ON)
Dialing	X11	(OFF)
		(Normal connection)
Connecting	X12	
	-	(Normal connection)
RS-232 CD termin	al	
	-	
* Set "Display a res using the AT com the Host station si	ult code mand" ir de mode	Reception       Result code receive *         Image: Communication using MC protocol
Point P	• The	connection channel on the C24 side is set in the module parameter

- The connection channel on the C24 side is set in the module parameter.
- Abnormal processing when the target device initiate the line connection is left entirely to the target device. There is no method on the C24 side to check a line connection error occurrence at the target device.
- When a remote password check is performed for the CPU module, normal completion of the unlock processing enables data communication thereafter.

### Considerations during the line connection

- Prior to data communication with target devices, determine when and which station will perform the line connection (dialing) and line disconnection processing to the target device.
- Use the following method to perform the unlock processing for the CPU module remote password from the target device. During communication using MC protocol, transmit the dedicated command to the C24 side.

For countermeasures against abnormal completion of the unlock processing, refer to the following section.

( I Page 167 When the remote password unlock processing is completed abnormally)

• When reconnecting the line after disconnection, allow several seconds for the modem before turning ON the 'Connection request' (Y11).

If it (Y11) is turned ON immediately after line disconnection, the modem may not accept the first connection request, resulting in connection failure, and may require to wait the retry time.

# Line connection program

An example of a line connection program is shown below.

# ■Program example (When establishing the line connection from the C24 side following the completion of initialization)

When the data for connection has been registered with Engineering tool or from the CPU module

Category	Label name	Description	Device
Module label	C24_1.bSts_ModemInitializationCompletion	Modem initialization completion	X10
	C24_1.bSts_ConnectionProcessing	Connection	X12
	C24_1.bSts_Initialization_Connection_AbnormalCompletion	Initialization/connection abnormal completion	X13
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
	C24_1.bSet_Req_ModemInitialization	Modem initialization request	Y10
	C24_1.bSet_Req_Connection	Connection request	Y11
	C24_1.uErrorCode_ModemFunction_D	Modern function error code	U0\G545
Label to be defined	Define the global label as shown below.	·	
	Label Name Data Type	Class Assign (Device/Label)	

	Label Name	Data Type	Llass		Assign (Device/Label)
1	bReq_Connection	Bit	 VAR_GLOBAL	•	X21
2	bReq_ConnectionClegr	Bit	 VAR_GLOBAL	•	X27
3	bUnitAccessibleFlag	Bit	 VAR_GLOBAL	•	MO
4	bConnectionDataRegistrationCompletion	Bit	 VAR_GLOBAL	•	M2
5	bInitializationCompletion	Bit	 VAR_GLOBAL	•	M3
6	bConnectionCompletion	Bit	 VAR_GLOBAL	•	M4
7	bConnectionPossibleFlag	Bit	 VAR_GLOBAL	Ŧ	M40
8	bReq_Connection2	Bit	 VAR_GLOBAL	•	M41
9	bDisconnectionFlag	Bit	 VAR_GLOBAL	Ŧ	M49
10	wConectionAbnormalCompleteErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	٠	D101

(0)	C24_1.bSts_Unit Ready X1E	C24_1.bSts_WatchdogTi merError X1F								bUnitAccessible Flag M0
(3)	bUnitAccessible Flag M0	bConnectionDataRegistr ationCompletion M2 	bInitializati onComplet ion M3	C24_1.bSts_Mod emInitializationC ompletion X10	C24_1.bSts_Co nnectionProce ssing X12	C24_1.bSts_Initializa tion_Connection_Ab normalCompletion X13	C24_1.bSet_ Req_Connect ion Y11			bConnectionPos sibleFlag M40
• Re • Re • Mo	gistration of o gistration of o odem/TA initia	data for initialization data for connection alization	) 			<u></u>		 		
(106)	bReq_Connectio n X21								PLS	bReq_Connectio n2 M41
(109)	bReq_Connectio n2 M41	bConnectionPossibleFla g M40							SET	C24_1.bSet_Req_ Connection Y11
									SET	bDisconnection Flag M49
(113)	C24_1.bSet_Req_ Connection Y11	C24_1.bSts_ConnectionP rocessing X12							SET	bConnectionCo mpletion M4
									RST	C24_1.bSet_Req_ Connection Y11
		C24_1.bSts_Initialization_ Connection_AbnormalCo mpletion X13	bUnitAcce ssibleFlag M0					MOVP	C24_1.uErrorCod e_ModemFunctio n_D U0¥G545	wConectionAbn ormalCompleteE rrorCode D101
									RST	C24_1.bSet_Req_ Connection Y11
(129)	bReq_Connectio nCleqr X27								RST	bDisconnection Flag M49
									RST	bConnectionCo mpletion M4
(132)										(END )

(14)

(41) Register data for connection.

to SP Page 184 Program example

(44)

(75) Modem/TA initialization

to Page 188 Program example

(90)

(106) Issue the line connection command.

(109) Set the connection request signal.

(113) Set the connection completion flag when the connection signal is turned ON (normal completion). Read the error code at connection error.

(129) Reset the flag with the clear command.

# ■Program example (When performing the initialization and the line connection from the C24 side simultaneously)

When the data for initialization and connection have been registered with Engineering tool or from the CPU module

Category	Label name	Description	Device
Module label	C24_1.bSts_ModemInitializationCompletion	Modem initialization completion	X10
	C24_1.bSts_ConnectionProcessing	Connection	X12
	C24_1.bSts_Initialization_Connection_AbnormalCompletion	Initialization/connection abnormal completion	X13
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
	C24_1.bSet_Req_ModemInitialization	Modem initialization request	Y10
	C24_1.bSet_Req_Connection	Connection request	Y11
	C24_1.uErrorCode_ModemFunction_D	Modern function error code	U0\G545
Label to be defined	Define the global label as shown below.		
	Label Name Data Type	Class Assign (Device/Label)	

	Label Name	Data Type	Liass		Assign (Device/L
1	bReq_Connection	Bit	 VAR_GLOBAL	•	X21
2	bReq_ConnectionCleqr	Bit	 VAR_GLOBAL	•	X27
3	bUnitAccessibleFlag	Bit	 VAR_GLOBAL	•	MO
4	bInitializationCompletion	Bit	 VAR_GLOBAL	•	M3
5	bConnectionCompletion	Bit	 VAR_GLOBAL	Ŧ	M4
6	bConnectionPossibleFlag	Bit	 VAR_GLOBAL	•	M40
7	bReq_Connection2	Bit	 VAR_GLOBAL	•	M41
8	bDisconnectionFlag	Bit	 VAR_GLOBAL	•	M49
9	wErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	Ŧ	D101
10	bConnectionDataRegistrationCompletion	Bit	 VAR GLOBAL	•	M2

(0)	C24_1_bSts_Unit Ready X1E	C24_1.bSts_WatchdogTi merError X1F									bUnitAccessible Flag M0
(3)	bUnitAccessible Flag M0	bConnectionDataRegist rationCompletion M2	bInitialization Completion M3	C24_1.bSts_Mode mInitializationCom pletion X10	C24_1.bSts_Conn ectionProcessing X12	C24_1.bSts_Initializatio n_Connection_Abnorm alCompletion X13	C24_1.bSet_Req_ ModemInitializati on Y10	C24_1.bSet_R eq_Connectio n Y11			bConnectionPo sibleFlag M40
Re Re	egistration o egistration o	f data for initializa f data for connec	ation tion								
76)	bReq_Connectio n X21									PLS	bReq_Connecti n2 M41
(79)	bReq_Connectio n2 M41	bConnectionPossibleFla g M40								SET	C24_1.bSet_Re Connection Y11
										SET	bDisconnection lag M49
83)	C24_1.bSet_Req _Connection Y11	C24_1.bSts_Connection Processing X12								SET	bInitializationC mpletion M3
										SET	bConnectionCo pletion M4
										RST	C24_1.bSet_Re Connection Y11
		C24_1.bSts_Initialization _Connection_AbnormalC ompletion X13 	bUnitAccessi bleFlag M0						MOVP	C24_1.uErrorCode_Mode mFunction_D U0¥G545	wErrorCode D101
										RST	C24_1.bSet_Re Connection Y11
00)	bReq_Connectio nCleqr X27									RST	bDisconnectior lag M49

(12) Register data for initialization.

to 🖙 Page 180 Program example

(15)

(42) Register data for connection.

to Page 184 Program example

(45)

(76) Issue the line connection command.

(79) Set the connection request signal.

(83) Set the connection completion flag when the connection signal is turned ON (normal completion). Read the error code at connection error.

(100) Reset the flag with the clear command.



When the line connection is initiated from the target device, any of the registration, setting or connection processing related to the line connection is not necessary.

Data communication is available when the 'Connection' (X12) turns ON after the completion of the C24 modem/TA initialization.

Page 191 Input/output signals used for line connection

For program example of the modem/TA for initialization, refer to the following section.

 $\boxtimes$  Page 187 Modem/TA initialization with a program

# **Data communication**

The following explains the considerations for data communication with target devices using the modem function.

### **Requirements for data communication**

## When communicating data with target devices

Perform the appropriate processing up to line connection or modem/TA initialization, depending on whether or not the line connection is initiated from the C24 side.

After line connection, data communication can be performed using an MC protocol/nonprocedural protocol/bidirectional protocol in full-duplex communication.

- When line connecting from the C24 side, complete the processing up to line connection beforehand. (SP Page 190 Line connection)
- When line connecting from the target device, complete the processing up to the initialization of the modem/TA beforehand. (IPP Page 185 Initialization of modem/TA (terminal adapter))

### Buffer memory and input/output signals to be used

### When communicating data with target devices

Only buffer memory and input/output signals used for data communication (MC protocol/nonprocedural protocol/bidirectional protocol) is used.

Communicate data using the ON of 'Connection' (X12) as the interlock signal.



There is no input/output signal or buffer memory for modem functions used in data communication.



### General procedure

This section explains the general procedure for nonprocedural protocol/bidirectional protocol (executed in full-duplex communication) data communication using the modem function between the CPU modules with C24 installed.

### ■System configuration



### ■General procedure

- **1.** Perform initial setting for C24 at both station A and station B.
- 2. Perform modem/TA initialization on station B.
- 3. Perform modem/TA initialization and line connection on station A.
- **4.** Communicate data using the nonprocedural protocol/bidirectional protocol.
- 5. In order to end the communication, disconnect line from station A that initiated the line connection.

## ■Processing flow

Station A (connection request side)	Connection	Communication	Disconnection
Connection Y11			
Modem initialization X10 completion			-
Connecting X12			<b>, *</b>
Disconnection Y12 request			
Disconnection X14 completion			
RS-232 CD terminal	, , , , , , , , , , , , , , , , , , ,	1 1 1 1 1	
Station B (connection reception side)			
Modem initialization X10 completion	(ON)		
Connecting X12	<b>x</b>		
Disconnection Y12 request			(OFF)
Disconnection X14 completion			(OFF)
RS-232 CD terminal			<b>`</b> ▶

\* It is possible to disconnect line from Station B, as well.

# Considerations for performing data communication

### When communicating data with the target device

- When setting the no-communication interval time to 'Infinite wait' (setting value = 0) in the initial setting of C24, be sure to perform line disconnection after the completion of data communication.
- Only the nonprocedural protocol/bidirectional protocol data communication can be performed with the CPU module with C24 installed.
- C24 automatically performs line disconnection processing if no data communication is performed during the nocommunication interval time.

The 'Connection' (X12) and the 'Modem initialization completion' (X10) turn OFF and the 'Modem disconnection completion' (X14) turns ON when the line disconnection processing is performed.

# Line disconnection

The following explains the line disconnection upon communication completion when communicating data with the target device using the modem functions.

## Input/output signals to be used

Use the 'Modem disconnection request' (Y12) and 'Modem disconnection completion' (X14).



### Point P

- There is no buffer memory for line disconnection processing.
- Line disconnection processing can be conducted from either device as long as the connection is in progress.
- The line disconnection processing disconnects the line connection with the target device as well as the connection with the modem on the C24 side.
- Even when an error occurs during the line disconnection, the disconnection processing will be forced.
- When resuming data communication after line disconnection, start form either one of the following processing depending on the 'Modem initialization completion' (X10).
   'Modem initialization completion' is OFF: Start from the initialization of the modem/TA.
   'Modem initialization completion' is ON: Start from the line connection with the target device.

### Considerations during the line disconnection

- · Prior to data communication with target devices, determine when and which station will perform the line connection (dialing) and line disconnection processing to the target device.
- · If the line is disconnected during data transmission, transmission processing will be performed depending on the signal status of the C24 RS-232 interface.
- If the line is disconnected during data reception, data reception will be disabled. This may cause an error occurrence such as a reception time out.
- · When data communication is not performed for the period equivalent to the no-communication interval time designation, C24 will automatically disconnect the line.

When the line is disconnected, the 'Connection' (X12) and the 'Modem initialization completion' (X10) turn OFF, and the 'Modem disconnection completion' (X14) turns ON.

To turn OFF the 'Modem disconnection completion' (X14), turn ON the 'Modem disconnection request' (Y12) for a second after the 'Modem disconnection completion' (X14) turned ON.

### Program for line disconnection

A program example for line disconnection is shown below.

11 wErrorCode

12 bReq\_DisconnectionSignal

### ■Program example

Category	Label name				Dese	cription		Device
Module label	C24_1.stnCH1.bSts_Transmission	NormalCompleti	on		CH1	Transmission normal	completion	X0
	C24_1.stnCH1.bSts_Transmission	nAbnormalEnd			CH1	Transmission abnorm	al completion	X1
	C24_1.bSts_ModemInitializationC	ompletion		Mode	m initialization comple	etion	X10	
	C24_1.bSts_DialProcessing				Dialir	ıg		X11
	C24_1.bSts_ConnectionProcessir	ng			Conn	ection		X12
	C24_1.bSts_Initialization_Connec	tion_AbnormalCo	ompl	etion	Initial comp	ization/connection abi	X13	
	C24_1.bSts_DisconnectionCompl	etion			Mode	m disconnection com	pletion	X14
	C24_1.bSts_UnitReady				Modu	Ile READY		X1E
	C24_1.bSts_WatchdogTimerError				Watc	hdog timer error		X1F
	C24_1.stnCH1.bSet_Req_Recept	ionRead			CH1	Reception data read r	equest	X3
	C24_1.stnCH1.bSts_ReceptionAb	normalDetection			CH1	Reception abnormal c	letection	X4
	C24_1.stnCH1.bSet_Req_Transm	nission	ssion			Transmission request	Y0	
	C24_1.stnCH1.bSet_Req_Recept	ionReadComplet	tion		CH1	Reception data read of	completion	Y1
	C24_1.bSet_Req_ModemInitializa	ation	tion			m initialization reques	st	Y10
	C24_1.bSet_Req_Connection					ection request		Y11
	C24_1.bSet_Req_Disconnection					m disconnection requ	lest	Y12
	C24_1.uErrorCode_ModemFunct	ion_D	on_D			ern function error code	U0\G545	
	C24_1.wnForUserRegistrationNo	3001H_D[0]			For u	ser registration numb	U0\G6912	
	C24_1.wnForUserRegistrationNo	3002H_D[0]			For u	ser registration numb	U0\G6953	
Label to be defined	Define the global label as shown l	pelow.		I				
	Label Name	Data Type		Class VAB GLOBAL	-	Assign (Device/Label)		
	2 bUnitAccessibleFlag	Bit		VAR GLOBAL	· ·	MO		
	3 bDisconnectionCompletion	Bit		VAR_GLOBAL	. 🔻	M7		
	4 bDataTransmissionPossibleFlag	Bit		VAR_GLOBAL	•	M50		
	5 bDisconnectionPossibleFlag	Bit		VAR_GLOBAL	•	M70		
	6 bReqPulse_Disconnection2	Bit		VAR_GLOBAL	-	M71		
	7 bDisconnectionStatus	Bit		VAR_GLOBAL	AL 🗸 M72			
	8 bReq_Disconnection	Bit		VAR_GLOBAL	•	M78		
	9 bDisconnectionExecuting	Bit		VAR_GLOBAL	•	M79		
	10 wDisconnection limer	l imer		VAR_GLUBAL	•	15		
	11 WErrorCode	[Word [Signed]		TVAR_GLUBAL	•	0105		

VAR GLOBAL

▼ M77

Word [Signed]

Bit

(0)	C24_1.bSts_U nitReady X1E	C24_1.bSts_Watchdog TimerError X1F										bUnitAccessi bleFlag M0
• Re • Re • Mo • Lir	l egistration egistration odem/TA in ne connect	of data for initia of data for conr nitialization tion	lization lection									<u></u>
(133)	bUnitAccessi bleFlag M0	C24_1.bSts_ModemIni tializationCompletion X10	C24_1.bSts_Connec tionProcessing X12									bDataTransm issionPossibl eFlag M50
(137)	bDataTransmi ssionPossible Flag M50	C24_1.stnCH1.bSts_T ransmissionNormalCo mpletion X0	C24_1.stnCH1.bSts_ TransmissionAbnor malEnd X1	C24_1.stnCH1bS et_Req_Reception Read X3	C24_1.stnCH1.bSts_ ReceptionAbnormal Detection X4	C24_1.stnCH1.bSet_ Req_Transmission Y0	C24_1.stnCH1.bSet_ Req_ReceptionRead Completion Y1	C24_1.bSet_Re q_Disconnectio Y12				bDisconnecti onPossibleFla M70
(146)	bReq_Connec tion X23										PLS	bReqPulse_Di sconnection2 M71
(149)	bReqPulse_Di sconnection2 M71	bDisconnectionPossi bleFlag M70									RST	bDisconnecti onCompletion M7
											SET	C24_1.bSet_R eq_Disconnec tion Y12
											SET	bDisconnecti onExecuting M79
	bDisconnecti onExecuting	C24_1.bSet_Req_Disc onnection	C24_1.bSts_ModemI nitializationComplet	C24_1.bSts_Conn ectionProcessing	C24_1.bSts_Disconn ectionCompletion	bUnitAccessibleFlag M0				MOVP	C24_1.uErrorCode_ ModemFunction_D	wErrorCode
(154)	M79	Y12	×10	×12	×14		1				U0¥G545	D105
(154)	M79	Y12		X12			=	КО	wErrorCod e D105		U0¥G545 SET	D105 bDisconnecti onCompletion M7
(154)	M79	Y12					=	КО	wErrorCod e D105		U0¥G545 SET	D105 bDisconnecti onCompletion M7 bDisconnecti onStatus M72
(154)	M79 bDisconnecti onStatus M72	Y12 C24_1.bSts_Disconne ctionCompletion X14					=	КО	wErrorCod e D105		UU¥G545 SET SET RST	D105 bDisconnecti onCompletion M7 bDisconnecti onStatus M72 C24_1bSet_R eq_Disconnec tion Y12
(154)	M79 bDisconnecti onStatus M72 1	Y12 C24_1,bSts_Disconne ctionCompletion X14 C24_1.bSts_Disconne ctionCompletion X14						КО	wErrorCod e D105		UU¥G545 SET SET RST RST	D105 bDisconnecti onCompletion M7 bDisconnecti onStatus M72 C24.1.bSet_R eq_Disconnection Y12 bDisconnection Y12 bDisconnection M7
(154)	M79 bDisconnecti onStatus M72	V12 C24_1.bSts_Disconne ctionCompletion X14 C24_1.bSts_Disconne ctionCompletion X14						КО	wErrorCod e D105		UU¥G545 SET SET RST RST	D105 bDisconnecti onCompletion M7 bDisconnecti ionStatus M72 C24.1.bSet_R eq_Disconnecti ionCompletion M7 bDisconnecti onCompletion M7
(154)	M79 bDisconnecti onStatus M72 I	V12 C24_1.bSts_Disconne ctionCompletion X14 C24_1.bSts_Disconne ctionCompletion X14						КО	wErrorCod e D105		UU¥GS45 SET SET RST RST RST	D105 bDisconnecti onCompletion M7 bDisconnecti onStatus M72 C24.1.bSet,R eq.Disconnecti ionCompletion M7 bDisconnecti onCompletion M7 bDisconnecti onStatus M72 bDisconnecti onStatus M72

(184)	bReqPulse_Di sconnection2 M71	C24_1.bSet_Req_Disc onnection Y12							RST	C24_1.bSet_R eq_ModemInit ialization Y10
									RST	C24_1.bSet_R eq_Connectio n Y11
			C24_1.bSts_ModemI nitializationComplet ion X10			-			SET	C24_1.bSet_R eq_Disconnec tion Y12
			C24_1.bSts_Disconn ectionCompletion X14						SET	bReq_Disconr ection M78
(193)	bReq_Disconn ection M78							OUT	wDisconnectionTi mer T5	K10
		wDisconnectionTimer T5							RST	bReq_Discon ection M78
									SET	bReq_Discon ectionSignal M77
(201)	bReq_Disconn ectionSignal M77	C24_1.bSet_Req_Disc onnection Y12	C24_1.bSts_ModemI nitializationComplet ion X10	C24_1.bSts_Conn ectionProcessing X12	C24_1.bSts_Disconn ectionCompletion X14				RST	C24_1.bSet_R eq_Disconnec tion Y12
		C24_1.bSet_Req_Disc onnection Y12	C24_1.bSts_ModemI nitializationComplet ion X10	C24_1.bSts_DialP rocessing X11	C24_1.bSts_Connecti onProcessing X12	C24_1.bSts_Initializa tion_Connection_Abn ormalCompletion X13	C24_1.bSts_Disconn ectionCompletion X14		RST	bReq_Disconr ectionSignal M77
(216)										{(END )

- (0) Turn the READY flag ON.
- (11) Register data for initialization
- to 🛛 🖙 Page 180 Program example
- (14)
- (41) Register data for connection
- to 🛛 🖙 Page 184 Program example
- (44)
- (76) Modem/TA initialization
- to SP Page 188 Program example
- (91)
- (107) Line connection
- to 🛛 🖙 Page 194 Program example (When establishing the line connection from the C24 side following the completion of initialization)
- (130)
- (133) Turn the data update available flag ON.
- (137) Turn the line disconnection available flag ON.
- (146) Issue the line disconnection command.
- (149) Set the modem disconnection request signal.
- (154) Read the error code when modem disconnection completion signal is turned ON. Set the modem disconnection completion flag after the normal completion.
- (172) Reset the modem disconnection request signal.
- (181) Line disconnection processing (line disconnection from the target device)

(184) Reset the request signals.

- Set the modem disconnection request signal when either of completion signal or connection signal is turned ON.
- (193) To turn the 'Modem disconnection completion' (X14) OFF, wait for one second after the 'Modem disconnection request' (Y12) is turned ON.
- (201) Reset the request signal when the modern disconnection completion signal is turned ON. Reset the request signal when the modern disconnection completion signal is turned OFF.

# 7.5 Sample program

# Program for data communication

The following shows sample programs to test the connection between C24s.

Each program contains a minimum set of processing necessary for performing a communication test.

Modify the data for initialization and data for connection in accordance with the system. When adding error-handling

procedures, add them separately by referring to the following explanations.

# System configuration

The system configuration used in this program is shown below.



# Connection request station side (RJ71C24-R2<sup>1</sup>) program example

Perform the initialization of the modem connected to the CH1 side interface, line connection, data communication using the nonprocedural protocol, and line disconnection by the command from the user.

### ■Parameter list

The following shows the parameters of this sample program.

#### • Module parameter

Category	Setting item			Setting content			
Basic settings	Communication protoco	ol setting	ting				
	Communication speed	setting	19200 bps				
	Transmission setting	Data bit		8			
		Parity bit	None				
		Odd/even parity	Odd				
		Stop bit	1				
		Sum check code	Yes				
		Online change	Enable				
		Setting change	Enable				
	Station number setting	(CH1, 2 in common: 0 to 31	)	0			
Application	Modem function	Modem function	Modem connection CH specification	1CH			
settings	setting	specification 1	Data No. for initialization designation	07D5H			
			Data No. for connection designation	0BB8H			

#### · Module extended parameter

Category	Setting item		Setting contents
Modem connection data	Modem connection data No.3000	Telephone number	0123456789

# ■Program example

Category	Label name	Description	Device
Module label	C24_1	Target module	-
	C24_1.stnCH1.bSts_TransmissionNormalCompletion	CH1 Transmission normal completion	X0
	C24_1.stnCH1.bSts_TransmissionAbnormalEnd	CH1 Transmission abnormal completion	X1
	C24_1.bSts_ModemInitializationCompletion	Modem initialization completion	X10
	C24_1.bSts_DialProcessing	Dialing	X11
	C24_1.bSts_ConnectionProcessing	Connection	X12
	C24_1.bSts_Initialization_Connection_AbnormalCompletion	Initialization/connection abnormal completion	X13
	C24_1.bSts_DisconnectionCompletion	Modem disconnection completion	X14
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
	C24_1.stnCH1.bSet_Req_ReceptionRead	CH1 Reception data read request	X3
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4
	C24_1.stnCH1.bSet_Req_Transmission	CH1 Transmission request	Y0
	C24_1.stnCH1.bSet_Req_ReceptionReadCompletion	CH1 Reception data read completion	Y1
	C24_1.bSet_Req_ModemInitialization	Modem initialization request	Y10
	C24_1.bSet_Req_Connection	Connection request	Y11
	C24_1.bSet_Req_Disconnection	Modem disconnection request	Y12
	C24_1.uErrorCode_ModemFunction_D	Modem function error code	U0\G545
	C24_1.wnForUserRegistrationNo8001H_D[0]	For user registration number 8001H	U0\G6912
	C24_1.wnForUserRegistrationNo8002H_D[0]	For user registration number 8002H	U0\G6953

Category	Lab	el name		Descriptio	n	Device
Label to be defined	Defin	e the global label as shown belo	)W	1		1
	Donn					
		Label Name	Data Type	Class	Assign (Device/Label)	
	1	bReq_Initialization	Bit	 VAR_GLOBAL 👻	×20	
	2	bReq_Connection bBeg_DataTransmission	Bit	 VAR_GLUBAL -	X21 X22	
	4	bReq_Disconnection	Bit	 VAR_GLOBAL -	X23	
	5	bUnitAccessibleFlag	Bit	 VAR_GLOBAL 🔻	×60	
	6	bInitializationDataRegistrationCompletion	Bit	 VAR_GLOBAL	Y61	
	/	bLonnectionDataRegistrationLompletion	Bit	 VAR_GLUBAL VAR GLOBAL V	Y62 Y63	
	9	bConnectionCompletion	Bit	 VAR_GLOBAL -	Y64	
	10	bDisconnectionCompletion	Bit	 VAR_GLOBAL 👤	Y67	
	11	bUnitAccessibleFlag2	Bit	 VAR_GLOBAL -	MO	
	12	bConnectionDataRegistrationCompletion2	Bit	 VAR_GLOBAL VAR GLOBAL VAR	M2	
	14	bInitializationCompletion2	Bit	 VAR_GLOBAL 🔻	МЗ	
	15	bConnectionCompletion2	Bit	 VAR_GLOBAL -	M4	
	16	bDisconnectionCompletion2	Bit	 VAR_GLUBAL VAR GLOBAL V	M7 M10	
	18	bReqPulse_Registration2	Bit	 VAR_GLOBAL -	M20	
	19	bInitializationPossibleFlag	Bit	 VAR_GLOBAL 👻	M30	
	20	bReqPulse_Initialization	Bit	 VAR_GLOBAL	M31	
	21	bBegPulse Initialization2	Bit	 VAR_GLUBAL VAR GLOBAL V	M4U M41	
	23	bDataTransmissionPossibleFlag	Bit	 VAR_GLOBAL -	M50	
	24	bTransmissionPossibleFlag	Bit	 VAR_GLOBAL 👻	M51	
	25	bReqPulse_Transmission	Bit	 VAR_GLOBAL	M52	
	26	bReaPulse Disconnection	Bit	 VAR_GLOBAL VAR GLOBAL VAR	M70 M71	
	28	bDisconnectionOccur	Bit	 VAR_GLOBAL -	M80	
	29	bReceivingFlag	Bit	 VAR_GLOBAL 👻	M92	
	30	bSendingFlag	Bit	 VAR_GLOBAL	M93	
	31	bConnectionExecution	Bit	 VAR_GLOBAL VAR GLOBAL VAR	M100	
	33	bTransmissionExecuting	Bit	 VAR_GLOBAL -	M102	
	34	bReadingReceiveData	Bit	 VAR_GLOBAL 👻	M103	
	35	wRegistrationByteCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL -	D0	
	30	wControintenDesignation	Word [Unsigned]/Bit String [16-bit]	 VAR GLOBAL VAR GLOBAL	D2	
	38	wOutsideLineAccessCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 🔻	D11	
	39	wConectionType	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	D12	
	40	wWatingTimeMessageSending	Word [Unsigned]/Bit String [16-bit]	 VAR_GLUBAL VAR GLOBAL VAR	D23 D24	
	42	wMessageLength	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL -	D39	
	43	wTransmissionDataLengs	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D50	
	44	wTransmissionData	Word [Signed](08)	 VAR_GLOBAL -	D51	
	45	wReceiveData	Word [Unsigned]/Bit String [16-bit]	 VAR GLOBAL VAR GLOBAL VAR	D61	
	47	wInitializationErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 🗸	D100	
	48	wConnectionErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL -	D101	
	49	w I ransmissionErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLUBAL -	D103	
	51	wDisconnectionErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL -	D105	
	52	bReq_InitializationDevice	Bit	 VAR_GLOBAL 🔻	M42	
	53	bReq_TransmissionDevice	Bit	 VAR_GLOBAL	M53	
	54	wBecieveChannel	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL VAR GLOBAL VAR	D161	
	56	bReq_ReadingReceiveData	Bit	 VAR_GLOBAL -	M55	
	57	bReq_DisconnectionDevice	Bit	 VAR_GLOBAL 👤	M72	
	58	bReqPulse_Connection	Bit Word [Unsigned]/Bit String [16 hit]	 VAR_GLOBAL	M45	
	60	wTransmissionDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL VAR GLOBAL VAR	D152	
	61	bReq_OUTPUTInstructionTransmission	Bit	 VAR_GLOBAL -	M140	
	62	bOUTPUTInstructionNormalCompleteFlag	Bit	 VAR_GLOBAL 👻	M150	
	63	bOUTPUTInstructionAbnormalCompleteFlag	Bit	 VAR_GLOBAL	M151	
	65	w0UTPUTInstructionExecutionStatusriag	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL VAR GLOBAL VAR	D154	
	66	cTransmissionNormalCompleteCount	Counter	 VAR_GLOBAL -	C100	
	67	cTransmissionAbnormalCompleteCount	Counter	 VAR_GLOBAL -	C90	
	68	cUUTPUTInstructionNormalCompleteCount	Counter	 VAR_GLUBAL -	C50	
	70	wMaxRecvDataLength	Word [Unsigned]/Bit String [16-bit]	 VAR GLOBAL VAR GLOBAL	D162	
	71	bINPUTInstructionNormalCompleteDevice	Bit	 VAR_GLOBAL -	M170	
	72	bINPUTInstructionAbnormalCompleteDevice	Bit	 VAR_GLOBAL -	M171	
	73	bINPUTInstructionExecutionStatusFlag	Bit	 VAR_GLOBAL	M172	
	74	where of instructionEnorCode wReceiveDataCount2	Word [Unsigned]/Bit String [16-bit]	 VAR GLOBAL -	D164	
	76	cINPUTInstructionNormalCompleteCount	Counter	 VAR_GLOBAL -	C70	
	77	cINPUTInstructionAbnormalCompleteCount	Counter	 VAR_GLOBAL -	C71	
	78	bDisconnectionCompletionFlag	Bit	 VAR_GLOBAL	M73	
	79	cINPUTInstructionNormalCompleteCoupt2	Dit Counter	 VAR_GLOBAL -	1917 4 C60	
	81	cINPUTInstructionAbnormalCompleteCount2	Counter	 VAR_GLOBAL -	C61	
		-				

For information on the module  $\ensuremath{\mathsf{FB}}$  to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	C24_1.bSts_UnitRead	C24_1.bSts_WatchdogTim							bUnitAccessibleFlag
(0)	X1E	X1F							M0 O
(3)	bUnitAccessibleFlag2 M0	C24_1.bSts_ModemInitiali zationCompletion X10	C24_1.bSts_Connectio nProcessing X12	C24_1.bSts_Initialization _Connection_AbnormalC ompletion X13	C24_1.bSet_Req_ ModemInitializat ion Y10	C24_1.bSet_Req_Connection Y11			bConnectionPossible Flag M40
		C24_1.bSts_ModemInitiali zationCompletion X10	C24_1.bSts_Connectio nProcessing X12	/	<u>-</u> и				bDataTransmissionF ssibleFlag M50
(15)	bDataTransmissionP ossibleFlag M50	bSendingFlag M93							bTransmissionPossi eFlag M51
		C24_1.stnCH1.bSet_Req_ ReceptionRead X3	C24_1.stnCH1.bSts_Re ceptionAbnormalDete ction X4	C24_1.bSet_Req_Connec tion Y11 1	bReceivingFlag M92	bReceivingFlag M92			bDisconnectionPose leFlag M70
(26)	bReq_Connection X21							PLS	bReqPulse_Initializat n M31
(29)	bReqPulse_Initializati on M31	bConnectionPossibleFlag M40						SET	bReq_InitializationDe ce M42
(32)	bReq_InitializationDev ice M42							CALL	P4
(36)	bReq_DataTransmissi on X22							SET	bReqPulse_Transmit on M52
(38)	bReqPulse_Transmiss ion M52	bTransmissionPossibleFI ag M51						SET	bReq_Transmission vice M53
(41)	bReq_TransmissionD evice M53							CALL	P51
(45)	C24_1.stnCH1.bSet_R eq_ReceptionRead X3	bINPUTInstructionExecu tionDevice M160						SET	bReq_ReadingRecei Data M55
-	C24_1.stnCH1.bSts_R eceptionAbnormalDet ection X4								
(49)	bReq_ReadingReceiv eData M55							CALL	P52
(53)	bReq_Disconnection X23							PLS	bReqPulse_Disconn tion M71
(56)	C24_1.bSts_Connecti onProcessing X12							PLF	bDisconnectionOcc M80
(59)	bReqPulse_Disconne ction M71	bDisconnectionOccur M80						SET	bReq_Disconnection evice M72
	bDisconnectionOccur M80								

(67)			FEND
P4 (6) bReqPuise_initializati on2 M41		SET	C24_1.bSet_Req_Mode mInitialization Y10
C24_15Set_Reg_Mod eminifialization     C24_15Sts_Modeminifiali zationCompletion       (72)     Y10       X10		SET	bInitializationCompleti on2 M3
		RST	C24_1.bSet_Req_Mode mInitialization Y10
		PLS	bReqPulse_Connectio
C241.bSts_Initialization, Connection,AbnormalCo mpletion X13 M0 Hotel Carbon Carbon M0 Hotel Carbon	H221	wInitialization ErrorCode	M45
		D100 RST	C24_1.bSet_Req_Mode mInitialization
bReqPulse_Connection         n		SET	Y10 C24_1.bSet_Req_Conn ection
C24_1.bSte_Req.Com nection     C24_1.bSts_Modeminial zationCompletion     C24_1.bSts_Connectio nProcessing       (93)     Y11     X10		RST	Y11 C24_1.bSet_Req_Conn ection
C241.bisk_ation_ C241.bisk_ation_ Connection_AhnormalCo mition Ation		RST	Y11 bReq_InitializationDevi ce M42
C24_LISSEt_Ren_Con nection     C24_LISSEt_hinklaration. ConnectionAbnormalCo moletion       (100)     Y11	MOVP	C24_1.uError Code_Modem Function_D U0¥G545	wConnectionErrorCod e D101
			RET
P5 b RepPulse Transmiss tor M52 https://www.com/com/com/com/com/com/com/com/com/com/	MOV	K1	wTransmissionChanne I D151
	MOV	K6	wTransmissionDataCo unt D152
	\$MOV	"NO2 IO NO1"	wTransmissionData[0] D51
	MOV	H0A0D	wTransmissionData[5] D56
		SET	bReq_OUTPUTInstruc tionTransmission M140
		SET	bSendingFlag M93

	(126)				M_RJ71C24_Output_00C_1 (M+RJ71C Output FB	24_Output_00C)				
		bReq_OUTPUTInstru ctionTransmission M140			DELEN	- KENOR				bOUTPUTInstruction ExecutionStatusFlag M152
		11		 	D.DEN	0_DENO.B				0
				C24_1 [ }	DUT:i_stModule	o_bOK:B				bOUTPUTInstruction NormalCompleteFlag M150
				wTransmission Channel [ D151 ]	UWiuCh	o_bErr:B				bOUTPUTInstruction AbnormalCompleteFla M <sup>2</sup> 51
				wTransmission DataCount [ D152 ]	UW: <u>i</u> uSendDataLength	o_uErrId:UW	wOUTPUTInst ructionErrorCo de -{ D154 }-			
				wTransmission Data [ D51 ]	UWiuSendData					
	(171)	C24_1.stnCH1.bSts_T ransmissionAbnormal End X1							INC	cTransmissionAbnorm alCompleteCount C90
	(174)	C24_1.stnCH1.bSts_T ransmissionNormalCo mpletion X0							INC	cTransmissionNormal CompleteCount C100
	(177)	bOUTPUTInstruction NormalCompleteFlag M150							INC	cOUTPUTInstruction NormalCompleteCoun t C50
	(180)	bOUTPUTInstruction AbnormalCompleteFI ag M151							INC	cOUTPUTInstruction AbnormalCompleteCo unt C51
	(183)	bOUTPUTInstruction ExecutionStatusFlag M152							RST	bSendingFlag M93
									RST	bReq_OUTPUTInstruc tionTransmission M140
									RST	bReq_TransmissionDe vice M53
	(187)									RET
D52			 	 				 		
- 92	(188)	bReq_ReadingReceiv eData M55						MOVP	K1	wRecieveChannel D161
								MOVP	K10	wMaxRecvDataLength D162
									SET	bINPUTInstructionExe cutionDevice M160

(107						M_RJ71C24_Input_00C_1 (M+RJ71C24_Input_00C) Input FB				
	(197)									
		bINPUTInstructionEx ecutionDevice M160				D. F.M F.M.O.				bINPUTInstructionExe cutionStatusFlag M172
					 	B.DEN ODENO.B				0
					C24_1	DUT:ايغtModule م_bOK:B				bINPUTInstructionNor malCompleteDevice M170
					wRecieveChan nel					bINPUTInstructionAb normalCompleteDevic e M171
					 wMaxRecuDat	on.Luon Querr.B	wPacaiveError			0
					 aLength -[ D162 ]-	UWi_uMaxRecvDataLength ويErrld:UW	Code -[ D104 ]			
						o_uRecvDataLengthUW	wReceiveData Count -[ D60 ]			
						o_uRecvData:UW	wReceiveData -{ D61 }			
	(243)	bINPUTInstructionNo rmalCompleteDevice M170							INC	cINPUTInstructionNor malCompleteCount C70
	(246)	bINPUTInstructionAb normalCompleteDevi ce M171							INC	cINPUTInstructionAb normalCompleteCoun t C71
P7		bReg DisconnectionD								
	(249)	evice M72							PLS	bReq_Disconnection2
	(253)	bReq_Disconnection2 M74							SET	C24_1.bSet_Req_Disco nnection Y12
	(255)	C24_1.bSet_Req_Disc onnection Y12	C24_1.bSts_ConnectionP rocessing X12	C24_1.bSts_Disconnec tionCompletion X14				MOVP	U0¥G545	wDisconnectionError Code D105
									SET	bDisconnectionCompl etionFlag M73
	(264)	bDisconnectionComp letionFlag M73	C24_1.bSts_Disconnectio nCompletion X14						RST	C24_1.bSet_Req_Disco nnection Y12
			C24_1.bSts_Disconnectio nCompletion X14						RST	bDisconnectionCompl etionFlag M73
									RST	bReq_DisconnectionD evice M72
	(272)									RET

(273	bINPUTInstructionNo rmalCompleteDevice M170	INC	cINPUTInstructionNor malCompleteCount2 C60
(276	bINPUTInstructionAb normalCompleteDevi ce M171	INC	cINPUTInstructionAb normalCompleteCoun t2 C61
(279	bINPUTInstructionEx ecutionStatusFlag M172	RST	bSendingFlag M93
		RST	bReq_ReadingReceive Data M55
		RST	bINPUTInstructionExe cutionDevice M160
(283			RET
(284			(740)

- (0) Accessible
- (3) Modem initialization
- Data communication available
- (15) Data transmission available
- Modem disconnection available
- (26) Convert the modem initialization and line connection command into pulse.
- (32) Jump to the subroutine of the modem initialization and line connection processing.
- (36) Convert the data communication (transmission) command into pulse.
- (41) Jump to the subroutine of the data reception processing.
- (45) Jump to the subroutine of the receive data.
- (49) Jump to the subroutine of the data reception processing.
- (53) Convert the line disconnection command into pulse.
- (56) Convert the connection signal OFF into pulse.
- (63) Jump to the subroutine of the line disconnection processing.
- (69) Set the initialization request signal.
- (91) Set the connection request signal.
- (93) Reset the request signal when the initialization completion signal and connection signal are turned ON. Read the error code when initialization/connection abnormal completion signal is turned ON, and reset the request signal.
- (108) Set the transmission channel to CH1. Set the send data quantity. Set the send data.

- (177) Transmission normal completion
- (180) Transmission abnormal completion
- (188) Set the data reception channel CH1.
- (243) Received data read normal completion
- (246) Received data read abnormal completion
- (253) Set the modem disconnection request signal.
- (255) Read the error code when modem disconnection completion signal is turned ON. Set the modem disconnection completion flag when normal completion signal is turned ON.
- (264) Reset the modem disconnection request signal.

# Connection receiving station side (RJ71C24-R22) program example

Perform data communication using the nonprocedural protocol by the command from the user after the 'Connection' (X12) turns ON.

## ■Parameter list

Category	Setting item			Setting content	
Basic settings	Communication protoco	Nonprocedural protocol			
	Communication speed	19200 bps			
	Transmission setting	Data bit	8		
		Parity bit	None		
		Odd/even parity	Odd		
		Stop bit	1		
		Sum check code	Yes		
		Online change	Enable		
		Setting change	Enable		
	Station number setting	0			
Application	Modem function setting	Modem function specification 1	Modem connection CH specification	1CH	
settings			Data No. for initialization designation	07D5H	
		Modem function specification 2	Auto modem initialization designation	Automatically initialize	

### ■Program example

Category	Label name	Description	Device
Module label	C24_1	Target module	—
	C24_1.stnCH1.bSts_TransmissionNormalCompletion	CH1 Transmission normal completion	X0
	C24_1.stnCH1.bSts_TransmissionAbnormalEnd	CH1 Transmission abnormal completion	X1
	C24_1.bSts_ModemInitializationCompletion	Modem initialization completion	X10
	C24_1.bSts_DialProcessing	Dialing	X11
	C24_1.bSts_ConnectionProcessing	Connection	X12
	C24_1.bSts_Initialization_Connection_AbnormalCompletion	Initialization/connection abnormal completion	X13
	C24_1.bSts_DisconnectionCompletion	Modem disconnection completion	X14
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	XF
	C24_1.stnCH1.bSet_Req_ReceptionRead	CH1 Reception data read request	Х3
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4
	C24_1.stnCH1.bSet_Req_Transmission	CH1 Transmission request	Y0
	C24_1.stnCH1.bSet_Req_ReceptionReadCompletion	CH1 Reception data read completion	Y1
	C24_1.bSet_Req_ModemInitialization	Modem initialization request	Y10
	C24_1.bSet_Req_Connection	Connection request	Y11
	C24_1.bSet_Req_Disconnection	Modem disconnection request	Y12
Category	Label name	Description	Device
---------------------	---	-------------	--------
Label to be defined	Define the global label as shown below.		

Label to be defined	Define the global label as shown bel
---------------------	--------------------------------------

	Label Name	Data Type	Class	Assign (Device/Label)
1	bReq_Transmission	Bit	 VAR_GLOBAL 💌	X22
2	bUnitAccessibleFlag	Bit	 VAR_GLOBAL 👻	MO
3	bTransmissionPossibleFlag	Bit	 VAR_GLOBAL 👻	M51
4	bReqPulse_Transmission	Bit	 VAR_GLOBAL 👻	M52
5	bSendingFlag	Bit	 VAR_GLOBAL 👻	M92
6	bOUTPUTInstructionNormalCompletion	Bit	 VAR_GLOBAL 👻	M150
7	bOUTPUTInstructionAbnormalCompletion	Bit	 VAR_GLOBAL 👻	M151
8	bOUTPUTInstructionExecutionStatus	Bit	 VAR_GLOBAL 👻	M152
9	bReq_Transmission2	Bit	 VAR_GLOBAL 👻	M160
10	bINPUTInstructionNormalCompletion	Bit	 VAR_GLOBAL 👻	M170
11	bINPUTInstructionAbnormalCompletion	Bit	 VAR_GLOBAL 👻	M171
12	bINPUTInstructionExecutionStatus	Bit	 VAR_GLOBAL 👻	M172
13	wnOUTPUTInstructionTransmissionData	Word [Signed](05)	 VAR_GLOBAL 👻	D51
14	wnINPUTInstructionReceiveData	Word [Signed](05)	 VAR_GLOBAL 👻	D61
15	wOUTPUTInstructionTransmissionChannel	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D151
16	wOUTPUTInstructionTransmissionDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D152
17	wOUTPUTInstructionErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D159
18	wINPUTInstructionReceiveChannel	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D161
19	wINPUTInstructionAllowableCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D162
20	wINPUTInstructionErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D163
21	wINPUTInstructionReceiveDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D164
22	cOUTPUTInstructionNormalCompleteCounter	Counter	 VAR_GLOBAL 👻	C50
23	cOUTPUTInstructionAbnormalCompleteCounter	Counter	 VAR_GLOBAL 👻	C51
24	cINPUTInstructionNormalCompleteCounter	Counter	 VAR_GLOBAL 👻	C60
25	cINPUTInstructionAbnormalCompleteCounter	Counter	 VAR_GLOBAL 👻	C61
26	wInitializationNormalCompletion	Bit	 VAR_GLOBAL 👻	M1
27	bTransmissionPossibleDevice	Bit	 VAR_GLOBAL 👻	М3
28	wInitializationErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D100
29	bReq_Receive	Bit	 VAR_GLOBAL 👻	M140
30	cTransmissionNormalCompleteCount	Counter	 VAR_GLOBAL 👻	C100
31	cTransmissionAbnormalCompleteCount	Counter	 VAR_GLOBAL 👻	C90
32	wTransmissionData	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL 👻	D153

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

(0)	C24_1.bSts_UnitR eady X1E	C24_1.bSts_Watchd ogTimerError X1F									bUnitAccessibleFlag M0 O
	h    -::+ A:: - - [7]										
(3)	ag M0									SET	C24_1.bSet_Req_Mode mInitialization Y10
	C24_1.bSet_Req_	C24_1.bSts_ModemI									
(5)	ModemInitializatio Y10	nitializationComplet ion X10								SET	bTransmissionPossibl eDevice M3
										RST	C24_1.bSet_Req_Mode mInitialization Y10
										SET	wInitializationNormalC ompletion M1
		C24_1.bSts_Initializa	bUnitAccessib								
		normalCompletion X13	eFlag M0				FROMP	HO	H221	wInitializationErr orCode D100	K1
										SET	wInitializationNormalC ompletion M1
		C24 1.bSts ModemI	C24 1.bSts Co	10 F	 	 					
(23)	MinitializationNor malCompletion M1	nitializationComplet ion X10	nnectionProce ssing X12	Flag M92							eFlag M51
				* 1	 	 					v
(28)	bReq_Transmissio n X22									PLS	bReqPulse_Transmissi on M52
											MJZ
	bReqPulse_Trans	bTransmissionPossi								K1	wOUTPUTInstruction
(31)	M52	M51							MOV		TransmissionChannel D151
										K6	wOUTPUTInstruction
									моу		TransmissionDataCou nt D152
									\$MOV	"NO2 IO NO1"	wnOUTPUTInstructio nTransmissionData[0]
									-		D51
									MOV	H0A0D	wnOUTPUTInstructio nTransmissionData[5] D56
										SET	bReq_Receive M140
										SET	bSendingFlag M92
	l				 						

				M_RJ71C24_Output_00C_1 (M+RJ71C24_Output_00C Output FB				
(49)								
	bReq_Receive							bOUTPUTInstructionE
	M140							M152
				B:i_bEN o_bENO:E	3			
			C24_1	DUTi_stModule o_bOK:E				bOUTPUTInstructionN ormalCompletion M150
			wOUTPUTInstru ctionTransmissio nChannel [ D151 ]	UW:_uCh o_bErr:E	3	-		bnormalCompletion M151
			wOUTPUTInstru ctionTransmissio		wOUTPUTInstr uctionErrorCod			
			nDataCount [ D152 ]	-UW;i_uSendDataLength o_uErrld:UV	( _C D159 ]			
			wnOUTPUTInstr uctionTransmissi onData [ D51 ]	UW:i_uSendData				
(94)	C24_1.stnCH1.bSt s_TransmissionAb normalEnd X1						INC	cTransmissionAbnorm alCompleteCount C90
	C24_1.stnCH1.bSt							
(97)	rmalCompletion X0						INC	c I ransmissionNormal CompleteCount C100
	bOUTPUTInstruct							
(100)	ionNormalComple tion M150						INC	cOUTPUTInstruction NormalCompleteCoun ter C50
	bOUTPUTInstruct							
(103)	letion M151						INC	cOUTPUTInstructionA bnormalCompleteCou nter C51
	bOUTPUTInstruct							
(106)	M152						RST	bSendingHag M92
							RST	bReq_Receive M140
	C24 1.stnCH1.bS							•
(109)	et_Req_Reception Read X3	2 M160				MOVP	K1	wINPUTInstructionRe ceiveChannel D161
	C24 1.stnCH1.bSt	- '					<u>.</u>	
	s_ReceptionAbnor malDetection X4					MOVP	K10	wINPUTInstructionAll owableCount
							SET	bReq_Transmission2
						_		MIOU

			M_RJ71C24_Input_00C_1 ( M+	RJ71C24_Input_00C)			
(127)							
	bReg Transmissio n2 M160		- Bi hEN	o bENO B			bINPUTInstructionExe cutionStatus M172
			D. DEN	0_02100.0			V
		C24_1	DUT:i_stModule	o_bOK:B			bINPUTInstructionNor malCompletion M170
		wINPUTInstructi onReceiveChann el					bINPUTInstructionAbn ormalCompletion M171
		[ D161 ]	- UW:i_uCh	o_bErr:B			0
		wINPUTInstructi onAllowableCoun t [ D162 ]	- UW:⊥uMaxRecvDataLength	o_uErrId:UW	wINPUTInstruc tionErrorCode -[ D163 ]		
			o	_uRecvDataLength:UW	wINPUTInstruc tionReceiveDat aCount [ D164 ]		
				ou BecyData:UW	wnINPUTInstru ctionReceiveD ata f D61 7		
	http://ttester.etic						
(173)	nNormalCompleti on M170					INC	cINPUTInstructionNor malCompleteCounter C60
						RST	bINPUTInstructionNor malCompletion M170
	bINPUTInstructio						
(177)	MAbnormalComple M171					INC	cINPUTInstructionAbn ormalCompleteCounte r C61
						RST	bINPUTInstructionNor malCompletion M170
(181)							(END )
(0)	Accessible						

(3) Initialize the modem.

(31) Set the transmission channel. Set the send data quantity. Set the send data.

Issue the transmission execution direction.

(100) Normal completion

(103) Abnormal completion

(109) Set the reception channel to CH1. Issue the reception execution direction.

(173) Normal completion

(177) Abnormal completion

# 8 RECEIVING DATA WITH AN INTERRUPT PROGRAM

In data communications between C24 and a target device, an interrupt program can be used to receive data for the following data communication functions.

- Data reception during communication using the nonprocedural protocol
- · Data reception during communication using the bidirectional protocol

This chapter explains data reception with the following data communication function by an interrupt program.



Point P

Receiving data with an interrupt program expedites the process of retrieving received data to the CPU module.

## 8.1 Settings for Receiving Data Using an Interrupt Program

The following explains the settings for performing data reception with an interrupt program during communication using the nonprocedural protocol or bidirectional protocol.

For setting for data reception with an interrupt program, set "Interrupt factor" to "BUFRCVS instruction data reception", and set the interrupt pointer to be used in the program to "Interrupt pointer".

℃ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Module Name ⇒ [Module Parameter] ⇒ "Interrupt Settings"

## 8.2 Interrupt Program Startup Timing

The following explains the startup timing for interrupt program when performing data reception with an interrupt program during communication using the nonprocedural protocol or bidirectional protocol.

- The startup timing is the same for communication using either the nonprocedural protocol or bidirectional protocol.
- Received data from the target device is stored in the receive area of the buffer memory. When the next input signal rises, the interrupt program is started.

Input signal name	CH1 side	CH2 side
CHn reception data read request signal	Х3	ХА
CHn reception abnormal detection signal	X4	ХВ

## 8.3 Reception Control Method Using an Interrupt Program

The following explains the reception control method when receiving data with an interrupt program during communication using the nonprocedural protocol or bidirectional protocol.



• When data is received from the target device, the receive data is stored in the buffer memory and the 'CH1 reception data read request' signal turns ON.

2 The main program stops executing and the interrupt program starts.

O The data reception dedicated instruction, BUFRCVS, for the interrupt program is executed and data is received.<sup>\*1</sup>

Ø When the execution of the BUFRCVS instruction is complete, the 'CH1 reception data read request' signal turns OFF.

• The execution of the interrupt program is completed, and execution of the main program restarts.

\*1 When the reading of received data using the BUFRCVS instruction is finished, the following processes are performed.

At normal completion
 CPU module error flag (SM0) turns OFF.

· At abnormal completion

CPU module error flag (SM0) turns ON.

The error code is stored in the CPU module error code (SD0).

For more details on the error flag (SM0) and error codes (SD0) of the CPU module, refer to the following manual.

MELSEC iQ-R CPU Module User's Manual (Application)

# 8.4 Program Example

This section shows programming examples for data reception with an interrupt program in data communications using the nonprocedural protocol or bidirectional protocol.

### Program example for data reception

The following shows a program example for data reception with an interrupt program in data communication using the nonprocedural protocol.

### ■Parameter list

The following shows the parameters for this program.

Setting item			Setting content
Interrupt settings CH1 Inte		Interrupt factor BUFRCVS instruction data reception	
		Interrupt pointer	150

### ■Program example

Category	Label name	Description	Device
Module label	C24_1.stnCH1.bSet_Req_ReceptionRead_D	CH1 Reception data read request	DX3
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection_D	CH1 Reception abnormal detection	DX4
	C24_1.stnCH1.uSet_ReceiveInterruptIssued_D	CH1_Receive interrupt-issued designation	U0\G8208

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class		Assign (Device/Label)
1	bNormalReceptionFlag	Bit	 VAR_GLOBAL	Ŧ	M100
2	bAbnormalReceptionFlag	Bit	 VAR_GLOBAL	Ŧ	M101
3	wReceiveDataLength	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	Ŧ	D200



(0) For the CH1 side, designate the receive interrupt-issued designation.

(15) Receive the data.



- is used to receive data with an interrupt program. (SP Page 520 Dedicated Instructions)
- To startup an interrupt program, create a program to allow/prohibit interrupt during the main program. Instruction to be used is EI, DI, and IMASK.

# 8.5 Considerations when Receiving Data with an Interrupt Program

This section describes the considerations when receiving data with an interrupt program.

- · Create an interrupt program for data reception for each interface.
- Do not use the INPUT and BIDIN instructions during execution of the interrupt program. Always use the BUFRCVS instruction to receive data.
- Do not turn the 'CHD reception data read completion' (Y1/Y8) ON/OFF during execution of the interrupt program since C24 turns OFF the 'CHD reception data read request' (X3/XA) and the 'CHD reception abnormal detection' (X4/XB) for data reception with an interrupt program.
- Use always ON (SM400) or direct input signal (DX3, DX4) as the contact signal when executing the BUFRCVS instruction.
- After the power supply turns OFF ⇒ ON or the CPU module is reset, data cannot be received because the interrupt program is invalid during the initial processing of the CPU module. For asynchronous data communication with C24 from the target device without communication procedure setting, refer to the program example shown below.

### Program example

The following shows an example of program for asynchronous data communications from the target device side to C24 without communication procedure settings on the target device side.

Category	Label name	Description	Device
Module label	C24_1	Target module	—
	C24_1.stnCH1.bSet_Req_ReceptionRead	CH1 Reception data read request	X3
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4
	C24_1.stnCH1.bSts_Error	CH1 Error occurrence	XE
	C24_1.bSet_Req_ErrorInitialization	Error initialization request	YE
	C24_1.stnCH1.uSet_ReceiveInterruptIssued_D	CH1_Receive interrupt-issued designation	U0\G8208
Label to be defined	Define the global label as shown below.		
	LabelMana Data Tura	Class Assime Opering Halter	
	1 bINPUTInstructionExecutionCompleteDevice Bit	VAB GLOBAL VM0	
	2 bINPUTInstructionAbnormalCompleteDevice Bit	VAR_GLOBAL - M1	

2	DINFOTINSUUCIONADIOIIIIaiCOMpleteDevice	DIL	 VAN_GLUBAL	•	181.1
3	bINPUTInstructionExecutionStatusDevice	Bit	 VAR_GLOBAL	-	M2
4	bReq_INPUTInstructionExecution	Bit	 VAR_GLOBAL	•	M10
5	wReceiveChannel	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	Ŧ	D1
6	wAllowableReceiveDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	-	D2
7	wReceiveResult	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D3
8	wReceiveDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	Ŧ	D4
9	wnINPUTTInstructionReceiveData	Word [Unsigned]/Bit String [16-bit](015)	 VAR_GLOBAL	•	D10
10	wnBUFRCVSInstructionReceiveData	Word [Unsigned]/Bit String [16-bit](015)	 VAR_GLOBAL	•	D200
11	wINPUTInstructionNormalCompleteFlag	Word [Signed]	 VAR_GLOBAL	•	W0
10	wINDLIT Instruction Abnormal Complete Flag	)u(ard [Cigned]	MAD CLODAL	-	5.74

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	(0)	RCPU.stSM.bAlwa ys_ON SM400								MOV	K1	C24_1.stnCH1.uSet ReceiveInterruptIs sued_D U0¥G8208
												EI
	(6)	RCPU.stSM.bAfte r_RUN1_Scan_ON SM402	C24_1.stnCH1.bSe t_Req_ReceptionR ead X3							MOVP	K1	wReceiveChannel D1
			C24_1.stnCH1.bSt s_ReceptionAbnor malDetection X4							MOVP	K10	wAllowableReceive DataCount D2
											SET	bReq_INPUTInstru ctionExecution M10
	(17)					M_RJ71C24_Input_00C_1 Inpu	(M+RJ71C24_Input_00C) tFB					
		bReq_INPUTInstru ctionExecution M10				B:i,bEN	o_bENO:B					ExecutionStatusDe vice M2
					C24_1	DUT:i_stModule	o_bOK:B					bINPUTInstruction ExecutionComplet eDevice M0
					wReceiveChann el D1 ]-	- UW:i_uCh	o_bErr:B					bINPUTInstruction AbnormalComplete Device M1
				(	wAllowableRece iveDataCount D2 ]	UW: <u>i</u> uMaxRecvDataLength	o_uErrld:UW	wReceiveResult -{ D3 }				
							o_uRecvDataLength:UW	wReceiveDataC ount -[ D4 ]-				
							o_uRecvData:UW	wnINPUTTInstr uctionReceiveD ata -{ D10 }				
	(63)	bINPUTInstructio nExecutionCompl eteDevice M0									INCP	wINPUTInstruction NormalCompleteFI ag W0
	(67)	bINPUTInstructio nAbnormalComple teDevice M1									INCP	wINPUTInstruction AbnormalComplete Flag W1
	(71)	C24_1.stnCH1.bSt s_Error X0E										C24_1.bSet_Req_Er rorInitialization Y0E
	(73)											FEND
150	(75)	RCPU.stSM.bAlwa ys_ON SM400							Z.BUFRCV S	UO	K1	wnBUFRCVSInstru ctionReceiveData D200
	(86)											IRET
	(87)											(END }

(0) For the CH1 side, designate the receive interrupt-issued designation.

(63) Processing at normal completion

(67) Processing at abnormal completion

 $(71) \qquad \mbox{Initialize the error information of the CH1 side.}$ 

(75) Execute the receive interrupt program.

# **9** CHANGING DATA LENGTH UNITS TO BYTE UNITS (WORD/BYTE UNITS SETTING)

The word units are used for the data length (count) of the amount of data transmitted/received using the following data communication functions in data communication between C24 and target devices.

This chapter explains how to change the units (word  $\rightarrow$  byte, byte  $\rightarrow$  word) of the data length (count) transmitted/received with the following data communication functions.

The data length units can be set for each C24 interface. C24 controls the number of data to be transmitted to the target device and the number of data when it requests the CPU module to read the data received from the target device according to the units set by the user.

### Data communication functions and buffer memory affected by data length units

The following lists the data communications functions and buffer memory which are affected by the data length units. (The buffer memory addresses in the table are the default value.)

Data communications	function	Name of buffer memory related to data length units	Reference		
MC protocol	On-demand function	Data length designation (Un\G161/321)	MELSEC Communication Protocol Reference Manual		
Nonprocedural protocol	Data transmission function	Send data quantity designation (Un\G1024/2048)	Page 52 DATA COMMUNICATION		
	Data reception function	Receive end data quantity designation (Un\G164/324) Receive data quantity (Number of data for which read is requested) (Un\G1536/2560)	USING NONPROCEDURAL PROTOCOL		
Bidirectional protocol	Data transmission function	Send data quantity designation (Un\G1024/2048)	Page 86 DATA COMMUNICATION		
	Data reception function	Receive end data quantity designation (Un\G164/324) Receive data quantity (Number of data for which read is requested) (Un\G1536/2560)	USING BIDIRECTIONAL PROTOCOL		

### How to change the units of the data length (count)

Change the units of the data length (count) by the either of the following methods.

· Changing with Engineering tool

Set "Word/byte units designation" to "Byte units".

- Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings"
  ⇒ "Various control specification"
- · Changing by the CPU module

The units can be changed with the CSET instruction. (IP Page 520 Dedicated Instructions)

# **10** CHANGING DATA COMMUNICATION MONITORING TIME

The monitoring time is time used by C24 to monitor the receiving interval time between each byte when receiving data from the target device, the programmable controller CPU processing time, and the time it takes to transmit to the target device. The monitoring time can be set for each interface. C24 uses the monitoring time set by the user to control data transmission to and reception from the target device.

Set the monitoring time in accordance with the specifications of the target device.

C24 monitoring times are listed below.

○: Configurable ×: Non-configurable, —: Not used

Monitoring time		C24 default value	Protoc the tim	ol that o le	an mon	itor	Remarks		
			МС	Non	Bi	Pd			
No-reception monitoring time (timer 0)	Method 0 <sup>*1</sup>	0 bytes (Unlimited wait)	0	0	0	—	Transmission time for the set number of byte (depending on the		
	Method 1 <sup>*1</sup>		×	0	×	—	transmission speed)		
Response monitoring time (time	r 1)	5 seconds	0	—	0	0	Transmission only for the bidirectional protocol.		
Send monitoring time (timer 2)		3 minutes	0	0	0	—	—		
Transmission wait time		0 ms	0	—	—	—	No wait time		

#### \*1 Nonprocedural and no-reception monitoring time method

The C24 input signal which turns ON when the no-reception monitoring time (timer 0) timed out differs.

Nonprocedural and no-reception monitoring time method	Input signal which turns ON					
Method 0	Reception abnormal detection (X4, XB)					
Method 1	Reception data read request (X3, XA)					



### Data communication using MC protocol



# **10.1** No-reception Monitoring Time (timer 0) Setting

The no-reception monitoring time (timer 0) is a monitoring time for clearing the state of C24 when it is placed into the data receive wait state by trouble on the target device side.

C24 monitors the reception interval in byte units at the start of data reception from the target device and ends monitoring when the preset last data is received, and it repeats this operation.

The following explains the no-reception monitoring time (timer 0) operation.



One byte is always handled as 12 bits in the no-reception monitoring time (timer 0), regardless of the transmission setting. When the no-reception monitoring time (timer 0) is changed by a program, perform any of the following to enable the changed value.

- Mode switching ( Page 377 SWITCHING THE MODE AFTER STARTING)
- UINI instruction (CMELSEC iQ-R Programming Manual (Instructions, Standard functions/Function blocks))
- Programmable controller CPU information clear (F Page 455 How to Clear Programmable Controller CPU Information)

## C24 operation by no reception monitoring time (timer 0)

C24 monitors the reception interval in byte units and returns the elapsed time to 0 each time one byte is received. At time-out, C24 performs the following processing.

### Data communication using the MC protocol

- C24 stores the error code to the 'MC protocol send error code' (Un\G602/618) for the target interface side.
- C24 transmits a NAK message to the target device and waits to receive the next command message.

### Data communications using the nonprocedural protocol (Method 0)

### Data communications not using user frames

- C24 retrieves the received data up to time-out to C24.
- C24 stores the error code to the 'Data reception result' (Un\G600/616) for the target interface and turns ON the 'CH□ reception abnormal detection' (X4, XB), and waits to receive the next data.

### Ex.

Receiving by the receive end code (Receive end code: CR + LF (0D0AH))

When the LF is not received within the set time for timer 0 after reception of the CR, the received data up to the CR is stored in the receive data storage area of the buffer memory and the reception abnormal detection signal to the CPU module turns ON.



\*1 CR is treated as 1 byte of data included in the message.

### Data communications using user frames

- When designating the final frame, C24 retrieves an arbitrary portion of data in the received data between the start of the reception of the current message and the time-out, and ignores (deletes) the data in the final frame portion.
- C24 stores the error code to the 'Data reception result' (Un\G600/616) for the target interface and turns ON the 'CHD reception abnormal detection' (X4, XB) and waits to receive the next data.

### Data communication using the nonprocedural protocol (Method 1)

The reception monitoring using Method 1 of the no-reception monitoring time (timer 0) is used to receive a message of which the receive end code and receive end data quantity have not been determined by a timeout of the no-reception monitoring time (timer 0) in data communication using the nonprocedural protocol.

• Data is received by C24 until the time is out, the 'CHD reception data read request' (X3, XA) turns ON, and waits to receive the next data.



When receiving using the receive end data quantity (Receive end data quantity: 511 bytes)

After 16 bytes of data is received, the 16-byte data is stored in the receive data storage area of the buffer memory by the time out (timer 0) and the reception data read request signal to the CPU module turns ON.

				• •	   
Target device	A	в	С	Timer 0 Set time	       
C24					       
Reception data read request signal					
					1

(X3/XA)

### Data communications using the bidirectional protocol

- C24 ignores (deletes) the received data from the start of reception of the current message to time-out.
- C24 stores the error code to the 'Data reception result' (Un\G600/616) for the target interface.
- When reading received data is completed, C24 transmits a NAK message to the target device, and waits to receive the next data.

### Changing the no-reception monitoring time (timer 0)

### Changing the no-reception monitoring time (timer 0)

For the no-reception monitoring time (timer 0), set the number of transmission characters (number of bytes) corresponding to the data transmission speed set to the target interface to "No-reception monitoring time (timer 0) designation".

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

Adjust or set the value based on the specifications of the target device.

### Nonprocedural no-reception monitoring time method designation (Method 0/1)

For the nonprocedural and no-reception monitoring time method designation, set the method to use the no-reception monitoring time (timer 0) in data communications using the nonprocedural protocol to "Nonprocedural and no-reception monitoring time method designation".



### Remarks

### When changing the no-reception monitoring time (timer 0)

Set the no-reception monitoring time (timer 0) to the following number of bytes or greater.

No-reception monitoring time (timer 0) = 1 +  $\frac{Td \times Vbps}{12000}$ (Round up fractions below decimal point.)

Td : Maximum delay time for target device output processing (ms)

Vbps: Transmission rate (bps)

### Ex.

Calculation of no-reception monitoring time (timer 0)

Transmission rate (Vbps) : 9600 bps

Maximum delay time for target device output processing (Td) : 50 ms

No-reception monitoring time (timer 0) = 1 +  $\frac{50 \times 9600}{12000}$  = 41 bytes

In this case, actual monitoring time is as shown below:

41 bytes  $\times$  12<sup>\*1</sup> ÷ 9600 × 1000 = 51.25 ms

\*1 Number of transmit bits per byte (Fixed)

## ■When changing the no-reception monitoring time (timer 0) for data communication with a target device through C24 RS-422/485 interface

Set the no-reception monitoring time (timer 0) to the following number of bytes or greater.

No-reception monitoring time (timer 0) = 1 +  $\frac{(Td + T1) \times Vbps}{12000}$ 

(Round up fractions below decimal point.)

Td : Maximum delay time for target device output processing (ms)

T1 : Target device side hardware gate OFF time (ms)

Vbps: Transmission rate (bps)

# **10.2** Response Monitoring Time (timer 1) Setting

The response monitoring time (timer 1) is a monitoring time for clearing the receive wait state of the device that receives a response message when any trouble occurs on the side of device which received a message and the response message (result) cannot be returned to the target device.

When C24 receives a message from the target device, it monitors the CPU module processing time up to the start of transmission of the response message to the target device.

When a message was transmitted, it monitors the target device processing time up to the start of reception of the response message from the target device.

The following describes the response monitoring time (timer 1) operation.



If on-demand data is transmitted before a response message during data communications using the MC protocol, the time up to the start of transmission of the on-demand data is monitored.

Target device	Command message			
CPU module		On-demand data	Response message	
	<b>-</b> +	Monitoring time		
	1	Elapsed time reset		

## C24 operation by response monitoring time (timer 1)

### When response monitoring time (timer 1) is set to 0 ms

- After receiving a message, C24 does not monitor the time up to the start of transmission of the response message to the target device, but waits infinitely.
- After transmitting a message, C24 does not monitor the time up to the start of reception of the response message from the target device, but waits infinitely.

### When response monitoring time (timer 1) is set to 100 ms or longer

- After receiving a message, C24 monitors the time up to the start of transmission of the response message to the target device and returns the elapsed time to 0 at the start of transmission.
- After transmitting a message, C24 monitors the time up to the start of reception of the response message from the target device and returns the elapsed time to 0 at the start of reception.

At time-out, C24 performs the following processing.

### ■Data communications using the MC protocol

- C24 stores the error code to the 'MC protocol send error code' (Un\G602/618) for the target interface.
- · C24 transmits a response message (NAK message) to the target device and waits to receive the next command message.

### Data communications using the bidirectional protocol

- C24 stores the error code to the 'Data transmission result' (Un\G599/615) for the target interface and completes the transmission processing abnormally.
- · While waiting to transmit a response message, C24 does not check the response monitoring time.

## Changing the response monitoring time (timer 1)

The response monitoring time (timer 1) is registered on "Response monitoring time (timer 1) designation" of the parameter.

Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings" ⇔ "Various control specification"

During data communications using the MC protocol, set the response monitoring time so as to be as long as the transmission wait time or longer.

The transmission wait time is designated in the following:

- 1C frame: Designate it is a command message.
- 2C/3C/4C frame: "Transmission wait time designation"

### Considerations for data communications using the MC protocol

When changing the response monitoring time (timer 1) default value (5 sec), take into account the following.

Set it as to be as long as the transmission wait time or longer in either case of the following. ( Page 235 Transmission Wait Time Setting)

### When specifying monitor condition

When designating the monitor conditions with the following functions, set the maximum time according to the system operation.

- · Random read in word units
- · Device memory monitor

### When accessing by other than above

- When accessing a station connected (including multidrop connection) to a target device, set the following value, or longer. Response monitoring time ≥ Maximum number of scans required to process the command used × Connected station scan time
- When accessing another station over a network system, set the default value to 'Unlimited wait', or the following time or longer.

Response monitoring time  $\geq$  maximum number of scans required to process the command used  $\times$  communications time When setting the default value to 'Unlimited wait', check the target device response wait time, and initialize C24 transmission sequence when time-out occurs.

For the maximum number of scans and the communication time required by processing, refer to the following manual.

### Considerations for data communications using bidirectional protocol

when changing the default value (5 seconds) for the response monitoring time (timer 1), set it as to be as long as the following time, or longer.

• (Sequence scan time  $\times$  2) + 100 ms

# **10.3** Send Monitoring Time (timer 2) Setting

The send monitoring time (timer 2) is a monitoring time for clearing the wait state of C24 when C24, which is to transmit a message or response message (result), is placed into the data transmit wait state due to any trouble of the target device side When C24 transmits a message, it monitors the wait time up to the end of transmission of the message.

When C24 received a message from a target device, it monitors the wait time up to the end of transmission of the response message.

The following explains the send monitoring time (timer 2) operation.

Target device	Message			Response message
CPU module		Response message	Message	
		Monitoring time		

If on-demand data is transmitted before a response message during data communications using the MC protocol, each time is monitored.



## C24 operation by send monitoring time (timer 2)

### When send monitoring time (timer 2) is set to 0 ms

- The time until transmission of a message or response message has been completed is not monitored.
- · If C24 cannot transmit, it waits infinitely.

### When send monitoring time (timer 2) is set to 100 ms or longer

• C24 monitors the time from completion of message or response message transmission preparations to the end of transmission, and returns the elapsed time to 0 at the end of transmission.

At time-out, C24 performs the following processing.

### ■Data communications using MC protocol

 While waiting for the end of transmission of the response message, C24 stores the error code to the 'Data transmission result' (Un\G599/615) for the target interface.

C24 enters the state in which it waits to receive the next command message without sending a response message (NAK message) to the target device.

- During on-demand data transmission, C24 stores the error code to the 'On-demand execution results' (Un\G598/614) for the target interface.
- If transmission was terminated midway in either of the cases above, C24 does not transmit the remaining data.

### Data communications using nonprocedural protocol or bidirectional protocol

- While waiting for the end of transmission of a message, C24 stores the error code to the 'Data transmission result' (Un\G599/615) for the target interface and completes the transmission processing abnormally. If message transmission was terminated midway, C24 does not transmit the remaining data.
- If waiting for the end of transmission of a response message, C24 stores the error code to the 'Data reception result' (Un\G600/616) for the target device and turns ON the 'CH□ reception abnormal detection' (X4, XB).<sup>\*1</sup>When the receive data read processing completes, C24 turns OFF the 'CH□ reception abnormal detection' (X4, XB) and waits to receive the next command.

If transmission of the response message was terminated midway, C24 does not transmit the remaining data.

\*1 When communicating using bidirectional protocol, it stores the error code in the data reception result storage area for the target interface. (The reception abnormal detection signal does not turn ON.)

## Changing the send monitoring time (timer 2)

The send monitoring time (timer 2) is set in "Send monitoring time (timer 2) designation" of the parameter.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

The send monitoring time (timer 2) monitors the transmission termination time in the condition below.

- When DTR/DSR signal control is used and the DR (DSR) signal is turned OFF ( Page 237 Control Contents of DTR/ DSR (ER/DR) Signal Control)
- When DC1/DC3 receive control is used and DC3 is received ( Page 239 Control Contents of DC Code Control)
- When the RS-232 interface CS (CTS) signal is turned OFF (LMELSEC iQ-R Serial Communication Module User's Manual (Startup))

### Remarks

### When changing the send monitoring time (time 2) setting

Find the send monitoring time (timer 2) from the maximum delay time for the message reception processing or response message transmission processing on the target device side and the transmission time per one-byte (t), and change the setting value. However, the value should be rounded to the nearest 100 ms above.

- Number of bytes transmitted per second (n) = Transmission rate/number of bits transmitted per byte
- Transmission time per byte (t) = 1000 (ms)/number of bytes transmitted per second (n)
- Send monitoring time (timer 2) = (Maximum processing delay time of target device) + (Transmission time per one-byte (t) × Number of transmission bytes)

Under the following conditions, the send monitoring time (timer 2) is set to 300 ms.

- Transmission rate : 9600 bps
- Number of transmit bits/byte : 11 (start bit: 1, data bits: 8, stop bits: 2)
- · Maximum processing delay time : 200 ms
- · Number of transmission bytes: 3 bytes

# **10.4** Transmission Wait Time Setting

The transmission wait time is used during data communications using the MC protocol.

It is the time for a target device that cannot receive the data immediately after data has been transmitted.

When C24 transmits a response message in reply to a command message received from the target device, transmission of the response message is delayed by the transmission wait time, or longer.

The following explains the transmission wait time operation for data communications using 2C/3C/4C frame. (For 1C frame, the transmission wait time is designated in the command message.)

Target device	Command message	]	
CPU module			Response message
		1	1
		<b>→</b>	Message wait time
		1	

## C24 operation by transmission wait time

### When transmission wait time is set to 0 ms

If a response message can be transmitted, C24 immediately transmits the response message. A transmission wait time is not set.

### When the transmission wait time is set to 10 ms or longer

If a response message can be transmitted, and the transmission wait time after reception of the command message has elapsed, C24 transmits the response message.

### Changing the transmission wait time

The transmission wait time is registered on "Transmission wait time designation" of the parameter.

- Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings" ⇔ "Various control specification"
- If the target device that must wait a certain time before it can receive a response message after a command message was transmitted, set the transmission wait time as explained above.

Especially, for data communications with a target device connected to C24 RS-422/485 interface, set the transmission wait time to the hardware gate OFF time or longer of the target device.

• The transmission wait time described here is the time for data communications using the 2C/3C/4C frame.

# **11** DATA COMMUNICATIONS USING DC CODE TRANSMISSION CONTROL

The transmission control function controls (suspends, restarts) the transmission and reception of data between C24 and target device by turning transmission control signals ON and OFF or by transmitting and receiving DC codes (DC1, DC2, DC3, DC4), or informs the valid range for the data to the target device.

The transmission control function can be set for each C24 interface. C24 uses the transmission control function set by the user to control data communications with target devices.

Set the transmission control function to match the specifications of the target device.

The table below lists C24 transmission control functions.

### $(\bigcirc: Valid, -: Invalid)$

Transmission Type of control control function		Interface that can be controlled		Protoc contro	ol that olled	can be		Remarks		
		232	422/485	МС	Non	Bi	Pd			
DTR/DSR signal	DTR control	o – –	—	0	-	0	Cannot be used simultaneously with			
control <sup>*1</sup>	DSR control		(ignore)	0	0	—	0	DC control. Select either one.		
RS/CS signal control <sup>*2</sup>		0	—	0	0	0	0	Normally controlled.		
CD signal control <sup>*2</sup>		0	_	0	0	0	0	The cable wiring depends on whether or not control is used. With half-duplex communications, control is necessary.		
DC code control <sup>*1</sup>	DC1/DC3 transmission control	0	0	-	0	-	0	Cannot be used simultaneously with DTR/DSR signal control.		
	DC1/DC3 reception control			0	0	0	0	Select either one.		
	DC2/DC4 transmission control			0	0	0	0			
	DC2/DC4 reception control			0	0	0	0			

\*1 Refer to the following section when the full-duplex communication is used to communicate data with the bidirectional protocol.

\*2 Check the operation on C24 by the RS(RTS) signal, control contents of CS(CTS) signal, or CD terminal check designation.

### Precautions

When C24 is started, DTR/DSR signal control and RS/CS signal control are enabled.

### How to change the transmission control method and DC code

Switching between DC code control and DTR/DSR control as well as changing of the DC code are set on "Transmission control specification" of the parameter.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings"

# 11.1 Control Contents of DTR/DSR (ER/DR) Signal Control

This control uses the RS-232 interface DTR/DSR signals to inform the target device whether or not the host station is ready to receive data.

C24 uses the ER (DTR) signal to inform the target device whether or not the host station is ready to receive data, and uses the DR (DSR) signal to check if the target device is ready to receive data.



## C24 DTR control contents and free OS area specification

### C24 DTR control contents

C24 uses the ER (DTR) signal to inform the target device whether or not it is ready to receive data.

The data transmitted from the target device using the nonprocedural protocol is stored in the receive data storage area in the buffer memory through the OS area. ( I Page 53 Receiving Data from Target Device)

Under the following conditions, the received data is temporarily stored to the OS area and is transferred to the receive data storage area when the current received data read processing is completed.

- Received data exceeding the size of the receive data storage area on the buffer memory when data, which is "receive data storage area < receive data length", was received.
- · Data received before the program reads the previously received data.

C24 turns the ER (DTR) signal ON/OFF as listed below, depending on the size of the free OS area.

- · Free area is 64 bytes (default) or less: OFF
- · Free area is 263 bytes (default) or more: ON



### Specification of free OS area

For the DTR/DSR (ER/DR) signal control, the size of the free OS area that informs data cannot be received can be set in the parameter below.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

Set the setting value as to be "Transmission control start free space < Transmission control end free space".

• "Transmission control start free space designation"

- Specify an available capacity in the OS area in order to notify that data cannot be received (ER (DTR) signal is OFF).
- Transmission control start free space: 64 to 4,095 (Default: 64)
- "Transmission control end free space designation"

Specify an available capacity in the OS area in order to notify that data can be received (ER (DTR) signal is ON).

• Transmission control end free space: 263 to 4,096 (Default: 263)

#### Remarks

- The receive data clear processing clears the data stored in the OS area. (The receive area on the buffer memory is not cleared.) (
- If more data is received when the free area of the above mentioned OS area is 0 bytes, an SIO error occurs and the data received until a free area is available is ignored. At that time, the SIO signal is turned ON. (SP Page 466 Hardware information communication error "SIO" occurs)

## C24 DSR control

C24 uses the DSR signal to detect whether or not the target device is ready to receive data and to control data transmission to the target device as shown below, depending on whether the DSR is ON/OFF.

- If the DSR signal is ON and there is data to be transmitted, C24 transmits it to the target device.
- If the DSR signal is OFF, even if there is data to be transmitted, C24 does not transmit it to the target device. When the DSR signal is turned ON, C24 transmits the data to the target device.

# **11.2** Control Contents of DC Code Control

This control uses C24 transmission control data to inform a target device whether or not host station is ready to receive data and the valid range of the transmitted/received data.

The four types of C24 DC code control shown below are available. These control functions can be used simultaneously.

- DC1/DC3 transmission control
- DC1/DC3 reception control
- DC2/DC4 transmission control
- DC2/DC4 reception control

## DC1/DC3 transmission control, DC1/DC3 reception control

C24 informs the target device whether or not host station is ready to receive data by transmitting the DC1 and DC3 signals, and checks whether or not the target device is ready to receive data by receiving the DC1 and DC3 signals.

- · DC1: Control data that notifies the target device that C24 is ready to receive data
- DC3: Control data that notifies the target device that C24 is not ready to receive data



### DC1/DC3 transmission control and free OS area specification

The control contents and the free OS area specification are the same as those of the DTR control. (EP Page 237 C24 DTR control contents and free OS area specification)

C24 operates as shown below depending on the capacity of free OS area.

- Free area is 64 bytes (default) or less: DC3 transmission (reception disabled)
- · Free area is 263 bytes (default) or more: DC1 transmission (reception enabled)



### Remarks

- The receive data clear processing clears the data stored in the OS area. (The receive area on the buffer memory is not cleared.) (
- If more data is received when the free area of the above mentioned OS area is 0 bytes, an SIO error occurs and the data received until a free area is available is ignored. At that time, the SIO signal is turned ON. (SP Page 466 Hardware information communication error "SIO" occurs)

### C24 DC1/DC3 reception control contents

When C24 receives DC3 from the target device, it terminates data transmission.

The program cannot read the received DC3 signal.

• When C24 receives DC1 from the target device, it restarts data transmission. (C24 resumes transmission from the data terminated by the DC3 reception.)

The program cannot read the received DC1 signal.



• Once DC1 is received, subsequent DC1 is ignored and removed from the received data.

### ■Remarks

In the DC1/DC3 transmission/reception control, the state of C24 is as follows at the time of power-on, reset or mode switching of the CPU, or the UINI instruction execution.

- C24 does not transmit DC1 to the target device.
- C24 is in the same state as when it transmits DC1.
- C24 is in the same state as when it received DC1 even if DC1 is not received from the target device.

## DC2/DC4 transmission control, DC2/DC4 reception control

C24 encloses the data transmitted from the host station in the DC2 and DC4 codes and transmits it to the target device, and processes the data received from the target device enclosed in the DC2 and DC4 codes as valid data.

- DC2: Control data that informs the target device that the data following it is the start of the valid data
- DC4: Control data that informs the target device that the data immediately preceding it is the end of the valid data

E	Ex.									1
	Target device	DC2	Data	DC4				DC2	Data	
	CPU module				DC2	Data	DC4			
										1

### C24 DC2/DC4 transmission control contents

When transmitting data to a target device, C24 adds the DC2 code to the head of the data to be transmitted and the DC4 code to the end of the data to be transmitted.



\* The DC2 and DC4 code are also added for communication using MC protocol.

### C24 DC2/DC4 reception control contents

- When DC2 is received from the target device, C24 processes the received data up to DC4 as valid data. The received DC2 cannot be read by the program.
- When DC4 is received from the target device, C24 ignores the received data up to the one immediately before DC2 as invalid data.

The received DC4 cannot read by the program.



· Once DC2 is received, subsequent DC2 is ignored and removed from the received data.

## 11.3 Considerations for Using Transmission Control Functions

The following describes the considerations for using the transmission control function of C24.

### Agreement between target device and CPU module

Determine the following between the target device and the CPU module.

- Whether or not the transmission control function is to be used. When it is used, which control is to be used for data communications.
- Control timing
- DC1 to DC4 codes when DC code control is performed (The DC1 to DC4 codes to be used can be arbitrarily changed.)

### Conditions to use the transmission control function

- · DTR/DSR control and DC code control cannot be used at the same time.
- When using DTR/DSR control, connect the ER (DTR) and DR (DSR) signals on the C24 side to the target device.

### Transmission control function setting

Set the transmission control function that can control the target interface.

If a function that cannot control the target interface is set, the set contents are invalid.

### Setting of transmission control function during interlink operation

When the two interfaces of C24 is used as interlink operation, set the transmission control function to either one of interfaces of which transmission control is required.

Set the other interface to "Do not use transmission control function" (the setting values to directly set to the buffer memory is 0001H).

### DC code control

 DC1/DC3 transmission control and DC1/DC3 reception control are possible when full-duplex communications is used to communicate data between C24 and target devices.

Do not use DC1/DC3 control for half-duplex communications.

• The same data as the DC1 to DC4 codes cannot be included in the user data.

To handle the same data as a DC code as user data, perform any of the following: Use DTR/DSR control.

Change the DC code. Do not use the transmission control function.

### ■Remarks

If the user data received from the target device includes the relevant DC code when DC1/DC3 reception control and DC2/DC4 reception control are used, C24 performs the corresponding DC code control.

If the user data transmitted from the CPU module includes a DC code, it is sent unchanged.

### Handling of ER (DTR) and DR (DSR) signals when DTR/DSR control is not used

When the DTR/DSR control is not used, C24 handles the ER (DTR) and DR (DSR) signals as described below.

- ER (DTR) signal is always ON.
- The ON/OFF status of DR (DSR) signal is ignored.

# **12** DATA COMMUNICATIONS USING HALF-DUPLEX COMMUNICATIONS

This chapter explains the settings to prevent simultaneous transmission from C24 and the target device for data

communication between them using the RS-232 interface.

The setting for each interface is available for RJ71C24-R2.

When C24 is started, full-duplex communications is set. The communication method can be changed by the user according to the specifications of the target device.

### Point P

Since the setting for half-duplex communications is not required in the following cases, this chapter can be skipped.

- When data is only transmitted or received during data communications using the nonprocedural protocol.
- When no data is transmitted from the target device to C24 without direction from C24 by the specifications of the target device.

## **12.1** Half-duplex Communications

The following describes the differences between full-duplex communications and half-duplex communications. Since C24 performs the communication controls on the C24 side with the communication method set by the parameter as shown below, control by a program is not necessary.

### Full-duplex communications

This is a communication method to communicate data with a target device like a conversation pattern with a telephone. C24 can receive data while transmitting data to the target device.

It can also transmit data while receiving data from the target device.

Target device	Data A	<b>\-1</b>					Data A-2	
CPU module			ata B-1		Data B-2			

### Half-duplex communications

This is a communication method to communicate data with a target device like a conversation pattern with a transceiver.

When C24 receives data from the target device while transmitting data to the target device, it controls data transmission and reception according to 'simultaneous transmission priority/non-priority designation'.

C24 does not transmit data while it is receiving data from the target device.

Target device	Data A-1			Data A-2
CPU module		Data B-1	Data B-2	

# **12.2** Data Transmission and Reception Timing

Half-duplex communications uses C24 RS-232 interface CD (DCD) and RS (RTS) signals to control communications. If the target device can transmit and receive data according to ON/OFF of C24 RS (RTS) and CD (DCD) signals as shown below, half-duplex communications is possible.

• RS (RTS) signal : C24 turns ON/OFF this signal as shown below.

When data is transmitted from C24, this signal is turned ON. When transmission is completed, this signal is turned OFF. • CD (DCD) signal: Turn ON/OFF this signal on the target device side as shown below.

To transmit data from the target device, turn ON this signal. When transmission is complete, turn OFF this signal.

The data transmission/reception timings for data communications with half-duplex communications are shown by the CD (DCD) signal and RS (RTS) signal of C24.

### Timing when transmitting data from target device

Transmit data by controlling C24 CD (DCD) signal according to the setting value for "simultaneous transmission priority/nonpriority designation" of the parameter.

### ■When C24 is designated to "Priority"



• When transmitting data, check the RS (RTS) signal. If the RS (RTS) signal is OFF, turn ON the CD (DCD) signal. If the RS (RTS) signal is ON, wait until it is turned OFF, and then turn ON the CD (DCD) signal.

Transmit data after turning ON the CD (DCD) signal.

Of After data transmission is completed, turn OFF the CD (DCD) signal.

If the RS (RTS) signal is turned ON during data transmission, terminate data transmission and turn OFF the CD (DCD) signal, and perform data reception processing. (Simultaneous transmission occurred.)

● After transmission from C24 is completed, retransmit all the data terminated at the step ④.

- \*1 Take the following measures between the devices communicating data as a countermeasure against ignoring received data by C24. • Transmission and reception of a response message in reply to data transmission
  - · Time-out check of a response message and retransmission of data due to time-out error (target device side)

### ■When C24 is designated to "Non-priority"



The contents of steps 4 and 5 below are different from those of the case "Priority" is designated.

• When transmitting data, check the RS (RTS) signal. If the RS (RTS) signal is OFF, turn ON the CD (DCD) signal. If the RS (RTS) signal is ON, wait until it is turned OFF, then turn ON the CD (DCD) signal.

Transmit data after turning ON the CD (DCD) signal.

S After data transmission is completed, turn OFF the CD (DCD) signal.

• Keep transmitting data to C24 even if the RS (RTS) signal is turned ON during data transmission. (Simultaneous transmission occurred.)

• After transmission from the target device is completed, transmit data from C24 to the target device. ( Page 246 Timing when transmitting data from C24)

\*1 For the transmission content, refer to the following section.

 $\ensuremath{\mathbb{S}}^{\ensuremath{\mathbb{S}}}$  Page 246 Timing when transmitting data from C24

### Remarks

When using the DTR/DSR transmission control function, transmit data from the target device to C24 as shown below in both cases above. (IP Page 236 DATA COMMUNICATIONS USING DC CODE TRANSMISSION CONTROL)

• When C24 ER (DTR) signal is turned OFF, terminate data transmission.

• When C24 ER (DTR) signal is turned ON after data transmission is terminated, restart data transmission (transmit from the terminated part of the data).

### Timing when transmitting data from C24

Transmit data by controlling C24 RS (RTS) signal according to the setting value for "simultaneous transmission priority/non-priority designation" of the parameter.

### ■When C24 is designated to "priority"



• When transmitting data, check the C24 CD (DCD) signal. If the CD (DCD) signal is OFF, turn ON the C24 RS (RTS) signal. If the CD (DCD) signal is ON, wait until it is turned OFF, and then turn ON the RS (RTS) signal.

2 Transmit the data after turning ON the RS (RTS) signal.

Offer data transmission is completed, turn OFF the RS (RTS) signal.

G Keep transmitting data from C24 to the target device even if the CD (DCD) signal is turned ON during data transmission. (Simultaneous transmission occurred.)

• After transmission from C24 is completed, transmit all the data terminated at step • from the target device to C24.

\*1 As a countermeasure against the disregard for the received data by C24, perform the following between the communicating devices.

• Transmission and reception of a response message in reply to data transmission.

 $\cdot$  Time-out check of a response message and retransmission of data due to time-out error (target device side)

### ■When C24 is designated to "Non-priority"



The contents of steps **4** and **5** below are different from those of the case "Priority" is designated.

• When transmitting data, check the C24 CD (DCD) signal. If the CD (DCD) signal is OFF, turn ON the C24 RS (RTS) signal. If the CD (DCD) signal is ON, wait until it is turned OFF, then turn ON the RS (RTS) signal.

2 Transmit the data after turning ON the RS (RTS) signal.

3 After data transmission is completed turn OFF the RS (RTS) signal.

If the CD (DCD) signal is turned ON during data transmission, terminate data transmission and turn OFF the RS (RTS)

signal, and perform the data receive processing. (Simultaneous transmission occurred.)

• After transmission from the target device is completed, transmit the data terminated at step • from the beginning or terminated part of the data.<sup>\*2</sup>

\*1 The data equivalent to the setting value of "simultaneous transmission priority/non-priority" is not transmitted.

\*2 The data is transmitted from the beginning or from the part where the last transmission has been terminated according to the settings of "Retransmission time transmission method".

### Remarks

When using the DTR/DSR transmission control function, transmit data from the target device to C24 as shown below in both cases above. (SP Page 236 DATA COMMUNICATIONS USING DC CODE TRANSMISSION CONTROL)

- When the C24 DR (DSR) signal is turned OFF, terminate data transmission.
- When the C24 DR (DSR) signal is turned ON after data transmission is terminated, restart data transmission (transmit from the terminated part of the data).

## 12.3 Changing the Communication Method

To change the data communication method from full-duplex communication to half-duplex communication, setting the following parameters is required.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

### RS-232 communication method designation

Set to "half-duplex communications".

### Simultaneous transmission priority/non-priority designation

Set whether to continue ("priority") or stop ("non-priority") transmission from C24 when C24 and the target device start data transmission simultaneously in half-duplex communications.

Setting values "1" to "255" to set to "Non-priority" will be the transmission wait time that elapses from when the resumption of data transmission becomes available until data is actually sent.

### Retransmission time transmission method designation

When "half-duplex communication" and "non-priority" are set as indicated above, this setting becomes valid. Set whether the terminated message will be transmitted from the beginning ('Resend') or from the terminated part of the message ('Do not resend') when C24 and the target device start transmission simultaneously, and C24 stops and then restarts transmitting.

### RS-232 CD terminal check designation

Set the CD terminal check designation to "Check".

## **12.4** Connector Connections for Half-duplex Communications

The following explains the connector that connects C24 and target device when half-duplex communications are used. Connect to the target device in accordance with the following.

- Connect the C24 RS (RTS) signal to one of the target device signals (CS (CTS), DR (DSR), or CD (DCD) signal) for halfduplex communications.
- Connect the C24 CD (DCD) signal to one of the target device signals (RS (RTS) or DR (DSR) signal) for half-duplex communications.
- The half-duplex communications cannot be performed when an RS-232 and RS-422 converter is used.

C24		Cable connection and signal direction	Target device
Signal name	Pin No.	Cable connection and signal direction	Signal name
CD(DCD)	1		CD(DCD)
RD(RXD)	2		RD(RXD)
SD(TXD)	3		SD(TXD)
ER(DTR)	4		ER(DTR)
SG	5	$\bullet \longrightarrow \bullet$	SG
DR(DSR)	6		DR(DSR)
RS(RTS)	7		RS(RTS)
CS(CTS)	8	J₄┘	CS(CTS)
CI(RI)	9		

# **12.5** Considerations for Half-duplex Communications

The following describes the considerations for using half-duplex communications.

### Half-duplex communications system configuration and functions

Half-duplex communications can be used only in a system configuration where the CPU module and a target device are connected on a 1:1 basis.



### Agreement and confirmation between target device and CPU module

Determine and confirm the following items between the target device and the CPU module.

- Whether or not half-duplex communications can be performed by C24 RS (RTS) signal and CD (DCD) signal.
- · C24 RS (RTS) signal and CD (DCD) signal ON/OFF timing
- C24 and target device data transmission timing
- · RS-232 cable connection method

### Transmission control

When the transmission control function is used, DC1/DC3 transmission control and DC1/DC3 reception control of the DC code control cannot be used with half-duplex communications. Therefore, do not designate them.( Page 236 DATA COMMUNICATIONS USING DC CODE TRANSMISSION CONTROL)

12

# **13** CONTENTS AND REGISTRATION OF USER FRAMES FOR DATA COMMUNICATION

User frames are used to register some part, or all of messages exchanged between a target device and C24 in advance and use them to check the data to be transmitted or received.

The following functions can use C24 user frames to transmit and receive data.

- MC protocol on-demand function.( I Page 267 ON-DEMAND DATA COMMUNICATIONS USING USER FRAMES)
- The data transmit/receive function using the nonprocedural protocol ( □ Page 276 DATA COMMUNICATIONS USING USER FRAMES)

Data can be transmitted and received by registering the corresponding user frames to C24 in advance to match the data contents that are transmitted and received between the target device and C24.

This chapter explains the data that can be registered, the data contents that are transmitted and received, and registering to C24 of user frames that can be used in data communications with the target device.

For information on how to use user frames in each data communication function, refer to the following sections.

IF Page 267 ON-DEMAND DATA COMMUNICATIONS USING USER FRAMES

Page 276 DATA COMMUNICATIONS USING USER FRAMES

# **13.1** User Frame Types and Contents During Communication

This section explains the types of user frames handled by C24 and the data contents that are transmitted and received. The following two types of user frames are available. Either type can be used as a user frame.

Frame type	Overview	Reference
User frame	A frame that contains arbitrary data arranged according to the specifications of a target device. The data arrangement can be defined by a user.	Page 250 User frames to be registered and used by the user
Default registration frame	A frame that is registered in C24 in advance. The frame cannot be changed by a user.	Page 258 Default registration frame (read only)

## User frames to be registered and used by the user

The following explains data to be registered, data contents that are transmitted and received, and how C24 handles user frames registered C24 flash ROM or buffer memory by the user.

### Overview

User frames registered by the user are frames that contain arbitrary data according to the specifications of the target device, and the data arrangement are determined by the user.
# User frame registration

Up to 80 bytes (80 characters) of data can be registered as 1 user frame. Up to 231 user frames can be registered (written), read, and deleted to/from C24.

Registration destination		Maximum number of frames can be registered	Frame No.	Application	Remarks	
CPU module	Built-in memory <sup>*1</sup>	31 frames	8001H to 801FH	A user frame of which contents are changed after data communication has started	—	
	SD memory card <sup>*1</sup>	31 frames	8001H to 801FH	A user frame of which contents are changed after data communication has started	—	
C24	Flash ROM <sup>*1</sup>	200 frames	03E8H to 04AFH	A user frame of which contents is not changed after data communication has started	—	
	Buffer memory	31 frames	8001H to 801FH	A user frame of which contents are changed after data communication has started	Registration by overwriting with MOV instruction is available.	

\*1 For the priority of the registered data, refer to the following section.

Page 401 PARAMETER REGISTRATION TO CPU MODULE

Registration data to handle variable data (Sum check code, C24 station number, etc.) as a part of the user frame can be included in the user frame. ( Page 251 Variable data)

User frames can be registered by overwriting to C24 buffer memory. (The preceding contents are destroyed.)

# Data that can be registered as user frame

Up to 80 bytes of data can be registered by combining 1 byte data of which registered code is 01H to FEH and 2 bytes data of which registered code is FFH + 00H to FFH + FFH.

### ■One byte data of which registered code is (01H to FEH)

This is the registered code for transmitting and receiving the data of which registered code is (01H to FEH).

# ■Two bytes data of which registered code is (FFH + 00H) to (FFH + FFH)

This is the registered code for transmitting and receiving the variable data (sum check code, C24 station number, etc.) as part of the user frame. (See Page 251 Variable data)

FFH is the registered code of the first byte for handling variable data.

# Variable data

"Variable data" is a generic term for the data shown below.

These variable data can be handled as part of a user frame.

- Sum check code covering a determined range of messages to be transmitted/received
- · Horizontal parity code covering a determined range of message to be transmitted/received
- · Two's complement sum check code covering a determined range of messages to be transmitted/received
- · C24 station number
- · One byte data in data transmission (00H (NULL), FFH)
- One byte of arbitrary data in data reception. (Used to handle an arbitrary byte of data as part of the user frame during reception check by C24.)

#### ■Variable data designation method

Variable data is designated by combining registered code FFH and the data codes shown in the table below.

The sum check code, C24 station No., and other variable data can be handled according to FFH of the first byte and 00H to FFH of the second byte.



# ■Variable data designation contents, data contents transmitted and received, and handling by C24

The table below shows the registered codes (FFH+00H) to (FFH + FFH) combinations for handling variable data, the data contents that are transmitted and received, and how C24 handles the data.

Variable data registered code		Data contents transmitted and received/C24 handling	Calculating range	Detailed explanation		
1st byte	2nd byte					
Variable dataSistered1st byte2nd byteFFH00H01H01H04H05H04H05H04H05H04H05H11H17H17H15HE5HEBHEBHF1HF1HF3HF3HF4H	00H	When transmitting: Transmits the data code 00H (NULL) data (1 byte). When receiving: Skips the given part (1 byte) of the receive user frame. (Skips the check and performs receive processing.)	-	Series Page 253 C24 processing to the registered code FFH+00H		
	01H	Transmits and receives the host station number as 1-byte binary code data (00H to 1FH).		Page 253 C24 processing to the registered code FFH+01H		
	04H	Transmits and receives the horizontal parity code in the calculating range using 1 byte of binary code data.	Range 1	CF Page 254 C24 processing to registered codes FFH+04H,		
05H       Transmits and receives the horizontal parity code in the calculating range using 2-byte ASCII code data       FFH+05H, FFH+ FFH+05H, range using 1 byte of binary code data.       Range 2         0BH       Transmits and receives the horizontal parity code in the calculating range using 2-byte ASCII code data       Range 1       FFH+05H, FFH+FFH+FFH+FFH+05H, FFH+05H, FFH+05H, FFH+05H, FFH+05H, FFH+05H, FFH+05H, FFH+05H, range 2         11H       Transmits and receives the horizontal parity code in the calculating range.       Range 1       FPage 255 C, to registered code to registered	05H	Transmits and receives the horizontal parity code in the calculating range using 2-byte ASCII code data		FFH+05H, FFH+0AH, and FFH+0BH		
	0BH	Transmits and receives the horizontal parity code in the calculating range using 2-byte ASCII code data				
	11H	Transmits and receives the two's complement sum check code in	Range 1	Page 255 C24 processing		
	17H	the calculating range.	Range 2	to registered codes FFH+11H and FFH+17H		
	E5H	Transmits and receives the sum check code in the calculating range. (Excluding the last one frame) <sup>*1</sup>	Range 3	CF Page 257 C24 processing to registered code FFH+E5H		
	EBH		Range 4	CF Page 257 C24 processing to registered code FFH+EBH		
	EEH	Transmits and receives the sum check code in the calculating	receives the horizontal parity code in the calculating byte of binary code data. receives the horizontal parity code in the calculating byte ASCII code data receives the horizontal parity code in the calculating byte of binary code data. receives the horizontal parity code in the calculating byte of binary code data. receives the horizontal parity code in the calculating byte ASCII code data receives the horizontal parity code in the calculating byte ASCII code data receives the horizontal parity code in the calculating byte ASCII code data receives the two's complement sum check code in range. Range 1 receives the sum check code in the calculating range. last one frame) <sup>11</sup> Range 4 receives the sum check code in the calculating range. Range 4 FH+0BH FH+0BH FF	Page 256 C24 processing		
	F0H	range. '		to registered codes FFH+EEH		
	F1H			to the registered code FFH+01H FFH+05H, FFH+0AH, and FFH+05H, FFH+0AH, and FFH+0BH FFH+0		
	Image using 1 byte of binary code data.       Image using 1 byte of binary code data.       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Range 1       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Range 1       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Range 1       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Range 1       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Range 1       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Range 1       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Range 1       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Range 1       Image using 2-byte ASCII code data         Image using 2-byte ASCII code data       Image using 2-byte ASCII code data       Range 1       Image Using 2-byte ASCII code data         Image using 2-byte ASCII code data       Image using 2-byte ASCII code data       Range 1       Image Using 2-byte ASCII code data         Image using 2-byte ASCII code data       Image using 2-byte ASCII code data       Image Using 2-byte ASCII code data       Image Using 2-byte ASCII code data         Image using 2-byte ASCII code data       Image Using 2-byte ASCII code data       <					
F F F	F4H		Range 2			
	F6H					
	F7H					
	F9H					
	FFH	Transmits and receives the registered code FFH data (1 byte).	—	-		

\*1 During data communication using a user frame that handles the final frame, the contents of the "sum check code" in the transmission setting set by the parameter will be ignored.

# ■Calculating ranges for the registered codes

The following shows the calculating ranges for the registered codes.



(Calculation range when transmitting data)

(Calculation range when receiving data)

Calculating r	anges	Target range*1
Range 1	When transmitting	Range from the data following the start frame (the user frame (1st) when multiple user frames are designated) to the one immediately before the registered code
	When receiving	Range from the data following the start frame to the one immediately before the registered code
Range 2	When transmitting/ receiving	Range from the head of a message to the data immediately before the registered code
Range 3	When transmitting	Range from the data following the start frame (the user frame (1st) when multiple frames are designated) to the one immediately before the final frame (the user frame (nth) when multiple frames are designated)
	When receiving	Range from the data following the start frame to the one preceding the final frame
Range 4	When transmitting/ receiving	Range from the head of a message to the data preceding the final frame

\*1 The additional code data for the transparent code designation shown below is excluded.

# Variable data registered code

# ■C24 processing to the registered code FFH+00H

The following shows an example to describe the processing performed by C24 when it receives a user frame portion corresponding to registered codes FFH and 00H.

When setting a user frame containing the data codes 02H, FFH, 00H, and 3BH for a receive user frame as user frame number, 3EAH

- C24 performs the reception processing as the user frame, 3EAH has been received when it receives 3 bytes of data, "STX, arbitrary data (for 1 byte), ;".
- C24 does not check the 2 bytes described above.



# ■C24 processing to the registered code FFH+01H

C24 transmits and receives the user frame portion corresponding to registered code, FFH+01H by representing the station number set in the parameter as 1-byte binary data.

For the usage example, refer to the start frame portion in the figures below.

Page 254 C24 processing to registered codes FFH+04H, FFH+05H, FFH+0AH, and FFH+0BH

# ■C24 processing to registered codes FFH+04H, FFH+05H, FFH+0AH, and FFH+0BH

• For FFH + 04H and FFH + 0AH

The horizontal parity code that calculates the range for the data to be transmitted/received (message) is expressed as 1 byte binary data and then transmitted and received.

The difference between FFH + 04H and FFH + 0AH is the difference in the calculating range.

• For FFH + 05H and FFH + 0BH

The horizontal parity code that calculates the range for the data to be transmitted/received (message) is expressed as 2byte ASCII code data and then transmitted and received from the upper digit.

The difference between FFH + 05H and FFH + 0BH is the difference in the calculating range.

# Ex.

Examples of data arrangement when the horizontal parity code is transmitted/received are shown below. (The start frame and final frame are equivalent to one frame respectively.)

For registered code FFH + 04H





#### · How to calculate the horizontal parity code

This is a numeric value obtained by calculating the XOR for the subject data and then converting it to ASCII code.

#### Ex. For message example above



254 13 CONTENTS AND REGISTRATION OF USER FRAMES FOR DATA COMMUNICATION
 13.1 User Frame Types and Contents During Communication

# ■C24 processing to registered codes FFH+11H and FFH+17H

The two's complement sum check code that calculates the range for data (message) to be transmitted/received is expressed as two character data in ASCII code, then transmitted and received from the upper digit.

The difference between (FFH+11H) and (FFH+17H) is the difference in the calculating ranges.

An example of the contents (arrangement) of the transmission and reception of the two's complement sum check code is shown below.

# Ex.

Arrangement of data transmitted and received with the registered code FFH+17H (The start frame and final frame are equivalent to one frame respectively.)



· How to calculate the two's complement sum check code

The lower 1 byte of the value obtained by adding the subject data as binary data is converted to a two's complement, then converted to a hexadecimal ASCII code.

#### **Ex.** For message example above

02H+00H+3BH+31H+32H+33H+34H+03H=10AH ----- 
Data in the subject range are added as binary data (hexadecimal)

00001010 ----- The lower 1 byte of the above numeric value is expressed as a binary number
 11110110 ----- Reversed, then converted to a two's complement
 <u>F6H</u> ----- Converted to a hexadecimal ASCII code
 "F" "6"
 (46H) (36H)

# ■C24 processing to registered codes FFH+EEH to FFH+F9H

The sum check code that calculates the range for data (message) to be transmitted/received is expressed as the binary code/ ASCII code data listed below, then transmitted and received.

Registered code	Data contents transmitted and received
FFH + EEH or FFH + F4H	The lower 2 bytes of the calculated sum check code are transmitted and received as 2-byte binary code data.
FFH + F0H or FFH + F6H	The lower byte of the calculated sum check code is transmitted and received as 1-byte binary code data.
FFH + F1H or FFH + F7H	The lower byte of the calculated sum check code is converted to 2-digit ASCII code, then transmitted and received.
FFH + F3H or FFH + F9H	The lower 4 bits of the calculated sum check code is converted to 1-digit ASCII code, then transmitted and received.

An example of the contents (arrangement) of the transmission and reception of the sum check code is given below.



 $\boldsymbol{\cdot}$  How to calculate the sum check code and data contents transmitted and received

This is a numeric value obtained by adding data in the above range as binary data.

# Ex. For Range 1: 41H+ 31H + ABH + 12H + 03H = 0132H For Range 2: 02H + 00H + 3BH + 41H + 31H + ABH + 12H + 03H = 016FH

Calculating range	Registered code	Data contents transmitted and received (arrangement)		
Range 1	FFH + EEH	01H and 32H are transmitted and received, beginning from 32H.		
	FFH + F0H	32H is transmitted and received.		
	FFH + F1H	"3" and "2" are transmitted and received, beginning from "3."		
	FFH + F3H	"2" is transmitted and received.		
Range 2	FFH + F4H	01H and 6FH are transmitted and received, beginning from 6FH.		
	FFH + F6H	6FH is transmitted and received.		
	FFH + F7H	"6" and "F" are transmitted and received, beginning from "6".		
	FFH + F9H	"F" is transmitted and received.		

# ■C24 processing to registered code FFH+E5H

The sum check code that calculates data (message) to be transmitted/received excluding the first one frame and last one frame is expressed as the ASCII code data and transmitted or received.

• How to calculate the sum check code

Lower one byte of the calculated sum check code is converted into 2-digit ASCII code data, and transmitted and received.





### ■C24 processing to registered code FFH+EBH

The sum check code that calculates the data (message) to be transmitted/received, including the first one frame and excluding the last one frame, is expressed as the ASCII code data, and transmitted or received.

· How to calculate the sum check code

Lower one byte of the calculated sum check code is converted into 2-digit ASCII code data, and transmitted or received.



# Default registration frame (read only)

This frame is registered in C24 in advance and can be used in the same way as the other user frames.

# Overview

The default registration frame is registered in the operating system ROM of C24.

The one-byte data (code: 01H to FEH) and a maximum of five-byte data is registered, and can be used for read-only. (Frame No.: 1H to 3E7H)

Each of these frames is treated as a user frame.

# Default registration frame registered data and data contents transmitted and received

The codes of the registration data for default registration frame and the data contents that are transmitted and received are shown below.

Default registration frame No. (HEX (DEC))	Registration data code (1st byte to nth byte)	Registered byte count	Frame byte count	Data contents transmitted and received		
				Data contents		
1H(1)	01H	1	1	(Data of code shown at the left)		
2H(2)	02H			STX		
:	1			:		
FEH(254)	FEH			(Data of code shown at the left)		
FFH(255)	-		-	(For variable data designation)		
100H(256)	00H	1	1	NUL		
101H(257)	FFH	1		(Data of code shown at the left)		
102H(258)	0DH, 0AH	2	2	CR, LF		
103H(259)	10H, 02H	1       1       2       2       3       3       AH       5          2       2       3       2       3       2       2       2       3       2       2       2       3       2       2       2       2       2       2		DLE, STX		
104H(260)	10H, 03H			DLE, ETX		
105H(261)	00H, FEH	2	2	(Data of codes shown at the left)		
106H(262)	00H, 00H, FEH	3	3	(Data of codes shown at the left)		
107H(263)	03H, FFH, F1H	3	2	ETX, sum check code <sup>*1</sup>		
108H(264)	03H, FFH, F1H, 0DH, 0AH	5	4	ETX, sum check code, CR, LF <sup>*1</sup>		
109H(265)	(None)	—	-	-		
:						
10DH(269)						
10EH(270)	FFH, EEH	2	1	Sum check code <sup>*1</sup>		
110H(272)	FFH, F0H					
111H(273)	FFH, F1H					
113H(275)	FFH, F3H					
114H(276)	FFH, F4H					
116H(278)	FFH, F6H					
117H(279)	FFH, F7H					
119H(281)	FFH, F9H					
11FH(287)	FFH, FFH	7		Registered code FFH data (1 byte)		
120H(288)	(None)	-	-	-		
:	]					
3E7H(999)	]					

\*1 The combination of FFH,  $\Box\Box$ H in the registered code is used to handle variable data (sum check code, C24 station number, etc.) as part of the user frame.

The data contents that are transmitted and received and the byte count depend on the code combined with registered code FFH. For combination of registered code to handle variable data and the data contents transmitted/received, refer to the following section.

# **13.2** Transmission/Reception Processing Using User Frame Registration Data

The following explains how C24 transmits and receives using user frame registration data. C24 checks the transmission/reception of following data, using registered data.

# Transmitting data

# When user frame transmission is designated

A user frame is converted or not converted from ASCII to binary data and transmitted, depending on the data communications protocol, ASCII-BIN conversion designation, and user frame No. designation, based on the following data as the send data of the given part.

# ■Registered portion of 1-byte data for code of registration data, 01H to FEH

C24 transmission is based on the data for registered code (01H to FEH).



When data codes 03H, 0DH, and 0AH are registered as user frame number, 3E8H

When user frame number, 3E8H is designated during data transmission, C24 transmits the data codes 03H, 0DH, 0AH (ETX, CR, LF) as the data to be transmitted for the given user frame if ASCII-BIN conversion is disabled.

When ASCII-BIN conversion is enabled, C24 converts each of the data above to 2-byte ASCII code data and transmits.

						_		
Data designated by program							С	L
	Data designated by program					x	R	F
А	В	1	2	to	(89ABH)		1	
41H	42H	31H	32H	P.	ABH 89H	03H	0DH	0AH

Part that designated user frame No. 3E8H (Added by the C24)

(When ASII-BIN conversion disabled)

# ■Registered portion of 2-byte data for code of registration data, FFH+00H to FFH

C24 transmission is based on the variable data corresponding to the combination of the registered codes FFH and 00H to FFH.

For example, if sum check code is registered, C24 will calculate and transmit the sum check code. If C24 station No. is registered, the station number set to C24 is transmitted.



When data codes 03H, FFH, F0H, 0DH, 0AH are registered as user frame number, 3E9H

When user frame number, 3E9H is designated during data transmission, C24 calculates the sum check code as the data to be transmitted for the given user frame portion. If ASCII-BIN conversion is disabled, C24 transmits the calculated data. If ASCII-BIN conversion is enabled, C24 converts the calculated data to 2 bytes per byte ASCII code data and transmits.



# ■Remarks

With the multidrop connection, including data for the target device to identify which station transmitted a message in the user frame can facilitate creation of arbitrary data to be transmitted.



# **Receiving data**

# When user frame reception is designated

When the start frame is set, C24 receives the message when it receives data with the same arrangement as the designated start frame.

If the final frame is set, C24 issues the read request of received data to the CPU module when it receives data with the same arrangement as the designated final frame.

# C24 reception processing by registration data

#### ■Registered portion of 1-byte data for code of registration data, 01H to FEH

C24 receives and checks if the received data is data of the same code (01H to FEH) as the registered code.



When data code 03H, 0DH, 0AH is registered as user frame number, 3E8H

When user frame No. 3E8H is set for data reception, C24 receives and checks data codes 03H, 0DH, 0AH (ETX, CR, LF) as the receive data of that user frame portion.



# ■Registered portion of 2-byte data for code of registration data, FFH+00H to FFH

C24 receives and checks if the received data is variable data corresponding to the combination of the registered codes FFH and 00H to FFH.

For example, if a sum check code is registered, C24 calculates the sum check code from the receive data and checks if it is the same as the received sum check code. If the two codes are not the same, C24 performs error processing.

If C24 station number is registered, C24 checks if the received station number is the same as the station number set in C24. If the two station numbers are not the same, C24 processes the data as if normal data was received instead of a user frame.

# Ex.

When data code 03H, FFH, F0H, 0DH, 0AH is registered as user frame number, 3E9H

When user frame No. 3E9H is set for data reception, C24 calculates, receives, and checks the sum check code as the receive data of that user frame portion.

### In a reception message

C24 removes the user frame data portion from the reception message.

(The CPU module cannot read this data.)

#### ■Remarks

With the multidrop connection, the module on a given station stores only arbitrary data portion of a message transmitted by the target device in the receive data storage area by registering each receive user frame specific to respective modules to be connected.



# **13.3** Considerations for Registering, Reading, and Deleting User Frames

The following shows the considerations for registering user frames and using registered user frames to transmit data to and receive data from the target device normally.

# Considerations for registering, reading or deleting user frames

# ■Registration of user frame

A user frame can be registered using one of the following methods.

- Registering by using the module extended parameters. ( SP Page 265 Registration method using module extended parameters)
- Registering with the dedicated instruction "PUTE" from the CPU module. (LAMELSEC iQ-R Programming Manual (Instructions, Standard functions/Function blocks))
- Registering from a target device with command "1610" through communications using the MC protocol. (

When a user frame is registered using the dedicated instruction or the MC protocol after the registration to the CPU built-in memory or SD memory card by module extended parameters, it is replaced with the contents registered using module extended parameters by powering OFF  $\rightarrow$  ON or switching the CPU module STOP  $\rightarrow$  RUN.

# Setting required to register/delete user frame

The following settings are required when registering or deleting user frames.

• Set "Setting change" to "Enable" in the transmission setting of the parameter.

# ■Registering, reading or deleting user frames from the CPU module

Register/read/delete a user frame when no data is communicated with the target device.

# ■Registration of sum check code

A user frame only with sum check code for variable data cannot be registered. To register sum check code, add arbitrary data.

# ■User frame to be used for reception

Register a receive user frame in the CPU module or the flash ROM of C24.

# Designation of variable data

The variable data (05H to F9H) can be designated at only one place in the final frame.

# Considerations for using user frames

### ■Transmitting/receiving data using user frames

It is necessary to set the user frame number to be used to the buffer memory prior to data transmission/reception (receive user frames must be set at the startup of C24).

# Data communication procedure when the number for a receive user frame is set from the CPU module

The procedure to set a receive user frame number form the CPU module and receive data is shown below.

Receive user frame data by performing the following operations sequentially.

- Restart the CPU module when a user frame to be used for data reception was registered from the CPU module.
- Set the receive user frame number to the buffer memory at the startup of C24, and write "1" in the 'User frame use enable/ disable designation' (Un\G173/333) on the buffer memory.
- Start data reception once the value in the user frame use enable/disable designation area on the buffer memory changes to "2".
- Check whether data is received normally from the target device.

# When additional code data is received during data reception using the nonprocedural protocol

C24 does not assume that 1-byte data immediately after it is data for the following controls.

- Data received as the start frame, final frame for user frame ( Page 250 User Frame Types and Contents During Communication, Page 259 Transmission/Reception Processing Using User Frame Registration Data)
- Receive end code data

Therefore, do not set a user frame containing data receive additional code data as a user frame for data reception using the nonprocedural protocol.

# Arbitrary data portion in a message received from a target device

The arbitrary data portion of a message received from a target device cannot include data with the same arrangement (same code) as the final frame.



User frame (First frame)	Arbitrary data	User frame (Last frame)

# Data bit length of transmission specification

In the following cases, set the data bit length of the transmission specification to 8 bits.

(Set this in "Transmission Setting" of the parameter with Engineering tool for the C24 side.)

- When transmitting and receiving the sum check code of the variable data as binary data (registered code: FFH+EEH, FFH+F0H, FFH+F4H, FFH+F6H)
- · When transmitting and receiving a user frame containing data codes 80H to FFH

# **13.4** Registering/Reading/Deleting User Frames

This section explains registering, reading, and deleting user frames in/from C24 flash ROM or buffer memory.

Type of user frames						
Туре		User frame No.	Registration destination	Remarks		
Data communication function	Default registration frame	1H to 3E7H (1 to 999)	ROM for C24 operating system	Read enabled		
	User frame	3E8H to 4AFH <sup>*1</sup> , <sup>*2</sup> (1000 to 1199)	C24 flash ROM	Register/read/delete enabled		
		8001H to 801FH <sup>*3</sup> (-32767 to -32737)	C24 buffer memory (Un\G6912 to 8182)			
User frame for the programmable controller CPU monitoring function		B001H to B00AH, B061H, B080H to B082H	ROM for C24 operating system	Register/read/delete disabled		

\*1 A user frame cannot be overwritten for registration. To reregister a user frame having the same number, first delete the current user frame and then reregister.

\*2 Check the registration status of the user frame number with Engineering tool.

\*3 The data arrangement of user frame for registration or reading is the same as the one for registration or reading to/from the flash ROM. Register or read user frames in accordance with the arrangement above.

Although user frames can registered in the buffer memory, register user frames of the fixed format portion in the flash ROM as much as possible.

# Devices that can register/read/delete user frames

Туре	User frame No.	Device that can register/read/delete								
		CPU module			Target device			Engineering tool		
		Register	Read	Delete	Register	Read	Delete	Register	Read	Delete
Default registration frame	1H to 3E7H	×	-		×	0	×	×		
User frame	3E8H to 4AFH	O*1	O*2	0*1	0			0		
	8001H to 801FH	0					×			
User frame for the programmable controller CPU monitoring function	B001H to B00AH, B061H, B080H to B082H	×								

\*1 Use the PUTE instruction.

\*2 Use the GETE instruction.

# Precautions

Register/read/delete user frames by a program while no data is communicated with the target device.

# Registration method using module extended parameters

Register the user frame to be used for "Registration frame No. 1000" to "Registration frame No. 1199".

Navigation window ⇒ [Parameters] ⇒ [Module Information] ⇒ Module Name ⇒ [Module Extended Parameter] ⇒ "User frame contents"

# Buffer memory to be used

Requirement for reading/writing from CPU module

 $\bigcirc$ : Always performed,  $\triangle$ : Performed as required,  $\times$ : Unnecessary

Address	Name		Stored value	Processin	ıg	
(Hexadecimal (decimal))				Register	Read	Delete
2H ( 2)	For flash ROM access	Register/read/delete instruction	0: No request 1: Registration request 2: Read request 3: Deletion request	0	0	0
3H ( 3)		Frame number direction	struction       0: No request 1: Registration request 2: Read request 3: Deletion request 3: Deletion request 3: Deletion request         n       0: No designation 1000 to 1199 (3E8H to 4AFH): Frame No. to be registered/read/deleted         e result storage       0: Normal completion Other than 0: Abnormal completion (error code)         count designation ation data byte count       0: When deleting 1 to 80 (1H to 50H): Registered code byte count         me (Un\G6 to 45, 6993,, 8143 to       0: No registration to flash ROM 1 to 200 (1H to C8H): Number of registration to flash ROM         i status storage me registration status er check) (Un\G517 to teck)       0: No registration in the given range Other than 0 : Registration status         n: number of registration (LCP Page 258 Default registration frame (read only))       1 to 80 (1H to 50H): Number of registred code bytes • Registered code bytes • Registered code bytes • Registered frame code (for 80 bytes)         ration data byte count 112, 6953,, 8142))       • 1 to 80 (1H to 50H): Number of registered code bytes • Registered area for 31 frames)         ration data byte count 112, 6953,, 8142))       • 1 to 80 (1H to 50H): Number of registered area for 31 frames)         ration data byte count 112, 6953,, 8142))       • 1 to 80 (1H to 50H): Number of registered area for 31 frames)         ration data byte count 112, 6953,, 8142))       • 1 to 80 (1H to 50H): Number of registered area for 31 frames)         ration data byte count 112, 6953,, 8142))       • 1 to 80 (1H to 50H): Number of registered area for 31 frames			
4H ( 4)		Registration/read/delete result storage	0: Normal completion Other than 0: Abnormal completion (error code)			
5H ( 5)		Registration data byte count designation ( Image 266 Registration data byte count designation (Un\G5, 6912, 6953,, 8142))	0: When deleting 1 to 80 (1H to 50H): Registered code byte count	0	0	×
6H ( 6) to 2DH ( 45)		User frame ( ) Page 266 User frame (Un\G6 to 45, 6913 to 6952, 6954 to 6993,, 8143 to 8182))	Code of frame to be registered/read (for 80 bytes)			
204H (516)		Number of registered user frame storage	0: No registration to flash ROM 1 to 200 (1H to C8H): Number of registration to flash ROM		Δ	Δ
205H (517) to 21DH (541)		User frame registration status storage ( Cም Page 266 User frame registration status (For registration number check) (Un\G517 to 541)) (For registration No. check)	0: No registration in the given range Other than 0 : Registration status			
21EH (542)	Number of regiant (ROM for operation)	stered default registration frames storage ating system)	n: number of registration ( I Page 258 Default registration frame (read only))			
1B00H (6912)	Registration No. 8001H	Registration data byte count designation ( I Page 266 Registration data byte count designation (Un\G5, 6912, 6953,, 8142))	<ul> <li>1 to 80 (1H to 50H): Number of registered code bytes</li> <li>Registered frame code (for 80</li> </ul>	0	Δ	×
1B01H (6913) to 1B28H (6952)		User frame storage (for 40 bytes) ( Image 266 User frame (Un\G6 to 45, 6913 to 6952, 6954 to 6993,, 8143 to 8182))	bytes) (Registered area for 31 frames)			
1B29H (6953)	Registration No. 8002H	Registration data byte count designation ( I Page 266 Registration data byte count designation (Un\G5, 6912, 6953,, 8142))				
1B2AH (6954) to 1B51H (6993)		User frame storage (for 40 words) ( Image 266 User frame (Un\G6 to 45, 6913 to 6952, 6954 to 6993,, 8143 to 8182))				
1B52H (6994) to 1FCDH (8141)	:					
1FCEH (8142)	Registration No. 801FH	Registration data byte count designation ( Image 266 Registration data byte count designation (Un\G5, 6912, 6953,, 8142))				
1FCFH (8143) to 1FF6H (8182)		User frame storage (for 40 words) ( Image 266 User frame (Un\G6 to 45, 6913 to 6952, 6954 to 6993,, 8143 to 8182))				

# ■Registration data byte count designation (Un\G5, 6912, 6953, ..., 8142)

- The total number of bytes of registration data of user frame to be registered (written)/read is indicated.
- Accessing to the flash ROM
   At the time of registration, the user writes the total number of bytes of registration data.
   At the time of reading, the total number of bytes of registration data is stored.
- · Accessing to the buffer memory

At the time of registration, the user writes the total number of bytes of registration data.

# ■User frame (Un\G6 to 45, 6913 to 6952, 6954 to 6993, ..., 8143 to 8182)

- During the registration, the user sequentially stores the registration data of the user frame to be registered in the order of (L) and (H), beginning from the head area of the given area range.
- During the reading, the registration data of the registered user frame is stored with the same contents and arrangement as when registering.

# Ex.

Contents stored in the user frame storage area when a user frame to transmit and receive ETX, sum check code, CR, and LF (registered codes: 03H, FFH, F1H, 0DH, 0AH) is registered to the flash ROM.



# ■User frame registration status (For registration number check) (Un\G517 to 541)

- The registration status of user frames to the flash ROM is stored with the values shown below.
- The contents of each area that indicates the registration status are shown below. The contents of the area are indicated in one user frame number/1 bit form.



# **14** ON-DEMAND DATA COMMUNICATIONS USING USER FRAMES

During communications between a target device and a CPU module using the MC protocol, on-demand data can be transmitted from the CPU module to the target device with the on-demand function using user frames.

This chapter explains the transmission of the data specified by the CPU module using a message format other than the formats (1C frame format 1 to 4, 4C frame format 5) described in the following manual.

(C MELSEC Communication Protocol Reference Manual)

# 14.1 Data Communication Function Using User Frame

The data communication using user frame means transmitting/receiving the first and last parts of a message in the format selected by a user in data communications between the CPU module and target devices via C24.

By using the function described in this chapter, on-demand data in the order shown below can be transmitted from C24 to the target device.

Ex.

Transmitting data according to the order of 3C frame, format 1

On-demand data

T identification No. T identification No. T Network No. T PC No.	т Self-station г No.	ревр обр (character area	ETX	H Sum check	
---	-------------------------	-----------------------------------	-----	-------------	--

As shown in the left, the user can sort the data except for the "Send data" portion.

Transmitted by user frame.

Data can be communicated using the user frames by registering in advance (by data codes) message formats that can be transmitted/received by the target device according to its specifications as user frames in C24. In the above figure, C24 transmits the on-demand data as described below:

Sum check code of a user frame

C24 calculates the sum check code according to the contents registered in advance by the user, and transmits it as ASCII/ binary data.

· Other than sum check code of a user frame

C24 transmits data of the code registered in advance by the user. (No conversion)

Send data (character B portion)

This is the data that the program requested to transmit with ONDEMAND instruction.

It is transmitted with the same contents and in the same order as the one transmitted without using a user frame according to the communication protocol and word/byte designation by the parameters of Engineering tool. (C MELSEC Communication Protocol Reference Manual)

# 14.2 User Frame On-Demand Data Transmission and Buffer Memory Used

This section explains the on-demand data transmission processing using a user frame and the arrangement of on-demand data based on the user frame specification to the buffer memory.

# Transmission of on-demand data using user frames

The following describes the transmission of on-demand data using user frames.

#### ■Processing on the CPU module side

- Before issuing a transmission request to C24, set the No. of the user frame registered in C24 to the buffer memory shown in the table below.
- The execution procedures and control procedures of the CPU module side excluding the above are the same as transmitting on-demand data without user frame described in the following manual.
   (L) MELSEC Communication Protocol Reference Manual)

### ■Processing of the target device side

• When the target device receives the user frame transmitted by C24 as the start frame, receive it as on-demand data.

# Buffer memory to be used and the order of on-demand data

#### ■Buffer memory to be used

For on-demand data transmission using a user frame, the user frame to be transmitted is designated in the buffer memories shown below.

Address		Name			Description			
CH1	CH2							
АЭН ААН	149H 14AH	On-demand user frame specification	Start frame No. designation	(1st) (2nd)	Designates the number of the user frame to be transmitted as the start frame. 0H : No designation Others : Designated <sup>*1</sup> For the 1st frame, other than 0 must be designated. When designating the 1st frame, the 2nd frame can			
ABH	14BH		Final frame No. designation	(1st)	Designates the number of the user frame to be			
ACH	14CH	1		(2nd)	transmitted as the final frame. 0H : No designation Others : Designated <sup>*1</sup> When designating the 1st frame, the 2nd frame can also be designated.			

\*1 Designates the registration No. (shown below) of the user frame to be transmitted from among the user frames registered in C24.
 1H to 3E7H (1 to 999) : Default registration frame
 3E8H to 4AFH (1000 to 1199) : User frame (registered in flash ROM)
 8001H to 801FH (-32767 to -32737) : User frame (registered in buffer memory)

# ■On-demand data arrangement

The following shows the order of on-demand data by user frame specification.

On-demand data



# ■Combination

Only the following combinations can be used for arrangement of on-demand data by user frame specification. O: designated data

Combination	Data name								
	Start frame (1st)	Start frame (2nd)	Send data	Final frame (1st)	Final frame (2nd)				
1	0	0	0	0	0				
2	0	0	0	0					
3	0	0	0						
4	0	0							
5	0		0	0	0				
6	0		0	0					
7	0		0						
8	0								

# ■Description of data to be transmitted

• The outline of data to be transmitted for on-demand data transmission by user frame specification is shown below.

Contents of data to be transmit	ted	Communication with ASCII         Communication wit binary           code         code						
User frame • Start frame (1st)	The portions of which registered code is from 00H to FEH	The data of the code registered in C24	is transmitted. (No conversion)					
Final frame (Last 1 frame)	Combined portions of which registered code is FFH and 00H to FFH	The data according to the user-designated contents, code, and number of bytes is transmitted.						
User frame • Start frame (2nd) • Final frame (Other than last 1 frame)	The portions of which registered code is from 00H to FEH	The data of the code registered in C24 is converted to ASCII data and transmitted.	The data of the code registered in C24 is transmitted. For 10H data, the data of 10H + 10H is transmitted.					
	Combined portions of which registered code is FFH and 00H to FFH	The data of the contents, code, and number of bytes designated by the user to ASCII data and transmitted.	The data of the contents, code, and number of bytes designated by the user is transmitted. For 10H data, the data of 10H + 10H is transmitted.					
Send data (L_] MELSEC Communication Protocol Reference Manual)	—	The designated send data is converted to ASCII data and transmitted.	The designated send data is transmitted by the code unchanged. (No conversion) For 10H data, the data of 10H + 10H is transmitted.					

# 14.3 On-Demand Function Control Procedure During User Frame Use

This section explains the control procedure when on-demand data is transmitted to a target device with the on-demand function by using a user frame.

# Data communication using the ASCII code

Control procedure when two-word send data (1234H, 5678H) is designated by ONDEMAND instruction

- Set the "Communication protocol setting" to any one of the "MC protocol (format 1 to format 4) ".
- Set the "Station number" to "0".
- Set the "Word/byte units designation" to word unit.
- · Set the "On-demand user frame specification" items to the following:

Start frame No. 1st: 02H

Start frame No. 2nd: 3EBH

Final frame No. 1st: 401H

Final frame No. 2nd: 0H (No specification)

User frame registration

User frame No.	User frame (Registered code)	Contents of user frame registration					
02H(2)	02H	Data code from STX to host station number matched to 3C frame, format 1					
3EBH(1003)	F9H, 00H, 00H, FFH, FFH, 00H						
401H(1025)	03H, FFH, F1H	Data code of ETX, sum check code equivalent to 3C frame, format 1					



# Data communications using the binary code

Control procedure when two-word send data (1234H, 5678H) is designated by ONDEMAND instruction

- Set the "Communication protocol setting" to "MC protocol (format 5)".
- Set the "Station number" to "0".
- Set the "Word/byte units designation" to word unit.
- Set the "On-demand user frame specification" items to the following:

Start frame No. 1st: 3ECH

Start frame No. 2nd: 0H (No specification)

Final frame No. 1st: 402H

Final frame No. 2nd: 0H (No specification)

User frame registration

User frame No.	User frame (Registered code)	Contents of user frame registration
3ECH(1004)	02H, FFH, 01H, 3BH	STX + C24 station No. +;
402H(1026)	03H, FFH, F0H, 0DH, 0AH	ETX + sum check code + CR + LF Sum check code is designated by one byte binary code.



# 14.4 Example of On-Demand Data Transmission Program Using User Frames

The following shows a program example when transmitting on-demand data including user frames. Configure the settings and perform registration with Engineering tool in advance.

# On-demand data transmission program using user frames

# ■Input/output signal of C24

Install C24 in the position where the I/O signal is X/Y00 to X/Y1F.

### ■C24 interface used for communication with target device

CH1 side RS-232 interface of C24

# ■Parameter settings

Setting iten	Setting item					
Basic	Various control	Communication protocol setting	MC protocol (format 1)			
settings	specification	Communication speed setting	19200 bps			
		Transmission setting	Data bit	8 bits		
			Parity bit	None		
			Odd/even parity	Odd		
			Stop bit	1 bit		
			Sum check code	None		
			Online change	Disable		
			Setting change	Disable		
		Station number setting (CH1, 2 in common: 0 to 3	31)	0		
		Communication control specification	Word/byte units designation	Word		
		Send wait time specification	Transmission wait time designation	ОН		
		On-demand function specification	Buffer memory start address designation	400H		
			Data length designation	ОН		
Application	User frame specification	On-demand user frame specification	Start frame No. designation (1st)	2H		
settings			Start frame No. designation (2nd)	3EBH		
			Final frame No. designation (1st)	401H		
			Final frame No. designation (2nd)	он		

# ■Program example

Transmit the on-demand data with the on-demand function, and designate the two-word data to be transmitted with the ONDEMAND instruction.

The data in the user frame portion of the on-demand data to be transmitted is the registered data of the user frame number registered with Engineering tool.

Category	Label name		Description	Device
Module label	C24_1		Target module	—
Label to be defined	Define the global label as shown below	Ι.		
	Label Name Label Name bRegPutse_Transmission bRouterNameTransmission bRouterNameTransmission bDNDEMANDInstructionAbnormalCompleteFlag bDReg_Transmission bDNDEMANDInstructionExecutionCompleteDevice bDNDEMANDInstructionExecutionStatusDevice bDNDEMANDInstructionExecutionReguestDevice b	Data Type           Bit	Class         Assign (Device/Label)           VAR_GLOBAL         w M50           VAR_GLOBAL         M100           VAR_GLOBAL         W101           VAR_GLOBAL         X33           VAR_GLOBAL         M0           VAR_GLOBAL         M1           VAR_GLOBAL         M1           VAR_GLOBAL         M1           VAR_GLOBAL         M1           VAR_GLOBAL         M2           VAR_GLOBAL         M51           VAR_GLOBAL         D1	
	10         w I ransmissionDataLount           11         w TransmissionResult           12         wnTransmissionData	Word [Unsigned]/Bit String [16-bit] Word [Unsigned]/Bit String [16-bit] Word [Unsigned]/Bit String [16-bit](01)	VAH_GLUBAL VD2 VAR_GLOBAL VD3 VAR_GLOBAL VD3 VAR_GLOBAL VD3	

For information on the module FB to be used, refer to the following manual.

hBag Transmissi							
X53						PLS	bReqPulse_Transmission M50
bReqPulse_Transmission						K1	wTransmissionChanne
M50					MOV		D1
							DI
						1/0	
					MOV	KZ	w I ransmissionDataGour
						<u> </u>	D2
					MOV	H1234	wnTransmissionData[0]
					 WOV		D10
						H5678	wnTransmissionData[1
					MOV		D11
						RST	ormalCompleteFlag
			-				M100
						RST	bONDEMANDInstruction bnormalCompleteElag
	 						M101
							bONDEMANDInstruction
						SET	xecutionRequestDevice M51
		M_RJ71C24_SendOndemand_00C_1 Send Onder	(M+RJ71C24_SendOndemand_00C) mand EB				
bONDEMANDInstructionE							bONDEMANDInstruction
xecutionRequestDevice M51							xecutionStatusDevice M2
	 	- B:i_bEN	o_bENO:B				0
							bONDEMANDInstruction
							xecutionCompleteDevic
	 	- DUT:i_stModule	0_bOK:B		 		O
	-						
	wTransmission						bnormalCompleteDevice
	Channel	L IIWG LICH	o bErrB				M1
	L	- on tool	0_0E11D				U
	wTransmission			wTransmissionPa			
	DataCount			sult			
	-L <sup>D2</sup> .	⊢ UW:i_uSendDataLength	o_uErrld:UW	-L D3 ]-			
	wnTransmissio nData						
	 [ D10 ]	UW:i_uSendData					
bONDEMANDInstructionE						SET	bONDEMANDInstruction
bONDEMANDInstructionE xecutionCompleteDevice M0					 	JET	M100
bONDEMANDInstructionE xecutionCompleteDevice M0							
bONDEMANDInstructionE xecutionCompleteDevice M0 bONDEMANDInstructionA							
bONDEMANDInstructionE xecutionCompleteDevice M0 bONDEMANDInstructionA bnormalCompleteDevice							bONDEMANDInstruction
bONDEMANDInstructionE xecutionCompleteDevice M0 bONDEMANDInstructionA bnormalCompleteDevice M1						SET	bONDEMANDInstruction bnormalCompleteFlag M101
bONDEMANDInstructionE xecutionCompleteDevice M0 bONDEMANDInstructionA bnormalCompleteDevice M1					 	SET	bONDEMANDInstruction bnormalCompleteFlag M101
bONDEMANDInstructionE xecutionCompleteDevice bONDEMANDInstructionA bnormalCompleteDevice bONDEMANDInstructionE xecutionStructionE					 	SET	bONDEMANDInstruction bnormalCompleteFlag M101 bONDEMANDInstruction
bONDEMANDInstructionE xecutionCompleteDevice bONDEMANDInstructionA bnormalCompleteDevice bONDEMANDInstructionE bONDEMANDInstructionE xecutionStrusDevice M2						SET	bONDEMANDInstruction bnormalCompleteFlag M101 bONDEMANDInstruction xecutionRequestDevice M51
boNDEMANDInstructionE xecutionCompleteDevice Montematic and the second second second borneralCompleteDevice Mi boNDEMANDInstructionE xecutionStatusDevice					 	SET RST	bONDEMANDInstruction bnormalCompleteFlag M101 bONDEMANDInstruction xecutionRequestDevice M51
boNDEMANDInstructionE xecutionCompleteDevice Minimum CompleteDevice boNDEMANDInstructionA bnormalCompleteDevice h boNDEMANDInstructionE xecutionStatusDevice M2 h						SET RST	bONDEMANDInstruction bnormalCompleteFlag M101 bONDEMANDInstruction xecutionRequestDevice M51
boNDEMANDInstructionE xecutionCompleteDevice Montematic and the second second brommalCompleteDevice the secutionStatusDevice 2 boNDEMANDInstructionE xecutionStatusDevice M2						SET RST	EONDEMANDInstruction bnormalCompleteFlag M101 bONDEMANDInstruction xecutionRequestDevice M51

- Set the transmission channel to the CH1 side. Set the send data quantity to two-word. Set the data to be transmitted. Reset the normal completion flag. Reset the abnormal completion flag. Set the execution direction.
- (61) Normal completion
- (63) Abnormal completion
- (65) Reset the execution direction.



- The SPBUSY instruction is used to read the communication status by the dedicated instruction. (SP Page 520 Dedicated Instructions)
- Designate the storage capacity for send data (stored in D10 to D11 in the above program example) and data length (stored in D2 in the above program example) so that they do not exceed the range of buffer memory assigned by the user for the on-demand function.

# **15** DATA COMMUNICATIONS USING USER FRAMES

Registering the fixed format portion of the message transmitted/received by a target device and C24 as a user frame beforehand allows data transmission/reception using a user frame.

Data transmission/reception using a user frame simplifies the creation of data to be transmitted on the CPU module side, and the program for checking received data.

This chapter explains the data transmission/reception methods and procedures when communication data using user frames with the nonprocedural protocol of C24.



• When performing data communication using ASCII-BIN conversion ( Page 347 COMMUNICATING WITH ASCII CODE (ASCII-BIN CONVERSION))

# **15.1** Procedure of Data Communication

This section explains an overview of the procedure when performing data communication between a target device and a CPU module using a user frame.



- \*1 SPage 422 PARAMETER SETTING
- \*2 C Page 250 CONTENTS AND REGISTRATION OF USER FRAMES FOR DATA COMMUNICATION
- \*3 Page 289 Setting of receive user frames
- \*4 Page 278 Receive data
- \*5 SPage 284 Timing for start/completion of data reception
- \*6 Page 313 Data Transmission

# 15.2 Data Reception

When receiving data using a user frame, the reception method on C24 side includes Method 0 and Method 1. The following explains data reception for each method.

# **Receive data**

In data reception using a user frame, data arranged as indicated below can be received.



#### \*1 User frames for receiving

• The user frame for data reception can be set to a maximum of four combinations of the start frame and the final frame, regardless of whether there is a specification.

For a combination that specifies the start frame (with a start frame), specifying the start frame is required even in other combinations.
 For a combination that does not specify the start frame (without a start frame), the start frame cannot be specified even in other combinations.

A combination with the start frame and a combination without the start frame cannot be combined.

\*2 If data of other than 30H to 39H and 41H to 46H are received as the data code of the arbitrary data area (including the transparent code data), an error will occur after the C24 ASCII-BIN conversion processing.

\*3 Arbitrary data portion of received data

When the arbitrary data portion is stored to the receive area, and the storage byte quantity is an odd number of bytes, the receive data quantity shown below is stored to the receive data quantity storage area. (When ASCII-BIN conversion is enabled, the receive data quantity is the storage byte count when the arbitrary data portion is converted to binary code and stored to the receive area.)  $\cdot$  Word units: Receive data quantity = Number of bytes stored to receive area  $\div$  2 (Digits after a decimal points are rounded up.)

· Byte units: Receive data quantity = Number of bytes stored to receive area

(00H is stored to the upper byte of the last data storage location of the receive area.)

When "ASCII-BIN conversion" is enabled, make the arbitrary data part of the receive data an even number of bytes excluding the additional code.



Handling of received data by C24

- When a user frame (start frame, final frame) registered to C24 is received, the reception processing by user frame is performed.
- Of the start frame No. and final frame No. (maximum 4 sets) set in default by the user for the user frame specification for receiving area in buffer memory, the set number (nth) of the user frame received from the target device is stored to the receive user frame storage area.
- When a transparent code for receiving is specified, the additional code data included in the arbitrary data portion is deleted immediately after reception (or, before conversion when ASCII-BIN conversion is performed).

# Reception with the start frame (combination 1-A to C) (reception using Method 0)

### ■Reception of combination (1-A)

This is a method that any data portion of a reception message which can be handled by the CPU module side is enclosed by a start frame and a final frame and transmitted from a target device.

C24 starts the reception processing when data of the same arrangement as the start frame is received.

When data of the same arrangement as the final frame is received, the arbitrary data is stored in the receive area on the buffer memory and a read request is issued to the CPU module.

### Precautions

- Any received data prior to the start frame will be ignored.
- Set a data quantity that exceeds the size of the arbitrary data portion to be received for the receive end data quantity initially set to C24.
- Reception processing by the receive end code initially set to C24 will not be performed. Received data of a receive end code are treated as an arbitrary data portion.



#### When data transmitted from a bar code reader is received

Register STX as the start frame and register ETX as the final frame according to the message format of the bar code reader.





# ■Reception of combination (1-B)

This is a method that message to be received by the CPU module side are all transmitted in a fixed format from a target device.

C24 starts the reception processing when data of the same arrangement as the start frame is received.

When data of the same arrangement as the final frame is received, a read request is issued to the CPU module.

Since there is no arbitrary data portion, the receive data quantity will be "0" when a read request is issued to the CPU module.

# Precautions

- · Any received data prior to the start frame will be ignored.
- The receive end data quantity initially set to C24 uses the default value.

# Ex.

When ACK is registered as the start frame, and CR+LF is registered as the final frame



# ■Reception of combination (1-C)

This is a method that the start of data transmission from a target device to the CPU module side is notified by a start frame, an arbitrary data portion of a fixed length is repeatedly transmitted from a target decide after that.

After the start frame is received, the subsequent received data will be handled as arbitrary data portion.

C24 starts the reception processing when data of the same arrangement as the start frame is received.

A read request is repeatedly issued to the CPU module when an arbitrary data portion, which is equivalent to the receive end data quantity initially set to C24, is received.

# Precautions

- · Any received data prior to the start frame will be ignored.
- The receive end data quantity initially set to C24 should be a data quantity for an arbitrary data (fixed length) transmitted from the target device.
- Reception processing by the receive end code initially set to C24 will not be performed. Received data of a receive end code are treated as an arbitrary data portion.



# Reception with the start frame (combination 1-D, 1-E) (reception using Method 1)

This is a method that an arbitrary data portion, which is equivalent to the 'Method 1 dedicated receive end data quantity' initially set to C24, is transmitted from a target device with a start frame.

C24 starts the reception processing when data of the same arrangement as the start frame is received.

When an arbitrary data, which is equivalent to the specified 'Method 1 dedicated receive end data quantity', is received, the arbitrary data portion is stored in the receive area on the buffer memory and a read request is issued to the CPU module.

# Point P

· Method 1 dedicated receive end data quantity

The receive end data quantity for data reception by using Method 1 is referred to as 'method 1 dedicated receive end data quantity'.

It can be specified with the number of word/byte of "0" or bigger (the unit depends on the word/byte units designation) for each combination of the start frame and the final frame, which specifies Method 1 (up to 4 combinations).

# Precautions

- · Any received data prior to the start frame will be ignored.
- The receive end data quantity initially set to C24 is not used.
- Reception processing by the receive end code initially set to C24 will not be performed. Received data of a receive end code are treated as an arbitrary data portion.
- For reception using Method 1, set "No designation" to the final frame.

# Ex.

By specifying a user frame, in which only ACK (06H) is registered, as the start frame and also the 'method 1 dedicated receive end data quantity' for an arbitrary data portion as 0 bytes, a read request will be issued to the CPU module upon the reception of a 1-byte ACK.

# Ex.

By specifying a user frame, in which only NAK (15H) is registered, as the start frame and also the 'method 1 dedicated receive end data quantity' for an arbitrary data portion as 2 bytes, a read request will be issued to the CPU module upon the reception of NAK + 2-byte data.



# Reception without the start frame (combination 2-A, 2-B) (reception using Method 0)

# ■Reception of combination (2-A)

This is a method that a user frame is used as the final frame in place of the end code for nonprocedural protocol data reception and transmitted from a target device with an arbitrary data portion.

C24 starts the reception processing when the arbitrary data portion is received.

When data of the same arrangement as the final frame is received, the arbitrary data is stored in the receive area on the buffer memory and a read request is issued to the CPU module.

# Precautions

- · Any received data prior to the final frame will be all treated as an arbitrary data portion.
- The receive end data quantity initially set to C24 should be a data quantity that exceeds the size of the arbitrary data to be received.
- C24 performs the following processing with respect to the received data that is the same as the receive end code initially set to C24.

When it is included in the arbitrary data portion: C24 performs the reception processing by the receive end code.

When it is included in the final frame: C24 does not perform the reception processing by the receive end code.

# Ex.

By registering ETX + CR + LF as the final frame, a read request is issued to the CPU module when the end of the received data receives a message of ETX + CR+ LF.



# ■Reception of combination (2-B)

This is a method that a user frame is used as the final frame in place of the end code for nonprocedural protocol data reception and data in a fixed format is transmitted from a target device.

C24 issues a read request to the CPU module when data of the same arrangement as the final frame is received. Upon data reception of this combination which contains no arbitrary data portion, the receive data quantity will be "0" when a read request is issued to the CPU module.

# Precautions

- Any received data prior to the final frame will be all treated as an arbitrary data portion.
- The receive end data quantity initially set to C24 uses the default value.
- When received data that is the same as the receive end code initially set to C24 is included in the final frame, C24 does not perform the reception processing by the receive end code.

# Ex.

By registering ACK + CR + LF as the final frame, a read request is issued to the CPU module when the end of the received data receives a message of ACK + CR + LF.



# Remarks

The following shows the difference between the reception methods (Method 0 and Method 1) in regard to how to treat the received data when data in combination of (a start frame + and arbitrary data portion) is received.

# When data is received using Method 0 (combination (1-C))

- C24 regards all arbitrary data portions as valid data after a start frame has been received, and stores it sequentially in the receive area.
- C24 issues a read request to the CPU module each time arbitrary data portions, which are equivalent to the receive end data quantity, are received, and repeats this process.



# ■When data is received using Method 1 (combination (1-D, 1-E))

- C24 regards arbitrary data portions, which are equivalent to the 'method 1 dedicated receive end data quantity' specified for combination of the received start frames, as valid data after a start frame has been received, and stores it in the receive area. It then issues a read request to the CPU module.
- Any received data after data, which is equivalent to the 'method 1 dedicated receive end data quantity', has been received up to the next start frame will be ignored. (Data will not be stored in the receive area.)



# Timing for start/completion of data reception

This section explains the reading of received data based on the user frame and other factors (such as the receive end code and receive end data quantity) during data reception using a user frame.

# Timing for start/completion of data reception

The following describes the timing for start/completion of the data reception processing with C24.

- Data reception using a user frame
- Data reception using the receive end code and receive end data quantity initially set in C24
- · Data reception using 'method 1 dedicated receive end data quantity'

Туре	Setting of the receive user frame	When using Method 0	When using Method 1				
Data receptio n start	With a start frame	When the start frame is received.					
	Without a start frame	When the first data of arbitrary data is received.	—				
Data	-	The factors of data reception completion (timing of reading received data to the CPU module) is one of the following:					
receptio		(Depends on the conditions of the prior settings. 🖙 Page 285 Timing chart for reception processing of C24)					
n completi on		<ul> <li>When the final frame is received.</li> <li>When data of the receive end code is received. (In the case of a combination without the start frame)</li> <li>When data which is equivalent to the receive end data quantity is received.</li> <li>When a reception error (time out for the no-reception monitoring time (timer 0)) occurs.</li> </ul>	<ul> <li>When the start frame is received while "0" is specified for the 'method 1 dedicated receive end data quantity'.</li> <li>When data which is equivalent to the 'method 1 dedicated receive end data quantity' is received while "1" or more is specified for the 'method 1 dedicated receive end data quantity'.</li> <li>When a reception error (time out for the no-reception monitoring time (timer 0)) occurs.</li> </ul>				
		Arbitrary data portion up to the reception of any listed above or the occurrence of a reception error is stored in the receive area in the buffer memory.					

# Timing chart for reception processing of C24

The charts indicating the timing of the reception processing for data reception using a user frame, including the reception processing by the receive end data quantity, are shown below.

Combination		Amount of received data of	Timing pattern number							
		arbitrary data	Received data	ı						
			Received data prior to the reception of the start frame	When to receiving the start frame of		When receiving arbitrary data in the reception message		ary data in receiving the receiving the receiving the receiving the final frame age		When receiving the end code <sup>*1</sup>
Combi nation	1-A	Receive data quantity < receive end data quantity	Deleted	Data reception start		1-A(1) 1-A(2)		1-A(1)		Data of the end code is treated as part of
with the start frame		Receive data quantity ≥ Receive end data quantity	-						arbitrary data.	
	1-B	Receive data quantity = 0				—		1-B		—
	1-C	Receive data quantity ≤ Receive end data quantity				1-C(1)		—		Data of the end code is treated as part of
		Receive data quantity > Receive end data quantity	-			1-C(2)			arbitrary data.	
	1-D	Receive data quantity Method 1 dedicated receive end data quantity > 0				1-D				
	1-E	Receive data quantity Method 1 dedicated receive end data quantity = 0		Data recepti on start	1-E	_				_
Combi nation	2-A <sup>*2</sup>	Receive data quantity < Receive end data quantity	—	—		Data reception start		2-A(1)		2-A(3)
without the start		Receive data quantity ≥ Receive end data quantity				Data recepti on start	2-A(2)	• •		2-A(4)
name	2-B <sup>*2</sup>	Receive data quantity = 0				_		Data reception start	2-B	_

\*1 The reception processing by the receive end code is not performed when the same data as the receive end code has been registered in the final frame.

\*2 The data reception interval is not monitored with the no-reception monitoring time (timer 0) when only the final frame is set.

Point P

When a reception error is detected, C24 stores arbitrary data portion of the data received immediately before the error in the receive area on the buffer memory, then turns the 'CH1 reception abnormal detection' (X4) ON.

# Combination with the start frame (Timing patterns for data reception start and data reception complete (read))

(For data reception with format-0)


# Combination without the start frame (Timing patterns for data reception start and data reception complete (read))



### **Reception procedure**

The following shows the reception procedure when a message, including data with the same arrangement as the specified user frame, is received and the arbitrary data is read to the CPU module.

### Procedure

(When the CH1 side interface of C24 receives data)

• Read the user frame setting number received from the target device ( $\Box$ -th) out of the start frame number and final frame number (up to 4 combinations) initially set in the user frame specification for receiving area on the buffer memory from the 'Receive user frame (nth)' (Un\G603).

Read arbitrary data portion in the reception message from the receive area (Un\G1536 to 2047 (default))



- \*1 For received data using a user frame and the timing of reading the received data to the CPU module, refer to the timing for start/
- completion of data reception ( Page 278 Receive data, Page 284 Timing for start/completion of data reception))
  \*2 The receive user frame registration number and others should have been set with Engineering tool.
- At the time of debugging, the initial setting value for data reception shall be set prior to data reception, but after debugging is completed, it shall be set to the startup of C24. ( 🖙 Page 289 Setting of receive user frames)
- \*3 Reading (1) for the CPU module to check which user frame was received by C24 and reading of the received data (2).

### Setting of the receive user frame

This setting is to receive data from a target data using the nonprocedural protocol with a user frame.

 $\texttt{Module Name } \texttt{Module Parameter} \Rightarrow \texttt{[Module Information]} \Rightarrow \texttt{Module Name} \Rightarrow \texttt{[Module Parameter]} \Rightarrow \texttt{"Application}$ 

### Settings" ⇒ "User frame specification"

Setting item		Description of setting value			
		Method 0	Method 1		
Receive end data quantity designation	on	Designates the data quantity that exceeds the size of the arbitrary data to be received or the data count of the received data size.	The specified value is invalid. (The 'method 1 dedicated receive end data quantity' becomes valid.)		
Receive end code designation		<ul> <li>Reception of combination with the start frame: The specified value is invalid</li> <li>Reception of combination without the start frame: Designate the code for the last data in the reception message for performing a read request to the CPU module.</li> </ul>			
User frame use enable/disable desig	gnation	Designates "Use".			
Start frame No. designation	1st to 4th	Designate the user frame No. ('0' or '1' or higher).	Designate the user frame No. ('1' or higher).		
Final frame No. designation	1st to 4th	Designate the user frame No. ('0' or '1' or higher).	Designate '0H' for all.		
User frame receiving method designation	1st to 4th	Designate "Method 0".	Designate "Method 1".		
Method 1 dedicated receive end data quantity	1st to 4th	The specified value is invalid.	Designate the data quantity for the arbitrary data to be received.		

### Examples of registering a receive user frame

The following are examples of pre-registering a receive user frame on the CH1 side with Engineering tool.

### ■When the start frame is specified

In the example, the following three combinations are registered for the receive user frame.

Setting conditions

User frame		User frame receiving method designation	Method 1 dedicated receive end data quantity	Remarks
1st combination	(Start frame + Final frame)	Method 0	_	The receive end data quantity becomes valid.
2nd combination	(Start frame only)	Method 1	ОН	Method 1 dedicated receive end data quantity
3rd combination	(Start frame only)	Method 1	2Н	becomes valid.

### · Setting value

Setting item		Setting value	Remarks
Receive end data quantity designation		1FFH	For Method 0
Receive end code designation		FFFFH	Set to "No designation" for receive end code.
User frame specification for receiving User frame use enable/disable designation	ation	Use	Always specify "Use".
User frame specification for receiving	1st	3E8H	0H: No designation
Start frame No. designation	2nd	3E9H	1H or higher: Designated
	3rd	ЗЕАН	
	4th	0H	
User frame specification for receiving	1st	41DH	
Final frame No. designation	2nd	0H	
	3rd	0H	
	4th	0H	
User frame receiving method	1st	Method 0	The receive end data quantity becomes valid.
designation	2nd	Method 1	Method 1 dedicated receive end data quantity becomes valid.
	3rd	Method 1	
	4th	Method 0	-
Method 1 dedicated receive end data	1st	0H	For Method 1
quantity designation	2nd	0H	
	3rd	2H	
	4th	OH	

### ■When the start frame is not specified

In the example, the following three combinations are registered for the receive user frame.

### Setting conditions

User frame		User frame receiving method designation	Method 1 dedicated receive end data quantity	Remarks
1st combination	(Final frame only)	Method 0	_	The receive end data quantity becomes valid.
2nd combination	(Final frame only)			
3rd combination	(Final frame only)			

### · Setting value

Setting item		Setting value	Remarks
Receive end data quantity designation		1FFH	For Method 0
Receive end code designation		ООН	Designate any receive end code.
User frame specification for receiving User frame use enable/disable designation	ation	Use	Always specify "Use".
User frame specification for receiving	1st	0Н	0H: No designation
Start frame No. designation	2nd	0Н	
	3rd	0Н	
	4th	0Н	
User frame specification for receiving	1st	41DH	0H: No designation
Final frame No. designation	2nd	41EH	1H or higher: Designated
	3rd	41FH	in this setting, only three combinations become valid.
	4th	ОН	
User frame receiving method	1st	Method 0	The receive end data quantity becomes valid.
designation	2nd	Method 0	'Method 0' is applied to all since the start frame is not
	3rd	Method 0	designated.
	4th	Method 0	
Method 1 dedicated receive end data	1st	ОН	Setting value for Method 1.
quantity designation	2nd	0H	This setting is not required since 'Method 0' is applied to all.
	3rd	0H	
	4th	ОН	

### Receive user frame setting details

The following explains the purpose and designated value/stored value of each setting data for data reception using a user frame.

### ■User frame use enable/disable designation (Un\G173/333)

Designate "Use" when using user frames to receive data.



- Write '1' in the user frame use enable/disable designation area.
- After the preparation for receiving data using the user frames is completed, '2' is written in the user frame use enable/ disable designation area. (Set by C24)
- After the value in the user frame use enable/disable designation area is changed from '1' to '2', start receiving data used by the user frame.

Until '2' is written in the user frame use enable/disable designation area, data transmission cannot be started.

# Start frame No. designation area and final frame No. designation area (Un\G174 to 181/334 to 341)

From among the user frames registered in C24, designate the user frame No. to be used by following the designation method as shown below.



- 0H (0): No designation
- 1H to 3E7H (1 to 999): Designate the default registration frame (for OS ROM registration).
- 3E8H to 4AFH (1000 to 1199): Designate the user frame (for flash ROM registration).
- 8001H to 801FH (-32767 to -32737): Designate the user frame (for buffer memory registration).

### Precautions

• For the receive user frames, the start frame and final frame are set as a pair, regardless of whether the target device transmits these frames.

(If the target device does not transmit either one of the frames, set the frame No. that is not transmitted to "0" (No designation).)

• A maximum of four combinations of start and final frames can be set for the nonprocedural protocol. However, if there is a combination that specifies the start frame when multiple combinations are set, specify the start frame for all other combinations.

In addition, set in the following order starting from the first buffer memory.

When specifying the start frame

Each frame number for combinations that specify the start frame and the final frame

Each frame number for combinations that specify the start frame but not the final frame

When setting multiple combinations

For the combination that specifies only the final frame without specifying the start frame, the start frame for all of the combinations cannot be specified. Set the frame number for the final frame to be used from the first buffer memory in order.

- When setting more than one combination, the start frame having the registered code in the same arrangement or the same frame No. cannot be designated.
- Use the user frame No. of the following user frames to set the receive user frames. Default registration frame No.: 1H to 3E7H

User frame No. registered in C24 flash ROM: 3E8H to 4AFH

User frame No. registered in C24 buffer memory: 8001H to 801FH

• Do not set the frame number of a user frame contains the additional code data by the transparent code for receiving specification as a user frame for data reception using the nonprocedural protocol.

### ■User frame receiving method designation (Un\G8224 to 8227/8480 to 8483)

In data reception using a user frame, designate the reception method for each combination of receive user frames. This setting is valid when the setting is configured in a combination that specifies a start frame. ( Page 293 Start frame No. designation area and final frame No. designation area (Un\G174 to 181/334 to 341))



For combinations other than those with the start frame only, data reception is performed using 'Method 0' even if 'Method 1' is designated through the above reception method setting.

### ■Method 1 dedicated receive end data quantity designation (Un\G8228 to 8231/8484 to 8487)

• For a combination specifying Method 1 in the user frame receiving method designation, designate the arbitrary data word/ byte count (size for performing a reception data read request to the CPU module) when the applicable start frame is received.

Specify this for each combination specifying Method 1.

- · Designate this within the size of the receive data storage area on the buffer memory.
- The unit of setting values is in accordance with the setting value set for word/byte units designation.



## 15.3 Program for Data Reception with User Frame

This section shows examples of the program to read the received data stored in C24 buffer memory to the CPU module, when data including the user frame is received.

### **Reception program example**

Data reception using a user frame in the following conditions and settings is shown below.

### ■Input/output signal of C24

Install C24 in the position where the I/O signal is X/Y00 to X/Y1F.

### ■C24 interface used for communication with target device

CH1 side RS-232 interface of C24

### ■Parameter settings

Setting ite	m	Setting value								
Basic	Various control	Test mode setting	l	-						
settings	specification	Communication p	rotocol setting	Nonprocedural protocol						
		Communication s	peed setting	19200 bps						
	Transmissi setting	Transmission	Operation setting	Independent						
		setting	Data bit	8						
			Parity bit	None						
			Odd/even parity	Odd						
			Stop bit	1						
							Sum check code	None		
			Online change	Disable						
										Setting change

### Setting content of buffer memory

For other than the following items, use default values.

Address DEC (HEX)	Name	Setting value
CH1		
173 (ADH)	User frame use enable/disable designation	1H: Use
174 (AEH)	Start frame No. designation, 1st <sup>*1</sup>	3E8H <sup>*2</sup>
		8001H <sup>*3</sup>
175 (AFH)	Start frame No. designation, 2nd <sup>*1</sup>	3E9H <sup>*2</sup>
		8002H <sup>*3</sup>
176 (B0H)	Start frame No. designation, 3rd <sup>*1</sup>	6H
177 (B1H)	Start frame No. designation, 4th <sup>*1</sup>	15H
178 (B2H)	Final frame No. designation, 1st <sup>*1</sup>	41BH <sup>*2</sup>
		8005H <sup>*3</sup>
179 (B3H)	Final frame No. designation, 2nd	0H: None
180 (B4H)	Final frame No. designation, 3rd	0H: None
181 (B5H)	Final frame No. designation, 4th	0H: None
8224 (2020H)	User frame receiving method designation, 1st	0H: Method 0
8225 (2021H)	User frame receiving method designation, 2nd	1H: Method 1
8226 (2022H)	User frame receiving method designation, 3rd	1H: Method 1
8227 (2023H)	User frame receiving method designation, 4th	1H: Method 1
8229 (2025H)	Method 1 dedicated receive end data quantity designation, 2nd	12 words
8230 (2026H)	Method 1 dedicated receive end data quantity designation, 3rd	0 word
8231 (2027H)	Method 1 dedicated receive end data quantity designation, 4th	2 words

\*1 It indicates the registered contents of the user frame No. specified to the start and final frame No., respectively.

\*2 When the setting is configured with Engineering tool. (EP Page 296 Program example when setting with Engineering tool)

\*3 When the setting is configured by a program. (

### ■Registration contents in user frame

User frame No.	Registered code	Registered data content
3E8H/8001H	02H, 51H, 20H, 0AH, 3BH	STX, Q, (SP), Station No. of target device, ;
3E9H/8002H	02H, 41H, 3BH	STX, A, ;
6H	06H	ACK
15H	15H	NAK
41BH/8005H	03H, FFH, F0H	ETX, Sum check code

### Program example when setting with Engineering tool

### ■Program example

Category	Label name	Description	Device
Module label	C24_1	Target module	—
	C24_1.stnCH1.bSet_Req_ReceptionRead	CH1 Reception data read request	Х3
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4
	C24_1.stnCH1.uResult_ReceiveUserFrame_D	CH1_Receive user frame (nth)	U0\G603
Label to be defined	Define the global label as shown below.		

1	bINPUT InstructionNormalCompleteFlag	Bit	 VAR_GLUBAL	•	M100
2	bINPUTInstructionAbnormalCompleteFlag	Bit	 VAR_GLOBAL	Ŧ	M101
3	wReceptionUserFramesPairingNumber	Word [Signed]	 VAR_GLOBAL	٠	D100
4	bINPUTInstructionExecutionCompleteDevice	Bit	 VAR_GLOBAL	•	M3
5	bINPUTInstructionAbnormalCompleteDevice	Bit	 VAR_GLOBAL	Ŧ	M4
6	bINPUTInstructionExecutionStatusDevice	Bit	 VAR_GLOBAL	•	M5
7	bINPUTInstructionExecutionRequestDevice	Bit	 VAR_GLOBAL	Ŧ	M10
8	wReceptionChannelNumber	Word [Signed]	 VAR_GLOBAL	•	D1
9	wReceptionResult	Word [Signed]	 VAR_GLOBAL	•	D2
10	wReceptionDataCount	Word [Signed]	 VAR_GLOBAL	Ŧ	D3
11	wReceptionDataAllowableCount	Word [Signed]	 VAR_GLOBAL	•	D4
12	wnReceptionData	Word [Signed](015)	 VAR_GLOBAL	•	D10

Label Name Data Type Class Assign (Device/Label)

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

(0) C24_1.st	tnCH1.bSet_Req_R ceptionRead X3					MOVP	C24_1.stnCH1.uResult_Re ceiveUserFrame_D	wReceptionUserFramesPa ingNumber
						_	UU¥G603	0010
C24_1.st tionAb	tnCH1_bSts_Recep						K1	wReceptionChannelNumb
		 				MOVP		D1
-								
						MOVP	K20	wReceptionDataAllowable ount D4
-								
							SET	bINPUTInstructionExecu nRequestDevice M10
4)			M_RJ71C24_Input_00C_1 (M+RJ71C24_Inp Input FB	ut_00C )				
LINDI ITI	InstructionExecuti	 						hINDI ITInstructionExecut
onR	RequestDevice M10		BibEN	o hENO:B				nStatusDevice M5
		 	D.DEN	0_02110.0				
		G24_1	DUT:istModule	o bOK:B				nCompleteDevice M3
		 		-3				hINPLITInstruction Abnorm
		wReceptionCha nnelNumber						CompleteDevice M4
		L D1	- UW:i_uCh	o_bErr:B				0
		wReceptionData AllowableCount			wReceptionR esult			
		[ D4 ]	UW:LuMaxRecvDataLength	o_uErrld:UW	-[ D2 ]			
			o_uRec	vDataLength:UW				
				o_uRecvData:UW				
i0)	InstructionExecuti CompleteDevice M3						SET	bINPUTInstructionNorma ompleteFlag M100
LINDUT	TinstructionAbnor	 						
2) malC	CompleteDevice M4						SET	bINPUTInstructionAbnorm CompleteFlag M101
54)								(END )
								LIND }

 Read the combinations of user frames received. Set the reception channel to CH1.
 Set the allowable number of data to be received to 20.
 Specify the execution instruction.

(14) Execute reception

(60) Set normal completion flag.

(62) Set abnormal completion flag.



### Program example when setting by a program

### ■Program example

Category	Label name	Description	Device
Module label	C24_1	Target module	—
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.stnCH1.bSet_Req_ReceptionRead	CH1 Reception data read request	X3
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4
	C24_1.stnCH1.uSet_UserFrameUse_Enable_disable_ReceiveUserFrame_D	CH1_Receive user frame use enable/disable designation	U0\G173
	C24_1.stnCH1.wnSet_FirstFrameNum_1st_ReceiveUserFra me_D[0]	CH1_Receive user frame_Start frame No. designation [0]	U0\G174
	C24_1.stnCH1.wnSet_FirstFrameNum_1st_ReceiveUserFra me_D[1]	CH1_Receive user frame_Start frame No. designation [1]	U0\G175
	C24_1.stnCH1.wnSet_FirstFrameNum_1st_ReceiveUserFra me_D[2]	CH1_Receive user frame_Start frame No. designation [2]	U0\G176
	C24_1.stnCH1.wnSet_FirstFrameNum_1st_ReceiveUserFra me_D[3]	CH1_Receive user frame_Start frame No. designation [3]	U0\G177
	C24_1.stnCH1.wnSet_LastFrameNum_1st_ReceiveUserFra me_D[0]	CH1_Receive user frame_Final frame No. designation [0]	U0\G178
	C24_1.stnCH1.wnSet_LastFrameNum_1st_ReceiveUserFra me_D[1]	CH1_Receive user frame_Final frame No. designation [1]	U0\G179
	C24_1.stnCH1.wnSet_LastFrameNum_1st_ReceiveUserFra me_D[2]	CH1_Receive user frame_Final frame No. designation [2]	U0\G180
	C24_1.stnCH1.wnSet_LastFrameNum_1st_ReceiveUserFra me_D[3]	CH1_Receive user frame_Final frame No. designation [3]	U0\G181
	C24_1.stnCH1.uResult_ReceiveUserFrame_D	CH1_Receive user frame (nth)	U0\G603
	C24_1.wnForUserRegistrationNo8001H_D[0]	For user registration number 8001H [0]	U0\G6912
	C24_1.wnForUserRegistrationNo8001H_D[1]	For user registration number 8001H [1]	U0\G6913
	C24_1.wnForUserRegistrationNo8001H_D[2]	For user registration number 8001H [2]	U0\G6914
	C24_1.wnForUserRegistrationNo8001H_D[3]	For user registration number 8001H [3]	U0\G6915
	C24_1.wnForUserRegistrationNo8002H_D[0]	For user registration number 8002H [0]	U0\G6953
	C24_1.wnForUserRegistrationNo8002H_D[1]	For user registration number 8002H [1]	U0\G6954
	C24_1.wnForUserRegistrationNo8002H_D[2]	For user registration number 8002H [2]	U0\G6955
	C24_1.wnForUserRegistrationNo8005H_D[0]	For user registration number 8005H [0]	U0\G7076
	C24_1.wnForUserRegistrationNo8005H_D[1]	For user registration number 8005H [1]	U0\G7077
	C24_1.wnForUserRegistrationNo8005H_D[2]	For user registration number 8005H [2]	U0\G7078
	C24_1.stnCH1.wnSet_UserFrameReceiveFormat_D[1]	CH1_User frame receiving method designation [1]	U0\G8225
	C24_1.stnCH1.wnSet_UserFrameReceiveFormat_D[2]	CH1_User frame receiving method designation [2]	U0\G8226
	C24_1.stnCH1.wnSet_UserFrameReceiveFormat_D[3]	CH1_User frame receiving method designation [3]	U0\G8227
	C24_1.stnCH1.wnSet_UserFrameExclusiveFormat1Receive dDataCount_D[1]	CH1_User frame method 1 dedicated receive end data quantity [1]	U0\G8229
	C24_1.stnCH1.wnSet_UserFrameExclusiveFormat1Receive dDataCount_D[2]	CH1_User frame method 1 dedicated receive end data quantity [2]	U0\G8230
	C24_1.stnCH1.wnSet_UserFrameExclusiveFormat1Receive dDataCount_D[3]	CH1_User frame method 1 dedicated receive end data quantity [3]	U0\G8231
Label to be	Define the global label as shown below.		
defined	Label Name         Data Type           1         bReq_UserFramesReceptionSet         Bit          V           2         bUserFramesReceptionSet         Bit          V           3         bReception?PerseCompleteFlag         Bit          V           4         bINPUT InstructionNormalCompleteFlag         Bit          V           5         bHRPUT InstructionAbnormalCompleteFlag         Bit          V           6         wReceptionUserImameSamigNUmber         Word (Signed]          V           7         bINPUT InstructionExecutionCompleteDevice         Bit          V           9         bINPUT InstructionExecutionStatusDevice         Bit          V           9         bINPUT InstructionExecutionStatusDevice         Bit          V           10         bINPUTInstructionExecutionRequestDevice         Bit          V           11         wReceptionDataLocunt         Word [Signed]          V           11         wReceptionDataCount         Word [Signed]          V           13         wReceptionDataCount         Word [Signed]          V <tr< td=""><td>Class         Assign (Device/Label)           AR_GLOBAL         M0           AR_GLOBAL         M1           AR_GLOBAL         M1           AR_GLOBAL         M1           AR_GLOBAL         M1           AR_GLOBAL         M100           AR_GLOBAL         M101           AR_GLOBAL         M101           AR_GLOBAL         M3           AR_GLOBAL         M3           AR_GLOBAL         M5           AR_GLOBAL         M10           AR_GLOBAL         M5           AR_GLOBAL         M5           AR_GLOBAL         M10           AR_GLOBAL         M10           AR_GLOBAL         M10           AR_GLOBAL         D1           AR_GLOBAL         D2           AR_GLOBAL         D2           AR_GLOBAL         D3           AR_GLOBAL         D4           AR_GLOBAL         D4</td><td></td></tr<>	Class         Assign (Device/Label)           AR_GLOBAL         M0           AR_GLOBAL         M1           AR_GLOBAL         M1           AR_GLOBAL         M1           AR_GLOBAL         M1           AR_GLOBAL         M100           AR_GLOBAL         M101           AR_GLOBAL         M101           AR_GLOBAL         M3           AR_GLOBAL         M3           AR_GLOBAL         M5           AR_GLOBAL         M10           AR_GLOBAL         M5           AR_GLOBAL         M5           AR_GLOBAL         M10           AR_GLOBAL         M10           AR_GLOBAL         M10           AR_GLOBAL         D1           AR_GLOBAL         D2           AR_GLOBAL         D2           AR_GLOBAL         D3           AR_GLOBAL         D4           AR_GLOBAL         D4	

299

### For information on the module FB to be used, refer to the following manual. MELSEC iQ-R Serial Communication Module Function Block Reference

0     1 <th></th> <th>C24_1.bSts_UnitR eady</th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th> <th>bReq_UserFramesReceptionSet</th>		C24_1.bSts_UnitR eady							bReq_UserFramesReceptionSet
Note of the second s	(0)	X1E	 			 		PLS	M0
	(3)	bReq_UserFrames ReceptionSet M0				 	моу	К5	C24_1 wnForUserRegistrationN o8001H_D[0] U0¥G6912
							MOV	H5102	C24_1.wnForUserRegistrationN o8001H_D[1] U0¥G6913
$ \left  $						 	MOV	H0A20	C24_1.wnForUserRegistration o8001H_D[2] U0¥G6914
Image: State of the state o						 	MOV	H38	C24_1 wnForUserRegistrationN o8001H_D[3] U0¥G6915
$\left  \left  \left$							MOV	КЗ	C24_1.wnForUserRegistrationN o8002H_D[0] U0¥G6953
Image: Product of the state							MOV	H4102	C24_1.wnForUserRegistrationN o8002H_D[1] U0¥G6954
Nov         Nov <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>MOV</td> <td>H38</td> <td>C24_1 wnForUserRegistrationN o8002H_D[2] U0¥G6955</td>							MOV	H38	C24_1 wnForUserRegistrationN o8002H_D[2] U0¥G6955
Image: Control of the contro							MOV	K3	C24_1.wnForUserRegistrationN o8005H_D[0] U0¥G7076
Image: state in the s							MOV	H0FF03	C24_1.wnForUserRegistrationN o8005H_D[1] U0¥G7077
$ \left[ $							MOV	HOFO	C24_1 wnForUserRegistrationN o8005H_D[2] U0¥G7078
$ \left  $							MOV	H8001	C24_1.stnCH1.wnSet_FirstFran eNum_1st_ReceiveUserFrame_ D[0] U0¥G174
Image: Section of the section of th						 	MOV	H8002	C24_1.stnCH1.wnSet_FirstFran eNum_1st_ReceiveUserFrame_ D[1] U0¥G175
Image: Solution of the second seco							MOV	H6	C24_1.stnCH1.wnSet_FirstFran eNum_1st_ReceiveUserFrame_ D[2] U0¥G176
Image: Section of the section of t						 	MOV	H15	C24_1.stnCH1.wnSet_FirstFran eNum_1st_ReceiveUserFrame_ D[3] U0¥G177
Image: second						 	MOV	H8005	C24_1.stnCH1.wnSet_LastFran eNum_1st_ReceiveUserFrame_ D[0] U0¥G178
Image: Section of the section of t						 	MOV	H0	C24_1.stnCH1.wnSet_LastFran eNum_1st_ReceiveUserFrame_ D[1] U0¥G179
MOV     H0     C24.1stnCH1wnSet_LastFrame. PU[3]       D[3]     D[3]       U(3)     U(3)						 	MOV	HO	C24_1.stnCH1.wnSet_LastFran eNum_1st_ReceiveUserFrame_ D[2] U0¥G180
							MOV	H0	C24_1.stnCH1.wnSet_LastFram eNum_1st_ReceiveUserFrame_ D[3] U0¥G181

	1	ľ							
							MOV	К1	C24_1.stnCH1.wnSet_UserFram eReceiveFormat_D[1]
							_		U0¥G8225
							моч	К1	C24_1.stnCH1.wnSet_UserFram eReceiveFormat_D[2]
									00+00220
							MOV	К1	C24_1.stnCH1.wnSet_UserFram eReceiveFormat_D[3]
									00+00227
							MOV	K12	C24_1.stnCH1.wnSet_UserFram eExclusiveFormat1ReceivedDa taCount_D[1] U0¥G8229
							MOV	КО	C24_1 stnCH1 wnSet_UserFram eExclusiveFormat1ReceivedDa taCount_D[2] U0¥G8230
							MOV	K2	C24_1 stnCH1.wnSet_UserFram eExclusiveFormat1ReceivedDa taCount_D[3] U0¥G8231
							MOV	K1	C24_1.stnCH1.uSet_UserFrame Use_Enable_disable_ReceiveUse rFrame_D U0¥G173
								SET	bUserFramesReceptionSetCom pleteFlag M1
	hlloorFramosPao				 		 		
(105	eptionSetComplet eFlag M1	=_U	C24_1.stnCH1.uSet_UserFram eUse_Enable_disable_Receive UserFrame_D	K2				RST	bUserFramesReceptionSetCom pleteFlag
			00#0173						NI I
								SET	bReceptionPrepareCompleteFl ag M2
	C24.1 ctoCH1 bS								
(112)	et Reg Reception Read X3						MOVP	C24_1 stnCH1 uRe sult_ReceiveUserFr ame_D U0¥G603	wReceptionUserFramesPairing NUmber D0
	s ReceptionAbnor malDetection X4						MOVP	К1	wReceptionChannelNumber
									D1
							MOVP	K20	wReceptionDataAllowableCoun t
						<u>.</u>	_		D4
				2					bINPUTInstructionExecutionRe
								SET	M10

			M_RJ71C24_Input_00C_1 (M+RJ71C24_Input_00C)			
(126)			input i b			
	hIND!!Thestwatia					
	stDevice					bINPUTInstructionExecutionSt atusDevice
	M10		– Bi bEN o bENO:	3		M5
			-			
						bINPUTInstructionExecutionCo mpleteDevice
		C24_1				M3
			F DUT:LstModule o_bOK:t	3		0
		wRecepti onChann				bINPUTInstructionAbnormalCo mpleteDevice M4
			- UW:i_uCh o_bErr:1	3		0
		1				
		wRecepti onDataAl lowabl…	FIIWiuMayBacyDataLangth ouEwIddlb	wReceptionRe sult		
		ι Η.				
				wReceptionDa taCount		
			o_uRecvDataLength:UV	N-[ D3 ]		
				wnReceptionD ata		
			o_uRecvData:UV	v [ D10 ]		
	bINPUTInstructio					hINDUTIngtructionNormalComp
(172)	eteDevice M3				SET	leteFlag
					-	M100
	bINPUTInstructio					
(174)	nAbnormalCompl eteDevice				SET	bINPUTInstructionAbnormalCo mpleteFlag
					-	M101
(176)						

- (3) Frame No. 8001H setting: registration 1 to 4
  Frame No. 8002H setting: registration 1 to 4
  Frame No. 8005H setting: registration 1 to 4
  Start frame No. designation for receiving: 1 to 4
  Final frame No. designation for receiving: 1 to 4
  Receiving method designation: 2 to 3 Method 1 designation
  Method 1 dedicated receive end data quantity: 2 to 3
  Set User frame use enable/disable designation to "Enable".
- (105) Reception ready
- Read combined number.
   Specify the reception channel.
   Set the allowable number of data to be received.
   Issue the INPUT instruction execution direction.
- (172) Normal completion
- (174) Abnormal completion

# Application program for data reception using a combination that specifies the start frame

The following shows the program example when receiving data using a combination that specifies the start frame.

### **Reception program example**

Data reception using a user frame set with the following conditions is shown below.

#### ■C24 interface used for communication with target device

CH1 side RS-232 interface of C24

#### ■Parameter settings

For other than the following items, use default values.

Item	Setting content	Buffer memory address to store registration value	Remarks
Word/byte units designation	Word/byte	150(96H)	Set to either one according to the program example.
Transparent code for receiving specification	Designated/No designation	288(120H)	When 'Designated', Additional code: 10H (DLE) Transparent code: 02H (STX)
ASCII-BIN conversion designation	Do not convert	289(121H)	-
Receive end data quantity	6	164 (A4H)	-
Receive end code	No designation	165 (A5H)	-
User frame use enable/disable designation	Use	173 (ADH)	Refer to the illustrations provided in this section.
Start frame No. designation Final frame No. designation <sup>*1</sup>	Designated	174 to 177 (AEH to B5H)	
User frame receiving method designation	Method 0/Method 1	8224 to 8227 (2020H to 2023H)	
Method 1 dedicated receive end data quantity designation	0H to FFFFH	8228 to 8231 (2024H to 2027H)	

\*1 It indicates the registered contents of the user frame No. specified to the start and final frame No., respectively.

### ■Registration contents in user frame

Item		User frame No.	Registered code	Registered data content	
Start frame No.	1st	3E8H	02H, 51H, 20H, 0AH, 3BH	STX, Q, (SP), Station No. of target device, ;	
	2nd	3E9H	02H, 41H, 3BH	STX, A, ;	
	3rd	6H	06H	ACK	
	4th	15H	15H	NAK	
Final frame No.	1st	41BH/8005H	03H, FFH, F0H	ETX, Sum check code	
	2nd	0H (none)	—	—	
	3rd	0H (none)	—	—	
	4th	0H (none)			

#### ■Program example

The following shows example of data reception with a user frame.

Category	Label name	Description	Device		
Module label	C24_1	Target module	—		
	C24_1.stnCH1.bSet_Req_ReceptionRead CH1 Reception data read request				
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4		
	C24_1.stnCH1.uResult_ReceiveUserFrame_D	CH1_Receive user frame (nth)	U0\G603		

Category	Label name	Description	Device

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class		Assign (Device/Label)
1	bINPUTInstructionNormalCompleteFlag	Bit	 VAR_GLOBAL	•	M100
2	bINPUTInstructionAbnormalCompleteFlag	Bit	 VAR_GLOBAL	•	M101
3	wReceptionUserFramesPairingNumber	Word [Signed]	 VAR_GLOBAL	•	D100
4	bINPUTInstructionExecutionCompleteDevice	Bit	 VAR_GLOBAL	•	MO
5	bINPUTInstructionAbnormalCompleteDevice	Bit	 VAR_GLOBAL	•	M1
6	bINPUTInstructionExecutionStatusDevice	Bit	 VAR_GLOBAL	•	M2
7	bINPUTInstructionExecutionRequestDevice	Bit	 VAR_GLOBAL	•	M10
8	wReceptionChannelNumber	Word [Signed]	 VAR_GLOBAL	•	D1
9	wReceptionResult	Word [Signed]	 VAR_GLOBAL	•	D2
10	wReceptionDataCount	Word [Signed]	 VAR_GLOBAL	•	D3
11	wReceptionDataAllowableCount	Word [Signed]	 VAR_GLOBAL	•	D4
12	wnReceptionData	Word [Signed](015)	 VAR_GLOBAL	Ŧ	D10

For information on the module FB to be used, refer to the following manual. MELSEC iQ-R Serial Communication Module Function Block Reference

CeptionRead X3					MOVP	C24_1.stnCH1.uResult_Rec eiveUserFrame_D U0¥G603	wReceptionUserFran ngNumber D100
24.1 stnCH1 bSte Recenti							
onAbnormalDetection X4					MOVP	К1	wReceptionChannel D1
					MOVP	K6	wReceptionDataAllo unt D4
						SET	bINPUTInstructionE RequestDevic M10
		M_RJ71C24_Input_00C_1 (1 Input FB	M+RJ71C24_Input_OOC )				
INPUTInstructionExecutio nRequestDevice M10							bINPUTInstructionE StatusDevic M2
		B:i_bEN	o_bENO:B				0
	C24_1	DUT:LstModule	o_bOK:B				bINPUTInstructionE CompleteDev M0
	wReceptionChannel Number						bINPUTInstruction CompleteDev M1
	[ D1 ]	UW:i_uCh	o_bErr:B				O
	wReceptionDataAllo wableCount [ D4 ]	- UW:i_uMaxRecvDataLength	o_uErrid:UW	wReceptionResult -{ D2 }			
				wReceptionDataC			
			o_uRecvDataLength:UW	-{ D3 }			
			o_uRecvData:UW	wnReceptionData -{ D10 }			
INPUTInstructionExecutio nCompleteDevice M0						SET	bINPUTInstruction mpleteFlag M100
INPU I InstructionAbnorma ICompleteDevice M1						SET	bINPUTInstruction/ CompleteFla M101
							(END )-

Read the combinations of user frames received.
 Set the reception channel to CH1.
 Set the allowable number of data to be received to 6.
 Specify the execution instruction.

(14) Execute reception

(60) Set normal completion flag.

(62) Set abnormal completion flag.

### Operation example of various combinations

## When receiving with a combination of the start frame, arbitrary data and final frame (reception using Method 0)



## When receiving with a combination of the start frame and arbitrary data (reception using Method 0)



### When receiving with user frame only (reception using Method 0)



The following diagram is for reception using the combination of first frame and last frame. User frame use enable/disable designation First frame No. designation (1st) (2nd) (3rd) (4th) Last frame No. designation (1st) (None) (2nd) (None) (3rd) (None) (4th) (YES) (NO) Receive transparent code 1002H/ 0H designation ASCII-BIN conversion (Disable) designation **2** to D0 Receive user frame ( th) € to D3 Receive data count 00H , 00H User frame receive format designation Un\G8224 0H (1st = format-0) Un\G8225 0H (2nd = format-0) Un\G8226 1H (3rd = format-1) Un\G8227 1H (4th = format-1)Received data count 0H Un\G8228 for format 1 only (1st) 0H Un\G8229 (2nd) Un\G8230 0H (3rd) 2H Un\G8231 (4th) Buffer memory

### ■When receiving with first start only (reception using Method 1)



## When receiving with a combination of the start frame and arbitrary data (method 1 dedicated receive end data quantity) (reception using Method 1)



# Application program for data reception using a combination that does not specify the start frame

The following shows the program example when receiving data using a combination that does not specify the start frame.

### **Reception program example**

Data reception using a user frame set with the following conditions is shown below.

#### ■C24 interface used for communication with target device

CH1 side RS-232 interface of C24

### ■Parameter settings

For other than the following items, use default values.

Item	Setting content	Buffer memory address to store registration value	Remarks
Word/byte units designation	Word/byte	150 (96H)	The unit is set to "Word" in the example.
Transparent code for receiving specification	Designated	288 (120H)	Specify as follows: Additional code: 10H (DLE), Transparent code: 02H (STX)
ASCII-BIN conversion designation	Do not convert	289 (121H)	-
Receive end data quantity	6	164 (A4H)	—
Receive end code	No designation	165 (A5H)	-
User frame use enable/disable designation	Use	173 (ADH)	
Start frame No. designation <sup>*1</sup>	No designation	174 to 177 (AEH to B1H)	
Final frame No. designation <sup>*1</sup>	Designated	178 to 181 (B2H to B5H)	
User frame receiving method designation	Method 0	8224 to 8227 (2020H to 2023H)	
Method 1 dedicated receive end data quantity designation	ОН	8228 to 8231 (2024H to 2027H	

\*1 It indicates the registered contents of the user frame No. specified to the start and final frame No., respectively.

### ■Registration contents in user frame

Item		User frame No.	Registered code	Registered data content	
Start frame No.	1st	0H (none)	—	—	
	2nd	0H (none)	—	—	
	3rd	0H (none)	—	-	
	4th	0H (none)	—	—	
Final frame No.	1st	419H	3BH, 04H	;, E0T	
	2nd	0H (none)	—	-	
	3rd	0H (none)	—	—	
	4th	0H (none)	_	_	

### ■Program example

The following shows the example of data reception with a user frame.

Category	Label name	Description	Device			
Module label	C24_1	Target module	—			
	C24_1.stnCH1.bSet_Req_ReceptionRead CH1 Reception data read request					
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4			
	C24_1.stnCH1.uResult_ReceiveUserFrame_D	CH1_Receive user frame (nth)	U0\G603			

Category	Label name	Description	Device

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class		Assign (Device/Label)
1	bINPUTInstructionNormalCompleteFlag	Bit	 VAR_GLOBAL	-	M100
2	bINPUTInstructionAbnormalCompleteFlag	Bit	 VAR_GLOBAL	•	M101
3	wReceptionUserFramesPairingNumber	Word [Signed]	 VAR_GLOBAL	Ŧ	D100
4	bINPUTInstructionExecutionCompleteDevice	Bit	 VAR_GLOBAL	•	MO
5	bINPUTInstructionAbnormalCompleteDevice	Bit	 VAR_GLOBAL	•	M1
6	bINPUTInstructionExecutionStatusDevice	Bit	 VAR_GLOBAL	•	M2
7	bINPUTInstructionExecutionRequestDevice	Bit	 VAR_GLOBAL	•	M10
8	wReceptionChannelNumber	Word [Signed]	 VAR_GLOBAL	-	D1
9	wReceptionResult	Word [Signed]	 VAR_GLOBAL	•	D2
10	wReceptionDataCount	Word [Signed]	 VAR_GLOBAL	•	D3
11	wReceptionDataAllowableCount	Word [Signed]	 VAR_GLOBAL	•	D4
12	wnReceptionData	Word [Signed](015)	 VAR_GLOBAL	•	D10

For information on the module FB to be used, refer to the following manual. MELSEC iQ-R Serial Communication Module Function Block Reference

eceptionRead X3					MOVP	C24_1.stnCH1.uResult ReceiveUserFrame_D U0¥G603	wReceptionUser airingNum D100
224 Late OHI h Ste Desert		·					
ionAbnormalDetection X4					MOVP	К1	wReceptionCha ber D1
					MOVP	K6	wReceptionDat eCoun D4
						SET	bINPUTInstruc tionRequest M10
		M D 171004 Inv. + 000 1	( MIR 171024 hourt 000 )				
		M_RJ/TG24_Input_00C_T Inp	(M+RJ/1C24_Input_00C) ut FB				
onRequestDevice M10		DUD					bINPUTInstructionStatus M2
		BIDEN	0_DENU:B				0
	C24_1	DIIT: etModule	a bOK B				bINPUTInstructionComplet M0
	L 1	DOT. stimodule	0_00/08				V
	wReceptionChann eINumber						bINPUTInstru malComplet M1
		UW:LuCh	0_bErr:B				0
	wReceptionDataA IlowableCount D4 7	UW iuMaxRecyDataleneth	o uErrid:LIW	wReceptionRe sult - D2 - D2			
	J			· J			
			o_uRecvDataLength:UW	wReceptionDat aCount -{ D3 }			
				wnReceptionD ata			
			o_uRecvData:UW	-{ D10 }			
DINPUTInstructionExecuti onCompleteDevice							bINPLITInstruc
						SET	IComplet M10
INPUTInstructionAbnorm							
M1						SET	bINPUTInstruc malComple M10
							END

Set the reception channel to CH1. Set the allowable number of data to be received to 6. Specify the execution instruction.

(14) Execute reception

(60) Set normal completion flag.

(62) Set abnormal completion flag.

### **Operation example**





# 15.4 Data Transmission

This section explains the arrangement of the data to be transmitted and transmission procedure when transmitting data using a user frame.

### Send data

The order of data, codes, and handling of send data by C24 for data transmission using a user frame are shown below.

### Send data arrangement

The combination shown below are only allowed as the order of data to be transmitted using a user frame.



- \*1 OH to FH data for four bits are converted to 30H to 39H and 41H to 46H ASCII code data and transmitted as the data codes of the data to be transmitted (including the transparent code data).
- \*2 Arbitrary data portion of send data

 $\cdot$  When the send data quantity designated by the CPU module during transmission in byte units is an odd number of bytes, the data of the lower byte of the last transmitted data storage location in the send data storage area is transmitted.

· When ASCII-BIN conversion is enabled, the data to be transmitted is transmitted as 2 characters per byte.



Handling of send data by C24

- The data of the user frame and the data in the send area designated from the CPU module is transmitted in accordance with the contents and order designated to the send user frame designation area in the buffer memory.
- For the user frame portion and arbitrary data portion, the data can be transmitted as ASCII code data using the ASCII-BIN conversion. (SP Page 347 COMMUNICATING WITH ASCII CODE (ASCII-BIN CONVERSION))
- If a transparent code for sending is specified, the additional code data is added in front of the transparent code/additional code in the data of the designated area and transmitted.

### **Transmission procedure**

The following describes the transmission procedure when a message containing user frames is transmitted to the target device.

### Procedure



\*1 Designate the user frame number for the data to be sent.

- \*2 CPU module processing
  - Before issuing a transmission request to C24, designate (write) the following data.
  - Send user frame designation area : User frame number, transmission method and transmission order registered in C24 • Send area (Buffer memory): User data corresponding to arbitrary data portion in the transmission message
- \*3 When a send data quantity designation error or data transmission error occurred, C24 stores the error code to the transmission result storage area of control data for PRR instruction, and the status display device at completion turns ON.

### Settings of send user frames

These settings are required for transmitting data to a target device using user frames by the nonprocedural protocol. These settings are configured with Engineering tool or from the CPU module.

### Settings with Engineering tool

- · Configure the settings to transmit data in "Send user frame designation" of the parameter.
- Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ Module Name ⇔ [Module Parameter] ⇔ "Application Settings" ⇔ "User frame specification"

### Settings by the CPU module

### How to designate and write send data when transmitting with user frames

For arbitrary data portion when transmitting user frames and arbitrary data portion in combination, the send data quantity and send data are written in the send area as is the case in transmitting them in an arbitrary format.

User frames are registered using Engineering tool. Or, the user frame registration number to be sent is written from the CPU module to the send user frame designation area of the buffer memory as shown in the figure below.

After executing registration/write, C24 transmits the designated data in the designated order upon execution of the PRR instruction.



### Sending data in the following order

Transmission order	Send data type	User frame No.	Contents of transmitted/registered data
1	User frame	2H (2)	02H (STX)
2	User frame	3E8H (1000)	01H, 3BH (station No., ";")
3	Arbitrary data	8000H (-32768)	41H, 42H, 43H, 44H ("ABCD")
4	User frame	400H ( 1024)	03H, FFH, F6H, 0DH, 0AH (ETX, Sum check, CR, LF)





Figure at left is for byte units. For word units, the arbitrary data portion is sent in the sequence of "ABCD".

\*1 When sending data that was written to the send area, 8000H is used as a temporary user frame number. (Page 316 Send user frame designation)

### Send user frame designation

The following explains the purpose of the buffer memory to be used when transmitting data using user frames, along with the designated and stored values.

'Sending user frame' (Un\G182/342)
 In data communications using a user frame, what number of the send frame number designation area is being sent is stored.



0H( 0): Not sent

1H to 64H( 1 to 100): User frame being transmitted designation No. (nth number)

• 'CR/LF output designation' (Un\G183/343)

When transmitting a user frame or arbitrary data that does not contain CR/LF, designate whether or not a CR+LF will be sent each time a user frame or arbitrary data is sent.



· 'Output start pointer designation' (Un\G184/344)

Write the head position ( $\Box$ th) in the send frame number designation area for writing the registration number of the user frame to be sent.

However, transmission using a user frame is not performed when the value of the output start pointer designation area is "0".



• 'Output quantity designation' (Un\G185/345)

Write how many user frames are transmitted from the designated position in the output start pointer designation area. However, transmission is not performed and completed normally when the value of the output quantity designation area is "0".



'Send frame number designation' (Un\G186 to 285/346 to 445) Write the user frame No. to be sent in the order in which they are output from the position designated in the output start pointer designation area.

When transmitting data that is written in the send area, use 8000H as a temporary user frame No.

By designating user frame No. 8000H, C24 transmits the data in the send data specification area for the data quantity

### designated in the send data quantity designation area.

Buffer memory address	Un\G186	User frame No.(1st)	
	to	to	├ (CH1 side)
	Un\G285	User frame No.(100th)	J
	Un\G346	User frame No.(1st)	)
	to	to	├ (CH2 side)
	Un\G445	User frame No.(100th)	
		1	

Specifies the following user frame No. for the data to be sent.

Note that the number on the right side of the user frame No. below is the number used for transmission without ASCII-BIN  $\,$ 

conversion for only the data of any frame portion when transmission data is converted into ASCII-binary data and transmitted.

0H: No transmission designation. (No additional transmission is allowed.)

1H to 3E7H/4001H to 43E7H: Transmits the default frame having the designated number. 3E8H to 4AFH/43E8H to 44AFH: Transmits the user frame having the designated number. (For flash ROM registration)

8000H/C000H: Transmits data in the transmission area of the buffer memory. 8001H to 801FH/C001H to C01FH: Transmits the user frame having the designated number. (For buffer memory registration)

### Point P

The following transmission can be performed by adding 4000H to the registered user frame number and specifying it.

- When ASCII-BIN conversion is enabled, a specified frame can be sent without the conversion. ( Frage 348 ASCII-BIN Conversion for Data Communicated with Nonprocedural Protocol)
- A specified frame can be transmitted without adding the additional code by the transparent code for sending specification. (EP Page 328 Handling Transparent and Additional Codes for Nonprocedural Protocol Data Communication)

### 15.5 Application Program for Data Transmission using a Combination that does not Specify the Start Frame

The following shows the program examples for data transmission using a user frame.

### Transmission program example

Data transmission using user frames in the following conditions and settings is shown below:

### ■C24 interface used for communication with a target device

CH1 RS-232 interface of C24

### ■Parameter settings

Setting ite	m			Setting value		
Basic settings	Various control	Test mode setting	1	-		
	specification	Communication p	protocol setting	Nonprocedural protocol		
		Communication s	peed setting	19200 bps		
		Transmission	Data bit	8		
		setting	Parity bit	None		
			Odd/even parity	Odd		
			Stop bit	1		
			Sum check code	None		
		Station number se	Online change	Disable		
			Setting change	Disable		
			etting (CH1, 2 in common: 0 to 31)	1		

### ■Buffer memory setting contents

For other than the following items, use default values.

Item	Setting content	Buffer memory address to store registration value	Remarks
Word/byte units designation	Byte	150 (96H)	—
Transparent code for sending specification	No designation	287 (11FH)	—
ASCII-BIN conversion designation	Do not convert	289 (121H)	-
Send frame number designation (1st)	3F2H	186 (BAH)	-
Send frame number designation (2nd)	3F3H	187 (BBH)	-
Send frame number designation (3rd)	8001H	188 (BCH)	-
Send frame number designation (4th)	8000H	189(BDH)	-
Send frame number designation (5th)	41BH	190(BEH)	—

### Program example when setting using Engineering tool

The following shows the method to send data by specifying the send frame number with Engineering tool.

### ■Program example

Category	Labe	el name	Desc	riptio	on		Device		
Module label	C24_	1		Target module					—
	C24_	1.bSts_UnitReady		Module	e REA	٩D	Y		X1E
	C24_	1.bSts_WatchdogTimerError		Watchdog timer error					X1F
	C24_	1.stnCH1.uSet_TransmissionD	ataCount_D	CH1_S	Send	da	ta quantity design	ation	U0\G1024
	C24_	1.wnForUserRegistrationNo800	01H_D[0]	For us	er reg	gist	tration number 800	D1H [0]	U0\G6912
	C24_	1.wnForUserRegistrationNo800	01H_D[1]	For us	er reg	gist	tration number 800	D1H [1]	U0\G6913
Label to be defined	Defin	e the global label as shown bel	OW.						
			D : T	~					
	- 1	Label Name	Data Type		ass DAT	_	Assign (Device/Label)		
	2	bPPPIpetructionNormalCompleteFlag	Dit .	 VAR_GLO		-	M100		
	2	bPBBInstructionAbnormalCompleteFlag	Bit	 VAR GLO		÷	M101		
	4	bBeg Transmission	Bit	 VAB GLO	IBAI	÷	X50		
	5	wTransmissionDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR GLO	BAL	-	DO		
	6	wnTransmissionData	Word [Unsigned]/Bit String [16-bit][01]	 VAR GLO	BAL	-	D1		
	7	bPRRInstructionExecutionCompleteDevice	Bit	 VAR_GLO	BAL	-	MO		
	8	bPRRInstructionAbnormalCompleteDevice	Bit	 VAR_GLO	)BAL	-	M1		
	9	bPRRInstructionExecutionStatusDevice	Bit	 VAR_GLO	)BAL	-	M2		
	10	bPRRInstructionExecutionRequestDevice	Bit	 VAR_GLO	)BAL	-	M10		
	11	wTransmissionResult	Word [Unsigned]/Bit String [16-bit]	 VAR_GLO	BAL	-	D15		
	12	wTransmissionChannel	Word [Signed]	 VAR_GLO	BAL	-	D21		
	13	wCR_LF_OutputDesignation	Word [Signed]	 VAR_GLO	BAL	-	D22		
	14	wTransmissionPointer	Word [Signed]	 VAR_GLO	BAL	•	D23		
	15	wOutputCount	Word [Signed]	 VAR_GLO	)BAL	•	D24		

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

(0)	bReq_Transmissi on X50								PLS	bReqPulse_Transn ission M50
(3)	bReqPulse_Tran smission M50	C24_1.bSts_ UnitReady X1E	C24_1.bSts_Watc hdogTimerError X1F					MOVP	K1	wTransmissionCha nnel D21
			<u>, , , , , , , , , , , , , , , , , , , </u>							
								MOVP	КО	wCR_LF_OutputD signation D22
								MOVP	К1	wTransmissionPo nter D23
								MOVP	K5	wOutputCount
										D24
								моу	К4	wTransmissionDa aCount
								моу	H1234	wnTransmissionD ta[0]
									-	D1
				 				MOV	H56AB	wnTransmissionD ta[1] D2
										01
							BMOV	wTransmissi onDataCoun t D0	C24_1.stnCH1.uS et_TransmissionD ataCount D U0¥G1024	К3
								MOV	H2	C24_1.wnForUser egistrationNo800 H D[0] U0¥G6912
										GUIGUUIE
								MOV	H12D	C24_1.wnForUserl egistrationNo800 H D[1] U0¥G6913
									SET	bPRRInstruction xecutionRequest evice M10
									RST	bPRRInstruction xecutionComplete Device M0



(3) Set the transmission channel to 1. Set CR/LF to "Do not send". Set the send pointer to 1. Set the output quantity to 5. Set an arbitrary send data quantity. Set an arbitrary send data. Set an arbitrary send data in send area. Set the transmission direction.

(86) Set normal completion flag.

(88) Set abnormal completion flag.


#### Program example when not setting with Engineering tool

The following shows the methods to transmit data without specifying the send frame number with Engineering tool.

#### ■Program example

Category	Label name	Description	Device
Module label	C24_1	Target module	—
	C24_1.bSts_UnitReady	Module READY	X1E
	C24_1.bSts_WatchdogTimerError	Watchdog timer error	X1F
	C24_1.stnCH1.wnSet_OutputFrameNum_UserFrame_D	CH1_Send user frame_Send frame number designation	U0\G186
	C24_1.stnCH1.uSet_TransmissionDataCount_D	CH1_Send data quantity designation	U0\G1024
	C24_1.wnForUserRegistrationNo8001H_D[0]	For user registration number 8001H [0]	U0\G6912
	C24_1.wnForUserRegistrationNo8001H_D[1]	For user registration number 8001H [1]	U0\G6913
Label to be defined	Define the global label as shown below.		
	Label Name         Data Type           1         bRegPulse_Transmission         Bit            2         bPRRInstructionNormalCompleteFlag         Bit            3         bbPRRInstructionAbnormalCompleteFlag         Bit	Class         Assign (Device/Label)           VAR_GLOBAL         ▼         M50           VAR_GLOBAL         ▼         M100           VAR_GLOBAL         ▼         M101	

	DHeqPuise_Transmission	Bit	 VAR_GLUBAL	•	M50
2	bPRRInstructionNormalCompleteFlag	Bit	 VAR_GLOBAL	•	M100
3	bbPRRInstructionAbnormalCompleteFlag	Bit	 VAR_GLOBAL	Ŧ	M101
4	bReq_Transmission	Bit	 VAR_GLOBAL	-	×50
5	wTransmissionDataCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	Ŧ	DO
6	wnTransmissionData	Word [Unsigned]/Bit String [16-bit](01)	 VAR_GLOBAL	•	D1
7	wTransmissionPointer1	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D5
8	wTransmissionPointer2	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	Ŧ	D6
9	wTransmissionPointer3	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D7
10	wTransmissionPointer4	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D8
11	wTransmissionPointer5	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D9
12	bPRRInstructionExecutionCompleteDevice	Bit	 VAR_GLOBAL	Ŧ	MO
13	bPRRInstructionAbnormalCompleteDevice	Bit	 VAR_GLOBAL	•	M1
14	bPRRInstructionExecutionStatusDevice	Bit	 VAR_GLOBAL	•	M2
15	bPRRInstructionExecutionRequestDevice	Bit	 VAR_GLOBAL	Ŧ	M10
16	wTransmissionResult	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D15
17	wTransmissionChannel	Word [Signed]	 VAR_GLOBAL	Ŧ	D21
18	wCR_LF_OutputDesignation	Word [Signed]	 VAR_GLOBAL	•	D22
19	wTransmissionPointer	Word [Signed]	 VAR_GLOBAL	-	D23
20	w0utputCount	Word [Signed]	 VAR_GLOBAL	•	D24

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

(0)	bReq_Transmissi on X50								PLS	bReqPulse_Tran smission M50
(3)	bReqPulse_Tran smission M50	C24_1.bSts _UnitReady X1E	C24_1.bSts_ WatchdogTi merError X1F					MOVP	K1	wTransmission Channel D21
							[	MOVP	KO	wCR_LF_Output Designation D22
							[	MOVP	K1	wTransmissionP ointer D23
								MOVP	K5	wOutputCount D24
								MOV	K4	wTransmission DataCount D0
							[	MOV	H1234	wnTransmission Data[0] D1
								MOV	H56AB	wnTransmission Data[1] D2
							BMOV	wTransmis sionDataC ount D0	C24_1.stnCH1.uSet_ TransmissionDataC ount_D U0¥G1024	K3
								MOV	H2	C24_1 wnForUs erRegistrationN o8001H_D[0] U0¥G6912
							[	MOV	H12D	C24_1.wnForUs erRegistrationN o8001H_D[1] U0¥G6913
								MOV	H3F2	wTransmissionP ointer1 D5
								MOV	H3F3	wTransmissionP ointer2 D6
								MOV	H8001	wTransmissionP ointer3 D7
								MOV	H8000	wTransmissionP ointer4 D8
								MOV	H41B	wTransmissionP ointer5 D9
							вмоу	wTransmis sionPointer 1 D5	C24_1.stnCH1.wnSe t_OutputFrameNum_ UserFrame_D U0¥G186	К5
									SET	bPRRInstructio nExecutionRequ estDevice M10
									RST	bPRRInstructio nExecutionCom pleteDevice M0
	l			 	 	i				l



(3) Set CR/LF to "Do not send". Set the send pointer to 1. Set the output quantity to 5. Set an arbitrary send data. Set an arbitrary send data in send area. Set the send user frame.
(101) Set normal completion flag.

(103) Set abnormal completion flag.

#### Normal end

D0	Transmission data count	(0004H)		Transmission data cou	unt (0004H)
D1	Too serie data	(3412H)		Transmission data	(3412H)
D2	- Transmission data	(AB56H)		- Transmission data	(AB56H)
D5	Transmission frame No.	(03F2H)		Transmission frame N	o. (03F2H)
D6		(03F3H)			(03F3H)
D7		(8001H)			(8001H)
D8		(8000H)			(8000H)
D9		(041BH)			(041BH)
D10		(0000H)			(0000H)
D11	Interface No.	(0001H)		Interface No.	(0001H)
D12	Transmission result	(0000H)		Transmission result	(other than 0000H)
D13	CR/LF output	(0000H)		CR/LF output	(0000H)
D14	Output head pointer	(0001H)		Output head pointer	(0001H)
D15	Output counter	(0005H)		Output counter	(0005H)

Abnormal end

# **16** TRANSPARENT CODES AND ADDITIONAL CODES

Transparent codes and additional codes are used during data communication with a target device to send/receive one-byte data for transmission control on the target device side as arbitrary data.

Transparent codes and additional codes are handled in data communication using the nonprocedural or bidirectional protocol.

Туре	Description
Transparent code	One-byte data for transmission control
Additional code	During transmission, one-byte data added immediately before the transparent code and additional code data
	During reception, one-byte data to be deleted (The immediately following one-byte data is processed for reception.)

## 16.1 Handling Transparent Code and Additional Code Data

The following explains how C24 handles transparent codes and additional codes during data communication using the nonprocedural or bidirectional protocol.

For the range of additional code data that is added or deleted, refer to the following sections.

Page 328 Handling Transparent and Additional Codes for Nonprocedural Protocol Data Communication

Page 339 Handling Transparent and Additional Codes for Bidirectional Protocol Data Communication

#### At the time of data transmission

Additional code data is added immediately before the transparent code and additional code data set for transmission.



#### At the time of data reception

When additional code data set for reception is detected, the additional code data is removed and the immediately succeeding 1-byte data is processed for reception.



#### During data communication using the ASCII-BIN conversion

When transmitting data, the transparent code check is performed to the data after ASCII-BIN conversion. If a transparent code is detected, an additional code is added to the 1-byte immediately preceding it.

When receiving data, the additional code check is performed to the data before ASCII-BIN conversion. If an additional code is detected, the additional code are deleted.

Data which will be subject for the handling of a transparent code and an additional code is data after ASCII-BIN conversion for data transmission and data before ASCII-BIN conversion for data reception.

#### Ex.

When transmitting/receiving data using an arbitrary format of the nonprocedural protocol

#### Target device



## 16.2 Registering Transparent Codes and Additional Codes

To control transparent codes and additional codes for data to be sent/received with the nonprocedural or bidirectional protocol, configuring the settings to C24 prior to data communication is required.

#### **Registration method**

For each interface, 10 combinations and one combination of transparent codes and additional codes can be set for transmission and reception, respectively.

Transparent codes and additional codes are set in "Transparent code designation\_Transparent code for sending specification (nth)", and "Transparent code designation\_Transparent code for receiving specification" of the parameter.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings"
⇒ "Various control specification"

When specifying a transparent code for sending, set it by left justifying from the transparent code for sending specification (1st) in order.

#### Precautions

If additional code data is received during data reception, C24 will not treat the immediately succeeding one-byte data as the control data for the following frame:

· Data received as the start frame and final frame of the user frames

Therefore, do not configure the following settings. (The code for the data described above cannot be designated as additional codes for data reception.)

- · A receive user frame setting that contains an additional code data for data reception
- · The same receive same code setting as the additional code data for data reception

## **16.3** Handling Transparent and Additional Codes for Nonprocedural Protocol Data Communication

This section explains how to handle the transparent codes and additional codes during data communication using the nonprocedural protocol.

#### Adding/deleting data

The data designated by the additional code is added to/deleted from the data to be transmitted or received.

#### Transmitted/received data range for processing

The range of transmitted/received data to which the processing of transparent codes and additional codes is performed is as shown below.



C24 performs the following processing during data transmission and reception.

#### ■At the time of data reception

When an additional code set for reception is detected, C24 removes the additional code data and perform data reception processing by treating the immediately succeeding 1-byte data as a part of the received data.

#### ■At the time of data transmission

When transparent code/additional code data set for transmission is detected, C24 transmits data by adding the additional code designation data immediately before it.

During data transmission using user frames, even if a transparent code or additional code has been specified in the transparent code for sending specification area, it is possible to transmit data without adding the additional code data to the user frame portion or arbitrary data portion.

When sending data without adding the additional code specified by the transparent code for sending specification, specify the user frame number using the following method.

• Specify the number obtained by adding 4000H to the registered user frame No.



When sending data in the portions designated in 4001H to 44AFH, C000H to C01FH, the data is transmitted without conversion even when the following designations are enabled.

- Designating "Enable" in the ASCII-BIN conversion designation area. (SP Page 348 ASCII-BIN Conversion for Data Communicated with Nonprocedural Protocol)
- Designating "Auto delete enabled" in the NULL character automatic removal designation area. ( Frage 408 NULL Character Removal to Send Data using Nonprocedural Protocol)

User frame No. to be sent	Specified No. when transmitting data without adding the additional code specified by the transparent code for sending specification (4000H added)
1H to 3E7H (1 to 999)	4001H to 43E7H (16385 to 17383)
3E8H to 4AFH (1000 to 1199)	43E8H to 44AFH (17384 to 17583)
8000H to 801FH (-32768 to -32737)	C000H to C01FH (-16384 to -16353)

#### Processing order for transmitting/receiving data

The processing steps taken by C24 to transmit/receive data by the transparent code designation and ASCII-BIN conversion enabled are as shown below.

#### ■Data reception in arbitrary format

- C24 deletes (removes) the additional code designation data when a transparent code for receiving is specified.
- C24 stores the arbitrary data portion in the receive area on the buffer memory.
- When ASCII-BIN conversion is designated, C24 converts it to binary code data and stores in the buffer memory.
- C24 issues a reception data read request to the CPU module when the receive end code data is stored or data equivalent to the receive end data quantity is stored during reception of an arbitrary data portion.

#### ■Data transmission in arbitrary format

C24 transmits the data to be sent (arbitrary data portion of a transmission message), which is designated by the CPU module.

When ASCII-BIN conversion is designated, C24 converts it to ASCII code data and transmits it.

- C24 adds the additional code data immediately before the transparent code/additional code data, and transmits it when a transparent code for sending is specified.
- C24 notifies the CPU module of the transmission normal (abnormal) completion once transmission for the send data quantity has been completed.



#### Ex. When ASCII-BIN conversion is performed



#### ■Data reception using user frames

- · C24 checks the reception of the user frame (start frame and final frame).
- C24 deletes (removes) the additional code designation data from an arbitrary data portion when a transparent code for receiving is specified.
- C24 calculates the sum check code when a sum check code is designated in a user frame (final frame).
- C24 stores the arbitrary data portion in the receive area on the buffer memory.
   When ASCII-BIN conversion is designated, C24 converts it to binary code data and stores in the buffer memory.
- C24 issues a reception data read request to the CPU module when the receive end code/data equivalent to the receive end data quantity is stored during reception of an arbitrary data portion, or when a user frame (final frame) is received.

#### Transmitting data using user frames

- C24 transmits data to be sent (an arbitrary data portion of a transmission message), which is designated by the user frame or CPU module, in the order specified by the user.
- When ASCII-BIN conversion is designated, C24 converts the data in the applicable range to ASCII code data and transmits it.

In addition, it adds the additional code data immediately before the transparent code/additional code data when transmitting the data in the applicable range, and transmits it when a transparent code for sending is specified.

• C24 notifies the CPU module of the transmission normal (abnormal) completion once transmission for the send data quantity has been completed.



The figure above shows how C24 processes the data to be sent/received when the data sending/receiving function using user frame, the ASCII-BIN conversion function, and/or the data send/receive function by transparent code designation are enabled and disabled.

Use this information as a reference to select the method to send/receive data for data communication with a target device.

### 16.4 Data Communication Using Nonprocedural Protocol

This section shows examples of data communication using the nonprocedural protocol when the settings/registrations are made with Engineering tool.

#### Parameter settings

For details for each setting item, refer to "Parameter". ( SP Page 422 PARAMETER SETTING)

Setting it	em				Setting content		
					CH1	CH2	
Basic	Various control	Test mode setting			—	CH2 is not used	
settings	specification	Communication speed setting	g	19200 bps			
		Communication protocol setti	ing	Nonprocedural protocol			
		Transmission setting	Operation setting		Set according to the		
			Data bit		target device		
			Parity bit				
			Odd/even parity				
			Stop bit				
			Sum check code				
			Online change E		Enable		
			Setting change		Enable		
		Station number setting (CH1,	2 in common: 0 to 31)		—		
		Transparent code	Transparent code for	Transparent code	02H (STX)		
		designation	sending specification (1st)	eration setting       Set according to the target device         ta bit       target device         ta bit       itraget device         target device       target device         tad	10H (DLE)		
			Transparent code for				
			sending specification (2nd)	Additional code	10H (DLE)		
			Transparent code for	ling specification     Additional code       )     sparent code for     Transparent code	02H (STX)		
			receiving	Additional code	10H (DLE)		
		Receiving end specification	Receive end data quan	tity designation	6		
			Receive end code desig	gnation	0D0A	]	

### Example of data reception

#### Program example

The following shows an example of storing received data in the data register.

Category	Label name D					Description				Device	
Module label	C24_1				Target module —				—		
	C24_1.stnCH1.bSet_Req_ReceptionRead				CH1 Reception data read request			X3			
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection					CH1 Reception abnormal detection				X4	
Label to be defined	Define the global label as shown below.										
	1 2 3 4 5 6 7 8 9	Label Name bINPUTInstructionNormalCompleteDevice bINPUTInstructionExecutionStatusDevice bINPUTInstructionExecutionDevice bINPUTInstructionNormalCompleteFlag bINPUTInstructionAbnormalCompleteFlag wReceiveChannel wReceiveDataCount wAllowableReceiveDataCount	Data Type Bit Bit Bit Bit Bit Word [Signed] Word [Signed]	···· ···· ···· ····	Class VAR_GLOB/ VAR_GLOB/ VAR_GLOB/ VAR_GLOB/ VAR_GLOB/ VAR_GLOB/ VAR_GLOB/ VAR_GLOB/	s AL AL AL AL AL AL AL AL	4 4 4 4 4 4 4 4 4	Assign (Device/Label) M0 M1 M1 M10 M10 M100 M101 D1 D2 D3			
	10 11	wErrorCode wReceiveData	Word [Signed] Word [Signed]		VAR_GLOBA	AL AL	* *	D4 D10			

For information on the module FB to be used, refer to the following manual. MELSEC iQ-R Serial Communication Module Function Block Reference

(0)	C24_1.stnCH1.bSet_Req_ ReceptionRead				MOVP	K1	wReceiveChannel D1
	C24_1.stnCH1.bSts_Rece ptionAbnormalDetection 4				MOVP	K6	wAllowableReceiveDat aCount D3
						SET	bReq_INPUTInstructio nExecutionDevice M10
(9)			M_RJ71C24_Input_00C_1 (M+RJ71C24_Input_00C) Input FB				
	bReg_INPUTInstructionEx ecutionDevice M10 I		Bijjen ojeno:B				bINPUTInstructionExe cutionStatusDevice M2
		C24_1	DUT:jstModule o_bOKB				bINPUTInstructionNor malCompleteDevice M0
		wReceiveChannel [ D1 ]	UWiuCh օ,bErr։B				bINPUTInstructionAbn ormalCompleteDevice M1
		wAllowableReceive DataCount [ D3 ]	UWiuMaxRecvDataLength ويErrld:UW	wErrorCode -{ D4 }			
			o_uRecvDataLength:UW	wReceiveData Count -[ D2 ]			
			o_uRecvData:UW	wReceiveData -{ D10 }			
(55)	bINPUTInstructionNormal CompleteDevice MO					SET	bINPUTInstructionNor malCompleteFlag M100
(57)	bINPUTInstructionAbnor malCompleteDevice					SET	bINPUTInstructionAbn ormalCompleteFlag M101
(59)							{END }

(0) Set the reception channel to the CH1 side. Set the allowable number of data to be received. Set the reception direction.

(55) Normal completion

(57) Abnormal completion

#### Reception example based on the receive end data quantity

When C24 receives data from the target device when the transparent code designation is enabled

#### Ex.

Transparent code designation: Additional code: 10H (DLE), Transparent code: 02H (STX), Receive end data quantity designation: 6-word or 12-word



When the transparent code for receiving specification is enabled, the codes for receivable data and the codes for the received data which is stored is stored in the receive area on the buffer memory are as shown below.

Туре		Receivable codes	Codes stored in the receive area	
Transparent code for receiving	Additional code	01H to FFH	(Delete)	
specification portion	Transparent code	00H to FFH	00H to FFH	
Arbitrary data portion (including end co	ide)			

#### Operation example of reception by the receive end code

When C24 receives data from the target device when the transparent code designation is enabled



When the transparent code for receiving specification is enabled, the codes for receivable data and the codes for the received data which is stored in the receive area on the buffer memory are as shown below.

Туре		Receivable codes	Codes stored in the receive area	
Transparent code for receiving	Additional code	01H to FFH	(Delete)	
specification portion	Transparent code	00H to FFH	00H to FFH	
Arbitrary data portion (including end co	ode)			

#### Example of data transmission

The following shows an example of data transmission.

#### Transmission by transparent code for sending specification, 1st

Ex.

Transparent code designation: Additional code: 10H (DLE), Transparent code: 02H (STX)



#### ■Program example

When C24 transmits data to the target device by transparent code designation (1st combination of the transparent code for sending specification is set)

Category	Label name				De	scr	iption	Device	
Module label	C24_1				Tar	geti	module	—	
Label to be defined	Defin	e the global label as shown below.							
		Label Name	Data Type		Class		Assign (Device/Label)		
	1	bReq_Transmission	Bit		VAR_GLOBAL	-	×50		
	2	b0UTPUTInstructionNormalCompleteDevice	Bit		VAR_GLOBAL	. 🔻	MO		
	3	bOUTPUTInstructionAbnormalCompleteDevice	Bit		VAR_GLOBAL	•	M1		
	4	bOUTPUTInstructionExecutionStatusDevice	Bit		VAR_GLOBAL	-	M2		
	5	bReq_OUTPUTInstructionExecutionDevice	Bit		VAR_GLOBAL	. 🔻	M10		
	6	bOUTPUTInstructionNormalCompleteFlag	Bit		VAR_GLOBAL	•	M100		
	7	bOUTPUTInstructionAbnormalCompleteFlag	Bit		VAR_GLOBAL	-	M101		
	8	wTransmissionChannel	Word [Signed]		VAR_GLOBAL	. 🔻	D1		
	9	wErrorCode	Word [Signed]		VAR_GLOBAL	•	D2		
	10	wAllowableTransmissionDataCount	Word [Signed]		VAR_GLOBAL	•	D3		
	11	wnTransmissionData	Word [Signed](05)		VAR_GLOBAL		D10		

For information on the module FB to be used, refer to the following manual.

1	h Dan Tananaianian							
	X50					DMOVP	H33323130	wnTransmissionData[0]
Ή		 	<u>.</u>	<u>.</u>				D10
						DMOV/D	H42410002	wnTransmissionData[2]
	-	 				DMOVP		D12
		 	ļ		·····			
							H0A0D1234	wnTransmissionData[4]
		 				DMOVP		D14
							К1	wTransmissionChannel
						MOVP		D1
							K6	wAllowableTransmissionD
						MOVP		ataCount D3
								bReg OUTPUTInstruction
							SET	ExecutionDevice M10
								inite
			M_RJ71C24_Output_00C_1	(M+RJ71C24_Output_00C)				
"			004	Jul PD				
Ь	Req_OUTPUTInstructio							bOUTPUTInstructionExec
	nExecutionDevice M10							utionStatusDevice M2
+	I I	 	B:i_bEN	o_bENO:B				
		 				1		bOUTPUTInstructionNorm
		024.1						alCompleteDevice M0
+		 -( <sup>~</sup> )	DUT:i_stModule	o_bOK:B			_	0
								bOUTPUTInstructionAbno
		wTransmissionChan						rmalCompleteDevice M1
+		{ D1 }	- UW:i_uCh	o_bErr:B				——————————————————————————————————————
		wAllowableTransmis			wErrorCo			
F		 sionDataCount —-[ D3 ]	UW:i_uSendDataLength	o_uErrId:UW	de -{ D2 }			
		wnTransmissionDat						
L		 D10 ]	- UW:i_uSendData					
	011T011T1	 						
D	malCompleteDevice							bOUTPUTInstructionNorm
<sup>5)</sup>	MU	 					SET	alCompleteFlag M100
1	OUTPUTInstructionAb normalCompleteDevice							bOUTPUTInstructionAbno
n	M1	 					SET	rmalCompleteFlag M101
0								
								[END ]
n n n	OUTPUTInstructionAb normalCompleteDevice I							SET

Set the send data quantity to 6. Execute transmission

(65) Normal completion

(67) Abnormal completion

#### Transmission by 1st/2nd combinations of transparent code for sending specification

#### Ex.

Transparent code designation (1st): Additional code: 10H (DLE),Transparent code: 02H (STX) Transparent code designation (2nd): Additional code: 10H (DLE),Transparent code: 03H (ETX)



#### ■Program example

When C24 transmits data to the target device by transparent code designation (2nd combination of transparent code for sending specification is set.)

Category	Labe	el name			De	sc	ription		Device	
Module label	C24_	1	Target module —							
Label to be defined	Defin	e the global label as shown below.								
		Label Name	Data Type	Clas	ss		Assign (Device/Label)			
	1	bReq_Transmission	Bit	 VAR_GLOB	BAL	-	X50			
	2	bOUTPUTInstructionNormalCompleteDevice	Bit	 VAR_GLOB	BAL	-	MO			
	3	bOUTPUTInstructionAbnormalCompleteDevice	Bit	 VAR_GLOB	BAL	-	M1			
	4	bOUTPUTInstructionExecutionStatusDevice	Bit	 VAR_GLOB	BAL	-	M2			
	5	bReq_OUTPUTInstructionExecutionDevice	Bit	 VAR_GLOB	BAL	-	M10			
	6	bOUTPUTInstructionNormalCompleteFlag	Bit	 VAR_GLOB	BAL	-	M100			
	7	bOUTPUTInstructionAbnormalCompleteFlag	Bit	 VAR_GLOB	BAL	-	M101			
	8	wTransmissionChannel	Word [Signed]	 VAR_GLOB	BAL	-	D1			
	9	wErrorCode	Word [Signed]	 VAR_GLOB	BAL	-	D2			
	10	wAllowableTransmissionDataCount	Word [Signed]	 VAR_GLOB	3AL	-	D3			
	11	wnTransmissionData	Word [Signed](05)	 VAR_GLOB	3AL	•	D10			

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	bReq_Transmission					H33323130	wnTransmissionData[0]
(0)	X50				DMOVP		D10
	11						
						H42410002	wnTransmissionData[2]
					DMOVP		D12
							-
						H0A0D0003	wnTransmissionData[4]
					DMOVP		D14
							-
						K1	wTransmissionChannel
					MOVP		D1
							1
						K6	wAllowableTransmissionD
					MOVP		taCount D3
							bReq_OUTPUTInstruction
						SET	ExecutionDevice M10
(20)			M_RJ/1G24_Output_00C_1 (M+RJ/1G24_Output Output FB	t_00C)			
(==)							
	bReq_OUTPUTInstructi						bOUTPUTInstructionExe utionStatusDevice
	M10						M2
	1		- BILDEN	O_DENU:B			0
							bOUTPUTInstructionNorr alCompleteDevice
		C24_1		LOKA			MO
		L		0_DUK:B			0
		wTransmissionChann					bOUTPUTInstructionAbn rmalCompleteDevice
		el		. h C D			M1
			- owi <u>-</u> don	0_0011.0			0
		wAllowableTransmiss		wErrorCo			
		onDataCount	LIW: uSandDataLanath				
		L					
		wnTransmissionData	ך LW iuSendData				
	rmalCompleteDevice						bOUTPUTInstructionNor
(65)	MU					SET	alCompleteFlag M100
	hOUTPUTInatrusti Ah						•
	normalCompleteDevice						bOUTPUTInstructionAbn
(67)						SET	rmalCompleteFlag M101
(00)							
(69)					_		{END }
(0)	Set the data	to be transmitted in D10 to D15.					

Set the transmission channel to the CH1 side. Set the send data quantity to 6. Set the transmission direction.

(65) Normal completion

(67) Abnormal completion

## **16.5** Handling Transparent and Additional Codes for Bidirectional Protocol Data Communication

This section explains how to handle the transparent codes and additional codes during data communication using the bidirectional protocol.

#### Adding/deleting additional code designation code

The data designated by the additional code is added to/deleted from the data to be transmitted or received.

#### Data range of transmit/receive processing

The range of transmitted/received data to which processing to transmit/receive transparent codes and additional codes is performed includes data length, data portion, and error code of a message.

Head code (ENQ, ACK, NAK) and sum check code of each message are not included.

Ex.									
								*	
Transmission sequen	се					ı		<u>← →</u>	•
Target device					ACK	(When normal)	N A K	Error code	(When abnormal)
CPU module	ЕNQ	Data length L H	Data section (Designated transmission data)	Sum check code L H		• Applicable	data	a range	
		-	*	•					

C24 performs the following processing during data transmission/reception.

#### ■At the time of request data reception

When an additional code set for reception is detected, C24 removes the additional code data and perform data reception processing by treating the immediately succeeding 1-byte data as a part f the received data during the reception of a request data.

#### ■At the time of response message transmission

When transparent code/additional code data set for transmission is detected, C24 transmits data by adding the additional code designation data immediately before it during the transmission of the response message to data reception.

#### ■At the time of request data transmission

When transparent code/additional code data set for transmission is detected, C24 transmits data by adding the additional code designation data immediately before it during data transmission.

#### ■At the time of response message reception

When an additional code set for reception is detected, C24 removes the additional code data and perform data reception processing by treating the immediately succeeding 1-byte data as a part of the received data during the reception of the response message to data transmission.

#### Precautions

The additional code data to be added/deleted is not included in the data length, nor will it be subject for sum check code. Example of request data transmission when ASCII-BIN conversion is disabled



#### Processing order for transmitting/receiving data

#### ■At the time of reception

- C24 deletes (removes) the additional code designation data from an arbitrary data portion when a transparent code for receiving is specified.
- · C24 stores the arbitrary data portion in the receive area on the buffer memory.

When ASCII-BIN conversion is designated, C24 converts it to binary code data and stores in the buffer memory.

• When the data portion for the designated data length is received, reading the received data is requested of the CPU module.

If the sum check code is set to 'Yes' in the transmission setting via an Engineering tool parameter settings, reading the received data is requested of the CPU module upon reception of the sum check code.



#### ■At the time of transmission

• C24 adds the transmission control code to the data to be sent (arbitrary data portion of a transmission message), which is designated by the CPU module, and transmits it.

When ASCII-BIN conversion is designated, C24 converts it to ASCII code data at first and transmits it.

- When the sum check code is set to be enabled, C24 calculates the sum check code from the transmission message and add it to the transmission message.
- C24 adds the additional code data immediately before the transparent code/additional code data in respect to arbitrary data portion, and transmits it when a transparent code for sending is specified.



The figure above shows how C24 processes the data to be transmitted/received when the ASCII-BIN conversion function, and/or the data communication function by transparent code designation are enabled and disabled.

Use this information as a reference to select the method to send/receive data for data communication with a target device.

#### Ex.

The following example shows the data array when data is transmitted and received. (The transmission/reception portion of the response message is omitted.)

When ASCII-BIN conversion is not performed

30H 32H 30H 30H 31H 32H 30H 32H 33H 10H 41H 42H

051



43F 80H 02F

(For 41H)

(For 10H)

Transpare nt code

Additional

code

(The data count is in word units)

## **16.6** Data Communication Using Bidirectional Protocol

This section shows examples of data communication using the bidirectional protocol when the settings/registrations are made with Engineering tool.

#### Parameter settings

For details for each setting item, refer to "Parameter". (SP Page 422 PARAMETER SETTING)

Setting it	em			Setting content		
				CH1	CH2	
Basic	Various control	Test mode setting		—	CH2 is not used	
settings	specification	Communication protocol setting		Bidirectional protocol		
		Communication speed setting		19200 bps		
		Transmission setting	Operation setting	Set according to the		
			Data bit	target device		
			Parity bit			
			Odd/even parity			
			Stop bit			
			Sum check code			
			Online change	Enable		
			Setting change	Enable		
		Station number setting (CH1, 2 in common: 0 to 31)		—		
		Transparent code designation_Transparent code	Transparent code	02H (STX)		
		for sending specification (1st)	Additional code	10H (DLE)		
		Transparent code designation_Transparent code	Transparent code	03H (ETX)		
		for sending specification (2nd)	Additional code	10H (DLE)		
		Transparent code designation_Transparent code	Transparent code	02H (STX)	-	
		for receiving specification	Additional code	10H (DLE)		

#### Example of data reception

The following example shows when receiving binary data including a transparent code from a target device.

#### Transparent code for receiving specification is enabled



Transparent code designation: Additional code: 10H (DLE), Transparent code: 02H (STX)



#### ■Program example

Category	Labe	l name	Desc	cri	ption	Device				
Module label	C24_	1	Targe	t n	nodule		—			
	C24_	1.stnCH1.bSet_Req_ReceptionRead		CH1 I	Re	ception data read r	X3			
Label to be defined	Define	e the global label as shown below.								
		Label Name	Data Tupe		Cla			Assign (Device /Label)		
	1	bBIDINPUTInstructionNormalCompleteDevice	Bit	İ	VAR GLO	)BAL	•	MO		
	2	bBIDINPUTInstructionAbnormalCompleteDevice	Bit		VAR_GLO	)BAL	-	M1		
	3	bBIDINPUTInstructionExecutionStatusDevice	Bit		VAR_GL0	DBAL	-	M2		
	4	bBIDINPUTInstructionNormalCompleteFlag	Bit		VAR_GL0	)BAL	-	M100		
	5	bBIDINPUTInstructionAbnormalCompleteFlag	Bit		VAR_GLO	)BAL	-	M101		
	6	wReceiveChannel	Word [Signed]		VAR_GLO	)BAL	-	D1		
	7	wAllowableReceiveDataCount	Word [Signed]		VAR_GLO	)BAL	-	D2		
	8	wReceiveDataCount	Word [Signed]		VAR_GLO	DBAL	-	D3		
	9	wReceiveData	Word [Signed]		VAR_GLO	DBAL	-	D10		
	10 wErrorCode Word [Signed] VAR_I						-	D20		

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	C24_1.stnCH1.bSet_Req_ ReceptionRead						K1	wReceiveChanne
(0)	Î					MOVP		D1
							K6	wAllowableReceiveD
						MOVP		ount D2
							RST	bBIDINPUTInstruct rmalCompleteDev M0
8)			M_RJ71C24_BidirectionalInput_00C_1 Bidirectiona	(M+RJ71C24_BidirectionalInpu t_00C) al Input FB				
	C24_1.stnCH1.bSet_Req_ ReceptionRead X3							bBIDINPUTInstruct ecutionStatusDe M2
			BILDEN	o_bENO:B				0
		(C24_1	DUT: <u>i.</u> stModule	o_bOK:B				rmalCompleteDe M0
		wReceiveChannel						bBIDINPUTInstruc normalCompleteD M1
ł			UW:i_uCh	o_bErr:B				
-		wAllowableReceiv eDataCount {D2 ]-	·UW: <u>iu</u> MaxRecvDataLength	o_uErrId:UW	wErrorCode { D20 }			
				o_uRecvDataLength:UW	wReceiveDa taCount -[ D3 ]-—			
-								
				o_uRecvData:UW	wReceiveDa ta -{ D10 }			
	bBIDINPUTInstructionNor							
1)	malCompleteDevice M0 I						SET	bBIDINPUTInstruc ecutionStatusDe M2
3)	bBIDINPUTInstructionAb normalCompleteDevice M1						SET	bBIDINPUTInstruc rmalCompleteF M100
	1.1							
0								(END )-
	Set the recention channel to	CH1						

 specification portion
 Transparent code
 00H to FFH
 00H to FFH

 Data length, data portion
 00H to FFH
 00H to FFH
 00H to FFH

for the received data which is stored in the receive area on the buffer memory are as shown below.

Additional code

When the data length unit is in bytes and the data length is an odd byte, 00H is stored in the upper byte of the last data storage position in the receive area.

When the transparent code for receiving specification is enabled, the codes for receivable arbitrary data portion and the codes

**Receivable codes** 

01H to FFH

Codes stored in the receive

area

(Delete)

Set the reception direction.

Execute reception

Normal completion Abnormal completion

Transparent code for receiving

(8)

(54)

(56)

Туре

#### Example of data transmission

The following example shows when transmitting binary data including a transparent code to a target device.

#### Transparent code for sending specification is enabled

#### Ex.

Transparent code designation (1st): Additional code: 10H (DLE), Transparent code: 02H (STX) Transparent code designation (2nd): Additional code: 10H (DLE), transparent code: 03H (ETX)



#### ■Program example

Category	Label name		Desc	ription	Device	
Module label	C24_1		Target	module	—	
Label to be defined	Define the global label as shown below.					
	Label Name bBIDOUTPUTInstructionNormalCompleteDevice bBIDOUTPUTInstructionAbnormalCompleteDevice bBIDOUTPUTInstructionStatusDevice bBIDOUTPUTInstructionStatusDevice bBIDOUTPUTInstructionCompleteFlag bBIDOUTPUTInstructionAcompleteFlag bBIDOUTPUTINstructionAcompl	Data Type	C VAR_GLI VAR_GLI VAR_GLI VAR_GLI VAR_GLI VAR_GLI	ass DBAL V DBAL V DBAL V DBAL V DBAL V	Assign (Device/Label) M0 M1 M2 M10 M100 M100 M101	
	0         Extreme to introduce input of algorithm and any processing of algorithm and any processing of algorithm and any processing of algorithm and algorithm angorithm and algorithm and algori	Word [Signed]	VAR_GLI VAR_GLI VAR_GLI VAR_GLI VAR_GLI	DBAL - DBAL - DBAL - DBAL - DBAL - DBAL -	D1 D3 D100 D10 X50	

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	bReq_Transmission						K1	wTransmissionChannel
(0)	X50					MOVP		D1
						MOVP	К4	wTransmissionDataCount D3
						MOVP	H1102	wnTransmissionData[0] D10
						MOVP	H4241	wnTransmissionData[1] D11
						MOVP	H3	wnTransmissionData[2] D12
						MOVP	H0A0D	wnTransmissionData[3] D13
							SET	bReq_BIDOUTPUTInstructi onExecutionDevice M10
			M BJ71C24 BidirectionalOutput 00C 1	(M+RJ71C24 BidirectionalOutput 00C)				
(20)			Bidirectional	Output FB				
	bReg_BIDOUTPUTInstruc tionExecutionDevice M10							bBIDOUTPUTInstructionEx ecutionStatusDevice M2
			B:j_bEN	o_bENO:B				
		C24_1	DUT:i stModule	a bOK-B				bBIDOUTPUTInstructionN ormalCompleteDevice M0
		L J	born_stability	0_00110				
		wTransmission Channel D1 -	11WiuCh	o hErr B				bBIDOUTPUTInstructionA bnormalCompleteDevice M1
		L 9, J	0112001	0,00000				U
		wTransmission DataCount [ D3 ]-	UW:i_uSendDataLength	o_uErrld:UW	wErrorCo de { D100 }			
		wnTransmission Data [ D10 ]-	UW:i_uSendData					
	bBIDOUTPUTInstructionN		i					
(65)	ormalCompleteDevice M0						SET	bBIDOUTPUTInstructionN ormalCompleteFlag M100
	bBIDOUTPUTInstructionA							
(67)	bnormalCompleteDevice M1						SET	bBIDOUTPUTInstructionA bnormalCompleteFlag M101
(69)								{END }
	1							

Set the transmission channel to CH1.
 Set the send data quantity to 4.
 Set the data to be transmitted in D10 to D13.
 Set the transmission direction.

(20) Execute transmission.

(65) Normal completion

(67) Abnormal completion

## **17** COMMUNICATING WITH ASCII CODE (ASCII-BIN CONVERSION)

This chapter explains the ASCII-binary conversion in order to transmit/receive data in ASCII code to/from a target device.

### **17.1** ASCII-Binary Conversion

ASCII-BIN conversion is the data conversion function that converts all data communicated between C24 and a target device to ASCII code data.

The ASCII-BIN conversion of data to be sent/received is performed by C24 according to the parameter settings.



### **17.2** Settings for ASCII-BIN Conversion

In order to convert data to be sent/received with the nonprocedural protocol and bidirectional protocol from binary code to ASCII code, it is necessary to configure the setting for C24 before performing data communication.

The settings for ASCII-BIN conversion are as shown below:

- The ASCII-BIN conversion settings can be configured for each interface.
- To enable ASCII-BIN conversion, set "ASCII-BIN conversion designation" to "ON".
- Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings" ⇔ "Various control specification"

## **17.3** ASCII-BIN Conversion for Data Communicated with Nonprocedural Protocol

This section explains the ASCII-BIN conversion of data to be communicated using the nonprocedural protocol.

#### Data range of transmit/receive processing

The range of data to be sent/received to which ASCII-BIN conversion is performed is as shown below:



C24 performs the following processing when sending or receiving data.

#### ■At the time of data reception

- C24 receives data of which data code is in the range of 30H to 39H ('0' to '9') and 41H to 46H ('A' to 'F') as the data within the above conversion applicable range.
- C24 regards given data portion as ASCII code, and converts it to binary code to store in the buffer memory.
- The user frame portion is received in the data format corresponding to the registration to C24.

#### ■At the time of data transmission

- C24 transmits data of which data code is in the range of 30H to 39H ('0' to '9') and 41H to 46H ('A' to 'F') as the data within the above conversion applicable range.
- C24 regards data designated by the CPU module (given data portion in a transmission message) and user frame portions
  as binary code data, and converts to ASCII code to transmit them.



At the time of data transmission with the user frame, it is possible to transmit data without converting the data in any user frame portion or send area on the buffer memory even if "Convert" is designated in the ASCII-BIN conversion designation area.

When sending data without ASCII-BIN conversion, specify the user frame number by the method shown below.

• Specify the number obtained by adding 4000H to the registered user frame No.



When sending data in the portions designated in 4001H to 44AFH, C000H to C01FH, the data is transmitted without conversion even when the following designations are enabled.

- Specifying an additional code by the transparent code for sending specification ( Page 326 TRANSPARENT CODES AND ADDITIONAL CODES)
- Designating "Auto delete enabled" in the NULL character automatic removal designation area ( Page 408 NULL Character Removal to Send Data using Nonprocedural Protocol)

User frame No. to be sent	Designated No. for the user frame when transmitting without ASCII-BIN conversion (4000H added)
1H to 3E7H (1 to 999)	4001H to 43E7H (16385 to 17383)
3E8H to 4AFH (1000 to 1199)	43E8H to 44AFH (17384 to 17583)
8000H to 801FH (-32768 to -32737)	C000H to C01FH (-16384 to -16353)

#### Processing order for data transmission/reception

The processing steps taken by C24 to transmit/receive data with ASCII-BIN conversion and transparent code designation enabled are explained in the section for transparent codes and additional codes. (EP Page 328 Handling Transparent and Additional Codes for Nonprocedural Protocol Data Communication)

- · Data transmission/reception in arbitrary formats
- · Data transmission/reception using user frames

### 17.4 Data Communication Using Nonprocedural Protocol

This section shows examples of data communication using the nonprocedural protocol when the settings/registrations are made with Engineering tool.

#### Parameter settings

For details for each setting item, refer to the parameters. (SP Page 422 PARAMETER SETTING)

Setting item				Setting content		Remarks
				CH1	CH2	
Basic	Various control	Test mode setting	l	—	CH2 is not used	—
settings	specification	Communication p	rotocol setting	Nonprocedural protocol		
		Communication s	peed setting	Set according to the target device		
		Transmission	Operation setting	Independent		
		setting	Data bit	Set according to the	-	
			Parity bit	target device		
			Odd/even parity			
			Stop bit			
			Sum check code			
			Online change			
			Setting change	hange hange 1, 2 in common: 0 to 31) —		
	S		Station number setting (CH1, 2 in common: 0 to 31)			
		Conversion designation	ASCII-BIN conversion designation	ON		
		Receiving end specification	Receive end data quantity designation	3		
			Receive end code designation	0009H		
Application settings	User frame specification	User frame specification for	User frame use enable/disable designation	Use		Arbitrary registered data
		receiving	Start frame No. designation (1st)	03E8H		
			Start frame No. designation (2nd)	03E9H		
			Final frame No. designation (1st)	041BH		
			Final frame No. designation (2nd)	041BH		
		Send user	Output start pointer designation	0001H		1st
		frame	Output quantity designation	0005H		5th
		designation	Send frame number designation (1st)	43F2H		Arbitrary registered data
			Send frame number designation (2nd)	43F3H		
			Send frame number designation (3rd)	C001H		
			Send frame number designation (4th)	8000H	]	Buffer memory designation
			Send frame number designation (5th)	441BH	]	Arbitrary registered data

#### Program example

The following shows an example of data reception.

Category	Labe	I name		Descrip	tio	n	Device
Module label	C24_	1		Target mo	odu	le	-
	C24_	1.stnCH1.bSet_Req_ReceptionRead		CH1 Rec	ept	ion data read request	X3
	C24_	1.stnCH1.bSts_ReceptionAbnormalDe	etection	CH1 Rec	ept	ion abnormal detection	X4
Label to be defined	Define	e the global label as shown below.					
		Label Name	Data Tune	Class		Assign (Device /Label)	
	Label Name           1         wReceiveChannel         Wo           2         wAllowableReceiveDataCount         Wo		Word [Signed]	 VAR GLOBAL	-	D1	
	Label Name           1         wReceiveChannel         Wo           2         wAllowableReceiveDataCount         Wo		Word [Signed]	 VAR_GLOBAL	-	D3	
	3	wErrorCode	Word [Signed]	 VAR_GLOBAL	•	D100	
	4	bReq_INPUTInstructionReceive	Bit	 VAR_GLOBAL	Ŧ	M10	
	5	bINPUTInstructionReceiveExecution	Bit	 VAR_GLOBAL	•	MO	
	6	bINPUTInstructionReceiveNormalCompletion	Bit	 VAR_GLOBAL	•	M1	
	7	bINPUTInstructionReceiveAbnormalCompletion	Bit	 VAR_GLOBAL	•	M2	
	8	bNormalCompleteFlag	Bit	 VAR_GLOBAL	Ŧ	M100	
	9	bAbnormalCompleteFlag	Bit	 VAR_GLOBAL	Ŧ	M101	
	10	wReceiveDataCount	Word [Signed]	 VAR_GLOBAL	•	D2	

VAR\_GLOBAL - D10

Word [Signed] Word [Signed](0..15)

For information on the module FB to be used, refer to the following manual.

11 wnReceiveData

#### MELSEC iQ-R Serial Communication Module Function Block Reference

(0)	C24_1.stnCH1 bSet Req_Re ceptionRead X3				моу	K1	wReceiveChannel D1
	C24_1.stnCH1.bSts_Recepti onAbnormalDetection X4				моу	K6	wAllowableReceiveDataC ount D3
						SET	bReq_INPUTInstructionR eceive M10
(7)			M_RJ71C24_Input_00C_1 (M+RJ71C24_Input_00C) Input FB				
	bRegINPUTInstructionRec eive M10		Bijden ojdeno:B				bINPUTInstructionReceiv eExecution M0
		C24_1	DUT:LstModule o.bOK:B				bINPUTInstructionReceiv eNormalCompletion M1
		wReceiveChannel	- UWiuCh ๑.bErr:B				bINPUTInstructionReceiv eAbnormalCompletion M2
		wAllowableReceive DataCount [ D3 ]	ู UW:i_uMaxRecvDataLength o_uErrld:UW	wErrorCod - D100 -			
			o_uRecvDataLength:UW	wReceiveD ataCount -[ D2 ]			
			o_uRecvData:UW	wnReceive Data -[ D10 ]			
(53)	bINPUTInstructionReceive NormalCompletion MI					SET	bNormalCompleteFlag M100
(55)	bINPUTInstructionReceive AbnormalCompletion M2					SET	bAbnormalCompleteFlag M101
(57)							(END )

(0) Set the reception channel to CH1. Set the allowable number of data to be received to 6. Set the reception direction.

Execute reception. (7)

(53) Normal completion

(55) Abnormal completion

#### Operation example of reception by the receive end code

When C24 receives data from the target device when ASCII-BIN conversion is enabled (Reception by the receive end code)



When ASCII-BIN conversion is enabled, the codes for the receivable data and the codes for the received data which is stored in the receive area on the buffer memory are as shown below.

Туре	Receivable codes	Codes stored in the receive area		
Arbitrary data portion (including end code)	30H to 39H, 41H to 46H	0H to 9H, AH to FH		

If data codes other than 30H to 39H and 41H to 46H are received for an arbitrary data portion, an error (7F20H) occurs after ASCII-BIN conversion processing by C24.

To perform ASCII-BIN conversion, ensure the end code is the code after conversion.

#### Operation example of reception based on the receive end data quantity

#### Ex.

When C24 receives data from the target device when ASCII-BIN conversion is enabled (Reception based on the receive end data quantity)



When the transparent code for receiving specification is disabled and ASCII-BIN conversion is enabled, the codes for the receivable data and the codes for the received data which is stored in the receive area on the buffer memory are as shown below.

Туре	Receivable codes	Codes stored in the receive area
Arbitrary data portion (including end code)	30H to 39H, 41H to 46H	0H to 9H, AH to FH

If data codes other than 30H to 39H and 41H to 46H are received for an arbitrary data portion, an error (7F20H) occurs after ASCII-BIN conversion by C24.

#### Ex.

When C24 receives data from the target device when ASCII-BIN conversion is enabled (Reception using user frames)



#### Example of data transmission

The following shows an example of data transmission.

#### Transmission of arbitrary data

When C24 transmits data to the target device with ASCII-BIN conversion used (Transmitting given data with OUTPUT dedicated instruction)



#### ■Program example

Category	Labe	el name		Descrip	otio	on	Device	
Module label	C24_	1		Target m	odı	ule	—	
Label to be defined	Defin	e the global label as shown below.						
		Label Name	Data Type		Class		Assign (Device/Label)	
	1	bReq_Transmission	Bit		VAR_GLOBAL	•	X50	
	2	wTransmissionChannel	Word [Signed]		VAR_GLOBAL	•	D1	
	3	wTransmissionDataCount	Word [Signed]		VAR_GLOBAL	•	D2	
	4	wErrorCode	Word [Signed]		VAR_GLOBAL	•	D20	
	5	bReq_OUTPUTInstructionTransmission	Bit		VAR_GLOBAL	•	M10	
	6	bOUTPUTInstructionTransmissionExecution	Bit		VAR_GLOBAL	•	MO	
	7	bOUTPUTInstructionTransmissionNormalCompletion	Bit		VAR_GLOBAL	-	M1	
	8	bOUTPUTInstructionTransmissionAbnormalCompletion	Bit		VAR_GLOBAL	-	M2	
	9	wnTransmissionData	Word [Signed](01)		VAR_GLOBAL	-	D10	
	10	bNormalCompleteFlag	Bit		VAR_GLOBAL	•	M100	
	11	bAbnormalCompleteFlag	Bit		VAR_GLOBAL	•	M101	

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

(0)	bReq_Transmission X50					NOV	K1	wTransmissionChanne
(0)								D1
							K3	T
						MOV	N2	w I ransmissionDataCol
						_		
							H1234	wnTransmissionData
						MOV		D10
							H56AB	wnTransmissionData
		 				MOV		D11
								bReq_OUTPUTInstruction
						_	SET	nsmission M10
			M_RJ71C24_Output_00C_1	(M+RJ71C24_Output_00C)				
10)			Outp	ut FB				
	bReq_OUTPUTInstructionTran	 						bOUTPUTInstructionTra
	smission M10							ssionExecution M0
		 	– BilbEN	o_bENO:B				O
		 						bOUTPUTInstructionTr
		C24_1						ssionNormalCompleti M1
		 	} DUT:i_stModule	o_bOK:B			-	0
								bOUTPUTInstructionTra
		annel						M2
		L D1 _	} UW:i_uCh	o_bErr:B				0
1		wTransmissionDat			wErrorCo			
		aCount						
			F OW.I_USendDataLength	0_dEnta.ow	1 020 ]			
		wnTransmissionD						
1		 ata 	₩UW:iuSendData					
				-				
	sionNormalCompletion							bNormalCompleteFla
55)							SET	M100
	hOUTPUTInetructionTranemie	 						
	sionAbnormalCompletion M2						OFT	bAbnormalCompleteF
o/) -					<u> </u>		SET	M101
(59)								
-								(END )
ŝ.		 	.å	ž	.3		.5	5

Set the transmission direction.

(10) Execute transmission.

(55) Normal completion

(57) Abnormal completion

#### Transmission using user frame

When C24 transmits data to the target device with ASCII-BIN conversion used (Transmitting given data and user frame combined with PRR dedicated instruction)



#### ■Program example

Category	Label name	e Description Device				
Module label	C24_1		Target module	-		
	C24_1.stnCH1.wnSet_TransmissionDa	ta_D[0]	CH1_Send data specification	U0\G1025		
	C24_1.wnForUserRegistrationNo8001H	H_D[0]	For user registration number 8001H [0]	U0\G6912		
	C24_1.wnForUserRegistrationNo8001H	H_D[1]	For user registration number 8001H [1]	U0\G6913		
Label to be defined	Define the global label as shown below			·		
	Label Name Label Name BReq_Transmission WTransmissionChannel WCR_LF_OutputDesignation WTransmissionPointer WUtputCount WErorCode UserFlameTransmissionNormalCompletion UserFlameTransmissionExecution UserFlameTransmissionEata DWnTransmissionEata DNormalCompleteFlag DAbnormalCompleteFlag DabLongTaneTransmission	Data Type         C           Bit	Itass         Assign (Device/Label)           .0BAL         × X50           .0BAL         > D1           .0BAL         > D2           .0BAL         > M0           .0BAL         > M1           .0BAL         > M10           .0BAL         > M100           .0BAL         > M101			
	13 bReq_UserFlameTransmission	Bit VAR_GL	OBAL 🚽 M10			

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

(0)	bReq_Transmission X50							MOVP	К1	wTransmissionChannel D1
		 						MOVP	КО	wCR_LF_OutputDesignatio n D2
								MOVP	K1	wTransmissionPointer D3
								MOVP	 K5	wOutputCount D4
								MOVP	K2	C24_1.stnCH1.uSet_Trans missionDataCount_D U0XG1024
								MOVP	H1234	wnTransmissionData[0]
			 					MOVP	H56AB	wnTransmissionData[1]
								wnTransmissio	C24 1.stnCH1.wnSet T	K2
			 				BMOVP	nData D10	ransmissionData_D[0] U0¥G1025	
			 					MOVP	H1	C24_1.wnForUserRegistrati onNo8001H_D[0] U0¥G6912
			 					MOVP	H2D	C24_1.wnForUserRegistrati onNo8001H_D[1] U0¥G6913
									SET	bReq_UserFlameTransmiss ion M10
(41)				M_RJ71C24_SendUserFrame_00C_1 Send User	(M+RJ71C24_SendUserFrame_00C) Frame FB					
	bReq_UserFlameTrans mission M10			B:i_bEN	م_bENO:B					UserFlameTransmissionEx ecution M2
			 C24_1	DUT:istModule	ο ხΟΚ-Β					bUserFlameTransmissionN ormalCompletion M0
			wTransmissionCh annel		-					bUserFlameTransmissionA bnormalCompletion M1
			 wCR_LF_OutputD	UN,LUCH	0_0En.8	wErrorCo de				9
			 wTransmissionPoi	UW:LuCrLfSetting	o_uErrld:UW	- D20 F				
		 	 ( D3 )	- UW:LuSendFramePointer						
	bUserFlameTransmissi	 	 [ D4 ]	- UW:LuSendFrameCount						
(88)	onNormalCompletion M0		 						SET	bNormalCompleteFlag M100
(90)	bUserFlameTransmissi onAbnormalCompletion M1								SET	bAbnormalCompleteFlag M101
	1									
(92)										(END )

Set the transmission channel to CH1.
 Set CR/LF to "Do not send".
 Set the send pointer to 1.
 Set the output quantity to 5.

Set the send data length to 2WORD.

Set an arbitrary send data.

Set an arbitrary transmitted data in send buffer.

Set the data to be transmitted to user frame 8001H.

Set the transmission direction.

(41) Execute user frame transmission.

(88) Normal completion

(90) Abnormal completion
# **17.5** ASCII-BIN Conversion for Data Communicated with Bidirectional Protocol

This section explains the ASCII-BIN conversion of data to be communicated using the bidirectional protocol.

### Transmitted/received data range for ASCII-BIN conversion

The range of data to be sent/received to which ASCII-BIN conversion is performed is as shown below:



C24 performs the following processing when sending or receiving data.

### ■At the time of data reception

Processing flow when a message is received during data reception

- C24 converts a received data length (4-digit ASCII code data (hexadecimal)) to 2-byte binary code data and stores it in the receive data quantity storage area.
- C24 converts each two characters of a received data portion (2-digit ASCII code data (hexadecimal)) to 1-byte binary code data and stores it in the receive data storage area.
- C24 calculates a sum check code using the received data length and data portion prior to ASCII-BIN conversion, then checks the received head of the sum-check code using the code as a lower byte.

Processing flow when a response message is received

• C24 converts the first 2 digits of a received error code (4-digit ASCII code data (hexadecimal)) to 2-byte binary code data as the lower byte, and stores it in the transmission result storage area. (When '1234' is received, it is converted to 3412H and stored.)

### ■At the time of data transmission

Processing flow when a message is transmitted during data transmission

- C24 converts a data length (send data quantity) to 4-digit ASCII code data (hexadecimal), and sends it beginning with the lowest byte (L).
- C24 converts a data portion (send data) for one address to 4-digit ASCII code data (hexadecimal), and sends it beginning with the lowest byte (L).
- C24 calculates a sum check code using the data length and data section after ASCII-BIN conversion, and adds it to the transmission message.

Processing flow when a response message is transmitted

• C24 converts an error code for a detected error to 4-digit ASCII code data (hexadecimal), then sends it beginning with the lowest byte (L).

(For 3412H, it is converted to '3412' and sent beginning with '12'.)

### Ex. Calculation of sum check code



### Processing order for data transmission/reception

The processing steps taken by C24 to transmit/receive data with ASCII-BIN conversion and transparent code designation enabled are explained in the section for transparent codes and additional codes. (EP Page 339 Handling Transparent and Additional Codes for Bidirectional Protocol Data Communication)



# **17.6** Data Communication Using Bidirectional Protocol

This section shows examples of data communication using the bidirectional protocol when the settings/registrations are made with Engineering tool.

### Parameter settings

For details for each setting item, refer to the parameter. (SP Page 422 PARAMETER SETTING)

Setting it	tem			Setting content				
				CH1	CH2			
Basic	Various	Test mode setting		—	CH2 is not used			
settings	settings control	Communication protocol setting	Communication protocol setting					
specification	Communication speed setting	Set according to the target device.						
		Transmission setting	Operation setting	Independent				
		Data bit	Set according to the					
			Parity bit	target device.				
			Odd/even parity					
			Stop bit					
			Sum check code					
			Online change					
			Setting change					
		Station number setting (CH1, 2 in common: 0 to 31)		—				
		Conversion designation	ASCII-BIN conversion designation	ON				

### Data reception example (ASCII-BIN conversion is enabled)

The following shows an example of data reception when ASCII-BIN conversion is enabled.



### ■Program example

Category	Labe	l name				Descri	pti	ion	Device			
Module label	C24_^	1				Target module				—		
	C24_^	1.stnCH1.bSet_Req_ReceptionRead			CH1 Reception data read request				Х3			
Label to be defined	Define the global label as shown below.											
						~						
		Label Name	Data Type			Class		Assign (Device/Label)				
	1	wReceiveChannel	Word [Signed]		VAR	_GLOBAL	Ŧ	D1				
	2	wAllowableReceiveDataCount	Word [Signed]		VAR	_GLOBAL	•	D2				
	3	bReq_INPUTInstructionReceive	Bit		VAR	GLOBAL	•	M10				
	4	bINPUTInstructionReceiveNormalCompletion	Bit		VAR	GLOBAL	•	MO				
	5	bINPUTInstructionReceiveAbnormalCompletion	Bit		VAR	GLOBAL	•	M1				
	6	bINPUTInstructionReceiveExecution	Bit		VAR	GLOBAL	•	M2				
	7	wErrorCode	Word [Signed]		VAR	GLOBAL	•	D20				
	8	wReceiveDataCount	Word [Signed]		VAR	GLOBAL	•	D3				
	9	wnReceiveData	Word [Signed](015)		VAR	GLOBAL	•	D10				
	10	bNormalCompleteFlag	Bit		VAR	GLOBAL	•	M100				
	11	bAbnormalCompleteFlag	Bit		VAR	GLOBAL	•	M101				

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

C24_1 stnCH1 bSet_Req ReceptionRead X3				MOV	K1	wReceiveChannel
						D1
				MOV	K6	wAllowableReceiveDa nt D2
					SET	bReq_INPUTInstructi
>		M_RJ71C24_BidirectionalInput_00C_1 (M+RJ71C24_BidirectionalInput_00C ) Bidirectional Input FB				
bReq_INPUTInstruction Receive M10						bINPUTInstructionR Execution M2
		BibEN obENO!	3			bINPUTInstructionF
	C24_1	DUTi_stModule o_bOKf	3			NormalGomplet M0
	wReceiveChannel	UWiuCh o_bErr:1	3			bINPUTInstruction AbnormalComple M1
	wAllowableReceiv eDataCount D2 1	IWi MayRecyDatal earth ouFridd U	wErrorCod			
		on and a second and a	wReceiveD ataCount			
		o_uRecvDataLength:UV	/ [ D3 ]			
		o_uRecvData:UV	Data L D10			-
bINPUTInstructionRece iveNormalCompletion M0					SET	bNormalComplet M100
bINPUTInstructionRece iveAbnormalCompletion M1					SET	bAbnormalComple M101
						L
1						{END }

Set the reception channel to CH1.
 Set the allowable number of data to be received to 6.
 Set the reception direction.

(6) Execute reception.

(52) Normal completion

(54) Abnormal completion

When ASCII-BIN conversion is enabled, the codes for receivable arbitrary data portion and the codes for the received data that is stored in the receive area on the buffer memory are as follows:

Туре	Receivable codes	Codes stored in the receive area
Data length, data portion	30H to 39H, 41H to 46H	0H to 9H, AH to FH

### Data transmission example (ASCII-BIN conversion is enabled)

The following shows an example of data transmission with ASCII-BIN conversion used.



For data designated by the CPU module, data for one word is converted to 4-byte data ('0' to '9' and 'A' to 'F') and transmitted.

### ■Program example

Category	Labe	el name			Description				Device		
Module label	C24_	_1			Target module				—		
Label to be defined	Define the global label as shown below.										
		Label Name	Data Type			Class		Assign (Device/Label)			
	1	bReq_Transmission	Bit		VAR_	GLOBAL	-	X50			
	2	wTransmissionChannel	Word [Signed]		VAR_	GLOBAL	•	D1			
	3	wTransmissionDataCount	Word [Signed]		VAR_	GLOBAL	•	D3			
	4	wnTransmissionData	Word [Signed](03)		VAR_	GLOBAL	-	D10			
	5	wErrorCode	Word [Signed]		VAR	GLOBAL	-	D20			
	6	bReq_OUTPUTInstructionTransmission	Bit		VAR	GLOBAL	-	M10			
	7	b0UTPUTInstructionTransmissionNormalCompletion	Bit		VAR	GLOBAL	-	MO			
	8	b0UTPUTInstructionTransmissionAbnormalCompletion	Bit		VAR	GLOBAL	-	M1			
	9	bOUTPUTInstructionTransmissionExecution	Bit		VAR	GLOBAL	-	M2			
	10	bNormalCompleteFlag	Bit		VAR	GLOBAL	-	M100			
	11	bAbnormalCompleteFlag	Bit		VAR	GLOBAL	-	M101			
						-	_				

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	bReq_Transmission						K1	T
(0)	X50					MOVP	NI	w i ransmissionGhannel
	├						L	D1
							K4	wTransmissionDataCount
		 				MOVP		D3
							H3412	wnTransmissionData[0]
						MOVP		D10
							I	010
		 1			1			
						MOVP	H0BC5A	wnTransmissionData[1]
		 						D11
							H0F0DE	wnTransmissionData[2]
						MOVP		D12
							HOADD	umTranamiaaianData[2]
						MOVP	HUAUD	wini ransini ssion Data[5]
						-	L	D13
							SET	bReq_OUTPUTInstructionTra
		 _						M10
(20)			M_RJ71C24_BidirectionalOutput_00C_1 Bidirection	I (M+RJ71C24_BidirectionalOutput_00C) nal Output FB				
(20)								
	bReq_OUTPUTInstructionTr							bOUTPUTInstructionTransmi
	ansmission M10							ssionExecution M2
		 	- B:i_bEN	o_bENO:B				O
		 						LOUTDUTI- de utien Terrerei
								ssionNormalCompletion
		C24_1		- LOKR				MO
		L		0_004.8				
		- · · ·						bOUTPUTInstructionTransmi
		Channel						M1
		 [ D1	]- UW:i_uCh	o_bErr:B				
		wTransmission			wEmerCode			
		 DataCount	] UW:i_uSendDataLength	o_uErrId:UW	-[ D20 ]			
		wnTransmissio						L
		wnTransmissio nData						
		 wnTransmissio nData [ D10	]-UW:i_uSendData					
	bOUTPUTInstructionTransm	 wnTransmissio nData [ D10	]- UW:i_uSendData					
(65)	bOUTPUTInstructionTransm issionNormalCompletion M0	vmTransmissio nData [ D10	]- UWi_uSendData				SET	bNormalCompleteFlag
(65)	bOUTPUTInstructionTransm issionNormalCompletion M0	wmTransmissio nData [ D10	]- UW:_uSendData				SET	bNormalCompleteFlag M100
(65)	bOUTPUTInstructionTransm issionNormalCompletion M0 I bOUTPUTInstructionTransm	wnTransmissio nData [ D10	]- UW:⊔uSendData				SET	bNormalCompleteFlag M100
(65)	bOUTPUTInstructionTransm issionNormalCompletion M0 I bOUTPUTInstructionTransm issionAbnormalCompletion	wnTransmissio nData D10	]- UW:LuSendData				SET	bNormalCompleteFlag M100 bAbnormalCompleteFlag
(65) (67)	bOUTPUTInstruction Transm issionNormalCompletion M0 bOUTPUTInstructionTransm issionAbnormalCompletion M1	wnTransmissio Data D10	} UWi_uSendData				SET	bNormalCompleteFlag M100 bAbnormalCompleteFlag M101
(65) (67)	bOUTPUTInstructionTransm issionNormalCompletion I bOUTPUTInstructionTransm issionAbnormalCompletion I	wnTransnissio Data C D10	]- UWE_uSendData				SET	bNormalCompleteFlag M100 bAbnormalCompleteFlag M101

Set the transmission channel to CH1.
 Set the send data quantity to 4.
 Set arbitrary data to be transmitted in D10 to D13.
 Set the instruction execution.

(20) Execute transmission.

(65) Normal completion

(69)

(67) Abnormal completion

END

# **18** DATA COMMUNICATIONS BETWEEN TARGET DEVICE AND CPU MODULE IN M:N BASIS

### Point P

Always read this chapter when communicating data by the multidrop connection in the system configuration that the target device and CPU module are connected on an m:n basis.

This section explains data communications between the target devices and the CPU module by the multidrop connection of multiple target devices (m stations) and C24s (n stations). (The total number of 'm' and 'n' is up to 32 stations.) With this m:n multidrop communication, only MC protocol data communications by command transmission from the target devices can be performed.

### **18.1** Considerations on Data Communications

### Concurrent data communication with multiple target devices

When communicating data in m:n system configuration, more than one target devices cannot communicate data with the CPU module at the same time.

Configure interlock among the target devices so that the target device can communicate data with the CPU module in a 1:1 basis.

For details on arrangement and method for interlock among target devices, refer to the following sections.

Page 368 Arrangement for Interlock among Target Devices

IPage 371 Examples of Procedure for Data Communications with CPU Module

### Data communication method

Data communication between target devices and the CPU module can be performed by the following methods only:

- Data communication with the full-duplex communication method (The m:n data communications is impossible with halfduplex communications)
- Data communications by command transmission from target device using the MC protocol excluding the format 3 and format 5 control procedure (Data communications using the format 3 and format 5 control procedure and data transmission from sequence program using the on-demand function cannot be performed.)

### Data transmitted from any of target devices

Data transmitted by one target device is received by all the other target devices, including the target device that transmitted the data. The sent data from the CPU module is also received by all the target devices.

Therefore, devices that received data not addressed to their own stations (by judging by the station number in a message) are required to ignore the received data.

At the CPU module side, C24 also ignores the received data not addressed to it.

### Numbers designated for "Station No." and "Self-station No."

Designate the numbers below for "Station No." and "Self-station No." in the command message transmitted from the target device for data communications in the m:n system configuration.

#### ■When accessing to C24

Item	Communications with 2C/3C/4C frame	Communications with 1C frame					
Station No.	Station number of C24 to be passed through						
Self-station No.	Station number of access source target device <sup>*1</sup>	No designation necessary (No "Self-station No." item)					

#### When accessing to other device (communications for interlock)

Item	Communications with 2C/3C/4C frame	Communications with 1C frame		
Station No.	Station number of access destination device*1			
Self-station No.	Station number of access source device*1	No designation necessary (No "Self-station No." item)		

\*1 The number which has not been set to the respective C24s on the CPU module side is used within the range of "0" to "31" (00H to 1FH) as the number for the target device side in "Station No." and "Self-station No." in the message.

Select and designate the number of each target device.

The designation method is as shown in 'Contents of the data designation items' of each frame.

(CD MELSEC Communication Protocol Reference Manual)

 $\cdot$  Station No.: Designate the number of the transmit destination device.

· Self-station No.: Designate the number of the transmit source device. (No designation necessary when 1C frame is used.)

# **18.2** Arrangement for Interlock among Target Devices

When using the multidrop connection to communicate data between target devices and the CPU module in a m:n basis, the interlocks need to be configured among the target devices to prevent more than one target devices from communicating data with the CPU module at the same time.

The arrangements necessary for providing the interlocks among the target devices in order for one of the target devices to communicate data with the CPU module are as shown below.

(Arrangements for priority use of the line (obtaining line ownership) from the start to the end of data communications with the CPU module.)

### Maximum communication time per target device station

Determine the maximum time for each target device to communicate data with the CPU module once it obtained the line ownership.

This prevents loss of data communications between other devices and the CPU module in such cases as the target device, which obtained the line ownership, went down.

Ex.				
Target device 1	— Time — +	 	⊦4:   c	ndicates the range within which the target device annot obtain line ownership.
Target device 2 S Target device 5 Start of	data communications	 	)	ndicates the range within which the target device can obtain line ownership and can have data communication with the CPU module.

Restriction ("

- The maximum data communication time per target device station must be the maximum time required by the respective devices to communicate data with the CPU module.
- The device which obtained the line ownership must complete data communication with the CPU module within the maximum data communication time after the system started. (If data communications cannot be completed within the time, initialize the C24 transmission sequence by transmitting the EOT/CL code to the target CPU module within the maximum communication time. (L MELSEC Communication Protocol Reference Manual)
- While a target device and the CPU module are communicating data, have the other devices check for timeout so that they do not transmit data during this time.

# Message structure when communicating data among target devices

Determine the message structure to communicate data among target devices by any of the following. This is determined to provide interlocks among the other target devices so that each of them can communicate data with CPU module on a 1:1 basis.

### Same message structure as control procedure format frame

### ■Use an unset number for "Station No." and "Self-station No." in a message.

The number which has not been set to the respective C24s on the CPU module side is used within the range of "0" to "31" (00H to 1FH) as the number for the target device side in "Station No." and "Self-station No." in the message.

#### Select and designate the target device numbers.

The designation method is as shown in 'Contents of the data designation items' of each frame. (L MELSEC Communication Protocol Reference Manual)

- Station No. : Designate the number of the transmission destination device.
- Self-station No.: Designate the number of the transmission source device. (No designation necessary when 1C frame is used.)
- Ex.

#### When the m:n configuration is 5:27

The values in () indicate the respective station number of the target device and C24. (decimal: hexadecimal)



The above C24 includes Q series C24, L series C24, QC24(N), and UC24.

(3	(3C frame format 1)												
шZQ	Frame identification- No.		identification- No. Station No.						Self- station		\		
	н	L	н	L	н	L	н	L	н	L			
	F	9	1	С	0	0	F	F	1	В			
05H	46H	39H	31H	43H	30H	30H	46H	46H	31H	42H		I	

### Different message structure from control procedure format frame

#### Change the head data of each message to other arbitrary data.

• When format 1, format 2, or format 4 is selected for communication using ASCII code, change ENQ (05H).

## ■Use arbitrary data array after the head data of each message according to the user specifications.



### Point P

For the message structure for general report to all of the other devices except the CPU module station, use an unused station number or a massage structure different from the C24 control procedure format.

# **18.3** Examples of Procedure for Data Communications with CPU Module

This section shows examples of procedures to communicate data with the CPU module by configuring interlocks among the target devices.

# Sequential data communications between target devices and the CPU module

Each target device obtains the line ownership in turns according to the station number to communicate with the CPU module.



### Ex.

The example below shows the procedures for each target device to communicate data with the CPU module.



The above C24 includes Q series C24, L series C24, QC24(N), and UC24.

- When the system starts, the target device with the lowest station number (1BH) obtains the line ownership.
- When format 1, format 2, or format 4 is selected for communication using ASCII code, change ENQ (05H).
- 2 The target device that obtained the line ownership,
- Begins the processing from ④ after communicating data with the CPU module within the maximum data communication time arranged among the target devices, when communicating data with the CPU module.
- Immediately begins the processing from 4, when not communicating data with the CPU module.
- 3 The target devices that have not obtained the line ownership check the line usage time of the target device that obtained the line ownership and ignore the received data not addressed to their own station.

When the line usage time exceeds the maximum data communication time, each target device performs the processing of **Q**.



The target device that has communicated data with the CPU module, or a target device that does not need to communicate data with the CPU module transmits the data for transferring the line ownership to the target device with the next station number. A message structure example is shown in ⑤.

When a response message (refer to **③** in this section) is not received from the next target device to which the line ownership to be passed, data transmission for transferring the line ownership to the target device with the next station number is repeated until the line ownership is transferred.

• The target device that receives the line ownership transmits a response message to the target device that passes it the line ownership.



\*1 Command "ZZ" is a command for description purpose. Determine the command to transfer/obtain the line ownership at the user side.
The target device that accepted the line ownership by transmitting the response message performs the processing from
2.

• When the line usage time of the target device that currently has the line ownership exceeds the maximum data communications time,

• The target device, which has the next station number, transmits all of the other devices excluding the CPU module station the general report data and obtains the line ownership and performs the processing **2**.



\*1 It is a station number for general report to all of the other devices.

\*2 Command "ZZ" is a command for description purpose. Determine the command to transfer/obtain the line ownership at the user side.• The other target devices check if the general report data was received.

If the data was received, the target device performs the processing **3**.

If the data was not received, the next target device transmits general report data and obtains the line ownership and performs the processing **2** . The other target devices checks if the general report data has been received.

### Data communications between target devices and CPU module by designating a master station and slave stations

One of the target devices becomes the master station and the other target devices communicate data with the CPU module after obtaining permission from the master station.



The example below shows the procedures for each target device to communicate data with the CPU module. In this example, after the start of data communications between a target device and the CPU module, each device checks for timeout of the maximum data communication time. In addition, devices on the slave station, which are not communicating data with the CPU module, check if the target device that completed data communications with the CPU module transmitted a communication complete report.

In the following descriptions, the target device with the lowest station number(1BH) is the master station and the other target devices are slave stations.





• A slave station that wants to communicate data with the CPU module sends a communications request to the master station to obtain the line ownership. A message structure example is shown in **2**.

2 The master station transmits a permission response to the slave station that issued the communications request.



**③** The slave station that received the permission response performs the processing from **⑤** after communicating data with the CPU module within the maximum data communication time arranged among the target devices.

The master station that transmitted the permission response and the slave stations that does not obtain line ownership check the line usage time of the slave station that obtained the line ownership, and ignore the received data not addressed to their own station.

If the line usage time exceeds the maximum communication time, each target device performs the processing Ø.

**③** The slave station that has communicated data with the CPU module transmits a communication complete report to the master station after data communications completed. A message structure example is shown in **⑥**.

Slave stations that do not communicate data with the CPU module check if a communications complete report was transmitted, and do not communicate data with the master station during that time.

**6** The master station that received the communication complete report transmits a response to the slave station that transmitted the communication complete report.



After the completion of 3 above, or when the line usage time of the slave station that obtained the line ownership exceeds the maximum data communication time,

• The master station waits for a communication request from a slave station.

When the master station receives a communication request, it performs processing from 2.

• The slave stations do not communicate data with the master station until data communication with the CPU module is required.

When data communications with the CPU module is required, they perform the processing from **0**.

When the master station itself communicates data with the CPU module, it transmits all devices excluding the CPU module station a general report data and obtains the line ownership before communicating data with the CPU module while slave stations do not have the line ownership.

After data communications with the CPU module were completed, the master station transmits general report data to inform the slave stations that data communications with the CPU module are completed.

During this time, the slave stations do not communicate data with the master station until master station data communications have been completed.



	*1		*2			
(;) 3BH :	H10 H10 H20 H20 H20 H20 H20 H20 H20 H20 H20 H2	Transmission (18) H 75 H 75 H 75 H 75 H 75 H 75 H 75 H 75	Command (XZ) 58H HA5	≌ ©Message wait	Code Sum check (0) 30H 32H	<ul> <li>*1 Station No. for all target devices general report.</li> <li>*2 Commands "ZX" and "ZY" are commands for description purposes. The user should select the command when the master station communicates data with slave stations.</li> </ul>
	*1		*2			
(;)	(1) Transmission (1) destination station No.	(B) Transmission (B) source station No.	Command	e © Message wait	(80) Sum check	
	(;) 3BH (;)	+1 1 1 1 1 1 1 1 1 1 1 1 1 1	Lansmission () Transmission () Transmi	Lansmission () () () () () () () () () () () () () (	.1     .5       .1     Transmission       .1     destination No.       .1     Transmission       .1     destination No.       .1     .1       .2     .1       .1     .1       .2     .1       .2     .1       .2     .1       .2     .1       .2     .1       .2     .1       .2     .1       .2     .2       .2     .2       .2     .2       .2     .2       .2     .2       .2	.1     .5       .1     .1       .1     .2       .1     .1       .1     .2       .1     .1       .2     .1       .1     .2       .1     .1       .2     .1       .1     .2       .1     .2       .1     .2       .1     .2       .1     .2       .1     .2       .1     .2       .1

# **19** SWITCHING THE MODE AFTER STARTING

This function forcefully switches the current communication protocol and transmission specifications of a designated interface from a target device and by program after C24 starts up.

C24 starts operating with the setting values in "Module Parameter" of Engineering tool at the time of the startup.

### Point P

This function is used to change the communication protocol and transmission specification of the designated interface and continue data communications without restarting the CPU module. For mode switching by using the dedicated instruction (UINI instruction) or the module FB (InitialUnit instruction), refer to the following section.

Page 520 Dedicated Instructions

MELSEC iQ-R Serial Communication Module Function Block Reference

### Mode switching from target device

- Mode switching can be performed when the communication protocol of an interface connected to the target device is the MC protocol.
- The communication protocol can be changed from the MC protocol as shown below.



· The transmission specifications set with the parameter setting of Engineering tool can be changed.

### Mode switching by program

- Regardless of the current communication protocol of an interface connected to the target device, mode switching can be performed by program.
- The communication program can be changed by program as shown below.



• The transmission specifications set with the parameter setting of Engineering tool can be changed.



When using the mode switching function, set "Setting change" of the Engineering tool parameter settings (by selecting [Basic settings] ⇔ [Various control specification]⇔[Transmission Setting]) to "Enable".

# **19.1** Mode Switching Operation and Contents that can be Changed

This section describes the settings that can be changed with the mode switching function and the operation of C24 after mode switching.

### Settings that can be changed with mode switching

The settings that can be changed with mode switching are as shown below.

### Switching the communication protocol

- · The communication protocol setting of each interface can be switched.
- The communication protocol after mode switching is specified with the 'Switching mode No. designation' (Un\G144/304) in the area for designation of mode switching on the buffer memory.

### Switching the transmission specifications

- The transmission setting of each interface can be switched.
- The transmission setting after mode switching is specified with the 'Transmission specifications after switching designation' (Un\G145/305) in the area for designation of mode switching on the buffer memory.

Point 🄑

With the mode switching function, the settings corresponding to "Communication protocol setting" and "Transmission setting" in the parameter settings of Engineering tool can be changed.

### **Operation for mode switching**

The following describes C24 operation for mode switching.

### Processing currently in execution

- When a mode switching request is issued, the mode switching process starts immediately.
- If one of the following processing was being performed when a mode switching request was issued, the processing is terminated.

(Data communications using the MC protocol)

Command message receive processing and response message or on-demand data transmission processing are all terminated.

The transmission completion signal for an on-demand data transmission request is not turned ON.

(Data communications using the nonprocedural, bidirectional, or predefined protocol)

Transmit and receive processing are all terminated.

All the input signals from the CPU module related to transmit and receive processing are turned OFF.

While received data from the target device was being stored to C24, the received data up to that point is ignored and the data is processed with the current receive data quantity treated as "0".

### Modification of buffer memory stored value

- Special applications area (Un\G594 to 595/610 to 611)
   The communication protocol status and transmission specifications after mode switching has been completed are stored.
   The values stored to areas other than the above are not changed. The contents before mode switching are preserved.
- User setting area (Un\G1024 to 6911, 9728 to 16383) The stored value is not changed. The contents before mode switching are preserved.

## **19.2** Considerations for Mode Switching

### Modification of buffer memory stored value

Determine the following items between the target device and the CPU module to prevent mode switching during data communications.

- · How to perform mode switching from the target device or by program
- Timing for each mode switching pattern ( Page 378 Operation for mode switching)
- · Interlocking of all connected devices for mode switching

Method to configure interlock when informing all of the connected stations the mode switching execution Method and message structure when informing all of the connected stations the mode switching completion

Device number and meaning of the value when a CPU module word device is used

### Mode switching from target device

• Once the mode has been switched to a mode other than MC protocol (Formats 1 to 5), it cannot be changed from the target device.

In this case, switch the mode by program.

 Mode switching from the target device can be performed to only C24 connected to a target device (including connected stations by multidrop connection).

It is not available for C24s on the other stations via network system. ( MELSEC Communication Protocol Reference Manual)

Point P

It is recommended to perform mode switching by program.

### Data communications after mode switching

While the mode switching is being executed, data communications between C24 and the target device cannot be performed, including the processing time to store the setting value to the special applications area on the buffer memory.

Mode switching in progress signal X6/XD

### Mode switching related to interlink operation

Do not switch the mode when the two interfaces of C24 are in the interlink operation. Also, do not switch the mode for the interlink operation.

# **19.3** I/O Signals for Handshake with CPU Module and Buffer Memory

This section explains the I/O signals for handshake and the buffer memories used when mode switching is performed.

IO Signais for handshake with CFO module											
Туре	I/O signal		Signal name	Device tur OFF	ned ON/	Timing					
	CH1	CH2		CPU	C24						
Mode	X6	XD	Switching mode		0	Ormalata					
switching	Y2	Y9	Mode switching request	0		X6/XD (Switching)					

### I/O signals for handshake with CPU module

### Point P

The following signals can also be used as I/O signals, in addition to the above.

- Module READY signal (X1E): Turns ON when C24 can be accessed from the CPU module.
- Watchdog timer error signal (X(n+1)F): Turns ON when C24 does not operate normally.
- 'CH1 Error occurrence' (XE): Turns ON when error occurred on the CH1 side.
- 'CH2 Error occurrence' (XF): Turns ON when error occurred on the CH2 side.

For details on the CPU module I/O signals, refer to the following section.

( I Page 493 Input/Output Signal List)

### Buffer memory

Dunier	inemory					
Address (DEC (HEX))		Name		Setting value/Stored value		
CH1	CH2					
144 (90H)	304 (130H)	For designation of mode switching	Switching mode No. designation ( Page 381 Switching mode No. designation (Un\G144/304))	0001H: MC protocol (Format 1) to 00FFH: MELSOFT connection		
145 (91H) 305 (131H)		-	Transmission specifications after switching designation( SP Page 381 Transmission specifications after switching designation (Un\G145/305))	0000H : Match the setting in MELSOFT. 8000H to 8FFFH: Match the setting to that of this area		
515 (203H)		For confirmation of parameter setting and mode switching	Parameter setting error and mode switching error status	0 : No error Other than 0: Parameter setting error, mode switching error ( ) Page 473 Error Code List)		

### Switching mode No. designation (Un\G144/304)

Write the mode No. after mode switching (0001H to 0007H, 0009H, 00FFH). When "0000H" is designated, the operation will be matched with the setting in MELSOFT.



\*1 Specify "00H" for the communication protocol setting when specifying the MELSOFT connection mode with the parameter settings of Engineering tool.

### ■Transmission specifications after switching designation (Un\G145/305)

- 1. Specify the transmission specifications after mode switching.
- 2. Write "0000H" when returning to the settings configured with Engineering tool.
- **3.** When setting arbitrary transmission specifications (other than the transmission specification set with Engineering tool), write the value corresponding to ON/OFF of the relevant bit.<sup>\*2</sup> The relevant bit 1 (ON)/0 (OFF) is specified as the same as the transmission setting of Engineering tool.
- For C24

15	to	b8	b7	b6	b5	b4	b3	b2	b1	b0	_				
80F	l∼8F⊦	ł								0	CH1 side	e <sup>*1</sup>			
80F	l∼8F⊦	ł									CH2 side	e <sup>*1</sup>			
	1		Î	Î	Î	Î	Î	Î	Î	Î	Bit	Description	OFF(0)	ON(1)	Remarks
											b0	Operation setting	Independent	Link	Be sure to set the CH1 side to OFF(0).
											b1	Data bit	7	8	Parity bit is not included.
											b2	Parity bit	No	Yes	Vertical parity
											b3	Odd/Even parity	Odd	Even	Valid only when parity bit is set to Exist.
											b4	Stop bit	1	2	
											b5	Sum check code	None	Exist	
											b6	Online change	Disable	Enable	
											b7	Setting modifications	Disable	Enable	
											<b></b>				
											Bit	Description	Set v	alue	Remarks
											b8 to b15	Communication rate	80H~	~8FH	Refer to *2

\*1 On the side of interface to which "MELSOFT connection" is set for the switching mode No. designation, set all items to the OFF side. C24 operates with the setting values set with Engineering tool.

Transmission setting	Engineering tool side setting
Operation setting	Independent
Data bit	8
Parity bit	Yes
Odd/even parity	Odd
Stop bit	1
Sum check code	Yes
Online change	Enable
Setting change	Enable

\*2 It indicates the setting value for the communication speed.

Communication speed	Bit position	Communication speed	Bit position	Remarks		
(units: bps)	b15 to b8	(units: bps)	b15 to b8			
1200	82H	38400	89H	Decrease the communication		
2400	83H	57600	8AH	speed when data cannot be		
4800	84H	115200	8BH	to overrun error, framing		
9600	85H	230400	8CH	error, etc. in communication		
14400	86H	-	-	with the target device.		

• Set "80H" to the interface to which "MELSOFT connection" is set for the switching mode No. designation. The communication speed set on the Engineering tool side is applied.

### Precautions

The following I/O signals for handshake and buffer memories need to be considered on the CPU module side at the time of mode switching from the target device.

- 'CH□ switching mode' (X6/XD)
- 'Parameter setting error, mode switching error status' (Un\G515)

### **19.4** Mode Switching Method by Program

This section shows how to switch the C24 mode by program.

### Mode switching procedure

The procedures for switching C24 mode by program are as shown below.



\*1 Inform in advance all the connected device that data communications cannot be performed due to mode switching.

\*2 When an error occurs after checking 'Parameter setting error, mode switching error status' (Un\G515), take the corresponding actions. (SP Page 473 Error Code List)

· Checking of mode switching designation contents for buffer memory mode switching area and writing of mode switching designation contents within the range that can be designated

· Re-execution of mode switching

\*3 After confirming that mode switching was completed normally, inform all the connected devices that data communications are possible, and restart data communications.

To check C24 mode (communication protocol, transmission specifications) after mode switching, read the buffer memory (Un\G594 to 595/610 to 611). (EF Page 447 Current operation status reading method)

### ■Program example

The following shows an example of program for mode switching of the CH1 side interface.

Category	Label name	Description	Device
Module label	C24_1	Target module	—
	C24_1.stnCH1.bSet_Req_ReceptionRead	CH1 Reception data read request	Х3
	C24_1.stnCH1.bSts_ReceptionAbnormalDetection	CH1 Reception abnormal detection	X4
	C24_1.stnCH1.bSts_ModeSwitchingProcessing	CH1 Switching mode	X6
	C24_1.stnCH1.bSet_Req_ModeSwitching	CH1 Mode switching request	Y2
	C24_1.stnCH1.uSet_SwitchingModeNum	CH1_Switching mode No. designation	U0\G144
	C24_1.uSts_ModeSwitching_ParameterSetting_D	Parameter setting error, mode switching error status	U0\G515

Label to be defined Define the global label as shown below.

	Label Name	Data Type	Class		Assign (Device/Label)
1	wModeSwichingError	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D2
2	bModeSwichingCompletion	Bit	 VAR_GLOBAL	•	M50
3	bReq_ModeSwichingReqestClear	Bit	 VAR_GLOBAL	•	X52
4	bReq_ModeSwiching	Bit	 VAR_GLOBAL	•	X60
5	bReceivingFlag	Bit	 VAR_GLOBAL	•	M11
6	bSendingFlag	Bit	 VAR_GLOBAL	Ŧ	M12
7	wnModeSwichingDesignation	Word [Unsigned]/Bit String [16-bit](01)	 VAR_GLOBAL	Ŧ	DO



Set the transmission specifications. Write the mode switching designation contents to the buffer memory. Set the mode switching request.

(17) Reset the mode switching request signal. Read the mode switching request contents. Mode switching completes.

(28) Change the setting value of the communication protocol according to the communication specification. Mode switching complete reset

(31) Clear the mode switching request with the clear direction.

## **19.5** How to Switch Mode from Target Device

This section shows how to switch the C24 mode from the target device.

### Mode switching procedure

The procedures for switching C24 mode from the target device.



- \*1 Inform in advance all the connected device that data communications cannot be performed due to mode switching.
- \*2 When 'CH□ Error occurrence' (XE, XF) turns ON, check the error contents and take the corresponding actions. (▷ Page 473 Error Code List)

· Checking of mode switching designation contents for buffer memory mode switching area and writing of mode switching designation contents within the range that can be designated

 $\cdot$  Re-execution of mode switching

- \*3 When mode switching is performed from the target device, perform the read/write operation from/to the special applications area on the buffer memory shown below from the CPU module after mode switching is completed.
   · 'Parameter setting error, mode switching error status' (Un\G515)

  - $\cdot$  Initial setting areas for data communication (Un\G147 to 289/307 to 449) ( $\square$  Page 498 Buffer memory list)
- \*4 After confirming that mode switching was completed normally, inform all the connected devices that data communications are possible, and restart data communications.



To check C24 mode (communication protocol, transmission specifications) after mode switching, read the buffer memory (Un\G594 to 595/610 to 611). (Read the buffer memory with the MC protocol buffer memory read function when checking by the target device.) (III MELSEC Communication Protocol Reference Manual)

### ■Program example

The following shows an example of program on the CPU module side for mode switching of the CH1 side interface from the target device.

Category	Label name	Description	Device
Module label	C24_1	Target module	—
	C24_1.stnCH1.bSet_Req_ModeSwitching	CH1 Mode switching request	Y2
	C24_1.stnCH1.bSts_ModeSwitchingProcessing	CH1 Switching mode	X6
	C24_1.uSts_ModeSwitching_ParameterSetting_D	Parameter setting error, mode switching error status	U0/G515
1			

Label to be defined Define the global label as shown below.

	Label Name	Data Tupe	Class		Assign (Device/Label)
	Labernianie	Data Type	Cidaa	_	Assign (Device/Label)
1	wModeSwichingError	Word [Signed]	 VAR_GLOBAL	•	D2
2	bModeSwichingCompletion	Bit	 VAR_GLOBAL	•	M50
3	bCommunicationProtocolSettingValue	Bit	 VAR_GLOBAL	•	M5000

(0)	C24_1.stnCH1.bSts_ModeS witchingProcessing X6				 N	IOV	C24_1.uSts_ModeSwitchi ng_ParameterSetting_D U0¥G515	wModeSwichingE rror D2
		=	wModeSwic hingError D2	ко			SET	bModeSwichingC ompletion M50
(10)	bModeSwichingCompletion M50						SET	bModeSwichingC ompletion M50
							RST	bModeSwichingC ompletion M50
(13)								(END )

(0) Read the mode switching request contents. Mode switching is completed.

(10) Change the setting value of the communication protocol according to the communication specification. Mode switching complete reset

# **20** USING SEND/RECEIVE DATA MONITORING FUNCTION

The following describes C24 send/receive data monitoring function.

### 20.1 Send/receive Data Monitoring Function

### Overview

The send/receive data monitoring function is a function to monitor send/receive data between the C24 and a target device on communication lines.

The system startup phase can be shortened by analyzing the send/receive data on the communication lines when debugging the program.

The two methods below are available for the send/receive data monitoring method.

This chapter explains the send/receive data monitoring by the program.

### Send/receive data monitoring by program

Monitoring is performed by writing the monitor start instruction to the send/receive data monitoring designation area of the buffer memory.

### Send/receive data monitoring by Engineering tool

Monitoring (circuit trace) is performed by using the circuit trace function of Engineering tool ( 🖙 Page 109 Circuit Trace).

### Send/receive data monitoring operation

The following describes the send/receive data monitoring operation.

Point P

 When using the send/receive data monitoring function, the total transmission speed of the two interfaces should not exceed 230400 bps.

### Start monitoring

- Write the monitor start instruction "0001H" to the send/receive data monitoring designation (Un\G8216/8472). (Set by user)
- By the monitor start instruction, the monitor data pointer/monitor data size area are cleared to '0' and "0002H" is written in the send/receive data monitoring designation area to start monitoring. (Set by C24)
   Monitor data area (Un\G9730 to 13055/13058 to 16383 (default)) is not cleared to '0'.
- When a monitor setting error occurs, "100FH" is written to the send/receive data monitoring designation area. (Set by C24) Review the monitor buffer start address and the monitor buffer size setting range and perform monitoring again.

### During monitoring

- Once monitoring starts, data of reception, transmission, data reception error, and signal change are stored from the start address of the monitor data area in the order of occurrence.
- When the monitored data exceeds the monitor data area size, monitoring is continued by writing new data over the oldest data.

However, monitoring may automatically stop according to the settings of the 'Monitor option specification' (Un\G8217/ 8473). ( I Page 391 Monitor option specification (Un\G8217/8473))



Each data is stored in the monitor data area at the timing shown below.

Data classification		Data storage timing		
Receive data		When data is received		
Send data		When data is transmitted		
Reception err	or data	When a reception error is detected		
RS-232 line	RS (RTS), ER (DTR) signals	When the RS (RTS), ER (DTR) signals change		
CS (CTS), DR (DSR), CD (DCD) signals		When signal changes are detected during the periodic processing (operation interval: 1 to 19 ms) and at the each timing described above (Monitoring is not performed to changes during the periodic processing)		

### Stop monitoring

Monitoring stops when any of the following conditions is satisfied.

- For monitor stop by user instructions Monitoring stops when "0000H" is written in the send/receive data monitoring designation area of the buffer memory. (Set by user)
- For monitor stop by the system when the monitor data area is full.

The stop at buffer full specification (bit 0) of the monitor option specification area of the buffer memory is set to "ON". When the monitor data area is full (monitor buffer size), monitoring is automatically stopped and "1002H" is written in the send/receive data monitoring designation area. (Set by C24)

For monitor stop by the system when the timer 0 error occurs

The 0 timer error outbreak stop designation (bit 2) of the monitor option specification area of the buffer memory is set to "ON".

When the timer 0 error (error code 7F40H) occurs, monitoring is automatically stopped and "1002H" is written in the send/ receive data monitoring designation area. (Set by C24)

Part of the data immediately after the occurrence of a timer 0 error may be entered in the monitor data area.

# 20.2 Send/receive Data Monitoring Function Settings

This section explains how to configure the settings for the send/receive data monitoring function. The settings are configured with Engineering tool or by program.

### Setting with Engineering tool

The setting items for the send/receive data monitoring function are listed below.

Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings" ⇔ "Various control specification"

### ■Parameter settings

Paramete	er setting it	em		Description
Basic Various settings control specificati	Various control	Send/receive data monitoring	Send/receive data monitoring function specification	Select "monitor start instruction" for constant monitoring.
	specificati	function	Stop at buffer full specification	Select "ON" to stop monitoring when the monitor data area is full.
	011	specification	0 timer error outbreak stop designation	Select "ON" to stop monitoring when a timer 0 error occurs.
		Monitor buffer start address designation	Designate the value to change the monitor buffer address. (Default: 2600H/3300H)	
			Monitor buffer size designation	Designate the value to change the monitor buffer size (Default: 0D00H)

### Buffer memory for send/receive data monitoring function

### Send/receive data monitoring designation (Un\G8216/8472)

Designate the start/stop of the send/receive data monitoring function.

For details on the send/receive data monitoring designation operation, refer to the following section.

Page 388 Send/receive data monitoring operation



### Monitor option specification (Un\G8217/8473)

Designate the options of the send/receive data monitoring function.



### ■Stop at buffer full specification (bit 0)

- When the stop at buffer full specification is OFF
   When the monitored data exceeds the monitor data area size, monitoring is continued by writing new data over the oldest data.
- · When stop at buffer full specification is ON

When the monitor data area is full (monitor buffer size), monitoring is automatically stopped and "1002H" is written in the send/receive data monitoring designation area. (Set by C24)

### ■0 timer error outbreak stop designation (bit 2)

- When the o timer error outbreak stop designation is OFF Monitoring continues even if the timer 0 error (error code 7F40H) occurs.
- When the 0 timer error outbreak stop designation is ON
   When the timer 0 error (error code 7F40H) occurs, monitoring is automatically stopped and "1002H" is written in the send/ receive data monitoring designation area. (Set by C24)

### Monitor buffer start address designation (Un\G8218/8474)

Designate the start address of the storage area (monitor data area) for the monitored data within the range of the user setting area of the buffer memory.

Setting range: 0400H to 1AFDH, 2600H to 3FFDH (Default: 9728/13056 (2600H/3300H))

### Monitor buffer size designation (Un\G8219/8475)

Designate the size of the monitor data area. Setting range: 0003H to 1A00H (Default: 0D00H) 20

### Monitor data pointer storage area (Un\G9728/13056 (default))

# The oldest data position of the monitor data area is stored using the offset value from the start address of the monitor data area.

0 to (monitor buffer size designation (default: 0D00H) - 3): the oldest data position

## When the monitored data exceeds the monitor buffer size, the new data is written over the oldest data. (Ring buffer type)

The oldest data position of the monitor data area can be confirmed from this area.

### Ex.

"Un\G9745" becomes the oldest data when "000FH" is the monitor data pointer using "Un\G9730" as the start address of the monitor data area.

1 [Device/Buf	fer Me	mory Batch M	onitor] Monitoring	]			
🔿 Device	<u>N</u> ame			T	D	etailed Conditions 🛛 😵	Monitoring Stop Monitoring
<u> B</u> ufferm	emory	<u>U</u> nit	0		Address 9728	▼ DEC ▼	]
Device Name		FEDC	B A 9 8 7	6 5 4 3 2 1 0	Current Value	String	Monitor data pointe
<u>U0\G9728</u>		0 0 0 0	00000	001111	000F		storage area
<u>(U0\G9729</u>		0000	<u>1 1 0 0 1 '</u>	1 1 1 1 1 1 0	OCFE	þ. 🔪 🔨	
U0\G9730	+0	0001	0 0 1 1 0	1 0 0 0 1 0 0	1344	D.	Monitor data size
U0\G9731	+1	0001	0 0 1 1 0	1 0 0 0 1 0 1	1345	Ε.	storage area
U0\G9732	+2	0001	0 0 1 1 0	1 0 0 0 1 1 0	1346	F.	
U0\G9733	+3	0001	0 0 1 1 0	1 0 0 0 1 1 1	1347	G.	
U0\G9734	+4	0001	0 0 1 1 0	1 0 0 1 0 0 0	1348	H.	
U0\G9735	+5	0001	0 0 1 1 0	1 0 0 1 0 0 1	1349	1.	
U0\G9736	+6	0001	0 0 1 1 0	1 0 0 1 0 1 0	134A	J.	
U0\G9737	+7	0 0 0 1	0 0 1 1 0	1 0 0 1 0 1 1	134B	К.	
U0\G9738	+8	0001	0 0 1 1 0	1 0 0 1 1 0 0	134C	L.	
U0\G9739	+9	0 0 0 1	0 0 1 1 0	1 0 0 1 1 0 1	134D	М.	
U0\G9740	+A	0001	0 0 1 1 0	1 0 0 1 1 1 0	134E	N.	
U0\G9741	+B	0 0 0 1	0 0 1 1 0		134F	0.	
U0\G9742	+C	0001	0 0 1 1 0	1 0 1 0 0 0 0	1350	P.	
U0\G9743	+D	0001	0 0 1 1 0	0 0 1 1 0 1	130D		
U0\G9744	+E	0001			130A		Oldest data in the
U0\G9745	+F	0001	00110		1344	D.	monitor data area
00\G9746			0 0 1 1 0		1346	F.	

### Monitor data quantity storage area (Un\G9729/13057(default))

The number of monitor data stored in the monitor data area is stored. 0 to (monitor buffer size designation (default: 0D00H) - 2): number of monitor data

### Monitor data area (Un\G9730 to 13055/13058 to 16383(default))

The monitor data is stored in one-word units in the configuration below.

For an example of the send/receive data monitoring, refer to the following section.

Page 394 Send/receive Data Monitoring Example



1: When transmitting data

2: When the RS(RTS)/ER(DTR)signal is changed

3: When a reception error occurs

4: When detecting a CD(DCD) to DR(DSR)signal change

\*1 FE : Framing error

OVR : Overrun error

PE : Parity error

# 20.3 Send/receive Data Monitoring Example

The following shows an example of the send/receive data monitoring for communication using the nonprocedural protocol.

### System configuration

The system configuration for the program example is as shown below. The CH used for operation of this sample program is CH1 only.



### Program example for send/receive data monitoring

### ■Parameter settings

Setting item				Setting content		
			CH1	CH2		
Basic settings	Various control specification	Test mode setting		-	CH2: Not used	
		Communication protocol setting		Nonprocedural protocol		
		Communication speed setting		19200 bps		
		Transmission setting	Operation setting	Independent		
			Data bit	8		
			Parity bit	None		
			Odd/even parity	Odd		
			Stop bit	1		
			Sum check code	None		
			Online change	Enable		
			Setting change	Enable		
		Station number setting (CH1, 2 in common: 0 to 31)		0		

### ■Program example

Category	Label name	Description	Device				
Module label	C24_1	Module	—				
	C24_1.stnCH1.uSet_DataMonitoring_D	CH1_Send/receive data monitoring designation	U0\G8216				
	C24_1.stnCH1.uSet_MonitoringDataOptional_D	CH1_Monitor option specification	U0\G8217				
Label to be defined	Define the global label as shown below.						
	LabelMana Data Tura	less Assime (Device / she)					

		Label Name	me Data Type C		Class		Assign (Device/Label)	
	1	bReq_MonitoringStart	Bit		VAR_GLOBAL	•	×20	
	2	bReq_MonitoringOption	Bit		VAR_GLOBAL	•	X21	
	3	bReq_MonitoringStop	Bit		VAR_GLOBAL	•	X22	
	4	bReq_MonitoringStartFlag	Bit		VAR_GLOBAL	•	M20	
	5	bReq_MonitoringFlag	Bit		VAR_GLOBAL	•	M21	
	6	bReq_MonitoringStopFlag	Bit		VAR_GLOBAL	•	M22	
	7	wMonitoringDataDesignationAreaStstus	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D300	
	8	wMonitoringOptionDesignationAreaStstus	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D301	
	RCPU.stSM.bAI						014.1 -t=01110-+ D-+-	Maritania Data Dational
------	------------------------------------	--------------------------------	--	-------	-------	------	--	--
(0)	SM400	1				MOV	Monitoring_D U0¥G8216	ionAreaStstus D300
						MOV	C24_1.stnCH1.uSet_Monit oringDataOptional_D U0¥G8217	wMonitoringOptionDesign ationAreaStstus D301
(9)	bReq_Monitorin gStart X20	bReq_Monitori ngFlag M21			FMOVP	H0	U0¥G9730	H0CFE
						MOVP	H1	C24_1.stnCH1.uSet_Data Monitoring_D U0¥G8216
							SET	bReq_MonitoringStartFlag
								M20
(24)	gStartFlag M20	=	C24_1.stnCH1.uSet_Da taMonitoring_D U0¥G8216	H2			RST	bReq_MonitoringStartFlag M20
							-	hPag ManitaringElag
							SET	M21
		=	C24_1.stnCH1.uSet_Da taMonitoring_D U0¥G8216	H100F			RST	bReq_MonitoringStartFlag M20
	bRea Monitorin	bRea Monitori						
(38)	gOption X21	ngFlag M21				MOVP	H5	C24_1.stnCH1.uSet_Monit oringDataOptional_D U0¥G8217
(46)	bReq_Monitorin gFlag M21	=	C24_1.stnCH1.uSet_Da taMonitoring_D U0¥G8216	H1002			RST	bReq_MonitoringFlag M21
(52)	bReq_Monitorin gStop X22	bReq_Monitori ngFlag M21				MOVP	H0	C24_1.stnCH1.uSet_Data Monitoring_D U0¥G8216
							SET	bReq_MonitoringStopFlag M22
(01)	bReq_Monitorin gStopFlag M22	_	C24_1.stnCH1.uSet_Da	H0			DOT	bReq_MonitoringStopFlag
(01)		_	U0¥G8216					M22
							RST	bReq_MonitoringFlag M21
(68)								(END )

(9) Clear the monitor data area to '0'. During monitor start instruction

(24) During monitoring (002H) Monitor setting error (100FH)

(46) During monitor stop (1002H)

(52) During monitor stop instruction

(61) Monitor stopped (0000H)

#### Confirming monitor data with Engineering tool

Monitor the monitor data area on the CH1 side (Un\G9730 to 13055) with the Device/Buffer Memory Batch Monitor function of Engineering tool.

For the data configuration of the monitor data area, refer to the following section.

IPage 393 Monitor data area (Un\G9730 to 13055/13058 to 16383(default))

#### Ex.

Monitoring example when the following data is transmitted from CH1 for data communication using the nonprocedural protocol.

#### Send data; "ABCDEFGH" + 0D0AH (5-word)

. [Device	e/Buffer	r Merr	ory	Batc	h Mo	nitor	Moni	toring	3													
© Di	evice <u>N</u> a	ame								-	•						De	etai <u>l</u> ed C	Cond	litions	8	Monitoring Stop Monitoring
<u>۹ او</u>	uffermen	nory		<u>U</u> nit			0			Ŧ	1	HEX	9		<u>A</u> ddress	972	8		Ŧ	DEC	-	
Device	Name		FE	D	CE	8 A	9 8	7	6 5	4	3	2	1	0	Curre	nt Value		ç	String	g	_	
J0\G9;	728	1	0 0	0	0 0	) ()	0 0	0	0 0	0	0	0	0	0		I	0000				1	
U0\G9;	729		) ()	0	0 0	) ()	0 0	0	0 0	0	1	0	1	1		(	000B				1	
U0\G9;	730		0   0	1	0 0	) ()	1 1	0	0 0	0	0	0	1	1		:	2303	.#				
JO/G97	731		) 0	0	1 0	) ()	1 1	0	1 0	0	0	0	0	1			1341	A.				
JO/G97	732	1	0 0	0	1 0	) (0	1 1	0	1 0	0	0	0	1	0			1342	В.				
U0/G9;	733	1	0 0	0	1 0	) ()	1 1	0	1 0	0	0	0	1	1			1343	C.				
U0/G97	734	1	) ()	0	1 0	) ()	1 1	0	10	0	0	1	0	0			1344	D.				
JO/G97	735	1	0 0	0	1 0	) ()	1 1	0	1 0	0	0	1	0	1			1345	Ε.				
JO/G9;	736	1	) 0	0	1 0	) ()	1 1	0	10	0	0	1	1	0			1346	F				
U0/G9;	737	1	0 0	0	1 0	) ()	1 1	0	1 0	0	0	1	1	1			1347	G.			-	
U0\G9;	738	1	0 0	0	1 0	) ()	1 1	0	1 0	0	1	0	0	0			1348	Н.			_	
U0\G9;	739	1	0 0	0	1 0	0 0	1 1	0	0 0	0	1	1	0	1		1	130D				-	
UO\G9;	740	1	) ()	0	1 0	) ()	1 1	0	0 0	0	1	0	1	0			130A				-	
JO/G9;	741		) 0	0	0 0	0	0 0	0	0 0	0	0	0	0	0			0000				-	
00/69.	742		JU	U	UL	U U	0 0	U		U	U	U	U	U			0000					
00/69,	743		JU	U	0 0		0 0	0		U	U	U	0	0			0000				-	
00/69,	744		J U	0	00	0	0 0	0	0 0	0	0	U	0	0			0000				-	
00/63/	740		) U ) 0	0			0 0	0		0	0	0	0	0			0000				-	
00/03/	/40		J	0	0 1	10	0 0	101	υĮυ	0	U	0	U	0							-	Ŧ
b15	b14	b13	k	012	b1	1	b10	b9	k	08		b7		b6	b5	b4	b3	b2	2	b1	b0	
0	0	0		1	0		0	1		1		0		1	0	0	0	0		0	1	When transmitting
Syste	m are	а			<b>†</b>	([		CS	C G) (D	R SR			_		Trar	nsmissi	on d	ata				σατα

# 21 INDEPENDENT/LINKED OPERATION OF INTERFACE

This chapter explains the independent/linked operation of C24.

### 21.1 Setting and Data Flow of Independent Operation

#### Setting

For the independent operation of two interfaces on C24, configure the parameter setting as shown below.

Setting iter	m		Setting content			
				CH1	CH2	
Basic	Various control	Test mode setting		-	<u>.</u>	
settings	specification	Communication protocol setting		Set according to the target	Set according to the target	
		Communication speed setting		device.	device.	
		Transmission setting	Operation setting Independent		Independent	
			Data bit	Set according to the target S device. device.	Set according to the target device.	
			Parity bit			
			Odd/even parity			
			Stop bit			
			Sum check code			
			Online change			
			Setting change			
		Station number setting (CH1, 2 in	common: 0 to 31)	Set arbitrary value for data communication using the MC protocol or for multidrop connection when MELSOFT connection is selected.		

#### Data flow in independent operation

Two interfaces operate independently according to the settings in the parameter settings "Basic Settings".

C24 (data flow in independent operation)





### **21.2** Setting and Data Flow of Interlink Operation

During the interlink operation, all data received from either one of the two interfaces is transmitted to the other interface.

```
Point P
```

When two interfaces are in the interlink operation, the transmission time for one character becomes equal to the H/W gate OFF time.

#### Setting

For the interlink operation of two interfaces on C24, configure the parameter setting as shown below.

Setting iter	n		Setting content			
				CH1	CH2	
Basic	Various control	Test mode setting		-		
settings	specification	Communication protocol setting		Set according to the target device.	The setting is configured automatically. (No changing necessary)	
		Communication speed setting			Set according to the target device.	
		Transmission setting	Operation setting	Independent	Interlink	
			Data bit	Set CH1 and CH2 to the same specifications.	Set CH1 and CH2 to the same specifications.	
			Parity bit			
			Odd/even parity			
			Stop bit			
			Sum check code			
			Online change			
			Setting change			
		Station number setting (CH1, 2 in	common: 0 to 31)	Set arbitrary value for data construction or for multidrop control connection is selected.	ommunication using the MC nection when MELSOFT	

#### Data flow in interlink operation

The two interfaces operate interconnectedly using the functions configured in "Communication protocol setting" from "Basic Settings" ⇔ "CH2 side" of module parameter (MC protocol (same format) or nonprocedural protocol) within the transmission specifications set in the respective transmission settings.



#### Precautions

#### When setting to nonprocedural protocol

Exclusive control of the received data is necessary when data is communicated using the nonprocedural protocol since all of the connected stations receive the data.

#### ■When setting to MC protocol

When data communication is performed using the MC protocol, only the C24, of which station number is specified in the massage, performs the process designated by the command.

Furthermore, when data communication is performed with 2C/3C/4C frame of the MC protocol, the header information for interlink operation is added to messages directed to other stations linked by multidrop connection.

- Processing performed by C24 connected to a target device
- C24 adds the header information to the command massages directed to other stations, which was received from the target device, and transmits them to the other stations through the other interface.
- C24 deletes the header information from the response messages received from the other stations, and transmits them to the target device through the other interface. (The header information is also sent during the multidrop connection using the interlink operation setting.)
- Operation of the accessed station
- The accessed station processes the request contained in a command message, adds the header information to a response message, and sends it using the interface that received the command message.

The header information for the interlink operation, which is added by C24 to a message is as shown below. • When communicating with ASCII code (Formats 1 to 4)

The following 13- or 15-character header information is added immediately before the control code (ENQ/ STX/ACK/NAK) at the head of each message (13 characters for Formats 1, 3 and 4; 15 characters for Format 2).

• When communicating in binary mode (Format 5)

The following 10-byte header information is added immediately before the control code (DLE + STX) at the head of each message.



#### Restriction (")

Do not use the above settings for the following cases because the interlink operation cannot be performed.

- When using RJ71C24-R2.
- · When a target device is not connected to either of the interfaces.
- When communicating data using the predefined or bidirectional protocol.
- When communicating data using the modem function.

399

Point P

### Setting example for MELSOFT connection via C24

Examples of the parameter settings for MELSOFT connection via C24 are as shown below.





Setting at station No.0

Setting iter	m		Setting content		
				CH1	CH2
Basic	Transmission	Test mode setting		-	
settings	setting	Communication protocol setting		MELSOFT Connection	-
		Communication speed setting		115200 bps	115200 bps
		Transmission setting	Operation setting	Independent	Interlink
			Data bit	8	8
			Parity bit	Yes	Yes
			Odd/even parity	Odd	Odd
			Stop bit	1	1
			Sum check code	Yes	Yes
			Online change	Enable	Enable
			Setting change	Enable	Enable
		Station number setting (CH1, 2 in	common: 0 to 31)	0	

#### Setting at station No.1

Setting item			Setting content			
				CH1	CH2	
Basic	Transmission	Test mode setting		-		
settings	setting	Communication protocol setting		Set depending on the use	MC protocol (format 5)	
		Communication speed setting			115200 bps	
		Transmission setting	Operation setting		Independent	
			Data bit		8	
			Parity bit		Yes	
			Odd/even parity		Odd	
			Stop bit		1	
			Sum check code		Yes	
			Online change		Enable	
			Setting change		Enable	
		Station number setting (CH1, 2 in	common: 0 to 31)	1		

# 22 PARAMETER REGISTRATION TO CPU MODULE

C24 enables the parameter settings to be saved in the CPU module.

It reduces man-hours for any recovery works since the parameter resetting is not necessary at the time of replacement of C24.

The parameters controlled by the CPU module are as shown below.

Parameters name	Storage location of parameters	File name <sup>*1</sup>
Module parameter	CPU built-in memory (data memory)	UNIT.PRM
Module extended parameter	<ul> <li>Select from the following for each file.</li> <li>CPU built-in memory (data memory)</li> <li>SD memory card installed in the CPU</li> <li>Built-in memory of Intelligent function module (in the flash ROM of C24)</li> </ul>	UEXmmmnn.PRM <sup>*2,*3</sup> UEXmmm00.PPR <sup>*2</sup>

\*1 It indicates a file name to store the parameters in CPU built-in memory or SD memory card.

\*2 The value indicating the head input/output number of the module ÷ 10H (3 digits in hexadecimal) is entered in 'mmm'.

\*3 The sequential serial number of each module, 00 is entered in 'nn'.

For more details on parameters controlled by CPU modules, refer to the following manual.

MELSEC iQ-R CPU Module User's Manual (Application)

The parameters controlled by C24 parameter corresponding to CPU module are as shown below.

Corresponding parameter controlled by CPU module	Parameter of C24		Remarks	
Module parameter	Basic settings	Various control specification	-	
	Application settings	User frame specification	"User frame contents" is stored in the module extended parameter.	
		Modem function setting	"Modem initialization data" and "Modem connection data" are stored in the module extended parameters.	
		Programmable controller CPU	-	
		monitoring function designation		
	Interrupt setting	js	—	
	Refresh setting		—	
Module extended parameter	User frame con	itents	File name: UEXmmmnn.PRM	
	Modem initializa	ation data		
	Modem connect	tion data		
	Protocol setting	y data	File name: UEXmmm00.PPR This is set with the Predefined protocol support function of Engineering tool.	

Each file of module extended parameters held in the CPU module is given priority over the one in the flash ROM of C24. The contents in flash ROM of C24 is replaced with the contents of module extended parameters registered in the CPU module by powering OFF  $\rightarrow$  ON or switching the CPU module STOP  $\rightarrow$  RUN after the module extended parameters were registered in the CPU built-in memory or SD memory card.

#### **Deleting module extended parameters**

The following explains how to delete each file of module extended parameters.

#### Deleting module extended parameter "UEXmmmnn.PRM"

It can be deleted by the following procedure.

- **1.** Place the CPU module in the STOP state.
- **2.** On the "Module extended parameter setting " screen for RJ71C24(-R2/4) of Engineering tool, restore the default setting value of module extended parameter.
- 3. Select [Online]⇒[Write to PLC].
- **4.** On the "Online Data Operation" screen, select the checkbox of the corresponding Intelligent function module (C24), and perform the write operation. At this point, the content in the flash ROM of C24 is deleted.
- **5.** On the "Online Data Operation" screen, select the [Delete] tab. When there are module extended parameters on the CPU module, "Module extended parameter: mmmm<sup>\*1</sup>" is displayed on the [Parameter] in the tree. Select the checkbox and perform the delete operation. By performing this operation, the module extended parameter on the CPU module is deleted.
- 6. Return the CPU module to the RUN state as necessary.
- \*1 The 'mmmm' indicates the head input/output number of the module.

#### ■Deleting module extended parameter "UEXmmm00.PPR"

It can be deleted by the following procedure.

- **1.** Place the CPU module in the STOP state.
- 2. Start the Predefined protocol support function from the [Tool] menu of Engineering tool.
- 3. Select [Module Write] from the [Online] menu without adding protocol.
- **4.** On the "Module Write" screen, select "Intelligent Function Module" as the target memory, and perform the write operation. At this point, the content in the flash ROM of C24 is deleted.
- 5. After the step 4 above, select [Online] → [User Data] → [Delete] of Engineering tool. The "User Data Operation" screen is displayed.
- **6.** When there are module extended parameters on the CPU module, user data "UEXmmm00.PPR<sup>\*1</sup>" is displayed. Select the checkbox and perform the delete operation. By performing this operation, the module extended parameter on the CPU module is deleted.
- 7. Return the CPU module to the RUN state as necessary.
- \*1 The value indicating the head input/output number of the module ÷ 10H (3 digits in hexadecimal) is entered in 'mmm'.

# 23 RS-422/485 INTERFACE ECHO BACK ENABLE/ PROHIBIT SPECIFICATION

This chapter explains the echo back enable/prohibit specification.

This function can be used for the both interfaces on RJ71C24(-R4).

The echo back function is a function that transmitted data is also sent to RDA or RDB on the host station when data communication is performed through RS-458 (2-wire type) from RS-422/485 interface.

Whether to receive the returned data or not (discard) can be specified.



Receives or not receiv (discards) the data.

#### Application

- Disabling the echo back will eliminate the processing to ignore unnecessary data, which has been programmed for nonprocedural protocol communication.
- When the same message format is used for a request (command) and a response of the target device protocol during data communication using the predefined protocol, disabling the echo back function can enable data communication with the target device.

#### Setting method

· Setting by engineering tool

Set "Echo back enable/prohibit specification" to "Echo back enable" or "Echo back prohibit".

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings" ⇒ "Various control specification"

· Setting by a program

In the 'RS-422/485 interface echo back enable/prohibit specification' (Un\G290/450), store either of the following values. (Default: 0)

Setting value	Description
0: Echo back enable	When C24 transmits data, it also receives the transmitted data with its own RDA or RDB.
1: Echo back prohibit	When C24 transmits data, it does not receive the transmitted data with its own RDA or RDB. (The data is discarded.)

#### Precautions

The setting for the echo back enable/prohibit specification must be configured before sending data. Any setting changed during transmission does not take effect.

# 24 ERRONEOUS NOISE SIGNAL RECEPTION PREVENTION FUNCTION

This chapter explains the erroneous noise signal reception prevention function of C24.

### 24.1 Erroneous Noise Signal Reception Prevention Function

Depending on the device to be connected to C24, noise signals may be added on the line when turning ON the power or connecting cables of the device.

When noise signals are added, C24 falsely recognizes it has received improper data, and discards the data resulting in abnormal detection.

Using this function avoids erroneous noise signal reception.

This function is set in the module parameter and the 'Communication data reception enable/disable designation' (Un\G292/ 452).

Configure the setting to disable the reception with the parameter settings of Engineering tool, and set the buffer memory to 'Receive enable' (0) at a certain time before starting data reception after powering ON.



# 24.2 Setting for the Erroneous Noise Signal Reception Prevention Function

The setting procedure to use the erroneous noise signal reception prevention function is shown below.

**1.** Setting to disable the reception with Engineering tool

Set "Communication data reception enable/disable designation" to "Receive disable".

Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ "Module Name" ⇔ [Module Parameter] ⇔ "Basic Settings" ⇔ "Various control specification"

**2.** Setting to enable the reception by a program

Set the following buffer memory to 'Receive enable' (0) with a program at the timing when the serial line is settled.

Channel	Address	Setting value
CH1	Un\G292	0: Receive enable
CH2	Un\G452	1: Receive disable

#### Precautions

• Once the erroneous reception prevention designation area of noise signal is set to 'Receive disable' (1), normal data is not received as well.

Set the erroneous reception prevention designation area of noise signal to 'Receive enable' (0) promptly after the serial line has been settled.

Once it is set to 'Receive enable', it cannot be set to 'Receive disable' unless powering ON again or resetting the CPU module.

# **25** AUTOMATIC REMOVAL OF NULL CHARACTERS INCLUDED IN SEND DATA

This chapter explains the automatic removal of NULL characters in data transmission of C24.

### 25.1 Automatic Removal of NULL Characters during Data Transmission

The automatic removal of NULL characters during data transmission is a function to automatically delete NULL characters included in data transmitted to a target device from C24.



### 25.2 Setting for NULL Character Automatic Removal Function

The setting to C24 is required before data transmission in order to enable the NULL character automatic removal function for data to be transmitted using the nonprocedural protocol and the bidirectional protocol.

The settings to delete NULL characters automatically are shown below.

- The settings for automatic removal of NULL characters can be configured for each interface.
- To perform the NULL characters automatic removal function, set "NULL character automatic removal designation" to "Auto delete enabled".
- Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ "Module Name" ⇒ [Module Parameter] ⇒ "Basic Settings"
  ⇒ "Various control specification"

### 25.3 NULL Character Removal to Send Data using Nonprocedural Protocol

This section explains automatic removal of NULL characters to data to be transmitted using the nonprocedural protocol.

#### Target range of automatic removal of NULL characters

The send data range to which automatic removal of NULL characters is performed is as shown below:

· Transmitting data in arbitrary format



· Transmitting data with user frame



When data is transmitted, C24 performs the processing as follows:

C24 deletes NULL characters (data code: 00H) included in the data specified by the CPU module (arbitrary data portion in a transmission message) or a user frame portion, and transmits data.

NULL characters (00H) included in the send data in the buffer memory (send area) are deleted from the actual data to be transmitted.



To transmit data without removing NULL characters included in arbitrary user frame portion or the send area on the buffer memory when 0001H (Auto delete enabled) is set for NULL character automatic removal designation for transmitting data for data transmission with a user frame, designate the user frame number as shown below.

• Specify the number obtained by adding 4000H to the registered user frame No.



When sending data in the portions designated in 4001H to 44AFH, C000H to C01FH, the data is transmitted without conversion even when the following designations are enabled.

- Specifying an additional code by the transparent code for sending specification ( Page 326 TRANSPARENT CODES AND ADDITIONAL CODES)
- Designating "Enable" in the ASCII-BIN conversion designation area ( Page 347 COMMUNICATING WITH ASCII CODE (ASCII-BIN CONVERSION))

User frame number to be transmitted	User frame designation number to transmit data without removing NULL characters (4000H added)
1H to 3E7H ( 1 to 999)	4001H to 43E7H ( 16385 to 17383)
3E8H to 4AFH ( 1000 to 1199)	43E8H to 44AFH ( 17384 to 17583)
8000H to 801FH (-32768 to -32737)	C000H to C01FH (-16384 to -16353)



## 25.4 Program Example

This examples of data communication using the nonprocedural protocol are shown below.

# Program example of data communication using the nonprocedural protocol

This section shows program examples of data communication using the nonprocedural protocol when the settings/ registrations are made with Engineering tool.

#### Parameter setting

For details for each setting item, refer to the parameters. (SP Page 422 PARAMETER SETTING)

ltem				Setting conten	t	Remarks	
				CH1	CH2		
Basic	Various control	Test mode setting		—	CH2 is not used	—	
settings	specification	Communication protocol setting	Nonprocedural protocol				
		Communication speed setting		Set according to the target device	-		
		Transmission setting	Operation setting	Independent			
			Data bit	Set according to			
			Parity bit	the target device			
			Odd/even parity				
			Stop bit				
			Sum check code				
			Online change				
			Setting change				
		Station number setting (CH1, 2 in con	—				
		Communication control specification	NULL character automatic removal designation	Auto delete enabled			
Applicatio n settings	User frame specification	Send user frame designation	Send frame number designation (1st)	43F2H		Arbitrary registered data	
			Send frame number designation (2nd)	43F3H			
			Send frame number designation (3rd)	C001H			
				8000H		Buffer memory designation	
			Send frame number designation (5th)	441BH		Arbitrary registered data	

#### Example of arbitrary data transmission

C24 transmits a string data using the NULL character automatic removal function to the target device.



#### ■Program example

Category	Label name			escription		Device	
Module label	C24_1			rget module		—	
Label to be defined	Define the global label as shown below.						
	Label Name           1         bReq_Transmission           2         wTransmissionChannel           3         wTransmissionDataCount           4         wmTransmissionDataCount           5         bReq_OUTPUTInstructionTransmission           6         bOUTPUTInstructionTransmissionNormalCompletion	Data Type Bit Word [Unsigned]/Bit String [16-bit] Word [Unsigned]/Bit String [16-bit] Word [Signed](0.3) Bit Bit	· · · · · · · · · · · · · · · · · · ·	Class VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL	Assign (Device/Label) X50 D1 D2 D10 M10 M0		
	bDUTPUTInstructionTransmissionAbnormalCompletion     bDUTPUTInstructionTransmissionExecution     wErrorCode     bNormalCompleteFlag     bAbnormalCompleteFlag	Bit Bit Word [Unsigned]/Bit String [16-bit] Bit Bit	···· ···· ···	VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL VAR_GLOBAL V	M1 M2 D3 M100 M101		

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

	bReg Transmission							
(0)	×50					MOVP	K1	w I ransmission Channel
								וט
							KA	
						MOVP	154	wiransmissionDataGount
						-		02
Î							″100″	TuonomiasianData[0]
						\$MOVP	120	D10
							"ABC"	wnTransmissionData[2]
						\$MOVP	1.50	D12
								bReg OUTPUTInstructionTr
							SET	ansmission M10
			M R 171024 Output 000 1	(M+R-171024 Output 000 )				
20)			Outpu	it FB				
ь	Req_OUTPUTInstructionTr ansmission M10		BibEN	o hENO/B				bOUTPUTInstruction Fransm issionExecution M2
			D.DEN	0_00100.0				<u> </u>
		C24_1						bOUTPUTInstructionTransm issionNormalCompletion M0
F			DUT:i_stModule	o_bOK:B				O
		wTransmissionCh annel						bOUTPUTInstructionTransm issionAbnormalCompletion M1
		[ D1 ]	UW:i_uCh	o_bErr:B				0
		wTransmissionDa			wErrorCo			
-		[ D2 ]	UW:i_uSendDataLength	o_uErrId:UW	-[°D3]	_		
		wnTransmissionD ata[0]						
H		[ D10 ]	UW:i_uSendData					
E	oOUTPUTInstructionTrans		1					
65)	missionNormalCompletion M0						SET	bNormalCompleteFlag M100
	OUTPUThetructionTrans							
m	hissionAbnormalCompletion						OFT	bAbnormalCompleteFlag
~							SET	M101
39)								

(0) Set the transmission channel to CH1. Set the send data quantity to 4. Set the data to be transmitted. Set the transmission direction.

(65) Normal completion

(67) Abnormal completion

#### Example of transmission using user frame

C24 transmits a string data using the NULL character automatic removal function to the target device.

Ex. Transmitting given data in combination with a user frame with PRR dedicated instruction



#### ■Program example

Category	Label name	Description	Device
Module label	C24_1	Target module	—
Label to be defined	Define the global label as shown below.		

	Label Name	Data Type	Class		Assign (Device/Label)
1	bReq_Transmission	Bit	 VAR_GLOBAL	•	×50
2	wTransmissionChannel	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	٠	D1
3	wCR_LF_OutputDesignation	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D2
4	wTransmissionPointer	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D3
5	wOutputCount	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	•	D4
6	wnTransmissionData	Word [Signed](04)	 VAR_GLOBAL	-	D10
7	bUserFlameTransmissionNormalCompletion	Bit	 VAR_GLOBAL	-	MO
8	bUserFlameTransmissionAbnormalCompletion	Bit	 VAR_GLOBAL	Ŧ	M1
9	UserFlameTransmissionExecution	Bit	 VAR_GLOBAL	Ŧ	M2
10	bNormalCompleteFlag	Bit	 VAR_GLOBAL	Ŧ	M100
11	bAbnormalCompleteFlag	Bit	 VAR_GLOBAL	Ŧ	M101
12	wErrorCode	Word [Unsigned]/Bit String [16-bit]	 VAR_GLOBAL	Ŧ	D20
13	bReg PRRInstructionTransmission	Bit	 VAR GLOBAL	•	м10

For information on the module FB to be used, refer to the following manual.

	bReq_Transmission					ŕ		K4	T 0
(0)	X50						MOVP	KI	w I ransmissionChannel
									D1
		 			· · · · · · · · · · · · · · · · · · ·				
						ſ	MOVP	К0	wCR_LF_OutputDesignatio
		 	-				moti		D2
						ſ		K1	wTransmissionPointer
			-				MOVP		D3
						ĺ		K5	wOutputCount
							MOVP		D4
						1			
						ſ		KA	wnTransmissionData[0]
							MOV		wirinansinissionibata[o]
									DIU
								11	
							\$MOVP	123	wnTransmissionData[1]
			1						D11
						[	\$MOV/D	"ABC"	wnTransmissionData[3]
							\$WOVE		D13
					]	DMG	wnTransmissi	C24_1.stnCH1.uSet_Trans	К3
		 				BWOAD	onData[0] D10	missionDataGount_D U0¥G1024	
						ſ		H1	C24_1.wnForUserRegistrati
							MOVP		onNo8001H_D[0] U0¥G6912
						ŀ			
						ſ		H2D	C24.1 wnForl learBagistrati
							MOVP	1110	onNo8001H_D[1]
									00#G6913
								SET	bReq_PKRInstruction I rans mission
									M10
			M_RJ71C24_SendUserFrame_00C_1	(M+RJ71C24_SendUserFrame_00C)					M10
(44)			M_RJ71C24_SendUserFrame_00C_1 Send User	(M+RJ71C24_SendUserFrame_00C) Frame FB					M10
(44)			M_RJ71C24_SendUserFrame_00C_1 Send User	(M+RJ71C24_SendUserFrame_00C) Frame FB					M10
(44)	bReq_PRRInstructionTrans mission		M_RJ71C24_SendUserFrame_00C_1 Send User	(M+RJ71C24_SendUserFrame_00C) Frame FB					M10 UserFlameTransmissionEx eoution
(44)	bReq_PRRInstructionTrans mission M10		M,RJ71C24_SendUserFrame_00C_1 Send User	(M+RJ71C24_SendUserFrame_00C) Frame FB					M10 UserFlameTransmissionEx ecution M2
(44)	bReq_PRRInstructionTrans mission M10 I		M.R.J71C24_SendUserFrame_00C_1 Send User BijbEN	(M+RJ71C24_SendUserFrame_00C) Frame FB o_bENO-B					M10 UserFlameTransmissionEx ecution M2 O
(44)	bReq_PRRInstructionTrans mission MIO		M.RJ71C24_SendUserFrame_000C.1 Send User BijbEN	(M+RJ71C24_SendUserFrame_00C) Frame FB ojENO:B					M10 UserFlameTransmissionEx ecution M2 OUserFlameTransmissionN ormalCompletion
(44)	bReq_PRRInstructionTrans mission MIO	C24.1	M_RJ71C24_SendUserFrame_00C.1 Send User B: JJEN	(M+RJ71C24_SendUserFrame_00C) Frame FB o_bENO B					M10 UserFlameTransmissionEx ecution M2 O bUserFlameTransmissionN ormalCompletion M0
(44)	bReg_PRRInstructionTrans mission M10		M_RJ71C24_SendUserFrame_D0C_1 Send User B:j_bEN DUT:j_stModule	(M+RJ71C24_SendUserFrame_00C) Frame FB о_bENO-B о_bENO-B					MT0 UserFlameTransmissionEx ecution M2 O bUserFlameTransmissionN ormalCompletion O
(44)	bReg-PRRinstructionTrans Mission H I	( <sup>224,1</sup> }	M.RJ71C24_SendUserFrame_000C_1 Send User BijbEN DUTijstModule	(M+RJ71C24_SendUserFrame_00C) Frame FB o_bENO:B o_bOKB					MID UserFlameTransmissionEx ecution M2 bUserFlameTransmissionA bUserFlameTransmissionA
(44)	bRegPRRInstructionTrans mission III	C24_1 } wTransmissio nOhannel	M.RJ71C24_SendUserFrame_000_1 Send User B.j.bEN DUT:i_stModule	(M+RJ71C24_SendUserFrame_00C) Frame FB o_bENO.B o_bOK.B					MIO UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN 00 bUserFlameTransmissionA boromalCompletion
(44)	bReg_PRRInstructionTrans mission M10 I I	C24.1 } v Transmissio r Cohannel L D }	M_RJ71C24_SendUserFrame_00Q_1 Send User B3_bEN DUT3_stModule	(M+RJ71C24_SendUserFrame_00C) Frame FB စ_bENO B စ_bOKB ၀_bErr-B					MT0 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN ormalCompletion M bUserFlameTransmissionA bnormalChapletion
(44)	bReg_PRRInstructionTrans mission MIO I	C24.1 } 	M_RJ71C24_SendUserFrame_D0C_1 Send User BijbEN DUT:ijstModule UWELuCh	(M+RJ71C24_SendUserFrame_00C) Frame FB o_bENO:B o_bOKB o_bErrB					MT0 UserFlameTransmissionEx ecution M2 DUserFlameTransmissionN bUserFlameTransmissionA bormalCompletion M1
(44)	bRegPRRInstructionTrans mission MIO	C24.1 } wTransmissio rOtannel [ D1 ] wORLFOLD uDDsimption	M.RJ71C24_SendUserFrame_00Q_1 Send User BijbEN DUTSijstModule UWLjuCh	(M+RJ71C24_SendUserFrame_00C) Frame FB oj:ENO:B oj:OK:B oj:Err:B	werrorCo de				MT0 UserFlameTransmissionEx ecution MC bUserFlameTransmissionN ormalCompletion bUserFlameTransmissionA boromalCompletion M
(44)	bRegPRRInstructionTrans mission MIG I	C24,1 wTransmissio nChannel [ D1 ] wCRLF_Outp uCRLF_Outp uCRLF_Outp uCRLF_Outp	M_RJ71C24_SendUserFrame_00Q_1 Send User BijbEN DUT:jstModule UW:juCh	(M+RJ71C24_SendUserFrame_00C) Frame FB စ_bENO-B ၀_bOK-B ၀_bErrB	wErrorCo				MT0 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN ormalCompletion buserFlameTransmissionA bnormalCompletion M0
(44)	bRegPRRInstructionTrans mission MIO I	C24.1 } wTransmissio Cohannel D ] } wORLF-Outp utDesignation D 2 }	M_RJ71C24_SendUserFrame_00Q_1 Send User B3_DEN DUT3_stModule UW4_uCh	(M+RJ71C24_SendUserFrame_00C) Frame FB ၀.bENO B ၀.bENO B ၀.bErr-B ၀.bErr-B	wErrorCo de [ D20 ]-				MIO UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN bUserFlameTransmissionA bloserFlameTransmissionA
(44)	bReg-PRRInstructionTrans mission 	C24.1 } wTransmissio rothumrel D 1 J utDesignation D 2 ] wTransmissio	M.RJ71C24_SendUserFrame_00Q_1 Send User BijbEN DUT:jstModule UW:LuCh UW:LuCrLfSetting	(M+RJ71C24_SendUserFrame_00C ) Frame FB ့bENO:B ့bOKB ့bCKB ့bErr:B	wērrorCo de [ D20 ]-				MT0 UserFlameTransmissionEx ecution M2 DUserFlameTransmissionN bUserFlameTransmissionN bUserFlameTransmissionA bnormalCompletion MT
(44)	bRegPRRInstructionTrans mission 	C24.1 [ ] wTransmissio nOhannel [ D1 ] wORLF_Outp uDesignation [ D2 ] wTransmissio nPointer [ D3 ]	M.RJ71C24_SendUserFrame_DOC_1 Send User BijbEN DUTSjstModule UWEjuCh UWEjuCh	(M+RJ71C24_SendUserFrame_00C ) Frame FB စ_bENO.B ၀_bOK.B ၀_bCKB ၀_bErrFB	wErrorCo de -{ D20 }-				M10 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionA m00 bUserFlameTransmissionA buserFlameTransmissionA buserFlameTransmissionA
(44)	bRe_PRRInstructionTrans mission II	C24_1 wTransmissio nChannel [ D1 ] wCRLF_Outp utDesignation [ D2 ] wTransmissio nPointer [ D3 ]	M_RJ71C24_SandUserFrame_00Q_1 Sand User BijbEN DUT:jstModule UW:juCh UW:juCrLfSetting UW:juSendFramePointer	(M+RJ71C24_SendUserFrame_00C ) Frame FB ၀၂၁ENO-B ၀၂၁OK-B ၀၂၁ErrB ၀၂၁ErrB	wErrorCo de [ D20 ]-				MT0 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN ormalCompletion botserFlameTransmissionA botserFlameTransmissionA botserFlameTransmissionA
(44)	bReg_PRRInstructionTrans mission IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	C24.1 ] wTransmissio Cohannel D ] } wORLF-Outp utDesignation Pointe D 2 ] wTransmissio nPointe D 3 ] wOutputCoun	M_RJ71C24_SandUserFrame_00Q_1 Send User B3_bEN DUT3_stModule UW4_LuCh UW4_LuCh UW4_LuCh	(M+RJ71C24_SendUserFrame_00C) Frame FB ၀.bENO-B ၀.bENO-B ၀.bErr-B ၀.pErr-B					MID UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN bUserFlameTransmissionA bnormalCompletion M
(44)	bRegPRRInstructionTrans Million H	C24_1 } wTransmissio nOhannel [ D1 ] wORLF-Outp uDasignation D2 ] wTransmissio nPointer [ D3 ] wOutputCoun	M.RJ71C24_SendUserFrame_00Q_1 Send User BijbEN DUTSjstModule UW:juCh UW:juCh UW:juGendFramePointer	(M+RJ71C24,SendUserFrame_00C ) Frame FB ၀.jtENO:B ၀.jtENO:B ၀.jtENO:B ၀.jtErrB ၀.jtErrB	    				MI0 UserFlameTransmissionEx ecution MC bUserFlameTransmissionA buserFlameTransmissionA bormalCompletion bUserFlameTransmissionA
(44)	bRegPRRInstructionTrans mission 	C24_1 C24_1 Transmissio rrOhannel rrOhannel rrOhannel work_LF_Outp utDesignation Pointer Pointer Pointer Pointer D3 } wotputCoun t D4 }	M.RJ71C24_SendUserFrame_00Q_1 Send User BijbEN DUTijstModule UWijuCh UWijuCrLfSetting UWijuSendFramePointer UWijuSendFrameCount	(M+RJ71C24_SendUserFrame_00C) Frame FB օ.յեΝΟ.Β օ.յեΝΟ.Β օ.յեΟK.Β օ.յեFrrB	wErrorCo -f <sup>e</sup> 020 }-				MI0 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN M0 bUserFlameTransmissionA buserFlameTransmissionA buserFlameTransmissionA
(44)	bRegPRRInstructionTrans mission II	C24,1 wTransmissio nChannelsio nChannelsio nChannelsio nChannelsio nChannelsio nChannelsio nPointe wTransmissio nPointe D2 } wTransmissio nPointe D3 } wOutputCoun L D4 }	M_RJ71C24_SandUserFrame_00Q_1 Sand User BijbEN DUT:jatModule UW:juCh UW:juCnLfSetting UW:juSendFramePointer UW:juSendFrameCount	(M+RJ71C24_SendUserFrame_00C ) Frame FB ၀.၆ENO-B ၀.၆OK-B ၀.၆CFrB ၀.၂JErrld:UW					MT0 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN ormalCompletion buserFlameTransmissionA bormalCompletion M1 bormalCompletion M1 bormalCompleter buserFlameTransmissionA
(44)	bReg-PRRInstructionTrans Mito Mito H I bUserFlameTransmissionN ormalCompletion Mito	C24.1 } wTransmissio mChannel tD1 } wCRLF.Outp ucDesignation [ D2 ] wTransmissio nPointer nPointer D3 } wOutputCoun t D4 }	M.RJ71C24_SendUserFrame_D0Q_1 Send User BijbEN DUT:jstModule UW:LuCh UW:LuCrLfSetting UW:LuSendFramePointer UW:LuSendFrameCount	(M+RJ71C24_SendUserFrame_00C) Frame FB ၀.bENO-B ၀.bOKB ၀.bErr-B ၀.uErrld:UW	wErrorCo de -[ D20 ]-			SET	MID UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN bUserFlameTransmissionN butterFlameTransmissionN M butterFlameTransmissionN M bnormaCompleteFlag MUO
(44)	bRegPRRInstructionTrans mission I I I I bUserFlame TransmissionN ormalCompletion I I	C24.1 } wTransmissio nChannel [ D1 ] wCRLF-Outp ucDesignation nPointer [ D3 ] wOutputCoun [ D4 ]	M.RJ71C24_SendUserFrame_D0C_1 Send User BijbEN DUTSjstModule UW:juCh UW:juCh UW:juCh UW:juCendFramePointer UW:juSendFrameCount	(M+RJ71C24,SendUserFrame_00C ) Frame FB စ.jtENO:B ၀.jtOK:B ၀.jtOK:B ၀.jtErrfB	wErrorCo de -[ D20 ]-			SET	MI0 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionA bus
(44)	bRegPRRInstructionTrans mission MIO I I I I I I I I I I I I I I I I I I	C24_1 wTransmissio rrOhanet [ D1 ] wORLF_Outp uOBesignation [ D2 ] wTransmissio nPointer [ D3 ] wOutputCoun t [ D4 ]	M.RJ71C24_SendUserFrame_DOQ.1 Send User BijbEN DUTi_stModule UWLuCh UWLuCh UWLuSendFramePointer UWLuSendFrameCount	(M+RJ71C24_SendUserFrame_00C ) Frame FB ၀.၆ENO.B ၀.၆OK.B ၀.၆ErrB ၀.µErrld.UW	wErrorCo			SET	M10 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN ormalCompletion bUserFlameTransmissionA bormalCompletion bNormalCompleteFlag M100
(44)	bRegPRRInstructionTrans mission MIQ I bUserFlameTransmissionN ormalCompletion M0 I bUserFlameTransmissionA bormalCompletion	C24,1 wTransmissio nChanomi I D1 } wCRLF_Outp uCDesignation [ D2 ] wTransmissio nPointer D3 ] wTransmissio nPointer D3 ] wOutputCoun [ D4 ]	M_RJ71C24_SendUserFrame_00Q_1 Send User BijbEN DUT:jstModule UW:juCh UW:juCrLfSetting UW:juSendFramePointer UW:juSendFrameCount	(M+RJ71C24_SendUserFrame_00C) Frame FB o_bENO-B o_bOKB o_bOKB o_bErrB o_uErrld:UW	    			SET	MID UserFlameTransmissionEx ecution M2 DuserFlameTransmissionN ormalCompletion buserFlameTransmissionA bormalCompletion MID bNormalCompleteFlag MID0 bAbnormalCompleteFlag
(44) (91) (93)	bReg PRRInstruction Trans Mission Min H bluserFlame TransmissionN ormalCompletion bUserFlame TransmissionA bluserFlame TransmissionA bluserFlame TransmissionA	C24.1 } w Transmissio rothannel L D1 } w ORLF-Outp utDesignation 	M.RJ71C24_SendUserFrame_00Q_1 Send User DIT:jstModule UW:LuCh UW:LuCrLfSetting UW:LuSendFramePointer UW:LuSendFramePointer	(M+RJ71C24,SendUserFrame_00C ) Frame FB ၀.bENO:B ၀.bOK:B ၀.bErr:B	 werrorCo de -{ D20 }-			SET	MID UserFlameTransmissionEx ecution MQ bUserFlameTransmissionA ormalCompletion MO bUserFlameTransmissionA bnormalCompletion MID bNormalCompleteFlag MID0
(44)	bRegPRRInstructionTrans mission I I I I I I I I I I I I I I I	C24.1 } wTransmissio r/Channel LD1 } wORLF-Outp ucDesignation r/Pointer D3 } wOutputCoun LD4 }	M.RJ71C24_SendUserFrame_00C_1 Send User BijbEN DUTSjstModule UW:juCh UW:juCh UW:juCh UW:juCh UW:juSendFramePointer UW:juSendFrameCount	(M+RJ71C24,SendUserFrame_00C) Frame FB ojtENO:B ojtENO:B ojtENO:B ojtENO:B ojtENO:B ojtENO:B	werrorCo de -[ D20 ]-			SET	MI0 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionA buserFlameTransmissionA bormalCompletion buserFlameTransmissionA bormalCompleteFlag M100 bAbnormalCompleteFlag M101
(44)	bRegPRRInstructionTrans mission Mi0 I I I I I I I I I I I I I I I I I I I	C24_1 wTransmissio rrOhanet [ D1 ] wORLF_Outp wORLF_Outp releasing atom Pointer [ D3 ] wOutputCoun t [ D4 ]	M.RJ71C24_SendUserFrame_DOC_1 Send User BijbEN DUT:jstModule UW:juCh UW:juCh UW:juSendFramePointer UW:juSendFrameCount	(M+RJ71C24_SendUserFrame_DOC) Frame FB o_bENO.B o_bOK.B o_bOK.B o_bErrB o_uErrld.UW	wErrorCo			SET	M10 UserFlameTransmissionEx ecution M2 bUserFlameTransmissionN ormalCompletion bUserFlameTransmissionA bormalCompletion bNormalCompleteFlag M100 bAbnormalCompleteFlag M101
(44) (91) (93) (95)	bRegPRRInstructionTrans Milon I I I I I I I I I I I I I I I I I I I	C24,1 WTransmissio nChannel [ D1 ] WORLE-Outp uDesignation [ D2 ] WTransmissio nFointer [ D3 ] WOutputCoun t D4 ]	MRJ71C24_SandUserFrame_00Q_1 Sand User DJTSijsEN DUTSijstModule UWSLuCh UWSLuCh UWSLuCrLfSetting UWSLuSendFramePointer UWSLuSendFrameCount	(M+RJ71C24_SendUserFrame_00C) Frame FB o_bENO:B o_bENO:B o_bENO:B o_bERO:B o_bErrB o_uErrld:UW	wErrorCo			SET	MID UserFlameTransmissionEx ecution M2 bluserFlameTransmissionN ormalOmpletion bluserFlameTransmissionA bnormalCompleteFlag M100 bAbnormalCompleteFlag M101

Set the transmission channel to CH1.
 Set CR/LF to "Do not send".
 Set the send pointer to 1.
 Set the output quantity to 5.
 Set the send data quantity to 4.
 Set the data to be transmitted from D11.
 Set an arbitrary send data in send buffer.
 Set the transmission direction.

(91) Normal completion

(93) Abnormal completion

### 25.5 NULL Characters Removal for Send Data using Bidirectional Protocol

This section explains automatic removal of NULL characters to data to be transmitted using the bidirectional protocol.

#### Target range of automatic removal of NULL characters

The send data range to which automatic removal of NULL characters is performed is as shown below. However, the automatic removal of NULL characters is not performed when a response message is transmitted.



\*NULL characters automatic deletion is disabled when transmitting a response message.

When data is transmitted, C24 performs the processing as follows:

· Range of automatic removal of NULL characters

C24 performs the automatic removal of NULL characters to an arbitrary data portion of a message (data length is not included).

- Automatic removal of NULL characters in data portion
   C24 deletes NULL characters included in send data, and then transmits data.
- · Handling of sum check code

The results of adding the data portion after automatic removal of NULL characters as binary code data are added to the transmission message as sum check code.



\*1 Calculation of sum check code is shown below:

06H+00H+31H+32H+33H+41H+42H+43H=0162H (H) (L)

#### Precautions

When the automatic removal of NULL characters is performed to data transmitted using the bidirectional protocol, always specify the "Word/byte units designation" to "Byte units".

Ex. Example of data transmission after automatic removal of NULL characters using the bidirectional protocol



## 25.6 Program Example

The examples of data communication using the bidirectional protocol are shown below.

# Program example of data communication using the bidirectional protocol

This section shows program examples data communication using the bidirectional protocol when the settings/registrations are made with Engineering tool.

#### parameter setting

For details for each setting item, refer to the parameters. (F Page 422 PARAMETER SETTING)

Setting it	tem			Setting content		
				CH1	CH2	
Basic Various	Various	Test mode setting	—	CH2 is not used		
settings	control	Communication protocol setting		Bidirectional protocol		
	specification	Communication speed setting	Set according to the target device			
		Transmission setting	Operation setting	Independent		
			Data bit	Set according to the		
			Parity bit	target device		
			Odd/even parity			
			Stop bit			
			Sum check code			
			Online change			
			Setting change			
		Station number setting (CH1, 2 in commo	n: 0 to 31)	-		
		Communication control specification	NULL character automatic removal designation	Auto delete enabled		
			Word/byte units designation	Byte unit		

#### Example of data transmission

C24 transmits a string data using the NULL character automatic removal function to the target device.

#### Ex.

Transmitting given data with BIDOUT dedicated instruction



#### ■Program example

Label name			Description				Device	
C24_	C24_1			Target module				—
Defin	e the global label as shown below.							
	Label Name	Data Type		Class		Assign (Device/Label)		
1	bReq_Transmission	Bit		VAR_GLOBAL	-	×50		
2	wTransmissionChannel	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	-	D1		
3	wTransmissionDataCount	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	-	D2		
4	wnTransmissionData	Word [Signed](03)		VAR_GLOBAL	-	D10		
5	bReq_OUTPUTInstructionTransmission	Bit		VAR_GLOBAL	-	M10		
6	bOUTPUTInstructionTransmissionNormalCompletion	Bit		VAR_GLOBAL	-	MO		
7	bOUTPUTInstructionTransmissionAbnormalCompletion	Bit		VAR_GLOBAL	-	M1		
8	bOUTPUTInstructionTransmissionExecution	Bit		VAR_GLOBAL	-	M2		
9	wErrorCode	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	-	D100		
10	bNormalCompleteFlag	Bit		VAR_GLOBAL	-	M100		
11	bAbnormalCompleteFlag	Bit		VAR_GLOBAL	•	M101		
	Labo C24_ Defin 1 2 3 4 5 6 7 7 8 9 10 11	Label name           C24_1           Define the global label as shown below.           1         bReq_Transmission           2         wTransmissionChannel           3         wTransmissionData           5         bReq_OUTPUTInstructionTransmission           6         bUUTPUTInstructionTransmissionAstormalCompletion           7         bOUTPUTInstructionTransmissionExecution           8         bOUTPUTInstructionTransmissionExecution           9         wErrorCode           10         bNormalCompleteRing           11         bAbnormalCompleteRing	Label name         C24_1         Define the global label as shown below.         1       bReg_Transmission       Bit         2       wTransmissionCharnel       Word [Unsigned]/Bit String [16-bit]         3       wTransmissionData       Word [Unsigned]/Bit String [16-bit]         4       wmTransmissionData       Word [Unsigned]/Bit String [16-bit]         5       bReg_OUTPUTInstructionTransmission       Bit         6       bOUTPUTIInstructionTransmissionAbnormalCompletion       Bit         7       bOUTPUTIInstructionTransmissionExecution       Bit         8       bOUTPUTIInstructionTransmissionExecution       Bit         9       wErrorCode       Word [Unsigned]/Bit String [16-bit]         10       bNormalCompleteFlag       Bit         11       bAbnormalCompleteFlag       Bit	Label name         D           C24_1         Ta           Define the global label as shown below.         Ta           1         bReq_Transmission         Bit           2         wTransmissionCharnel         Word [Unsigned]/Bit String [16-bit]            3         wTransmissionDataCount         Word [Unsigned]/Bit String [16-bit]            5         bReq_DUTPUTInstructionTransmissionNermalCompletion         Bit            6         b0UTPUTInstructionTransmissionExecution         Bit            7         b0UTPUTInstructionTransmissionExecution         Bit            9         wErrorCode         Word [Unsigned]/Bit String [16-bit]            10         bNormalCompleteTag         Bit	Label name         Description           C24_1         Target modu           Define the global label as shown below.         Target modu           1         bReg_Transmission         Bit	Label name         Description           C24_1         Target module           Define the global label as shown below.            1         bReg_Transmission         Bit	Label name     Description       C24_1     Target module       Define the global label as shown below.     Data Type       1     bReq_Transmission     Bit       2     wTransmissionChannel     Word [Unsigned/Bit String [16-bit]     VAR_GLOBAL       3     wTransmissionDataCount     Word [Unsigned/Bit String [16-bit]     VAR_GLOBAL       5     bReq_OUTPUTInstructionTransmissionBate     Word [Signed][0.3]     VAR_GLOBAL       6     bUUTPUTInstructionTransmissionBate     Word [Unsigned/Bit String [16-bit]     VAR_GLOBAL       7     bOUTPUTInstructionTransmissionBate     Word [Signed][0.3]     VAR_GLOBAL       8     bOUTPUTInstructionTransmissionBate     Word [Unsigned/Bit String [16-bit]     WAR_GLOBAL       8     bOUTPUTInstructionTransmissionAstormalCompletion     Bit     VAR_GLOBAL     M10       8     bOUTPUTInstructionTransmissionAstormalCompletion     Bit     VAR_GLOBAL     M10       8     bOUTPUTInstructionTransmissionExecution     Bit     VAR_GLOBAL     M10       10     bNormalCompleteFlag     Bit     VAR_GLOBAL     M10       11     bAbnormalCompleteFlag     Bit     VAR_GLOBAL     M100	Label name     Description       C24_1     Target module       Define the global label as shown below.     Data Type     Class     Assign (Device/Label)       1     bReq_Transmission     Bit      VAR_GLOBAL     × X50       2     wTransmissionDataCount     Word [Unsigned//Bit String [16-bit]      VAR_GLOBAL     > D2       3     wTransmissionData     Word [Unsigned//Bit String [16-bit]      VAR_GLOBAL     > D1       5     bReq_OUTPUTInstructionTransmission     Bit      VAR_GLOBAL     > M10       6     bOUTPUTInstructionTransmission/BohmalCompletion     Bit      VAR_GLOBAL     > M10       7     bOUTPUTInstructionTransmission/BohmalCompletion     Bit      VAR_GLOBAL     > M10       8     bOUTPUTInstructionTransmission/BohmalCompletion     Bit      VAR_GLOBAL     > M10       9     wErrorCode     Word [Unsigned//Bit String [16-bit]      VAR_GLOBAL     > M10       10     bAmmalCompleteFlag     Bit      VAR_GLOBAL     > M100       11     bAbnormalCompleteFlag     Bit      VAR_GLOBAL     > M100

For information on the module FB to be used, refer to the following manual.

MELSEC iQ-R Serial Communication Module Function Block Reference

(0)	X50					MOVP	К1	wTransmissionChannel
								D1
						MOVP	K8	wTransmissionDataCount
								D2
						\$MOVP	″123″	wnTransmissionData[0]
						¢mo m		D10
						theory D	"ABC"	wnTransmissionData[2]
						\$MOVP		D12
							057	bReq_OUTPUTInstructionTransm
							SET	M10
				(M.D. 171004 D'F				
(20)			M_RJ71C24_bidirectionalOutput_00C_1 Bidirectional	Output FB				
	bReq_OUTPUTInstructionTr							bOUTPUTInstructionTransmissio
	M10							M2
			- B:LEEN	o_bENO:B				0
								bOUTPUTInstructionTransmissio
		C24_1						MO
		-( )	DUT:i_stModule	o_bOK:B				0
			•					bOUTPUTInstructionTransmissio
		nnel						M1
		-{ D1 ]	- UW:i_uCh	o_bErr:B				0
		wTransmissionDat aCount			wErrorCode			
		-{ D2 ]	UW:i_uSendDataLength	o_uErrld:UW	-[ D100 ]			
		wnTransmissionDa ta						
		- <b>[</b> D10 ]	- UW: <u>i</u> uSendData					
	bOUTPUTInstructionTrans		-					
(65)	missionNormalCompletion M0						SET	bNormalCompleteFlag
								M100
	bOUTPUTInstructionTrans							
(67)	missionAbnormalCompletion M1						SET	bAbnormalCompleteFlag
						1		M101
(69)								
								(END )
	1							

Set the transmission channel to CH1.
 Set the send data quantity to 8.
 Set the data to be transmitted.
 Set the transmission direction.

(65) Normal completion

(67) Abnormal completion

# PART 3

# PARAMETER SETTINGS AND TROUBLESHOOTING

This part explains parameters and troubleshooting of C24.

**26 PARAMETER SETTING** 

27 TROUBLESHOOTING

# **26** PARAMETER SETTING

This section explains parameter settings necessary for data communication between C24 and a target device.

### 26.1 Parameter Setting Procedure

This section explains the parameter setting procedure to use RJ71C24.

- **1.** Add C24 to Engineering tool.
- C Select [Parameters] ⇒ [Module Information] from Navigation window, and right click and select [Add New Module].
- 2. Module parameters and module extended parameters are included in parameters. There are four types of module parameters: basic settings, application settings, interrupt settings, and refresh setting, and three types of module extended parameters: user frame contents, modem initialization data, and modem connection data, which are selected from the tree in the screen below.
- Navigation window ⇔ [Parameter] ⇔ [Module Information] ⇔ RJ71C24 ⇔ [Module Parameter]/[Module Extended Parameter]
- 3. Write the settings to the CPU module with Engineering tool after the parameter setting is completed.
- ♥ [Online] ⇒ [Write to PLC]
- **4.** The settings are reflected by resetting the CPU module or turning the power OFF  $\rightarrow$  ON.

## 26.2 Module Parameters

Set the module parameters. The module parameter includes the following four types: basic settings, application settings, interrupt settings, and refresh setting, which is selected from the tree in the screen below.

X Navigation window ⇔ [Parameters] ⇔ [Module Information] ⇔ Module name ⇔ [Module Parameter]

### **Basic settings**

Configure the settings to operate the basic functions of C24.

0000:RJ71C24 Module Parameter				E
Setting Item List	Setting Item			
Input the Setting Item to Search				
	Item	CH1	CH2	*
Egg         Value: contol specification         Application: Sering:         Image: Sering: Sering: Sering:         Image: Sering: Sering: Sering: Sering:         Image: Sering: Ser	Item           • Marious control specification           • TEST MODE reling           • Communication speed setting           • Communication speed setting           • Domain setting           • Domain setting           • Domain setting           • Dode/setting           • Static Number Setting (CH1, 2 common: 0 to 31)           • Static Number Setting (CH1, 2 common: 0 to 31)           • Dirt REB1 signal setting           • Dirt REB1 signal setting           • Commission control setting           • Commission control setting           • Commission control           • Control specification.	CH1 Ch1Carter Service control specification No specification No specification Notes Set the transmission enhod Independent Set the transmission enhod Deadle Deadle Deadle Deadle ON ON Set the ON/OFF status of the RS/DTR a ON ON Set the Service Set the Service ON DTR/DSR control	CH2 MELSOFT connection Autonatically set 7 None 0adl Diable Diable Diable Diable Diable Diable Diable Diable Diable	
Item List Find Result	Check Restore the Default Setting	38		

## Various control specification

Specify the variou	s controis.			
Item		Description	Setting range	
Test mode setting <sup>*1</sup>		Sets the test mode. When a problem occurs during data communication with a target device, check whether or not there is any problem in the operation of the C24.	<ul> <li>No specification (other than test mode)</li> <li>Hardware test</li> <li>Self-loopback test</li> <li>(Default: No specification (other than test mode))</li> </ul>	
Communication proto	col setting	Sets a protocol for communicating with a target device.	MELSOFT Connection     MC Protocol (Format 1)     MC Protocol (Format 2)     MC Protocol (Format 3)     MC Protocol (Format 4)     MC Protocol (Format 5)     Nonprocedural protocol     Bidirectional protocol     Predefined protocol     (Default: MELSOFT Connection)	
Communication spee	d setting	Sets a communication rate.	<ul> <li>Automatically set<sup>*2</sup></li> <li>1200 bps</li> <li>2400 bps</li> <li>4800 bps</li> <li>9600 bps</li> <li>14400 bps</li> <li>19200 bps</li> <li>28800 bps</li> <li>38400 bps</li> <li>57600 bps</li> <li>115200 bps</li> <li>230400 bps</li> <li>(Default: Automatically set)</li> </ul>	
Transmission setting	Operation setting*3	Configures an operation settings of two interfaces.	<ul> <li>Independent</li> <li>Interlink</li> <li>(Default: Independent)</li> </ul>	
	Data bit	Sets a bit length for one character in data to be transmitted/received to/from a target device.	• 7 • 8 <sup>*4</sup> (Default: 7)	
	Parity bit	Set whether or not a parity bit (vertical parity) is added for one character of data to be transmitted/received.	• None • Yes (Default: None)	
	Odd/even parity	Sets which parity bit is used, odd parity or even parity, when a parity bit is added. (This will be enabled only when the parity bit is set to "Yes".)	• Odd • Even (Default: Odd)	
	Stop bit	Sets a stop bit length for one character in data to be transmitted/received to/from a target device.	• 1 • 2 (Default: 1)	
	Sumcheck code	Sets whether or not a sum check code is added to transmission message and reception message.	None     Yes (Default: None)	
	Online change	Sets whether or not data is written to a CPU module during RUN when writing data from a target device to the CPU module.	• Disable • Enable (Default: Disable)	
	Setting change	<ul> <li>Sets whether or not the following processing is allowed after the startup.</li> <li>Data communication function of each interface, changing of transmission specification, changing of communication protocol</li> <li>Writing data to flash ROM</li> </ul>	• Disable • Enable (Default: Disable)	
Station number setting 0 to 31)	g (CH1, 2 in common:	Sets the host station number during multidrop communication.	0 to 31 (Default: 0)	

ltem		Description	Setting range		
Signal specification	RTS (RS) signal status designation	Sets the ON/OFF state of RTS(RS) signal.	• OFF • ON (Default: ON)		
	DTR (ER) signal status designation	Sets the ON/OFF state of DTR (ER) signal.	• OFF • ON (Default: ON)		
Transmission control specification	Transmission control	Sets which controls data communication with a target device, transmission control signal or DC code.	DTR/DSR control     DC code control (Default: DTR/DSR control)		
	DC1/DC3 control	Sets whether or not DC1/DC3 control is enabled.	Control disabled     Control enabled     (Default: Control disabled)		
	DC2/DC4 control	Sets whether or not DC2/DC4 control is enabled.	Control disabled     Control enabled     (Default: Control disabled)		
	DC1 code	Sets the control data to inform a target device that C24 can receive data.	00H to FFH (Default: 11H)		
	DC3 code	Sets the control data to inform a target device that C24 cannot receive data.	00H to FFH (Default: 12H)		
	DC2 code	Sets the control data to inform a target device the start of a valid data.	00H to FFH (Default: 13H)		
	DC4 code	Sets the control data to inform a target device the end of a valid data.	00H to FFH (Default: 14H)		
	Transmission control start free space designation	Designates a free capacity in the OS area that informs data cannot be received.	64 to 4095 (Default: 64)		
	Transmission control end free space designation	Designates a free capacity in the OS area that informs data can be received.	263 to 4096 (Default: 263)		
	Nonprocedural no-reception monitoring time method designation	Sets the format to use the no-reception monitoring time (timer 0).	Method 0     Method 1     (Default: Method 0)		
Communication control specification	Word/byte units designation	Sets the unit of data length (data count).	• Word unit • Byte unit (Default: Word unit)		
	CD terminal check designation	Checks the state of the CD (DCD) signal.	Check     Do not check     (Default: Do not check)		
	Communication method designation	Sets the communication method.	Full-duplex communication     Half-duplex communication     (Default: Full-duplex     communication)		
	Echo back enable/prohibit specification	Sets whether or not the returned data is received.	<ul> <li>Echo back enable</li> <li>Echo back prohibit</li> <li>(Echo back prohibit)</li> </ul>		
	NULL character automatic removal designation	Sets whether or not NULL character is automatically deleted.	Auto delete disabled     Auto delete enabled     (Default: Auto delete     disabled)		
	Communication data reception enable/ disable designation	Sets this if noise signals are added on the line when turning ON the power of the target device or connecting the communication cable. Setting to "Receive enable", improper data due to noise signal addition can be discarded. Set this designation to "Receive enable" by a program after the serial line has been settled. While this designation is set to "Receive disable", the normal data also is discarded.	Receive enable     Receive disable (Default: Receive enable)		
	Receive data enable/disable	Sets whether data received simultaneously is valid or invalid.	Enable     Disable     (Default: Enable)		
	Send data enable/disable	Sets whether data transmitted simultaneously is valid or invalid.	• Enable • Disable (Default: Enable)		

Item		Description	Setting range
Half-duplex communication control specification	Simultaneous transmission priority/non- priority designation	Sets whether the transmission from C24 is continued or discontinued when C24 and a target device stat data transmission at the same time. 0.0: Priority 0.1 to 25.5: Non-priority (Transmission wait time : unit: s)	0.0 to 25.5 (Default: 0.0: Priority)
	Retransmission time transmission method designation	Sets whether the discontinued message is transmitted from the beginning or it is transmitted from the part disconnected when C24 restarts transmission following the discontinuation at the time of simultaneous transmission.	Do not resend     Resend (Default: Do not resend)
Data communication time monitoring specification	No-reception monitoring time (timer 0) designation	Sets a monitoring time for the no-reception monitoring time (timer 0). 0: Unlimited wait 40 to 4000: Monitoring designation (Unit: byte)	0, 40 to 4000 (Default: 0: Unlimited wait)
	Response monitoring time (timer 1) designation	Set a monitoring time for the response monitoring time (timer 1). 0: Unlimited wait 0.1 to 300.0: Monitoring designation (Unit: s)	0, 0.1 to 300.0 (Default: 0.5)
	Send monitoring time (timer 2) designation	Set the monitoring time for transmission monitoring time (timer 2). 0: Unlimited wait 0.1 to 300.0: Monitoring designation (Unit: s)	0, 0.1 to 300.0 (Default: 180.0)
Send wait time specification	Transmission wait time designation	Set a wait time to transmit a response message to a message received from a target device. 0: No wait time 10 to 150: Monitoring designation (multiples of ten) (Unit: ms)	0, 10 to 150 (multiples of ten) (Default: 0: No wait time)
Send/receive data monitoring function specification	Send/receive data monitoring designation	Set the start/stop communication data monitoring.	No monitor/stop instruction     Monitor start instruction (Default: No monitor/stop instruction)
	Stop at buffer full specification	Sets whether the monitor is stopped when the monitor data area is full (buffer full).	• OFF • ON (Default: OFF)
	0 timer error outbreak stop designation	Set whether the monitor is stopped when the timer 0 error occurs.	• OFF • ON (Default: OFF)
	Monitor buffer start address designation	Set the start address of the storage area for the monitored data.	1024 to 6909 (400H to 1AFDH), 9728 to 16381 (2600H to 3FFDH) (Default (CH1): 9728 (2600H)) (Default (CH2): 13056 (3300H))
	Monitor buffer size designation	Set a monitor data area size.	3 to 6656 (3H to 1A00H) (Default: 3328(D00H))
On-demand function specification	Buffer memory start address designation	Set the start address of the buffer memory used with the on- demand function.	1024 to 6911 (400H to 1AFFH), 9728 to 16383 (2600H to 3FFFH) (Default (CH1): 1024 (400H)) (Default (CH2): 2048 (800H))
	Data length designation	Set a data length to be transmitted using the on-demand function.	0 to 13312 (0H to 3400H) (Default: 0 (0H))
Send area specification	Send buffer memory start address designation	Set the start address of the area used as the send area.	1024 to 6911 (400H to 1AFFH), 9728 to 16383 (2600H to 3FFFH) (Default (CH1): 1024 (400H)) (Default (CH2): 2048 (800H))
	Send buffer memory size specification	Set the size of the area used as the send area.	1 to 6656 (1H to 1A00H) (Default: 512 (200H))

Item		Description	Setting range
Receiving area specification	Receiving buffer memory start address designation	Set the start address of the area used as the receive area.	1024 to 6911 (400H to 1AFFH), 9728 to 16383 (2600H to 3FFFH) (Default (CH1): 1536 (600H)) (Default (CH2): 2560 (A00H))
	Receiving buffer memory size specification	Set the size of the area used as the receive area.	1 to 6656 (1H to 1A00H) (Default: 512 (200H))
Conversion designation	ASCII-binary conversion designation	Set whether or not data to be communicated to a target device is communicated with ASCII code.	Do not convert     Convert     (Default: Do not convert)
Transparent code designation_Trans parent code for sending specification (nth) <sup>*5</sup>	Transparent code	Set one-byte data for transmission control. Set '0' to both the transparent code and additional code when the transparent code for sending is not specified.	00H to FFH (Default: 00H: Do not specify (The transparent code and the additional code are 0 both.))
	Additional code	Set one-byte data added immediately before the transparent code and additional code data. Set the additional code within the range of 01H to FFH when the transparent code for sending is specified. Set '0' to both the transparent code and additional code when it is not specified.	00H to FFH (Default: 00H: Do not specify (The transparent code and the additional code are 0 both.))
Transparent code designation_Trans parent code for receiving specification	Transparent code	Set one-byte data for transmission control. Set '0' to both the transparent code and additional code when the transparent code for receiving is not specified.	00H to FFH (Default: 00H: Do not specify (The transparent code and the additional code are 0 both.))
	Additional code	Set one-byte data to be deleted at the data reception. (The immediately succeeding one-byte data is processed for reception.) Set the additional code within the range of 01H to FFH when the transparent code for receiving is specified. Set '0' to both the transparent code and additional code when it is not specified.	00H to FFH (Default: 00H: Do not specify (The transparent code and the additional code are 0 both.))
Receiving end specification	Receive end data quantity designation	Set the receive end data quantity.	1 to 13310 (Default: 511)
	Receive end code designation	Set a receive end code. 0D0AH: CR, LF 00H to FFH: Arbitrary receive end code FFFFH: No designation	0000H to 00FFH, 0D0AH, FFFFH (Default: 0D0AH: CR, LF)
Protocol execution history specification option		Set whether execution logs of all protocol are stored or whether execution logs of only abnormally completed protocol are stored.	<ul> <li>Only protocol that completed abnormally</li> <li>All protocol execution status and execution history</li> <li>(Default: Only protocol that completed abnormally)</li> </ul>

\*1 It can be set only on the CH1 side. When the test mode is selected, the communication protocol setting on the CH1 side and the setting on the CH2 side cannot be configured (will be invalid).

\*2 It will be enabled only when "MELSOFT Connection" is selected for the communication protocol setting.

\*3 It can be set on the CH2 side only. (Since the linked operation is not available for RJ71C24-R2, it is fixed to "Independent".) When it is set to "Interlink", the communication protocol setting for the CH2 side cannot be configured.

\*4 Set to 8-bit for data communication using MC protocol (Format 5) or Bidirectional protocol.

\*5 n: 1 to 10

### **Application settings**

Configure the settings such as the user frame specification.

0000:RJ71C24 Module Parameter			
Setting Item List	Setting Item		
Input the Setting Item to Search			
	Item	CH1	CH2 A
🛞 👘 Basic Settings	User frame specification		
🖨 👔 Application Settings	e on demand user frame specification	Register the system setting valu	e for sending/receiving data with h
User frame specification	Start frame No. designation (1st)	0	0
Modem function setting	Final frame No. designation (1st)	0	0
Programmable controller CPU monitoring function set	Start frame No. designation [2nd]	0	0
Befrech cetting	Final frame No. designation (2nd)	U Desistent and an utility of the	U
Tellean setting	user frame specification for receiving	Register the system setting valu	es for exchanging data with nonpi
	User frame use enable/disable	U. Not use	U. Not use
	Start frame No. designation (1st)	0	0
	Chart frame No. designation (1st)	0	0
	Statchame No. designation (2nd)	0	4
	Chat frame No. designation (2nd)	A .	×
	Stati traine No. designation (Std)	0	0
	Clast frame Ma. designation (30)	0	0
	Final frame No. designation (40)	0	0
	Sond year frame designation	Begister the system setting walk	on for each anging data with nonny
	- CB/LE output designation	D: Noture	B Notuce
	<	D. NOLUSE	t. Not use
	Explanation		
			^
< +	Chards Declary the Defend California		
Item List Find Result	criect?		

Item	Description	Reference
User frame specification	Sets the system setting value for data communication using a user frame.	Page 429 User frame specification
Modem function setting	Sets the system setting value for data communication using the modem function.	Page 430 Modem function setting
Programmable controller CPU monitoring function setting	Sets the system setting value to use the programmable controller CPU monitoring function.	Page 431 Programmable controller CPU monitoring function setting

#### User frame specification

Item		Description	Setting range
On-demand user frame specification	Start frame No. designation (nth)	Sets the user frame number to be used.	0000H to 801FH (Default: 0000H)
	Final frame No. designation (nth)	Sets the user frame number to be used.	0000H to 801FH (Default: 0000H)
User frame specification for receiving	User frame use enable/disable designation	Sets whether or not a user frame is used for data communication.	• Not use • Use (Default: Not use)
	Start frame No. designation (nth)	Sets the user frame number to be used.	0000H to 801FH (Default: 0000H)
	Final frame No. designation (nth)	Sets the user frame number to be used.	0000H to 801FH (Default: 0000H)
Send user frame designation	CR/LF output designation	Sets whether or not CR/LF is transmitted.	Do not send     Send (Default: Do not send)
	Output start pointer designation	Sets the head position in the transmission frame number designation area to which the registration number of the user frame to be transmitted is written.	0 to 100 (Default: 0)
	Output quantity designation	Sets the number of user frame to be transmitted from the designated position in the output start pointer designation area.	0 to 100 (Default: 0)
	Send frame number designation (nth)	Sets the user frame number to be transmitted from the designated position in the output start pointer designation area in the order of output.	0000H to FFFFH (Default: 0000H)
User frame receiving method designation	User frame receiving method designation (nth)	Sets the receive format of a user frame.	Method 0     Method 1     (Default: Method 0)
	Method 1 dedicated receive end data quantity designation (nth)	Sets the number of word/byte in the arbitrary data portion at the time of data reception using the user frame receive method 1.	0000H to FFFFH (Default: 0000H)

Set the system setting value for data communication using a user frame.

#### Modem function setting

Set the system setting value for data communication using the modem function.

Item		Description	Setting range
Modem function specification 1	Modem connection CH specification	Sets a channel to connecting a modem/TA	• None • CH1 • CH2 (Default: None)
	Connection re-try count designation	Sets a number of retries for the connection request.	1 to 5 (Default: 5)
	Connection retry interval designation	Sets an interval of the retry processing for the connection request. (Unit: s)	90 to 300 (Default: 180)
	Initialization/ connection timeout designation	Sets the wait time below. • Wait time until the modem/TA initialization is complete. • Wait time per one connection request (Unit: s)	1 to 60 (Default: 60)
	Number of initialization retries designation	Sets a number of initialization retries to the modem.	1 to 5 (Default: 3)
	Data No. for initialization designation	Sets the data number to be transmitted by the initialization request to the modem.	0000H, 07D0H to 07DDH (2000 to 2013), 09C4H to 09E1H (2500 to 2529) 8001H to 801FH (32769 to 32799) (Default: 0000H: No designation)
	Data No. for connection designation	Sets the data number for connection to be used for the processing to connect to a target device for data transmission.	0000H, 0BB8H to 0BD5H (3000 to 3029) 8001H to 801FH (32769 to 32799) (Default: 0000H: No designation)
	No-communication interval time designation	Sets the wait time before the line is closed when data communications with a target device is ceased after the line has been connected. 0: Infinite wait 1 to 120 (unit: minute)	0: Infinite wait 1 to 120 (0: Infinite wait)
	RS/CS control enable/disable designation	Sets whether or not the control to notify the reception capability of the host station to the target side with RS/CS signal is performed during data communication between C24 and a modem/TA.	<ul> <li>Control disabled</li> <li>Control enabled</li> <li>(Default: Control enabled)</li> </ul>
Modem function specification 2	Auto modem initialization designation	Sets whether or not the modem is automatically initialized.	<ul> <li>Do not automatically initialize</li> <li>Automatically initialize (Default: Do not automatically initialize)</li> </ul>
	Modem initialization DR (DSR) signal enable/disable designation	Sets how to treat DR signal when initializing a modem.	DR signal enabled     DR signal disabled     (Default: DR signal disabled)
Modem function specification 3	Line disconnection wait time specification (PLC CPU monitor)	Sets the time until data transmission from a modem on the host station side to the target device side is completed for data communication with the programmable controller CPU monitoring function.	0000H to FFFFH (Default: 0000H)
Remote password function	Remote password mismatch notification count designation	Sets the number of times to notify the CPU module that a remote password mismatch occurred during the unlock processing by a target device after the modern line has been connected.	0000H to FFFH (Default: 0000H: No designation)
	Remote password mismatch notification accumulated count designation	Set the accumulated number of times to notify the CPU module that a remote password mismatch occurred during the unlock processing by a target device after C24 has started up.	0000H to FFFFH (Default: 0000H: No designation)
### Programmable controller CPU monitoring function setting

Set the system setting value to use the programmable controller CPU monitoring function.

Item			Description	Setting range
Programmable contro	ller CPU monitoring fur	nction designation	Sets the timing to transmit the programmable controller CPU monitoring results to a target device.	Do not use the function     Fixed cycle send     Condition match send     (Default: Do not use the function)
Cycle time units desig	nation		Sets the unit of the cycle time.	• 100 ms • Second • Minute (Default: Minute)
Cycle time designation (programmable controller CPU monitoring interval time)		oller CPU monitoring	Set a cycle time. (The unit depends on the cycle time units designation.)	1 to 65535 (Default: 5)
Send pointer designat	tion		Sets the pointer position of the user frame to be transmitted.	0 to 100 (Default: 0: No designation)
Output quantity design	nation		Sets the number of user frame to be transmitted.	0 to 100 (Default: 0: No designation)
Block monitoring device	Registered word block	< quantity designation	Sets the number of registered word blocks.	0 to 10 (Default: 0: No designation)
	Registered bit block q	uantity designation	Sets the number of registered bit blocks.	0 to 10 (Default: 0: No designation)
	CPU error monitoring designation		Sets whether or not the monitoring for abnormality on CPU module is performed.	<ul> <li>Do not monitor</li> <li>Monitor</li> <li>(Default: Do not monitor)</li> </ul>
	n-th block monitoring device <sup>*1</sup>	Monitoring device designation	Sets the device code to be monitored.	CF Page 122 List of device code (Default: Do not designate)
		Start device No. specification	Sets the start number of device to be monitored.	CF Page 122 List of device code (Default: 0)
		Number of read points specification	Sets the read point.	0000H to FFFFH (Default: 0000H)
		Monitoring condition specification (judgment condition specification)	Sets the judgment conditions for the monitoring condition value.	<ul> <li>Do not designate</li> <li>= (Edge)</li> <li>&lt;&gt;(Edge)</li> <li>&lt;=(Unsigned, Edge)</li> <li>&lt;(Unsigned, Edge)</li> <li>&gt;=(Unsigned, Edge)</li> <li>&gt;=(Unsigned, Edge)</li> <li>&lt;(Unsigned, Edge)</li> <li>&lt;(Signed, Edge)</li> <li>&lt;(Signed, Edge)</li> <li>&gt;=(Signed, Edge)</li> <li>&gt;(Signed, Edge)</li> <li>&lt;(Signed, Edge)</li> <li>&lt;(Unsigned, Level)</li> <li>&lt;(Unsigned, Level)</li> <li>&lt;(Unsigned, Level)</li> <li>&lt;(Signed, Level)</li> <li>&lt;(Signed, Level)</li> <li>&lt;(Signed, Level)</li> <li>&gt;(Signed, Level)</li> <li>(Default: Do not designate)</li> </ul>

Item			Description	Setting range
Block monitoring device	n-th block monitoring device <sup>*1</sup>	Monitoring condition value designation	Sets the condition and numeric value for the monitoring condition.	<ul> <li>When the monitoring device is a word device</li> <li>0000H to FFFFH</li> <li>When the monitoring device is a bit device</li> <li>0000H: OFF</li> <li>0001H: ON</li> <li>(Default: 0000H)</li> </ul>
		Send pointer designation	Sets the pointer position of the user frame to be transmitted.	0 to 100 (Default: 0: No designation)
		Output quantity designation	Sets the number of user frame to be transmitted.	0 to 100 (Default: 0: No designation)
CPU error monitoring	Send pointer designa	tion	Sets the pointer position of the user frame to be transmitted.	0 to 100 (Default: 0: No designation)
designation	Output quantity desig	nation	Sets the number of user frame to be transmitted.	0 to 100 (Default: 0: No designation)

\*1 n: 1 to 10

## Interrupt settings

Configure the settings to receive data with an interrupt program.

0000:RJ71C24 Module Parameter				6
Setting Item List	Setting Item			
Input the Setting Item to Search				
	No.	Interrupt condition channel No.	Interrupt factor	Interruption pointer
De Carlos Cottingo	1	CH1	No specification	
tr in bour - sour te in Apple and Selfings in the Apple and Selfings in the Apple and Selfings in the Apple and the Apple a	2	CH2	No specification	
	Explanation			*
Nem List [Find Result]	Check Restore the Defay	t Settings		*

Item	Description	Reference
Interrupt factor	Sets the condition for interruption occurrence.	No specification     BUFRCVS instruction data     reception     (Default: No specification)
Interrupt pointer	Sets the interrupt pointer to be used by the program.	I0 to I15, I50 to I2023, label (up to 256 characters) (Default: — (blank))

## **Refresh setting**

With this refresh settings, the read and write processing by a program is not necessary. Set a device/module label of the CPU module which transfers data alternately with the buffer memory on C24. The device/module label to be transmitted is selected from the following from "Target".

- Module label
- Refresh Data Register (RD)
- Device

#### Module label

The contents are transferred alternatively between the module label corresponding to each buffer memory and the buffer memory. Set "Valid" for the item to be transferred using module labels and "Invalid" for the item not to be transferred. By enabling "Send data\_send area", the other transfer destinations will be set to "Valid".

#### Refresh data register (RD)

The contents are transferred alternatively between the refresh data register (RD) of a CPU module and the buffer memory. By setting the refresh data register (RD) to be transferred in "Top Device Name", the other transfer destinations will be automatically set.

#### Device

The contents are transferred alternatively between the designated device of a CPU module and the buffer memory. The devices that can be designated are X, Y, M, L, B, T, C, ST, D, W, R, ZR, and RD. When bit devices, X, Y, M, L, or B are used a number that can be divided by 16 points (for example, X10, Y120, M16, etc.) should be set. The buffer memory data is stored in the equivalent of 16 points from the designated device number.

(For example, when X10 is set, data is stored from X10 to X1F.)

Item		Description	Reference
Transfer to intelligent function module	Send data_send area	A refresh setting for the send data storage area.	Page 77 Transmitting Data to Target Device Page 96 Transmitting Data to Target Device
Transfer to CPU	LED lighting status, communication error status	A refresh setting for confirmation of LED lighting status and communication error status	া Page 441 Checking error status
	Transmission control status	A refresh setting for confirmation of transmission control status	Page 447 Current operation status reading method
	Control signal status	A refresh setting for confirmation of control signal status	Service Page 445 RS-232 control signal status reading method
	Communication result	A refresh setting for confirmation of communication result	Page 446 Data communication status (transmission sequence status) reading method Page 464 ERR LED turns ON Page 278 Data Reception
	For receive data	A refresh setting for the receive data storage area	Page 53 Receiving Data from Target Device Page 87 Receiving Data from Target Device
	Predefined protocol execution status	A refresh setting for confirmation of predefined protocol execution states	Page 113 Protocol Execution Log Storage Function (for Predefined Protocol only) Page 464 ERR LED turns ON
	Sending user frame	A refresh setting for confirmation of user frame being transmitted	Page 315 Settings of send user frames
	For user frame confirmation	A refresh setting for confirmation of user frame	—
	For modem function confirmation	A refresh setting for confirmation of modem function	Page 161 Details of the buffer memory (for modern function)
	For remote password function	A refresh setting for the remote password function	Page 165 Details of buffer memory (for the remote password function)
	Programmable controller CPU monitoring function	A refresh setting for the programmable controller CPU monitoring function	Page 119 USING THE PROGRAMMABLE CONTROLLER CPU MONITORING FUNCTION
	For flash ROM (user frame) access	A refresh setting for the flash ROM (user frame) access	—
	Transmission setting, for mode switching confirmation	A refresh setting for confirmation of the transmission setting and the mode switching	CF Page 377 SWITCHING THE MODE AFTER STARTING
Refresh group	Refresh group	A setting for the refresh group • At the Execution Time of END Instruction • At the Execution Time of Specified Program	
	Program group No.	Designate the number which will be enabled when selecting 'At the Execution Time of Specified Program' for Refresh group.	
Refresh Timing (I/O)	Refresh timing	Sets the timing to transmit the I/O device data. • It follows the refresh timing (buffer memory).	

-

#### Refresh processing time

A refresh processing time ( $\mu$ s) is a constituent of the scan time of CPU module. For details on the scan time, refer to the following manual.

MELSEC iQ-R CPU Module User's Manual (Application)

The refresh processing time  $(\mu s)$ , which is taken for the refresh, is given by:

 Refresh processing time (μs) = Refresh read time (time for transferring refresh data to the CPU module) + Refresh write time (time for transferring refresh data to the Intelligent function module)

The refresh read time and refresh write time vary depending on the settings of "Target".

#### When "Target" is "Module Label" or "Refresh Data Register (RD)"

The following table shows the refresh read time and refresh write time with an R□CPU used.

Classification	Refresh processing time
Refresh read time	80.80 µs
Refresh write time	20.48 μs

#### ■When "Target" is "Device"

Calculate the refresh read time and refresh write time according to the number of items and the number of their transfer data (in units of word) that are set to be refreshed. For the calculation method, refer to the following manual.

MELSEC iQ-R CPU Module User's Manual (Application)

In addition, substitute the following values in the calculation formula to calculate the refresh processing time.

Item	Description
Number of refresh settings	Number of items that are set to be refreshed
Refresh time (A) of each of the 1st to nth set items	$0.05 \ \mu s \ per \ one \ word^{*1}$
Refresh time (B) of each of the 1st to nth set items	0.01 μs per one word <sup>*1</sup>

\*1 This value is the time with an R□CPU used.

#### Ex.

When all the 48 items (1068 words in total) are set in the refresh read settings  $48 \times 0.98 + 0.05 \times 1068 + 11.6 = 112.04 \ \mu s$ 

The refresh read time, therefore, is 112.04 µs.

#### Ex.

When all the 2 items (1022 words in total ) are set in the refresh write settings  $2 \times 0.58 + 0.01 \times 1022 + 9.10 = 20.48 \ \mu s$ 

The refresh write time, therefore, is 20.48  $\mu$ s.

## 26.3 Module Extended Parameter

Set a module extended parameter. The Module extended parameter includes user frame contents, modem initialization data, modem connection data, which are selected from the tree on the following screen.

X Navigation window ⇒ [Parameters] ⇒ [Module Information] ⇒ Module Name ⇒ [Module Extended Parameter]

### User frame contents

Register the user frame which is used for the on-demand function using the MC protocol and the data transmit/receive function using nonprocedural protocol.

In the user frame contents, the setting value for each frame of the registration frame No. 1000 to 1199 is set.

0000:R071C24 Module Extended Parameter		8
Setting Item List	Setting Item	
Input the Setting Item to Search		
	Item	Setting Value
It of the contents	User frame contents User frame Contents Registration frame No.1000 Registration frame No.1001 Registration frame No.1002 Registration frame No.1003	Register the user frame used with the following functions.* MC protocol on
Us	er Frame Creation 0000:RJ71C24	
	Direct/Support Input Sping UEX System No. 1 2 3 4 5 String Control Code/Special Code Input © Control Code Special Code ODh.NUL © Experts Dots UEX December 2010	front     6 7 , Concel
Rem List [Find Result]	Check	

Item	Description	Setting range
User frame	Sets the setting value for a user frame.	80 (maximum number of characters that can be entered)

## Modem initialization data

In the modem initialization data, the data for initialization of the data number from 2500 to 2529 is set.

0000:RJ71C24 Module Extended Parameter		
0000.RUIC24 Module Extended Parameter Setting Item List Irput the Setting Item to Search The Setting Item to Search The Setting Item Contents The Setting Item Contents Modem connection data	Item           Kodem functor           Moden initialization data           Moden initialization data No.2301           Initialization command           User control data           Moden initialization data No.2301           Initialization command           User control data           Moden initialization data No.2301           Initialization command           User control data           Moden initialization data No.2303           Initialization command           User control data           Moden initialization data No.2303           Initialization command           User control data           Moden initialization data No.2304           Initialization command           User control data           Moden initialization data No.2305           Initialization command           User control data           Moden initialization data No.2305           Initialization command           User control data	Setting Value Setting Value Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Register the connected modem's initialization data in the MELSE( Reg
Tem List [Find Ress.2]	Explanation Explanation Check Restore the DeloyA Sotings	•
J		

Item	Description	Setting range
Initialization command	Sets a data code for initialization command.	78 (maximum number of characters that can be entered)
User control data	Sets an arbitrary data for a user to control the data to be registered.	0 to FFFF

## Modem connection data

In the modem connection data, the data for connection of data number from 3000 to 3029 is set.

	E
Extend (into Link)     Setting (low)       Proof the Setting (low)     Item     Setting (Value)       If you the Setting (low)     Item     Setting (Value)       If you the Setting (low)     If dotten function     Item       If you the Setting (Value)     If dotten function     Item       If you the Setting (Value)     If dotten function     Item       If you the Setting (Value)     If dotten function     Item       If you the Setting (Value)     If dotten function     Item       If you the Setting (Value)     If dotten function     Item       If you the Setting (Value)     If dotten function     Item       If you the setting (Value)     Item (Interview)     Item (Interview)       If you the setting (Value)     Item (Interview)     Item (Interview)       If you the setting (Value)     Item (Interview)     Item (Interview)       If you the setting (Value)     Item (Interview)     Item (Interview)       If you the setting (Value)     Item (Interview)     Item (Interview)       If you the setting (Value)     Item (Interview)     Item (Interview)       If you the setting (Value)     Item (Interview)     Item (Interview)       If you the setting (Value)     Item (Interview)     Item (Interview)       If you the setting (Value)     Item (Interview)     Item (Interview)    <	device for data

Item	Description	Setting range
External line outgoing number	Sets an external line outgoing number of the C24 side for line connection to the side of target device for data transmission.	<ul> <li>255: No external transmission</li> <li>0: 0</li> <li>1: 1</li> <li>2: 2</li> <li>3: 3</li> <li>4: 4</li> <li>5: 5</li> <li>6: 6</li> <li>7: 7</li> <li>8: 8</li> <li>9: 9</li> <li>10: *</li> <li>11: #</li> </ul>
Line type	Sets a line type between the target device for data communication.	• 0: Pulse • 1: Tone • 2: ISDN
Telephone number	Sets a telephone number between the target device for data communication.	62 (maximum number of characters that can be entered)
Comment	Sets an arbitrary comment.	254 (maximum number of characters that can be entered)

# **27** TROUBLESHOOTING

This chapter explains the errors which may occur when using C24 and the corrective actions.

## 27.1 Checking Module Status

The following functions can be used in the "Module Diagnostics" screen of C24.

Function	Description
Error Information	Contents of error currently occurs are displayed.
	Errors detected on C24 and history of operation performed to the module can
	be checked by clicking the [Event History] button.
Module Information List	Various status information of C24 is displayed.

### **Error information**

Check the content of error currently occurs and the corrective actions.

#### Window



#### Displayed items

Item	Description
Detailed Information	Up to three detail information of each error is displayed.
Cause	Detail reasons for error is displayed.
Corrective Action	Corrective actions for an error is displayed.

### Module information list

Check each status information of C24 by switching to the [Module Information List] tab.

#### Checking error status

The transmission status and the communication error status for C24 can be checked with Engineering tool. (Contents of the 'CH□ side LED lighting status and communication error status' (Un\G513/514) are displayed.)

When a communication error occurs, refer to the following section and take corrective action.

Page 457 Troubleshooting by Symptom

Point P

Each communications error status of SIO, PRO., P/S, and C/N turns ON when an error occurs. To turn them OFF by clearing the communication error status, turn 'Error initialization request' (YE) ON.

Window

Module Name	Production information Supplementary Function Monitoring	
RJ71C24	Execute Stop Monitor	ng
Information Module Information L		
Item	Content	-
LED information		
RUN	On: In normal operation	
ERR.	On: Communication error, setting error detected or major error(when the RUN LE	6
CH1_SD	Off: Channel 1 Data not sent	
CH1_RD	Off: Channel 1 Data not received	Ξ
CH1 C ERR	On: Channel 1 Communication error detected	
CH2_SD	Off: Channel 2 Data not received	
CH2_RD	Off: Channel 2 Data not received	
CH2 C ERR	Off: Channel 2 Communication error not detected	
Extension LED information		
CH1 SD WAIT	Off: Channel 1 Data send enable state	
CH1 SIO	Off: Channel 1 Normal	
CH1 PRO.	Off: Channel 1 Normal	
CH1 P/S	Off: Channel 1 Normal	
CH1 C/N	Off: Channel 1 Normal	
CH1 NAK	Off: Channel 1 Normal end send or before data communication	
CH1 ACK.	Off: Channel 1 Abnormal end send or before data communication	
CH1 NEU.	Off: Channel 1 Command processing	
CH2 SD WAIT	Off: Channel 2 Data send enable state	
CH2 SIO	Off: Channel 2 Normal	
CH2 PRO.	Off: Channel 2 Normal	
CH2 P/S	Off: Channel 1 Normal	Ŧ
•	III b	

#### Displayed items

#### ■Buffer memory area for the display contents



#### SD WAIT

SD WAIT indicates "Transmission wait status".

Value	Status	Description
0001 (ON)	Waiting for data transmission	<ul> <li>C24 got into a state in which data cannot be sent to a target device (waiting for data transmission) by the transmission control of C24.</li> <li>The transmission cannot be started.</li> <li>A transmission terminate request (receiving DC3/DR(DSR) signal OFF) is received from the target device during data transmission.</li> </ul>
0000 (OFF)	Data transmission available	The transmission became available, and the data transmission is started/resumed.

#### **■SIO**

SIO indicates "SIO error status".

Value	Status	Description
0001 (ON)	Overrun or framing error occurred	Overrun or framing error occurred. Keeps the ON-status even after the communication returns to normal. Initialize the error information as necessary. Image 473 Error Code List
	OS area is full.	No free space is available in the OS area, and the received data was discarded. Keeps the ON-status even after the communication returns to normal. Initialize the error information as necessary. Image 473 Error Code List
0000 (OFF)	Normal	-

#### ■PRO.

PRO. indicates "Character error status".

Value	Status	Description
0001(ON)	Error occurred	Character error occurred. Keeps the ON-status even after the communication returns to normal. Initialize the error information as necessary. SP Page 473 Error Code List
0000(OFF)	Normal	-

#### ■P/S

P/S indicates "Status of parity error or sum check error".

Value	Status	Description
0001(ON)	Error occurred	Parity error or sum check error occurred. Keeps the ON-status even after the communication returns to normal. Initialize the error information as necessary. Image 473 Error Code List
0000(OFF)	Normal	-

#### ■C/N

C/N indicates 'Access status with the CPU module'.

Value	Status	Description
0001(ON)	Error occurred	<ul> <li>The target device issued a data write request to the CPU module when online change is set to 'Disable' in the parameter settings with Engineering tool.</li> <li>For functions that cannot be used when online change is set to 'Disable', refer to the explanation section in each command list in the following manual.</li> <li>(L MELSEC Communication Protocol Reference Manual)</li> <li>An error occurred during the access between C24 and the CPU module.</li> <li>Keeps the ON-status even after the communication returns to normal. Initialize the error information as necessary.</li> <li>Page 473 Error Code List</li> </ul>
0000(OFF)	Normal	-

#### **■NAK**

NAK indicates "Abnormal completion status".

Value	Status	Description
0001(ON)	Abnormal completion transmission	C24 that could not receive data normally sent a response message (NAK message) to the target device to notice the abnormal completion.
0000(OFF)	Normal completion transmission or before data communication	<ul> <li>C24 that could receive data normally sent a response message (ACK message) to the target device to notice the normal completion.</li> <li>Before data is communicated.</li> </ul>

#### ■ACK.

ACK. indicates "Normal completion status".

Value	Status	Description
0001(ON)	Normal completion transmission	C24 that could receive data normally sent a response message (ACK message) to the target device to notice the normal completion.
0000(OFF)	Abnormal completion transmission or before data communication	<ul> <li>C24 that could not receive data normally sent a response message (NAK message) to the target device to notice the abnormal completion.</li> <li>Before data is communicated.</li> </ul>

#### ■NEU.

NEU. indicates "Command message to be received/command message in processing".

NEU. is valid only when MC protocol (format 1 to 5) is set as the communication protocol.

This is in the OFF-status when the communication protocol is set to other than MC protocol.

Value	Status	Description
0001(ON)	Neutral	Waiting for command message to be received.
0000(OFF)	Command reception	Command message is in process.

### Checking transmission setting

Details of transmission settings can be monitored.

#### Window

Module Name	Production information	Monitoring
RJ71C24	Execute	top Monitoring
r Information Module Information List		
Item	Content	-
Individual information		
CH1 Transmission setting_Operation setting	Independent	
CH1 Transmission setting_Data bit	7	
CH1 Transmission setting_Parity bit	None	
CH1 Transmission setting_0dd/even parity	Odd	
CH1 Transmission setting_Stop bit	1	
CH1 Transmission setting_Sumcheck code	None	
CH1 Transmission setting_Online change	Disable	
CH1 Transmission setting_Setting change	Disable	
CH1 Communication speed setting	Automatically set	
CH1 Communication protocol setting	Nonprocedural protocol	
TEST MODE setting		
CH2 Transmission setting_Operation setting	Independent	
CH2 Transmission setting_Data bit	7	
CH2 Transmission setting_Parity bit	None	
CH2 Transmission setting_0dd/even parity	Odd	8
CH2 Transmission setting_Stop bit	1	
CH2 Transmission setting_Sumcheck code	None	
CH2 Transmission setting_Online change	Disable	
CH2 Transmission setting_Setting change	Disable	
CH2 Communication speed setting	Automatically set	
CH2 Communication protocol setting	MELSOFT connection	•
•		۱.

### Displayed items

Item	Description
Operation setting	Independent, Interlink
Data bit	7, 8
Parity bit	None, Yes
Odd/even parity	Odd, Even
Stop bit	1, 2
Sum check code	None, Yes
Online change	Disable, Enable
Setting change	Disable, Enable
Test mode setting	No specification, Hardware test, Self-loopback test
Communication speed setting	1200, 2400, 4800, 9600 ,14400 ,19200 ,28800 ,38400, 57600, 115200, 230400 (bps)
Communication protocol	MELSOFT Connection, MC protocol (format 1 to 5), Nonprocedural protocol, Bidirectional protocol, For interlink operation setting The communication protocol is valid when the test mode setting is set to "No specification".
Station number setting	0 to 31

## Intelligent function module monitor

Check the status information of C24 on the "Intelligent Function Module Monitor" screen. For details of the "Intelligent Function Module Monitor" screen, refer to the following manual.

#### RS-232 control signal status reading method

The following shows how to read the control signal status stored in the buffer memory during communication using RS-232 interface.

This is a read operation to check the signal ON/OFF status of the RS-232 interface when a transmission problem occurs.

#### ■RS-232 control signal status (Un\G596/612)

The RS-232 control signal status is stored as follows:



#### Remarks

For details on signals for RS-232, refer to the following section.

MELSEC iQ-R Serial Communication Module User's Manual (Startup)

Signals output from the C24 side (RS(RTS) and ER(DTR)) are controlled by the system (operating system) of C24. They cannot be directly controlled by the program.

A lag of 100 ms at maximum occurs in the signal status stored in the buffer memory above.

#### Data communication status (transmission sequence status) reading method

The following shows how to read the current data communication status using the MC protocol stored in the buffer memory. This read processing is for checking the data communication status using the MC protocol when a transmission problem occurs.

#### ■Transmission sequence status (Un\G597/613)

The status of data communication using the MC protocol is stored as a numeric value as shown below.



The following shows the correspondence between the numerical values in the transmission sequence status storage area and the data communication status.



Remarks

When the target interface is not set to use the MC protocol, '0' is stored in the 'Transmission sequence status' (Un\G597/613).

#### Current operation status reading method

The following shows how to read the current operation status of C24.

For details on the contents of each parameter setting, refer to the following manual.

Page 422 PARAMETER SETTING

#### ■Operation mode status storage area

The current operation status of C24 is stored in the following buffer memory areas.

• Station number (instruction setting) (Un\G591)



For the correspondence table for the communication speed setting, see the table below. 1: ON 0: OFF

Transmission speed	b11	b10	b9	b8
1200 bps	0	0	1	0
2400 bps	0	0	1	1
4800 bps	0	1	0	0
9600 bps	0	1	0	1
14400 bps	0	1	1	0
19200 bps	0	1	1	1
28800 bps	1	0	0	0
38400 bps	1	0	0	1
57600 bps	1	0	1	0
115200 bps	1	0	1	1
230400 bps	1	1	0	0

## **Error information clear**

This section explains the factors causing the ERR LED to be turned ON and the error code initialization (clear) for C24.

#### Factors causing ERR LED to turn ON

When any of the following errors occurs, its error code is stored in the buffer memory corresponding to the interface (CH) where the error occurred, and the ERR LED turns ON.

Error factor	Error code storage buffer memory			Applicable protocol			
	Address		Name	МС	Nonpr	Bidire	Prede
	CH1	CH2			ocedu ral	ctiona I	fined
Parameter setting error	Un\G515		Parameter setting error, mode switch error	0	0	0	0
Mode switching error	5		status				
On-demand execution error	Un\G598	Un\G614	On-demand execution results	0	×	×	×
Data transmission error	Un\G599	Un\G615	Data transmission result	0	0	0	0
Data reception error	Un\G600	Un\G616	Data reception result	0	0	0	0
Modern function error	Un\G545		Modern function error code	0	0	0	×
MC protocol send error	Un\G602	Un\G618	MC protocol send error code	0	×	×	×
Monitoring device error	Un\G8709	Un\G8965	Programmable controller CPU monitoring function execution result	0	0	0	×
Predefined protocol function error	Un\G16450	Un\G16466	Predefined protocol function error code	×	×	×	0

#### Factors causing ERR LED to flash

When any parameter error was detected, the ERR LED flashes, and the buffer memory address which is set out of the range of the parameter setting value is stored in the error address storage area (Un\G20224 to 20231).

#### Turning OFF the ERR LED and initializing the error codes

Turn 'Error initialization request' (YE) ON to turn the ERR LED OFF and initialize the error code.

- The buffer memory, which is a factor in turning the LED ON, is initialized.
- The protocol execution logs are not initialized.

## Individual station test

When a problem occurs during data communication with a target device, perform an individual station test to check whether or not there is any problem in the operation of C24.

The individual station test consists of the following two tests:

- Hardware test
- Self-loopback test

#### Precautions

- To prevent any problems from occurring, set the CPU module in the STOP state during the individual station test.
- When either one of the interfaces needs to be tested, disregard the test result for the other interface.
- Cable removal and reconnection before and after the self-loopback test should be performed with the power to the station with C24 turned OFF.
- Before starting data communication with the target device after the individual station test, configure the respective setting and connect the cable by checking the specifications for the functions to be used.
- If an error occurs even though the settings have been configured correctly for C24 through an individual station test, please consult your local Mitsubishi representative, explaining a detailed description of the problem.



#### Hardware test

The hardware test is a test to check the memory of C24. Perform the hardware test according to the procedure described below.

#### Operating procedure

- **1.** Test mode setting ( Page 422 PARAMETER SETTING)
- · Set the test mode setting to "Hardware test".
- Configure all of the transmission settings and communication speed setting for the two interfaces according to the transmission specifications for data communication with a target device.
- Set the CPU module in the STOP state, and write the parameters.
- 2. Performing hardware test

By restarting or resetting the CPU module, the test starts automatically in approximately one second. The RUN LED flashes during the test. (Set the CPU module in the STOP state.)

- 3. Checking results of hardware test
- When the result is normal

The RUN LED turns ON and the ERR LED turns OFF.

• When the result is abnormal

The RUN LED turns ON and the ERR LED turns ON.

#### **4.** Completing hardware test

· When the result is normal

Perform an Self-loopback test. ( SP Page 451 Self-loopback test)

Start data communication with the target device according to the following procedure.

- · Configure the parameter settings with Engineering tool. (I Page 422 PARAMETER SETTING)
- · Turn OFF the power for the station with C24, and connect the cable to communicate with the target device.
- $\cdot$  Turn ON the power for the station with C24.
- When the result is abnormal

Check error contents on the items below on the "Intelligent Function Module Monitor" screen of Engineering tool.

Check the error descriptions on the screens by bit-decoding the monitored value (16-bit integer). Each bit corresponds to the following error description.

Buffer memory to be monitored		Description when	corresponding bit	Corrective action	
Bit position	Address		is ON		
	CH1 side: Un\G513	CH2 side: Un\G514			
b0	—		—		—
b1	SIO		When interlink operation is set	Transmission setting error	Check the parameter setting and perform the test
b2	PRO		Protocol setting error		again."
b3	P/S		When independent operation is set	Transmission setting error	PARAMETER SETTING
b4	C/N			Protocol setting error	
b5 to b6	—		—		-
b7	NEU	-	Test completed		-
b8 to b13	-		—		-
b14	—	CH2 ERR	RAM error		Check the module
b15	CH1 ERR	—	ROM error		installation status and perform the test again.*1

\*1 When an error occurs even after performing the test again, please consult your local Mitsubishi representative.

#### Self-loopback test

The self-loopback test is a test to check the communication between C24 and the CPU module and the operation of the data transmit/receive function of C24.

Perform the self-loopback test according to the procedure below.

#### Operating procedure

#### **1.** Connecting cable

· Connect cables to two interfaces as follows:

For the RS-232 interface, connect cables within the connector and install it to the interface.

For the RS-422/485 interface, connect cables on the terminal block.

RS-232 interface (D-Sub 9P female)

C24	Cable connection	
Signal name	Pin No.	
CD(DCD)	1	•
RD(RXD)	2	
SD(TXD)	3	
ER(DTR)	4	•
SG	5	
DR(DSR)	6	•
RS(RTS)	7	
CS(CTS)	8	
CI(RI)	9	



2. Test mode setting ( Page 422 PARAMETER SETTING)

• Set the test mode setting to "Self-loopback test".

- · Configure all of the transmission settings for the two interfaces according to the transmission specifications.
- Set the CPU module in the STOP state, and write the parameters.
- **3.** Performing the self-loopback test
- By restarting or resetting the CPU module, the test starts automatically in approximately one second. The RUN LED flashes during the test. (Set the CPU module in the STOP state.)
- C24 performs the following tests in sequence and repeat them (one test cycle takes approximately one second).

C24 ends the test when all test results become abnormal.

Test item	Description	LED flashes during the test
Checking communication with CPU module	Read and check the CPU module model.	RUN LED
Checking the transmit/receive function of interface	Send and receive data by changing data.	SD LED
		RD LED

4. Checking the results of self-loopback test

· When the result is normal

This test is performed repeatedly. When the ERR LED is OFF, C24 is operating normally.

• When the result is abnormal

The ERR LED turns ON.

#### 5. Completing self-loopback test

• When the result is normal

Start data communication with the target device.

· Configure the parameter settings with Engineering tool. (SP Page 422 PARAMETER SETTING)

- · Turn OFF the power for the station with C24, and connect the cable to communicate with the target device.
- Turn ON the power for the station with C24.
- When the result is abnormal

Check an error description on the "Intelligent Function Module Monitor" screen of Engineering tool.

Check the error descriptions on the screens by bit-decoding the monitored value (16-bit integer). Each bit corresponds to the following error description.

Buffer memory	to be monitored		Description when corresponding bit	Corrective action
Bit position	Address		is ON	
	CH1 side: Un\G513	CH2 side: Un\G514		
b0 to b3	-		-	-
b4	C/N	-	Error occurred on the CPU module.	Remove the cause of error in the CPU module.
			The power supply capacity is insufficient.	Review the power supply capacity.
r r		Module is not mounted correctly.	Mount the module properly.	
		Error on the base unit, extension cable, CPU module, or C24 occurred.	Check for each module and remove the cause of the error. Reconnect the cable correctly. Mount the module properly.	
b5 to b13	—		—	-
b14	-	CH2 ERR	CH2 side communication error	Reconnect the cable
b15	CH1 ERR —		CH1 side communication error	correctly. Review the test wiring connection.

## Loopback test

A loopback test is a test to perform communication with the loopback test function of the MC protocol in order to check the connection between C24 and the target device, the communication function of each device, and the operation of the communication program of the target device.

#### Operating procedure

1. Connecting C24 to a target device

Turn OFF the power for the station with C24 and connect a communication cable to communicate with the target device in order to perform data communication using the MC protocol.

MELSEC iQ-R Serial Communication Module User's Manual (Startup)

- 2. Setting the parameter with Engineering tool
- Configure the parameter settings with Engineering tool, and write the parameters to the CPU module in order to perform data communication using the MC protocol.
- The following shows an example of the settings when performing the loopback test on the interface on the CH1 side.

Parameter setting item		Setting contents
Communication protocol setting		MC protocol (Format 1)
Communication speed setting		9600 bps
Transmission setting	Operation setting	Independent
	Data bit	7
	Parity bit	Yes
	Odd/even parity	Odd
	Stop bit	1
	Sum check code	Yes
	Online change	Disable
Setting change		Disable
Station number setting		0

**3.** Performing loopback test

- By restarting or resetting the CPU module, the communication is enabled in approximately one second. (Set the CPU module in the STOP state.)
- Create a program for the loopback test on the target device side and send a command message as shown below to C24.
- For communication test with 1C frame: TT command

For communication test with 2C/3C/4C frame<sup>\*1</sup>: 0619 command

\*1 When performing communication test with 2C/3C/4C frame, refer to the following manual.

An example of control procedure when the TT command is used in the loopback test (station number: 00, sum check code: Yes) is as shown below.



#### 4. Checking loopback test result

Check for the target device side whether the data in the character area received from C24 in response to the data sent by the target device matches the data in the character area sent by the target device. (C24 sends back to the target device the received data, as is.)

• When the result is normal

The data in the character area that C24 sent back to the target device matches the one the target device had sent.

· When the result is abnormal

The data in the character area that C24 sent back to the target device does not match the one the target device had sent.

5. Completing loopback test

• When the result is normal

Configure the parameter settings with Engineering tool in accordance with the function to be used, and turn ON the power for the station with C24 to start data communication.

· When the result is abnormal

Check the items below, and take corrective actions.

Item	Corrective action
Reviewing the wiring of the connection cable	Check if the connection cable is wired correctly.
Reviewing the parameter setting of C24	Check whether the C24 parameter settings (such as transmission setting and communication speed setting) match that of the target device.
Check the detected error of C24	Check the error contents and take the corrective actions.

# 27.2 How to Clear Programmable Controller CPU Information

This section explains how to clear the programmable controller CPU information.

#### Programmable controller CPU information

This is the information about the access target CPU module type used for communications using MC protocol.
 C24 obtains this information from the access target CPU module at the time of initial access, and stores it inside the C24.
 When accessing for the second time or later, the processing to access to the CPU module get faster in accordance with this information.

• The programmable controller CPU information is cleared in the following cases:

When the programmable controller is powered OFF  $\rightarrow$  ON, or when the CPU module is reset When the programmable controller CPU information clear request is executed

#### If the programmable controller CPU information has not been correctly obtained

The following problems may occur:

- Accessible device range become narrowed. (Error code: 7140H)
- Some of commands and/or devices cannot be used. (Error code: 7142H, 714DH),
- etc.

In the above case, execute the programmable controller CPU information clear request.

Restriction ("

If initial access is made at startup of the access target CPU module or while the network is unstable, the programmable controller CPU information may not be correctly acquired.

#### Operation of the programmable controller CPU information clear request

• Write "4C43H" to the 'Programmable controller CPU information clear request' (Un\G128). (Set by the user)



- The programmable controller CPU information clear processing of C24 is performed.<sup>\*1</sup>
- Upon completion of the clear processing, "0000H" is written to the 'Programmable controller CPU information clear request' (Un\G128). (Set by the C24)



\*1 The 'Transmission sequence status' (Un\G597/613) is also initialized.

27

#### Executing the programmable controller CPU information clear request

- **1.** In the "Intelligent Function Module Monitor" screen, set "4C43H" to the 'Programmable controller CPU information clear request' (Un\G128).
- **2.** Check the 'Programmable controller CPU information clear request' (Un\G128) turns to "0000H" with the Buffer Memory Batch Monitor function.

#### Precautions

- Execute the programmable controller CPU information clear after communication with the target device is stopped. In addition, do not perform data communication with the target device during the programmable controller CPU information clear processing. (If any data are received from the target device during the programmable controller CPU information clear processing, the data will be discarded.)
- When a modem is connected, cut off the line linked with the target device before executing the programmable controller CPU information clear. (The line is cut off at execution of the programmable controller CPU information clear.)
- Do not execute the UINI instruction during the programmable controller CPU information clear processing. If the programmable controller CPU information clear is attempted during execution of the UINI instruction, the clear processing will be executed after completion of the UINI instruction.

## 27.3 Troubleshooting by Symptom

The troubleshooting for any troubles generated during communication between C24 and the target device by trouble symptom are as shown below.

When any trouble occurs, check on the C24 condition at first, and check the relevant item in the table below.

Symptom	Symptom description	Protocol			
		MC	Nonpro cedural	Bidirec tional	Predefi ned
LED turns ON or flashes <sup>*1</sup>	SP Page 459 SD LED does not flash even after a send request was made	0	0	0	0
	SP Page 459 RD LED does not flash even though the target device is transmitting a message	0	0	0	0
	Series Page 460 No response message is returned even though the target device transmitted a message and the RD LED flashes	0		0	
	Series Page 461 Read request signal does not turn ON even though the target device transmitted a message and the RD LED flashes		0	0	
	SP Page 462 The CPRTCL instruction execution is not completed although the RD LED flashes				0
	Page 463 RUN LED turns OFF	0	0	0	0
	☞ Page 463 ERR LED flashes	0	0	0	0
	Page 464 ERR LED turns ON	0	0	0	0
	Page 465 C ERR LED turns ON	0	0	0	0
Communication error occurred	$^{\complement}$ Page 466 Hardware information communication error "SIO" $\rm occurs^{*2}$	0	0	0	0
	$^{\texttt{CP}}$ Page 467 Hardware information communication error "PRO." $_{\texttt{occurs}^{*2}}$	0			
	S <sup>®</sup> Page 468 Hardware information communication error "P/S" occurs <sup>*2</sup>	0	0	0	0
	$^{\texttt{CF}}$ Page 468 Hardware information communication error "C/N" occurs $^{*2}$	0	0	0	0
	$^{\texttt{K3}^{\texttt{m}}}$ Page 469 Hardware information communication error "NAK" occurs $^{\texttt{*2}}$	0			
	Page 469 Communication is intermittent	0	0	0	0
	Page 470 Undecodable data are transmitted or received	0	0	0	0
	SP Page 471 Whether the communication error is caused on C24 or target device is unclear	0	0	0	0
Communication via modem cannot	Page 471 Communication is not established via modem	0	0	0	
be established <sup>*3</sup>	SP Page 472 Communication is not established with the ISDN sub- address when using a modem	0	0		
The programmable controller CPU	Page 472 Fixed cycle send is not performed normally	0	0		
monitoring function does not operate in the specified cycle	SP Page 472 Condition match send is not performed normally	0	0		
Data cannot be received by an interrupt program	SP Page 472 Data cannot be received by an interrupt program		0	0	
The initial setting cannot be configured	SP Page 472 Data cannot be written to flash ROM	0	0	0	0

\*1 For details on LED status, refer to the following manual.

MELSEC iQ-R Serial Communication Module User's Manual (Startup)

\*2 For details on how to check the hardware information communication error, refer to the following section.

Page 441 Checking error status

\*3 If an error occurs while performing data communication using the modem function, first check the following items and determine whether or not the error is caused by the modem/TA connection.

If an error relating to the modem function occurs, take corrective actions according to the following items shown below:

- $\cdot$  Check of the ON/OFF status of current input/output signals on C24
- $\cdot$  Check of the error code storage status for the modem function

· Check of the ON/OFF status of the DR terminal on the modem/TA (Refer to the instruction manual for modem/TA.)

457

#### Precautions

The considerations for data communication with the target device via either of C24 interfaces are shown below:

- When powering up the C24 side or the target device side, data reception error may occur at the target device side being connected.
- When the connected target device side starts up during data transmission, the data reception error occurs at the target device side.
- When the ERR LED on C24 turns ON due to data reception error, turn OFF the LED as necessary. ( Frage 448 Turning OFF the ERR LED and initializing the error codes)

Also, when a data reception error occurs on the target device side, take corrective actions in accordance with the instruction manuals for the target device.

#### ■Error occurred on the C24 side

Handle the error as shown below when data reception error occurs on C24 side.

- For communications using the MC protocol
   C24 will disregard the received data or return a response message indicating an abnormal completion if it detects a data reception error after receiving the head data of the command message in the set format.
   If the data reception error is detected before the head data of the command message in the set format is received, the received data will be disregarded.
- · When communicating using the predefined protocol

C24 will store the error code in the 'Data reception result' (Un\G600/616) when a data reception error occurs. Reception error can be also checked with the send/receive data monitoring function.

Take appropriate measures such as detecting a data reception error or clearing the received data, if necessary. For more details on the send/receive data monitoring function, refer to the following section.

( Page 387 USING SEND/RECEIVE DATA MONITORING FUNCTION)

- When communicating using nonprocedural protocol
   C24 will turns ON the reception abnormal detection (X4/XB) when it detects a data reception error.
   Take appropriate measures such as detecting a data reception error or clearing the received data, if necessary.
   (I Page 65 Reception error detection and check methods, Page 67 Receive data clear)
- · For communications using bidirectional protocol

C24 will return a response message indicating an abnormal completion if it detects a data reception error after receiving the head data of the communication message for the bidirectional protocol.

If the reception error is detected before the head data of the communication message for the bidirectional protocol is received, the received data will be disregarded.

#### Meaning of abbreviations in "Protocol" column

MC: MC protocol Non: Nonprocedural protocol Bi: Bidirectional protocol Pd: Predefined protocol

## SD LED does not flash even after a send request was made

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
SD LED does not flash even after a send request was made.	The CS(CTS) signal is in the OFF-state, and C24 cannot transmit data to the external device.	<ul> <li>While the CS(CTS) signal is OFF, C24 does not transmit data to the target device.</li> <li>Connect so that it is constantly ON when the target device is ready to receive data.</li> </ul>	0	0	0	0
	Due to the transmission control (DTR control, DC control), the external device cannot receive data.	<ul> <li>Wait until the external device is ready to receive data.</li> <li>Check the external device or the cable condition when it takes too long for the external device to be ready to receive data.</li> </ul>	0	0	0	0

## RD LED does not flash even though the target device is transmitting a message

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
RD LED does not flash even though the target device is transmitting a message.	Signal lines are not connected correctly.	<ul> <li>Cross-connect the RD(RXD) and SD(TXD) signals between C24 and the target device.</li> <li>When using MX Component, match the port opened by the OPEN statement of the target device with the cable connection port.</li> </ul>	0	0	0	0
	The transmission control signals on the target device side have not turned ON.	<ul> <li>Connect the wiring so that the transmission control signals including DR(DSR) and CS(CTS) are ready.</li> <li>Remarks</li> <li>The Specifications of control signal vary depending on the device. Perform the wiring in accordance with the instruction manual of the device used.</li> </ul>	0	0	0	0
	If the message passes through a modem or others, the signal is interrupted at the side of device relaying the message.	<ul> <li>Check the specification of the modem to review the settings and wiring, and correct them if necessary.</li> </ul>	0	0	0	

27

## No response message is returned even though the target device transmitted a message and the RD LED flashes

Symptom	Cause	Corrective action	MC	Non	Bi	Pd
The target device transmitted a message and RD LED flashes, but C24 does not return the response message.	Communication protocol setting is incorrect.	<ul> <li>Review the communication protocol setting.</li> <li>Review the program whether unintended mode switching is performed when the buffer memory mode switching area is used for mode switching.</li> <li>Remarks</li> <li>The communication protocol setting contents and the communication protocol currently in operation can be checked at the following addresses.</li> <li>'Communication protocol status (parameter setting)' (Un\G592/608) set by the parameter</li> <li>'Communication protocol status (current)' (Un\G594/610) currently in operation</li> </ul>	0			
	The CD terminal has been turned OFF when the CD terminal check is enabled.	<ul> <li>Change the wiring so that the CD terminal remains ON all the time since a message is initialized (skipped) if the CD terminal is OFF when the CD terminal check is set to be enabled.</li> </ul>	0		0	
	The header byte of the message is not data needed for the set protocol and format.	<ul> <li>Check the data transmitted from the target device with the Circuit Trace function of Engineering tool, and take the following corrective actions.</li> <li>If the format of message sent from the target device does not match with the respective protocol and format, correct the massage format according to the relevant protocol and format used.</li> <li>Remarks</li> <li>C24 skips all the messages transmitted until the header byte specified for each protocol and format (for example, "ENQ(05H)" for format 1) is received.</li> </ul>	0		0	
	C24 station number setting and message station number designation do not match.	<ul> <li>Check the data transmitted from the target device with the Circuit Trace function of Engineering tool, and take the following corrective actions.</li> <li>Match the station number setting of C24 with the station number designation of the message.</li> <li>Remarks</li> <li>C24 performs the data reception processing when the station No. designation is the host station after the header byte specified for each protocol and format is received.</li> </ul>	0			
	The C24 data communications monitoring time is set to "Unlimited wait", or the monitoring time is too long.	<ul> <li>Set or shorten the monitoring time and retransmit the message from the target device and determine the trouble from the contents of the time-out error.</li> <li>Remarks</li> <li>Error detection by the monitoring time (timer 0 to timer 2) is possible in the following cases.</li> <li>When part of a message is skipped.</li> <li>When transmission from the target device is interrupted.</li> <li>A link error occurred when accessing to the other station via CC-Link IE Controller Network or CC-Link IE Field Network.</li> <li>For details of the monitoring time, refer to the following manual.</li> <li>Page 227 CHANGING DATA COMMUNICATION MONITORING TIME</li> </ul>	0		0	
	The route setting of the access target CPU module is incorrect.	Check the route of the access target CPU module, and set the route again.	0			

## Read request signal does not turn ON even though the target device transmitted a message and the RD LED flashes

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
request' (X3/XA) does not turn ON even though the target device transmitted a message and the RD LED flashes.	Communication protocol setting is incorrect.	<ul> <li>Review the communication protocol setting.</li> <li>Review the program whether unintended mode switching is performed when the buffer memory mode switching area is used for mode switching.</li> <li>Remarks</li> <li>The communication protocol setting contents and the communication protocol currently in operation can be checked at the following addresses.</li> <li>'Communication protocol status (parameter setting)' (Un\G592/608) set by the parameter</li> <li>'Communication protocol status (current)' (Un\G594/610) currently in operation</li> </ul>		0	0	
	The CD terminal has been turned OFF when the CD terminal check is enabled.	<ul> <li>Change the wiring so that the CD terminal remains ON all the time since a message is skipped if the CD terminal is OFF when the CD terminal check is set to be enabled.</li> </ul>		0	0	
	When DC control is selected, the necessary DC codes are not transmitted.	<ul> <li>Check the data transmitted from the target device with the Circuit Trace function of Engineering tool, and take the following corrective actions.</li> <li>During DC1/DC3 control, if the target device transmits 'DC3(13H)' and interrupts the transmission processing of C24, transmit 'DC1(11H) at first and then the next message after the transmission processing of C24 resumed.</li> <li>During DC2/DC4 control, if the target device transmits the next message without adding 'DC2(12H)' after transmitting 'DC4(14H)', transmit a message with 'DC2(12H) added.</li> </ul>		0	0	
	The end code has not been received, or the fixed length data has not been received.	Check the data transmitted from the target device with the Circuit Trace function of Engineering tool, and take the following corrective actions. • Match the end code set by the receive end code designation of C24 with the one sent from the target device. • Match the data quantity set by the receive end data quantity of C24 with the data length sent from the target device. • For communication with the user frame, send the message with the final frame added to the end from the target device. ■Remarks When proper data are being transmitted from the target device, take the corrective action by referring to the troubleshooting below. • CIP Page 466 Hardware information communication error "SIO" occurs • CIP Page 463 ERR LED flashes		0	0	
	The C24 setting and message format do not match.	The interpretation of data count, or message format, etc. varies depending on the settings below. Review the settings of each item and the operation by the settings in accordance with the relevant descriptions. • ASCII-BIN conversion enable/disable • Transparent code setting • User frame setting		0	0	
	The C24 data communications monitoring time is set to "Unlimited wait", or the monitoring time is too long.	<ul> <li>Set or shorten the monitoring time and retransmit the message from the target device and determine the trouble from the contents of the time-out error.</li> <li>Remarks</li> <li>In the cases below, errors can be detected by setting each monitoring time (timer 0 to 2).</li> <li>When part of a message is skipped.</li> <li>When transmission from the target device is interrupted.</li> <li>For details of the monitoring time, refer to the following manual.</li> <li>Page 227 CHANGING DATA COMMUNICATION MONITORING TIME</li> </ul>		0	0	

# The CPRTCL instruction execution is not completed although the RD LED flashes

Symptom	Cause	Corrective action	MC	Non	Bi	Pd
When the CPRTCL instruction was executed for	Incorrect protocol number is specified in the control data.	<ul> <li>Review the protocol number specified in the control data for the CPRTCL instruction.</li> </ul>				0
the protocol with the communication type set to "Receive Only" or "Send & Receive" BD LED flashes	The CD terminal has been turned OFF when the CD terminal check is enabled.	<ul> <li>Change the wiring so that the CD terminal remains ON all the time since a message is skipped if the CD terminal is OFF when the CD terminal check is set to be enabled.</li> </ul>				0
but the instruction execution is not completed.	The user-edited protocol setting with the Predefined protocol support function of Engineering tool is inconsistent with the packet format of the target device.	<ul> <li>Check the packet format of the target device, and review the protocol setting.</li> <li>In the packet setting, are the element type and element order incorrect?</li> <li>Is each element setting item (Code type, Data length, Data flow, Calculating range, etc.) incorrect?</li> </ul>				0
	C24 has not received the expected packet.	Check the data transmitted from the target device with the Circuit Trace function of Engineering tool, and correct the message if it's incorrect. When proper data are being transmitted from the target device, take the corrective action by referring to the troubleshooting below. • IF Page 463 ERR LED flashes • IF Page 469 Communication is intermittent				0
	C24 has cleared the data received before the protocol execution. (On the "Protocol Detailed Setting" screen of Engineering tool predefined protocol support function, "Clear receive data before protocol execution" is designated.)	When data may be received before protocol execution, unselect the checkbox for "Clear OS area (receive data area) before protocol execution" on the "Protocol Detailed Setting" screen of Engineering tool predefined protocol support function.				0
	The C24 data communications monitoring time is set to "Unlimited wait", or the monitoring time is too long.	<ul> <li>Perform cancel processing to complete the CPRTCL instruction execution.</li> <li>Set or shorten the monitoring time and retransmit the message from the external device and determine the trouble from the contents of the time-out error.</li> <li>Remarks</li> <li>In the cases below, errors can be detected by setting the receive wait time for the "Receive Setting" on the "Protocol Detailed Setting" screen of Engineering tool predefined protocol support function.</li> <li>When part of a message is skipped.</li> <li>When transmission from the target device is interrupted.</li> </ul>				0

## **RUN LED turns OFF**

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
RUN LED on C24 turns OFF	The module is not mounted properly.	Mount the C24 on the base unit properly.	0	0	0	0
	Power module 5 VDC consumption current is insufficient.	<ul> <li>Calculate the 5 VDC consumption current of each mounted module. If the current capacity is insufficient, review power module selection.</li> </ul>	0	0	0	0
	Extraneous noise causes abnormal operation of C24.	<ul> <li>Review the wiring so that the shield is single-point grounded.</li> <li>When ground is used with other devices, ground the C24 independently.</li> </ul>	0	0	0	0

## ERR LED flashes

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
ERR LED flashes.	The communication protocol setting or transmission setting is incorrect.	<ul> <li>Read the error code from the buffer memory, and check the error contents and change to the correct setting.</li> </ul>	0	0	0	0
	The parameter settings are incorrect.	<ul> <li>Review the parameter settings with Engineering tool. Then, write the parameter settings to the CPU module, and reset it.</li> <li>Review each settings for the parameters set in the buffer memory, and turn ON the 'CH□ mode switching request' (Y2/Y9). For more details on 'CH□ mode switching request', refer to the following section.</li> <li>(▷ Page 380 I/O Signals for Handshake with CPU Module and Buffer Memory)</li> </ul>	0	0	0	0
	The protocol setting data stored in the CPU module is not for MELSEC iQ-R series C24.	Write the protocol setting data for MELSEC iQ-R series C24 to the CPU module.				0

#### Remarks

The error code when ERR LED flashes is stored in the buffer memory shown below.

Error factor	Error code storage buffer memory				
	Address	Name			
	CH1	CH2			
Parameter setting error	Un\G515		Parameter setting error, mode switching error status		
Parameter error (Module parameter)	Un\G20224 to 20231		Error address storage area		

## ERR LED turns ON

Symptom	Cause	Corrective action		Non	Bi	Pd
ERR LED turns ON.	The online mode switching designation is incorrect.	<ul> <li>Read the error code from the buffer memory, and check the error contents and correct the designation contents.</li> </ul>	0	0	0	0
	The receive data clear request is executed during the dedicated instruction execution.	<ul> <li>Read the execution result (error code) of control data for the dedicated instruction of which the abnormal completion signal has turned ON, and take the corrective action corresponding the error contents.</li> </ul>	0	0	0	0
	The power of C24 was turned OFF while writing to the flash ROM.	Write the data again to the flash ROM.	0	0	0	0
	An error is detected.	• Check if any symptom corresponding to the troubleshooting by symptom occurs, and remove the cause of the error. ( ISP Page 457 Troubleshooting by Symptom)	0	0	0	0
When the predefined protocol is executed, the ERR LED turns ON.	The communication protocol setting is set to other than "Predefined protocol".	<ul> <li>Set the communication protocol setting to "Predefined protocol".</li> </ul>				0
	No protocol setting data has been written.	<ul> <li>Write the protocol setting data with the Predefined protocol support function of Engineering tool, and then execute the CPRTCL instruction.</li> </ul>				0
	The protocol corresponding to the protocol number specified in the control data for the CPRTCL instruction is not registered.	<ul> <li>Read the protocol setting from C24 with the Predefined protocol support function of Engineering tool.</li> <li>On the "Add Protocol" screen, check for the registered protocol and protocol No., and correct them if incorrect.</li> </ul>				0
	Multiple CPRTCL instructions were simultaneously executed to the same channel.	Review the program so that the next CPRTCL instruction is executed once one CPRTCL instruction execution is completed.				0
	Incorrect control data are specified for the CPRTCL instruction.	Review the control data for the CPRTCL instruction.				0
	The edited protocol setting with the Predefined protocol support function of Engineering tool is inconsistent with the packet format of the target device.	<ul> <li>Check the packet format of the target device, and review the protocol setting taking the following into consideration.</li> <li>When a Conversion variable exists in the received packet, are conversion contents or the settings for sign character, number of decimals, or number of digits incorrect?</li> <li>When a check code exists in the received packet, are the processing method or the settings for code type, data length, data flow, complement calculation, or calculating range incorrect.</li> <li>When a Length exists in the received packet and a Conversion variable is included in the calculating range of the Length, are the code type or the settings for data length, data flow, or calculating range incorrect?</li> <li>Check the data transmitted from the target device with the Circuit Trace function of Engineering tool and correct if if the</li> </ul>				0
	monitoring timeout error occurred.	Check the error description with the System Monitor				
	occurred.	function, and remove the cause of the error.				

#### Remarks

The error code when ERR LED turns ON is stored in the buffer memory shown below.

Error factor	Error code storage buffer memory					
	Address	Name				
	CH1	CH2				
Modern function error	Un\G545	·	Modern function error			
Monitoring device error	Un\G8709	Un\G8965	Programmable controller CPU monitoring function execution result			
Predefined protocol function error	Un\G16450	Un\G16466	Predefined protocol function error code			

## C ERR LED turns ON

Symptom	Cause	Corrective action	мс	Non	Bi	Pd
C ERR LED turns ON.	An error occurred during the on-demand execution.	Read the error code from the buffer memory, and check the error contents and correct the designation contents.	0			
	C24 detected an error while transmitting data.	<ul> <li>Read the error code from the buffer memory, and take the corrective action corresponding to the error contents.</li> </ul>	0	0	0	0
	C24 detected an error while receiving data.	<ul> <li>Read the error code from the buffer memory, and take the corrective action corresponding to the error contents.</li> </ul>	0	0	0	0

Remarks

The error code when C ERR LED turns ON is stored in the buffer memory shown below.

Error factor	Error code storage buffer memory					
	Address		Name			
	CH1 CH2					
On-demand execution error	Un\G598	Un\G614	On-demand execution results			
Data transmission error	Un\G599	Un\G615	Data transmission result			
Data reception error	Un\G600	Un\G616	Data reception result			
Modern function error	Un\G545		Modern function error code			
MC protocol send error	Un\G602	Un\G618	MC protocol send error code			
Monitoring device error	Un\G8709	Un\G8965	Programmable controller CPU monitoring function execution result			
Predefined protocol function error	Un\G16450	Un\G16466	Predefined protocol function error code			

## Hardware information communication error "SIO" occurs

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Hardware information communication error "SIO" occurs.	The stop bit settings do not match.	Match the stop bit settings of C24 to that of the target device.		0	0	0
	Transmission speed is too fast and the next data is transmitted before C24 completes processing of the receive data.	Decrease the transmission speed and restart data communications.	0	0	0	0
	Data larger than the receive buffer size was received.	<ul> <li>Use the DTR and DC controls to interrupt transmission before the buffer becomes full. Perform RS/CS control when the modem function is used.</li> <li>Lengthen the transmission interval and take sufficient time for the read processing of the CPU module side.</li> <li>Remarks</li> <li>For the nonprocedural protocol, data up to the end code received at first or fixed length data is stored in the nonprocedural reception buffer memory area, and C24 turns ON the read request to the CPU module.</li> <li>When the next data is sent while the read request is ON, the data is temporarily stored in the operating system receive buffer. When the operating system receive buffer becomes full, C24 skips the rest of the data and turns ON the "SIO" LED.</li> </ul>		0	0	0
	During multidrop connection, two or more devices transmitted data at the same time.	<ul> <li>Connect the target devices to C24 on a 1:1 basis and perform a communications test.</li> <li>If C24 can communicate normally with each of all target devices, two or more devices transmit data simultaneously during multidrop communication. Therefore, interlock the devices not to transmit at the same time.</li> </ul>	0	0		0
# Hardware information communication error "PRO." occurs

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Hardware information communication error signal "PRO." turns ON.	Communications were performed with a control procedure different from the C24 communication protocol setting.	<ul> <li>Check the data transmitted from the target device with the Circuit Trace function of Engineering tool, and take the following corrective actions.</li> <li>Check the C24 communication protocol setting and the message from the target device and match the settings, or</li> </ul>	0			
	Some of the data are different from the control procedure.	correct the message and restart data communications.	0			
	Designated command does not exist.		0			
	The device number designation is not the character count corresponding to the command.		0			
	The characters in the message include a data other than the "A to Z", "0 to 9", "(SP)", and control data.	<ul> <li>Check the data transmitted from the target device with the Circuit Trace function of Engineering tool, and correct it if the message is in correct.</li> <li>■Remarks</li> <li>Only the data "0 to 9" and "A to F" can be handled as character area data during communications using MC protocol (ASCII mode).</li> <li>Therefore, when transmitting a character string as data, convert the ASCII code of each character string to 2-byte ASCII code.</li> <li>Transmitting the character "G" The ASCII code for "G" is 47H, and is transmitted as the two bytes 34H, 37H.</li> <li>Transmitting the character "A" The ASCII code for "A" is 41H, and is transmitted as the two bytes 34H, 31H. (When 41H, ASCII code for "A" is transmitted unchanged, C24 ASCII↔BIN conversion will convert it to AH(10) and pass it to the CPU module.)</li> </ul>	0			
	A device number outside the designated range was designated.	<ul> <li>When specifying a device, check "Device Setting" of the parameters written to the CPU module and correct it to a device No. within the designated range and restart data communications.</li> </ul>	0			

27



# Hardware information communication error "P/S" occurs

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Hardware information communication error signal "P/S" turns ON.	The parity bit settings do not match.	<ul> <li>Review the data format between C24 and the target device, and match the settings.</li> </ul>	0	0	0	0
	Sum check codes do not match.	<ul> <li>Calculate to check if the sum check code transmitted from the target device is correct, and correct the sum check code if it's incorrect.</li> </ul>	0			
	When CH1 and CH2 are set for the interlink operation, there is an interface to which the cable is not connected.	<ul> <li>When using CH1 and CH2 for the interlink operation, connect the cable to both of the interfaces.</li> <li>When using CH1 and CH2 for the independent operation, reconfigure the setting to the independent operation if it is set to the interlink operation.</li> <li>Remarks</li> <li>If the cable is not connected to one of the interfaces when CH1 and CH2 are used for the interlink operation, the data may be destroyed due to noise and may result in 'data cannot be decoded' or 'cause of communications error'.</li> </ul>	0	0	0	

## Hardware information communication error "C/N" occurs

Symptom	Cause	Corrective action	MC	Non	Bi	Pd
Hardware information communication error signal "C/N" turns ON.	PC number is specified to the self-station (FF), or a station other than the station number set with the network parameter.	<ul> <li>Change the PC number to the self-station (FF) or the station number set with the network parameter, and restart data communications.</li> </ul>	0			
	Routing parameters between the CPU module with C24 mounted and the communication destination CPU module are not set.	Check the routing parameters and set them up to the communication destination CPU module.	0			
	Errors occurred on CC-Link IE Controller Network or CC-Link IE Field Network.	<ul> <li>Check the error contents by the status of SB and SW related to CC-Link IE Controller Network and CC-Link IE Field Network with the monitor function of Engineering tool etc., and take corrective actions in accordance with the reference manuals for respective network.</li> </ul>	0			
	Errors occurred on the CPU module of the host station on CC-Link IE Controller Network or CC-Link IE Field Network.					
	Module installation address designation for communications with Intelligent function module is incorrect.	Change the transmission message designation data.	0			
	A command that cannot be	Stop the CPU module and restart data communications.	0			
	transmitted during RUN (program, parameters, etc.) was transmitted, or "Online change" is set to be disabled.	Enable the "Online change" by command and restart data communications.	0			

# Hardware information communication error "NAK" occurs

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Hardware information communication error signal "NAK" turns ON.	Refer to section which describes the communication error signal ("C/N", "P/S", "PRO", "SIO") that are turned ON simultaneously when the "NAK" signal is turned ON.	Take corrective action corresponding to the contents of the error.	0			
	■Remarks When the "NAK" signal is turne C24 to the target device. Take t C3 Page 473 Error Code List In addition, the error code when below, so it can be checked at t • Error code storage buffer me CH1 side: Un\G602 CH2 side: Un\G618	d ON, the error code is added to "NAK" and is transmitted from he corrective action depending on the error code listed below. "NAK" is transmitted is stored to the C24 buffer memory shown he C24 side as well. mory				

## **Communication is intermittent**

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Communications are intermittently established and lost.	During multidrop connection, two or more devices transmitted data at the same time.	<ul> <li>Connect the target devices to C24 on a 1:1 basis and perform a loopback test.</li> <li>If C24 can communicate normally with each of all target devices, two or more devices transmit data simultaneously during multidrop communication. Therefore, interlock the devices not to transmit at the same time.</li> </ul>	0	0	0	0
	The signal cable wiring has a loose connection.	Replace the cable, or make the connections firm.	0	0	0	0
	The CD(DCD) signal turns ON/OFF repeatedly when the CD terminal check is enabled.	<ul> <li>Change the wiring so that the CD(DCD) signal remains ON all the time, or change the setting so that the CD terminal check is disabled.</li> </ul>	0	0	0	0
-	When half-duplex communications is set, the ON/OFF timing of each signal does not match.	<ul> <li>Control at the target device side so that the ON/OFF timing of each signal matches.</li> <li>For details, refer to the following section.</li> <li>(Image 243 DATA COMMUNICATIONS USING HALF- DUPLEX COMMUNICATIONS)</li> </ul>		0	0	0
	The next transmission processing was requested before a previous transmission processing had been completed.	<ul> <li>Make sure to obtain handshake in the program.</li> </ul>	0	0	0	0
	The next reception processing was requested before a previous reception processing had been completed.					
	Communication via modem is disrupted.	<ul> <li>Since communication via modem may be disrupted due to low line quality or instantaneous interruption, create a program for reconnecting the line in case of unexpected line disruption.</li> <li>If this symptom occurs frequently, reduce the communication rate of the modem, and retry the communication.</li> </ul>	0	0	0	
	The data sent from C24 are received back to the RS-422/ 485 interface (CH2) side.	Disable the echo back with the Echo back enable/disable designation before communication.	0	0	0	0



### When a normal completion response message cannot be received

The following explains how to take corrective actions when a normal completion response message cannot be received upon command message transmission.

### An abnormal completion response message is received

When a target device received an abnormal completion response message in response to the sent command message, take corrective action according to the error code in the response message. ( Page 473 Error Code List)

When the following problem occurs at the time of access to other station CPU module, clear the programmable controller CPU information and retry. ( Page 455 How to Clear Programmable Controller CPU Information)

- Accessible device range became narrow. (Error code: 7140H)
- Some of commands and/or devices cannot be used (Error code: 7142H, 714DH) etc.

### ■Response messages cannot be received

Change the setting value for the response monitoring time (timer 1, 5 seconds by default). (SP Page 422 PARAMETER SETTING)

If response messages still cannot be received even after changing the setting value, check the communication protocol setting for the relevant interface, the ON status of the indicator LED, and the connection cable.

### The first part of a response message cannot be received

Increase the setting value of the transmission wait time (the default value is 0 ms). ( Page 422 PARAMETER SETTING) If response messages still cannot be received even after increasing the setting value, reducing the processing time from the end of transmission processing to the start of reception processing on the target device side is required.

### Undecodable data are transmitted or received

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Data that cannot be decoded was transmitted and received.	During multidrop connection, two or more devices transmitted data at the same time.	<ul> <li>Connect the target devices to C24 on a 1:1 basis and perform a loopback test.</li> <li>If C24 can communicate normally with each of all target devices, two or more devices transmit data simultaneously during multidrop communication. Therefore, interlock the devices not to transmit at the same time.</li> </ul>	0	0	0	0
	The parity bit settings do not match.	<ul> <li>Match the settings of C24 with that of the target device.</li> <li>Remarks</li> </ul>	0	0	0	0
	The bit length settings for the stop bit do not match.	If '7 bits' is set to the data bit with the parity bit set to 'Yes' at one side and '8 bits' is set to the data bit with the parity bit set to 'None' at the other side, the transmitted/received bit number will be the same. Therefore, data transmission/reception can be possible without error.	0	0	0	0
	Transmission speed settings do not match.	<ul> <li>Match the transmission speed of C24 with that of the target device.</li> </ul>	0	0	0	0
	During multidrop connection, the terminating resistor is not connected correctly.	• Connect the terminating resisters to the stations of both ends. (110 $\Omega$ or 330 $\Omega$ for C24)	0	0	0	0
	When CH1 and CH2 are set for the interlink operation, there is an interface to which the cable is not connected.	<ul> <li>When using CH1 and CH2 for the interlink operation, connect the cable to both of the interfaces.</li> <li>When using CH1 and CH2 for the independent operation, reconfigure the setting to the independent operation if it is set to the interlink operation.</li> <li>Remarks</li> <li>If the cable is not connected to one of the interfaces when CH1 and CH2 are used for the interlink operation, the data may be destroyed due to noise and may result in 'data cannot be decoded' or 'cause of communications error'.</li> </ul>	0	0	0	

# Whether the communication error is caused on C24 or target device is unclear

Symptom	Cause	Corrective action	MC	Non	Bi	Pd
Whether the communications	—	Perform the following tests on the C24 side to investigate	0	0	0	0
error is caused on the C24		where the cause is.				
side or the target device side		Check the hardware.				
is unclear.		C24 is mounted correctly.				
		The pins of C24 has no abnormalities such as bent.				
		Perform the individual station test on C24. (     Page 449				
		Individual station test)				
		No errors occur by the hardware test.				
		No errors occur by the self-loopback test.				
		Check the CPU module condition.				
		No errors that stop the CPU module operation occur.				
		■Remarks				
		The following methods are available for testing if normal				
		communications are possible with C24 alone.				
		<ul> <li>For single C24, set CH1 and CH2 to the nonprocedural</li> </ul>				
		protocol with self-loopback wiring.				
		When data transmitted from one channel and data received				
		at the other channel match, the transmission/reception				
		processing is performed normally.				
		When two C24s are used, set one C24 to the nonprocedural				
		protocol and the other C24 to the MC protocol, and transmit				
		an MC protocol message from the station which is set to the				
		nonprocedural protocol. If the station which is set to the MC				
		protocol returns the transmission message normally,				
		transmission/reception processing is performed normally.				

## Communication is not established via modem

Symptom	Cause	Corrective action	MC	Non	Bi	Pd
Auto modem initialization cannot be performed.	A modem initialization error occurs.	Check the error code and take corrective actions.	0	0	0	
	Modem connection CH specification is not performed.	Set the modem connection CH specification.	0	0	0	
	he parameter settings are	Set the parameters to match the host station modem/TA.	0	0	0	
	incorrect.	Review the parameter settings below with Engineering tool. Then, write the parameter settings to the CPU module, and reset it. • Communication speed setting • Transmission setting • Communication protocol setting • Station number setting				

# Communication is not established with the ISDN sub-address when using a modem

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Data cannot be communicated with ISDN sub-address	Sub-address is incorrect.	Review the sub-address.	0	0		
	The modem does not support ISDN sub-address.	Use modem supporting ISDN sub-address.	0	0		
	Delimiter code for sub- address is incorrect.	Review the delimiter code in accordance with the manual for the TA.	0	0		

## Fixed cycle send is not performed normally

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
The programmable controller CPU monitoring function does not operate in the cycle time designated by the fixed	The setting value of the fixed cycle send is incorrect.	<ul> <li>Review the settings for the fixed cycle send.</li> <li>(Check if the cycle shorter than the one calculated with the monitoring timing of the CPU module has been set, etc.</li> <li>(Image 123 Monitoring timing of CPU module))</li> </ul>	0	0		
cycle send setting.	The cycle time is affected by some causes.	<ul> <li>Remove the causes or designate the cycle time taking the causes into consideration.</li> </ul>	0	0		

## Condition match send is not performed normally

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
The programmable controller CPU monitoring function does not operate in the cycle time designated by the	The setting value of the condition match send is incorrect.	• Review the settings for the condition match send. (Check if the setting value of the programmable controller CPU monitoring function designation is incorrect. (CP Page 125 Condition match send))	0	0		
condition match send setting.	The cycle time is affected by some causes.	<ul> <li>Remove the causes or designate the cycle time taking the causes into consideration.</li> </ul>	0	0		

## Data cannot be received by an interrupt program

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Data cannot be received by an interrupt program.	C24 receives data by an instruction other than BUFRCVS.	Use BUFRCVS instruction to receive interrupt data.		0	0	
	The parameter settings for C24 from [Module Parameter] ⇒ [Interrupt Settings] are not configured, or the settings are incorrect.	Review the parameter settings from [Module Parameter] ⇔ [Interrupt Settings].		0	0	

### Data cannot be written to flash ROM

Symptom	Cause	Corrective action	МС	Non	Bi	Pd
Data cannot be written to the flash ROM.	The setting change is not set to be enabled in the parameter settings with Engineering tool.	Set the setting change to 'Enable' with Engineering tool.	0	0	0	0
Data written to flash ROM are not valid.	The power of C24 was turned OFF while writing to the flash ROM.	Write the data again to the flash ROM.	0	0	0	0
	Communication with Engineering tool was interrupted while writing to the flash ROM.					

# 27.4 Error Code List

This section explains the error codes, error contents, and corrective actions for errors may occur during data communication and when using the modem function.

The signal name in the table shows the LED lighting status and communication error status stored in the 'CH<sup>I</sup> side LED lighting status, communication error status' (Un\G513/514) when error occurs.

The CH side LED lighting status and communication error status can be checked with the System Monitor function or the Intelligent Function Module Monitor function of Engineering tool.

Note that "NAK" turns ON for errors which occur by the MC protocol communication and the signal name is not indicated. For the error code when communicating using 1C frame, refer to the following manual.

MELSEC-L Serial Communication Module User's Manual (Basic)

Error code (hexadecima	Error	Description	Signal	Corrective action	Protocol				
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined	
2242H	Module parameter error	<ul> <li>Incorrect setting value was set to the module parameter.</li> </ul>	ERR.	Set the correct value to the module parameter, and rewrite it to the CPU module.	0	0	0	0	
2250H 20E0H	Module extended parameter error	<ul> <li>The written module extended parameter setting is any of the following:</li> <li>The module extended parameter for other module was written to the CPU module.</li> <li>The predefined protocol setting has an error.</li> <li>The data for the set item is corrupted.</li> <li>C24 cannot communicate</li> </ul>	CHn ERR.	<ul> <li>Write module extended parameters for C24 to the CPU module.</li> <li>Check the predefined protocol setting in the protocol setting data error (buffer memory: 4086H to 4089H), and correct and write it to C24, and execute the CPRTCL instruction.</li> <li>Replace the module if error occurs even after rewriting.</li> <li>The hardware error of the</li> </ul>	0	0	0	0	
		with the CPU module.		CPU module may have been occurred. Please consult your local Mitsubishi representative.					
3C00H	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	-	Figure 490 Corrective actions for system error					
7102H	System error	The operating system of C24 detected some error.	-	Figure 290 Corrective actions for system error					
7103H	PLC access error	Communication with the CPU module is not established.	C/N	<ul> <li>Increase the monitoring time (timer 1).</li> <li>Perform a self-loopback test, and check if the data communication with the CPU module can be established.</li> </ul>	0				
7104H	System error	The operating system of C24 detected some error.	-	ে Page 490 Corrective actions for system error					

Error code	Error	Description	Signal	Corrective action	Protoco	ol		
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7140H <sup>*1</sup>	Request data error	<ul> <li>The request exceeded the limit of processing points that are predetermined for each command and allowed for one transmission.</li> <li>A word device was designated in a bit unit command.</li> <li>The requested range exceeded the end device number.</li> <li>(CPU module's last device number + Number of device points in message sent from the target device)</li> </ul>	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> <li>If no error is found in the device range, clear the programmable controller CPU information and retry.</li> </ul>	0			
7141H	System error	The operating system of C24 detected some error.	_	S Page 490 Corrective actions for system error				
7142H <sup>*1</sup>	Device name error	Device that cannot be specified by the corresponding command was designated.	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> <li>If no error is found in the device name, clear the programmable controller CPU information and retry.</li> </ul>	0			
7143H <sup>*1</sup>	Device No. error	The start device number is out of range.	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> </ul>	0			
7144H <sup>*1</sup>	Monitor registration error	Monitoring was requested before the monitor registration has been performed.	PRO	Register the device to be monitored before issuing a monitor request.	0			
7145H <sup>*1</sup>	Monitor PC No. error	The registered PC No. and PC No. in the monitor request are different.	C/N	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> <li>Perform the monitor registration again.</li> </ul>	0			
7146H <sup>*1</sup>	Monitor CPU model error	The registered CPU model name and the CPU monitor name in the monitor request are different.	C/N	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> <li>Perform the monitor registration again.</li> </ul>	0			
7147H <sup>*1</sup>	Number of monitor registration point exceeded error	The number of monitor registration points exceeded the range.	PRO	Check and correct the transmission message from the target device and restart data communications.	0			
7148H <sup>*1</sup>	Extended R block No. error	<ul> <li>A nonexistent extension file register block No. was designated.</li> <li>A block No. being used as an extension comment area, sampling trace area, or status latch area was designated.</li> </ul>	PRO	Check and correct the designated block No. and restart data communications.	0			

Error code	Error	Description	Signal	Corrective action	Protoco	ol		
(hexadecima I)			name		МС	Nonpr ocedu ral	Bidire ctiona I	Prede fined
714AH <sup>*1</sup>	Cannot execute a command during RUN	<ul> <li>A write command was designated when the 'Online change' is disabled.</li> <li>Parameter or program was written during RUN.</li> </ul>	C/N	<ul> <li>Change the setting to enable the 'Online change' and restart data communications.</li> <li>Stop the CPU module and restart data communications.</li> </ul>	0			
714DH	Unusable command error	An unsupported command is requested to the access target CPU module.	C/N	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> <li>If no error is found in the command, clear the programmable controller CPU information and retry.</li> </ul>	0			
714EH	Monitor network No. error	The registered monitor network number and the network number in the monitor request are different.	C/N	<ul> <li>Check and correct the other station access valid module No. in the network parameters, and restart data communications.</li> <li>Perform the monitor registration again.</li> </ul>	0			
7150H	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	—	Service Age Age Corrective actions for system error				
7151H	PC No. designation error	<ul> <li>A PC No. other than "FF" or "0 to 120 (00H to 78H)" was designated.</li> </ul>	C/N	Check and correct the transmission message from the target device and restart data communications.	0			
7153H	Frame length error	The request exceeded the limit of processing points that are predetermined for each command and allowed for one transmission.	CHn ERR.	Modify the setting of the transmission message from the target device so that the request will not exceed the limit of processing points that are allowed for one transmission and predetermined for each MC protocol command. Then, retry data communications.	0			
7155H	Monitor unregistration error	Monitoring was requested before the monitor registration has been performed.	PRO	<ul> <li>Register the device to be monitored before issuing a monitor request.</li> </ul>	0			
7156H	System error	The operating system of C24 detected some error.	_	ে Page 490 Corrective actions for system error				
7160H	PLC access error	CPU model cannot be confirmed.	C/N	If the CPU module has an error, remove the CPU module error and restart data communications.	0			
7161H	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	—	Service Age Age Corrective actions for system error				
7164H	Request error	The request contents or the device designation method is incorrect.	—	Check and correct the transmission message/ request from the target device, and restart data communications.	0			
7167H	Cannot execute a command during RUN	A write command was designated when the Online change is disabled.	C/N	<ul> <li>Change the setting to enable the online change and restart data communications.</li> <li>Stop the CPU module and restart data communications.</li> </ul>	0			
7168H	Cannot execute a command during RUN	<ul> <li>A command that cannot be executed during RUN was designated.</li> </ul>	C/N	Stop the CPU module and restart data communications.				

Error code	Error	Description	Signal	Corrective action	Protoco	ol		
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7169H	CPU error	Communication with the CPU module cannot be established normally.	C/N	<ul> <li>If the CPU module side has an error, remove the error and restart data communications.</li> </ul>	0			
716CH	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	-	Service And Corrective actions for system error				
716FH	Device error	<ul> <li>A nonexistent device was designated.</li> <li>Device that cannot be specified by the corresponding command was designated.</li> </ul>	PRO	Check and correct the transmission message from the target device and restart data communications.	0			
7170H	1C frame error	Number of access points exceeded the range.	PRO	Check and correct the transmission message from the target device and restart data communications.	0			
7171H	1C frame error	A device that cannot be designated was designated.	PRO	Check and correct the transmission message from the target device and restart data communications.	0			
7172H	1C frame error	The registered number of monitoring points is incorrect. For example, '0' was designated.	PRO	Check and correct the transmission message from the target device and restart data communications.	0	0	0	
7173H	Monitor registration error	<ul> <li>Monitor registration was performed to a CPU module other than R/Q/L/ QnACPU using 2C/3C/4C frame.</li> </ul>	PRO	<ul> <li>For CPU module other than R/ Q/L/QnACPU, use 1C frame for monitor registration and monitor.</li> </ul>	0			
7817H	Remote password error	C24 is in the remote password locked out state.	-	<ul> <li>Wait for awhile, and retransmit the password.</li> </ul>	0			
7D00H	Protocol No. setting error	The protocol number is out of range in the control data for CPRTCL instruction.	CHn ERR.	Review the protocol number.				0
7D01H	Protocol continuous execution count setting error	The number of protocols to be executed continuously is out of range in an argument of the CPRTCL instruction.	CHn ERR.	Review the number of protocols to be executed continuously.				0
7D02H	Protocol not- ready error	<ul> <li>The CPRTCL instruction was executed while the 'predefined protocol ready' (X1D) is OFF.</li> <li>The CPRTCL instruction was executed while the protocol setting data is being written.</li> <li>The CPRTCL instruction was executed with abnormal protocol setting data.</li> </ul>	CHn ERR.	<ul> <li>Execute the CPRTCL instruction after the 'predefined protocol ready' (X1D) turned ON.</li> <li>Do not execute the CPRTCL instruction while the protocol setting data is being written. (Set the CPU module in STOP state, and write protocol setting data.)</li> <li>Write the protocol setting data again to C24, and then execute the CPRTCL instruction.</li> <li>If this error persists even after rewriting, replace the module.</li> </ul>				0
7D10H	Protocol unregistration error	<ul> <li>The protocol No. which is not registered in C24 is specified in the control data for the CPRTCL instruction.</li> <li>The CPRTCL instruction was executed without the protocol setting data written.</li> </ul>	CHn ERR.	<ul> <li>Check if the specified protocol No. is correct.</li> <li>Check the 'Protocol registration' (Un\G16529 to 16536) to see if the specified protocol number is registered.</li> <li>Write the protocol setting data, and then execute the CPRTCL instruction.</li> </ul>				0

Error code	Error	Description	Signal	Corrective action	Protocol			
(hexadecima I)			name		МС	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7D11H	Protocol simultaneous execution error	The CPRTCL instruction and 'CH1 protocol execution request' (Y3) or 'CH2 protocol execution request' (YA) were executed simultaneously on the same channel.	CHn ERR.	Correct the program not to execute the CPRTCL instruction and 'CH1 protocol execution request' (Y3)/'CH2 protocol execution request' (YA) simultaneously on the same channel.				0
7D12H	Send monitoring time timeout error	<ul> <li>Send monitoring time has timed out.</li> <li>Although the transmission was retried the specified number of retries, it did not succeed.</li> </ul>	CHn ERR.	<ul> <li>Check if the transmission is interrupted due to some reasons such as DTR control.</li> <li>Check whether the CS signal is ON.</li> <li>Check if the cables are disconnected.</li> </ul>				0
7D13H	Receive wait timeout error	• Receive wait time has timed out.	CHn ERR.	<ul> <li>Check if the reception is interrupted due to some reasons such as DTR control.</li> <li>Check if the cables are disconnected.</li> <li>Check if any errors occur on the target device side.</li> <li>Using the circuit trace function (send/receive data monitoring function), check if;</li> <li>Transmissions from the target device are interrupted.</li> <li>Any data are missing due to a data reception error.</li> <li>The data (packet) sent from the target device is incorrect.</li> </ul>				0
7D14H	Response monitoring timeout error	<ul> <li>Response monitoring time (timer 1) has timed out during data transmission.</li> <li>Data to be sent to the target device was not obtained from the CPU module within the response monitoring time (timer 1).</li> </ul>	CHn ERR.	<ul> <li>Increase the setting value for the response monitoring time (timer 1). (Default: 5 seconds)</li> <li>If an error occurred on the CPU module, refer to the following manual.</li> <li>(L_MELSEC iQ-R CPU Module User's Manual (Application))</li> </ul>				0
7D15H	Response monitoring timeout error	<ul> <li>Response monitoring time (timer 1) has timed out during data reception.</li> <li>Data received from the target device was not stored into the CPU module within the response monitoring time (timer 1).</li> </ul>	CHn ERR.	<ul> <li>Increase the setting value for the response monitoring time (timer 1). (Default: 5 seconds)</li> <li>If an error occurred on the CPU module, refer to the following manual.</li> <li>(L_MELSEC iQ-R CPU Module User's Manual (Application))</li> </ul>				0
7D16H	Protocol cancel request error	<ul> <li>A cancel request was accepted during protocol execution, and the CPRTCL instruction was completed abnormally.</li> <li>The CPRTCL instruction was completed abnormally because protocol setting data were written during CPRTCL instruction execution.</li> <li>The STOP → RUN operation was performed on the CPU module.</li> </ul>	CHn ERR.	<ul> <li>Check the cancelled Predefined protocol in the CPRTCL instruction's control data (number of executions), and eliminate the cause of the cancellation.</li> <li>Clear the error information by the 'Error initialization request' (YE) as necessary.</li> <li>To prevent coincidental execution of the CPRTCL instruction, set the CPU module in the STOP state before writing the protocol setting data.</li> <li>Execute the CPRTCL instruction again.</li> </ul>				0

Error code	Error	Description	Signal Corrective action	Corrective action	Protoco	bl		
(hexadecima I)			name		МС	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7D17H	Packet size error	A packet of more than 2048 bytes was received.	CHn ERR.	<ul> <li>Check the data length of the packet sent from the target device.</li> <li>Divide the packet data into several parts and send them separately.</li> </ul>				0
7D18H	Insufficient digit number error	• When data is received using a protocol including a packet that contains Conversion variable (Variable number of data), the data (the number of digits) corresponding to the Conversion Variable is insufficient.	CHn ERR.	<ul> <li>Review data sent from the target device.</li> <li>Check the packet format of the target device to see if the number of digits is set correctly.</li> </ul>				0
7D19H	Abnormal digit number error	When data is received using a protocol including a packet that contains Conversion Variable (Fixed number of data and variable number of digits), the corresponding data is 0 bytes (0 digits) or exceeds the maximum number of digits.	CHn ERR.	<ul> <li>Review data sent from the target device.</li> <li>Check the packet format of the target device to see if the number of digits is set correctly.</li> </ul>				0
7D1AH	Data length error	<ul> <li>In the data received from the target device, the Length value does not match the data length of the Conversion Variable(s).</li> </ul>	CHn ERR.	<ul> <li>Check the packet format of the target device to see if the conversion variable is set correctly.</li> <li>Check the data sent from the target device to see if;</li> <li>The Length value is incorrect.</li> <li>Any of the data corresponding to the conversion variable is missing.</li> </ul>				0
7D1BH	Value range error	• When data is received using a protocol including a packet that contains Conversion Variable, data for the Conversion Variable exceeds the range of value allowed for C24.	CHn ERR.	<ul> <li>Review data sent from the target device.</li> <li>Check the packet format of the target device to see if the conversion size is set incorrectly.</li> <li>If it exceeds the range for word data, change the conversion size setting to double word.</li> <li>If it exceeds the range for double word data, change the element to Non-conversion Variable.</li> </ul>				0
7D20H	Data length size error Data count size error	The value set in the data length storage area or the data count storage area is out of range.	CHn ERR.	<ul> <li>Check the maximum data length can be set to the data length storage area, and specify the value which is equal to the maximum data length or less.</li> <li>Check the maximum number of data can be set to the data count storage area, and specify the value which is equal to the maximum number of data or less.</li> </ul>				0

Error code	Error	Description	Signal	Corrective action	Protoco	bl		
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7D21H	Decimal point place specification error	<ul> <li>An out-of-range decimal point position is set when the number of decimals is set to Variable point.</li> <li>The number of decimals is larger than the number of digits for each data.</li> </ul>	CHn ERR.	<ul> <li>Correct the decimal point position.</li> <li>Check the number of digits setting, and set the decimal point position so that the number of decimals is less than the number of digits.</li> </ul>				0
7E01H	System error	The operating system of C24 detected some error.	_	লে Page 490 Corrective actions for system error				
7E03H to 7E05H	System error	The operating system of C24 detected some error.	_	F Page 490 Corrective actions for system error				
7E07H	System error	The operating system of C24 detected some error.	—	Series Page 490 Corrective actions for system error				
7E08H	Execution currently disabled error	The UINI instruction was executed during execution of the programmable controller CPU information clear.	_	Execute the UINI instruction while the programmable controller CPU information clear is not executed.	0	0	0	0
7E09H to 7E0AH	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	—	Page 490 Corrective actions for system error				
7E40H	Command error	<ul> <li>A nonexistent command or subcommand was designated.</li> </ul>	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> </ul>	0			
7E41H	Data length error	<ul> <li>A data length exceeding the number of points that can communicate during random read/write was designated.</li> </ul>	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> </ul>	0			
7E42H	Data count error	Number of processing points exceeds the range allowed for the command.	PRO	Modify the setting of the transmission message from the target device so that the request will not exceed the limit of processing points that are allowed for one transmission and predetermined for each MC protocol command. Then, retry data communications.	0			
7E43H	Device error	<ul> <li>A nonexistent device was designated.</li> <li>Device that cannot be specified by the corresponding command was designated.</li> <li>The start device number is out of range.</li> </ul>	PRO	Check and correct the transmission message from the target device and restart data communications.	0	0		
7E44H	Timer 1 time-out error	<ul> <li>A response message was not returned within the response monitoring time (timer 1).</li> </ul>	C/N	<ul> <li>Increase the monitoring time for the response monitoring time (timer 1).</li> <li>When accessing other station's CPU, check if the routing parameters are correct.</li> </ul>	0			
7E47H	Continuous request error	The next request was received before a response message was returned for the preceding request.	PRO	<ul> <li>Do not send requests continuously from the target device.</li> <li>Adjust the monitoring time for the response monitoring time (timer 1) to the timeout time set for the target device side.</li> </ul>	0			

Error code	Error	Description	Signal	Corrective action	Protocol			
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7E48H	Request error	<ul> <li>A request was received during parameter communication.</li> </ul>	PRO	Wait for awhile and transmit the request again.	0			
7E4FH	Number of device points error	Number of access points is incorrect.	PRO	Check and correct the transmission message from the target device and restart data communications.	0	0		
7E50H	User frame No. designation error	A user frame No. outside the range was designated.	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> <li>Review the frame No.</li> </ul>	0	0		
7E51H	User frame unregistration error	<ul> <li>An unregistered user frame number was designated.</li> </ul>	PRO	<ul> <li>Perform the frame registration beforehand.</li> <li>Change the frame No. and restart data communications.</li> <li>Review the frame No.</li> </ul>	0	0		
7E52H	User frame overwrite error	<ul> <li>An overwrite request was issued to the frame number which has been already registered.</li> </ul>	PRO	<ul> <li>Change the write destination to an unregistered frame number.</li> <li>When overwriting, delete the given number beforehand.</li> </ul>	0			
7E53H	Requested frame data error	<ul> <li>A nonexistent command was designated in a subcommand.</li> <li>Byte count exceeding the number of bytes that can be requested was designated.</li> </ul>	PRO	Check and correct the transmission message from the target device and restart data communications.	0			
7E54H	Modification not- allowed error	<ul> <li>The setting change enable/disable setting is set to be disabled.</li> </ul>	PRO	<ul> <li>Set the setting change enable/ disable setting to 'Enable'.</li> </ul>	0	0	0	0
7E55H	User frame data error	The user frame variable data has an error.	PRO	Check and correct the transmission message from the target device and restart data communications.	0	0		
7E57H	Flash ROM write error	Writing to the flash ROM was not performed normally.     Power is turned OFF	— CHn	<ul> <li>Rewrite the module extended parameter to the CPU module or C24.</li> <li>If the error occurs after</li> </ul>	0	0	0	0
		during writing to Flash ROM.	ERR.	rewriting, replace the module.				
7E58H	Mode modification error	At the time of mode modification, the mode No. or transmission specifications are incorrect.	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> <li>Review the parameter settings.</li> </ul>	0	0	0	0
7E59H	Number of writing to flash ROM exceeded error	<ul> <li>Writing to flash ROM has been performed 1000 times since the power was turned ON.</li> <li>Writing to flash ROM has been performed 100,000 times.</li> </ul>	CHn ERR.	<ul> <li>Review the program.</li> <li>Write "0" to the flash ROM write count area (address: 2401H) and restart data communication.</li> <li>When the number of writes reached 100,000, replace the module.</li> </ul>	0	0	0	0
7E5EH	PLC CPU monitoring function registration error	The programmable controller CPU monitoring function is registered for the communication protocol that does not support the function.	CHn ERR.	Correct the communication protocol setting.			0	0

Error code	Error	Description	Signal Corrective action	Corrective action	Protoco	Protocol		
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7E60H	Device monitoring duplicate registration error	<ul> <li>Programmable controller CPU monitoring registration was performed twice.</li> </ul>	_	Cancel the programmable controller CPU monitoring and perform the programmable controller CPU monitoring registration again.	0	0		
7E61H	Cycle time units range error	<ul> <li>The setting value for the cycle time units is out of range.</li> </ul>	—	Correct the cycle time units setting value.	0	0		
7E62H	PLC CPU monitoring function error	<ul> <li>The setting value for the programmable controller CPU monitoring function is out of range.</li> </ul>	_	Correct the programmable controller CPU monitoring function setting value.	0	0		
7E63H	Transmission method setting error	The transmission method setting for programmable controller CPU monitoring is incorrect.	_	Correct the transmission method setting value.	0	0		
7E64H	Registration point range error	The total number of word blocks and bit blocks registered for programmable controller CPU monitoring is out of range.	_	<ul> <li>Correct the setting value so that the total number of registered word blocks and bit blocks is within 1 to 10.</li> </ul>	0	0		
7E66H	Monitoring condition error of monitoring device	The monitoring condition     is out of range.		Correct the monitoring condition.	0	0		
7E67H	CPU error monitoring setting value error	<ul> <li>The setting value (fixed value) for CPU error monitoring is out of range.</li> </ul>	_	<ul> <li>Correct the setting value (fixed) for CPU error monitoring.</li> </ul>	0	0		
7E68H	Transmission condition range error of monitoring device	The setting value for the transmission condition (condition match send) is out of range.	_	<ul> <li>Correct the setting value for the transmission condition (condition match send).</li> </ul>	0	0		
7E69H	CPU error monitoring setting value error	<ul> <li>The setting value (fixed value) for CPU error monitoring is out of range.</li> </ul>		<ul> <li>Correct the setting value (fixed) for CPU error monitoring.</li> </ul>	0	0		
7E6AH	Monitoring device read point range error	<ul> <li>The read point of the monitoring device is out of range.</li> </ul>	_	<ul> <li>Correct the setting value for the monitoring device read point.</li> </ul>	0	0		
7E6BH to 7E6DH	CPU error monitoring setting value error	<ul> <li>The setting value (fixed value) for CPU error monitoring is out of range.</li> </ul>	_	<ul> <li>Correct the setting value (fixed) for CPU error monitoring.</li> </ul>	0	0		
7E6FH	Modem connection error	Modem is connected to an incorrect channel.		<ul> <li>Correct the destination to which data is sent with the modem function.</li> </ul>	0	0		
7E70H	CPU error	<ul> <li>The communication with the CPU module was not performed normally.</li> </ul>	C/N	<ul> <li>If the CPU module side has an error, remove the error and restart data communications.</li> </ul>	0	0		0
7E71H	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	—	Page 490 Corrective actions for system error				
7EC1H to 7EC2H	System error	The operating system of C24 detected some error.	—	Page 490 Corrective actions for system error				
7EC3H	Double send request error	<ul> <li>A send request was sent again during processing of the send request.</li> </ul>	_	<ul> <li>Provide an interlock for send requests.</li> </ul>		0	0	

Error code	Error	Description	Signal	Corrective action	Protoco	ol		
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7EC4H	Transmission data count error, Send and receive buffer setting error	<ul> <li>Data exceeding the send buffer memory size was transmitted.</li> <li>Send/receive buffer settings are out of range.</li> </ul>	_	<ul> <li>Make the send data quantity smaller than the buffer memory size.</li> <li>Increase the value for the send buffer memory length designation.</li> <li>Designate the start address and size of transmit/receive buffer within the range of the user setting area.</li> </ul>	0	0	0	
7EC5H	Flash ROM access error	Writing to flash ROM was requested when the setting change enable/ disable setting is set to be disabled with Engineering tool.	_	<ul> <li>Set the setting change enable/ disable setting to 'Enable' with Engineering tool, write to the CPU, and re-execute after the CPU reset or powering OFF</li> <li>→ ON.</li> </ul>	0	0	0	0
7EC6H	Flash ROM access error	The flash ROM read/write request contents are incorrect.	_	Check the data at the time of read/write request, and specify the correct data.	0	0	0	0
7F00H	Other module response error	An error response has been returned from CPU module.	_	<ul> <li>An error code is included in the response message of MC protocol. Refer to the manual for the relevant CPU module to check the error, and review the request message of MC protocol.</li> <li>If this error has occurred at the execution of G(P).CPRTCL instruction, refer to the manual for the relevant CPU module to check the error, and review the CPU device number specified in the data storage area for Non- conversion Variable.</li> </ul>	0			0
7F01H	Other module response error	An error response has been returned from a module other than CPU module.	_	<ul> <li>An error code is included in the response message of MC protocol. Refer to the manual for the relevant module to check the error, and review the request message of MC protocol.</li> </ul>	0			
7F02H	CPU error	CPU module error has been detected.	—	Check the error contents of the CPU module using the module diagnostics, and take corrective actions.	0			0
7F03H to 7F06H	System error	The operating system of C24 detected some error.	—	Service Age Age Corrective actions for system error				

Error code	Error	Description	Signal	Corrective action	Protoco	bl		
(hexadecima I)			name		МС	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7F20H	ASCII→BIN conversion error	<ul> <li>When the nonprocedural or bidirectional protocol is used, an ASCII code that cannot be converted to binary code was received.</li> <li>When the nonprocedural or bidirectional protocol is used, an odd number of bytes of data was received during data communications using ASCII ↔ BIN conversion.</li> </ul>	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> <li>When the nonprocedural or bidirectional protocol is used and data is communicated using ASCII ↔ BIN conversion, be sure to send data in units of even bytes.</li> </ul>		0	0	
		<ul> <li>When data is received by Conversion Variable of the predefined protocol function, the data corresponding to the Conversion Variable cannot be converted to binary numbers.</li> <li>When data is received by a Check code (ASCII hexadecimal or ASCII decimal) of the predefined protocol function, the data corresponding to the check code cannot be converted to binary numbers.</li> </ul>	PRO	<ul> <li>If the predefined protocol was edited, check if the following values match the packet format of the target device:</li> <li>Conversion, sign character, number of decimals, delimiter, number of digit for conversion variable</li> <li>Code type and data length of check code</li> </ul>				0
7F21H	Receive header area error	<ul> <li>The command (frame) part designation has an error.</li> <li>An ASCII code that cannot be converted to binary code was received.</li> </ul>	PRO	Check and correct the transmission message from the target device and restart data communications.	0			
7F22H	Command error	<ul> <li>A nonexistent command, subcommand, or device was designated.</li> <li>The remote password length is incorrect.</li> </ul>	PRO	<ul> <li>Check and correct the transmission message from the target device and restart data communications.</li> </ul>	0			
7F23H	MC protocol message error	There is no data (ETX, CR-LF, etc.) following the character area, or the designation was incorrect.	PRO	Check and correct the transmission message from the target device and restart data communications.	0			
7F24H	Sum check error	<ul> <li>The sum check code calculated does not match the sum check code received.</li> <li>The horizontal parity code calculated does not match the horizontal parity code received.</li> <li>The calculated check code does not match the received check code.</li> </ul>	P/S	<ul> <li>Review the sum check code of the target device.</li> <li>Review the horizontal parity code of the target device.</li> <li>Review CRC-16 of the target device.</li> <li>If the predefined protocol was edited, check if the following values match the packet format of the target device:</li> <li>Processing method or code type of the check code</li> <li>Data length</li> <li>Data flow</li> <li>Complement calculation</li> <li>Calculating range</li> </ul>	0	0		0

Error code	Error	Description	n Signal Corrective action		Protocol			
(hexadecima I)			name	name		Nonpr ocedu ral	Bidire ctiona I	Prede fined
7F25H	Data length error	The length of the received data exceeds the receive area size.	CHn ERR.	<ul> <li>Correct the "data length" that is transmitted from the target device.</li> <li>Change the word/byte units designation to 'byte units'.</li> <li>Increase the value for the receive buffer memory length designation.</li> </ul>			0	
7F26H	Command error	Another command was received before the unlock processing when the remote password is registered.	CHn ERR.	Perform data communications after the unlock processing is normally completed.	0			
7F30H	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	_	Figure 490 Corrective actions for system error				
7F31H	Simultaneous transmission error	C24 and the target device started transmissions simultaneously.	_	<ul> <li>Perform processing according to the predefined arrangement with the target device. If necessary, change the 'simultaneous transmission data valid/invalid designation' (Un\G155/315) setting.</li> </ul>			0	
7F32H	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	—	Series Page 490 Corrective actions for system error				
7F40H	Time-out error	<ul> <li>No-reception monitoring time (timer 0) has timed out.</li> </ul>	PRO	<ul> <li>Check if any data is missing due to a data reception error.</li> <li>Check if the DTR control, etc. interrupted data reception.</li> </ul>	0	0	0	
7F41H	Time-out error	Response monitoring time     (timer 1) has timed out.	—	Check the status of the target device, and restart data communications, as required.	0		0	
7F42H	Time-out error	<ul> <li>Send monitoring time (timer 2) has timed out.</li> </ul>	—	Check if the DTR control, etc. interrupted data transmission.	0	0	0	
7F50H to 7F54H	System error	The operating system of C24 detected some error.	—	ে Page 490 Corrective actions for system error				
7F67H	Overrun error	C24 received the next data before it completed receive processing of the previous data.	SIO	<ul> <li>Decrease the transmission speed and restart data communications.</li> <li>Check whether momentary power failure has occurred on the station with C24. (can be checked "AC DOWN counter" of the special register.) In case momentary power failure has occurred, remove the cause.</li> <li>Perform the registration, read, and delete to/from the flash ROM while the data communication is not performed.</li> </ul>	0	0	0	0

Error code	Error	Description	Signal	Corrective action	Protocol			
(hexadecima I)			name		МС	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7F68H	Framing error	<ul> <li>The stop bit settings do not match.</li> <li>A malfunction occurred on the line because the power for the target station was ON/OFF.</li> <li>Noise occurs on the line.</li> <li>During multidrop connection, two or more devices transmitted data at the same time.</li> </ul>	SIO	<ul> <li>Match the settings of C24 with that of the target device.</li> <li>Clear the error information by 'Error initialization request' (YE). In addition, when communicating data with the nonprocedural protocol, execute the INPUT instruction, and read and discard the unnecessary data.</li> <li>Take measures against noise.</li> <li>During multidrop connection, provide the interlock so that data will not be transmitted simultaneously by multiple devices.</li> </ul>	0	0	0	0
7F69H	Parity error	<ul> <li>The parity bit settings do not match.</li> <li>A malfunction occurred on the line because the power for the target station was ON/OFF.</li> <li>Noise occurs on the line.</li> <li>During multidrop connection, two or more devices transmitted data at the same time.</li> </ul>	P/S	<ul> <li>Match the settings of C24 with that of the target device.</li> <li>Clear the error information by 'Error initialization request' (YE). In addition, when communicating data with the nonprocedural protocol, execute the INPUT instruction, and read and discard the unnecessary data.</li> <li>Take measures against noise.</li> <li>During multidrop connection, provide the interlock so that data will not be transmitted simultaneously by multiple devices.</li> </ul>	0	0	0	0
7F6AH	Buffer full error	The operating system receive buffer overflowed and received data was skipped.	SIO	<ul> <li>Use the DTR and DC controls and perform data communications so that the buffer does not become full. (Perform RS/CS control when the modem function is used.)</li> <li>When the reception data read request signal turns ON, execute read operation immediately.</li> </ul>	0	0	0	0
7F6BH	CD(DCD) signal control error	<ul> <li>Data was received when the CD(DCD) signal is OFF with the CD terminal check enabled.</li> </ul>	CHn ERR.	<ul> <li>Review the CD(DCD) signal control of the target device.</li> <li>(Data is sent when the CD(DCD) signal is ON.)</li> <li>Perform data communications with the CD terminal check disabled.</li> </ul>	0	0	0	0
7F6CH	Transmission error	Data cannot be sent because the line is not connected.	CHn ERR.	<ul> <li>Send data after line connection processing on the interface side that uses the modem function.</li> </ul>	0	0	0	
7F9AH	System error	The operating system of C24 detected some error.	—	Page 490 Corrective actions for system error				
7FABH	System error	The operating system of C24 detected some error.	_	Figure 200 Corrective actions for system error				
7FC7H	System error	The operating system of C24 detected some error.	—	Page 490 Corrective actions for system error				
7FC9H to 7FCCH	System error	The operating system of C24 detected some error.	_	Series Page 490 Corrective actions for system error				

Error code	ror code Error Description Signal Corrective action		Protocol					
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7FCFH	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	-	Series Page 490 Corrective actions for system error				
7FD1H	Modem function error	The connection re-try count designation is incorrect.	CHn ERR.	Set the connection re-try count to 1 to 5.	0	0	0	
7FD2H	Modem function error	<ul> <li>The connection retry interval designation is incorrect.</li> </ul>	CHn ERR.	<ul> <li>Set the connection retry interval to 90 to 300 (seconds).</li> </ul>	0	0	0	
7FD3H	Modem function error	The initialization/ connection timeout designation is incorrect.	CHn ERR.	<ul> <li>Set the time for the initialization/connection timeout to 1 to 60 (seconds).</li> </ul>	0	0	0	
7FD4H	Modem function error	The number of initialization retries designation is incorrect.	CHn ERR.	Set the number of initialization retires to 1 to 5.	0	0	0	
7FD5H	Modem function error	The data No. for initialization designation is incorrect.	CHn ERR.	<ul> <li>Designate the registered number of data for initialization or '0'.</li> </ul>	0	0	0	
7FD6H	Modern function error	The data for connection of the number specified in the data No. for connection designation is incorrect.	CHn ERR.	Review the line type.	0	0	0	
7FD7H	Modem function error	The data for connection of the number specified in the data No. for connection designation is incorrect.	CHn ERR.	<ul> <li>Review the external line outgoing number.</li> </ul>	0	0	0	
7FD8H	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	-	Series Page 490 Corrective actions for system error				
7FD9H	Modern function error	<ul> <li>The line is connected to the target, or the modem has not been initialized.</li> </ul>	CHn ERR.	Upon the completion of the modem initialization, connect the line to the target device (via public line) while the line has not been connected yet.	0	0	0	
7FDAH	Modem function error	The data No. for connection designation is incorrect.	CHn ERR.	Designate the registered     number of data for connection.	0	0	0	
7FDBH	System error	The operating system of C24 detected some error.	—	Page 490 Corrective actions for system error				
7FDCH	Modern function error	The data for connection of the number specified in the data No. for connection designation is incorrect.	CHn ERR.	Review the data for connection.	0	0	0	
7FDDH	Modem function error	The connection timeout error occurred.	CHn ERR.	<ul> <li>Review the telephone number in the data for connection.</li> <li>Check whether the connection target is connectable.</li> <li>Review the setting value for the connection timeout.</li> <li>Review the data for initialization.</li> </ul>	0	0	0	

Error code	Error	Description	Signal	Corrective action	Protocol			
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7FDEH	Modem function error	Connection to the modem/ TA failed, or a modem/TA is not connected.	CHn ERR.	<ul> <li>Check if the modem/TA has any failure by referring to the instruction manual for the modem/TA.</li> <li>Connect the modem/TA to C24.</li> <li>Check the connection cable by referring to the instruction manual for the modem/TA.</li> <li>Check for any abnormality according to the following procedure.</li> <li>(KSP Page 490 Corrective actions for system error)</li> </ul>	0	0	0	
7FDFH	Modem function error	The modem connection channel No. has not been set.	CHn ERR.	Set the modem connection CH specification to 1 or 2.	0	0	0	
7FE0H	Modem function error	<ul> <li>The designated value for modem connection channel is incorrect.</li> </ul>	_	Set the modem connection CH specification to 1 or 2.	0	0	0	
7FE1H	Modem function error	<ul> <li>The user frame No. designation is incorrect.</li> <li>The output start pointer designation is incorrect.</li> </ul>	CHn ERR.	<ul> <li>Review the user frame No.</li> <li>Designate the registered user frame No.</li> <li>Register the designated data for initialization.</li> <li>Set the output start pointer designation to 1 to 100.</li> <li>Designate the position (n-th) to which the number of data for initialization is designated.</li> <li>Designate the number of data for initialization to the designated position (n-th).</li> </ul>	0	0	0	
7FE2H	Modem function error	The output frame No. designation is incorrect.	CHn ERR.	Designate the registered number of data for initialization to the range of the designated output quantity starting from the position of the output start pointer designation.	0	0	0	
7FE3H	Modem function error	The registration data byte count designation is incorrect.	CHn ERR.	<ul> <li>Set the data for initialization to 1 to 78.</li> <li>Set the data for connection to 80.</li> </ul>	0	0	0	
7FE4H	Modern function error	• The data for connection of the number specified in the data No. for connection designation is incorrect.	CHn ERR.	Review the data for connection.	0	0	0	
7FE5H	Modem function error	<ul> <li>The no-communication interval time designation is incorrect.</li> </ul>	CHn ERR.	Set the no-communication interval time designation to 0 to 120.	0	0	0	
7FE6H	Remote password error	Remote passwords do not match.	_	<ul> <li>Review the remote password and restart data communications.</li> </ul>	0			

Error code	Error	Description	Signal	Corrective action	Protoco	ol		
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7FE7H	Remote password error	<ul> <li>The remote password is not registered.</li> <li>The remote password processing command was received on the interface side where the modem function is not used.</li> <li>The MELSOFT Connection is selected in the Communication protocol setting for the corresponding channel.</li> </ul>	_	<ul> <li>A remote password processing command is not necessary when a remote password is not registered.</li> <li>Unlock the remote password by MELSOFT. Alternatively, change the Communication protocol setting for the corresponding channel to MC protocol.</li> </ul>	0			
7FE8H	Remote password error	The number of remote password mismatch exceeded the designated value of the address 200DH.	CHn ERR.	Clear the 'accumulated count of unlock process abnormal completion' (Un\G8956) to '0'.	0			
7FE9H	Modem function error	The number of callback denial exceeded the designated value of address 2002H.	CHn ERR.	Clear the callback denial accumulated count (address: 22F1H) to '0'.	0	0	0	
7FECH	Module extended parameters do not exist.	Reading data has failed since module extended parameters do not exist.	—	Write module extended parameters to C24 or CPU module.				
7FEDH	Simultaneous execution error	More than one target device accessed to the parameter file at the same time.	CHn ERR.	Do not access to the parameter file from more than one target device simultaneously.				
7FEFH	Parameter setting error	The parameter settings with MELSOFT are incorrect.	CHn ERR.	<ul> <li>Correct the parameter settings, write it to the CPU module, and restart it.</li> </ul>	0	0	0	0
7FF0H	Dedicated instructions simultaneous execution error	Dedicated instructions were executed simultaneously.	_	Do not execute the dedicated instructions simultaneously.	0	0	0	0
7FF1H	Control data error	<ul> <li>Setting value is incorrect.</li> <li>Setting value is out of the range.</li> </ul>	—	Correct the setting value in the control data.	0	0	0	
7FF2H	Communication protocol setting error	The instruction cannot be executed with the current communication protocol.	—	Correct the setting value of the communication protocol.	0	0		0
7FF3H to 7FF4H	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	-	ে Page 490 Corrective actions for system error				
7FF5H	Transmission cancel at mode switching/ transmission sequence initialization	<ul> <li>The processing in operation was cancelled due to performance of the following functions:</li> <li>Mode switching, transmission sequence initialization, receive data clear (by buffer memory), user frame use enable/ disable designation, UINI instruction, programmable controller CPU information clear</li> </ul>	_	Do not execute these functions during various processes in progress.	0	0	0	0
7FF7H	Simultaneous access error	<ul> <li>Multiple target devices accessed to a station on the same network at the same time.</li> </ul>	_	Do not access to a station on the same network from multiple target device at the same time.	0			
7FFBH	Channel error	<ul> <li>Incorrect channel was designated with a dedicated instruction.</li> </ul>	_	Review the channel for a dedicated instruction.	0	0	0	0

Error code	Error	Description	Signal	Corrective action	Protocol			
(hexadecima I)			name		MC	Nonpr ocedu ral	Bidire ctiona I	Prede fined
7FFCH	System error	<ul> <li>The operating system of C24 detected some error.</li> </ul>	_	Page 490 Corrective actions for system error				
7FFDH	NULL character transmission error	<ul> <li>Only NULL character data was transmitted when NULL characters automatic deletion is designated.</li> </ul>	_	Review the data to be transmitted.		0	0	
7FFFH	System error	The operating system of C24 detected some error.	_	ে Page 490 Corrective actions for system error				

\*1 Error code when the target CPU is MELSEC-A series

### Corrective actions for system error

- **1.** Check if the C24, the power module, and the CPU module are mounted correctly.
- **2.** Check if the environment of the C24 usage is within the range of the general specifications for the CPU module.
- **3.** Check if the power supply capacity is sufficient.
- **4.** Check if the hardware of the C24 and the CPU module is normal according to the respective module manual. In case of a malfunction, please contact your local Mitsubishi representative for service.
- **5.** If the problem is still not solved, please consult your local Mitsubishi representative, explaining a detailed description of the problem.

# 27.5 Event History List

### The table below shows the events saved by C24.

Event code	Event type	Description	Cause
00700	System	The contents of error code for error occurred	The causes of error code for error occurred
10200	Security	Remote password lock	The remote password is locked.
10201		Remote password unlock	The remote password is unlocked.
10202		Failure of remote password unlock	The remote password was failed to be unlocked.
20700	Operation	Transmission sequence initialization	The transmission sequence used by the MC protocol was initialized.
20701		Programmable controller CPU information clear	The programmable controller CPU information clear request was executed.
20702		Error clear request	The error clear request was executed.
20703		Mode switching request	The mode switching request was executed.
20704		Modem initialization request	The modem initialization request was executed.
20705		Connection request	The connection request for the modem was executed.
20706		Modem disconnection request	The disconnection request for the modem was executed.
20707		Parameter initialization request	The parameter initialization request was executed.
20708		Connection request from MELSOFT products	By MELSOFT connection, the access via Serial communication module was performed.

# APPENDIX

# Appendix 1 Module Label

The input/output signal and buffer memory of C24 can be set by using module label.

### Module label configuration

A name of module label is defined in the configuration below:

"Instance name"\_"Module number"."Channel number"."Label name"

"Instance name"\_"Module number"."Label name"

"Instance name"\_"Module number"."Channel number"."Label name"\_D

"Instance name"\_"Module number"."Label name"\_D



C24\_1.stnCH1.uSet\_ReceivedDataCount\_Reception\_D

### ■Instance name

The instance name for RJ71C24(-R2/R4) is "C24".

### ■Module number

A module number is a number starting from 1, which is added to identify a module that has the same instance name.

### Channel number

A channel number is a number added to the module label corresponding to a buffer memory other than the CH1/CH2 common area.

For module label corresponding to a buffer memory other than the CH1/CH2 common area, the following content is added as the channel number.

Channel number	Content to be added
CH1	stnCH1
CH2	stnCH2

### ■Label name

This is a module unique label name.

### ∎\_D

This indicates that the module label is for direct access. Without this symbol means a label for refresh. There are some differences between refresh and direct access as shown below.

Туре	Description	Access timing
Refresh	Values written to/read from a module label are reflected to the module in batch at the time of refresh. This shortens program execution time.	At the time of refresh
Direct access	Values written to/read from a module label are immediately reflected to the module. Although the program execution time is longer than refresh, the responsiveness will be increased.	At the time of writing to/ reading from module label

# Appendix 2 Input/Output Signal List

This section explains the input/output signals of C24.

The input/output signal assignments in the table below are when the start I/O number of C24 is '0000'.

The devices starting with X indicate input signals from a C24 to CPU module.

The devices starting with Y indicate output signals from a CPU module to C24.

Point P

Do not output (turn ON) the signals of "Use prohibited" in the input/output signal list shown below. If any of the "Use prohibited" signals is output, the programmable controller system may malfunction.

input signals	liput signals					
Device number	Signal name	Reference				
X0 <sup>*1</sup>	CH1 Transmission normal completion	-				
X1 <sup>*1</sup>	CH1 Transmission abnormal completion					
X2 <sup>*1</sup>	CH1 Transmission processing					
X3 <sup>*2</sup>	CH1 Reception data read request	Page 53 Receiving Data from Target				
X4*2	CH1 Reception abnormal detection	Device Page 87 Receiving Data from Target Device				
X5	CH1 Protocol execution completion	-				
X6 <sup>*3</sup>	CH1 Switching mode	Page 377 SWITCHING THE MODE AFTER STARTING				
X7 <sup>*1</sup>	CH2 Transmission normal completion	-				
X8 <sup>*1</sup>	CH2 Transmission abnormal completion					
X9 <sup>*1</sup>	CH2 Transmission processing					
XA <sup>*2</sup>	CH2 Reception data read request	Page 53 Receiving Data from Target				
XB <sup>*2</sup>	CH2 Reception abnormal detection	Device Page 87 Receiving Data from Target Device				
XC	CH2 Protocol execution completion	-				
XD <sup>*3</sup>	CH2 Switching mode	Page 377 SWITCHING THE MODE AFTER STARTING				
XE	CH1 Error occurrence	-				
XF	CH2 Error occurrence					
X10	Modem initialization completion	Page 160 List of input/output signals for				
X11	Dialing	the modem function				
X12	Connection					
X13	Initialization/connection abnormal completion					
X14	Modem disconnection completion					
X15 to X16	Use prohibited	-				
X17 <sup>*1</sup>	User frame read completion from flash ROM					
X18 <sup>*1</sup>	User frame write completion from flash ROM					
X19	Use prohibited					
X1A	CH1 Global signal	MELSEC Communication Protocol				
X1B	CH2 Global signal	Reference Manual				
X1C	Parameter initialization completion	-				
X1D <sup>*4</sup>	Predefined protocol ready	Page 48 Execution Condition of Predefined Protocol Communication				
X1E <sup>*5</sup>	Module READY	-				
X1F <sup>*6</sup>	Watchdog timer error					

\*1 The device does not turn ON/OFF by executing a dedicated instruction when using a function that corresponds to the input signal.

\*2 The device turns ON/OFF by executing a dedicated instruction when using a function that corresponds to the input signal. (ON→OFF: Data read completion)

\*3 The 'CH□ Switching mode' (X6/XD) turns ON when the following function is performed. · Mode switching, transmission sequence initialization, reception data clear (by buffer memory), user frame use enable/disable designation, UINI instruction, programmable controller CPU information clear While the 'CH□ Switching mode' (X6/XD) is ON, do not issue a communication request to a target interface. (The transmission/reception processing of C24 is stopped while the 'CH□ Switching mode' (X6/XD) is ON.)

- \*4 'Predefined protocol ready' (X1D) is a signal that turns ON when predefined protocol communication becomes ready.
- \*5 Module READY is a signal that sends a signal of the applicability of accessing to C24 from the CPU module. Use it as an interlock signal for a program.
- \*6 Restart the CPU module when the watchdog timer error is turned ON. If the error still occurs after restarting, refer to the following section and take corrective actions. IP Page 463 RUN LED turns OFF

Output signals							
Device number	Signal name	Reference					
Y0	CH1 Transmission request	-					
Y1	CH1 Reception data read completion						
Y2	CH1 Mode switching request	Page 377 SWITCHING THE MODE AFTER STARTING					
Y3	CH1 protocol execution request	-					
Y4 to Y6	Use prohibited						
Y7	CH2 Transmission request						
Y8	CH2 Reception data read completion						
Y9	CH2 Mode switching request	Page 377 SWITCHING THE MODE AFTER STARTING					
YA	CH2 protocol execution request	-					
YB to YD	Use prohibited						
YE	Error initialization request	Page 448 Turning OFF the ERR LED and initializing the error codes					
YF	Use prohibited	-					
Y10	Modem initialization request	Page 160 List of input/output signals for					
Y11	Connection request	the modem function					
Y12	Modem disconnection request						
Y13 to Y16	Use prohibited	-					
Y17	User frame read request from flash ROM						
Y18	User frame write request to flash ROM						
Y19 to Y1B	Use prohibited						
Y1C	Parameter initialization request						
Y1D to Y1F	Use prohibited						

# Appendix 3 Buffer Memory

The buffer memory is the memory of C24 used for storing data (setting values, monitoring values, etc.) transmitted to or received from the CPU module.

Initial values are set to the buffer memory.

When changing the initial values, set the parameters with Engineering tool.

For details, refer to the following section.

Page 422 PARAMETER SETTING

### Configuration of buffer memory

A buffer memory consists of a user area and a system area as shown below.

#### ■User area

- · User area is an area where a user can read/write data.
- The user area consists of areas for storing setting values for data communication, for actual data communication, and for storing communication status and communication error information.
- Read/write data from/to the user area in accordance with the instructions in the corresponding reference section.

#### System area

System area is an area used by the C24 system.

### Buffer memory assignment list

A buffer memory is configured with 16 bits per address.

Names, default values, etc. of each address of the buffer memory are as shown below.

Page 498 Buffer memory list

### ■Meaning of abbreviations in "Protocol" column

MC: MC protocol Non: Nonprocedural protocol Bi: Bidirectional protocol Pd: Predefined protocol

### ■Meaning of symbols in "Protocol" column

The following symbols are assigned to protocols related to the setting values of a corresponding area and to areas used for control by user settings.

RW: An area where data can be read/written to/from the CPU module and an target device.

R: An area where data can only be read from the CPU module and an target device.

-: System area used by the system or area not used by the corresponding protocol.

### Precautions

- Do not write data in the "System area" of the buffer memory.
   If data is written to any of the system areas, the programmable controller system may malfunction.
   The system area exists in the user area partially, therefore, take caution when reading from/writing to the buffer memory.
- To use the dedicated instructions, change the following initial settings (default values) for data communications by setting parameters with an Engineering tool, or by executing the CSET instruction in the program.

Initial setting		Setting item
Communication using MC protocol	Setting the unit of data length sent by the on- demand function	"Word/byte units designation" (addresses: 96H/136H)
	Setting the buffer memory used by the on- demand function	<ul> <li>"Buffer memory start address designation" (addresses: A0H/ 140H)</li> <li>"Send buffer memory length designation" (addresses: A3H/143H)</li> </ul>
Communication using nonprocedural/ bidirectional protocols	Setting the unit of data length to be sent and received	"Word/byte units designation" (addresses: 96H/136H)
	Setting the data send area	<ul> <li>"Send buffer memory start address designation" (addresses: A2H/142H)</li> <li>"Send buffer memory length designation" (addresses: A3H/143H)</li> </ul>
	Setting the data receive area	<ul> <li>"Receive buffer memory length designation" (addresses: A7H/ 147H)</li> </ul>

For details on the registration operation by an Engineering tool, refer to the following section.

Page 422 PARAMETER SETTING

For the CSET instruction, refer to the following manual.

MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks)

# **Buffer memory list**

Address Dec (Hex)		Purpose	Name	Defaul t value	Protocol				Reference
CH1 (	CH2				МС	Non	Bi	Pd	
0, 1 (0H, 1H)		Use prohibited	System area	-					1
2 (2H)		For flash ROM (user frame) access	Register/read/delete instructions 0: No request 1: Registration request 2: Read request 3: Deletion request	0	RW		_		_
3 (3H)			Frame No. direction 0: No designation Other than 0: Frame number	0					
4 (4H)			Registration/read/delete result storage 0: Normal completion Other than 0: Abnormal completion	0	-				
5 (5H)			Registration data byte count designation 0: No designation Other than 0: Number of registered data bytes (maximum 80 bytes)	0					
6 to 45 (6H to 2DH)			User frame 0: No designation Other than 0: Registration data (maximum 80 bytes)	0					
46 (2EH)		For designation of the modem function-1	Modem connection CH specification 0: None 1: CH1 2: CH2	0	RW			_	Page 161 Buffer memory
47 (2FH)		Use prohibited	System area	—	·				
48 (30H)		For designation of the modem	Connection re-try count designation 1 to 5: Number of retries	3 (3 times)	RW			-	Page 161 Buffer memory
49 (31H)		function-1	Connection retry interval designation 90 to 300: Connection retry interval (unit: s)	180 (180 second s)					
50 (32H)			Initialization/connection timeout designation 1 to 60: Timeout time (unit: s)	60 (60 second s)					
51 (33H)		-	Number of initialization retries designation 1 to 5: Number of retries	3 (3 times)	-				
52 (34H)			Data No. for initialization designation 0H : Send designated data for initialization by the send user frame designation area. 7D0H to 801FH: Data number for initialization	7D0H					
53 (35H)			Data No. for connection designation 0H: No designation BB8H to 801FH: Data number for connection	0					
54 (36H)		Use prohibited	System area	—					
55 (37H)		For designation of the modem function-1	No-communication interval time designation 0: Infinite wait 1 to 120: No communication interval (line disconnection wait time) (unit: min)	30 (30 minutes )	RW			_	Page 161 Buffer memory
56 (38H)			RS/CS control enable/disable designation 0: Control disabled 1: Control enabled	1					
57 to 127 (39H to 7FH)		Use prohibited	System area	-					

Address Dec (Hex)		Purpose	Name	Defaul t value	Prote	ocol			Reference
CH1	CH2				МС	Non	Bi	Pd	
128 (80H)		For programmable controller CPU information clear	Programmable controller CPU information clear request 0: No request 4C43H: Requested	0	RW	-	•		Page 455 How to Clear Programmable Controller CPU Information
129 to 143 (81H to 8FI	H)	Use prohibited	System area	-					
144 (90H)	304 (130H)	For designation of mode switching	Switching mode No. designation (0001H to 0007H, 0009H, 00FFH) 0000H: Match the setting in MELSOFT. 0001H: MC protocol (Format 1) 0002H: MC protocol (Format 2) 0003H: MC protocol (Format 3) 0004H: MC protocol (Format 4) 0005H: MC protocol (Format 5) 0006H: Nonprocedural protocol 0007H: Bidirectional protocol 0009H: Predefined protocol 000FH: MELSOFT connection	0	RW				Page 380 I/O Signals for Handshake with CPU Module and Buffer Memory
145 (91H)	305 (131H)	For designation of mode switching	Transmission specifications after switching designation Designates transmission specifications after switching when b15 of this area is 1 (ON). • Operation setting (b0) 0: Independent 1: Interlink • Data bit (b1) 0: 7 bits 1: 8 bits • Parity bit (b2) 0: None 1: Yes • Odd/even parity (b3) 0: Odd 1: Even • Stop bit (b4) 0: 1 bit 1: 2 bits • Sum check code (b5) 0: None 1: Yes • Online change (b6) 0: Disable 1: Enable • Setting change (b7) 0: Disable 1: Enable • Communication speed (b8 to b11) 1200 bps to 230400 bps • For system (b12 to b14) All 0 • Transmission specifications direction after switching (b15) 0: Match settings in MELSOFT 1: Match settings in this area	0					
146 (92H)	306 (132H)	Signal specification	RS and DTR signal status designation 0: OFF 1: ON RS (RTS) signal (b0) ER (DTR) signal (b2) For system (b1). (b3) to (b15)	5H	-				MELSEC iQ-R Serial Communication Module User's Manual (Startup)



Address Dec (Hex)		Purpose	Name	Defaul t value	Protocol				Reference	
CH1	CH2				мс	Non	Bi	Pd		
147 (93H)	307 (133H)	For designation of transmission control	DTR/DSR (ER/DR), DC control designation • Transmission control (b0) 0: DTR/DSR control 1: DC code control • DC1/DC3 control (b8) 0: Control disabled 1: Control enabled • DC2/DC4 control (b9) 0: Control disabled 1: Control enabled	0	RW	1		1	Page 236 DATA COMMUNICATIONS USING DC CODE TRANSMISSION CONTROL	
148 (94H)	308 (134H)		DC1/DC3 (Xon/Xoff) code designation • DC1 code (b0 to b7) 00H to FFH: DC1 code • DC3 code (b8 to b15) 00H to FFH: DC3 code	1311H						
149 (95H)	309 (135H)		DC2/DC4 code designation • DC2 code (b0 to b7) 00H to FFH: DC2 code • DC4 code (b8 to b15) 00H to FFH: DC4 code	1412H				-		
150 (96H)	310 (136H)	For designation of communication control	Word/byte units designation 0: Word units 1: Byte units	0	RW			_	Page 225 CHANGING DATA LENGTH UNITS TO BYTE UNITS (WORD/BYTE UNITS SETTING)	
151 (97H)	311 (137H)		CD terminal check designation (for RS-232) 0: Check 1: Do not check	1	RW				MELSEC iQ-R Serial Communication Module User's Manual (Startup)	
152 (98H)	312 (138H)		Communication method designation (for RS- 232) 0: Full duplex communication 1: Half-duplex communication	0					Page 243 DATA COMMUNICATIONS USING HALF- DUPLEX COMMUNICATIONS	
153 (99H)	313 (139H)	For designation of half-duplex communications control (for RS- 232)	Simultaneous transmission priority/non-priority designation 0: Priority 1 to 255: Non-priority (transmission wait time, unit: 100 ms)	0						
154 (9AH)	314 (13AH)		Retransmission time transmission method designation 0: Do not resend 1: Resend	0						
155 (9BH)	315 (13BH)	For designation of communication control	Simultaneous transmission data valid/invalid designation • Receive data enable/disable (b0) 0: Enable 1: Disable • Send data enable/disable (b8) 0: Enable 1: Disable	0	_		RW	—		
156 (9CH)	316 (13CH)	For designation of data communication time monitoring	No-reception monitoring time (timer 0) designation 0H: Unlimited wait 28H to FA0H: Monitoring time (unit: byte)	0	RW	/		—	Page 227 CHANGING DATA COMMUNICATION MONITORING TIME	
157 (9DH)	317 (13DH)		Response monitoring time (timer 1) designation 0H: Unlimited wait 1H to BB8H: Monitoring time (unit: 100ms)	32H (5 second s)	RW	-	RW			
158 (9EH)	318 (13EH)		Send monitoring time (timer 2) designation 0H: Unlimited wait 1H to BB8H: Monitoring time (unit: 100ms)	708H (3 minutes )	RW			_		
159 (9FH)	319 (13FH)	Use prohibited	System area	-						

500

Address Dec (Hex)		Purpose	Name	Defaul t value	Proto	ocol		Reference	
CH1	CH2				мс	Non	Bi	Pd	
160 (A0H)	320 (140H)	For designation of on-demand function	Buffer memory start address designation (400H to 1AFFH, 2600H to 3FFFH)	CH1:40 0H CH2:80 0H	RW	_			Page 267 ON- DEMAND DATA COMMUNICATIONS USING USER
161 (A1H)	321 (141H)		Data length designation (0000H to 3400H)	0					FRAMES MELSEC Communication Protocol Reference Manual
162 (A2H)	322 (142H)	For designation of send area	Send buffer memory start address designation (400H to 1AFFH, 2600H to 3FFFH)	CH1: 400H CH2: 800H	_	RW		_	Page 390 Send/ receive Data Monitoring Function Settings
163 (A3H)	323 (143H)		Send buffer memory length designation (0001H to 1A00H)	200H					
164 (A4H)	324 (144H)	For data reception	Receive end data quantity designation 0001H to 33FEH: Receive end data quantity	1FFH	—	RW	—		
165 (A5H)	325 (145H)		Receive end code designation FFFFH : No designation for receive end code 0H to FFH: Receive end code	0D0AH: CR+LF					
166 (A6H)	326 (146H)	For designation of receive area	Receiving buffer memory start address designation (400H to 1AFFH, 2600H to 3FFFH)	CH1: 600H CH2: A00H	—	RW		_	Page 390 Send/ receive Data Monitoring Function Settings
167 (A7H)	327 (147H)		Receive buffer memory length designation (0001H to 1A00H)	200H					
168 (A8H)	328 (148H)	For data reception	Receive data clear request 0: No request 1: Requested	0	—	RW	-		
169 (A9H)	329 (149H)	For designation of on-demand user frame	Start frame No. designation, 1st 0: No designation Other than 0: Designated	0	RW —	—	_		Page 268 User Frame On-Demand
170 (AAH)	330 (14AH)		Start frame No. designation, 2nd 0: No designation Other than 0: Designated	0					Frame On-Demand Data Transmission and Buffer Memory Used
171 (ABH)	331 (14BH)		Final frame No. designation, 1st 0: No designation Other than 0: Designated	0					Page 289 Setting of receive user frames
172 (ACH)	332 (14CH)		Final frame No. designation, 2nd 0: No designation Other than 0: Designated	0					
173 (ADH)	333 (14DH)	For designation of receive user frame	User frame use enable/disable designation 0: Not use 1: Use 2: Data communication possible (Set by C24)	0	—	RW	-		
174 to 177 (AEH to	334 to 337 (14EH to		Start frame No. designation (1st to 4th) 0H: No designation 1H or more: Start frame No.	0					
B1H)	151H)								
178 to 181 (B2H to	338 to 341 (152H to		Final frame No. designation (1st to 4th) 0H: No designation 1H or more: Final frame No.	0DH 0AH 00H					
85H)	155H)	Conding year	Conding upor frame	00H		<b>D</b>			Dage 215 Cettings of
(B6H)	(156H)	frame	0 : Has not been sent 1 to 100: User frame being sent (nth)	0		ĸ			send user frames
183 (B7H)	343 (157H)	For designation of send user	CR/LF output designation 0: Do not send 1: Send	0	—	RW	-		
184 (B8H)	344 (158H)	frame	Output start pointer designation 0: No designation 1 to 100: Send from nth	0					
185 (B9H)	345 (159H)		Output quantity designation 0: No designation 1 to 100: Output n	0					
186 to 285 (BAH to 11DH)	346 to 445 (15AH to 1BDH)		Send frame number designation (A maximum of 100 can be designated) 0H: No transmission designation 1H to C01FH: Designated	0					

Address Dec (Hex)		Purpose	Name	Defaul t value	Protocol				Reference
CH1	CH2				МС	Non	Bi	Pd	
286 (11EH)	446 (1BEH)	For designation of send wait time	Transmission wait time designation 0: No wait time 1H to FH: Wait time (unit: 10 ms)	0	RW	—			Page 235 Transmission Wait Time Setting
287 (11FH)	447 (1BFH)	For designation of transparent code	Transparent code for sending specification, 1st 0000H: No specification Other than 0000H: Specified (below) • Transparent code (b0 to b7) 00H to FFH: Transparent code • Additional code (b8 to b15) 01H to FFH: Additional code	0	_	RW		_	Page 326 TRANSPARENT CODES AND ADDITIONAL CODES
288 (120H)	448 (1C0H)		Transparent code for receiving specification 0000H: No specification Other than 0000H: Specified (below) • Transparent code (b0 to b7) 00H to FFH: Transparent code • Additional code (b8 to b15) 01H to FFH: Additional code	0					
289 (121H)	449 (1C1H)	For conversion designation	ASCII-binary conversion designation 0: Do not convert 1: Convert	0					Page 347 COMMUNICATING WITH ASCII CODE (ASCII-BIN CONVERSION)
290 (122H)	450 (1C2H)	For communication control specification	Echo back enable/prohibit specification for RS- 422/485 interface 0: Echo back enable 1: Echo back prohibit	0	RW				Page 403 RS-422/ 485 INTERFACE ECHO BACK ENABLE/PROHIBIT SPECIFICATION
291 (123H)	451 (1C3H)	For NULL character automatic removal designation	NULL character automatic removal designation for transmission 0: Auto delete disabled 1: Auto delete enabled	0	_	RW		_	Page 407 AUTOMATIC REMOVAL OF NULL CHARACTERS INCLUDED IN SEND DATA
292 (124H)	452 (1C4H)	For erroneous reception prevention designation	Communication data reception enable/disable designation 0: Receive enable 1: Receive disable	0	RW				Page 405 ERRONEOUS NOISE SIGNAL RECEPTION PREVENTION FUNCTION
293 to 303 (125H to 12FH)	453 to 511 (1C5H to 1FFH)	Use prohibited	System area						
Address Dec (Hex)	Purpose	Name	Defaul t value	Protocol				Reference	
----------------------	--	--	--	----------	-----	----	----	--	
CH1 CH2				МС	Non	Bi	Pd		
512 (200H)	For confirmation of station number setting status	Station number (parameter setting)	Depend s on paramet er setting	R	1	1		Page 441 Module information list	
513 (201H)	For confirmation of LED lighting status and communication error status	CH1 side LED lighting status and communication error status 0: LED OFF, no error 1: LED ON, error SD WAIT (b0) SIO (b1) PRO. (b2) P/S (b3) C/N (b4) NAK (b5) ACK. (b6) NEU. (b7) For system (b8) to (b14) CH1 ERR. (b15)	Depend s on module status.	-					
514 (202H)		CH2 side LED lighting status and communication error status 0: LED OFF, no error 1: LED ON, error SD WAIT (b0) SIO (b1) PRO. (b2) P/S (b3) C/N (b4) NAK (b5) ACK. (b6) NEU. (b7) CH2.ERR. (b14) For system (b8) to (b13),(b15)	Depend s on module status.						
515 (203H)	For confirmation of parameter setting and mode switching	<ul> <li>Parameter setting error and mode switching error status</li> <li>0: No error</li> <li>Other than 0: Parameter setting error and mode switching error</li> <li>CH1 Communication protocol setting number (b0)</li> <li>0: Normal 1: Error</li> <li>CH1 Communication speed setting (b1)</li> <li>0: Normal 1: Error</li> <li>CH1 Mode switching at setting change prohibit (b3)</li> <li>0: Normal 1: Error</li> <li>CH2 Communication protocol setting number (b4)</li> <li>0: Normal 1: Error</li> <li>CH2 Communication speed setting (b5)</li> <li>0: Normal 1: Error</li> <li>CH2 Communication speed setting (b5)</li> <li>0: Normal 1: Error</li> <li>CH2 Communication speed setting (b5)</li> <li>0: Normal 1: Error</li> <li>CH2 Mode switching at setting change prohibit (b7)</li> <li>0: Normal 1: Error</li> <li>Setting station No. (b14)</li> <li>0: Normal 1: Error</li> <li>Interlink operation setting (b15)</li> <li>0: Normal 1: Error</li> </ul>	0	R				Page 445 Intelligent function module monitor	

Address Dec (Hex)	Purpose	Name	Defaul t value	ul Protocol ue				Reference
CH1 CH2	_			МС	Non	Bi	Pd	-
516 (204H)	For confirmation of user frame	Number of registered user frames 0: No registration 1 to 200: Number of registered frames	Depend s on registrat ion status.	R		_		_
517 to 541 (205H to 21DH)		User frame registration status (for registration number check) 0: No registration 1: Registered Bit corresponding to registration No. is 0(OFF)/ 1(ON). Registration No. 3E8H (1000): Address 205H (b0) to Registration No. 4AFH(1199): Address 211H (b7)	Depend s on registrat ion status.					
542 (21EH)	For confirmation of user frame	Number of registered default registration frames (for system)	Depend s on registrat ion status.					Page 258 Default registration frame (read only)
543, 544 (21FH, 220H)	Use prohibited	System area	—					
545 (221H)	For confirmation of the modem function	Modern function error code (error code when the modem function is being used) 0 : Normal completion Other than 0 (error code) : Abnormal completion	0	RW				Page 161 Buffer memory
546 (222H)		Modem function sequence status 0: Idle 1: Waiting for initialization 2: Initializing modem 3: Waiting 4: Checking password 5: Communicating 7: Modem disconnected	0	R			_	
547 (223H)		Number of data registration for connection 0: No registration 1 to 30: Number of registrations	Depend s on registrat ion status.					
548, 549 (224H, 225H)		Data registration status for connection (for confirmation of registration No.) 0: No registration 1: Registered Bit corresponding to registration No. is 0(OFF)/ 1(ON). Registration No. BB8H (3000) : Address 224H (b0) to Registration No. BD5H (3029) : Address 225H (b13)	Depend s on registrat ion status.					
550 (226H)		Number of data registration for initialization 0: No registration 1 to 30: Number of registrations	Depend s on registrat ion status.					
551, 552 (227H, 228H)	For confirmation of the modem function	Data registration status for initialization (for confirmation of registration No.) 0: No registration 1: Registered Bit corresponding to registration No. is 0(OFF)/ 1(ON). Registration No.9C4H (2500) : Address 227H (b0) to Registration No. 9E1H (2529) : Address 228H (b13)	Depend s on registrat ion status.	R				
553 to 589 (229H to 24DH)	Use prohibited	System area	—					

Address Purpose Dec (Hex)		Purpose	Name	Defaul t value	Proto	ocol		Reference	
CH1	CH2				мс	Non	Bi	Pd	
590 (24EH)		For confirmation of test mode status	Test mode setting status 0000H: No specification 0001H: Hardware Tests 0002H: Self-loopback test	Depend s on paramet er setting.	R				_
591 (24FH)		For confirmation of station number setting status	Station number (instruction setting) (0 to 31)	Depend s on module status.	R				Page 445 Intelligent function module monitor
592 (250H)	608 (260H)	For confirmation of transmission control status	Communication protocol status (parameter setting) 0: MELSOFT Connection 1: MC protocol (Format 1) 2: MC protocol (Format 2) 3: MC protocol (Format 3) 4: MC protocol (Format 4) 5: MC protocol (Format 5) 6: Nonprocedural protocol 7: Bidirectional protocol 8: (For interlink operation) 9: Predefined protocol	Depend s on paramet er setting.					_

Address Dec (Hex	)	Purpose	Name	Defaul t value	e Protocol				Reference
CH1	CH2				мс	Non	Bi	Pd	
593 (251H)	609 (261H)	For confirmation of transmission control status	Transmission setting status (parameter setting) • Operation setting (b0) 0: Independent 1: Interlink • Data bit (b1) 0: 7 bits 1: 8 bits • Parity bit (b2) 0: None 1: Yes • Odd/even parity (b3) 0: Odd 1: Even • Stop bit (b4) 0: 1 bit 1: 2 bits • Sum check code (b5) 0: None 1: Yes • Online change (b6) 0: Disable 1: Enable • Setting change (b7) 0: Disable 1: Enable • Communication speed (b8 to b11) 1200 bps to 230400 bps • For system (b12 to b15) All 0	Depend s on paramet er setting.	R				
594 (252H)	610 (262H)		Communication protocol status (current) 0: MELSOFT connection 1: MC protocol (Format 1) 2: MC protocol (Format 2) 3: MC protocol (Format 3) 4: MC protocol (Format 4) 5: MC protocol (Format 5) 6: Nonprocedural protocol 7: Bidirectional protocol 8: (For interlink operation) 9: Predefined protocol	Depend s on module status.					Page 445 Intelligent function module monitor
595 (253H)	611 (263H)		Transmission status (current) • Operation setting (b0) 0: Independent 1: Interlink • Data bit (b1) 0: 7 bits 1: 8 bits • Parity bit (b2) 0: None 1: Yes • Odd/even parity (b3) 0: Odd 1: Even • Stop bit (b4) 0: 1 bit 1: 2 bits • Sum check code (b5) 0: None 1: Yes • Online change (b6) 0: Disable 1: Enable • Setting change (b7) 0: Disable 1: Enable • Communication speed (b8 to b11) 1200 bps to 230400 bps • For system (b12 to b15) All 0	Depend s on module status.					
596 (254H)	612 (264H)	Control signal status	RS-232 control signal status 0: OFF status 1: ON status RS(RTS) (b0) DR(DSR) (b1) ER(DTR) (b2) CD(DCD) (b3) CS(CTS) (b4) CI(RI) (b5) Not used (b6 to b15) All 0	Depend s on signal status.	R				

Address Dec (Hex	)	Purpose	Name	Defaul t value	aul Protocol lue				Reference
CH1	CH2				МС	Non	Bi	Pd	
597 (255H)	613 (265H)	For confirmation of communication result	Transmission sequence status (For confirmation of MC protocol communication status) 0: Waiting for receiving command message 1: Receiving command message 2: Command message reception complete 3: Waiting to access CPU module 4: Accessing CPU module 5: CPU module access complete 6: Response message transmission	0	R	_			Page 445 Intelligent function module monitor
598 (256H)	614 (266H)		On-demand execution results 0: Normal completion Other than 0: Abnormal completion (error code)	0	RW	—			Page 233 Send Monitoring Time (timer 2) Setting
599 (257H)	615 (267H)		Data transmission result 0: Normal completion Other than 0: Abnormal completion (error code)	0	RW	·			Page 448 Error information clear
600 (258H)	616 (268H)		Data reception result 0: Normal completion Other than 0: Abnormal completion (error code)	0					
601 (259H)	617 (269H)	Use prohibited	System area	-					
602 (25AH)	618 (26AH)	For confirmation of communication	MC protocol send error code (excludes 1C frame communication) 0: No error 1 or more: Send error code	0	RW	—			-
603 (25BH)	619 (26BH)	result	Receive user frame (nth) 0 : Has not been received 1 to 4: Combination of user frame No. designations for reception message	0	—	R	_		
604 to 607 (25CH to 25FH)	620 to 1023 (26CH to 3FFH)	Use prohibited	System area	_					
1024 (400H)	2048 (800H)	Send/receive area <sup>*1</sup>	Send data quantity designation 0: No designation 1 or more: Number of send data	0	RW				Page 57 Receive area and receive data arrangement
1025 to 1535 (401H to 5FFH)	2049 to 2559 (801H to 9FFH)		Send data specification Data to be sent to a target device	0					Page 78 Send area and send data arrangement
1536 (600H)	2560 (A00H)		Receive data quantity (Number of data for which read is requested) 0: No receive data 1 or more: Receive data quantity	0					
1537 to 2047 (601H to 7FFH)	2561 to 3071 (A01H to BFFH)		Receive data Data received from a target device	0					
3072 to 69 (C00H to 1	11 AFFH)	For user	User setting area (3840 words) Determined by the user.	0	RW				-

Address Dec (Hex)	Purpose	Name	Defaul Protocol t value					Reference
CH1 CH2				мс	Non	Bi	Pd	
6912 to 6952 (1B00H to 1B28H)	For user registration	For registration No. 8001H	The user together	registra for the f	ition are ollowing	a is use usage,	ed with	Page 161 Buffer memory
6953 to 6993 (1B29H to 1B51H)		For registration No. 8002H	data writt the purpo	en by th ose of us	ne user a se by th	accordir e TO	ng to	
6994 to 7034 (1B52H to 1B7AH)		For registration No. 8003H	■When c	lata is c les	ommuni	cated u	sing	
7035 to 7075 (1B7BH to 1BA3H)		For registration No. 8004H	• User fr     ■When c	ame lata is c	ommuni	cated u	sing	
7076 to 7116 (1BA4H to 1BCCH		For registration No. 8005H	the mode • Data fo	em funct or initiali	ion zation			
7117 to 7157 (1BCDH to 1BF5H)		For registration No. 8006H	Data it					
7158 to 7198 (1BF6H to 1C1EH)		For registration No. 8007H	]					
7199 to 7239 (1C1FH to 1C47H)		For registration No. 8008H						
7240 to 7280 (1C48H to 1C70H)		For registration No. 8009H						
7281 to 7321 (1C71H to 1C99H)		For registration No. 800AH						
7322 to 7362 (1C9AH to 1CC2H)		For registration No. 800BH						
7363 to 7403 (1CC3H to 1CEBH		For registration No. 800CH						
7404 to 7444 (1CECH to 1D14H)		For registration No. 800DH						
7445 to 7485 (1D15H to 1D3DH)		For registration No. 800EH						
7486 to 7526 (1D3EH to 1D66H)		For registration No. 800FH						
7527 to 7567 (1D67H to 1D8FH)		For registration No. 8010H						
7568 to 7608 (1D90H to 1DB8H)		For registration No. 8011H						
7609 to 7649 (1DB9H to 1DE1H)		For registration No. 8012H						
7650 to 7690 (1DE2H to 1E0AH)		For registration No. 8013H						
7691 to 7731 (1E0BH to 1E33H)		For registration No. 8014H	]					
7732 to 7772 (1E34H to 1E5CH)		For registration No. 8015H	]					
7773 to 7813 (1E5DH to 1E85H)		For registration No. 8016H						

Address Dec (Hex)	)	Purpose	Name	Defaul t value	Prot	ocol		Reference			
CH1	CH2				МС	Non	Bi	Pd			
7814 to 785 (1E86H to 7	54 1EAEH)	For user registration	For registration No. 8017H	The user together	registra for the f	ation area	a is use usage,	d with	Page 161 Buffer memory		
7855 to 789 (1EAFH to	95 1ED7H)		For registration No. 8018H	data writt	en by tl ose of u	ne user a se by the	ng to				
7896 to 793 (1ED8H to	36 1F00H)		For registration No. 8019H	■When d	lata is c les	ommuni	cated u	sing			
7937 to 797 (1F01H to 1	77 1F29H)		For registration No. 801AH	• User fr ∎When d	ame lata is c	ommuni	cated u	sing			
7978 to 801 (1F2AH to	18 1F52H)		For registration No. 801BH	the mode     Data fo     Data fo	em functor finitialition finitialition	zation zation					
8019 to 805 (1F53H to 1	59 1F7BH)		For registration No. 801CH								
8060 to 810 (1F7CH to	00 1FA4H)		For registration No. 801DH								
8101 to 814 (1FA5H to 2	41 1FCDH)		For registration No. 801EH								
8142 to 818 (1FCEH to	32 1FF6H)		For registration No. 801FH								
8183 to 819 (1FF7H to 2	98 2006H)	Use prohibited	System area	—				_			
8199 (2007H)		For designation of the modem function -2	Auto modem initialization designation 0: Do not automatically initialize 1: Automatically initialize	0	RW			_	Page 161 Buffer memory		
8200 (2008H)			Modem initialization DR (DSR) signal enable/ disable designation 0: DR signal enabled 1: DR signal disabled	1							
8201 (2009H)			Complete signal handling for modem function designation 0: Do not turn ON/OFF X13, X14. 1: Turn ON/OFF X13, X14.	1	-						
8202, 8203 (200AH, 20	0BH)	Use prohibited	System area	-							
8204 (200CH)		For remote password function	Remote password mismatch notification count designation 0H: No designation 1H to FFFFH: Number of times for notification	0	RW	-			Page 161 Buffer memory		
8205 (200DH)			Remote password mismatch notification accumulated count designation 0H: No designation 1H to FFFFH: Cumulative number of times for notification	1							
8206 (200EH)		For designation of the modem function -3	Line disconnection wait time specification (PLC CPU monitor) 0000H to FFFFH: Wait time (unit: s)	0	RW		—		Page 161 Buffer memory		
8207 (200FH)	8459 to 8463 (210BH to 210FH)	Use prohibited	System area	_							
8208 (2010H)	8464 (2110H)	Interrupt specification	Receive interrupt-issued designation 0: Do not issue interrupt. 1: Issue interrupt.	0	_	RW		-	Page 433 Interrupt settings		
8209 (2011H)	8465 (2111H)	Use prohibited	System area	-							

509

Address Dec (Hex	)	Purpose	Name	Defaul t value	Prote	ocol			Reference
CH1	CH2				МС	Non	Bi	Pd	
8210 (2012H)	8466 (2112H)	For designation of transmission control	Transmission control start free space designation 64 to 4095: transmission control start free space	64	RW		1		Page 237 C24 DTR control contents and free OS area specification
8211 (2013H)	8467 (2113H)		Transmission control end free space designation 263 to 4096: transmission control end free space	263					
8212 (2014H)	8468 (2114H)		Nonprocedural no-reception monitoring time method designation 0: Method 0 1: Method 1	0	—	RW	—		
8213 to 8215 (2015H to 2017H)	8469 to 8471 (2115H to 2117H)	Use prohibited	System area	_					
8216 (2018H)	8472 (2118H)	Send/receive data monitoring function	Send/receive data monitoring designation 0000H: No monitor/stop instruction 0001H: Monitor start instruction 0002H: Monitoring (set by C24.) 1002H: Monitoring stopped (set by C24.) 100FH: Monitor setting error (set by C24.)	0	RW				Page 388 Send/ receive data monitoring operation
8217 (2019H)	8473 (2119H)		Monitor option specification 0: OFF 1: ON Stop at buffer full specification (b0) 0 timer error outbreak stop designation (b2) For system (b1), (b3) to (b15)	0					
8218 (201AH)	8474 (211AH)		Monitor buffer start address designation (400H to 1AFDH, 2600H to 3FFDH)	CH1: 2600H CH2: 3300H					
8219 (201BH)	8475 (211BH)		Monitor buffer size designation (0003H to 1A00H)	0D00H					
8220 to 8223 (201CH to 201FH)	8476 to 8479 (211CH to 211FH)	Use prohibited	System area	_					
8224 to 8227 (2020H to 2023H)	8480 to 8483 (2120H to 2123H)	For designation of user frame receiving method	User frame receiving method designation (1st to 4th) 0: Method 0, 1: Method 1	0	_	RW			Page 289 Setting of receive user frames
8228 to 8231 (2024H to 2027H)	8484 to 8487 (2124H to 2127H)		Method 1 dedicated receive end data quantity designation (1st to 4th) 0 or more: Method 1 dedicated receive end data quantity designation	0					
8232 to 8239 (2028H to 202FH)	8488 to 8495 (2128H to 212FH)	Use prohibited	System area	—					
8240 to 8248 (2030H to 2038H)	8496 to 8504 (2130H to 2138H)	For designation of transparent code	Transparent code for sending specification (2nd to 10th) 0000H: No specification Other than 0000H: Specified (below) • Transparent code (b0 to b7) 00H to FFH : Transparent code • Additional code (b8 to b15) 01H to FFH : Additional code	0	_	RW		_	Page 327 Registering Transparent Codes and Additional Codes
8249 to 8255 (2039H to 203FH)	8505 to 8511 (2139H to 213FH)	Use prohibited	System area	_					

Address Dec (Hex	)	Purpose	Name	Defaul t value	Il Protocol e				Reference
CH1	CH2				мс	Non	Bi	Pd	
8256 (2040H)	8512 (2140H)	For designation of	Cycle time units designation 0: 100 ms 1: s 2: min	2	R		—		Page 138 Settings for Using the
8257 (2041H)	8513 (2141H)	programmable controller CPU monitoring function	Cycle time designation (programmable controller CPU monitoring interval time) 0H : No designation 1H to FFFFH: Programmable controller CPU monitoring interval time	5H					Programmable Controller CPU Monitoring Function
8258 (2042H)	8514 (2142H)		Programmable controller CPU monitoring function designation 0: Do not use the function. 1: Fixed cycle send 2: Condition match send	0					
8259 (2043H)	8515 (2143H)		System area	—					
8260 (2044H)	8516 (2144H)		Send pointer designation (For fixed cycle send and nonprocedural data transmission) 0: No specification 1 to 100: Output head point (send from the nth) Send the user frames designated in the following send frame number designation areas from the designated pointer position. (addresses: CH1 side = BAH to 11DH, CH2 side = 15AH to 1BDH)	0	_	R	_		
8261 (2045H)	8517 (2145H)		Output quantity designation (for fixed cycle send and nonprocedural data transmission) 0: No specification 1 to 100:Output quantity (Specify the number of frame to be transmitted.)	0					
8262 (2046H)	8518 (2146H)		Data No. for connection designation (for fixed cycle send) 0: No designation 0BB8H to 0BD5H, 8001H to 801FH: Data No. for connection	0	R		_		
8263 to 8268 (2047H to 204CH)	8519 to 8524 (2147H to 214CH)	Use prohibited	System area	—					
8269 (204DH)	8525 (214DH)	For designation of programmable controller CPU	Registered word block quantity designation 0: No designation 1 to 10: Number of blocks of word devices (Up to 10 blocks can be designated in total.)	0	R		_		Page 138 Settings for Using the Programmable Controller CPU
8270 (204EH)	8526 (214EH)	monitoring function	Registered bit block quantity designation 0: No designation 1 to 10: Number of blocks of bit devices (Up to 10 blocks can be designated in total.)	0					Monitoring Function
8271 (204FH)	8527 (214FH)		CPU error monitoring designation 0: Do not monitor. 1: Monitor.	0					
8272 (2050H)	8528 (2150H)		1st block monitoring device Monitoring device designation 0: No designation 90H to CCH: Device code	0					
8273, 8274 (2051H, 2052H)	8529, 8530 (2151H, 2152H)		1st block monitoring device Start device No. specification 0 or more: Start device number	0					
8275 (2053H)	8531 (2153H)		1st block monitoring device Number of read points specification 0: No specification 1 or more: read point	0					
8276 (2054H)	8532 (2154H)		1st block monitoring device Monitoring condition specification (judgment condition specification) 0: No specification 1 or more: Monitoring condition	0					

Address Dec (Hex	)	Purpose	Name	Defaul t value	Protocol				Reference	
CH1	CH2				мс	Non	Bi	Pd		
8277 (2055H)	8533 (2155H)	For designation of programmable controller CPU monitoring function	<ul> <li>1st block monitoring device</li> <li>Monitoring condition value designation</li> <li>At bit device</li> <li>0: OFF 1: ON</li> <li>At word device</li> <li>0 to FFFFH: Monitoring condition value</li> </ul>	0	R		_		Page 138 Settings for Using the Programmable Controller CPU Monitoring Function	
8278 (2056H)	8534 (2156H)		1st block monitoring device Send pointer designation (for condition match send and nonprocedural data transmission) 0: No designation 1 to 100: Output head point (send from the nth) Send the user frames designated in the following send frame number designation areas from the designated pointer position. (address: CH1 side = BAH to 11DH, CH2 side = 15AH to 1BDH)	0	-	R	_			
8279 (2057H)	8535 (2157H)		1st block monitoring device Output quantity designation (for condition match send and nonprocedural data transmission) 0: No designation 1 to 100: Output quantity (Designate the number of frame to be transmitted.)	0						
8280 (2058H)	8536 (2158H)		1st block monitoring device Data No. for connection designation (for condition match send) 0: No designation 0BB8H to 0BD5H, 8001H to 801FH: Data No. for connection	0	R					
8281 to 8361 (2059H to 20A9H)	8537 to 8617 (2159H to 21A9H)		2nd to 10th block monitoring devices The structure of each area is the same as the 1s Page 519 Monitoring device areas for the pr function	t block mor ogrammabl	nitoring le contro	device a oller CP	area. U moni	toring		
8362 to 8421 (20AAH to	8618 to 8677 (21AAH to	Use prohibited	System area	_						
20E5H) 8422 (20E6H)	21E5H) 8678 (21E6H)	For designation of programmable controller CPU monitoring function	CPU error monitoring designation Send pointer designation (for condition match send and nonprocedural data transmission) 0: No designation 1 to 100: Output head point (send from the nth) Send the user frames designated in the following send frame number designation areas from the designated pointer position. CH1 side = BAH to 11DH CH2 side = 15AH to 1BDH	0	_	R			Page 138 Settings for Using the Programmable Controller CPU Monitoring Function	
8423 (20E7H)	8679 (21E7H)		CPU error monitoring designation Output quantity designation (for condition match send and nonprocedural data transmission) 0: No designation 1 to 100: Output quantity (number of frame to be transmitted)	0						
8424 (20E8H)	8680 (21E8H)		CPU error monitoring designation Data No. for connection designation (for condition match send) 0: No designation 0BB8H to 0BD5H, 8001H to 801FH: Data No. for connection	0	R		_			

Address Dec (Hex	)	Purpose	Name	Defaul t value	ul Protocol Je				Reference
CH1	CH2				МС	Non	Bi	Pd	
8425 to 8458 (20E9H to 210AH)	8681 to 8703 (21E9H to 21FFH)	Use prohibited	System area	—	•		-		
8704 to 8707 (2200H to 2203H)	8960 to 8963 (2300H to 2303H)	Use prohibited	System area	—					
8708 (2204H)	8964 (2304H)	Programmable controller CPU monitoring function	Programmable controller CPU monitoring function operation status 0: Not executed 1: Wait for programmable controller CPU monitoring time 2: Accessing programmable controller CPU 3: Sending monitoring results	0	R		_		Page 138 Settings for Using the Programmable Controller CPU Monitoring Function
8709 (2205H)	8965 (2305H)		Programmable controller CPU monitoring function execution result (current) 0: Normal completion Other than 0: Abnormal completion (error code)	0					
8710 (2206H)	8966 (2306H)		Programmable controller CPU monitoring function number of transmission 0: Not executed 1 or more: Number of transmissions	0					
8711 (2207H)	8967 (2307H)		Monitoring condition attained block No. 0 : No block of which monitoring condition is satisfied 1 to 10: Registration order of word/bit block (nth) 4096 : CPU abnormal monitoring block The latest block No. for which monitoring condition is satisfied is stored.	0	-				
8712 to 8948 (2208H to 22F4H)	8968 to 9215 (2308H to 23FFH)	Use prohibited	System area	_					
8949 to 895 (22F5H to 2	54 22FAH)	Use prohibited	System area	_					
8955 (22FBH)		For the remote password function	Accumulated count of unlock process normal completion 0 or more: Accumulated count of normal completion	0	RW	_			Page 161 Buffer memory
8956 (22FCH)			Accumulated count of unlock process abnormal completion 0 or more: Accumulated count of abnormal completion	0					
8957, 8958 (22FDH, 22	2FEH)	Use prohibited	System area	—					
8959 (22FFH)		For the remote password function	Accumulated count of lock process by line disconnection 0 or more: Accumulated count of lock process by line disconnection	0	RW	—			Page 161 Buffer memory
9216 (2400H)		Use prohibited	System area	_					
9217 (2401H)		For storage of number of flash ROM write	Flash ROM write count 0 to 1000: Number of rewriting	0	R				-
9218 to 972 (2402H to 2	27 25FFH)	Use prohibited	System area	—					

Address Dec (Hex	)	Purpose	Name	Defaul t value	aul Protocol lue				Reference
CH1	CH2				МС	Non	Bi	Pd	
9728 to 163 (2600H to 3	383 3FFFH)	For user	User setting area 2 (6656 words) (Send/receive data monitoring function default buffer) Usage is determined by the user.	0	RW		I		_
16384 (4000H)	16416 (4020H)	For designation of predefined protocol function control data	Number of consecutive protocol executions 0: No protocol executed 1 to 8: Number of protocols to be executed continuously	0	—			RW	
16385 (4001H)	16417 (4021H)	Use prohibited	System area	—				-	
16386 (4002H)	16418 (4022H)	For designation of predefined protocol function	Execution results 0: Normal completion Other than 0: Abnormal completion (error code)	0	_			R	—
16387 (4003H)	16419 (4023H)	control data	Result of the execution count 0: No protocol executed 1 to 8: Number of executed protocol for continuous execution	0	—			R	
16388 to 16395 (4004H to 400BH)	16420 to 16427 (4024H to 402BH)		Protocol number 0: No designation 1 to 128, 201 to 207: Protocol number to be executed	0	—			RW	
16396 to 16403 (400CH to 4013H)	16428 to 16435 (402CH to 4033H)		Matched packet No.1 to 8 0: No matched packet 1 to 16: Matched packet No.	0	_			R	
16404 to 16415 (4014H to 401FH)	16436 to 16447 (4034H to 403FH)	Use prohibited	System area	_					
16448 (4040H)	16464 (4050H)	For designation of predefined protocol function control data	Protocol cancel 0: No cancel direction (default) 1: Cancel request (set by user) 2: Cancel completed (set by C24)	0	_			RW	_
16449 (4041H)	16465 (4051H)	For confirmation of predefined protocol function execution status	Protocol execution status 0: Unexecuted (default) 1: Waiting for transmission 2: Sending 3: Waiting for data reception 4: Receiving 5: Completed	0	_			R	Page 109 DEBUG SUPPORT FUNCTION Page 473 Error Code List
16450 (4042H)	16466 (4052H)		Predefined protocol function error code 0: Normal Other than 0: Error (error code)	0					
16451 (4043H)	16467 (4053H)		Protocol execution count 0: No log 1 to 65535: Number of executions	0					_
16452 to 16463 (4044H to 404FH)	16468 to 16479 (4054H to 405FH)	Use prohibited	System area	_					
16480 to 16 (4060H to 4	6517 4085H)	Use prohibited	System area	_					

Address Dec (Hex)		Purpose	Name	Defaul t value	Prot	ocol			Reference
CH1	CH2				МС	Non	Bi	Pd	
16518 (4086H)		Protocol setting data error information	Protocol No. 1 to 128: Protocol No. 65535: Unidentified	0	—	•		R	Page 35 Packet elements Page 473 Error Code
16519 (4087H)			Setting type 0: Packet setting or element setting 1: Protocol detailed setting 65535: Unidentified	0					List
16520 (4088H)			Packet No. 0: Send packet 1 to 16: Receive packet No. 65535: Unidentified Valid when the Setting type value is 0.	0					
16521 (4089H)			Element No. 1 to 32: Element No. 65535: Unidentified Valid when the Setting type value is 0.	0					
16522 to 16 (408AH to 4	6527 408FH)	Use prohibited	System area	-					
16528 (4090H)		For confirmation of protocol setting data	Number of registered protocols 0: No registration 1 to 128: Number of registrations	0	- R			Page 26 DATA COMMUNICATION USING PREDEFINED PROTOCOL	
16529 to 16536 (4091H to 4098H)			Protocol registration 0: No registration 1: Registered The bit corresponding to each protocol No. turns ON or OFF.	0					_
			* Each bit indicates the corresponding protocol No.         b15       b14       b13       b2       b1       b0         Un\G16529       16       15       14       3       2       1         Un\G16530       32       31       30       2       1       10         Un\G16530       32       31       30       2       1       11         Un\G16531       48       47       46       4       55       34       33         Un\G16532       64       63       62       51       50       49         Un\G16533       96       95       9       83       82       81         Un\G16536       128       127       126       115       114       113         Un\G16536       128       127       126       115       114       113						
16537 to 16	6607	Use prohibited	1: Registered System area						
(4099H to 4 16608, 16609 (40E0H, 40E21)	40DFH) 16624, 16625 (40F0H, 40F1H)	Use prohibited	System area	-					
16610 (40E2H)	16626 (40F2H)	For designation of protocol execution history	Execution log options History storage condition 0 (OFF): Error logs of only protocol that completed abnormally are stored. 1 (ON): All protocol execution status and execution logs are stored.	0	_			RW	Page 113 Protocol Execution Log Storage Function (for Predefined Protocol only)
16611 to 16623 (40E3H to 40EFH)	16627 to 16638 (40F3H to 40FEH)	Use prohibited	System area	_					
16639 (40FFH)	18431 (47FFH)	Use prohibited	System area						

Address Dec (Hex	:)	Purpose	Name	Defaul t value	Prot	ocol			Reference
CH1	CH2				мс	Non	Bi	Pd	
16640 (4100H)	18432 (4800H)	For confirmation of protocol execution	Number of stored protocol execution logs 0: No log 1 to 32: Number of stored logs	0	—			R	Page 113 Protocol Execution Log Storage Function (for
16641 (4101H)	18433 (4801H)	history	Protocol execution log write pointer 0: No log 1 to 32: Latest protocol execution log No.	0					Predefined Protocol only)
16642 (4102H)	18434 (4802H)	Use prohibited	System area	—					
16643 (4103H)	18435 (4803H)	For confirmation of protocol execution history	Execution log 1 Protocol No. 0: No log 1 to 128: Protocol No. 201 to 207: Functional protocol No.	0		_		R	Page 113 Protocol Execution Log Storage Function (for Predefined Protocol only)
16644 to 16659 (4104H to 4113H)	18436 to 18451 (4804H to 4813H)		Execution log 1 Target device model 0: No protocol executed Other than 0: Target device model (Up to 32 bytes are stored in ASCII codes.)	0					
16660 to 16675 (4114H to 4123H)	18452 to 18467 (4814H to 4823H)		Execution log 1 Protocol name 0: No protocol executed Other than 0: Protocol name (Up to 32 bytes in ASCII codes are stored.)	0					
16676 (4124H)	18468 (4824H)		Execution log 1 Communication type 0: No protocol executed 1: Send only 2: Receive only 3: Send and receive 14: Functional protocol 15: Unregistered protocol	0					
16677 (4125H)	18469 (4825H)		Execution log 1 Protocol execution status 0: Unexecuted 1: Waiting for transmission 2: Sending 3: Waiting for reception 4: Receiving 5: Completed	0					
16678 (4126H)	18470 (4826H)		Execution log 1 Execution result 0: Normal completion Other than 0 (error code): Abnormal completion	0					
16679 (4127H)	18471 (4827H)		Execution log 1 Matched packet No. 0: Error occurred, or Communication type of the executed protocol is "Send only". 1 to 16: Matched receive packet number	0					
16680 (4128H)	18472 (4828H)		Execution log 1 Number of retries 0: No retry 1 to 10: Number of retries	0					
16681 (4129H)	18473 (4829H)	Use prohibited	System area	_					

Address Dec (Hex)	)	Purpose	Name	Defaul t value	ul Protocol ue			Reference	
CH1	CH2				мс	Non	Bi	Pd	
16682 (412AH)	18474 (482AH)	For confirmation of protocol execution history	Execution log 1 start time and date           0: No log           Upper 8 bits: Month           Lower 8 bits: Last 2 digits of year           b15         to         b8 b7         to         b0           Month (01H to 12H)         Year (00H to 99H), last 2 digits	0	_	I	1	R	Page 113 Protocol Execution Log Storage Function (for Predefined Protocol only)
16683 (412BH)	18475 (482BH)		Execution log 1 start time and date 0: No log Upper 8 bits: Hour Lower 8 bits: Day <u>b15 to b8 b7 to b0</u> <u>Hour (00H to 23H) Day (01H to 31H)</u>	0					
16684 (412CH)	18476 (482CH)	For confirmation of protocol execution history	Execution log 1 start time and date 0: No log Upper 8 bits: Second Lower 8 bits: Minute <u>b15 to b8 b7 to b0</u> <u>Second (00H to 59H)</u> Minute (00H to 59H)	0	_			R	Page 113 Protocol Execution Log Storage Function (for Predefined Protocol only)
16685 (412DH)	18477 (482DH)		Execution log 1 start time and date 0: No log Lower 8 bits: First 2 digits of year Lower 8 bits: Day of week (0: Sun to 6: Sat) b15 to b8 b7 to b0 Year (00H to 99H), first 2 digits Day of week (00H to 06H) 00H (Sunday) to 06H (Saturday)	0					
16686 (412EH)	18478 (482EH)		Execution log 1 end time and date           0: No log           Upper 8 bits: Month           Lower 8 bits: Last 2 digits of year           b15         to         b8 b7         to         b0           Month (01H to 12H)         Year (00H to 99H), last 2 digits	0					
16687 (412FH)	18479 (482FH)		Execution log 1 end time and date           0: No log           Upper 8 bits: Hour           Lower 8 bits: Day           b15         to         b8 b7         to         b0           Hour (00H to 23H)         Day (01H to 31H)	0					
16688 (4130H)	18480 (4830H)		Execution log 1 end time and date 0: No log Upper 8 bits: Second Lower 8 bits: Minute b15 to b8 b7 to b0 Second (00H to 59H) Minute (00H to 59H)	0					
16689 (4131H)	18481 (4831H)		Execution log 1 end time and date 0: No log Lower 8 bits: First 2 digits of year Lower 8 bits: Day of week (0: Sun to 6: Sat) <u>b15 to b8 b7 to b0</u> <u>Year (00H to 99H), first 2 digits Day of week (00H to 06H)</u> 00H (Sunday) to 06H (Saturday)	0					
16690 to 18177 (4132H to 4701H)	18482 to 19969 (4832H to 4E01H)		Execution log 2 to 32 Same as Execution log 1	0					
18178 to 18430 (4702H to 47FEH)	19970 to 20223 (4E02H to 4EFFH)	Use prohibited	System area	_					

Address Dec (Hex)		Purpose	Name	Defaul t value	Protocol				Reference
CH1	CH2				МС	Non	Bi	Pd	
20224 to 20 (4F00H to 4	0231 4F07H)	Error address storage area	Stores the buffer memory address of which parameter setting value is set outside the range. (Up to 8)	0	_			R	Page 448 Error information clear
20232 to 20479 (4F08H to 4FFFH)		Use prohibited	System area	—					
20480 to 24575 (5000H to 5FFFH)		Send/receive area for predefined protocol function	Predefined protocol function buffer	0	_		RW	Page 448 Error information clear	
24576 to 65535 (6000H to FFFFH)		Use prohibited	System area	—					

\*1 The area can be used as a user setting area (the send and receive data storage areas).

#### Monitoring device areas for the programmable controller CPU monitoring function

■CH1 side buffer memory address: decimal (hexadecimal)

N-th bloc	k monitor	ing device								Name
1	2	3	4	5	6	7	8	9	10	
8272	8281	8290	8299	8308	8317	8326	8335	8344	8353	Monitoring device designation
(2050H)	(2059H)	(2062H)	(206BH)	(2074H)	(207DH)	(2086H)	(208FH)	(2098H)	(20A1H)	
8273 to	8282 to	8291 to	8300 to	8309 to	8318 to	8327 to	8336 to	8345 to	8354 to	Start device No. specification
8274	8283	8292	8301	8310	8319	8328	8337	8346	8355	
(2051H	(205AH	(2063H	(206CH	(2075H	(207EH	(2087H	(2090H	(2099H	(20A2H	
to	to	to	to	to	to	to	to	to	to	
2052H)	205BH)	2064H)	206DH)	2076H)	207FH)	2088H)	2091H)	209AH)	20A3H)	
8275	8284	8293	8302	8311	8320	8329	8338	8347	8356	Number of read points specification
(2053H)	(205CH)	(2065H)	(206EH)	(2077H)	(2080H)	(2089H)	(2092H)	(209BH)	(20A4H)	
8276	8285	8294	8303	8312	8321	8330	8339	8348	8357	Monitoring condition specification (judgment condition specification)
(2054H)	(205DH)	(2066H)	(206FH)	(2078H)	(2081H)	(208AH)	(2093H)	(209CH)	(20A5H)	
8277	8286	8295	8304	8313	8322	8331	8340	8349	8358	Monitoring condition value designation
(2055H)	(205EH)	(2067H)	(2070H)	(2079H)	(2082H)	(208BH)	(2094H)	(209DH)	(20A6H)	
8278 (2056H)	8287 (205FH)	8296 (2068H)	8305 (2071H)	8314 (207AH)	8323 (2083H)	8332 (208CH)	8341 (2095H)	8350 (209EH)	8359 (20A7H)	Send pointer designation (for condition match send, data transmission)
8279 (2057H)	8288 (2060H)	8297 (2069H)	8306 (2072H)	8315 (207BH)	8324 (2084H)	8333 (208DH)	8342 (2096H)	8351 (209FH)	8360 (20A8H)	Output quantity designation (for condition match send, data transmission)
8280 (2058H)	8289 (2061H)	8298 (206AH)	8307 (2073H)	8316 (207CH)	8325 (2085H)	8334 (208EH)	8343 (2097H)	8352 (20A0H)	8361 (20A9H)	Data No. for connection designation (for condition match send)

#### **CH2** side buffer memory address: decimal (hexadecimal)

N-th bloc	k monitor	ing device	l.							Name
1	2	3	4	5	6	7	8	9	10	
8528	8537	8546	8555	8564	8573	8582	8591	8600	8609	Monitoring device designation
(2150H)	(2159H)	(2162H)	(216BH)	(2174H)	(217DH)	(2186H)	(218FH)	(2198H)	(21A1H)	
8529 to	8538 to	8547 to	8556 to	8565 to	8574 to	8583 to	8592 to	8601 to	8610 to	Start device No. specification
8530	8539	8548	8557	8566	8575	8584	8593	8602	8611	
(2151H	(215AH	(2163H	(216CH	(2175H	(217EH	(2187H	(2190H	(2199H	(21A2H	
to	to	to	to	to	to	to	to	to	to	
2152H)	215BH)	2164H)	216DH)	2176H)	217FH)	2188H)	2191H)	219AH)	21A3H)	
8531	8540	8549	8558	8567	8576	8585	8594	8603	8612	Number of read points specification
(2153H)	(215CH)	(2165H)	(216EH)	(2177H)	(2180H)	(2189H)	(2192H)	(219BH)	(21A4H)	
8532	8541	8550	8559	8568	8577	8586	8595	8604	8613	Monitoring condition specification (judgment condition specification)
(2154H)	(215DH)	(2166H)	(216FH)	(2178H)	(2181H)	(218AH)	(2193H)	(219CH)	(21A5H)	
8533	8542	8551	8560	8569	8578	8587	8596	8605	8614	Monitoring condition value designation
(2155H)	(215EH)	(2167H)	(2170H)	(2179H)	(2182H)	(218BH)	(2194H)	(219DH)	(21A6H)	
8534 (2156H)	8543 (215FH)	8552 (2168H)	8561 (2171H)	8570 (217AH)	8579 (2183H)	8588 (218CH)	8597 (2195H)	8606 (219EH)	8615 (21A7H)	Send pointer designation (for condition match send, data transmission)
8535 (2157H)	8544 (2160H)	8553 (2169H)	8562 (2172H)	8571 (217BH)	8580 (2184H)	8589 (218DH)	8598 (2196H)	8607 (219FH)	8616 (21A8H)	Output quantity designation (for condition match send, data transmission)
8536 (2158H)	8545 (2161H)	8554 (216AH)	8563 (2173H)	8572 (217CH)	8581 (2185H)	8590 (218EH)	8599 (2197H)	8608 (21A0H)	8617 (21A9H)	Data No. for connection designation (for condition match send)

## **Appendix 4** Dedicated Instructions

Dedicated instructions are used to simplify programming when using intelligent function module functions. For details, refer to the following manual.

MELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks)

### **Dedicated instruction list**

#### List of dedicated instruction

The following table lists the dedicated instructions explained.

Purpose	Dedicated instruction	Function overview				
On-demand function transmission	ONDEMAND <sup>*1</sup>	Sends data using the on-demand function of MC protocol.				
Predefined protocol function	CPRTCL	Executes the protocol setting data registered using the Predefined protocol support function of Engineering tool.				
Nonprocedural protocol	OUTPUT <sup>*1</sup>	ransmits data for the designated data count.				
communication	INPUT <sup>*1</sup>	Reads received data.				
Bidirectional protocol	BIDOUT <sup>*1</sup>	Transmits data for the designated data count.				
communication	BIDIN <sup>*1</sup>	Reads received data.				
Communication status confirmation	SPBUSY	Reads the status of data transmission/reception using the dedicated instruction.				
Data transmission/reception	BUFRCVS <sup>*1</sup>	Receives data by an interrupt program using nonprocedural or bidirectional protocol communication.				
	PRR <sup>*1</sup>	Transmits data with the user frame according to the contents defined in the send user frame designation area in data communications using the nonprocedural protocol.				
Receive data clear	CSET	Performs the receive data clear without stopping the transmission processing in data communications using the nonprocedural protocol.				
Programmable controller CPU monitoring function		Registers/cancels programmable controller CPU monitoring in order to use the programmable controller CPU monitoring functions.				
Setting the units of send/receive data quantity		Sets the unit (word/byte) of data quantity to be sent and received.				
User frame registration to flash	PUTE	Registers a user frame.				
ROM (registration/reading of user frame)	GETE	Reads a user frame.				
Mode switching	UINI	Changes the mode, transmission specifications, and host station No. of C24.				

\*1 To change the following setting values of the buffer memory used by the dedicated instructions, use Engineering tool or execute the CSET instruction (initial setting) before starting data communication. (CMMELSEC iQ-R Programming Manual (Instructions, Standard Functions/Function Blocks)))

·'Word/byte units designation' (Un\G150/310)

'Buffer memory start address designation' (Un\G160/321)

'Send buffer memory start address designation' (Un\G162/322)

'Send buffer memory length designation' (Un\G163/323)

'Receiving buffer memory start address designation' (Un\G166/326)

'Receive buffer memory length designation' (Un\G167/327)

The dedicated instructions are executed base on the setting values of the buffer memory at the module startup or those which were changed by the CSET instruction (initial setting).

#### Precautions

Do not change data (control data, request data, etc.) designated by a dedicated instruction until the execution of that instruction is completed.

# Appendix 5 Operation Image and Data Structure of Predefined Protocol

## Operation image of each communication type of protocol

In the predefined protocol function, communication with target devices is performed through the communication type "Send only", "Receive only", or "Send & receive". This section explains the respective operation images.

#### When communication type is "Send Only"

The specified packet is transmitted once.



The operation image of "Send only" is as follows.

#### ■Normal completion



#### Error completion (transmission monitoring timeout error)

Example of setting

Standby time: 0, Number of send retries: 0, Monitoring time: other than 0



#### When communication type is "Receive Only"

When data are received from the target device, the process completes when the received data matches the receive packet and the receiving process is performed.



The operation image of "Receive only" is as follows.

#### ■Normal completion



#### **Error completion (receive wait timeout error)**

CPU	For other dealers to discontinue		Error occurred
module			<u>×                                    </u>
	Completion device		
			ON at error completion
	Status display device		
	at completion		J 1 1
			1 1 1
		) ( <u></u> ,	
		(Receive	
C24			1
		t: Reception waiting time	   
			!
		Verification mismatch	
	Target device	Receive packet Receive packet	
Point			
- Ont	When variables	s are included in receive packet elements, variable parts are not	verified.

- When more than one receive packet is specified, received data is verified with the receive packet information of the first registered packet in the order of registration. The receive processing is performed once received data match one of the receive packet number, and further verification is not performed.
- The receive packet number which is matched as the result of the verification is stored in the control data of the dedicated instruction (CPRTCL instruction).

#### When communication type is "Send & Receive"

A packet is sent once, and the status changes to the data receive wait stat after the transmission completes normally. Then, data is received from the target device, and the process completes when the received data matches the receive packet and the receiving process is performed.



The operation image of "Send & receive" is as follows.

#### ■Normal completion



#### **Error completion (receive wait timeout error)**



- When more than one receive packet is specified, received data is verified with the receive packet information of the first registered packet in the order of registration. The receive processing is performed once received data match one of the receive packet number, and further verification is not performed.
- The receive packet number which is matched as the result of the verification is stored in the control data of the dedicated instruction (CPRTCL instruction).

## Verification operation of receive packet

The following shows C24 operation when data that are different from the specified receive packet are received.

Receive data prior to the different data is discarded. Data is compared again from the start of the receive packet, and once the data matches the receive packet, the data receiving operation is processed.



## Data examples of packet elements

This section explains the processing procedures and practical data examples of elements that can be placed in a packet.

#### Length

#### Processing procedure

C24 processes length according to the following procedure.



#### ■Data example

The following is an example in the case where the calculated value of length is 258 bytes in decimal (258 is 102H in hexadecimal).

· Data flow is "Forward direction"

Code type	Data length <sup>*1</sup>									
	1 byte	2 bytes	3 bytes	4 bytes						
ASCII hexadecimal	'2' (32H)	'02' (30H 32H)	'102' (31H 30H 32H)	'0102' (30H 31H 30H 32H)						
ASCII decimal	'8' (38H)	'58' (35H 38H)	'258' (32H 35H 38H)	'0258' (30H 32H 35H 38H)						
HEX	02H	0102H	000102H	00000102H						

\*1 Values in '( )' indicate ASCII code.

· Data flow is "Reverse direction"

Code type	Data length <sup>*1</sup>								
	1 byte	2 bytes	3 bytes	4 bytes					
ASCII hexadecimal	-	'20' (32H 30H)	'201' (32H 30H 31H)	'2010'(32H 30H 31H 30H)					
ASCII decimal	-	'85' (38H 35H)	'852' (38H 35H 32H)	'8520' (38H 35H 32H 30H)					
HEX	—	0201H	020100H	02010000H					

\*1 Values in '( )' indicate ASCII code.

· Data flow is "Byte swap"

Code type	Data length <sup>*1</sup>									
	1 byte	2 bytes	3 bytes	4 bytes						
ASCII hexadecimal	—	-	—	'1020' (31H 30H 32H 30H)						
ASCII decimal	—	-	—	'2085' (32H 30H 38H 35H)						
HEX	—	—	—	00000201H						

\*1 Values in '()' indicate ASCII code.

#### ■Calculating range

The following shows specification examples of the calculating range of Length.



Example 1: Calculating range when 1 and n are specified as the start and the end respectively.

Example 2: Calculating range when 3 and n-2 are specified as the start and the end respectively.

Example 3: Calculating range when 3 and n are specified as the start and the end respectively.

#### Non-conversion variable

#### ■Processing procedure

C24 processes non-conversion variable according to the following procedure.



stores 00h to upper bytes

529

#### ■Data example

• The following table shows data to be stored in the data storage area when the string of send data is 'ABCD'. (Reference: A=41H, B=42H, C=43H, and D=44H in ASCII code)

Item	Description								
Fixed length/Variable length	Fixed length								
Data length	4 bytes	↓ bytes							
Start address of data storage area	D0	0							
Unit of stored data	Lower byte + Upper byte		Lower bytes only						
Byte swap	Disable	Enable	Disable	Enable					
Data to be stored in data storage	D0=4241H	D0=4142H	D0=0041H	D0=0042H					
area	D1=4443H	D1=4344H	D1=0042H	D1=0041H					
			D2=0043H	D2=0044H					
			D3=0044H	D3=0043H					

• The following table shows data to be stored in the data storage area when the string of send data is 'EFG'. (Reference: E=45H, F=46H, and G=47H in ASCII code)

Item	Description					
Fixed length/Variable length	Fixed length					
Data length	3 bytes	bytes				
Start address of data storage area	D0	D0				
Unit of stored data	Lower byte + Upper byte		Lower bytes only			
Byte swap	Disable	Enable	Disable	Enable		
Data to be stored in data storage area	D0=4645H D1=0047H	D0=4546H D1=4700H	D0=0045H D1=0046H D2=0047H D3= (any data)	D0=0046H D1=0045H D2=0047H D3= (any data)		

#### Conversion variable

#### ■Processing procedure

C24 processes conversion variable according to the following procedure.

- When "Conversion" is 'HEX  $\rightarrow$  ASCII hexadecimal' or 'ASCII hexadecimal  $\rightarrow$  HEX'



#### Blank-padded characters

When transmitting data, upper digits are filled with the data specified in "Blank-padded character" when the number of digits is less than that specified in "Number of Send Digits of Data".

When receiving data, either '0' or '\_(space)' is processed as a blank-padded character regardless of the specification in "Blank-padded character".

#### Ex.

Setting of "Number of Send Digits of Data" is '6' ('\_' indicates a space character in the table)

Received data	Operation of C24
000120	Considers the first 3 digits as blank-padded characters.
0120	Considers the first 3 digits as blank-padded characters.
0_0120	Considers the first 3 digits as blank-padded characters.
120	Considers the first 3 digits as blank-padded characters.
00012 _	Considers it to be an ASCII $\rightarrow$ BIN conversion error (7F20H).
12_	Considers it to be an ASCII $\rightarrow$ BIN conversion error (7F20H).
0001_0	Considers it to be an ASCII $\rightarrow$ BIN conversion error (7F20H).

• For conversion "HEX  $\rightarrow$  ASCII decimal", "ASCII decimal  $\rightarrow$  HEX"



#### ■Data example

The following table shows send data when a packet consists of [Header], [Conversion variable], [Terminator] and data stored in the data storage area is D0=837 (0345H), D1=18 (0012H). (Reference: 120345H =1180485 in decimal form)

Data example 1

Item	Setting contents		
Fixed number of data/Variable number of data	Fixed number of data	Fixed number of data	Fixed number of data
Number of Send Data	1	1	1
Start address of data storage area	D0	D0	D0
Conversion unit	Word	Word	Word
Conversion	$HEX \to ASCII \ decimal$	$HEX \to ASCII \text{ decimal}$	$HEX \to ASCII \ decimal$
Number of Send Digits of Data	5	5	Variable number of digits
Blank-padded character	0	Space	—(Not applicable)
Sign	Unsigned	Signed	Signed
Sign character	—(Not applicable)	+	+
Number of decimals	No decimal point	2	No decimal point
Delimiter	No delimiter	Comma	Comma
Send data <sup>*1</sup>	[Header]00837[Terminator]	[Header]+8.37, [Terminator]	[Header]+837, [Terminator]

\*1 The "\_" indicates a space.

Data example 2

Item	Setting contents		
Fixed number of data/Variable number of data	Fixed number of data	Fixed number of data	Fixed number of data
Number of Send Data	1	2	2
Start address of data storage area	D0	D0	D0
Conversion unit	Double word	Word	Word
Conversion	$HEX \to ASCII \ decimal$	$HEX \to ASCII \text{ decimal}$	$HEX \to ASCII \ decimal$
Number of Send Digits of Data	10	5	5
Blank-padded character	0	Space	0
Sign	Signed	Unsigned	Signed
Sign character	+	—(Not applicable)	+
Number of decimals	8	No decimal point	2
Delimiter	No delimiter	No delimiter	Comma
Send data <sup>*1</sup>	[Header]+00.01180485[Terminator]	[Header]83718[Terminator]	[Header]+008.37, +000.18[Terminator]

\*1 '\_' indicates a blank.

#### Check code

#### ■Processing procedure

C24 processes check code according to the following procedure.

- 1. Calculates value according to the selection of "Processing method".
- **2.** When "Complement calculation" is 'One's complement' or 'Two's complement', performs a 2-word-wise complement operation on the value calculated in the above 1.
- **3.** When "Code type" is 'ASCII decimal', extracts the lowest one word from the value calculated in the above 2, and performs the hexadecimal to decimal conversion.



#### ■Calculation procedure for horizontal parity

The following show procedures for calculating horizontal parities using the following sample data.



#### For the packet shown above

"R"	(52н)	0101 0010												
	()	XOR												
"J"	(4Ан)	0100 1010 =	0001 1000 XOR											
"7"	(37н)		0011 0111 =	0010 1111 XOR										
"1"	(31н)			0011 0001	=	0001 1110								
						XOR								
"C"	(43н)					0100 0011 :	=	0101 1101						
								XOR						
"2"	(32н)							0011 0010 =	0110 1111					
									XOR					
"4"	(34н)								0011 0100	) =	0101 1011			
											XOR			
ETX	(03н)										0000 0011	= 0101 100	0 (Bina	ary)
										Ho	rizontal pari	ty = 58	(Hexa	idecimal)

#### Data flow: Forward direction

#### • "No Complement Calculation" is designated (58H in hexadecimal is 88 in decimal)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	"8" (38H)	"58" (35H 38H)	"058"(30H 35H 38H)	"0058" (30H 30H 35H 38H)		
ASCII decimal	"8" (38H)	"88" (38H 38H)	"088" (30H 38H 38H)	"0088" (30H 30H 38H 38H)		
HEX	58H	0058H	000058H	00000058H		

\*1 Values in '()' indicate ASCII code.

• "One's complement" is designated (One's complement for 0000 0058H is FFFF FFA7H)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FFA7H in hexadecimal is 65447 in decimal.)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	"7"(37H)	"A7" (41H 37H)	"FA7" (46H 41H 37H)	"FFA7" (46H 46H 41H 37H)		
ASCII decimal	"7" (37H)	"47" (34H 37H)	"447" (34H 34H 37H)	"5447" (35H 34H 34H 37H)		
HEX	A7H	FFA7H	FFFFA7H	FFFFFA7H		

\*1 Values in '( )' indicate ASCII code.

• "Two's complement" is designated (Two's complement for 0000 0058H is FFFF FFA8H)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FFA8H in hexadecimal is 65448 in decimal.)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	"8" (38H)	"A8" (41H 38H)	"FA8" (46H 41H 38H)	"FFA8" (46H 46H 41H 38H)		
ASCII decimal	"8" (38H)	"48" (34H 38H)	"448" (34H 38H 38H)	"5448" (35H 34H 34H 38H)		
HEX	A8H	FFA8H	FFFFA8H	FFFFFA8H		

\*1 Values in '( )' indicate ASCII code.

#### Data flow: Reverse direction

#### • "No Complement Calculation" is designated (58H in hexadecimal is 88 in decimal)

Code type Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes	
ASCII hexadecimal	—	"85" (38H 35H)	"850" (38H 35H 30H)	"8500" (38H 35H 30H 30H)	
ASCII decimal	—	"88" (38H 38H)	"880" (38H 38H 30H)	"8800" (38H 38H 30H 30H)	
HEX	—	5800H	580000H	58000000H	

\*1 Values in '()' indicate ASCII code.

• "One's complement" is designated (One's complement for 0000 0058H is FFFF FFA7H)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FFA7H in hexadecimal is 65447 in decimal.)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	—	"7A" (37H 41H)	"7AF" (37H 41H 46H)	"7AFF" (37H 41H 46H 46H)		
ASCII decimal	—	"74" (37H 34H)	"744" (37H 34H 34H)	"7445" (37H 34H 34H 35H)		
HEX	—	A7FFH	A7FFFFH	A7FFFFFH		

\*1 Values in '( )' indicate ASCII code.

• "Two's complement" is designated (Two's complement for 0000 0058H is FFFF FFA8H)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FFA8H in hexadecimal is 65448 in decimal.)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	—	"8A" (38H 41H)	"8AF" (38H 44H 46H)	"8AFF" (38H 41H 46H 46H)		
ASCII decimal	—	"84" (38H 34H)	"844" (38H 34H 34H)	"8445" (38H 34H 34H 35H)		
HEX	—	A8FFH	A8FFFFH	A8FFFFFH		

\*1 Values in '( )' indicate ASCII code.

#### Data Flow: Byte swap

#### • "No Complement Calculation" is designated (58H in hexadecimal is 88 in decimal)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	—	—	—	"0085" (30H 30H 38H 35H)		
ASCII decimal	-	-	—	"0088" (30H 30H 38H 38H)		
HEX	-	-	—	00005800H		

\*1 Values in '()' indicate ASCII code.

• "One's complement" is designated (One's complement for 0000 0058H is FFFF FFA7H)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FFA7H in hexadecimal is 65447 in decimal.)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	—	-	-	"FF7A" (46H 46H 37H 41H)		
ASCII decimal	—	-	-	"4574" (34H 35H 37H 34H)		
HEX	—	-	-	FFFFA7FFH		

\*1 Values in '()' indicate ASCII code.

• "Two's complement" is designated (Two's complement for 0000 0058H is FFFF FFA8H)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FFA8H in hexadecimal is 65448 in decimal.)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	—	_	—	"FF8A" (46H 46H 38H 41H)		
ASCII decimal	—	-	—	"4584" (34H 35H 38H 34H)		
HEX	—	—	—	FFFFA8FFH		

\*1 Values in '()' indicate ASCII code.

#### ■Calculation procedure for sum check

The following show procedures for calculating sum check codes using the following sample data.

STX	"R"	"J"	"7"	"1"	"C"	"2"	"4"	ETX	Sum check
	4								<b>A</b>
	Calculating range							I	

#### For the data shown above

Sum check value=52H+4AH+37H+31H+43H+32H+34H+03H=1B0H

#### Data flow: Forward direction

• "No Complement Calculation" is designated (1B0H in hexadecimal is 432 in decimal)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	"0" (30H)	"B0" (42H 30H)	"1B0" (31H 42H 30H)	"01B0" (30H 31H 42H 30H)		
ASCII decimal	"2" (32H)	"32" (33H 32H)	"432" (34H 33H 32H)	"0432" (30H 34H 33H 32H)		
HEX	вон	01B0H	0001B0H	000001B0H		

\*1 Values in '( )' indicate ASCII code.

• "One's complement" is designated (One's complement for 0000 01B0H is FFFF FE4FH)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FE4FH in hexadecimal is 65103 in decimal.)

Code type	Data length <sup>*1</sup>					
	1 byte	2 bytes	3 bytes	4 bytes		
ASCII hexadecimal	"F" (46H)	"4F" (34H 46H)	"E4F" (45H 34H 46H)	"FE4F" (46H 45H 34H 46H)		
ASCII decimal	"3" (33H)	"03" (30H 33H)	"103" (31H 30H 33H)	"5103" (35H 31H 30H 33H)		
HEX	4FH	FE4FH	FFFE4FH	FFFFE4FH		

\*1 Values in '( )' indicate ASCII code.

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FE50H in hexadecimal is 65104 in decimal.)

Code type	Data length <sup>*1</sup>				
	1 byte	2 bytes	4 bytes		
ASCII hexadecimal	"0" (30H)	"50" (35H 30H)	"E50" (45H 35H 30H)	"FE50" (46H 45H 35H 30H)	
ASCII decimal	"4" (34H)	"04" (30H 34H)	"104" (31H 30H 34H)	"5104" (35H 31H 30H 34H)	
HEX	50H	FE50H	FFFE50H	FFFFE50H	

\*1 Values in '( )' indicate ASCII code.

 <sup>&</sup>quot;Two's complement" is designated (Two's complement for 0000 01B0H is FFFF FE50H)
#### Data flow: Reverse direction

#### • "No Complement Calculation" is designated (1B0H in hexadecimal is 432 in decimal)

Code type				
	1 byte	2 bytes	3 bytes	4 bytes
ASCII hexadecimal	—	"0B" (30H 42H)	"0B1" (30H 42H 31H)	"0B10" (30H 42H 31H 30H)
ASCII decimal	—	"23" (32H 33H)	"234" (32H 33H 34H)	"2340" (32H 33H 34H 30H)
HEX	—	B001H	B00100H	B0010000H

\*1 Values in '()' indicate ASCII code.

• "One's complement" is designated (One's complement for 0000 01B0H is FFFF FE4FH)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FE4FH in hexadecimal is 65103 in decimal.)

Code type	Data length <sup>*1</sup>				
	1 byte	4 bytes			
ASCII hexadecimal	—	"F4" (46H 34H)	"F4E" (46H 34H 45H)	"F4EF" (46H 34H 45H 46H)	
ASCII decimal	—	"30" (33H 30H)	"301" (33H 30H 31H)	"3015" (33H 30H 31H 35H)	
HEX	—	4FFEH	4FFEFFH	4FFEFFFFH	

\*1 Values in '( )' indicate ASCII code.

• "Two's complement" is designated (Two's complement for 0000 01B0H is FFFF FE50H)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FE50H in hexadecimal is 65104 in decimal.)

Code type	Data length <sup>*1</sup>				
	1 byte	2 bytes	3 bytes	4 bytes	
ASCII hexadecimal	—	"05" (30H 35H)	"05E" (30H 35H 45H)	"05EF" (30H 35H 45H 46H)	
ASCII decimal	—	"40" (34H 30H)	"401" (34H 30H 31H)	"4015" (34H 30H34H 35H)	
HEX	—	50FEH	50FEFFH	50FEFFFFH	

\*1 Values in '()' indicate ASCII code.

#### Data Flow: Byte Swap

#### • "No Complement Calculation" is designated (1B0H in hexadecimal is 432 in decimal)

Code type	Data length <sup>*1</sup>			
	1 byte	2 bytes	3 bytes	4 bytes
ASCII hexadecimal	—	—	—	"100B" (31H 30H 30H 42H)
ASCII decimal	-	-	—	"4023" (34H 30H 32H 33H)
HEX	-	-	—	0000B001H

\*1 Values in '()' indicate ASCII code.

• "One's complement" is designated (One's complement for 0000 01B0H is FFFF FE4FH)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FE4FH in hexadecimal is 65103 in decimal.)

Code type	Data length <sup>*1</sup>				
	1 byte	2 bytes	3 bytes	4 bytes	
ASCII hexadecimal	-	-	—	"EFF4" (45H 46H 46H 34H)	
ASCII decimal	-	-	—	"1530" (31H 35H 33H 30H)	
HEX	—	—	—	FFFF4FFEH	

\*1 Values in '()' indicate ASCII code.

• "Two's complement" is designated (Two's complement for 0000 01B0H is FFFF FE50H)

When "Code type" is "ASCII decimal", the lower one word is extracted and converted from hexadecimal to decimal. (FE50H in hexadecimal is 65104 in decimal.)

Code type	Data length <sup>*1</sup>			
	1 byte	2 bytes	3 bytes	4 bytes
ASCII hexadecimal	—	—	—	"EF05" (45H 46H 30H 35H)
ASCII decimal	—	-	—	"1540" (31H 35H 34H 30H)
HEX	—	—	—	FFFF50FEH

\*1 Values in '()' indicate ASCII code.

#### ■Calculation procedure for 16-bit CRC (for MODBUS)

This is an error check method to be used when data are transmitted/received with the RTU mode of the MODBUS protocol. The data length of CRC is fixed to 2 bytes (16 bits), and the CRC is calculated every 1 byte (8 bits) from the start of the calculating range according to the following procedure.

- 1. Load a 16-bit register whose bits are all '1'.
- **2.** Exclusive OR (XOR) the first 1 byte (8 bits) of the calculating range with 8 bits in above 1.
- **3.** Shift the result of the step 2. for one bit right.
- **4.** If the least significant bit in above 2. is '1', exclusive OR (XOR) the result of 3. with the generator polynomial (A001H). If the least significant bit is '0', shift the result of step 3. one bit right (operation described in 3.) without the exclusive OR (XOR) operation.
- 5. Repeat steps 3. and 4. for 8 times.
- **6.** Exclusive OR (XOR) the result of the above 5 with the next 1 byte (8 bits).
- **7.** Repeat step 3 through 6 until all bytes have been processed. The final result is CRC value.
- **8.** The CRC value is stored in a packet in the order of lower 8 bits  $\rightarrow$  upper 8 bits.

Ex. The calculation example of 16-bit CRC (for MODBUS)

Station number	Function code	16-bit CRC	
02H	07H	41H	12H

#### Calculation method of 16-bit CRC (for MODBUS) for the above packet example

CRC error checking procedure	16-bit register (MSB)		Flag	Calculating procedure
(Load a 16-bit register whose bits are all '1') 02H (Station number) Exclusive OR (XOR)	1111 1111 - 1111 1111	1111 1111 0000 0010 1111 1101	-	1 to 2
Shift 1 Generator polynomial Exclusive OR (XOR)	0111 1111 1010 0000 1101 1111	1111 1110 0000 0001 1111 1111	1	3 to 4
Shift 2 Generator polynomial Exclusive OR (XOR)	0110 1111 1010 0000 1100 1111	1111 1111 0000 0001 1111 1110	1	5
Shift 3 Shift 4 Generator polynomial Exclusive OR (XOR)	0110 0111 0011 0011 1010 0000 1001 0011	1111 1111 1111 1111 0000 0001 1111 1110	0 1	
Shift 5 Shift 6 Generator polynomial Exclusive OR (XOR)	0100 1001 0010 0100 1010 0000 1000 0100	1111 1111 1111 1111 0000 0001 1111 1110	0 1	
Shift 7 Shift 8 Generator polynomial Exclusive OR (XOR)	0100 0010 0010 0001 1010 0000 1000 0001	0111 1111 0011 1111 0000 0001 0011 1110	0 1	
07H (Function code) Exclusive OR (XOR)	- 1000 0001	0000 0111 0011 1001	-	6
Shift 1 Generator polynomial Exclusive OR (XOR)	0100 0000 1010 0000 1110 0000	1001 1100 0000 0001 1001 1101	1	7
Shift 2 Generator polynomial Exclusive OR (XOR)	0111 0000 1010 0000 1101 0000	0100 1110 0000 0001 0100 1111	1	
Shift 3 Generator polynomial Exclusive OR (XOR)	0110 1000 1010 0000 1100 1000	0010 0111 0000 0001 0010 0110	1	
Shift 4 Shift 5 Generator polynomial Exclusive OR (XOR)	0110 0100 0011 0010 1010 0000 1001 0010	0001 0011 0000 1001 0000 0001 0000 1000	0 1	
Shift 6 Shift 7 Shift 7	0100 1001 0010 0100 0001 0010	0000 0100 1000 0010 0100 0001	0 0 0	
CRC value	12H	41H	-	8

### Check code calculation range

The following shows specification examples of the check code calculation code.



Example 1: Calculating range when 1 and n-1 are specified as the start and the end respectively. Example 2: Calculating range when 2 and n-1 are specified as the start and the end respectively. Example 3: Calculating range when 2 and n-2 are specified as the start and the end respectively.

### Non-verified reception

The usage example for non-verified reception is shown below.



Using a non-verified reception element has the following advantages in the case of the packet format shown above.

- · The only necessary data can be stored in the device memory of a CPU module and buffer memory.
- · A single protocol (packet) can handle receive packets that includes data whose contents vary each time.

### Processing time for nonprocedural protocol (guideline)

The processing time for the Output and Input instructions can be estimated by the following formula.

Note, however, that the processing time may become longer depending on other communication functions (e.g.,

communication using the MC protocol) and special functions (e.g., ASCII-binary conversion, transmission control) that are used at the same time.

The value obtained from the following formula is considered to be the processing time taken for reception or transmission only when CH1 only is used (RS-232 connection).

### ■OUTPUT instruction

#### Tp=St+(Dle/Cr×1000+0.07)×Ds+T1

- Tp<sup>\*1</sup> : The time from the start of execution of the Output instruction to the End processing of the sequence scan at the completion of the Output instruction execution (ms)
- St : Scan time
- Dle : Data length of 1 byte at data transmission (number of bits)
- Cr : Communication rate (bps)
- Ds : Number of bytes of send data
- T1 : C24 T1=2.7
- \*1 This stands for the time range of processing (Tp).



Target device

### ■INPUT instruction

#### $Tp = Sr+0.09 \times Dr+T2$

- Tp<sup>\*1</sup> : Time from the start of the INPUT instruction execution to the start of End processing for the sequence scan at the completion of the INPUT instruction execution (ms)
- St : Scan time
- Dr : Number of bytes of reception data
- T2 : C24 T2=6.3
- \*1 This indicates the range of processing time (Tp).



- \*2 It indicates the time from when C24 receives data from the line to when the 'CH1 reception data read request' (X3) turns ON when only read processing of 30 bytes data is performed with one of the channels on C24 used.
- \*3 When DX3 (direct mode) is used, C24 is accessed at the time of the instruction execution with the program.
- DX3 (direct mode) speeds up reading input compared to X3 (refresh mode).

For differences between the modes, refer to the following manual.

MELSEC iQ-R CPU Module User's Manual (Application)

# Appendix 7 When Connecting the Module to a Remote Head Module

This section describes the restrictions and communication example for when connecting the C24 to a remote head module.

### Restrictions

This section describes the restricted functions and specifications of when connecting the C24 to a remote head module.

### When creating programs

- · Dedicated instructions cannot be used.
- Data cannot be received with an interrupt program.

### **Communications using the MC protocol**

The command that can be used differs from that of the CPU module. For the command that can be used in the remote head module, refer to the following.

MELSEC Communication Protocol Reference Manual

### **Communication example**

This section describes the communication example for when connecting the C24 to a remote head module.



#### **Communication procedure**

The following shows the procedure to send/receive data.

#### ■Data communication using the predefined protocol

• Writes the send data to the link register (W) of CPU module to store the send data in the data storage area set in the packet setting of the predefined protocol support function.

2 Executes the REMTO instruction to write the number of continuous protocol executions to the buffer memory of C24.

S Executes the REMTO instruction to write the protocol number to be executed to the buffer memory of C24.

Executes the protocol by 'CH2 protocol execution request' (YA).

G Checks the protocol execution by 'CH2 protocol execution completion' (XC).

**③** Reads the predefined protocol execution result, result of the execution count, and matched packet number from the buffer memory of C24 with the REMFR instruction.

Reads the data received from the external device which is transferred from the device of the remote head module to the link register (W) of the CPU module.



Link refres

Α

### Data communication using the nonprocedural or bidirectional protocol

Receiving procedure

O Checks the data reception from an external device by 'CH1 reception data read request' (X3).

**2** The data received from the external device is transferred from the buffer memory of C24 to the device of the remote head module by refresh (remote head module  $\Leftrightarrow$  C24).

**3** Reads the data received from the external device which is transferred to the link register (W) of the CPU module by link refresh.



Link scan

→ : Refresh (Remote head module⇔C24)

· Sending procedure

• Writes the send data to the link register (W) of the CPU module to write the send data to the buffer memory of C24.

Issues the transmission request by 'CH1 transmission request' (Y0).

3 'CH1 transmission normal completion' (X0) turns ON when the execution of the transmission request completes.



Link scan

→ : Refresh (Remote head module⇔C24)

### Setting in the master station on CC-Link IE Field Network

Connect the engineering tool to the CPU module of the master station on CC-Link IE Field Network and set parameters.

- **1.** Set the CPU module as follows.
- ‴◯ [Project] ⇔ [New]

New	X
<u>S</u> eries	RCPU
Type	12 R04 🗸
Mode	<b></b>
Program Language	🔂 Ladder 🗸 🗸
	OK Cancel

2. Click the [OK] button to add the module labels of the CPU module.

MELSOFT	GX Works3	
1	Add a module. [Module Name] R04CPU [Start I/O No.] 3E00	
Mode	ule Setting	Setting Change
Mod	dule Label:Use	~
		~
<u>D</u> o 1	Not Show this Dialog Again	ОК

3. Set the CC-Link IE Field Network master/local module as follows.

☆ [Parameters] ⇒ [Module Information] from Navigation window, and right click and select [Add New Module]

A	dd New Module	<b>—</b>
	Module Selection	
	Module Type	🚵 Network Module 📃 👻
	Module Name	RJ71GF11-T2
	Station Type	Master Station 👻
	Advanced Settings	
	Mounting Position	
	Mounting Base	Main Base
	Mounting Slot No.	0 💌
	Start I/O No. Specification	Not Set 🗾 👻
	Start I/O No.	0000 H
	Number of Occupied Points per 1 Sh	32 Points
M	lodule Type elect module type.	
		OK Cancel

Appendix 7 When Connecting the Module to a Remote Head Module

4. Click the [OK] button to add the module labels of the CC-Link IE Field Network master/local module.

MELSOFT GX Works3	
Add a module. [Module Name] RJ71GF11-T2 [Start I/O No.] 0000	
Module Setting	Setting Change
Module Label:Use	*
	▼
Do Not Show this Dialog Again	ОК

- 5. Set the items in "Required Settings" of "Module Parameter" as follows.
- (Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Module Parameter] ⇒ [Required Settings]

Setting Item			
Item	Setting		
Station Type			
Station Type	Master Station		
Network Number			
Network Number	1		
🖃 Station Number			
Setting Method	Parameter Editor		
Station No.	0		
Parameter Setting Method			
Setting Method of Basic/Application Settings	Parameter Editor		

- **6.** Set the network configuration as follows.
- [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Module Parameter] ⇒ [Basic Settings]
   Network Configuration Settings]

ľ	l co	CIE Fie	ld Cor	figuration (Start I/C	): 0000	)							
	сс	IE Fiel	d Cont	figuration <u>E</u> dit	<u>V</u> iew	Close with Discardi <u>ng</u> the Se	etting (	lose wit	th <u>R</u> efle	ctin <mark>g th</mark>	e Setting	3	
				Detect Now									
		Mode S	Setting	Online (Standard	Mode)	- <u>A</u> ssignment	Method	Start/	End	-	Link Sca	n Time (	Approx.): 1.03 ms
l			No.	Model Name	STA#	Station Type	RX	/RY Setti	ng	RWw	/RWr Se	tting	Reserved/Error Invalid (System Switching Monitoring Target
	•						Points	Start	End	Points	Start	End	, , , , , , , , , , , , , , , , , , ,
			1	Host Station	1	Master Station	1024	0000	03EE	1024	0000	03EE	No Setting
			-	NOVED TO TE	-	Incompose Device Station	1021	0000	0011	1021	0000	0011	no octang
													P
				STA#1									
Host Stati STA#0 Total S Line/St		Station A#0 Master al STA#:1 e/Star											
				RJ72GF15- T2									

7. Set the refresh settings as follows.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Module Parameter] ⇒ [Basic Settings]
 ⇒ [Refresh Setting]

NI-	Link Side					CPU Side							
NU.	Device Name		Points Start End		End		Target		Device Name		Points	Start	End
•	SB	•	512	00000	001FF	+	Module Lab	•					
•	SW	•	512	00000	001FF	+	Module Lab	•					
1	RX	•	1024	00000	003FF	+	Specify Dev	•	X	•	1024	01000	013FF
2	RY	•	1024	00000	003FF	+	Specify Dev	•	Y	•	1024	01000	013FF
3	R₩r	•	1024	00000	003FF	+	Specify Dev	•	W	•	1024	00000	003FF
4	R₩w	•	1024	00000	003FF	+	Specify Dev	-	W	•	1024	01000	013FF
5						-		-					

**8.** Write the set parameters to the CPU module of the master station on CC-Link IE Field Network. Then, reset the CPU module or power off and on the system.

(Online] ⇒ [Write to PLC]

### Point P

In this example, default values are used for parameters that are not shown above. For the parameters, refer to the following.

MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

### Setting in the intelligent device station on CC-Link IE Field Network

Connect the engineering tool to the remote head module of the intelligent device station on CC-Link IE Field Network and set the parameters.

- **1.** Set the remote head module as follows.
- ♥♥♥ [Project] ⇒ [New]

New	
<u>S</u> eries	🐗 RCPU 💌
<u>Т</u> уре	RJ72GF15-T2
Mode	·
Program Language	Do not Specify 👻
	OK Cancel

2. Set the items in "Network Required Setting" of "CPU Parameter" as follows.

[Navigation window] ⇔ [Parameter] ⇔ [RJ72GF15-T2] ⇔ [CPU Parameter] ⇔ [Network Required Setting]

Setting Item	
Item	Setting
Network Number	
Network Number	1
😑 Station Number	
Station No.	1

### 3. Set the C24 as follows.

(Parameters] 

[Module Information] from Navigation window, and right click and select [Add New Module]

Add	l New Module	×
N	Adule Selection	
N	Aodule Type	🚵 Information Module 🛛 🗸 🚽
N	Aodule Name	RJ71C24
S	itation Type	
A	idvanced Settings	
	Mounting Position	
	Mounting Base	Main Base
	Mounting Slot No.	0
	Start I/O No. Specification	Not Set 🗸 🗸
	Start I/O No.	0000 H
	Number of Occupied Points per 1 Sl	32Point
Mo	dule Type	
Sele	ect module type.	
		OK Cancel

### 4. Click the [OK] button.

MELSOFT GX Works3			
Add a module. [Module Name] RJ71C24 [Start I/O No.] 0000			
Module Setting	Setting Change		
Module Label:Not use	*		
	-		
Do Not Show this Dialog Again	ОК		

**5.** Set parameters of C24 according to the protocol to be used.

- Page 554 Program example of predefined protocol
- IP Page 559 Program example of nonprocedural protocol or bidirectional protocol

### Program example of predefined protocol

The following shows the program examples to connect an external device (temperature controller) to the CH2 of C24, and to execute the predefined protocol.

#### ■Module parameter setting of C24

1. Set the items in "Basic Settings" of "Module Parameter" as follows.

(Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71C24] ⇒ [Module Parameter] ⇒ [Basic Settings]

Setting Item				
Item	CH1	CH2		
Various control specification	Set the various control sp	pecification.		
TEST MODE setting	No specification			
Communication protocol setting	MELSOFT connection	Predefined protocol		
Communication speed setting	Automatically set	9600bps		
🛛 🗁 transmission setting	Set the transmission method.			
Operation setting	Independent	Independent		
Data bit	7	7		
Parity bit	None	Yes		
Odd/even parity	Odd	Even		
Stop bit	1	2		
Sumcheck code	None	None		
Online change	Disable	Disable		
Setting change	Disable	Disable		
Station Number Settings (CH1, 2 common: 0 to 31)	0			
🚽 🖂 signal setting	Set the ON/OFF status o	fthe RS/DTR signal		

**2.** Write the set parameters to the remote head module of the intelligent device station on CC-Link IE Field Network. Then, reset the remote head module or power the system off and on.

∑ [Online] ⇒ [Write to PLC]

Point P

In this example, default values are used for parameters that are not shown above. For the parameters, refer to the following.

MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

Page 422 PARAMETER SETTING

#### ■Predefined protocol support function setting of C24

- **1.** Select [Tool]⇔[Predefined Protocol Support Function] from an Engineering tool.
- 2. Select "Serial Communication Module" in "Module Type" on the "Predefined Protocol Support Function" screen.

Predefin	ned Protocol Support Function		3
M	Nodule Type Serial Communication Module	<b>-</b>	
< - - - - - - - - - - - - - - - - - - -	Caution> The connection destination setting of predefined protocol upport function is synchronous only when the predefined rotocol support function starting. Unable to change conne estination of predefined protocol support function when hange the connection destination setting in GX Works3 aff tarting the predefined protocol support function. Please st he predefined protocol support function again if you want ynchronize the connection destination.	ction :er art to OK	1

**3.** Select [File]  $\Rightarrow$  [New] on the "Predefined Protocol Support Function" screen.

6		FT Series <pre< th=""><th>lefined Protocol Su</th><th>pport Function-Serial Commu</th><th>nication Module&gt; - [Protocol</th><th>Setting - Untitled]</th><th></th><th></th></pre<>	lefined Protocol Su	pport Function-Serial Commu	nication Module> - [Protocol	Setting - Untitled]		
	F File Edit Online Tool Debugging Support Function Window							- 8 ×
	Protocol No.	Manufacture	r Model	Protocol Name	Communication Type	→ Send <-Receive	acket Name Packe	st Setting
	Add							
	Protoco	l in Predefine Pro	l Protocol Library – tocol Line	Editable Protocol	col Line			
		Se Re	nd Packet Line eive Packet Line	Send	Packet Line ive Packet Line			
P	rotocols	0/128 P:	ckets 0/256	Packet Data Area Usage 0.0%	6 Module for Debuggi	g	Kana characters CAP	NUM SCRL

- **4.** Select [Edit] ⇒ [Add Protocol] on the "Protocol Setting" screen.
- **5.** Select "Predefined Protocol Library" in "Type" on the "Add Protocol" screen, and select the protocol to be used in "Protocol to Add".

Add Protocol			×						
Adds new protocol. Selection of Protocol Type to Add									
<u>T</u> ype :	Type : Predefined Protocol Library  Reference								
Protocol to .	* Select from Predefined Protocol Library. Please select manufacturer, model and protocol name from Protocol to Add. Protocol to Add ——————————————————————————————————								
Protocol No.	Manufacturer	Model	Protocol Name						
1	OMRON	EJ1	0601H:RD Controller Status						
		OK	Cancel						

6. Click the "Variable Unset" cell of "Packet Setting" screen on the "Protocol Setting" screen.

	Protocol No.	Manufacturer	Model	Protocol Name	Communication Type	-> Send <-Receive	Packet Name	Packet Setting
	1 -	OMRON	EJ1	0601H:RD Controller Status	Send&Receive			
1						·>	0601H:RD Controller Status	Variable Unset
1						<-(1)	NOR/0601H:RD Controller Sta	Variable Unset
1						<-(2)	ERR/0601H:RD Controller Stal	Variable Unset
						<-(3)	ERR:Command Finished Abnor	Variable Unset
ſ	۵dd							

### 7. Click the "Variable unset error" cell on the "Packet Setting" screen

cket Setting			
Protocol No.	1	Protocol Na	ame 0601H:RD Controller Status
Packet Type	Send Packet	Packet <u>N</u> am	ne   0601H:RD Controller Status
lement List			
Element	Element Type	Element Name	Element Setting
1	Header	STX	ISTXI(1Byte)
			Variable unset error[->HEX/Fixed Number of Data/Number of data [1]/Digit [2]/Padded
2	Conversion Variable	Communication Unit No.	[0]/Word/Delimiter (none)]
3	Static Data	Sub Address	<u>"00"(28yte)</u>
4	Static Data	SID	"0"(1Byte)
5	Static Data	MRC	<u>"06"(28yte)</u>
6	Static Data	SRC	"01"(2Byte)
7	Terminator	ETX	[ETX][1Byte]
8	Check Code	BCC	(Object element2-7/Parity/HEX/No calculation/18yte)
Chang <u>e</u> Typ	e <u>A</u> dd New	<b>Copy</b>	ste Delete
			Close

- 8. Enter 'W0' to "Send Data Storage Area" on the "Element Setting" screen.
- **9.** Set the packet settings in the "Variable Unset" cell of "Packet Setting" on the "Protocol Setting" screen with the same procedure (from step 5 to step 8).

Set the following values for the data storage area.

Packet name	Element number	Element name	Data storage area specification
NOR/0601H:RD Controller Status	2	Communication Unit No.	Set 'W1000'
	8	Operation Status	Set 'W1001'
	9	Related Information	Set 'W1002'
ERR/0601H; RD Controller Status	2	Communication Unit No.	Set 'W1000'
	7	Response Code	Set 'W1003'
ERR: Command Finished Abnormally	2	Communication Unit No.	Set 'W1000'
	4	End Code	Set 'W1004'

**10.** Select [Online] ⇒ [Write to Module] from Engineering tool.

11. Select "CPU Built-in Memory" in "Target Memory" on the "Write to Module" screen, and click the [Execute] button.



### ■Program example

This program uses the module labels of the CC-Link IE Field Network master/local module. Write the program to the CPU module on the master station.

Cate	gory	Label name							escript	tion	Dev	Device				
Modu	ile label	GF11_1.bSts_DataLinkError							ata link e	error sta	I SB0	SB0049				
		GF11 1.bnSts Data	LinkError S	tation[1]				Da	ata link s	status o	f each station (sta	tion SW	SW00B0 0			
								No	o.1)							
Labe	I to be defined	Define the global lab	el as showr	n below.								(				
					_	_										
		Label Na bStartDirection	ame	Bit	Da	ata Lype			VAR GLO	ss BAL <del>▼</del> M	Assign (Device/Label) /1					
		bReqPulse_Execution		Bit					VAR_GLO	BAL 👻 M	/10					
		bReqSetProtocolExecution bCompleteStatusDevice		BitO	1)				VAR_GLU	BAL V	411 4100					
		bCompleteStatusDevice2		Bit(0	1)				VAR_GLO	BAL V	4102					
		bCompleteStatusDevice3	IC l-t-	Bit(0	1)				VAR_GLO	BAL 🗸 M	4104					
		bREMT0instructionAbnorma	IComplete	Bit					VAR_GLO	BAL VI	/200					
		bREMTOinstructionNormalCo	omplete	Bit					VAR_GLO	BAL 🗕 M	1202					
		bREMTOinstructionAbnorma	IComplete3	Bit					VAR_GLO	BAL - M	4203					
		bReqExecution		Bit					VAR_GLO	BAL V	/1000					
		bCH2_ProtocolExecutionCor	mpletion	Bit					VAR_GLO	BAL 👻 >	(100C					
		bSts_CommunicationProtoco	PreparationCom	pletion Bit Bit					VAR_GLO	BAL ->	(101D /1004					
		wCommunicationUnitNo	scation	Wor	d [Unsigned]/	Bit String [16-	-bit]		VAR_GLO	BAL - V	V0					
		wNumberOfConsecutiveExec	cutions	Wor	d [Unsigned]/	Bit String [16-	-bit]		VAR_GLO	BAL 🔻 [	00					
		winitializesProtocolExecution wExecutionResult	1	Wor Wor	a (Unsigned)/ d [Unsigned]/	Bit String [16- Bit String [16-	-oit](U., 7) -bit]		VAR_GLO VAR GLO	BAL VI	)100					
		wResultExecutionCount		Wor	d [Unsigned]/	Bit String [16-	-bit]		VAR_GLO	BAL 🖵 [	0101					
		wProtocolNumber		Wor	d [Unsigned]/	-bit](07)		VAR_GLO	BAL V	)102						
		wMatcheuracket wNumber0fProtocolRequest	s	Wor	d [Unsigned]/ d [Unsigned]/	Bit String [16- Bit String [16-	-bit]		VAR_GLO	BAL V	20					
		wNumberOfProtocolCompleti	ions	Wor	d [Unsigned]/	Bit String [16-	-bit]		VAR_GLO	BAL 🔻 (	1					
	GF11 1 bSts Datal	GE11 1 bnSts Datal inkErro														
(0)	inkError	r_Station[1]										N1	bStartDirection			
(0)	/ī	/									MC		M1			
N1 _	M1 bReqExecution	bSts_CommunicationProtoc	bDuringExecu tionFlag									1	bPocPulso Executio			
(6)	M1000	X101D	M400									PLS	n M10			
		1 1	* 1													
													bDuringExecutionFI			
												SET	ag M400			
	bBegPulse Executi															
(10)	on M10										MOV	K1	wCommunicationUni			
(12)	I												WO			
											MOV	K1	wNumberOfConsec			
											MOV		D0			
						1										
										EMOV	HO	wInitializesProtoc	К8			
												D1				
											MOV	K1	wInitializesProtocol Execution			
						1						l	D1			
				<u> </u>												
				ZP.REMTO	"J1"	К1	K1		H0	H4020	wNumberOfConse cutiveExecutions	K1	bCompleteStatusDe vice[0]			
				-			_				D0		M100			
	bCompleteStatusD															
(38)	evice[0] M100											RST	bReqPulse_Executio n			
(30)							-						M10			
		hCompleteStatusDovia=[1]														
		M101										SET	bReqSetProtocolEx			
		<u>н</u>				-							M11			
		pCompleteStatusDevice[1] M101										CET	bREMTOinstruction			
												- SET	M200			

557

	bReqSetProtocolE										
(46)	xecution M11		ZP.REMTO	″J1″	K1	K1	HO	H4024	wInitializesProtoco IExecution D1	K8	bCompleteStatusDe vice2[0] M102
(62)	bCompleteStatusD evice2[0] M102									RST	bReqSetProtocolEx ecution M11
		bCompleteStatusDevice2 [1] M103								SET	bCH2_Set_Req_Prot ocolExecution Y100A
		bCompleteStatusDevice2 [1] M103								SET	bREMTOinstruction AbnormalComplete2 M201
(70)	bCH2_Set_Req_Pro tocolExecution Y100A	bCH2_ProtocolExecutionCo mpletion X100C	ZP.REMFR	"J1"	K1	K1	H0	H4022	wExecutionResult D100	K18	bCompleteStatusDe vice3[0] M104
										RST	bCH2_Set_Req_Prot ocolExecution Y100A
(88)	bCompleteStatusD evice3[0] M104	bCompleteStatusDevice3 [1] M105								SET	bREMTOinstruction NormalComplete M202
		[1] M105								SET	bREMTOinstruction AbnormalComplete3 M203
										RST	bDuringExecutionFI ag M400
(97)										MCR	N1
	hCU2 Sat Bog Bro										
(98)	tocolExecution Y100A									INCP	wNumberOfProtoco IRequests C0
(102)	bGH2_ProtocolExe cutionCompletion X100C									INCP	wNumberOfProtoco ICompletions C1
(106)											

(6) Sets the send data and writes the number of continuous protocol executions and the protocol number to be executed to the buffer memory of C24 by the REMTO instruction.

(62) Issues the predefined protocol execution request when the REMTO instruction completes.

(70) Reads the execution result from the buffer memory of C24 by the REMFR instruction when the execution of the predefined protocol completes.

### Program example of nonprocedural protocol or bidirectional protocol

The following shows the program examples to connect an external device (personal computer) to the CH1 of C24, and to send/receive data by using the nonprocedural protocol or bidirectional protocol with input/output signals.

#### ■Module parameter setting of C24

1. Set the items in "Basic Settings" of "Module Parameter" as follows.

 $\bigcirc$  [Navigation window]  $\Rightarrow$  [Parameter]  $\Rightarrow$  [Module Information]  $\Rightarrow$  [RJ71C24]  $\Rightarrow$  [Module Parameter]  $\Rightarrow$  [Basic Settings] When communicating by using the bidirectional protocol, set "Bidirectional protocol" for the communication protocol setting.

ng Item		
Item	CH1	CH2
Various control specification	Set the various control sp	ecification.
TEST MODE setting	No specification	
Communication protocol setting	Nonprocedural protocol	MELSOFT connection
Communication speed setting	9600bps	Automatically set
🗧 transmission setting	Set the transmission meth	od
Operation setting	Independent	Independent
Data bit	8	7
Parity bit	None	None
Odd/even parity	Odd	Odd
Stop bit	1	1
Sumcheck code	Yes	None
Online change	Disable	Disable
Setting change	Disable	Disable
Station Number Settings (CH1, 2 common: 0 to 31)	0	
🗉 signal setting	Set the ON/OFF status of	the RS/DTR signal.

2. Set the items in "refresh settings" of "Module Parameter" as follows.

🯹 [Navigation window] ⇔ [Parameter] ⇔ [Module Information] ⇔ [RJ71C24] ⇔ [Module Parameter] ⇔ [Refresh setting]

Setting Item			
<b>.</b>			Number of transfers to i
l arget			Number of transfers to C
	Item	CH1	CH2
🗏 Transfert	to intelligent function module	The specified device data	is sent to the buffer memor
Send da	ta_send area	W0	
😑 Transfert	o CPU	Data in buffer memory is se	ent to specified device.
LED ligh	iting status, communication error status		
📮 Transfert	o CPU/transmission control status	Auto refresh setting for tra	nsmission control status c
Commun	ication protocol status (current)		
Transmis	ssion status (current)		
😑 Transfert	o CPU/control signal status	Auto refresh setting for co	ntrol signal status
BS-232	control signal status		
📮 Transfert	o CPU/communication results	Automatic refresh setting:	s for communication result
Transmis	ssion sequence status		
On dema	and execution results		
Data ser	nd results	W1202	
Data rec	eption result	W1203	
MC prote	ocol send error code		
Receive	d user frame		
📮 Transfert	o CPU/for receive data	Auto refresh setting for rea	ceive data (There are three
Receive	area	W1000	
🖃 Transfert	o CPU/communication protocol execution status	Automatic refresh setting	for protocol execution stat

- **3.** Write the set parameters to the remote head module of the intelligent device station on CC-Link IE Field Network. Then, reset the remote head module or power the system off and on.
- Conline] ⇒ [Write to PLC]

Point P

In this example, default values are used for parameters that are not shown above. For the parameters, refer to the following.

MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

### ■Program example for data reception

This program uses the module labels of the CC-Link IE Field Network master/local module. Write the program to the CPU module on the master station.

Category	Label name		De	escription		Device			
Module label	GF11_1.bSts_DataLinkError		Da	ta link error s	stat	us of own station	SB0049		
	GF11_1.bnSts_DataLinkError_Statio	on[1]	Da No	ta link status .1)	of	each station (station	SW00B0.0		
Label to be defined	Define the global label as shown be	low.							
	Label Name	Data Type		Class		Assign (Device/Label)			
	bStartDirection	Bit		VAR_GLOBAL	•	M1			
	bReqPulse_Receive	Bit		VAR_GLOBAL	•	M10			
	bDataReceptionNormalComplete	Bit		VAR_GLOBAL	•	M300			
	bReceptionAbnormalDetection	Bit		VAR_GLOBAL	•	M301			
	bCH1_Set_Req_ReceptionRead	Bit		VAR_GLOBAL	•	×1003			
	bCH1_Sts_ReceptionAbnormalDetection	Bit		VAR_GLOBAL	Ŧ	×1004			
	bCH1_Set_Req_ReceptionReadCompletion	Bit		VAR_GLOBAL	Ŧ	Y1001			
	wReceiveDataCount	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	Ŧ	W1000			
	wReceiveData	Word [Unsigned]/Bit String [16-bit](04)		VAR_GLOBAL	Ŧ	W1001			
	wReceptionResult	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	Ŧ	W1203			
	wDataCount	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	Ŧ	DO			
	wData	Word [Unsigned]/Bit String [16-bit](04)		VAR_GLOBAL	•	D1			
	wResult	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	D800			

	GF11_1.bSts_DataLin	GF11_1.bnSts_DataLi						3	
(0)	kError	nkError_Station[1]					МС	N1	bStartDirection
(0)		/			 		IVIC		M1
	bStartDirection								
N1-	M1								
- <sup>11</sup>									
	bCH1_Set_Req_Rece		 	 					
(6)	ptionRead X1003							PLS	bReqPulse_Receive
(0)					 			T LO	M10
	bReqPulse_Receive						<b></b>	wReceiveD	wDataCount
(9)	M10						MOV	ataCount	D0
								W1000	DU
						BMOV	wReceiveD	wData	wDataCount
					 	DIVIOV	W1001	D1	D0
									bDataReceptionNorm
								SET	alComplete M300
									1000
								SET	bCH1_Set_Req_Recep tionReadCompletion
					 				Y1001
	hCH1 Sts Recention		 	 	 				
	AbnormalDetection							wReceptio	wResult
(18)	X1004	-			 		MOV	nResult W1203	D800
	11								
									h De e e e tiere A har e e e e e e
								SET	Detection
									M301
								057	bCH1_Set_Req_Recep
					 			SET	Y1001
	bCH1_Set_Req_Rece	bCH1_Sts_Reception AbnormalDetection							hCH1 Set Reg Recen
(23)	X1003	X1004						RST	tionReadCompletion
	<u>/</u>	—_/I—			 				¥1001
(26)								MOR	N1
(20)					 			WOR	
ļ			 	 	 		1		
(27)									LEND 1
A									

(6) Reads the received data when the C24 receives data normally.

(18) Reads error description (error code) when the C24 detects an error at data reception. (Unnecessary for bidirectional protocols.)

### ■Program for data transmission

wDataCount

wData wResult

This program uses the module labels of the CC-Link IE Field Network master/local module. Write the program to the CPU module on the master station.

Category	Label name		Descript	io	n		Device					
Module label	GF11_1.bSts_DataLinkError			Data link e	errc	or status of own statior	ı	SB0049				
	GF11_1.bnSts_DataLinkError_St	ation[1]		Data link status of each station (station SW00B0.0 No.1)								
Label to be defined	Define the global label as shown	below.										
	Label Name	Data Type		Class		Assign (Device/Label)						
	bStartDirection	Bit		VAR_GLOBAL	-	M1						
	bReqPulse_Transmission	Bit		VAR_GLOBAL	-	M10						
	bDataTransmissionNormalCompletion	Bit		VAR_GLOBAL	-	М300						
	bD ataTransmissionAbnormalEnd	Bit		VAR_GLOBAL	-	M301						
	bD ataT ransmissionInstruction	Bit		VAR_GLOBAL	•	M1000						
	bCH1_Sts_TransmissionNormalCompletion	Bit		VAR_GLOBAL	Ŧ	X1000						
	bCH1_Sts_TransmissionAbnormalEnd	Bit		VAR_GLOBAL	•	X1001						
	bCH1_Set_Req_Transmission	Bit		VAR_GLOBAL	•	Y1000						
	wSendDataCount	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	•	W0						
	wSendData	Word [Unsigned]/Bit String [16-bit](04)		VAR_GLOBAL	•	W1						
	wDataTransmissionResult	Word [Unsigned]/Bit String [16-bit]		VAR_GLOBAL	-	W1202						
	D + O +	NUMBER OF THE PARTY OF THE PART		LUD CLODU		0.0						

VAR\_GLOBAL - D0 VAR\_GLOBAL - D1 VAR\_GLOBAL - D20

Word [Unsigned]/Bit String [16-bit](0..4) Word [Unsigned]/Bit String [16-bit]

Word [Unsigned]/Bit String [16-bit]

	GE11.1 bSts DataLink	GE11.1 bnSts DataLink									
(0)	Error	Error_Station[1]							MC	N1	bStartDirection
(0)	<u> </u>	//							MC		M1
	bStartDirection										
N1 _	<sup>L</sup> M1										
	bDataTransmissionIns	bCH1_Sts_Transmission	bCH1_Sts_Transmissi	bCH1_Set_Req_		1					
(6)	truction M1000	NormalCompletion X1000	onAbnormalEnd X1001	Transmission Y1000						DIS	bReqPulse_Transm
(0)		//	//	—-//—-						FLS	M10
	bRegPulse Transmissi				1					-	
(10)	on M10								MOV	H4102	wData[0]
(12)									WOV		D1
										H4342	wData[1]
									MOV		D2
										H4544	wData[2]
									MOV		D3
										H4746	wData[3]
									MOV		D4
										H348	wData[4]
									MOV		D5
										K5	wDataCount
									MOV		D0
										wDataCount	wSendDataCount
									MOV	DO	WO
							1				110
									wData[0]	wSendData	wSendDataCount
								BMOV	wData[0]	wSendData	wSendDataCount
								BMOV	wData[0] D1	wSendData W1	wSendDataCount W0
								BMOV	wData[0] D1	wSendData W1	wSendDataCount W0
								BMOV	wData[0] D1	wSendData W1 SET	wSendDataCount W0 bCH1_Set_Req_Tra
								BMOV	wData[0] D1	wSendData W1 SET	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000
	bCH1.Sts Transmissio							BMOV	wData[0] D1	wSendData W1 SET	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000							BMOV	wData[0] D1	wSendData W1 SET SET	wSendDataCount W0 bCH1_Set_Reg_Tra nsmission Y1000 bDataTransmission NormalCompletion
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000							BMOV	wData[0] D1	wSendData W1 SET SET	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission NormalCompletion M300
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000							BMOV	wData[0] D1	wSendData W1 SET SET	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission NormalCompletion M300
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000							BMOV	wData[0] D1	wSendData W1 SET SET RST	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Tra nsmission
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000							BMOV	wData[0] D1	wSendData W1 SET SET RST	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Tra nsmission Y1000
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd							BMOV	wData[0] D1	wSendData W1 SET SET RST	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Tra nsmission Y1000
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001							BMOV	wData[0] D1	wSendData W1 SET SET RST SET	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission AbnormalEnd
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001							BMOV	wData[0] D1	wSendData W1 SET SET RST SET	wSendDataCount W0 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Tra nsmission Y1000 bDataTransmission AbnormalEnd M301
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001							BMOV	wData[0] D1	wSendData W1 SET SET RST SET	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission AbnormalEnd M301
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001							BMOV	wData[0] D1	wSendData W1 SET SET RST SET wDataTransm issionResult	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission AbnormalEnd M301
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001							BMOV	wData[0] D1	wSendData W1 SET SET RST SET wDataTransm issionResult W1202	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission AbnormalEnd M301 wResult D20
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001							ВМОУ	wData[0] D1	wSendData W1 SET SET RST SET wDataTransm issionResult W1202	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission AbnormalEnd M301 wResult D20
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001							ВМОУ	wData[0] D1	wSendData W1 SET SET RST SET wDataTransm issionResult W1202	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission AbnormalEnd M301 wResult D20 bCH1_Set_Req_Transmission
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001 1							вмоч	wData[0] D1	wSendData W1 SET SET RST SET SET wDataTransm issionResult W1202	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission AbnormalEnd M301 wResult D20 bCH1_Set_Req_Transmission Y1000
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001							ВМОУ	wData[0] D1	wSendData W1 SET SET RST SET SET wDataTransm issionResult W1202	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission M301 wResult D20 bCH1_Set_Req_Transmission Y1000
(32)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001 1							BMOV	wData[0] D1	WSendData W1 SET SET RST SET SET WDataTransm issionResult W1202 RST	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission AbnormalEnd M301 wResult D20 bCH1_Set_Req_Transmission Y1000 N1
(32) (35) (40)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001 I							BMOV	wData[0] D1	WSendData W1 SET SET RST SET SET WDataTransm issionResult W1202 RST	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission X1000 bDataTransmission AbnormalEnd M301 bCH1_Set_Req_Transmission Y1000 bCH1_Set_Req_Transmission Y1000 bCH1_Set_Req_Transmission Y1000
(32) (35) (40)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001 IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII							BMOV	wData[0] D1	wSendData W1 SET SET RST SET wDataTransm issionResult W1202 RST RST	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission X1000 bDataTransmission M301 wResult D20 bCH1_Set_Req_Transmission Y1000 N1
(32) (35) (40) (41)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001 IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII							BMOV	wData[0] D1	wSendData W1 SET SET RST SET wDataTransm issionResult W1202 RST RST	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission M301 wResult D20 bCH1_Set_Req_Transmission Y1000 N1
(32) (35) (40) (41)	bCH1_Sts_Transmissio nNormalCompletion X1000 bCH1_Sts_Transmissio nAbnormalEnd X1001 IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII							BMOV	wData[0] D1	wSendData W1 SET SET RST SET SET wDataTransm issionResult W1202 RST RST	wSendDataCount W0 bCH1_Set_Req_Transmission Y1000 bDataTransmission NormalCompletion M300 bCH1_Set_Req_Transmission Y1000 bDataTransmission M301 wResult D20 bCH1_Set_Req_Transmission Y1000 N1

(6) Sets the send data and issues the send request.

 $\left( 32\right)$  Performs the processing when the send processing completes normally.

(35) Performs the processing when the send processing completes abnormally.

### Appendix 8 Added and Changed Functions

This section shows the added and changed functions of C24.

Added/changed contents	Firmware version	Reference
A remote head module redundant system is supported.	'07' or later	—

### INDEX

### 0 to 9

1C frame	-															24
2C frame	• •															24
3C frame	• •					•									•	24
4C frame	• •				•							•	•			24

### A

ACK	
Additional code	
Application setting 428	
ASCII-binary conversion	
Auto modem initialization designation 164	
Automatic removal of NULL character 407	

### В

Basic setting
Bidirectional protocol
Buffer memory 161,265,268,496
Buffer memory for send/receive data monitoring
function

### С

C/N       443         Check code       46         Circuit trace       109         Communication error status       441	3 3 9 1
Complete signal handling for modem function	
designation	1
Condition match send 125	5
Connection retry count designation 161	1
Connection retry interval designation 161	1
Conversion variable 41	1
CPU error monitoring designation	)
Current operation status reading	7
Cycle time designation	9
Cycle time units designation	9

### D

Data arrangement	130
Data communication status (transmission sequen	ce
status) reading	446
Data communication using user frame	276
Data No. for connection designation	162
Data No. for initialization designation	161
Data reception by receive end code	55
Data registration status for connection	163
Data registration status for initialization	163
DC code control	239
DC1/DC3	239
DC2/DC4	241
Debug support function	109
Dedicated instruction	520
Default registration frame	250
DTR/DSR (ER/DR) signal control	237

### E

Echo back
ERR LED
Erroneous noise signal reception prevention 405
Error code list
Error information
Error information clear
Event history list

### F

Fixed cycle send	24
Full-Duplex Communication	04
Full-duplex communication	243

### Η

Half-duplex communication	243
Hardware test.	50
Header	35

### I

I/O signals for handshake with CPU module380
Independent operation
Individual station test
Information to be transmitted
Initialization command177
Initialization of modem/TA (terminal adapter) 185
Initialization/connection timeout designation161
Input/output signal list
Interlink operation
Interlock
Interrupt setting

### L

Length
Line disconnection wait time (for PLC CPU
monitor)
List of input/output signal for modem function 160
Loopback test

### Μ

MC protocol
Method to register/read/delete data for
connection
Method to register/read/delete data for
initialization
Mode switching
Mode switching method by program
Modem connection CH specification
Modem connection data
Modem function error code
Modem function overview
Modem function sequence status
Modem function setting
Modem function specification
Modem initialization data

### Modem initialization DR (DSR) signal

enable/disable designation 16	64
Module extended parameter	37
Module label 49	)2
Module parameter	23
Monitoring condition 12	26
Monitoring device 12	22
Monitoring timing 12	23
MX Component	25

### Ν

N	
	NAK
	NEU
	No-communication interval time designation 162
	Non-conversion variable
	Nonprocedural no-reception monitoring time method
	designation
	Nonprocedural protocol
	Non-verified reception
	No-reception monitoring time (timer 0) 228
	Number of data registration for connection 163
	Number of data registration for initialization 163
	Number of initialization retries designation 161

### 0

On-demand data arrangement	268
On-demand data communication	267
On-demand function control procedure	270
On-demand function specification	274
On-demand user frame specification	268

### Ρ

P/S
Packet
Parameter registration to CPU module 401
Parameter setting 422
Parameter setting item for programmable controller
CPU monitoring function 138
Parameter setting procedure
Predefined protocol
Predefined protocol library
PRO 442
Processing time 543
Programmable controller CPU monitoring
function
Protocol execution count
Protocol execution log storage function 113

### R

Refresh setting
Register/read/delete data for connection
Register/read/delete data for initialization177
Registered bit block quantity designation 140
Registered word block quantity designation 140
Registering, reading or deleting user frames262
Registration data byte count designation
Registration data byte count designation area 164
Remote password check 150,156,167,171
Remote password function
Response monitoring time (timer 1)
Retransmission time transmission method
designation
RS/CS control enable/disable designation 162
RS-232 CD terminal check designation
RS-232 communication method designation248
RS-232 control signal status reading
RUN I FD

### S

SD LED.       .459         SD WAIT.       .442         Self-loopback test.       .451         Send area       .78,97         Send data       .79
Send data arrangement
Send monitoring time (timer 2)       .233         Send user frame designation       .316         Send/receive data monitoring       .387         Sending method       .77,96         Setting for receiving data using interrupt program       .210
Setting of send user frame
designation
SIO
Startup of Modem Function
Static data

### т

Terminator
Iransmission control
I ransmission control end free space designation
Transmission control start free space designation
Transmission error detection
Transmission procedure
Transmission timing of monitoring result
Transmission wait time
Transparent code
Troubleshooting
Troubleshooting by symptom

### U

Unauthorized access 1	55,168
User frame	250,266
User frame content	437
User frame registration status	266
User frame specification	429
User frame specification area	164
User frame type	250

V	
Variable data	251 424

### W

Word/byte units setting	g	225
-------------------------	---	-----

### REVISIONS

The manual number is given on the bottom left of the back cover.			
Revision date	*Manual number	Description	
June 2014	SH(NA)-081251ENG-A	First edition	
September 2014	SH(NA)-081251ENG-B	Partial correction	
June 2015	SH(NA)-081251ENG-C	■Added or modified parts Section 7.1, Section 26.2, Section 27.4	
May 2016	SH(NA)-081251ENG-D	■Added or modified parts TERMS, Appendix 7, Appendix 8	
December 2016	SH(NA)-081251ENG-E	■Added or modified parts SAFETY PRECAUTIONS, Section 3.1, Section 27.4	

### \*The manual number is given on the bottom left of the back cover.

#### Japanese manual number: SH-081249-E

This manual confers no industrial property rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2014 MITSUBISHI ELECTRIC CORPORATION

### WARRANTY

Please confirm the following product warranty details before using this product.

#### 1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

#### [Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
  - 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
  - 2. Failure caused by unapproved modifications, etc., to the product by the user.
  - 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
  - 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
  - 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
  - 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
  - 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

#### 2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

### 3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

#### 4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

### 5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

## TRADEMARKS

Ethernet is a registered trademark of Fuji Xerox Corporation in Japan.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as '<sup>TM</sup>' or '<sup>®</sup>' are not specified in this manual.

This Product uses the Source Code of  $\mu$ T-Kernel under  $\mu$ T-License granted by the T-Engine Forum (www.t-engine.org).

 SH(NA)-081251ENG-E(1612)KWIX

 MODEL:
 R-C24-U-OU-E

 MODEL CODE:
 13JX21

### MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS : 1-14 , YADA-MINAMI 5-CHOME , HIGASHI-KU, NAGOYA , JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.