



Instruction manual

OETIKER Schweiz AG
Spätzstrasse 11
CH-8810 Horgen
Schweiz

Inhaltsverzeichnis

1	Information about this manual.	5
1.1	Symbols and means of representation used	5
1.2	Scope	5
1.2.1	FAST 3000	6
1.2.2	Rating plates	7
1.3	Abbreviations	7
1.4	Light-curtain.	8
1.4.1	Requirements for the safety light curtain.	8
1.4.2	Mount safety light curtain	8
1.5	Stickers on the FAST 3000	9
1.6	Associated documents	9
2	Basic safety instructions.	10
2.1	Using the Operating Instructions	10
2.2	Use for the intended purpose.	10
2.3	General safety instructions	11
2.4	Covers.	12
2.5	Special safety instructions	12
2.6	Safe methods of working	13
2.7	Using the FAST 3000 via an external control system.	13
2.8	Conversions, modifications	13
2.9	Qualified personnel	13
2.10	Maintenance work.	15
2.11	Overload protection of the crimping cut-off head	15
2.12	Noise level.	15
3	Scope of supply of the FAST 3000 tool	16
3.1	Overview of the main components of the FAST 3000	16
3.2	Available main configurations.	17
3.3	Optional extras	17
4	Brief description of the FAST 3000	20
4.1	Design of the tool mechanism	20
4.2	Design of the FAST 3000 crimping cut-off head	22
4.3	Two-hand control desk (option).	23
5	Description of the process monitoring of the FAST 3000	24
5.1	Control of the closing force, description the of process parameters.	24
5.1.1	Functional description of control of the closing force	24
5.1.2	Closing Force.	25
5.1.3	Closing force tolerance.	25
5.1.4	Switch point reduction	25
5.1.5	Speed phase 1	25
5.1.6	Speed phase 2	26
5.1.7	Closing force holding time	26
5.1.8	Pulling force sensor check	28

5.2	Crimping monitoring	28
5.2.1	General information on the crimping force monitoring (CFM)	28
5.2.2	Mechanical design	29
5.2.3	CFM: Typical OK force curve	31
5.2.4	CFM: Wear detection.	32
5.2.5	CFM: Sample curves of crimping operations	33
5.3	Cut-off monitoring.	45
6	Working with the FAST 3000.	46
6.1	Commissioning	46
6.2	Connections to the control cabinet	48
6.3	Cable connections to the crimping force monitoring	49
6.4	Switching on the FAST 3000	50
6.5	Correctly positioning the FAST 3000	52
6.5.1	General instructions, positioning the FAST 3000 and WingGuard® clamp housing	52
6.5.2	Positioning of the FAST 3000 installation tool with the alignment aid	56
6.5.3	Dimensions for correctly positioning the FAST 3000	58
6.6	Normal operation (production)	59
6.7	Laboratory mode (password-protected)	62
6.7.1	One-hand operation	64
6.7.2	Foot pedal	65
6.8	Special operating modes (password-protected)	67
6.8.1	Unlocking	68
6.8.2	“Manual Drive” Operation	69
6.8.3	Setting the force offset to zero.	70
6.8.4	Verifying the pulling force	71
6.8.5	Crimping force monitoring verification	73
6.8.6	Adjusting the crimping force monitoring	74
6.8.7	Changing the measurement program	80
6.8.8	Loading new settings/measurement programs to the CFM units	82
7	GUI.	84
7.1	Touch Panel.	84
7.2	Computer	84
7.3	GUI Layout	85
7.4	Menu structure	86
7.4.1	Welcome screen	86
7.4.2	Closure data (a password is necessary to change the values)	87
7.4.3	Operating mode	88
7.4.4	Free state pull force test	92
7.4.5	I/O Test.	93
7.4.6	Logbook	98
7.4.7	Setting	104
7.4.8	Information	109
7.4.9	Error list	109
7.4.10	Access rights.	114
8	Assigning the IP address.	115
8.1	Setting the date and time	115

9	Maintenance and replacement of parts.	116
9.1	General safety instructions for maintenance and repair work	116
9.2	Maintenance	117
9.2.1	Before maintenance work	117
9.2.2	After maintenance work	117
9.2.3	Regular checking of the status.	118
9.2.4	Regular maintenance work / maintenance schedule.	119
9.2.5	A-service - to be performed every 100,000 cycles	120
9.2.6	B-service - to be performed every 200,000 cycles	122
9.3	Replacing parts	123
9.3.1	Removing the crimping cut-off head.	123
9.3.2	Installing the crimping cut-off head	125
9.3.3	Replacing the crimping jaws and/or the cut-off die	125
9.3.4	Replacing the crimping wedge.	128
9.3.5	Replacing the crimping jaws pivot pin	129
9.3.6	Replacing the clamping lever	131
9.4	Checking and adjusting the position of the strap detection sensor	133
9.5	Setting the closing force sensor	135
9.5.1	Checking the ease of movement of the clamping unit.	135
9.5.2	Adjusting the load cell	135
9.6	Replacing the control cabinet or tool mechanism	137
9.7	Tools and consumable materials for maintenance	138
10	Controlling the FAST 3000 via an external PLC.	146
10.1	Control via a field bus (Ethernet/IP or Profinet)	146
10.1.1	Settings for the Ethernet/IP communication protocol	146
10.1.2	Settings for the Profinet HW configuration.	147
10.1.4	Addition to industrial communication	160
10.1.5	Handling Function	163
10.2	Overview of the state machine in the PLC	165
10.3	Control via 24-V I/O signals.	165
11	Decommissioning, transport, storage, recommissioning	166
11.1	Decommissioning	166
11.2	Transport	166
11.3	Storage	167
11.4	Recommissioning	167
11.5	Disposal	167
12	Technical data	168
13	Troubleshooting and error messages.	169
13.1	General instructions in the event of errors	169
13.2	What should I do, if ...?	169
13.3	Error messages and their resolution	172
13.3.1	Warnings	172
13.3.2	Tool errors	176
13.3.3	Process errors	183
14	Appendix	190
15	Help and Support.	191

1 Information about this manual

1.1 Symbols and means of representation used

Safety notices are used in this manual to warn of the risk of personal injury or property damage.

- ▶ Always read and observe these safety notices.
- ▶ Observe all notices that are flagged with a safety alert symbol and text.

The following symbols are used in these Operating Instructions:



Hazardous situation.

Failure to observe this notice will lead to death or serious injury.



Indicates a hazard with medium risk, which can lead to death or serious injury!



Indicates a hazard with low risk, which can lead to medium or minor injuries!



Indicates a danger of damage to the device! Indicates a note useful for operation!

Symbol	Meaning
▶ ...	One-step instruction
1. ... 2. ... 3. ...	Multi-step instruction ▶ Carry out the steps in the order shown.
✓ ...	Requirement • Necessary or labor-saving steps for the successful execution of an action.
Connecting	Display or operating elements of the menu or the PC software are highlighted.

1.2 Scope

These Operating Instructions apply to all Oetiker FAST 3000 (stationary tool for installing strap clamps) and describe the method of operation together with the correct procedures for commissioning, operation, maintenance, decommissioning, recommissioning, storage and transport.

They contain important instructions for safe working procedures.

For the version FAST 3000 with Light curtain the corresponding leaflet “Manual FAST 3000 Light Curtain” has to be considered.

1.2.1 FAST 3000

- Control cabinet
- Two-hand control desk (optional)
- Installation tool
- Connecting cable
- Touch panel (optional)
- Foot pedal (optional)
- Closing force verification unit (optional)
- Crimping force monitoring devices
- Emergency stop dongle
- Jaws kit for CFM verification on the FAST 3000 (optional)




Fig. 1: FAST 3000

1.2.2 Rating plates




Fig. 2: Rating plates

1.3 Abbreviations

N	Newton	s	seconds
mm	millimeters	ms	milliseconds
kg	kilogram	CFM	Crimping Force Monitoring

1.4 Light-curtain




Fig. 3: Light curtain

1.4.1 Requirements for the safety light curtain


According to the following standards, a two-channel safety light curtain must be used:

- EN ISO 13849-1:2015: mindestens Kat. 3, PL d
- EN 62061+A1:2009: mindestens Kat. 3, SIL 2

Possible safety light curtain: Keyence GL-R (GL-R08H)


Stopping time of the OETIKER FAST 3000
for calculating the safety distance of the
safety light curtain: 0,15 s

1.4.2 Mount safety light curtain

	<p>NOTICE</p> <ul style="list-style-type: none"> ▶ The safety distance of the safety light curtain must be determined by the integrator. ▶ EN ISO 13855:2010 must be observed.
---	---

Stopping time of the OETIKER FAST 3000 for calculating of the safety distance of the safety light curtain:
0,15 s

1.5 Stickers on the FAST 3000

	<p>CAUTION</p> <p>► Comply with all safety stickers and always exercise great care when using the FAST 3000.</p>
---	---




Fig. 4: Stickers (1, 2, 3) on the FAST 3000

- 1 Wear safety glasses!
- 2 Crush hazard!
- 3 Crush hazard!




Fig. 5: Stickers (1, 2) on the crimping cut-off head and alignment aid

- 1 General warning signs: Never use a FAST 3000 without force sensors.
- 2 Warning sign: Magnetic field
- 3 Permanent magnet

1.6 Associated documents

- EC Declaration of Conformity, see Appendix (Section 14)
- Other associated documents, see Appendix (Section 14)

2 Basic safety instructions

2.1 Using the Operating Instructions

- Make sure that these Operating Instructions are always kept close at hand ready for use.
- Pass these Operating Instructions on to the next owner or user.
- Please read these Operating Instructions carefully before commissioning the FAST 3000 tool.
 - Familiarize yourself with all settings and their functions.
 - Anyone involved in setting up, commissioning, maintaining or repairing the unit must have read and understood the Operating Instructions and in particular the safety instructions.

2.2 Use for the intended purpose

	<p>CAUTION</p> <p>The FAST 3000 with its associated parts is intended solely for the controlled closure of OETIKER PG270 WingGuard® strap clamps. It may not be used to close clamps other than Oetiker WingGuard® strap clamps 270.</p>
---	---

- The unit may be used only for the intended purpose and under technically safe and fault-free conditions.
- Correct usage also covers observance of these Operating Instructions and compliance with the technical data.
- Any use not in accordance with the prescribed usage shall be regarded as incorrect usage.
- The use of the FAST 3000 in areas subject a risk of explosions is not permitted.
- The FAST 3000 can be used as a stand-alone tool or be integrated into an assembly cell.
- If the FAST 3000 is integrated into an assembly cell it can be used without the optional two-hand control desk and without the optional touch panel. In such cases the integrator is responsible for the safe integration of the FAST 3000 into the assembly cell.
 - For further information on the integration of the FAST 3000 see Section 10.
- The installation of the light curtain is the responsibility of the operator

Use other than for the intended purpose

The FAST 3000 is built to current technology and is safe in operation. Residual hazards remain if it used incorrectly or by untrained personnel. The manufacturer bears no responsibility for injuries to personnel and damage to property arising from improper use of the FAST 3000. In such cases the operating company is solely responsible.

Implemented safety concept for safe operation

The FAST 3000 is intended for operation by a single operator. It is prohibited for a third person to start the clamping cycle.

To exclude the risk that parts of limbs may be crushed between the WingGuard® clamp and the goods being strapped, the two-hand control requires the use of two hands to start the clamping cycle, which corresponds to a Performance Level PL d to EN ISO 13849-1.

The clamping cycle is started by depressing the two start buttons simultaneously.


After 300 milliseconds the WingGuard® clamp is sufficiently closed that no parts of limbs can be inserted, the start buttons can be released again once they have been depressed. This excludes the possibility of incorrect clamping that might be caused by premature release of the start buttons.

In the event of the clamping drive starting up unexpectedly during the insertion phase, an additional sensor ensures that the pulling unit is immediately disabled.

The safety concept considers the hazards that might arise from the FAST 3000. Other hazards in the surrounding working area must be considered by the operating company and countered as necessary by measures for personal safety.

If the FAST 3000 is not controlled via the Oetiker two-hand control, the operating company must ensure safe integration of the FAST 3000.

2.3 General safety instructions

	CAUTION
	Hazard due to an unsuitable workplace. ► Ensure sufficient space and sufficient lighting.

- Comply with all operating instructions and maintenance instructions.
- Maintenance and repair work should be carried out only by qualified specialists.
- The FAST 3000 tool may be used only by persons who are familiar with its use and have been informed of the risks.
- All relevant accident prevention regulations and other generally recognized health and safety rules must be complied with. The manufacturer shall not be held liable for damage resulting from unauthorized modifications to the FAST 3000.
- Use the FAST 3000 only in a clean and dry working environment.
- Use the FAST 3000 only in an area provided with sufficient lighting.
- Provide sufficient space for safe handling and operation.

Spare parts

In order to ensure the fast and accurate delivery of spare parts, a clear purchase order is essential. It must include the following information:

- Product name, software version
- Type designation
- Serial number
- Name of the spare part and quantity required
- Spare part number
- Shipping method
- Full address

Details can be found in the OETIKER tools catalog.

Improvements to the machine

In our endeavor to continuously improve the quality of our products, we reserve the right to make improvements without changing the Operating Instructions. Details of dimensions, weights, materials, performance ratings and names may therefore be subject to necessary changes. Regarding electrical diagrams, the diagram supplied with the machine takes precedence in all cases.

2.4 Covers



CAUTION

Use the FAST 3000 only when all covers are correctly fitted.




Fig. 6: Protective covers on the FAST 3000

- Make sure that identification marks and warning instructions on the machine are always present and legible.

2.5 Special safety instructions

Only specially trained personnel are authorized to carry out maintenance and repair work on electrical equipment.

- Before starting maintenance and repair work, switch off all units and disconnect the entire tool from the power supply.
- Check the crimping jaws and cut-off die as part of the preventive maintenance routine and replace them if necessary.

2.6 Safe methods of working

- Check the FAST 3000 for visible damage on each occasion before starting production, and make sure it is used only when in good condition. Make particularly sure to thoroughly check the crimping jaws and emergency stop!
- Any defects must be reported to a supervisor immediately.
 - Do not continue to use the FAST 3000 if defects have been identified.
- During operation of the machine and when performing maintenance, wear safety glasses.
- The FAST 3000 is intended for operation by only a single operator. The closing cycle may not be initiated by a second person.
- Keep sufficient free space around the product. Users must not be hampered by third persons.
- Arrange the working area of the FAST 3000 for good ergonomics.
- Pressing the emergency stop button on the two-hand control desk disconnects both positioning drives from the power supply and brings their movement to an immediate halt.
 - If the FAST 3000 is controlled via an external PLC, *see Section 10*.
- The operator must install a suitable light curtain!

2.7 Using the FAST 3000 via an external control system

- The integrator is responsible for the safe integration of the FAST 3000.
- The integrator must perform a risk evaluation and implement the system in accordance with the risk evaluation.
- The integration may be performed only by qualified personnel.
- If no two-hand control desk is used, an external emergency stop must be wired in.
- For more information on this subject, *see Section 10*.
- If you have questions about how to perform integration contact Oetiker.
- The installation of the light curtain is the responsibility of the operator

2.8 Conversions, modifications

- The FAST 3000 may not be modified either in respect of its design or in respect of its safety features without express permission from OETIKER. OETIKER shall not be held liable for any damages resulting from any unauthorized modifications.
- Use only original spare parts and accessories.
- Do not dismantle any safety equipment or features.

2.9 Qualified personnel

	WARNING
	Hazards due to operation by unauthorized or unqualified personnel.

This device may be used only by authorized and qualified personnel. Use other than in accordance with the Operating Instructions is prohibited. The levels of authorization for use are as follows:

Personnel Use/operation	Operator	Maintenance mechanic	Electrician
Installation/decommissioning	x	✓	✓
Transport/storage	x	✓	✓
Commissioning without the optional two-hand control desk / without the optional touch panel	x	x	✓
Commissioning with the optional two-hand control desk / with the optional touch panel	x	✓	x
Normal operation	✓	✓	✓
Removal/installation of the crimping cut-off head	x	✓	✓
Maintenance of the crimping cut-off head	x	✓	✓
“Manual mode” operation	x	✓	✓
Error correction	x	✓	✓
Removal of the covers	x	✓	✓
Opening the control cabinet	x	x	✓
Replacing parts	x	✓	✓

Explanation: ✓ = permitted x = not permitted

“Operator”:

- is familiar with the specified safety instructions and regulations
- knows the applicable procedures described in this document
- is appropriately trained
- is authorized by the competent office
- The operating company must ensure that the employee has received the safety instructions and regulations in the relevant language.

“Maintenance mechanic”:

- has the knowledge described for the “Operator”
- is familiar with the mechanical techniques required for working on the machines and tools (fastening, cleaning, lubricating)
- knows the applicable procedures described in this document
- does not use the tool under improper conditions (when maintenance intervals have been exceeded or when partially disassembled)

“Electrician”:

- has the knowledge described for the “Maintenance mechanic”
- has sound knowledge of mechanical and electrical matters
- has been trained and authorized to work on equipment at potentially fatal voltages (110/230 V AC)
- is aware that bad workmanship can lead to serious injuries to personnel and damage to equipment
- is aware that bad workmanship can lead to the failure of electrical and mechanical components
- is aware that the tool must be in good condition when handed over to another user
- knows the applicable procedures described in this document

The “Operator” is authorized to perform the following activities:

- Use of the tool in normal operation
- Cleaning the working area

The “**Maintenance mechanic**” is authorized to perform the following activities:

- The activities performed by the “Operator”
- Working in the *Manual operation* operating mode. This allows the tool to be operated manually.
- Make changes to the closure data
- Removal/installation of the crimping cut-off head and cleaning the associated parts
- Maintenance of the crimping cut-off head by replacing the spare parts, cleaning and lubricating
- Investigation of the crimping cut-off head and the associated parts for wear and damage
- Installation, transport and storage
- Removal of the covers for access to the components

The “**Electrician**” is authorized to perform the following activities:

- The activities performed by the “Maintenance mechanic”
- Repair of the tool if it is in a defective condition
- Removal of the covers and opening the control cabinet for access to the components
- Replacement of the parts and maintenance of the electrical wiring

2.10 Maintenance work

The inspection and maintenance intervals specified in the Operating Instructions must be complied with.

Maintenance and repair instructions must be followed accordingly.

2.11 Overload protection of the crimping cut-off head

	CAUTION
Do not remove the overload protection of the crimping cut-off head. Using the tool without overload protection and CFM force load cells can lead to mechanical damage.	




Fig. 7: Overload protection (1) of the crimping cut-off head

2.12 Noise level

In normal operation a maximum noise level of 75 dBA can be expected.

3 Scope of supply of the FAST 3000 tool

3.1 Overview of the main components of the FAST 3000








Fig. 8: Design of the FAST 3000 tool








1. Connecting cable
2. Control cabinet
3. Two-hand dongle, thin
4. Two-hand dongle (emergency stop two-hand control desk, used if the two-hand control desk is not connected)
5. Touch panel / optional
6. Foot pedal / optional
7. Two-hand control desk / optional
8. Jaws checking mirror
9. Closing force verification unit can CAL 01 calibrator (not shown) / optional
10. Alignment aid
11. Installation tool with crimping force monitoring devices
12. Jaws kit for CFM verification on the FAST 3000 (not shown) / optional



3.2 Available main configurations

Configuration	Scope of supply
Oetiker FAST 3000 AdvantEdge + CFM - EtherNet/IP Light curtain 2 Part number 13500362 Oetiker FAST 3000 with CFM and EtherNet/IP The tool is supplied with a tool carrier	
Oetiker FAST 3000 + CFM - PROFINET Light curtain 2 Part number 13500361 Oetiker FAST 3000 with CFM and PROFINET The tool is supplied with a tool carrier	

3.3 Optional extras

Option	Scope of supply
Two-hand control desk Part number 13500298 Two-hand control desk for autonomous operation of the FAST 3000.	
Touch panel, complete Part number 13500278 Touch panel for controlling the FAST 3000 if no laptop or supervisory controller is used.	

Option	Scope of supply
Foot pedal Part number 13500105 Foot pedal to allow hands-free use of the FAST 3000 during tests or in the laboratory.	
Test Equipment CAL01 CAL01 qualified UK / engl-de / SKS01-1500mm Part number 13600384 Test equipment for verification of the closure force and crimping force	
Test Equipment CAL01 CAL01 qualified USA / engl-es / SKS01-1500mm Part number 13600385 Test equipment for verification of the closure force and crimping force	
Test Equipment CAL01 CAL01 qualified CN / engl-de / SKS01-1500mm Part number 13600386 Test equipment for verification of the closure force and crimping force	
Test Equipment CAL01 CAL01 qualified EURO / de-engl / SKS01-1500mm Part number 13600387 Test equipment for verification of the closure force and crimping force	
Verification unit PG135 lockable Part number 13500299 Adapter jaws for verification of the closing force. The CAL 01 must be ordered separately.	
Jaws kit for CFM verification on the FAST 3000 Part number 13500237 For CFM verification The CAL 01 must be ordered separately.	

Option	Scope of supply
Connecting cable cpl. 1m 2x180° Part number 13500354	
Connecting cable cpl. 1.5 m 2x180° Part number 13500359	

For spare parts and auxiliary tools, see *Section 9.7*.

4 Brief description of the FAST 3000

The Oetiker FAST 3000 was developed to perform closure of the OETIKER WingGuard® strap clamps.

A production cycle consists of the following steps:

- The operator positions the OETIKER WingGuard® strap clamps on the application.
- The FAST 3000 is pulled in the direction of the application and the strap end of the OETIKER WingGuard® strap clamp is inserted into the crimping cut-off head.
- Pressing the clamping button secures the strap end.
- After the start of the closing cycle the strap end is drawn in by the FAST 3000 until a certain closing force is achieved. Precise control of the force is ensured by the force load cell and the high-performance electro-mechanical drive.
- After the closing force is achieved, the strap is crimped by the FAST 3000 to create the wings that secure the clamp against opening. The clamping procedure is monitored by two force load cells. The signal from the force load cells is evaluated by two force monitoring devices. OK/not OK signals are sent by the monitoring devices to the PLC of the FAST 3000.
- After crimping procedure has been performed, the strap ends are cut off.
- They are transported to the ejection position, where they fall out of the tool.
- The FAST 3000 returns to the home position.



NOTICE

More information on the different steps is provided in Section 6.6.

4.1 Design of the tool mechanism




Fig. 9: Tool mechanism

Tool mechanism of the FAST 3000

- | | |
|--|---|
| 1. Crimping cut-off head | The crimping cut-off head crimps the WingGuard® clamp and cuts off the projecting strap end. |
| 2. Strap end detection LED | Indicates the presence of the strap: <ul style="list-style-type: none">• Continually dark: No strap present• Flashing slowly: Strap present but not clamped• Flashing quickly: Strap present and clamped but not inserted sufficiently far. The strap must be inserted further• Continually lit: Strap present and clamped. Ready for the clamping cycle |
| 3. M8 3-pin port for connecting the customer's clamping pushbutton | When a second handle is used, a second clamping pushbutton can also be connected. |
| 4. Handle | The tool can be positioned using the handle. |
| 5. Clamping pushbutton | To trigger the securing of the WingGuard® strap end. |
| 6. Spirit level | Using the spirit level it can be checked that the tool is correctly positioned vertically (see Section 6.5). |
| 7. Sleeve for the sensor signal cable for crimping monitoring | Sleeve that contains the sensor signal cables for crimping monitoring. The cables are directly connected to the crimping force monitoring device. |
| 8. Connecting cable between the tool and control cabinet | Connecting cable between the tool mechanism and control cabinet |
| 9. Tapped hole for attachments | This is available for customer applications such as installation of sensors or of a second handle |
| 10. Pivot point for the tilting motion | This permits easy insertion of the WingGuard® clamp into the strap end slot. |
| 11. Tapped hole (concealed) | This can be used for instance to mount the customer's positioning cylinder. |
| 12. Linear guide | This permits each insertion of the WingGuard® clamp into the strap end slot. Achievement of the correct setting position must always be guaranteed. |
| 13. Transport restraint | This must be installed for transporting the mechanism. For normal operation the transport restraint must be removed. |
| 14. Positioning stop | The purpose of the stop is to ensure the correct horizontal positioning of the tool mechanism in the setting position. |
| 15. Strap end discharge duct | The strap ends of the WingGuard® clamps are ejected here.

Make sure that the strap ends are correctly discharged and do not remain on the linear guide. |

4.2 Design of the FAST 3000 crimping cut-off head



CAUTION

Risk of damage to the crimping jaws and the cut-off die.

- Make sure that only the intended OETIKER PG270 WingGuard® strap clamps are used. Otherwise the crimping jaws and the cut-off die may be damaged.




Fig. 10: Crimping cut-off head

1. Head housing
2. Crimping jaws
3. Crimping wedge
4. Crimping slide
5. Spacer plate
6. Cut-off die
7. Cut-off slide
8. Cut-off die guide
9. Clamping unit slide
10. Head housing cover




Fig. 11: Particulars of the crimping cut-off head: CFM force load cell and its brackets

- 11. Force sensor bracket
- 12. Crimping force sensor

4.3 Two-hand control desk (option)



DANGER

The two-hand control desk must be positioned at least 210 mm from the crimping tool mechanism and must be bolted in position.




Fig. 12: Two-hand control desk

- 1. Emergency stop button
- 2. 2-hand start buttons (must be depressed simultaneously to start a closing cycle)
- 3. Initialization button (for initializing the FAST 3000).
 - Flashes when the tool requires initialization.
 - The button is lit continually while initialization is in progress.
- 4. Acknowledgement button (“Acknowledge”; to display and acknowledge closures that are not OK, and error messages)
- 5. Green indicator light (“Ready”; indicates that the FAST 3000 is ready for operation)
- 6. Buzzer (active in laboratory mode, indicates the closing cycle is about to start)

5 Description of the process monitoring of the FAST 3000

5.1 Control of the closing force, description the of process parameters

The purpose of the FAST 3000 is to close OETIKER WingGuard® strap clamps.

	NOTICE
	For the recommended values for the process parameters please refer to the technical data sheet of the OETIKER PG270 WingGuard® strap clamp.




Fig. 13: Closure data table

5.1.1 Functional description of control of the closing force

The development of the closing force is divided into four phases. These three phases allow simple adjustment of the force control parameters, which are required for a constant and repeatable pulling operation.

Phase 1 Rapid pre-closing of the clamp.

- The clamp is closed at speed phase 1 until the closing force minus the switch point reduction has been reached.

Phase 2 A slower closing speed until the required closing force has been reached.

- The speed at which the clamp is closed is specified by the speed phase 2. Once the closing force has been reached, the force control switches to phase 3.

Phase 3 In phase 3, the FAST 3000 force control mode is active.

- As soon as the closing force has remained within the closing force tolerance for a period specified by the closing force holding time.

Phase 4 Phase 4 is the crimping phase.

- At the end of the crimping process the clamp is released. The pulling unit moves back 0.8 mm and then the band is cut




Fig. 14: Force control phases (Example, shows a target of closing force of 1850 N)

1. Closing force
2. Closing force tolerance (± 100 N around 1850 N)
3. Force threshold at which the engine is starts to decelerate
4. Switch point reduction
5. Force increase after reaching the closing force, due to the drive stroke during deceleration
6. Start crimp process
7. Closing force holding time
8. Strain relief on the clamp band
9. Force increase while cutting the band

5.1.2 Closing Force

OETIKER PG270 WingGuard® strap clamps must be closed with a recommended and uniform closing force (force priority). This results in a consistent, reproducible and permitted tensioning stress on the strap material and avoids overloading the individual components, the parts being clamped and the clamps.

5.1.3 Closing force tolerance

Specifies the tolerance range within which the closing force must lie for clamp locking to be activated.
Adjustable Tolerance Range: ± 50 N to ± 150 N

5.1.4 Switch point reduction

Sets the force to a value less than the set closing force. At that point the pulling speed changes from the fast speed phase 1 to a slower speed phase 2.

5.1.5 Speed phase 1

Speed during phase 1 (fast closure of the clamp).

5.1.6 Speed phase 2

Speed during phase 2 (slow closure of the clamp before activation of force control).

5.1.7 Closing force holding time




Some applications require a specific applied force and a specific period of time, so that the components are ideally connected. With the FAST 3000, the user can adjust this period of time.

In general, soft materials require a longer holding time than harder ones.

Sample curves with different closing force parameters

The preset closing force parameters function on all applications, including very hard ones. It is therefore recommended the settings are not changed unnecessarily.

Diagram/Setting	Comment
<p>Setting value</p> <p>Closing force: 1850 N Closing force tolerance: 100 N Closing force holding time: 500 ms Switch point reduction: 500 N Speed Phase 1: 80.0 mm/s Speed Phase 2: 2.0 mm/s</p> <p>Last closing cycle ID: S003a_CS_676</p> <p>Cycle time: 3.69 s Actual closing force: 1843 N Pulling distance: 32 mm</p> <p>Local / Automatic Waiting for clamp and fixation.... Cycle counter: 676 Service counter: 99324</p>	Closing with standard settings on a hard mandrel
<p>Setting value</p> <p>Closing force: 800 N Closing force tolerance: 100 N Closing force holding time: 500 ms Switch point reduction: 500 N Speed Phase 1: 80.0 mm/s Speed Phase 2: 2.0 mm/s</p> <p>Last closing cycle ID: S003a_CS_687</p> <p>Cycle time: 4.78 s Actual closing force: 802 N Pulling distance: 31 mm</p> <p>Local / Automatic Acknowledged Cycle counter: 687 Service counter: 99313</p>	Closing force set to 800 N
<p>Setting value</p> <p>Closing force: 1850 N Closing force tolerance: 100 N Closing force holding time: 100 ms Switch point reduction: 500 N Speed Phase 1: 80.0 mm/s Speed Phase 2: 2.0 mm/s</p> <p>Last closing cycle ID: S003a_CS_681</p> <p>Cycle time: 3.26 s Actual closing force: 1805 N Pulling distance: 34 mm</p> <p>Local / Automatic Waiting for clamp and fixation.... Cycle counter: 681 Service counter: 99319</p>	<ul style="list-style-type: none"> Reduced holding duration This results in a shorter cycle time

Diagram/Setting	Comment
 <p>Setting value</p> <p>Closing force: 1850 N Closing force tolerance: 100 N Closing force holding time: 500 ms Speed Phase 1: 80.0 mm/s Speed Phase 2: 2.0 mm/s</p> <p>Switch point reduction: 600 N</p> <p>Last closing cycle ID: S003a_CS_678</p> <p>Cycle time: 3.83 s Actual closing force: 1852 N Pulling distance: 32 mm</p> <p>Local / Automatic Waiting for clamp and fixation.... Cycle counter: 678 Service counter: 99322</p>	<ul style="list-style-type: none"> • Switch point reduction set to a higher value • The FAST 3000 switches earlier to phase 2. • The drive begins to reduce speed at 1250 N (600 N before reaching the closing force)
 <p>Setting value</p> <p>Closing force: 1850 N Closing force tolerance: 100 N Closing force holding time: 500 ms Speed Phase 1: 80.0 mm/s Speed Phase 2: 2.0 mm/s</p> <p>Switch point reduction: 500 N</p> <p>Last closing cycle ID: S003a_CS_683</p> <p>Cycle time: 3.95 s Actual closing force: 1857 N Pulling distance: 33 mm</p> <p>Local / Automatic Waiting for clamp and fixation.... Cycle counter: 683 Service counter: 99317</p>	<ul style="list-style-type: none"> • Phase 1 speed is lower • This results in a slightly longer cycle time • Due to the lower speed setting, the FAST 3000 switches to phase 2 at 1550 N. (Less time required to reduce the drive speed)
 <p>Setting value</p> <p>Closing force: 1850 N Closing force tolerance: 100 N Closing force holding time: 500 ms Speed Phase 1: 80.0 mm/s Speed Phase 2: 4.0 mm/s</p> <p>Switch point reduction: 500 N</p> <p>Last closing cycle ID: S003a_CS_679</p> <p>Cycle time: 3.44 s Actual closing force: 1843 N Pulling distance: 34 mm</p> <p>Local / Automatic Waiting for clamp and fixation.... Cycle counter: 679 Service counter: 99321</p>	<ul style="list-style-type: none"> • Phase 2 speed is higher • This results in a slightly shorter cycle time • The risk of a force overshoot is higher

5.1.8 Pulling force sensor check

During each closing cycle, the FAST 3000 performs a Pulling force sensor check. In the unloaded state, a check is carried out as to whether the measured force is approx. 0N (+/- 25N).

In addition, the system tests in a lightly loaded state whether the measured force is within the expected range (+/- 20N).

5.2 Crimping monitoring

The crimping operation is monitored during measurement of the forces occurring during crimping.



NOTICE

Details on how to export data, see maXYmos-BL Manual chapter 4.3.7

5.2.1 General information on the crimping force monitoring (CFM)




Fig. 15: Crimping force monitoring devices

- Two monitoring devices evaluate the force signals from the two load cells. A sensor and a monitoring device is used for each wing; one on the left, one on the right.
- The independent monitoring of the two wings ensures that as many irregularities as possible are recorded.
- The evaluation is based on a time-force curve.
- The units send OK/not OK signals to the FAST 3000 PLC. The FAST 3000 PLC uses these and other signals to determine whether the overall closing operation was OK or not OK.
- The monitoring devices must be positioned separately from the control cabinet. They can be mounted within the user's field of view.
- New measurement programs can be transmitted using the "Kistler maXYmos" software from a laptop to the monitoring devices via an Ethernet connection (see Section 6.8.7).
- The results of the individual closing operations, including the force curve and current evaluation settings of the monitoring device, can be saved automatically to a central server. For more detailed information on this, please refer to the Operating Instructions of the monitoring device.

5.2.2 Mechanical design

The following figure shows the action of the forces applied to the crimping jaw. Viewed from the crimping jaw side.




Fig. 16: Application of force to on the crimping jaws

1. Movement of the crimping wedge
2. Force acting on the jaw due to the closing action of the crimping wedge
3. Shearing and deformation force during the crimping of the WingGuard® strap clamp (wing formation
4. Resulting force accepted by the crimping jaws pivot pin

The force is transmitted via the crimping jaw pivot pins to the force transmission lever of the crimping head transmit.



NOTICE

Due to the principle of leverage the force is divided between the transmission lever and the spacer plate.




Fig. 17: Force transmission level, lateral sectional view through the crimping head




Fig. 18: Front view of the crimping cut-off head with force transmission levers

1. Force transmission lever
2. Spacer plate
3. Crimping jaw pivot pins
4. Crimping jaw
5. The force on the crimping jaw pivot pins is transmitted to the force transmission lever of the head housing
6. Fixed body hinge
7. Force measured by the crimping force sensor (leverage principle)

5.2.3 CFM: Typical OK force curve




Fig. 19: OK force curve

1. EO 3: No-Pass curve: The force curve may not intersect this curve. If the force curve intersects the No-Pass curve:
 - The crimping procedure will be evaluated as not OK.
 - In addition, the closing operation will be terminated immediately and the strap of the WingGuard® clamp will be cut off without formation of the closing wings. This function protects the components of the FAST 3000, particularly the crimping jaws, against overloading.
2. The crimping jaw touches the strap of the WingGuard® strap clamp, the force increases
3. EO 1: First envelope curve: If the actual force curve infringes the upper or lower envelope curve limit, the crimping operation will be evaluated as not OK.
4. First peak: The strap begins to shear/formation of the wings
5. EO 2: Second envelope curve: If the actual force curve infringes the upper or lower envelope curve limit, the crimping operation will be evaluated as not OK.
6. EO 4: Uni-Box: Transmits the force values on entry and exit to the FAST 3000 PLC. See next section.
7. Second peak: The crimping jaw reaches its end position
8. Relaxation effects. As there is no process-relevant information, this is not a part of the envelope curve
9. Switching signal: If the force curve intersects the switching signal, then the crimping operation is terminated immediately and strap of the WingGuard® clamp is cut off without forming the closing wings. This function protects the components of the FAST 3000, particularly the crimping jaws, against overloading.



NOTICE

As soon as an EO (Evaluation Object) does not meet the test condition, it is displayed in red.

5.2.4 CFM: Wear detection




Fig. 20: Wear detection

1. New crimping cut-off head
2. Worn crimping cut-off head

If the second peak is missing this means either that parts of the crimping cut-off head (crimping jaws, crimping wedge, crimping pivot pin) are worn or that the crimping jaw has broken off (Example pictures on page 39 to page 42). For this reason, the FAST 3000 PLC will perform an additional check: The monitoring devices measure the force levels at entry into the green rectangular box and exit from the box. These force values are transmitted to the FAST 3000 PLC, which calculates the difference between the entry force and exit force. If the difference is less than a specific value, an error message is generated (-50 N is the standard setting, adjustable range -100 to +100 N).

Formula:

Information on how to adjust the tol. wear value, see Section 7.4.7.

If Exit Force – Entry Force > Threshold value, then closure is OK

The condition of the Crimping cut-off head can be determined by:

- checking the condition of the crimping jaws visually. See picture of good jaws below:








Fig. 21: crimping jaws





- measuring the closing gap of the Crimping cut-off head in mounted condition (Refer to maintenance manual for information about how to measure the closing gap).


In addition to the condition of the crimping cut-off head, the band thickness of the WingGuard® clamp and side-acting forces on the WingGuard® clamp also affect the force differential.




5.2.5 CFM: Sample curves of crimping operations


CFM curve	Image of the closed clamp
<p>Left</p>  <p>Right</p> 	<p>Wings unusually thin and not closed to a sufficient height.</p> 



Description
<p>During wing closure the clamp housing was not parallel to the crimping cut-off head.</p>  <p>The following criteria have led to the not OK evaluation:</p> <ul style="list-style-type: none"> • Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“) • Wear detection right (Troubleshooting „PrErr_310: Crimping error CFM2 wear“)


CFM curve	Image of the closed clamp
<p>Left</p>  <p>Right</p> 	 




Description
<p>During wing closure the clamp housing was not parallel to the crimping cut-off head.</p>  <p>The following criteria have led to the not OK evaluation:</p> <ul style="list-style-type: none"> • First envelope curve (EO 1) right (Troubleshooting „PrErr_307: Crimping error CFM2 envelope curve 1“) • Second envelope curve (EO 2) left (Troubleshooting „PrErr_304: Crimping error CFM1 envelope curve 2“) • Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“)

CFM curve	Image of the closed clamp
<p>Left</p>  <p>Right</p> 	

Description
<p>During wing closure the clamp housing was not parallel to the crimping cut-off head.</p>  <p>Crimping jaw struck the edge of the strap instead of reaching underneath the strap.</p> <p>The closure process is aborted in order to protect the crimping jaws of the FAST 3000 against damage.</p> <p>Cancellation triggered by maximum force of the left crimping jaw.</p> <p>The following criteria have led to the not OK evaluation:</p> <ul style="list-style-type: none"> • Second envelope curve (EO 2) left (Troubleshooting „PrErr_304: Crimping error CFM1 envelope curve 2“) • Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“) • Uni-Box (EO 4) left (Troubleshooting „PrErr_304: Crimping error CFM1 envelope curve 2“) • Uni-Box (EO 4) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“)


CFM curve	Image of the closed clamp
<p>Left</p>  <p>Right</p> 	<p>Chip formation under the wing.</p> 

Description
<p>Slanting application; the right side is lower than the left side. Closure of the clamp on an oblique solid surface.</p>  <p>The following criteria have led to the not OK evaluation: Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“)</p>

CFM curve	Image of the closed clamp
<div><div>Left</div><div><p>The graph shows force in Newtons (N) on the y-axis (ranging from -60 to 1650) versus distance in millimeters (mm) on the x-axis (ranging from -0.020 to 0.300). A red curve represents the force profile, showing a sharp increase starting around 0.10 mm, peaking at approximately 1400 N around 0.15 mm, and then gradually decreasing. A shaded red area indicates the tolerance range. A vertical dashed pink line is positioned at approximately 0.10 mm. A horizontal dashed pink line is at approximately 400 N. A small '3' with an 'x' is marked on the x-axis at approximately -0.010 mm.</p></div></div> <div><div>Right</div><div><p>The graph shows force in Newtons (N) on the y-axis (ranging from -60 to 1650) versus distance in millimeters (mm) on the x-axis (ranging from -0.020 to 0.300). A red curve represents the force profile, showing a sharp increase starting around 0.10 mm, peaking at approximately 1400 N around 0.15 mm, and then gradually decreasing. A shaded red area indicates the tolerance range. A vertical dashed pink line is positioned at approximately 0.10 mm. A horizontal dashed pink line is at approximately 400 N. A small '3' with an 'x' is marked on the x-axis at approximately -0.010 mm.</p></div></div>	<div>No wing formation.</div> <div><p>A close-up photograph of a metal clamp assembly. The clamp is made of a dark, possibly coated, metal. It features two rectangular slots on the top surface, each containing a lighter-colored, possibly brass, insert. The clamp is shown in a closed position, with a dark, cylindrical component visible at the bottom. The background is a light, textured surface.</p></div>

Description

- Slanting application; the right side is lower than the left side. Closure of the clamp on an oblique solid surface.
- Foreign Object leads to a gap between cut off punch and WingGuard® housing, therefore there is a collision between the FAST 3000 crimp jaw and the WingGuard® housing.



The crimping process is terminated due to the premature increase in force, in order to prevent damage to the crimping jaws.

The following criteria have led to the not OK evaluation:


- No-Pass (EO 3) left (Troubleshooting „PrErr_305: Crimping error CFM1 NoPass“)
- First envelope curve (EO 1) left (Troubleshooting „PrErr_303: Crimping error CFM1 envelope curve 1“)
- First envelope curve (EO 1) right (Troubleshooting „PrErr_307: Crimping error CFM2 envelope curve 1“)
- Second envelope curve (EO 2) left (Troubleshooting „PrErr_304: Crimping error CFM1 envelope curve 2“)
- Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“)
- Uni-Box (EO 4) left (Troubleshooting „PrErr_304: Crimping error CFM1 envelope curve 2“)
- Uni-Box (EO 4) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“)

CFM curve	Image of the closed clamp
<p>Left</p> <p>Right</p>	<p>Closing width larger, wing less high.</p>

CFM curve	Image of the closed clamp
-----------	---------------------------

Description

Closing with simulated wear (closing gap 3.4 mm. Refer to maintenance manual for information about how to measure the closing gap.)



The FAST 3000 PLC checks if the following condition is fulfilled: Exit Force – Entry Force < Threshold value.


If yes, the FAST 3000 PLC outputs an error message and the closure operation is evaluated as not OK.

For more information about wear detection, see Section 5.2.4.


The following criteria have led to the not OK evaluation:

- Wear detection left (Troubleshooting „PrErr_306: Crimping error CFM1 wear“)
- Wear detection right (Troubleshooting „PrErr_310: Crimping error CFM2 wear“)

Left



Right



Right wing not formed, left wing badly formed.



CFM curve	Image of the closed clamp
-----------	---------------------------

Description

Right crimping jaw completely broken off.

In comparison to good jaws:




(Example image)


The following criteria have led to the not OK evaluation:







- First envelope curve (EO 1) right (Troubleshooting „PrErr_307: Crimping error CFM2 envelope curve 1“)
- Second envelope curve (EO 2) left (Troubleshooting „PrErr_304: Crimping error CFM1 envelope curve 2“)
- Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“)
- Uni-Box (EO 4) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“)
- Wear detection left (Troubleshooting „PrErr_306: Crimping error CFM1 wear“)
- Wear detection right (Troubleshooting „PrErr_310: Crimping error CFM2 wear“)




Left







Right





CFM curve	Image of the closed clamp
Description	
<p>Right crimping jaw partially broken off:</p>  <p>The following criteria have led to the not OK evaluation:</p> <ul style="list-style-type: none"> • Second envelope curve (EO 2) left (Troubleshooting „PrErr_304: Crimping error CFM1 envelope curve 2“) • Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“) • Wear detection right (Troubleshooting „PrErr_310: Crimping error CFM2 wear“) 	
<p>Left</p>  <p>Right</p> 	
Description	
<p>Both jaws partially broken off:</p> 	<p>In comparison to good jaws:</p> 

CFM curve	Image of the closed clamp
<p>The following criteria have led to the not OK evaluation:</p> <ul style="list-style-type: none"> Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“) 	
<p>Left</p>  <p>Right</p> 	



Description
<p>Right jaw partially broken off:</p>  <p>The following criteria have led to the not OK evaluation:</p> <ul style="list-style-type: none"> Second envelope curve (EO 2) right (Troubleshooting „PrErr_308: Crimping error CFM2 envelope curve 2“)

CFM curve	Image of the closed clamp
<p>Left</p>  <p>Right</p> 	

Description
<p>Fastening screws of the head housing cover are not sufficiently tight.</p> <p>Lock is still OK!</p> <p>For information about the correct tightening torque refer to Section 9.3.3.</p>

CFM curve	Image of the closed clamp
<p>Left</p>  <p>Right</p> 	

Description
<p>Closing force set to 800 N instead of the standard setting of 1850 N. CFM force level greater than at 1850 N, due to the in general lower stress level in the clamp band.</p> <p>Conclusion: The closing force has an influence on the CFM curves</p> <p>As a comparison, check the pictures on the next page</p>


CFM curve	Image of the closed clamp
<p>Left</p>  <p>Right</p> 	

Description
<p>Closing force set to 2500 N instead of the standard setting of 1850 N. Due to the generally higher stress level in the clamp band, the CFM force level is lower than with the standard 1850-N setting.</p> <p>Conclusion: The closing force has an influence on the CFM curves</p> <p>As a comparison, check the pictures on the page before</p>


5.3 Cut-off monitoring


The FAST 3000 PLC checks the force acting on the load measuring cell, while the strap end of the WingGuard® clamp is ejected. If the force measured is higher than expected, this may mean that the strap of the WingGuard® strap clamp has not been fully cut off and the cutting die is defective. An error message appears and the assembly operation is evaluated as not OK.


6 Working with the FAST 3000


	WARNING
	<p>Hazardous situation due to improper installation.</p> <ul style="list-style-type: none"> ▶ Read and understand the safety advice, Section 2. ▶ Make sure that the FAST 3000 has enough space around it to ensure the operator is not hampered or bumped into by other persons. ▶ Attach the FAST 3000 installation tool and its control cabinet to the attachment points provided. ▶ Ensure that the necessary plugs are inserted (the tool, two-hand control desk, ...) before the FAST 3000 is connected to the power supply. ▶ A touch panel/ two-hand control desk and/or a connection to a PLC must be provided.

6.1 Commissioning

	CAUTION
	<p>Hazard due to the machine being incorrectly installed.</p> <p>The installation of the FAST 3000 may be performed only by qualified personnel who have read and understood the Operating Instructions.</p>

	CAUTION
	<p>Hazard due to incorrect inspection.</p> <p>Ensure during and after each installation that</p> <ul style="list-style-type: none"> ▶ all parts are in good condition, ▶ all parts are installed so that they cannot fall down, ▶ all safety-relevant parts are installed and working correctly. ▶ the crimping cut-off head is correctly installed. Use only crimping jaws that are in good condition and use only an intact cut-off die.

	CAUTION
	<p>Hazard due to defective devices due to improper handling and positioning.</p> <ul style="list-style-type: none"> ▶ Connect all cables and installation tools to the control cabinet and disconnect them from it only when in the de-energized state. ▶ Plug connector contacts may be touched only by persons who are grounded to prevent ESD. ▶ The control cabinet may be installed only in an upright position.

	CAUTION
	<p>Risk of insufficient closure quality due to incorrect routing of the connecting cable</p> <p>When closing a WingGuard® clamp the WingGuard® strap clamp housing of the tool head must be pressed gently against the parts to be connected.</p> <ul style="list-style-type: none"> ▶ Lay the connecting cable so that the crimping cut-off head tilts downwards.

The commissioning procedure of the FAST 3000 includes the following steps:

1. Install the components of the FAST 3000 so that they cannot fall off, so they recognize ergonomic factors and so that clamps can be correctly closed.
2. Connect the installation tool to the control cabinet.




Fig. 22: Connection connecting cable

3. Connect the CFM unit to the control cabinet (see Section 6.3).
4. Optional: Connect the touch panel, the two-hand control desk, the foot pedal and the external PLC to the control cabinet (see Section 6.2).
5. Connect the control cabinet to the power supply.
6. Switch the FAST 3000 on (see Section 6.4).
The first closures on a loose mandrel can now be performed.
7. Position the installation tool (see Section 6.5).
The tool is now ready for operation.
8. Close a few test clamps to determine the functionality of the tool.

6.2 Connections to the control cabinet




Fig. 23: Connections to the control cabinet

1. Power supply
2. Connecting cable between the tool mechanism and control cabinet
3. Touch panel
4. Hard wire I/O
5. Power supply CFM 24 V
6. EtherCat CFM
7. Hardwire I/O power supply
8. Foot pedal
9. ProfiNet (active only on Oetiker FAST 3000 + CFM-Profinet)
10. EtherNet (TCP / Ethernet IP)
11. External emergency stop (if this port is not connected to an external emergency stop the thin two-hand dongle must be plugged in.)
12. Two-hand control desk (if no two-hand control desk is connected the two-hand dongle must be plugged in, see Section 3.3)
13. M16 cable gland, external light curtain, external power management

6.3 Cable connections to the crimping force monitoring



NOTICE

Use the cable strain relief strip supplied to provide strain relief to the connecting cables.




Fig. 24: Control unit, connections

1. Cables for connecting the crimping force-monitoring devices to the FAST 3000 control cabinet
2. 24-V power supply for the crimping force monitoring devices
3. Cable conduit and bracket for the force signal cables (use an M5 bolt for strain relief of the cables and attach the bracket to a secure surface).
4. Port for the left hand CFM force load cell (when the port is not occupied, cover it with the closure cap supplied. Do not allow dirt to enter the plug connector socket).
5. Port for the right hand CFM force load cell (when the port is not occupied, cover it with the closure cap supplied. Do not allow dirt to enter the plug connector socket).
6. EtherCAT connection (use the "Fieldbus In" port of the left hand CFM device)
7. RJ-45 cable connecting the "Fieldbus Out" socket of the left hand crimping force monitoring device to the "Fieldbus In" socket of the right hand CFM unit

6.4 Switching on the FAST 3000



NOTICE

For further information on controlling the FAST 3000 without the two-hand control desk (see Section 10).



NOTICE

The FAST 3000 may not be initialized when a clamp or other part is inserted in the crimping cut-off head. Disregard of this rule can lead to breakage of the crimping jaws.

1. Switch the FAST 3000 on using the On/Off switch (1) on the control cabinet.




Fig. 25: Main switch control cabine

2. Wait until the FAST 3000 PLC has booted up.
After the blue illuminated button on the two-hand control desk has started to flash, press the green button (2) on the control cabinet door.
This indicates that the power stages of the drives are supplied with power. **CAUTION!** As long as no enable flag from the supervisory system is present and the bypass is not active, the power cannot be switched on (see Sections 7.4.7 and 10.1.3).




Fig. 26: Switch for voltage power of the output stages

3. Make sure that no clamp is present in the crimping cut-off head and the crimping jaws and the cut-off die can move freely.
4. To initialize the FAST 3000, press the blue flashing button (3) on the two-hand control desk.




Fig. 27: Initialization key 2 Manual operation

The FAST 3000 is ready for operation when the green indicator lamp on the two-hand control desk is lit.

6.5 Correctly positioning the FAST 3000

6.5.1 General instructions, positioning the FAST 3000 and WingGuard® clamp housing

CAUTION	
<p>Hazard due to incorrect tool positioning.</p> <p>The positioning of the FAST 3000 may be performed only by qualified personnel who have read and understood the Operating Instructions.</p> <p>The following procedure is applicable only if after the installation the housing of the WingGuard® strap clamp must be in the horizontal position. In all other cases the FAST 3000 must be set up manually.</p> <ul style="list-style-type: none"> ▶ Many different mounting conditions are possible. Therefore, you must check the correct alignment of the WingGuard® strap clamp. For this purpose, you must install test clamps after the initial setup. ▶ The horizontal and tilting movement of the FAST 3000 must not be obstructed by contact with external objects. ▶ During the closure procedure, the crimping cut-off head of the FAST 3000 must not touch any parts other than the WingGuard® clamp that is being closed. Disregard of this rule can lead to mechanical damage and poor connection quality of the WingGuard® strap clamp (see Fig. 27). ▶ In order to obtain the full benefit of the WingGuard® strap clamp, the WingGuard®-housing must be supported by the application (see Fig. 22 and Fig. 24). ▶ The WingGuard® strap clamp must not be mounted on a conical surface (see Fig. 25). ▶ Before positioning the FAST 3000, always remove the transport restraint. The transport restraint must not be mounted during the productions operation. ▶ We emphatically recommend that a suitable jig is employed for the entire application. Free-hand closure can result in the clamps not being properly closed. ▶ The base plate of the FAST 3000 must be securely attached to the support frame. This is applicable also to the validation phase of the application. ▶ Incorrect alignment of the machine can lead to a reduced residual force in the WingGuard® strap clamp. ▶ The control cabinet must be installed in an upright position. 	




Fig. 28: Example of correct installation of the WingGuard® housing and the crimping cut-off head (both are parallel)




Fig. 29: *Example of an incorrect non-parallel alignment of the WingGuard®-housing and of the crimping cut-off head*




Fig. 30: *Impermissible positioning of the WingGuard® housing on an application*




Fig. 31: *Impermissible application of the WingGuard® strap clamp on a conical surface*




Fig. 32: *The crimping cut-off head must be at a sufficient distance from the application. No collision with the application.*




Fig. 33: *The crimping cut-off head collides with the application*

Impermissible application. The same is true if two WingGuard® strap clamps are fitted too close to each other.




Fig. 34: Do not mount the WingGuard® strap clamp on a stepped application




Fig. 35: Avoid contact between the end face of the strap and the goods being strapped (example: goods being strapped (1))

6.5.2 Positioning of the FAST 3000 installation tool with the alignment aid



WARNING

Hazard due to a magnetic field.

The alignment aid is held against the crimping cut-off head by a strong magnet. Personnel fitted with a heart pacemaker must maintain a suitable distance from the alignment aid.

1. Ensure that the base plate of the FAST 3000 is aligned horizontally.
2. Fix the customer application in the nest provided by the customer. Remove the transport restraint (2).
3. Attach the alignment aid (1) to the crimping cut-off head and satisfy yourself that both pins are correctly positioned.




Fig. 36: Alignment tool

4. Displace the FAST 3000 horizontally so that the indicated dummy housing (3) of the alignment aid (1) is correctly positioned relative to the intended position of the WingGuard® housing. In most applications this is the 12 o'clock position.




Fig. 37: Setup help

5. Make sure that the FAST 3000 has sufficient space (~ 50 mm) for attaching the positioning stop (3) to the guide rail.





Fig. 38: Positioning stop

6. Adjust the height of the tool so that the bubble of the spirit level is exactly central between the two vertical lines (horizontal alignment). The correct horizontal position must be maintained at all times.
7. Mount the positioning stop on the tool so that the both the vibration-absorbing rubber pads rest lightly against the tool.
8. Tighten the attachment screw (4) on the positioning stop (3) to a torque of 5 Nm.




Fig. 39: Setup aid Horizontal alignment

9. Check the horizontal alignment yet again. The tool must rest lightly against the positioning stop and against the alignment aid on the application.
10. Remove the alignment aid.
11. Check the alignment of the FAST 3000. To do this, install several WingGuard® clamps on your application. If the WingGuard® strap clamp is not in 12 o'clock position, manually correct the horizontal alignment of the FAST 3000.
You can check the correct vertical positioning of the FAST 3000 by reference to the spirit level which is mounted at the top of the tool. To do this, position the crimping cut-off head on the clamp housing of the WingGuard® clamp. The spirit level must now be correctly aligned.

The FAST 3000 is now correctly positioned.

6.5.3 Dimensions for correctly positioning the FAST 3000

	CAUTION
	<p>Hazard due to the machine being incorrectly installed.</p> <p>The following drawing relates to installation situations where the surrounding surfaces of the WingGuard® strap clamp housing are symmetrical (cylindrical surfaces)</p> <ul style="list-style-type: none"> ▶ If the surfaces on which WingGuard® strap clamp housing is installed are asymmetrical (elliptical or the like), the correct position of the WingGuard® strap clamp housing and the FAST 3000 must be determined by means of tests. ▶ The horizontal and tilting movement of the FAST 3000 must not be obstructed by contact with external objects. ▶ The crimping cut-off head and the clamping unit of the FAST 3000 must not touch any parts other than the WingGuard® clamp that is being closed. Disregard of this rule can lead to mechanical damage and poor connection quality of the WingGuard® strap clamp. ▶ Ensure suitable design of the customer-provided waste channel. ▶ Always remove the transport restraint before positioning the FAST 3000. ▶ We emphatically recommend that a suitable jig is employed for the entire application. Free-hand closure can result in the clamps not being properly closed.




Fig. 40: Alignment tool

Comment: On request, Oetiker will provide a 3D-CAD model of the FAST 3000.

Arrangement of the waste channel

It must be ensured that no foreign parts touch the clamping unit and distort the measured closing force. Among other things, this concerns the customer-provided waste channel. The below illustrations show the recommended design of the waste channel.







Fig. 41: Waste channel

6.6 Normal operation (production)

	<p>WARNING</p> <p>Crush hazard at the WingGuard® strap clamp. Fingers can be crushed when the two-hand start buttons are pressed or when a start is initiated by an external control.</p> <ul style="list-style-type: none"> ▶ When starting the clamping cycle, keep your fingers away from the clamp. <div data-bbox="488 1290 1082 1682"> </div>
--	--

	<p>WARNING</p> <p>Crush hazard at moving parts. The FAST 3000 may be used only when all covers are correctly fitted and bolted in place!</p>
--	--

	WARNING
	<p>Crush hazard due to positioning the hands under the installation tool.</p> <p>► Never reach under the installation tool while it is in operation.</p> <div data-bbox="400 360 639 658" data-label="Image">  </div>

	CAUTION
	<p>Danger due to parts being flung from the machine.</p> <p>If parts become defective while the machine is in during operation, parts may become loose and be flung from the machine.</p> <p>During operation and maintenance of the machine, always wear safety glasses</p>

1. Check that the process parameters are set to the correct values for your application (see Section 5.1).
2. Place the clamp around the parts to be connected and secure the customer application in the nest provided by the customer.
3. Hold the machine by the handle and pull it in the direction of the clamp. When doing so, guide the tail of the OETIKER PG270 WingGuard® strap clamp into the bottom slot on the crimping cut-off head.





Fig. 42: Mount Wingguard clamp

4. Push the OETIKER PG270 WingGuard® strap clamp into the tool as far as possible.

A sensor detects the correct positioning and confirms this with two LED lamps on the front cover (slowly flashing green light). Now the clamp can be locked by pressing the button on the top of the handle. Pressing the button a second time releases the lock.





Fig. 43: Locking clamp

Once the strap is locked (as shown by the two LEDs on the front cover) lighting up continuously, the installation of the OETIKER PG270 WingGuard® strap clamp can start.

If the clamp tail was inserted insufficiently far, the LEDs will flash at rapid intervals. In this case the button must be pressed again to release the clamp, the tail must be pushed in further and locked again.

	NOTICE
	<p>Risk of an increased error rate.</p> <p>► Do not touch the FAST 3000 until the closure procedure is completed.</p>

5. Start the installation by pressing both the left and right buttons (1) on the two-hand control desk simultaneously. This initiates closure of the clamp. At the end of the closure procedure the clamp is released and the tool can be pushed back into the output position.
6. Remove the installed assembly and start another cycle.




Fig. 44: Trigger buttons 2 hand operation

	NOTICE
	<p>After a defective clamp closure, always check the crimping jaws for damage.</p>

	<p>NOTICE</p> <p>If the tail sensor detects no tail, the clamping push button is deactivated.</p>
--	--

	<p>NOTICE</p> <p>You must depress both start buttons quickly and simultaneously. Otherwise the warning “War_2 Check button contacts occurs” is output.</p>
--	---



6.7 Laboratory mode (password-protected)


You can switch into the password-protected laboratory mode and choose between 1-hand control or foot pedal control. Laboratory mode can be used only for a limited number of connections and activated for only a limited period of time (see Section 7.4.3).

	<p>WARNING</p> <p>Hazard due to unqualified personnel.</p> <p>Laboratory mode can be used only under laboratory or test conditions where there is no alternative. The personnel must have been trained to use of the FAST 3000 with an increased level of care.</p>
--	---

	<p>WARNING</p> <p>Crush hazard at moving parts.</p> <p>The FAST 3000 may be used only when all covers are correctly fitted and bolted in place.</p>
--	---

	<p>WARNING</p> <p>Crush hazard at the WingGuard® strap clamp.</p> <p>Fingers can be crushed when the START button is pressed or when a start is initiated by an external control.</p> <ul style="list-style-type: none"> ▶ When starting the clamping cycle, keep your fingers away from the clamp. <div data-bbox="339 1603 935 1995"> </div>
--	---

	WARNING
	Crush hazard due to positioning the hands under the installation tool.
	<p>► Never reach under the installation tool while it is in operation.</p>
	

	CAUTION
	Danger due to parts being flung from the machine.
	If parts fracture while the machine is in operation, parts may become loose and be flung from the machine.
	<p>► During operation and maintenance of the machine, always wear safety glasses</p>

	NOTICE
	Only one laboratory mode can ever be activated at a time. Depending on the setting you can then initiate a cycle by pressing a start button or pressing the foot pedal.

6.7.1 One-hand operation

1. Check that the process parameters are set to the correct values for your application.
2. Activate the one-hand operation:
 - Switch to “operating mode”, activate “laboratory mode” and “one-hand operation”.
 - In order to access laboratory mode you must be logged in as Superuser.
3. Place the clamp around the parts to be connected.








Fig. 45: Laboratory operation one hand operation

4. Hold the machine by the handle and pull it in the direction of the clamp. When doing so, guide the tail of the OETIKER PG270 WingGuard® strap clamp into the bottom slot on the crimping cut-off head.



5. Push the OETIKER PG270 WingGuard® strap clamp into the tool as far as possible.

A sensor detects the correct positioning and confirms this with two LED lamps on the front cover (slowly flashing green light). Now the clamp can be locked by pressing the button on the top of the handle. Pressing the button a second time releases the lock.



If the sensor does not detect a tail, the locking button will not work.

Once the strap is locked (as shown by the two LEDs on the front cover lighting up continuously) the installation of the OETIKER PG270 WingGuard® strap clamp can start.

If the clamp tail was inserted insufficiently far, the LEDs will flash at rapid intervals. In this case the button must be pressed again to release the clamp, the tail must be pushed in further and locked again.



NOTICE

Risk of an increased error rate.

- ▶ Do not touch the FAST 3000 until the closure procedure is completed.

- Start the installation. Press either the left-hand or right-hand button on the two-hand control desk for at least 2.5 seconds.

After the buzzer has sounded 3 times the clamp will start to close. Once the closure procedure is complete, the clamp is released again.




Fig. 46: Trigger buttons 2 hand operation

6.7.2 Foot pedal

- Check that the process parameters are set to the correct values for your application.
- Activating foot pedal mode
 - Switch to “operating mode”, activate “laboratory mode” and “foot pedal”.
 - In order to access laboratory mode you must be logged in as Superuser.
- Place the clamp around the parts to be connected.








Fig. 47: Laboratory operation one hand operation

- Hold the machine by the handle and pull it in the direction of the clamp. When doing so, guide the tail of the OETIKER PG270 WingGuard® strap clamp into the bottom slot on the crimping cut-off head.



5. Push the OETIKER PG270 WingGuard® strap clamp into the tool as far as possible.

A sensor detects the correct positioning and confirms this with two LED lamps on the front cover (slowly flashing green light). Now the clamp can be locked by pressing the button on the top of the handle. Pressing the button a second time releases the lock.



If the sensor does not detect a tail, the locking button will not work.

Once the strap is locked (as shown by the two LEDs on the front cover lighting up continuously) the installation of the OETIKER PG270 WingGuard® strap clamp can start.

If the clamp tail was inserted insufficiently far, the LEDs will flash at rapid intervals. In this case the button must be pressed again to release the clamp, the tail must be pushed in further and locked again.



NOTICE

Risk of an increased error rate.

- Do not touch the FAST 3000 until the closure procedure is completed.

6. Start the installation. Depress the foot pedal down to the middle position for at least 2.5 seconds. After the buzzer has sounded 3 times the clamp will start to close. Once the closure procedure is complete, the clamp is released again.








Fig. 48: Foot pedal


6.8 Special operating modes (password-protected)

These operating modes are not intended for closing clamps, instead they are only for testing the positions and forces during maintenance and repair work, and for quality assurance.

	WARNING
	<p>Crush hazard at the WingGuard® strap clamp. When triggering the functions described below, fingers may be crushed by the WingGuard® strap clamp.</p> <ul style="list-style-type: none">▶ When starting functions, keep your fingers away from the clamp. <div></div>

	WARNING
	<p>Crush hazard at moving parts.</p> <ul style="list-style-type: none">▶ Use the FAST 3000 only when all covers are correctly fitted. and bolted into place.

	WARNING
	<p>Hazard due to positioning the hands under the installation tool.</p> <ul style="list-style-type: none">▶ Never reach under the installation tool while it is in operation. <div></div>

	CAUTION
	<p>Danger due to parts being flung from the machine. If parts fracture while the machine is in during operation, parts may become loose and be flung from the machine.</p> <ul style="list-style-type: none">▶ During operation and maintenance of the machine, always wear safety glasses.

6.8.1 Deblocking

NOTICE

In certain situations, tool initialization cannot be performed since it might lead to mechanical damage.

► Use the unlocking function of the FAST 3000 only when tool initialization cannot be performed.




Fig. 49: Deblocking

1. Switch to the “operating mode” tab.
2. If the emergency stop-button is set, unlatch it.
3. Press the “Deblocking” button (1).
The strap of the WingGuard® strap clamp will not be cut off from the FAST 3000, but not crimped. The residual piece of strap is discarded.
4. Press the blue “initializing” button on the two-hand control desk.

The tool is now ready for operation.

6.8.2 “Manual Drive” Operation



NOTICE

Possible damage to the FAST 3000

In this mode, the jaw overload protection feature is not active




Fig. 50: Drive manually

1. Activating operating mode.
 - Switch to “operating mode” and activate “manual drive”.
 - In order to access manual drive mode you must be logged in as Superuser.
2. Control the drives by pressing one of the pre-defined positions (1, 2).
For further Information see Section 7.4.3.

6.8.3 Setting the force offset to zero



NOTICE

Under various conditions the force measured by the force load cell in the clamping unit can vary due to changes in temperature. To compensate for this you can set the measured to zero when there is no force measured by the unloaded force load cell. If the value is found to deviate from zero by more than 20 N, we recommend that the force offset is set to zero. We recommend that the force offset is checked every week.




Fig. 51: Zero adjustment

1. Switch to the “Settings” tab.
 - In order to access the zero offset tab you must at least be logged in as Operator.
2. Select “Force verification” and “Zero balance”
 - ▶ Start the procedure by pressing “Zero balance”.
 - The tool will move so that the force load cell is unloaded.

The “Actual force average value” indicates the force actually measured. If you wish compensate an existing offset, press “Set offset to zero”.

- ▶ Press “Quit routine”
 - The tool returns to the home position.

For further information see Section 7.4.7.

6.8.4 Verifying the pulling force



NOTICE

To verify the correct operation of the load cell, verify the measured force at least once a week with an Oetiker CAL 01. At a set force of 1850 N, the force measured by the OETIKER CAL 01 must be within a tolerance of ± 50 N.

The tension band must be replaced after approx. 50 verifications.

Setting of CAL 01: SKS mode: hold-ME-EL / average
(see operating manual OETIKER FAST 3000)

1. Activate the verification.
 - Switch to the “Settings” tab.
 - In order to access force verification mode you must be at least logged in as Operator.
2. Press the “Force verification” button.
3. Press the “Pulling unit” button.
4. Press the “Force verification” button.




Fig. 52: Verify traction

Adjust Insert closing force verification unit (1) ting the closing force verification unit.

1. Pull the locking hook (2) backwards.
2. Insert the end of the tension band completely into the caulking separating head.
3. Engage the locking hook (2) and then release it.




Fig. 53: SKS Tensile force sensor

The cams of the verification unit must be correctly positioned in the holes of the caulking separating head. The locking hook must be engaged.

Positioning of the locking hook - ok




Fig. 54: SKS Correct positioning traction sensor

Positioning of the locking hook - incorrect





Fig. 55: SKS Incorrect positioning tensile force sensor

4. Press the button at the top of the handle.



5. Press on “Target force” to change the verification force to the desired value.
6. Press on “Verification activation”.
7. Input the force measured by the CAL 01 into the “Ext. Force value “CAL”” field. The value that is input will be saved in the verification log.
8. Press “Quit routine”.
9. Remove verification unit from the tool.
10. If the force measured by the CAL 01 is outside the tolerance, see Section 9.5 for further procedure.





Fig. 56: Verification traction

Removing the closing force verification unit (1)

1. Pull the locking hook (2) backwards.
2. Pull the verification unit (1) out of the caulking head. separating head.



6.8.5 Crimping force monitoring verification



NOTICE

To check the correct operation of the CFM force load cell, we recommend that the measured force is verified at least once a week, using an Oetiker CAL 01.

If the force is set to 1600 N, the force measured by the CAL 01 must be within a tolerance of ± 50 N of that value.

Setting the CAL 01: SKS mode: hold-ME-EL / average (see Section 7.4.7)



NOTICE

During the verification, do not hold the SKS firmly in the hand, since this can corrupt the measured result.

1. Activate the force verification.
 - Switch to the “Settings” tab.
 - In order to access CFM force verification mode you must at least be logged in as Operator.
2. Press the “Force verification” button.
3. Press the “Crimping” button.
4. Press the “Force verification” button.



Fig. 57: Verification crimping force

5. Set the “Target force” to the desired value, e.g. 1600 N \pm 50N.
6. Position the SKS 01 with the correctly installed CFM verification jaws (only use CFM-Verification-Jaw-Kit, 13500237) under the crimping cut-off head, as shown in the photo on the right.
7. Press the strap locking button on the handle, keeping the SKS01 in this position.
8. Keep the SKS 01 in this position until the CFM measured force achieves the force target value. After a few seconds, the SKS 01 will be released.
9. Input the force measured by the CAL 01 into the “Ext. Force value “CAL”)” field. The value that is input will be saved in the verification log.
10. Press “Quit routine”.
The values are written to the relevant log file.




Fig. 58: Positioning SKS crimping force

6.8.6 Adjusting the crimping force monitoring



NOTICE


The definition of the envelope curves for the crimping force monitoring devices is based on the force curve of the Wing-Guard® strap clamps for various different clamps, clamp straps and batches of steel. It is therefore recommended to use the factory settings for as long as possible so as to avoid faults in material due to differing melt batches.



NOTICE

Before making any adjustments, make sure that there is no problem other than the clamp batch. This is done by the following tests:

- ▶ Visual inspection of the crimping jaws. No chips or visible wear.
- ▶ Check the tightening torque of the two marked screws (1): Target 7–9 Nm.
- ▶ Remove the crimping force sensors; check to see that the area where they are mounted is free from particles. Reinstall the sensors.
- ▶ Measure the distance between the crimping jaws: Target 3 ± 0.1 mm (see Section 9.2.5).
- ▶ Check the CFM correlation factor:
On both CFM devices perform Setup / Global / Channel-Y / Channel-Y / Right arrow. The sensitivity should be about -1.2 pC/N.
- ▶ Check the crimping force (see Section 5.2.1).
- ▶ Set the crimp closing force in Newtons: 800 N
- ▶ Use the closing force verification unit to check the closing force (see Section 6.8.4).
- ▶ Check the positioning of the FAST 3000 installation tool (12 o'clock position) (see Section 6.5).



It is strongly recommended to use for EO 2, the second envelope curve, a smaller value for DY, for example 180.

It is likely, that these adapted curves will lead in production after a while to an increased rate of NOK closures again, due to variations of the WingGuard® strap clamp. In this case, check first if the standard settings work well.

A backup of the standard settings can be found on the monitoring devices under MP15, measurement program 15.

- ▶ Use the copy and paste function on the CFM devices.



NOTICE

If the closing force deviates from the factory setting of 1850 N you may have to teach new reference curves.

Teaching the crimping force monitoring

Each monitoring device must be set separately.

1. Select “Settings” and “Parameter Tool” on the FAST 3000 touch panel.
Select “CFM Teaching mode”.
In order to access CFM Teaching mode you must be logged in as Superuser.




Fig. 59: Setting parameters

Separately on each of the two crimping force monitoring devices:

2. Select “Setup” on the welcome screen.
3. Log in as Superuser (password-protected).
4. Select “MP Setup”.




Fig. 60: Login CFM

5. Select MP-00.



Fig. 61: Measuring program

6. Select “Evaluation”.




Fig. 62: Evaluation criteria

7. If the message “Retain the curve” appears on the screen, select “No”.
Select “Delete the curve”.

8. Close a WingGuard® strap clamp.

9. If the WingGuard® strap clamp closes correctly, press “Yes”, otherwise press “No”.

10. Repeat steps 11 and 12 four times, in order to record at least five OK reference curves.

11. Select the button “Forwards”  .









Fig. 63: Envelopes

12. Select the EO that you wish to change (01 or 02 for the envelope curves).
13. Select the button “Forwards” .
14. If necessary, adjust the evaluation tolerance by editing DY.
15. Select “Recalculate”.
16. If necessary, repeat steps 14 to 17 for further Eos (use the “Back” button  to select a different EO).
17. Confirm the new settings by pressing the check .
18. Press the button  twice to return to the welcome screen.
19. After the teaching process, deactivate the mode again. If this is not done, the relevant pop-pup window will appear periodically.
20. On the touch panel of the FAST 3000: Be sure to set “CFM Production mode” to “On”.
21. Log out of the FAST 3000 and also log out of the FAST 3000 as Superuser.




Fig. 64: Envelopes

Adjusting the crimping force monitoring tolerance

Each monitoring device must be set separately.

1. Select “Setup” on the welcome screen.
2. Log in as Superuser (password-protected).



Fig. 65: Measuring program

3. Select “MP Setup”.
4. Select MP-00.
5. Select “Evaluation”.




Fig. 66: Criteria

6. Select the button “Forwards” .









Fig. 67: Envelope

7. Select the EO that you wish to change (01 or 02 for the envelope curves).
8. Select the button “Forwards” .



9. Adjust the evaluation tolerance by editing DY.
 10. Select “Recalculate”.
 11. If necessary, repeat steps 7 to 10 for further EOs (use the “Back” button  to select a different EO).
 12. Confirm the new settings by pressing the check .
- Press the  button twice to return to the welcome screen.




Fig. 68: Envelope

6.8.7 Changing the measurement program

The active measurement program is always measurement program 0!

The measurement program must be changed on each monitoring device separately.



NOTICE

The purpose of the measurement program 0 is to evaluate the closing force curves. A backup is saved under measurement program 15.

1. Press the emergency stop-button
2. Select "Setup" on the welcome screen.
3. Log in as Superuser (password-protected).




Fig. 69: Login

4. Select "MP Manager"
5. Select to the measurement program to be copied:




Fig. 70: Measuring programs

6. Select copy




Fig. 71: Measuring programs

7. Select the Measurement program 00




Fig. 72: Measuring programs

8. Select paste




Fig. 73: Measuring programs

9. Confirm the new settings by pressing the check



- 10. log out of the monitoring devices.
- 11. Unlatch the emergency stop-button
- 12. Initialize the FAST3000

6.8.8 Loading new settings/measurement programs to the CFM units





NOTICE

If Oetiker recommends an optimized setting of the CFM devices, this setting can be transferred to the CFM devices according to the following procedure.

For communication with the CFM units both participants (PC and device) must be within the same network.

- ✓ A PC must be available for loading settings and programs.
 - ✓ The maXYmos software is available. The software is part of the FAST 3000 scope of delivery.
 - ✓ The CFM settings file must be available in zip format. The file is provided by Oetiker.
 - ✓ An Ethernet cable must be available.
1. Connect the laptop to the CFM device, using a LAN cable. Use the Ethernet port of the CFM device.
 2. Start the maXYmos software.
The currently connected device is displayed in the list of units (4) on the left, and is identified with a green dot.
 3. If necessary, use the “Languages” tab (1) to change the language settings.
 4. Double click on the device and acknowledge to log-in message.
 5. If the connection is not established automatically, proceed as follows:
 - Go to “New device” (2).
 - Enter the network address.
 - Confirm with “OK”.
 6. Select “Restore” (3), to load new settings to the device.
 7. Select the file with the new CFM settings.
 8. Select the settings to be loaded on the CFM device and deselect all others. The measuring programs 0 (5) and 15 (6) are activated by default.
 9. Confirm the selection with “OK” (7).
A message acknowledging the input will appear.
 10. Confirm the message with OK in order to load the new settings on to the device.



Only on the CFM device for the right-hand side:

11. Select “Setup” (8).





Fig. 74: Software CFM

12. Select the measurement programs for which the name are to be changed (9).



13. Switch to the "General" tab (10).
14. Rename the measurement program by replacing "Le" with "Ri" (11).
15. Confirm with OK (12).
A message acknowledging the input will appear.
16. Confirm the message with OK in order to load the new settings on to the device.




Fig. 75: Software CFM



NOTICE

The purpose of the measurement program 0 is to evaluate the closing force curves. A backup is saved under measurement program 15.

7 GUI

Control and monitoring of the FAST 3000 can be performed either by means of the optional touch panel, a laptop or computer.



WARNING

Danger of starting up unexpectedly

Only one operator control unit may be used for the FAST 3000. For reasons of safety, simultaneous control by the optional touch panel and a computer is not permitted.

7.1 Touch Panel

The available touch panel has software pre-installed. Using this software, all the main functions of the FAST 3000 closure procedures can be controlled and monitored. The output of images and data is the same as for a computer with a web browser.

7.2 Computer

You can connect the FAST 3000 to any standard computer or laptop with a RJ45 network port and a web browser.

1. Go to the settings for your LAN connection and open the TCP/IPv4 settings.
2. Set the IP of your devices to the value 192.168.10.xx,
Default IP-adresses:
 - 192.168.10.50 Ethernet Port PAC320 X2 (Laptop and Ethernet/IP)
 - 192.168.10.51 Ethernet Port PAC320 X3 (Touch-Panel)
 - 192.168.10.40 Touch Panel
 - 192.168.10.60 Ethernet Port CFM1
3. Set the subnet mask to the value 255.255.255.0.
4. Then you can input <http://192.168.10.50:8080/webvisu.htm> into your web browser and access the control of the FAST 3000. For more information see *Section 10*.

7.3 GUI Layout

The main view of the FAST 3000 visualization is as follows:




Fig. 76: Structure GUI

1. User management / Language selection / Date & Time
2. Tabs
3. Content of the tabs
4. Status bar

7.4 Menu structure

7.4.1 Welcome screen



Fig. 77: Startup image

1	- Arrow - Symbol for the WingGuard® strap clamp	<ul style="list-style-type: none"> - No WingGuard® strap clamp present in the FAST 3000 - WingGuard® strap clamp present in the FAST 3000
2	Status	Shows the status of the two electrical drives of the FAST 3000
3	Operating mode	Automatic mode or manual operation of drives; local or PLC
4	Messages	Error messages etc.
5	User	Select the user level
6	Oetiker Symbol	Press the symbol to log out from a higher user level
7	Target closing force	Set closing force in Newtons
8	Cycle time	Duration in seconds of the last clamp closure from start to readiness for the next start
9	Actual closing force	Force in Newtons applied during the last clamp closure
10	Pulling distance	Pulling travel in mm when closing the WingGuard® strap clamp

7.4.2 Closure data (a password is necessary to change the values)

All the settings for the installation of an OETIKER PG270 WingGuard® strap clamp are displayed under the "Closure data" tab. This tab can be accessed without using a password. Provided you are logged in you can change the values.




Fig. 78: Closing process Tractive force curve

Closing Force	Set the closing force in Newtons
Closing force tolerance	Set the closing force tolerance in Newtons
Switch point reduction	The force in Newtons below the set closing force at which the speed is reduced
Speed Phase 1	Speed during the first closing phase in mm/s
Speed phase 2	Speed during the second closing phase in mm/s
Closing force holding time	Holding time in milliseconds during which the closing force is held within the closing force tolerance.
ID	Name of the data record that is displayed
Cycle time	Duration in seconds of the last clamp closure from start to readiness for the next start
Actual closing force	Force in Newtons applied during the last clamp closure
Pulling distance	Pulling travel in mm when closing the WingGuard® strap clamp
Diagram	Shows how the force is/was achieved during closure

7.4.3 Operating mode



The operating mode can be selected using the “Operating mode” tab. The modes available are: Normal operation, Laboratory mode, Manual operation and Deblocking function.


Laboratory mode (password-protected)

	WARNING
	<p>Hazard due to unqualified personnel.</p> <p>Laboratory mode can be used only under laboratory or test conditions where there is no alternative. The personnel must have been trained to use of the FAST 3000 with an increased level of care.</p>

	WARNING
	<p>Crush hazard at the WingGuard® strap clamp.</p> <p>When triggering the functions described below, fingers may be crushed by the WingGuard® strap clamp.</p> <ul style="list-style-type: none">▶ When starting functions, keep your fingers away from the clamp.




	WARNING
	<p>Crush hazard at moving parts. The FAST 3000 may be used only when all covers are correctly fitted and bolted in place.</p>

	CAUTION
	<p>Crush hazard due to positioning the hands under the installation tool. Never reach under the installation tool while it is in operation.</p> <div style="text-align: center;">  </div>

	CAUTION
	<p>Danger due to parts being flung from the machine. If parts become defective while the machine is in during operation, parts may become loose and be flung from the machine.</p> <p>► During operation and maintenance of the machine, always wear safety glasses.</p>

Laboratory mode (password-protected)

OETIKER
2022/08/19 05:56:53

 User: Superuser
 


Operating mode ↶

Laboratory mode
Manual drive
Free state pulling force
IO - test

Laboratory mode

Time laboratory mode

60 min

Max. pieces in LabMode

50

one hand operation

Foot pedal

Deblocking
Step by Step

Remaining time

0 min

|

0

Remaining pcs in LabMode

Next step

Local / Automatic
▶ Waiting for clamp and fixation....

Cycle counter 6522

Service counter 98235

Fig. 79: Lab mode

Laboratory mode	Activating and deactivating laboratory mode
Time laboratory mode	Specify the duration in minutes, after which laboratory mode is deactivated automatically
Remaining time [min]	Time remaining until automatic deactivation of laboratory mode
Max. pieces in LabMode	Set the counter to the maximum number of pieces to be closed, after which laboratory mode is deactivated automatically
Remaining pcs in LabMode	Displays the remaining number of closures in laboratory mode
one hand operation	Activate this in order to use one-hand operation in laboratory mode
Foot pedal	Activate this in order to use the foot pedal in laboratory mode

Step by Step mode

Step by step	Activating / deactivating / Step by Step mode
Next Step	Perform the next step (the start of the cycle is triggered by the start signal (2-Hand triggering, industrial communication))

Deblocking (emergency scenario)

Deblocking	Start deblocking (there is no guarantee this will work in every case) <ul style="list-style-type: none"> • The motion link moves to the safe cutting position • The pulling unit moves to the ejection position
-------------------	---

Manual mode (password-protected)

	WARNING
	<p>Crush hazard at moving parts.</p> <p>For maintenance work it may be necessary to operate the tool in the operating mode “Manual operation” and without covers. Do this only if you have no alternative, and take the utmost care when doing so.</p> <p>► On completion, immediately refit the covers.</p>

	CAUTION
	<p>Hazard due to incorrectly closed clamps.</p> <p>The “Manual operation” function must not be used for closure of clamps. This function may be used only for the rectification of faults.</p>

	CAUTION
	<p>Damage to the device due to improper use of the manual mode.</p> <p>► Before each use of the commands “Crimp position” or “Cutting position” make sure that nothing is between the jaws.</p>

Manual mode (password-protected)




Fig. 80: Manual driving

Motion link (left-hand side)

Initializing	Initializing the motion link: Setting the zero
Home position	Motion link in the home position (if there is a WingGuard® strap clamp in the clamping unit, this is secured.)
Insert position	Motion link in the position that allows the clamp to be inserted
Crimp position	Motion link in the crimping position
Cutting position	Motion link in the cutting position
Safe cutting position	Motion link moves directly into the cutting position, skips the crimping position
Actual position	Position of the motion link in millimeters

Pulling unit (right-hand side)

Initializing	Initializing the pulling unit: Setting the zero point
Start pos.	Pulling unit in the start position
Eject position	Pulling unit in the position that allows the remaining strap to be ejected
Actual position	Position of the pulling unit in millimeters
Service pos.	Pulling unit in the position that allows the strap sensor to be set

7.4.4 Free state pull force test

NOTICE

The operating mode “Free state pull force test” is available for testing the internal friction of the WingGuard® clamp. To do this, the WingGuard® clamp is closed without any strap-ping present, and the maximum no-load closing force is determined.

2022/08/19 08:23:09
User: Superuser
🇬🇧

Operating mode

Laboratory mode
Manual drive
Free state pulling force
IO - test

Start free state p. f.

Target position

Speed

Motion link:

Powered ✓

Referenced ✓

Pulling unit:

Powered ✓

Referenced ✓

Maximal force

0 N

Pulling unit actual po...

-0.4 mm

Local / Manual
▶ System not initialized, please initialize

Cycle counter 6525

Service counter 98232

Fig. 81: Friction test

Start freestate p.f.	Start of the free state pull force test
Target position	End position of the pulling motor during the free state pull force test
Speed	Speed of the pulling unit during the free state pull force test
Maximum force	Maximum force applied during the free state pull force test
Pulling unit actual posi.	Pulling unit actual position

Sequence of the free state pull force test

- ✓ The FAST 3000 must be referenced.
- 1. Activate the function by pressing the “Start free state pull force test” button.
- 2. Insert the clamp.
- 3. Fix the clamp by pressing the button on the handle of the tool.
- 4. Start the test by pressing the start buttons on the two-hand control desk.
The pulling unit moves at the defined speed towards the end position. The maximum tensioning force applied during this time is determined. At the end, the strap is cut off.

7.4.5 I/O Test

The purpose of the “I/O Test” menu is to test the basic functions of the inputs to the FAST 3000. The depiction of the individual inputs are distributed across three pages. When the “I/O Test” menu is open, the individual buttons have no further functions.




Fig. 82: IO Test

Switch emergency stop	Status of the 2-channel emergency stop circuit; two-hand control desk and external emergency stop switch
Switch Acknowledge	Red acknowledgement button on the two-hand control desk
Switch Initialization	Blue initialization switch on the two-hand control desk
Switch start 1	2-channel start button on the two-hand control desk
Switch start 2	2-channel start button on the two-hand control desk
Foot pedal	2-channel foot pedal
Switch band locking	Clamp locking
band sensor existing	Clamp present sensor
Holdup sensor	Holdup sensor for monitoring the pulling motor
Light curtain 1	Light curtain
Light curtain 2	Light curtain
power enable ext.	External power available for the servo amplifier





Fig. 83: IO Test Digital Signals Industrial Communication

Bus Start	Start command via Profinet or Ethernet/IP	
Bus Stop	Stop command via Profinet or Ethernet/IP	
Bus lock clamp	Locking the clamps via Profinet or Ethernet/IP	
Bus Acknowledge	Acknowledgment of error messages via Profinet or Ethernet/IP	
Bus Init	Initializing via Profinet or Ethernet/IP	
Bus Ack. Msg Band rem.	Acknowledgment of the message "Remove strap" via Profinet or Ethernet/IP	
Bus Power enable	Enable connection of the power supply to the motors from the supervisory system via Profinet or Ethernet/IP	
Bus Bypass power drive	Connection of the power supply to the motors from the supervisory system via Profinet or Ethernet/IP	
Bus Deblocking	Deblocking of the tool via Profinet or Ethernet/IP	
Statusword	Status words (status word 1 and status word 2) generated by the tool (32-bit integer value)	
Control word	Control word sent by the external control unit to the FAST 3000.	
State communication	Status of the Profinet communication	Green: The controls are connected to a supervisory control unit White: The controls are not connected to any other control unit
	Status of the Ethernet/IP communication	Green (1): The controls are connected to a supervisory control unit White (1): The controls are not connected to any other control unit Red (2): There is communication error White (2): Communications are operating correctly

IO Test Communication Industrial Network



Signalization




Fig. 84: IO Test Industrial Communication

1. Status word
2. Signal inactive
3. Signal active
4. Signal not used
5. Value as integer

For every manual function are displayed the status word and the command word as integer value. All bit also displayed green or grey the state.




Fig. 85: IO Test Digital In Output Signals

I/O start 1	Hardwire I/O start channel 1
I/O start 2	Hardwire I/O start channel 2
I/O stop 1	Hardwire I/O stop channel 1
I/O stop 2	Hardwire I/O stop channel 2
I/O init	Hardwire I/O initializing
I/O Ack	Hardwire I/O acknowledgement
I/O Band lock	Hardwire I/O strap clamp



Fig. 86: Status EtherCAT devices

EtherCAT running	Green: Bus EtherCAT is running Red: Bus EtherCAT is not running
PACIO_01	Green: IO module1 OK Red: IO module1 fault
PACIO_02	Green: IO module2 OK Red: IO module2 fault
ClipX	Green: ClipX amplifier OK Red: ClipX amplifier fault
L7NH Motion link	Green: Servo drive motion link OK Red: servo drive motion link fault
L7NH Pulling unit	Green: Servo drive pulling unit OK Red: servo drive pulling unit fault
CFM1	Green: CFM1 (1st Kistler device) OK Red: CFM1 (1st Kistler device) fault
CFM2	Green: CFM2 (2nd Kistler device) OK Red: CFM2 (2nd Kistler device) fault

7.4.6 Logbook

Process log

The data on the most recent clamp closures are shown in the “Data log” tab. This menu can be accessed without using a password.

Date/Time	ID	Target force	Actual force	Pulling distance	Status	CFM	Error
2018/07/04 13:21:38	T01_P05_689	1850.0	1871.3	9.0	OK	OK	--
2018/07/04 13:20:26	T01_P05_688	1850.0	1868.4	9.0	OK	OK	--
2018/07/04 13:16:59	T01_P05_687	1850.0	-	-	NOK	-	205 / 206 / 214 / 105
2018/07/04 13:16:52	T01_P05_686	1850.0	1873.1	9.0	OK	OK	--

Fig. 87: LOG process log

Date/Time	Data and time of the installation
ID	Identification ID of the closure
Target force	Target force value in Newtons
Actual force	Tensioning force actual value in Newtons
Pulling distance	Pulling travel in mm when closing the WingGuard® strap clamp
Status	Closing status as viewed by the tool, evaluated by control of the installation tool (OK or not OK) based on pre-defined values
CFM	OK or not OK from the crimping force monitoring. “-”, if the CFM is not in production mode
Error	Error number if the closure was not OK; the error are listed, e.g. 205 / 206 / 214 /...

Error log / Warning log

The most recent errors of the tool are displayed in the “Error log” tab. This menu can be accessed without using a password.



OETIKER 2018/06/27 11:36:25 User: Superuser

Logbook

Process Log Error / Warnig Log Verification Log Service Log

Date/Time	additional information
2018/06/27 11:33:52	ToErr_5 Drive error active
2018/06/27 11:33:52	ToErr_6 Emergency circuit open
2018/06/27 11:33:52	ToErr_14 Emergency stop
2018/06/27 11:33:52	War_9 Drives Tool not powered
2018/06/27 11:33:24	ToErr_5 Drive error active
2018/06/27 11:33:24	ToErr_6 Emergency circuit open
2018/06/27 11:33:24	ToErr_14 Emergency stop
2018/06/27 11:33:24	War_9 Drives Tool not powered
2018/06/27 11:32:59	PrErr_4 Crimping CFM1 envelope 2
2018/06/27 11:32:59	PrErr_5 Crimping CFM1 NoPass
2018/06/27 11:32:59	PrErr_8 Crimping CFM2 envelope 2

Local / Automatic ▶ Waiting for clamp and fixation.... Cycle counter 675 Service counter 99325

Fig. 88: LOG ErrorMessage

See Sections 7.4.9 and 13.3 for detailed information about the individual error messages.

Alarm management

The alarm management is a list of the errors and warnings. To open the alarm management, click on the information (1) shown in the status bar.




Fig. 89: GUI Alarmhandling

If no alarm is active, the screen appears as follows:





Fig. 90: GUI alarm history

If alarms are active, the screen can appear as follows:



	Timestamp	Message	State	Class
0	27.06.2018 02:50:50	ToErr_6 Emergency circuit open	Active	ToolError
1	27.06.2018 01:15:13	ToErr_14 Emergency stop	Active	ToolError
2	27.06.2018 01:15:13	War_9 Drives Tool not powered	Active	Warning

History Freeze Scr Pos

Local / Automatic ✗ More than one error active Cycle counter 677 Service counter 100000

Fig. 91: GUI Active alarm messages

If only one alarm is active, the error is shown as a message in the status bar. If several alarms are active, the message “Several errors active” is shown.

Colored:


There are alarms that are active and not acknowledged

Not colored:

There are alarms outstanding which have been acknowledged.

- To acknowledge the alarms, press the Acknowledge button or the Initialization button on the two-hand control desk (if PLC mode is active, the relevant bit must be set).

If you press on the “History” button, a list of past errors and warnings is displayed:



	Timestamp	Message	State	Class
0	19.09.2018 02:36:07	ToErr_5 Drive error active	Active	ToolError
1	19.09.2018 02:36:07	ToErr_6 Emergency circuit open	Active	ToolError
2	19.09.2018 00:39:04	ToErr_5 Drive error active	Normal	ToolError
3	19.09.2018 00:39:04	ToErr_6 Emergency circuit open	Normal	ToolError
4	19.09.2018 00:39:04	ToErr_14 Emergency stop	Normal	ToolError
5	19.09.2018 00:38:11	ToErr_2 Clamping unit not in home position STO-> Initialize	Normal	ToolError
6	19.09.2018 00:38:11	ToErr_5 Drive error active	Normal	ToolError
7	19.09.2018 00:38:11	ToErr_6 Emergency circuit open	Normal	ToolError
8	19.09.2018 00:38:11	ToErr_14 Emergency stop	Normal	ToolError
9	19.09.2018 00:22:31	ToErr_5 Drive error active	Normal	ToolError
10	19.09.2018 00:22:31	ToErr_6 Emergency circuit open	Normal	ToolError

History Freeze Scr Pos

Local / Automatic ✗ More than one error active Cycle counter 12 Service counter 99990

Fig. 92: GUI alarms

Verification log

The most recent verification forces are displayed in the “Verification log” tab. This menu can be accessed only by inputting a password.

Date/Time	Force 1	Force 2	Cal	Correlation
2018/06/28 08:52:05	1499	-	1516	4900
2018/06/28 08:51:40	1845	-	1868	4900
2018/06/28 08:51:03	1848	-	1879	4880
2018/06/28 08:50:33	1845	-	1877	4880
2018/06/28 08:48:01	1848	-	1670	5400
2018/06/28 08:47:19	1845	-	1663	5500
2018/06/28 08:46:38	803	-	735	5500
2018/06/28 08:44:37	224.6759	260.1778	238	0
2018/06/28 08:44:02	352.2122	398.9201	397	0
2018/06/28 08:43:24	185.6953	206.3846	195	0
2018/06/28 08:42:41	185.973	204.4925	195	0

Local / Automatic ▶ System not initialized, press Init-Button Cycle counter 677
Service counter 100000

Fig. 93: LOG Verification entries

If a value is listed only for force 1, this is a pulling force verification. The scaling factor is listed for the correlation factor to convert the PLC force sensor input signal into the closing force (see Section 9.5.2).

For the crimping force verification, both forces are listed. The value 0 is shown for the correlation factor, since no correlation exists for the crimping force.

Service logbook

In the “Service logbook” the most recently performed Service work / Maintenance work are displayed. This menu can be accessed only by inputting a password.

OETIKER 2018/06/28 08:57:39 User: Superuser

Logbook

Process Log Error / Warnig Log Verification Log **Service Log**

Date/Time	Service-Info
2018/06/28 08:57:29	Eintrag Test 2018 V2.08 in 002
2018/06/28 08:57:22	Eintrag Test 2018 V2.08 in 001
2018/06/28 08:56:41	Eintrag 002
2018/06/28 08:56:32	Eintrag 001
2018/02/15 11:35:08	Service A
	ABC
	Text abc

Eintrag Test 2018 V2.08 in 002 to take on

Local / Automatic ✗ More than one error active

Cycle counter 677
Service counter 100000

1 2

Fig. 94: Log Service_log

To create a new Service log entry, write the text in the field (1) in the bottom left corner and press “enter” (2).

7.4.7 Setting

Setting Parameter Tool

2022/08/19 06:00:52
User: Superuser

Setting 1

Force verification

Parameter Tool

SW update

Max. pulling distance	CFM Teaching mode	Bypass: Unlocked external power	Scaling force-sensor	Time & date
-55.0 mm	Off	Active: Bypass	4980	06:00:52
Filename:	CFM Production mode	Control over external PLC	Tol. Wear value	Check voltage DC link
DataClosingClamp	On	Inactive: Control PLC	-25.0 N	230 V 110 V
Tool name		Control over IO	CFM1: Measuring Prog	CFM2: Measuring Prog
T01		Inactive: Control IO	0 0	0 0
Production ID:		Handling Function	Process interruption Eject position	
P05		Handling GUI	No Interrupt Eject Pos.	

Local / Automatic
System not initialized, please initialize
Cycle counter 6522
Service counter 98235

Fig. 95: Settings Tool Page 1

2022/08/19 06:01:31
User: Superuser

Setting 2

Force verification

Parameter Tool

SW update

Reset Servicecounter	MLD: War_107 Interrupt LC	Diagnostic information
Set	Message active	Reset
Reset Counter LC Relay	MLD: Check Light Curtain	1144 0 1167
Set	Message inactive	1469 0 2421


Info:
Counter Safety Relay
83

Local / Automatic
System not initialized, please initialize
Cycle counter 6522
Service counter 98235

Fig. 96: Settings Tool Page 2

Max. tightening stroke	Maximum pulling travel of the clamping unit. The maximum pulling travel limits the maximum diameter reduction of the WingGuard® clamp.
Filename	Name of the data file stored on the USB stick
Tool name	Name of the tool (part of the data record ID)
Production ID	Name of the production batch (part of the data record ID)
CFM Teaching mode	Production mode (the FAST 3000 PLC does not evaluate the output of the CFM monitoring devices)
CFM Production mode	Production mode (the FAST 3000 PLC evaluates the output of the CFM monitoring devices)
Bypass	Bypass the external power unlock signal.
Control over external PLC	Select this button in order to control the FAST 3000 via an external PLC
Handling Function: "Handling Ext. PLC"	Command are active from external PLC or local (GUI) for the manual Handling (Manual Drive, Verification Pulling unit, zero Balance, Verification Crimp Force, Friction test):
Scaling force-sensor	Scaling of the pulling force sensor (the factor should lie between 4750 and 5200)
Tol. Wear value	Limit for the error message of the wear value. See Section 5.2.4
Check voltage DC link: "230V / 110V"	Checks the voltage in the dc-link of the servo amplifier
Time & Date	Setting the date and time
Reset Servicecounter	Resets the Service counter to zero after a Service
Process Interruption Eject position: "Interrupt Eject Pos."	Activation / Deactivation Function: Stop the closing cycle in the eject position and waiting for the enable signal for continue.
CFM1: Measuring Program / CFM2: Measuring Program	Active and Target Program for the CFM; If the industrial communication is active then will be the target from the industrial communication.

Force verification / Zero offset



NOTICE

Under various conditions the force measured by the force load cell in the clamping unit can vary due to changes in temperature. To compensate for this you can set the measured to zero when there is no force measured by the unloaded force load cell. If the value is found to deviate from zero by more than 20 N, we recommend that the force offset is set to zero. We recommend that the force offset is checked every week (see Section 6.8.3).




Fig. 97: Zero adjustment

To zero the offset of the force load cell you must be logged in.

Force verification	Changes to the verifier force tab
Pulling unit	Changes to the pulling unit verification force tab
Zero balance	Activates the zero offset function
Set offset to zero	Press the button to change the current setting to zero
Quit routine	Quit the zero offset routine
Actual force	Displays the actual force measured by the force load cell, in Newtons

Force verification / verification of the pulling force when the force is configurable

NOTICE

For verification of correct operation of the force load cell which measures the tensioning force, the measured force must be measured at least once a week. For further Information see Section 6.8.4.

20220819 06:04:13
User: Superuser

Setting

Force verification

Parameter Tool

Pulling unit

Zero balance

Crimping

Force verification

Insert Band

Verification activation

Quit routine

Target force
1850 N
Average actual force
-72 N

Ext. Force value "CAL"
500 N
Average value
0 N

Local / Manual
Verification sensor pulling force: waiting for ban
Cycle counter 6522
Service counter 98235


Fig. 98: Zero adjustment

For checking the closing force you must at least be logged in as Operator.

Force verification	Changes to the verifier force tab
Pulling unit	Changes to the pulling unit verification force tab
Force verification	This activates the force verification routine
band locking	Indicates that the pull band is locked (the locking must be performed using the button on the handle of the FAST 3000)
Target force	Set the force in Newtons that the FAST 3000 will use to tension the clamps
Verification activation	Start the pulling process at the set force
Actual force	Displays the actual force measured by the force load cell, in Newtons
Ext. force value "CAL"	The force value that is input is read by the CAL 01 and is logged in the verification record

Quit routine	<p>Stop pulling and quit the force verification routine.</p> <p>In normal operation, the pulling force sensor stops automatically. When the force has been achieved, a defined time elapses after which the pulling unit / motion link revert to their home position.</p>
---------------------	---

Crimping force monitoring verification



NOTICE

For verification of the correct operation of the crimping force sensors which measure the crimping forces we recommend that the measured force is verified once a month using an Oetiker CAL 01. (For further Information see Section 6.8.5.)

OETIKER
2022/08/19 06:05:09
User: Superuser
🇬🇧

Setting ↩

Force verification

Parameter Tool

Pulling unit

Zero balance

Crimping

Force verification

CFM locking

Testing activ

Quit routine

Target force

1600 N

Ext. Force value "CAL"

200 N

Actual force L

0 N

Actual force R

0 N

Latch Actual force L

0 N

Latch Actual force R

0 N

Local / Manual
▶ Verification Crimp Force: Activation CFM force n

Cycle counter 6522
Service counter 98235

Fig. 99: Verification crimping force

For crimping force monitoring verification you must at least be logged in as operator.

Force verification	Changes to the verifier force tab
Crimping	Changes to the crimping force verification tab
Force verification	This activates the force verification routine
CFM locking	This activates the force verification
Target force	Set the verification force in Newtons; FAST 3000 stops the force increase as soon as the first force sensor detects this force
Force L/R	Currently measured force, in Newton
Testing active	Indicates that the force verification is being performed
(Latch Actual force L/R)	Displays the force measured by the force load cells, in Newton. The force value determined during the measurement phase of the verification is displayed
Ext. force value "CAL"	The force value that is input is read by the CAL 01 and is logged in the verification record
Quit routine	Quits the force verification routine

Setting the date and time

The Time & Date can be set by three ways.

1. Connecting to the controller of the Fast3000
2. Using the GUI (see below)
3. Industrial communication using UTC Unix Time Stamp

Fig. 100: Settings Tool Page 1

A popup window appears, in which the date and time can be set.





Fig. 101: Set time


Input the current date and time.

To load the setting, press the “Set time and date” button.

7.4.8 Information

The currently installed software version and the publication date are shown in the “Information” tab. It also contains a list of the Oetiker service addresses.

2018\06\27 10:24:25 User: Superuser

Information

Service adress
Headquarters Switzerland:
T + 41 44 728 55 55
info.ch@oetiker.com

Germany:
T + 49 76 42 6 84 0
info.de@oetiker.com

USA:
T + 1 989 635 3621
info.us.marlette@oetiker.com

China:
T +86 22 2697 1183
info.cn@oetiker.com


Japan:
T + 81 45 949 3151
info.jp@oetiker.com

India:
T + 91 77210 15261 64
info.in@oetiker.com

Sytem
FAST 3000
SrNr: 123456-1234

FW version:
SW V2.08l

Date:
2018-06-26


Local / Automatic More than one error active

Cycle counter677
Service counter100000

Fig. 102: Information page

7.4.9 Error list

For further information on error correction see Section 13.



NOTICE
The errors are grouped as follow:
100-199: Warnings. These are not affecting wheter a closure is evaluated as OK.
200-299: Tool error. These are not affecting wheter a closure is evaluated as OK.
300-399: Process error. All process errors cause the closure to be evaluated as NOK.

Error number	Description	Class/Severity	See Section
101	War_101 Error acknowledged	Warning	13.3.1
102	War_102 Check start button contacts	Warning	
103	War_103 No power -> press start / and init	Warning	
104	War_104 CFM box warning / error	Warning	
105	War_105 Soon service necessary	Warning	
106	War_106 Service necessary	Warning	
107	War_107 Stop about light curtain	Warning	
108	War_108 Mode CFM teaching activ	Warning	
109	War_109 Drives Tool not powered	Warning	
110	War_110 No Power - activate extern enable signal, then press Start , then press Init	Warning	
111	War_111 Band remove	Warning	
112	War_112 Abort verification pulling force	Warning	
113	War_113 Abort verification crimp force	Warning	
114	War_114 Stop about external stop command	Warning	
115	War_115 External Signal band lock is on	Warning	
116	War_116 EtherCAT - bus not running	Warning	
117	War_117 Init command is pending	Warning	
118	War_118 Please check function light curtain	Warning	
119	War_119 Manual Mode: Run command before last run end (Pulling Unit)	Warning	
120	War_120 Manual Mode: Run command before last run end (Motion link)	Warning	
121	War_121 Friction Test Target outside tolerance	Warning	
122	War_122 Verification Crimp Force Target outside tolerance	Warning	
123	War_123 Verification Pulling Force Target outside tolerance	Warning	
124	War_124 Warning Friction Test	Warning	
125	War_125 Warning Verification Crimp Force	Warning	
126	War_126 Warning Verification Pulling Unit	Warning	
127	War_127 Warning Zero Balance	Warning	
128	War_128 Warning Change soon LC-Relay	Warning	
129	War_129 Warning LC- Relay to be changed	Warning	
130	War_130 Release light curtain missing	Warning	
131	War_131 Stop after abort cmd	Warning	
132	War_132 CFM1 Wrong Number Measuring Prog.	Warning	
133	War_133 CFM2 Wrong Number Measuring Prog.	Warning	
134	War_134 Temperature Enclosure Cabinet to high	Warning	

Error number	Description	Class/Severity	See Section
201	ToErr_201 Band present -> remove & acknowledge	Tool error	13.3.2
202	ToErr_202 Clamping unit not in home position STO-> Initialize	Tool error	
203	ToErr_203 Check pulling and cutting units	Tool error	
204	ToErr_204 Position sensor pulling unit fault	Tool error	
205	ToErr_205 Drive error active	Tool error	
206	ToErr_206 Emergency circuit open	Tool error	
207	ToErr_207 Light curtain during init sequence	Tool error	
208	ToErr_208 Verification CFM error phase 1	Tool error	
209	ToErr_209 Verification CFM error phase 2	Tool error	
210	ToErr_210 Verification CFM: No force built up	Tool error	
211	ToErr_211 Check band scrap	Tool error	
212	ToErr_212 CFM general warning/error	Tool error	
213	ToErr_213 Check pulling force sensor	Tool error	
214	ToErr_214 Emergency stop	Tool error	
215	ToErr_215 Pulling unit not in home position	Tool error	
216	ToErr_216 During cyle, Drives Tool lost power	Tool error	
217	ToErr_217 Verification pulling force; Target force not reached	Tool error	
218	ToErr_218 Tool locked from external bus-signal	Tool error	
219	ToErr_219 Manual mode: More than 1 run command Pulling Unit	Tool error	
220	ToErr_220 Manual mode: More than 1 run command Motion Link	Tool error	
221	ToErr_221 Error Friction test	Tool error	
222	ToErr_222 Error Verification Crimp Force	Tool error	
223	ToErr_223 Error Verification Pulling unit	Tool error	
224	ToErr_224 Error Zero Balance	Tool error	
225	ToErr_225 Motion Link undervoltage	Tool error	
226	ToErr_226 Pulling Unit undervoltage	Tool error	
227	ToErr_227 EtherCAT not running	Tool error	
228	ToErr_228 Check pulling force sensor	Tool error	
229	ToErr_229 CFM wrong Measuring Program	Tool error	

Error number	Description	Class/Severity	See Section
301	PrErr_301 Max. pulling stroke exceeded	Process error	13.3.3
302	PrErr_302 Max. pulling time exceeded	Process error	
303	PrErr_303 Crimping CFM1 envelope 1	Process error	
304	PrErr_304 Crimping CFM1 envelope 2	Process error	
305	PrErr_305 Crimping CFM1 NoPass	Process error	
306	PrErr_306 Crimping CFM1 wear	Process error	
307	PrErr_307 Crimping CFM2 envelope 1	Process error	
308	PrErr_308 Crimping CFM2 envelope 2	Process error	
309	PrErr_309 Crimping CFM2 NoPass	Process error	
310	PrErr_310 Crimping CFM2 wear	Process error	
311	PrErr_311 General error crimping	Process error	
312	PrErr_312 Cutting error	Process error	
313	PrErr_313 Force limit exceeded	Process error	
314	PrErr_314 Max. pulling stroke exceeded	Process error	
315	PrErr_315 Closing force out of tolerance	Process error	
316	PrErr_316 Max. force at stop from light curtain	Process error	
317	PrErr_317 Max. force during move to throw-off position	Process error	
318	PrErr_318 Process interrupt	Process error	
319	PrErr_319 Max. force at stop from Bus	Process error	
320	PrErr_320 CFM1: Abort line crossed	Process error	
321	PrErr_321 CFM2: Abort line crossed	Process error	
11016	Servo pulling unit: IPM error	Drive error	
11017	Servo pulling unit: IPM temperature	Drive error	
11020	Servo pulling unit: Overcurrent	Drive error	
11021	Servo pulling unit: Current offset	Drive error	
11022	Servo pulling unit: Current limit exceeded	Drive error	
11033	Servo pulling unit: continually overloaded	Drive error	
11034	Servo pulling unit: Drive temperature 1	Drive error	
11035	Servo pulling unit: Overload on regeneration	Drive error	
11036	Servo pulling unit: Motor cable not connected	Drive error	
11037	Servo pulling unit: Temperature 2	Drive error	
11038	Servo pulling unit: Encoder temperature	Drive error	
11048	Servo pulling unit: Encoder communication error	Drive error	
11049	Servo pulling unit: Encoder cable not connected	Drive error	
11050	Servo pulling unit: Encoder data error	Drive error	
11051	Servo pulling unit: Motor settings	Drive error	

Error number	Description	Class/Severity	See Section
11052	Servo pulling unit: Z phase not connected	Drive error	
11053	Servo pulling unit: Low battery level	Drive error	
11054	Servo pulling unit: Sine ENC	Drive error	
11055	Servo pulling unit: Sine frequency	Drive error	
11056	Servo pulling unit: Encoder setting error	Drive error	
11064	Servo pulling unit: Undervoltage	Drive error	
11065	Servo pulling unit: Overvoltage	Drive error	
11066	Servo pulling unit: Interruption in power supply	Drive error	
11067	Servo pulling unit: Interruption in control voltage	Drive error	
11080	Servo pulling unit: Speed overshoot	Drive error	
11081	Servo pulling unit: POS following	Drive error	
11083	Servo pulling unit: Large SPD deviations	Drive error	
11099	Servo pulling unit: Checksum error	Drive error	
11113	Servo pulling unit: Error in the factory settings	Drive error	
12016	Servo Motion Link: IPM error	Drive error	
12017	Servo Motion Link: IPM temperature	Drive error	
12020	Servo Motion Link: Overcurrent	Drive error	
12021	Servo Motion Link: Current offset	Drive error	
12022	Servo Motion Link: Current limit exceeded	Drive error	
12033	Servo Motion Link: Continuously overloaded	Drive error	
12034	Servo Motion Link: Drive temperature 1	Drive error	
12035	Servo Motion Link: Overload on regeneration	Drive error	
12036	Servo Motion Link: Motor cable not connected	Drive error	
12037	Servo Motion Link: Temperature 2	Drive error	
12038	Servo Motion Link: Encoder temperature	Drive error	
12048	Servo Motion Link: Encoder communication error	Drive error	
12049	Servo Motion Link: Encoder cable not connected	Drive error	
12050	Servo Motion Link: Encoder data error	Drive error	
12051	Servo Motion Link: Motor settings	Drive error	
12052	Servo Motion Link: Z phase not connected	Drive error	
12053	Servo Motion Link: Low battery level	Drive error	
12054	Servo Motion Link: Sine ENC	Drive error	
12055	Servo Motion Link: Sine frequency	Drive error	
12056	Servo Motion Link: Encoder setting error	Drive error	
12064	Servo Motion Link: Undervoltage	Drive error	
12065	Servo Motion Link: Overvoltage	Drive error	
12066	Servo Motion Link: Interruption in power supply	Drive error	
12067	Servo Motion Link: Interruption in control voltage	Drive error	
12080	Servo Motion Link: Speed overshoot	Drive error	
12081	Servo Motion Link: POS following	Drive error	
12083	Servo Motion Link: Large SPD deviations	Drive error	
12099	Servo Motion Link: Checksum error	Drive error	
12113	Servo Motion Link: Error in the factory settings	Drive error	

* Reserved warning/error but not in use

7.4.10 Access rights


Rights	User		
	“none” = status at switch-on	Operator	Superuser
Closing force parameter	x	x	✓
Parameter Tool	x	x	✓
Process protocol	✓	✓	✓
Error / warning protocol	✓	✓	✓
Verification protocol	x	x	✓
Service logbook	x	x	✓
Unlocking function	x	✓	✓
Laboratory mode	x	x	✓
Manual operation (manual operation)	x	x	✓
Friction test	x	x	✓
I/O test	x	x	✓
Force verification	x	✓	✓

Explanation: ✓ = access x = no access


The user “Superuser” will be logged out automatically on expiry of a certain time.

8 Assigning the IP address

If the tool is to be integrated into a network, make sure that the IP address that is assigned will not generate any conflicts. The factory setting of the IP address is 192.168.10.50. You can use a web browser to access the controller in order to change the IP address. To do this, enter `http://192.168.10.50:81/` into the address bar of the browser.




After logging in to the home page, input the desired IP address, subnet mask and standard gateway.



The IP address that is set is used both for the Ethernet TCP/IP and also for the Ethernet/IP (industrial communication).


8.1 Setting the date and time


Select the menu tab “System settings” and input the date and time.




9 Maintenance and replacement of parts

9.1 General safety instructions for maintenance and repair work

	WARNING
	<p>Danger of death from electric shock. Touching live parts can result in death.</p> <ul style="list-style-type: none"> ▶ Withdraw the mains plug from the electrical socket and secure the FAST 3000 to prevent it being plugged in again accidentally. ▶ If working with electrical components internal to the cabinet, wait 15 minutes after switching off the power, to allow the intermediate circuit voltage in the servo amplifier to dissipate. ▶ Ensure that only qualified and authorized electricians work on the electrical equipment. ▶ Ensure that operators rectify only those faults that are clearly attributable to operating or maintenance errors


	WARNING
	<p>Never immerse the FAST 3000 in water or other liquids.</p>


	CAUTION
	<p>Risk of damage to the force load cell.</p> <ul style="list-style-type: none"> ▶ The FAST 3000 is equipped with a force load cell. This is a precision measuring device. So as not to damage the force load cell, apply only the intended forces to it (do not apply hammer impacts and the like).

- Cleaning, lubrication and maintenance work should only be carried out by authorized technical personnel in accordance with the enclosed maintenance instructions and local safety regulations. Failure to observe these instructions and regulations may lead to personal injury and property damage.
- For maintenance and repair work use only the tools and original equipment recommended by OETIKER.
- Use only original-spare parts from OETIKER.
- Maintenance work may be performed on the FAST 3000 only when it is disconnected from the electrical supply.
- Following initial commissioning, the FAST 3000 tool should be cleaned daily or weekly, depending on the degree of soiling.
- Never immerse the FAST 3000 in water or other liquids.


9.2 Maintenance


9.2.1 Before maintenance work

	WARNING
	<p>Danger of death from electric shock. Touching live parts can result in death.</p> <ul style="list-style-type: none"> ▶ Withdraw the mains plug from the electrical socket and secure the FAST 3000 to prevent it being plugged in again accidentally. ▶ Wait 15 minutes after switching off the power, to allow the intermediate circuit voltage in the servo amplifier to dissipate. ▶ Ensure that only qualified and authorized electricians work on the electrical equipment. ▶ Ensure that operators rectify only those faults that are clearly attributable to operating or maintenance errors.

	CAUTION
	<p>Crush hazard at moving parts.</p> <ul style="list-style-type: none"> ▶ Maintenance work may be performed on the FAST 3000 only when it is disconnected from the electrical supply. ▶ The covers may be removed only by authorized, trained and qualified personnel.

9.2.2 After maintenance work

	CAUTION
	<p>Crush hazard at moving parts.</p> <ul style="list-style-type: none"> ▶ After maintenance work, ensure that all safety devices have been replaced and securely bolted in place.

	CAUTION
	<p>Danger due to parts being flung from the machine. If parts fracture while the machine is in during operation, parts may become loose and be flung from the machine.</p> <ul style="list-style-type: none"> ▶ During operation and maintenance of the machine, always wear safety glasses.

- ▶ Ensure that the electrical plug connectors which were withdrawn are plugged in again following the maintenance and inspection work.
- ▶ Check all screw connections.
- ▶ Reattach all safety devices immediately.
- ▶ Check all operating functions of the FAST 3000 and the initialize the tool.

9.2.3 Regular checking of the status



CAUTION

Any defects must be reported to a supervisor immediately.

- ▶ Do not continue to use the FAST 3000 if defects have been identified.

- ▶ Check the FAST 3000 for visible damage daily or at the start of each shift, and make sure it is used only when in good condition. This applies particularly to the crimping jaws and operation of the emergency stop.




Fig. 103: Use the mounted jaws checking mirror to check the crimping jaws

- ▶ The closing force must be verified every week (see Section 6.8.4).
- ▶ We recommend that the force offset is verified every week (see Section 6.8.3).
- ▶ We recommend that the crimping force sensors are verified once every month (see Section 6.8.5).
- ▶ We recommend that the tool positioning is checked weekly.

9.2.4 Regular maintenance work / maintenance schedule

Service	Service interval / Performed by	Parts to be replaced	Maintenance activities	Time required
A	100,000 cycles CUSTOMER or Oetiker	<ul style="list-style-type: none"> Crimping jaws kit (part number 13500112) 	<ul style="list-style-type: none"> Replace the crimping jaws Rotate the cut-off die through 180° Clean and lubricate the tool head 	10 minutes
B	200,000 cycles CUSTOMER or Oetiker	<ul style="list-style-type: none"> Parts involved in the 100,000 cycles service activities Cut-off die Clamping lever Crimping wedge Crimping jaw pivot pins (Select all the parts contained in part number 13500157) 	<ul style="list-style-type: none"> A-service Replacing parts Clean and lubricate the clamping unit 	40 minutes
C	2,000,000 cycles Exclusively by Oetiker: Please contact your OETIKER representative.	<ul style="list-style-type: none"> Parts involved in the 200,000 cycles service activities Clamping lever kit Clamping unit slide (depending on the extent of wear) (Select all the parts contained in part number 13500228) 	<ul style="list-style-type: none"> B-service Replacing parts Grease the drives Check the condition of the tool Clean the dust filter of the control cabinet 	2 hours

Recommended lubricant

Description	Type	Manufacturer
Grease	MICROLUBE GBU-Y 131	Klüber Lubrication AG (Switzerland) Thurgauerstrasse 39 8050 Zürich Tel.: +41 44 308 69 69 Fax: +41 44 308 69 44 www.klueber.com

Greasing points

- Apply a thin film of grease to all the areas marked yellow.




Fig. 104: Fat head

9.2.5 A-service - to be performed every 100,000 cycles

	CAUTION
	Replace wear parts (crimping jaws) after 100,000 closures. When doing this, clean and grease the entire head.

This service must be performed every 100,000 cycles.

1. Dismantle the crimping cut-off head (see Section 9.1).
2. Clean and grease the crimping cut-off head.
3. Perform a visual inspection of the crimping wedge and crimping jaw pivot pins: No excessive wear.
4. Replace the crimping jaws (see Section 9.3.3).
5. Rotate the cut-off die through 180° (see Section 9.3.3).

6. Reassemble the crimping cut-off head (see Section 9.3.3).
7. The closure gap SS must be within 3 ± 0.1 mm (measure it in the closed condition).




Fig. 105: Adjusting the closing gap

8. After installing and securing the head housing cover, all three slides must be free to move with very little resistance.
9. After assembling the FAST 3000, perform a closing force verification at 1850 N (see Section 6.8.4). The closing force must lie within ± 100 N.
10. Perform ten WingGuard® clamp closures. These ten closures must all be evaluated as OK pieces.

9.2.6 B-service - to be performed every 200,000 cycles

	CAUTION
	Replace wear parts (crimping jaws) after 100,000 closures.
	Replace the wear parts (cut-off die, crimping wedge, crimping jaws pivot pin, clamping lever) after 200,000 closures.
	When doing this, clean and grease the entire crimping cut-off head and clamping unit.

An extended/major service must be performed every 200,000 cycles.

1. Dismantle the crimping cut-off head (see Section 9.3).
2. Clean and lubricate the tool head (see Section 9.2.4).
3. Replace the crimping wedge (see Section 9.3.4).
4. Replace the crimping jaws pivot pin (see Section 9.3.5).
5. Replace the crimping jaws (see Section 9.3.3).
6. Replace the cut-off die (see Section 9.3.3).
7. Reassemble the crimping cut-off head (see Section 9.3).
8. Clean and grease the clamping unit.
9. Replace the clamping lever (see Section 9.3.4).
10. The closure gap SS must be within 3 ± 0.1 mm (measure it in the closed condition).






Fig. 106: Adjusting the closing gap

11. After installing and securing the head housing cover, all three slides must be free to move with very little resistance.
12. After assembling the FAST 3000, perform a closing force verification at 1850 N. The closing force must lie within ± 100 N.
13. Perform ten WingGuard® clamp closures. These ten closures must all be evaluated as OK pieces.

9.3 Replacing parts

	<p>WARNING</p> <p>Risk of injury when the crimping cut-off head is not mounted.</p> <ul style="list-style-type: none"> ▶ Never operate the FAST 3000 without a correctly fitted crimping cut-off head.
---	---

	<p>CAUTION</p> <p>When the CFM force load cells are not fitted there is a risk of mechanical damage.</p> <ul style="list-style-type: none"> ▶ If the force load cells are not installed in their normal position, never operate the FAST 3000 with a crimping cut-off head that is equipped for CFM. Failure to comply with this instruction risks mechanical damage to the crimping cut-off head.
---	---

9.3.1 Removing the crimping cut-off head

1. To facilitate installation, move the clamping unit to the ejection position (see Section 6.8.2).
2. Switch off the FAST 3000.




Fig. 107: Main switch

3. Unscrew the 4 screws at the side and remove the cover from the head.




Fig. 108: Disassembly protective cover head

4. Release the force sensor cable from the cable clips.
5. Unscrew the screws from the force sensor brackets.
6. Using a no. 2 slot-head screwdriver, remove the crimping force sensors and their brackets.




Fig. 109: Disassembly sensors caulking monitoring

7. Before removing the crimping cut-off head, lay the force sensor cables (1) over the FAST 3000. This reduces the risk of inadvertently crushing the force sensor cables.




Fig. 110: *Sensors caulking monitoring*

8. Unscrew the 4 screws on the front face, and pull the crimping cut-off head off.




Fig. 111: *Disassembly head*

9. Place the crimping cut-off head face-down on the maintenance worktop.




Fig. 112: *Removed crimping cut-off head*

9.3.2 Installing the crimping cut-off head

1. Make sure that the FAST 3000 is switched off.
2. To install the crimping cut-off head, perform steps 3 to 7 of Section 9.3.1 in the reverse order.
Tightening torque of the M6 screws:
7–9 Nm (62–80 lbf in)




Fig. 113: Main switch

9.3.3 Replacing the crimping jaws and/or the cut-off die



CAUTION

Damage to the tool due to the use of unauthorized parts or improper handling.
Use only original OETIKER spare parts. Crimping jaws other than those designated may not be installed in the crimping cut-off head.

Use no impact tools when disassembling or reassembling the crimping cut-off head. The assembly is part of a measurement system which can be damaged by improper handling.

For further information on the part numbers of spare parts, see Section 9.5.

For information on naming the components of the crimping cut-off, see Section 4.2.

Dismantling the crimping cut-off head

1. Make sure that the workplace is free of chips and dust.
2. Place the crimping cut-off head face-down on the worktop.
3. Release the 4 screws and take off the head housing cover.




Fig. 114: Head cover housing

4. Dismantle the parts.




Fig. 115: *Disassemble head*

5. To remove the spacer plate, lift the spacer plate by inserting a no. 2 slot-head screwdriver into the recesses provided. After lifting at one recess, always switch to the opposite recess.




Fig. 116: *Disassemble head*

Reassembling the crimping cut-off head

To install the crimping cut-off head, perform the steps for disassembly in the reverse order.

Comply with the following instructions:

- When assembling the crimping cut-off head and installing it on the FAST 3000 mechanism, make sure that the crimping jaw rollers are located in the crimping wedge guides as shown in the left-hand photo. Failure to comply with this instructions can lead to mechanical damage to the crimping cut-off head.




Fig. 117: *Assembly caulking jaws*

- Push down the spacer plate by hand alternately at the points indicated.

Tightening torque the M6 screws: 7-9 Nm (62-80 lbf in)




Fig. 118: Mounting spacer plate

Replacing the cut-off die



NOTICE

Do not use the respective side of the cut-off die any longer that the number of cycles specified in the Maintenance section.



NOTICE

When the FAST 3000 is delivered, the cut-off die is inserted so that the side marked “1” is the cutting side. Accordingly, a new cut-off die should be inserted so that the side marked “1” cuts.

1. Comply with the disassembly instructions when dismantling the crimping cut-off head.





Fig. 119:

Dismantled cut-off die and slide

2. Push the cut-off die out of the slide.



- When for the first time the cut-off die is due for replacement it can simply be turned over and the other side used. If this has already been done, replace the cut-off die with a new one.




Fig. 120: Separator

Replacing the crimping jaws



NOTICE

Always replace the right-hand and left-hand crimping jaws together.



NOTICE

Do not use the crimping jaws any longer that the recommended number of cycles (see Section 9.2.4).

- Comply with the disassembly instructions when dismantling the crimping cut-off head (see “Dismantling the crimping cut-off head”)
- Replace the crimping jaws.
- Reassemble the crimping cut-off head.

9.3.4 Replacing the crimping wedge

For details of dismantling the crimping cut-off head see Sections 9.3.1 and 9.3.3.

- Release the attachment screw and remove it.
- Remove the pins.
- Pull the crimping wedge out of the crimping slide and replace the crimping wedge with a new one.
- Insert the pins again into their recesses.
- Tighten the attachment screw.
- Assemble the crimping head again, as described in the Section “Assembling the crimping cut-off head”.




Fig. 121: Caulking wedge

9.3.5 Replacing the crimping jaws pivot pin




NOTICE


Only the press-out and press-in tools provided for the purpose (see Section 9.7) may be used to replace crimping jaw pivot pins. Do not use any hammers or punches, since these increase the risk of mechanical damage.

The pivot pin press-in tool ensures that each crimping jaw pivot pin is pressed in to the correct depth. The pivot pin must not project beyond the spacer plate and must not be pressed in too deeply.

1. Mount the pivot pin press-out tool on the crimping cut-off head as shown in the picture on the right. Comply with the sequence of tightening operations.



2. Tighten the marked screw (1) and press the first pivot pin out. Then screw the screw in the other tapped hole and press the second pivot pin out. Remove the press-out tool.



3. Mount the pivot pin press-in tool on the crimping cut-off head as shown in the picture on the right. Comply with the sequence of tightening operations.






Fig. 122: Off- Pressing device

4. Insert the new crimping jaw pivot pin (3) and insert the marked screw (2). Now tighten the screw, to press the crimping jaw pivot pin in. Stop tightening as soon as resistance is clearly sensed. Do the same for the second new pivot pin.
5. Remove the press-in tool and assemble the crimping head again, as described in the Section "Assembling the crimping cut-off head".
6. The pivot pin press-in tool ensures that each crimping jaw pivot pin is pressed in to the correct depth (3).



9.3.6 Replacing the clamping lever



CAUTION

Damage to the tool due to the use of unauthorized parts.
Use only original OETIKER spare parts.

For further information on the part numbers of spare parts see Section 9.7



CAUTION

Damage to the tool due to incorrect closure of clamps.
Install the clamping lever in the correct position with the nose facing forwards.



NOTICE

Do not use the clamping lever any longer than the number of cycles specified in the Maintenance section.

1. Move the lower drive into the ejection position.
2. Press the emergency stop button.
3. Remove the front covers.




Fig. 123:

Tool with front covers removed

4. Pull the clamping lever pivot pin out (no tool necessary).





Fig. 124:

Removal clamping lever

5. Move the clamping lever forwards.



6. Push the clamping lever to one side, take it off and replace it with a new one.




Fig. 125: *Clamping lever*

7. Reassemble everything. To do this, perform the above steps in the reverse order.

9.4 Checking and adjusting the position of the strap detection sensor



NOTICE

To check whether the strap sensor is set correctly, perform steps 1 to 6.



NOTICE

For information about the part numbers of the two strap strips, see Section 9.7.

1. Move the lower drive into the service position (Operating mode -> Manual operation -> Service position).
2. Press the Emergency Stop button.
3. Remove both the side covers.
4. Insert the strap section (1) bearing the “LED on” legend into the slot in the pulling unit. Press the tensioning lever rod (2) of the crimping cut-off head, to open the pulling unit. Once the strap section has been inserted, release the tensioning lever rod.
(Note: If the strap section is curved, insert it as shown by the yellow line. This ensures that once the tensioning lever has been released the strap section will lie flat.
If the sensor is correctly set, the LED (4) will light up.
5. Remove the strap section bearing the “LED on” legend again and insert the strap section bearing the “LED off” legend.
If the sensor is correctly set, the LED will not light up.
6. If at steps 4 or 5 the LED status is incorrect, continue with the next step. Otherwise the setting of the sensor is correct; continue with step 14.




Fig. 126: Setting band detection sensor

7. Once again insert the strap section bearing the "LED on" legend into the slot in the pulling unit.
8. Using a 1.5 mm hexagon drive key, undo the set screw (3) about one turn.
9. Press the strap sensor down until it rests on the strap section. You can do this more easily if you hold the sensor by gripping its cable with a pair of tweezers.
10. Slowly raise the sensor off the strap section until the LED lights up.
11. If necessary, rotate the sensor so that the LED is visible.
12. Hold the LED securely in position and tighten the set screw. Tightening torque: 5 Ncm. Excessive tightening of the set screw may damage the sensor.
13. Perform steps 4 and 5 to check the sensor position once again.
14. Reinstall both the side covers.
15. Deactivate the Emergency Stop and initialize the FAST 3000.




Fig. 127: *Setting band detection sensor*

9.5 Setting the closing force sensor



NOTICE

If the factor “Force sensor scaling” is set incorrectly this will cause the WingGuard® strap clamps to be closed with a closing force that is either too high or too low.

- Make adjustments carefully, use a calibrated CAL 01.



NOTICE

Adjusting the scaling of a tool with a mechanical problem masks the mechanical problem, which can lead to incorrectly installed WingGuard® clamps and incorrectly mounted products

- Before adjusting the force sensor scaling, check the tool mechanics, in particular the smooth running of the linear guide of the clamping unit and the correct alignment of the clamping unit to the crimping head.

For adjustment you will need a CAL 01 and a PG135 verification unit. For information about part numbers see Section 3.3.

See Section 6.8.4 (Verifying the closing force) for information on how to verify the closing force sensor.

9.5.1 Checking the ease of movement of the clamping unit

1. Move the motion link to the home position and the pulling unit to the service position.
2. Press the emergency stop.
3. Remove the screw red marked.
4. Move the pulling unit by hand, it must be possible to move it smoothly and easily over the entire available stroke.
5. Reassemble the screw removed in step 3.
6. Release the emergency stop and initialize the FAST 3000.




Fig. 128: Checking the ease of movement of the clamping unit

9.5.2 Adjusting the load cell

1. Log in as “Superuser”.
2. Set the CAL 01 to Hold-ME-EL Average mode.
3. Wait five minutes until the CAL 01 has warmed up.
4. Check whether there is any force deviation (zero point offset). If there is, zero the device (see Section 6.8.3)

(Setting the force offset to zero)).

5. Perform five force verifications with a target force of 1850 N and make a note of the values.
6. Calculate the average of these five values. (for instance 1950 N)
7. Select “Settings” on the FAST 3000 touch panel and select the “Tool parameters” sub-menu:

Fig. 129: Setting parameters Tool Page 1

8. Use the following formula to calculate the new value for the force sensor scaling:

$$NKS = D_{CAL01} / F_Z \cdot AKS$$

NKS: New Force Sensor scaling
 D_{CAL01} : Average value of the CAL01 force measurement
 F_Z : Target force
 AKS: Old force sensor scaling

9. Input this value into the field “Force sensor scaling”).
10. Check whether there is any force deviation (zero point offset). If there is, zero the device.
11. Perform force verification to check the correct setting once again.

9.6 Replacing the control cabinet or tool mechanism













WARNING






Failure to comply with the procedure described below will cause the WingGuard® strap clamps 270 to be closed with a closing force different from the set value. It is absolutely essential that the closing force is verified and the force sensor scaling factor is adjusted if necessary.

1. Remove the defective components (from the tool mechanism or control cabinet).
2. If you have to send the defective component back to Oetiker for repair, make sure you send back all the necessary components.
The scope of the components sent back must be the same as the scope of spare components supplied. Caution: The scope of supply of the tool mechanism includes both the crimping force monitoring devices.
3. Install all the components within the scope of supply of the spare components.
4. Perform a closing force verification (see Section 6.8.4).
5. If the measured closing force deviates by more than 25 N from the set value, perform readjustment of the closing force sensor (see Section 9.5).


9.7 Tools and consumable materials for maintenance






Tool error / Consumable materials		Part number	Applications
Spare parts kit for the crimping jaws (Service pack A)		13500112	A-service
Service pack B		13500157	B-service
Service pack C		13500228	C-service
Crimping wedge		13500324	Spare part
Spare parts kit for clam- ping lever		13500335	Spare part

Tool error / Consumable materials	Part number	Applications
Crimping cut-off head for CFM		13500215 Crimping cut-off head for quick maintenance
Crimping cut-off tool + CFM		13500352 Spare part
Ethernet IP control ca- binet	—	13500364 Spare part
Profinet control cabinet	—	13500363 Spare part
Sensor Clamping Unit		13500292 Spare part
Force Cell with Connec- tor		13500293 Spare part
Press-in tool		13500342 Press in the crimping jaws






Tool error / Consumable materials		Part number	Applications
Press-out tool		13500341	Press out the crimping jaws
Pull band		13500347	Closing force verification
Installation aid for the crimping cut-off head		13500288	Facilitates the installation of the crimping head
CAL01 and SKS01		*	Closing force verification
Sensor setting strip "LED on"		13500336	Setting the strap detection sensor
Sensor setting strip "LED off"		13500337	Setting the strap detection sensor





* Various different article numbers (see Section 3.3)



Force measurement jaws set		13500264	<p>The force measurement jaws set is used to determine the remaining radial force on the set WingGuard® strap clamps.</p> <p>The set must be used in conjunction with a CAL01 and a SKS01.</p>
----------------------------	---	----------	--

Tool error / Consumable materials	Part number	Applications
Proximity switch IFRM 03P3501/KS35L (Clamping unit strap sensor)		06001786 Spare part
Damper, complete		13500318 Spare part
Sensor clamping bus- hing		13500346 Spare part
Clamping unit rail		13500345 Spare part
Contact module NO		06001813 Spare part


Tool error / Consumable materials	Part number	Applications
Contact module NC		06001814 Spare part
Servo amplifier L7NHA004U		06001892 Spare part
Measurement amplifier 1-BM40IE		06002147 Spare part
Digital input / output card		06001891 Spare part
PLC PAC320 PROFINET		06002146 Spare part

Tool error / Consumable materials	Part number	Applications
PLC PAC320 Ethernet/IP	06001870	Spare part
	13500271	Spare part
Drive GSM20 complete (complete with connection plugs)		
	06001877	Spare part
Force monitoring device		
	06001864	Spare part
Miniature force sensor 2.5kN (crimping force sensor)		
	13500343	Positioning of the FAST 3000
Alignment aid		
	06001878	Cable for connecting the crimping force sensor to the crimping force monitoring devices
Cable for the force monitoring device 2 m		

Tool error / Consumable materials	Part number	Applications
Connecting Cable PLC – CFM	13500276	Spare part
		
Spare Part Head Housing, force monitoring	13500314	Spare part
		
Tool Mount Guide	13500041	Spare part
		
Jaws checking mirror	13500351	Spare part
		

Tool error / Consumable materials		Part number	Applications
Sensor plug connector M8		13500115	Extension cable for the band sensor
Handle cpl.		13500178	
Safety sticker set for the FAST 3000		08904156	Spare part
Hexagon key wrench 1.5 mm			Strap sensor
Hexagon key wrench 2 mm			Safety proximity sensor, ...
Hexagon key wrench 2.5 mm			Power supply chain
Hexagon key wrench 3 mm			Covers, ...
Hexagon key wrench 4 mm			-
Hexagon key wrench 5 mm			Various different
Hexagon key wrench 6 mm			Transport restraint, ...
Hexagon key wrench 8 mm			Jointed pin, female
Tweezers			Setting the strap sensor
MICROLUBE GBU-Y 131 grease			Greasing the crimping cut-off head, Clamping unit and strap
Brush			Applying grease
Feeler gauge 0-150 mm			Closure gap verification

10 Controlling the FAST 3000 via an external PLC

	WARNING
	Never operate the FAST 3000 via an external PLC, without providing the necessary safety precautions.
	Failure to observe this instruction may lead to death or serious injury.
	<ul style="list-style-type: none"> ▶ The system integrator is responsible for the safe integration of the FAST 3000 into the assembly cell. ▶ The system integrator must perform a risk analysis and configure the tool in accordance with this analysis. ▶ If particular, if the two-hand control desk is not used, the two-hand dongle must be plugged in. An external emergency stop must be connected. ▶ The integration may be performed only by qualified personnel. ▶ If you have questions about how to perform integration contact Oetiker.

See also circuit diagram:

- Connecting the emergency stop
- light curtain and power-on readiness

10.1 Control via a field bus (Ethernet/IP or Profinet)

The FAST 3000 can be controlled via an external control system based on the Ethernet/IP or Profinet field bus.

Connect the supervisory control system to the respective LAN port of the FAST 3000 control cabinet.

For further information see Section 6.2 and 7.4.5.

10.1.1 Settings for the Ethernet/IP communication protocol

Name:	Parker
IP address:	192.168.10.50
Communication format:	Bytes
Inhibit module:	true
Use a Unicast connection via EtherNet/IP:	false

	Assembly example	Size
Input	101	256
Output	100	128
Configuration	102	2

10.1.2 Settings for the Profinet HW configuration

The GDSML file for configuration of the supervisory control system can be found on the USB stick supplied. The following settings must be performed in the configuration of the supervisory control system:

- 256 Bytes
- 128 Bytes




Fig. 130: HW Configuration Profinet PLC Siemens

10.1.3 Field bus mapping

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
R-DW0: Sta- tusword	In DW-0	IM1 In 0	Statusinformation			
R-DW0: Sta- tusword	In DW-0	Bit0	Part OK	Normally Mode	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit1	Part not OK	Normally Mode	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit2	Verification Pulling force: Routine active	Force adjust- ment	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit3	Verification Pulling force: Ready for band	Force adjust- ment	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit4	Verification Pulling force: Controller active	Force adjust- ment	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit5	Zero balance: Routine active	Adjust to zero	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit6	Zero balance: Ready for set Zero	Adjust to zero	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit7	Motion link: Powerd	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit8	Motion link: Referenced	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit9	Pulling unit: Powerd	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit10	Pulling unit: Referenced	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit11	Light curtain (Input safety relais)	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit12	PLC ready and EtherCAT running	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit13	Feedback external Enable power	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit14	Ready for external Enable power	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit15	Ready for initialization	Normally Mode	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit16	Ready for locking the clamp	Normally Mode	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit17	Ready for start the cycle closing clamp	Normally Mode	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit18	Busy (Cycle closing clamp active)	Normally Mode	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit19	Error from the drives	Normally Mode	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit20	Laboratory Mode active	Laboratory-mo- de	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit21	State Restart Light curtain	Safety Informa- tion	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit22	State Emergency Stop (Input safety relais)	Safety Informa- tion	R Bool	

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
R-DW0: Sta- tusword	In DW-0	Bit23		Safety Informa- tion	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit24	Request Deblocking	Deblocking	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit25	Deblocking Routine aktiv	Deblocking	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit26	HMI-message «Band remo- ve» (Kont.)	Init Poutine	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit27	Routine Closing clamp active	Normally Mode	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit28	Sensor: Clamp present	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit29	Sensor: Holdup Sensor	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit30	Alive Bit	Tool	R Bool	
R-DW0: Sta- tusword	In DW-0	Bit31	Release clamp requierd	Normally Mode	R Bool	
R-DW1: Sta- tusword	In DW-1	IM1 In 1	Statusinformation			
R-DW1: Sta- tusword	In DW-1	Bit0	Closing Cycle: Release ex- ternal parallel Process	Normally Mode	R Bool	
R-DW1: Sta- tusword	In DW-1	Bit1	Closing Cycle: Busy prarallel part is working	Normally Mode	R Bool	
R-DW1: Sta- tusword	In DW-1	Bit2	ReadyToReset PartStatus- Bits	Normally Mode	R Bool	
R-DW2	In DW-2	IN1 In 2	Manual Mode			
R-DW3	In DW-3	IN1 In 3	Closing force	Normally Mode	R Real	x
R-DW4	In DW-4	IN1 In 4	Cycle time	Normally Mode	R Real	y
R-DW5	In DW-5	IN1 In 5	Total cycle counter	Service	R Int	y (x)
R-DW6	In DW-6	IN1 In 6	Service Cycle counter	Service	R Int	
R-DW7	In DW-7	IN1 In 7	Actual position motion link	Tool	R Real	
R-DW8	In DW-8	IN2 In 0	Actual position pulling unit	Tool	R Real	
R-DW9	In DW-9	IN2 In 1	PID Pulliung force: Gain force cotrol	Tool PID Cont- roller	R Real	
R-DW10	In DW-10	IN2 In 2	PID Pulliung force: Reset time force control	Tool PID Cont- roller	R Real	
R-DW11	In DW-11	IN2 In 3	PID Pulliung force: Ratetime force control	Tool PID Cont- roller	R Real	
R-DW12	In DW-12	IN2 In 4	-			
R-DW13	In DW-13	IN2 In 5	Status message	Error Handling	R Int	
R-DW14	In DW-14	IN2 In 6	Force holding Time (Closing clamp)	Tool	R Int	
R-DW15	In DW-15	IN2 In 7	Time laboratory mode	Laboratory-mo- de	R Real	
R-DW16	In DW-16	IN3 In 0	Remaining time laboratory mode	Laboratory-mo- de	R Real	
R-DW17	In DW-17	IN3 In 1	Max. pieces in laboratory mode	Laboratory-mo- de	R Int	

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
R-DW18	In DW-18	IN3 In 2	Remaining pieces in labora- tory mode	Laboratory-mo- de	R Int	
R-DW19	In DW-19	IN3 In 3	Home position motion link	Parameter mo- tion link	R Real	
R-DW20	In DW-20	IN3 In 4	Insert position motion link	Parameter mo- tion link	R Real	
R-DW21	In DW-21	IN3 In 5	Crimping position motion link	Parameter mo- tion link	R Real	
R-DW22	In DW-22	IN3 In 6	Cutting position motion link	Parameter mo- tion link	R Real	
R-DW23	In DW-23	IN3 In 7	Setting minimal crimping current	Parameter mo- tion link	R Int	
R-DW24	In DW-24	IN4 In 0	Setting maximum crimping current	Parameter mo- tion link	R Int	
R-DW25	In DW-25	IN4 In 1	Setting minimal cutting current	Parameter mo- tion link	R Int	
R-DW26	In DW-26	IN4 In 2	Setting maximum cutting current	Parameter mo- tion link	R Int	
R-DW27	In DW-27	IN4 In 3	Home position pulling unit	Parameter pul- ling unit	R Real	
R-DW28	In DW-28	IN4 In 4	Eject position pulling unit	Parameter pul- ling unit	R Real	
R-DW29	In DW-29	IN4 In 5	Max. tightening stroke	Parameter pul- ling unit	R Real	
R-DW30	In DW-30	IN4 In 6	Switch Phase 1 => Phase 2	Parameter pul- ling unit	R Int	
R-DW31	In DW-31	IN4 In 7	Tolerance Force	Parameter pul- ling unit	R Real	
R-DW32	In DW-32	IN5 In 0	PullDistance	Parameter pul- ling unit	R Real	y
R-DW33	In DW-33	IN5 In 1	Pulling force Home position	Parameter pul- ling unit	R Real	
R-DW34	In DW-34	IN5 In 2	Pulling force insert position	Parameter pul- ling unit	R Real	
R-DW35	In DW-35	IN5 In 3	CFM1: Force entry EO4	CFM EO4	R Real	y
R-DW36	In DW-36	IN5 In 4	CFM1: Force exit EO4	CFM EO4	R Real	y
R-DW37	In DW-37	IN5 In 5	CFM2: Force entry EO4	CFM EO4	R Real	y
R-DW38	In DW-38	IN5 In 6	CFM2: Force exit EO4	CFM EO4	R Real	y
R-DW39	In DW-39	IN5 In 7	CFM1: Force max value	CFM	R Real	y
R-DW40: i_Current- CFM1Mea- sProg	In DW-40	IN6 In 0	CFM1: Current measuring program	CFM		
R-DW41	In DW-41	IN6 In 1	CFM2: Force max value	CFM	R Real	y
R-DW42 : i_Current- CFM1Mea- sProg	In DW-42	IN6 In 2	CFM2: Current measuring program	CFM		
R-DW43	In DW-43	IN6 In 3	Warning	Error Handling	R Int	(y)
R-DW44	In DW-44	IN6 In 4	Tool Error	Error Handling	R Int	(y)
R-DW45	In DW-45	IN6 In 5	Process Error	Error Handling	R Int	(y)

	Ether- netIP	Profi- net	Descriptions		Data Type	Recom- mendation
R-DW46: Statusword VeriPullF	In DW-46	IN6 In 6	Statusinformation Verifica- tion Pulling unit	Verification Pul- ling force	R_Int	
b_ReqPullVer- fiAvailable	In DW-	Bit 0	It's available for a request the handling Verification pulling force (Must be true for a re- quest , else the request will be denied)	Verification Pul- ling force	R_Bool	
b_ReqPullVer- fiAck	In DW-	Bit 1	Conformation Request handling verification pulling unit is accepted	Verification Pul- ling force	R_Bool	
b_ReqPullVer- fiDone	In DW-	Bit 2	Handling Request Verifica- tion Pulling force is done	Verification Pul- ling force	R_Bool	
b_ReqPullVer- fiDenied	In DW-	Bit 3	Handling Request Verifica- tion Pulling Force is denied	Verification Pul- ling force	R_Bool	
b_StatePull- VerfiBusy	In DW-	Bit 4	Function Verification Pulling Force is active	Verification Pul- ling force	R_Bool	
b_StatePull- VerfiInsert- Clamp	In DW-	Bit 5	Function Verification Pulling Force is waiting for insert a clamp	Verification Pul- ling force	R_Bool	
b_StatePull- VerfiLocked- Clamp	In DW-	Bit 6	Function Verification Pulling Force clamp is locked	Verification Pul- ling force	R_Bool	
b_StatePull- VerfiPIDAct	In DW-	Bit 7	Function Verification Pulling Force activation control force			
b_StatePull- VerfiForce- Reached	In DW-	Bit 8	Function Verification Pul- ling Force, Target Force is reached	Verification Pul- ling force	R_Bool	
b_StatePull- VerfiDone	In DW-	Bit 9	Function Verification Pulling Force Completed waiting for next verification or Pull Force Quit.	Verification Pul- ling force	R_Bool	
b_StatePull- VerfiInter- ruptLC	In DW-	Bit 10	Function is interrupted by LightCurtain	Verification Pul- ling force	R_Bool	
b_StatePull- VerfiWarning	In DW-	Bit 11	State Warning Verification Pulling Force	Verification Pul- ling force	R_Bool	
b_StatePull- VerfiError	In DW-	Bit 12	State Error Verification Pul- ling Force	Verification Pul- ling force	R_Bool	
b_StateFunc- tionAbort	In DW-	Bit 13	Information Function is aborted	Verification Pul- ling force	R_Bool	
b_StateC- lampPresent	In DW-	Bit 14	Sensor ClampPresent is active	Verification Pul- ling force	R_Bool	
b_StateTar- FOutLimit	In DW-	Bit 15	Information Target Pulling force is out of Limits	Verification Pul- ling force	R_Bool	
R-DW47: Statusword VeriCrimpF	In DW-47	IN6 In 7	Statusinformation Verifica- tion Crimping force	Verification Crimp Force	R_Int	

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
b_ReqCrimp-VerfiAvailable	In DW-	Bit 0	It's available for a request the handling Verification Crimp (Must be true for a request , else the request will be denied)	Verification Crimp Force	R_Bool	
b_ReqCrimp-VerfiAck	In DW-	Bit 1	Conformation Request handling verification Crimp force is accepted	Verification Crimp Force	R_Bool	
b_ReqCrimp-VerfiDone	In DW-	Bit 2	Handling Verification Crimp Force is done	Verification Crimp Force	R_Bool	
b_ReqCrimp-VerfiDenied	In DW-	Bit 3	Request handling Crimp Force is denied	Verification Crimp Force	R_Bool	
b_State-CrimpForce-Busy	In DW-	Bit 4	State Function Crimp Force is active	Verification Crimp Force	R_Bool	
b_State-CrimpForceF-ControlAct	In DW-	Bit 5	State Function Crimp Force Control is active	Verification Crimp Force	R_Bool	
b_State-CrimpForce-Done	In DW-	Bit 6	State Function Zero Balance Completed waiting for next Zero Balance or Zero Balance Quit.	Verification Crimp Force	R_Bool	
b_State-CrimpForce-Warning	In DW-	Bit 7	State Warning Crimp Force Verification	Verification Crimp Force	R_Bool	
b_State-CrimpForceError	In DW-	Bit 8	State Error Crimp Force Verification	Verification Crimp Force	R_Bool	
b_State-CrimpForceAbort	In DW-	Bit 9	State Function Crimp Force Verification Abort	Verification Crimp Force	R_Bool	
b_State-CrimpForce-TarOutLimit	In DW-	Bit 10	Information Target Crimp force out of Limits	Verification Crimp Force	R_Bool	
R-DW48: Statusword ZeroBaPullF	In DW-48	IN7 In 0	Statusinformation Zero Balance	Zero Balance	R_Int	
b_ReqZBalA- available	In DW-	Bit 0	It's available for a request the handling Zero Balance (Must be true for a request , else the request will be denied)	Zero Balance	R_Bool	
b_ReqZBal- IAck	In DW-	Bit 1	Conformation Request handling Zero balance is accepted	Zero Balance	R_Bool	
b_ReqZBal- Done	In DW-	Bit 2	Handling Zero Balance is done	Zero Balance	R_Bool	
b_ReqZBal- Denied	In DW-	Bit 3	Request handling Zero Balance is denied	Zero Balance	R_Bool	
b_StateZBal- Busy	In DW-	Bit 4	Function Zero Balance is active	Zero Balance	R_Bool	
b_StateRea- dySetZero	In DW-	Bit 5	Ready for set to Zero	Zero Balance	R_Bool	

	Ethernet-IP	Profinet	Descriptions		Data Type	Recommendation
b_StateZBal-Done	In DW-	Bit 6	Function Zero Balance Completed waiting for next Zero Balance or Zero Balance Quit.	Zero Balance	R_Bool	
b_StateZBal-InterruptLC	In DW-	Bit 7	Function is interrupted by Light Curtain	Zero Balance	R_Bool	
b_StateZBal-Warning	In DW-	Bit 8	Warning Function Zero Balance	Zero Balance	R_Bool	
b_StateZBal-IErr	In DW-	Bit 9	Error Function Zero Balance	Zero Balance	R_Bool	
b_StateZBal-IAbort	In DW-	Bit 10	Function Zero Balance Abort	Zero Balance	R_Bool	
R-DW49: Statusword DriveManual	In DW-49	IN7 In 1	Statusinformation Manual Mode Drive	Manual Drive Operation	R_Int	
b_ReqManualControlAvailable	In DW-	Bit 0	It's available for a request the handling Manual Mode (Must be true for a request , else the request will be denied)	Drive Manual Mode	R_Bool	
b_ReqManualControlAck	In DW-	Bit 1	Confirmation Request handling manual mode is accepted	Drive Manual Mode	R_Bool	
b_ReqManualControlDone	In DW-	Bit 2	Handling Manual mode is done	Drive Manual Mode	R_Bool	
b_ReqManualControlDenied	In DW-	Bit 3	Request handling Manual Mode is denied	Drive Manual Mode	R_Bool	
b_StatePullingUnitAxisPowered	In DW-	Bit 4	Pulling Unit is powered	Drive Manual Mode	R_Bool	
b_StatePullingUnitReferenced	In DW-	Bit 5	Pulling unit is referenced	Drive Manual Mode	R_Bool	
b_StatePullingUnitRunning	In DW-	Bit 6	Pulling unit is moving	Drive Manual Mode	R_Bool	
b_StatePullingUnitWarning	In DW-	Bit 7	Warning from Pulling unit	Drive Manual Mode	R_Bool	
b_StatePullingUnitError	In DW-	Bit 8	Error from Pulling unit	Drive Manual Mode	R_Bool	
b_StatePullingUnitInitDone	In DW-	Bit 9	Initialization Pulling unit is finished	Drive Manual Mode	R_Bool	
b_PullingUnitOnStartPos	In DW-	Bit 10	Pulling Unit is in Start Position	Drive Manual Mode	R_Bool	
b_PullingUnitOnEjectPos	In DW-	Bit 11	Pulling Unit is in Eject Position	Drive Manual Mode	R_Bool	
b_PullingUnitOnServicePos	In DW-	Bit 12	Pulling Unit is in Service Position	Drive Manual Mode	R_Bool	
b_StateMotionLinkAxisPowered	In DW-	Bit 16	Motion Link is powered	Drive Manual Mode	R_Bool	

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
b_StateMotionLinkReferenced	In DW-	Bit 17	Motion Link is referenced	Drive Manual Mode	R_Bool	
b_StateMotionLinkRunning	In DW-	Bit 18	Motion link is moving	Drive Manual Mode	R_Bool	
b_StateMotionLinkWarning	In DW-	Bit 19	Warning from Motion link	Drive Manual Mode	R_Bool	
b_StateMotionLinkError	In DW-	Bit 20	Error from Motion link	Drive Manual Mode	R_Bool	
b_StateMotionLinkInitDone	In DW-	Bit 21	Initialization Motion link is finished	Drive Manual Mode	R_Bool	
b_MotionLinkOnHomePos	In DW-	Bit 22	Motion link is in Home Position	Drive Manual Mode	R_Bool	
b_MotionLinkOnInsertPos	In DW-	Bit 23	Motion link is in Insert Position	Drive Manual Mode	R_Bool	
b_MotionLinkOnCrimpPos	In DW-	Bit 24	Motion link is in Crimp Position	Drive Manual Mode	R_Bool	
b_MotionLinkOnCutPos	In DW-	Bit 25	Motion link is in Cut Position	Drive Manual Mode	R_Bool	
b_MotionLinkOnSafeCutPos	In DW-	Bit 26	Motion link is in Safe Cut Position	Drive Manual Mode	R_Bool	
R-DW50: Statusword FrictionTest	In DW-50	IN7 In 2	Statusinformation Friction Test	Friction test	R_Int	
b_ReqFricVerfiAvailable		Bit 0	It's available for a request the handling Friction test (Must be true for a request , else the request will be denied)	Friction test	R_Bool	
b_ReqFricVerfiAck		Bit 1	Conformation Request handling Friction test is accepted	Friction test	R_Bool	
b_ReqFricVerfiDone		Bit 2	Handling Friction test is done	Friction test	R_Bool	
b_ReqFricVerfiDenied		Bit 3	Request handling Friction test is denied	Friction test	R_Bool	
b_StateFric-TestBusy		Bit 4	Active Function: "Free State Pulling Force"	Friction test	R_Bool	
b_StateFric-TestDone		Bit 5	Function Friction Test Completed waiting for next Zero Balance or Zero Balance Quit.	Friction test	R_Bool	
b_StateFric-TestClamp-Pres		Bit 6	Clamp present	Friction test	R_Bool	
b_StateFric-TestClampLocked		Bit 7	Clamp is locked			

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
b_StateFric- TestInter- ruptLC		Bit 8	Function is interrupted by Light Curtain	Friction test	R_Bool	
b_StateFric- TestWarning		Bit 9	Warning function friction test	Friction test	R_Bool	
b_StateFric- TestError		Bit 10	Error function friction test	Friction test	R_Bool	
b_StateFric- TestAbort		Bit 11	Abort function friction test	Friction test	R_Bool	
b_StateTar- FOutLimit		Bit 12	Limit function friction test. Target out of range	Friction test	R_Bool	
R-DW51: Statusword Deblocking	In DW-51	IN7 In 3	Reserve (Deblocking)	Deblocking	R_Int	
R-DW52: i_ForcePull- Verifi	In DW-52	IN7 In 4	Result Pulling Force Verifi- cation	Verification Pul- ling force	R_Int	daN
R-DW53: i_ForceCrimp- VerifiSen1	In DW-53	IN7 In 5	Result Crimp force 1 Verifi- cation	Verification Crimp Force	R_Int	daN
R-DW54: i_ForceCrimp- VerifiSen2	In DW-54	IN7 In 6	Result Crimp Force 2 Verifi- cation	Verification Crimp Force	R_Int	daN
R-DW55: i_ZBalActPull- Froce	In DW-55	IN7 In 7	Actual Value Pulling Force Zero Balance	Zero Balance	R_Int	daN
R-DW56: i_PullingUni- tActPos	In DW-56	IN8 In 0	Position Pulling Unit	Drive Manual Mode	R_Int	mm *100
R-DW57: i_MotionLin- kActPos	In DW-57	IN8 In 1	Position Motion Link	Drive Manual Mode	R_Int	mm *100
R-DW58: i_MaxForceF- ricTest	In DW-58	IN8 In 2	Max. Force Friction test	Friction test	R_Int	daN
R-DW59: i_FricActPo- sPullUnit	In DW-59	IN8 In 3	Actual Position Pulling unit Friction Test	Friction test	R_Int	mm *100
R-DW60: i_ForcCrim- pActSen1	In DW-60	IN8 In 4	Actual Force CrimpSensor CFM1	Verification Crimp Force	R_Int	dN
R-DW61: i_ForcCrim- pActSen1	In DW-61	IN8 In 5	Actual Force CrimpSensor CFM2	Verification Crimp Force	R_Int	dN
R-DW62: i_MaxCutCur- rent	In DW-62	IN8 In 6	Max. Cutting current	Parameter pul- ling unit	R_Int	mA
R-DW63: i_MaxCrim- Current	In DW-63	IN8 In 7	Max. Crimping current	Parameter pul- ling unit	R_Int	mA
W-DW0: Steuerwort	Out DW-0	OM1 Out 0	Commad			

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
W-DW0: Steuerwort		Bit0	Start Zyklus	Normally mode	W Bool	
W-DW0: Steuerwort		Bit1	Stop Zyklus	Normally mode	W Bool	
W-DW0: Steuerwort		Bit2	Start locking the clamp	Normally mode	W Bool	
W-DW0: Steuerwort		Bit3	Acknowledge error	Normally mode	W Bool	
W-DW0: Steuerwort		Bit4	Initialization	Normally mode	W Bool	
W-DW0: Steuerwort		Bit5	ResetPartStatusBits	Normally mode	W Bool	
W-DW0: Steuerwort		Bit10	Power enable	Start mode	W Bool	
W-DW0: Steuerwort		Bit11	Bypass start power for drives	Start mode	W Bool	
W-DW0: Steuerwort		Bit12	Start deblocking	Deblocking	W Bool	
W-DW0: Steuerwort		Bit13	Ack.message "Band remove"	Normally mode	W Bool	
W-DW0: Steuerwort		Bit14	Locking Tool	Normally mode	W Bool	
W-DW0: Steuerwort		Bit15	Closing Cycle: Enable for Working after parallel Process	Normally mode	W Bool	
W-DW1: Steuerword VeriPullF	Out DW-1	OM1 Out 1	Command Function Verification Pulling Unit	Verification Pulling force	W_Int	
b_ReqPull- Verfi	Out DW-	Bit 0	Request Handling Verification Pulling force	Verification Pulling force	W_Bool	
b_StartPull- Verfi	Out DW-	Bit 1	Command Verification Pulling force Start	Verification Pulling force	W_Bool	
b_LckClamp- PullVerfi	Out DW-	Bit 2	Command Lock Clamp in function Verification	Verification Pulling force	W_Bool	
b_UnLCK- ClampPullVeri	Out DW-	Bit 3	Command Unlock Clamp in function Verification	Verification Pulling force	W_Bool	
b_ActPullVerfi	Out DW-	Bit 4	Command Start PID-Control Pulling Force	Verification Pulling force	W_Bool	
b_QuitPull- Verfi	Out DW-	Bit 5	Command Quit Routine	Verification Pulling force	W_Bool	
b_ConInterruptLCPull- Veri	Out DW-	Bit 6	Command Continue interrupt Light Curtain	Verification Pulling force	W_Bool	
b_AbortPull- Verfi	Out DW-	Bit 7	Command Abort Routine Pulling force	Verification Pulling force	W_Bool	
W-DW2: Steuerword VeriCrimpF	Out DW-2	OM1 Out 2	Command Function Verification Crimp Force	Verification Crimp Force	W_Int	
b_ReqCrimp- Verif	Out DW-	Bit 0	Request Handling Verification Crimp force	Verification Crimp Force	W_Bool	
b_StartCrimp- Verif	Out DW-	Bit 1	Command Verification Crimp Force Start Function	Verification Crimp Force	W_Bool	

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
b_LockCFM	Out DW-	Bit 2	Command Verification Crimp Force Lock CFM	Verification Crimp Force	W_Bool	
b_QuitCrimp-Verifi	Out DW-	Bit 3	Command Quit Verification Crimp Force	Verification Crimp Force	W_Bool	
b_Abort-CrimpVeri	Out DW-	Bit 4	Command Abort Verification Crimp Force	Verification Crimp Force	W_Bool	
W-DW3: Steuerword ZeroBalPullF	Out DW-3	OM1 Out 3	Command Function Zero Balance	Zero Balance	W_Int	
b_ReqZero-Balance	Out DW-	Bit 0	Request handling Zero Balance	Zero Balance	W_Bool	
b_StartZBal	Out DW-	Bit 1	Command Start function Zero Balance	Zero Balance	W_Bool	
b_SetOffsetZ-Bal	Out DW-	Bit 2	Command Set the Pulling force Sensor to Zero	Zero Balance	W_Bool	
b_QuitZBal	Out DW-	Bit 3	Command Quit Function Zero Balance	Zero Balance	W_Bool	
b_ConInter-ruptLCZBal	Out DW-	Bit 4	Command Continue inter-rupt Light curtain	Zero Balance	W_Bool	
b_AbortZBal	Out DW-	Bit 5	Command Abort Function Zero Balance	Zero Balance	W_Bool	
W-DW4: Steuerword DriveManual	Out DW-4	OM1 Out 4	Command Function Manual Mode Drive	Manual Drive Operation	W_Int	
b_ReqManu-alControl	Out DW-	Bit 0	Request handling Drive Manual Mode	Drive Manual Mode	W_Bool	
b_PullingUnit-PowerAxis	Out DW-	Bit 1	Power for Pulling Unit	Drive Manual Mode	W_Bool	
b_PullingUnit-InitAxis	Out DW-	Bit 2	Init Pulling Unit	Drive Manual Mode	W_Bool	
b_PullingUnitStartPos	Out DW-	Bit 3	Command go to Start Position Pulling Unit	Drive Manual Mode	W_Bool	
b_PullingUnitEjectPos	Out DW-	Bit 4	Command go to Eject Position Pulling Unit	Drive Manual Mode	W_Bool	
b_PullingUnit-ServicePos	Out DW-	Bit 5	Command go to Service Position Pulling Unit	Drive Manual Mode	W_Bool	
	Out DW-					
b_Motion-LinkPowerA-xis	Out DW-	Bit 9	Power for Motion Link	Drive Manual Mode	W_Bool	
b_MotionLinkInitAxis	Out DW-	Bit 10	Init for Motion Link	Drive Manual Mode	W_Bool	
b_Motion-LinkHomePos	Out DW-	Bit 11	Command go to Home Position Motion Link	Drive Manual Mode	W_Bool	
b_MotionLinkInsertPos	Out DW-	Bit 12	Command go to Insert Position Motion Link	Drive Manual Mode	W_Bool	
b_Motion-LinkCrimpPos	Out DW-	Bit 13	Command go to Crimp Position Motion Link	Drive Manual Mode	W_Bool	
b_Motion-LinkCutPos	Out DW-	Bit 14	Command go to Cut Position Motion Link	Drive Manual Mode	W_Bool	

	Eterne- tIP	Profi- net	Descriptions		Data Type	Recom- mendation
b_Motion- LinkSafeCut- Pos	Out DW-	Bit 15	Command go to Safe Cut Position Motion LinkSafe	Drive Manual Mode	W_Bool	
W_DW5: Steuerword Friction Test	Out DW-5	OM1 Out 5	Command Function Friction Test	Friction test	W_Int	
b_ReqFric- Test	Out DW-	Bit 0	Request handling Friction Test	Friction test	W_Bool	
b_StartFric- Test	Out DW-	Bit 1	Command Start function Friction test	Friction test	W_Bool	
b_LckCalm- pFricTest	Out DW-	Bit 2	Command Lock the clamp Friction test	Friction test	W_Bool	
b_UnLck- ClampFric- Test	Out DW-	Bit 3	Command Release the clamp Friction Test	Friction test	W_Bool	
b_StartFric- TestPull	Out DW-	Bit 4	Command Friction test start pulling	Friction test	W_Bool	
b_ContInter- ruptLCFric- Test	Out DW-	Bit 5	Command Continue Inter- rupt Light Curtain	Friction test	W_Bool	
b_AbortFric- Test	Out DW-	Bit 6	Command Abort Routine Friction Test	Friction test	W_Bool	
W_DW6: steuerword Deblocking	Out DW-6	OM1 Out 6	Reserve (Deblocking)	Deblocking		
W-DW7: i_TargetFor- cePullVerifi	Out DW-7	OM1 Out 7	Target Force Pulling Force Verification	Verification Pul- ling force	Int	N (400..2500)
W-DW8: i_CalValFor- cePulVerifi	Out DW-8	OM2 Out 0	Value CAL01 Verification Pulling Verification	Verification Pul- ling force	Int	N (0..5000)
W-DW9: i_ TargetForce- CrimpForce	Out DW-9	OM2 Out 1	Target Force Crimp Force Verification	Verification Crimp Force	Int	N (250..800)
W-DW10: i_ CalValFroce- CrimpVerifi	Out DW- 10	OM2 Out 2	Value CAL01 Verification Crimp Verification	Verification Crimp Force	Int	N (0..2000)
W-DW11: i_TargetPos- FricTest	Out DW- 11	OM2 Out 3	Target Position Friction test	Friction test	Int	mm (-10 .. -50)
W-DW12: i_ TargetSpeed- FricTest	Out DW- 12	OM2 Out 4	Target speed Friction test	Friction test	Int	"mm*100" /s (5 .. 100)
W-DW13:	Out DW- 13	OM2 Out 5	Unix Time stamp		Int	
W-DW14:	Out DW- 14	OM2 Out 6	Time Offset		Int	
W-DW15:	Out DW- 15	OM2 Out 7	CFM1: Measuring program		Int	(0..15)
W-DW16:	Out DW- 16	OM1 Out 0	CFM1: Measuring program		Int	(0..15)

R Real	3 decimal fraction
R Real	2 decimal fraction

x:	Values for process documentation
y	Values for build of experience

Bit0:	Manual Mode
Bit1:	Automatic Mode
Bit2:	Labor Mode 2 Hand-Control
Bit3:	Labor Mode Foot-Pedal
Bit4:	Reserve
Bit5:	Command Lokal
Bit6:	Command HW IO
Bit7:	Command Bus
Bit8:	Reserve
Bit9:	Handling Function GUI
Bit10:	Handling Function Bus

10.1.4 Addition to industrial communication

R-DW43 Warning

Hereby the messages from Section 7.4.9 (error list) are transmitted. It is the messages (warnings) 100 to 199. In these cases, 100 is subtracted from the error number, and then the number is bitwise added to the sum.

Error	Weight	Value	Description
x01	2 ¹	2	War_101 Error acknowledged
x02	2 ²	4	War_102 Check start button contacts
x03	2 ³	8	War_103 No power -> press start / and init
x04	2 ⁴	16	War_104 CFM box warning / error
x05	2 ⁵	32	War_105 Soon service necessary
x06	2 ⁶	64	War_106 Service necessary
x07	2 ⁷	128	War_107 Stop about light curtain
x08	2 ⁸	256	War_108 Mode CFM teaching activ
x09	2 ⁹	512	War_109 Drives Tool not powered
x10	2 ¹⁰	1024	War_110 No Power - activate extern enable signal, then press Start , then press Init
x11	2 ¹¹	2048	War_111 Band remove
x12	2 ¹²	4096	War_112 Abort verification pulling force
x13	2 ¹³	8192	War_113 Abort verification crimp force
x14	2 ¹⁴	16384	War_114 Stop about external stop command
x15	2 ¹⁵	32768	War_115 External Signal band lock is on
x16	2 ¹⁶	65536	War_116 EtherCAT - bus not running
x17	2 ¹⁷	131072	War_117 Init command is pending
x18	2 ¹⁸	262144	War_118 Please check function light curtain
x19	2 ¹⁹	524288	War_119 Manual Mode: Run command before last run end (Pulling Unit)
x20	2 ²⁰	1048576	War_120 Manual Mode: Run command before last run end (Motion link)
x21	2 ²¹	2097152	War_121 Friction Test Target outside tolerance
x22	2 ²²	4194304	War_122 Verification Crimp Force Target outside tolerance
x23	2 ²³	8388608	War_123 Verification Pulling Force Target outside tolerance
x24 *	2 ²⁴	16777216	War_124 Warning Friction Test
x25 *	2 ²⁵	33554432	War_125 Warning Verification Crimp Force
x26 *	2 ²⁶	67108864	War_126 Warning Verification Pulling Unit
x27 *	2 ²⁷	134217728	War_127 Warning Zero Balance
x28	2 ²⁸	268435456	War_128 Warning Change soon LC-Relay
x29	2 ²⁹	536870912	War_129 Warning LC- Relay to be changed
x30	2 ³⁰	1073741824	War_130 Release light curtain missing
x31	2 ³¹	2147483648	War_131 Stop after abort cmd

* Reserved warning but not in use

R_DW44 Tool Error

Hereby the messages from Section 7.4.9 (error list) are transmitted. It is the messages (tool errors) 200 to 299. In these cases, 200 is subtracted from the error number, and then the number is added bitwise to the sum.

Error	Weight	Value	Description
x01	2 ¹	2	ToErr_201 Band present -> remove & acknowledge
x02	2 ²	4	ToErr_202 Clamping unit not in home position STO-> Initialize
x03	2 ³	8	ToErr_203 Check pulling and cutting units
x04	2 ⁴	16	ToErr_204 Position sensor pulling unit fault
x05	2 ⁵	32	ToErr_205 Drive error active
x06	2 ⁶	64	ToErr_206 Emergency circuit open
x07	2 ⁷	128	ToErr_207 Light curtain during init sequence
x08	2 ⁸	256	ToErr_208 Verification CFM error phase 1
x09	2 ⁹	512	ToErr_209 Verification CFM error phase 2
x10	2 ¹⁰	1024	ToErr_210 Verification CFM: No force built up
x11	2 ¹¹	2048	ToErr_211 Check band scrap
x12	2 ¹²	4096	ToErr_212 CFM general warning/error
x13	2 ¹³	8192	ToErr_213 Check pulling force sensor
x14	2 ¹⁴	16384	ToErr_214 Emergency stop
x15 *	2 ¹⁵	32768	ToErr_215 Pulling unit not in home position
x16	2 ¹⁶	65536	ToErr_216 During cyle, Drives Tool lost power
x17	2 ¹⁷	131072	ToErr_217 Verification pulling force; Target force not reached
x18	2 ¹⁸	262144	ToErr_218 Tool locked from external bus-signal
x19	2 ¹⁹	524288	ToErr_219 Manual mode: More than 1 run command Pulling Unit
x20	2 ²⁰	1048576	ToErr_220 Manual mode: More than 1 run command Motion Link
x21 *	2 ²¹	2097152	ToErr_221 Error Friction test
x22 *	2 ²²	4194304	ToErr_222 Error Verification Crimp Force
x23 *	2 ²³	8388608	ToErr_223 Error Verification Pulling unit
x24 *	2 ²⁴	16777216	ToErr_224 Error Zero Balance
x25	2 ²⁵	33554432	ToErr_225 Motion Link undervoltage
x26	2 ²⁶	67108864	ToErr_226 Pulling Unit undervoltage
x27	2 ²⁷	134217728	ToErr_227 EtherCAT not running
x28	2 ²⁸	268435456	ToErr_228 Check pulling force sensor
x29	2 ²⁹	536870912	ToErr_229 CFM wrong Measuring Program

* Reserved error but not in use

R_DW45 Process Error

Hereby the messages from Section 7.4.9 (error list) are transmitted. It is the messages (process errors) 300 to 399. In these cases, 300 is subtracted from the error number, and then the number is added bitwise to the sum

Error	Weight	Value	Description
x01	2 ¹	2	PrErr_301 Max. pulling stroke exceeded
x02	2 ²	4	PrErr_302 Max. pulling time exceeded
x03	2 ³	8	PrErr_303 Crimping CFM1 envelope 1
x04	2 ⁴	16	PrErr_304 Crimping CFM1 envelope 2
x05	2 ⁵	32	PrErr_305 Crimping CFM1 NoPass
x06	2 ⁶	64	PrErr_306 Crimping CFM1 wear
x07	2 ⁷	128	PrErr_307 Crimping CFM2 envelope 1
x08	2 ⁸	256	PrErr_308 Crimping CFM2 envelope 2
x09	2 ⁹	512	PrErr_309 Crimping CFM2 NoPass
x10	2 ¹⁰	1024	PrErr_310 Crimping CFM2 wear
x11	2 ¹¹	2048	PrErr_311 General error crimping
x12	2 ¹²	4096	PrErr_312 Cutting error
x13	2 ¹³	8192	PrErr_313 Force limit exceeded
x14	2 ¹⁴	16384	PrErr_314 Max. pulling stroke exceeded
x15	2 ¹⁵	32768	PrErr_315 Closing force out of tolerance
x16	2 ¹⁶	65536	PrErr_316 Max. force at stop from light curtain
x17	2 ¹⁷	131072	PrErr_317 Max. force during move to throw-off position
x18	2 ¹⁸	262144	PrErr_318 Process interrupt
x19	2 ¹⁹	524288	PrErr_319 Max. force at stop from Bus
x20	2 ²⁰	1048576	PrErr_320 CFM1: Abort line crossed
x21	2 ²¹	2097152	PrErr_321 CFM2: Abort line crossed

10.1.5 Handling Function

The individual functions can be handled via the GUI or via industrial communication. From where the individual functions are handled must be set in the GUI.

Handlings via GUI

For individual handlings in manual mode, it is possible to change between handlings without initialization being necessary. This is the case in Verify Pull, Zero & Verify Crimp Force.




Fig. 131: Operation via GUI for the manual functions

Handlings via ind. Communication

When selecting the individual handlings in manual mode via ind. communication, the tool must always be reinitialized after exiting





Fig. 132: Operation via ind. Communication for the manual functions

10.2 Overview of the state machine in the PLC



To control the various functions via industrial communication, the corresponding function must be selected in the settings.

10.3 Control via 24-V I/O signals

As an alternative to the bus the FAST 3000 can be controlled via 24-V signals.

Details of the connection for external control at the control cabinet of the FAST 3000 can be found in the circuit diagram on pages 350, 351, 352. For further information about activating control via I/O see *Sections 7.4.5 and 7.4.7* (Settings, Tool Parameters).

11 Decommissioning, transport, storage, recommissioning

11.1 Decommissioning

If the FAST 3000 is to remain out of service for an extended period, it must be decommissioned.

- Withdraw the electrical plug.
- Clean the FAST 3000 before putting it into storage.
- Replace any defective parts.
- Store the FAST 3000 in a clean dry place and protect it from dust.

11.2 Transport

The parts of the FAST 3000 are heavy. Always use appropriate means of transport. Always use two persons when lifting the tool.

Use the transport restraint to prevent linear and rotational movement of the tool mechanism during transport.

Remove the transport restraint before recommissioning.

	CAUTION
	Risk the machine may be dropped during transport!
	<ul style="list-style-type: none"> ▶ Do not remain underneath the machine. ▶ Wear safety equipment (particularly safety shoes).

	CAUTION
	Risk of dropping the control cabinet during transport!
	<ul style="list-style-type: none"> ▶ Do not remain underneath the machine. ▶ Wear protective equipment (especially safety shoes).




Fig. 133: Transport Too

1. Transport eyes
2. Transport restraint
3. Handle

11.3 Storage

If the FAST 3000 is to remain out of service for an extended period, it must be decommissioned.

- Withdraw the electrical plug.
- Clean the FAST 3000 before putting it into storage.
- Replace any defective parts.
- Smear the mechanical parts with rust inhibitor.
- Store the FAST 3000 in a clean dry place and protect it from dust.

11.4 Recommissioning

If the FAST 3000 is to be returned into service for an extended period, it must be recommissioned.

- Check the FAST 3000 for defective parts or rust and perform any necessary repairs or maintenance.
- Perform setting up, see Section 6.1.


11.5 Disposal

The tool, all replacement parts and in particular used operating fluids or other environmentally polluting substances must be disposed of by specialist firms in accordance with applicable statutory regulations.

12 Technical data

- For use only indoors
- Temperature range 5 °C to 40 °C
- Max. relative atmospheric humidity 80 % at temperatures up to 31 °C
- 110 V or 220/230 V 50-60 Hz AC, grounded
- Closing force tolerance: ± 100 N
- Max. noise level: 75 dBA
- Machine capability $C_{mk} > 1.33$ at 1850 ± 50 N
- Closing force 800 to 2500 N

Dimensions and weight



Pos.	Component	Approximate dimensions [mm]	Approximate weight [kg]
1	Connecting cable	–	2.5
2	Control cabinet	300 x 400 x 800	40
3	Touch panel	340 x 220 x 120	2
4	Foot pedal	260 x 150 x 140	1.5
5	Two-hand control desk	465 x 190 x 120	2.5
6	Installation tool	610 x 71 x 470 (without base plate)	30
	Crimping force monitoring device	190 x 195 x 125	1

13 Troubleshooting and error messages

13.1 General instructions in the event of errors

- If the closing operation cannot be started or if functional faults occur during operation, then the technical personnel responsible for maintenance of the FAST 3000 should be contacted.
- Errors may only be corrected in a technically correct manner. If in doubt contact Oetiker (www.oetiker.com).

13.2 What should I do, if ...?

Type of error	Reason for fault	Actions to rectify fault
Closure operation will not start	Tool not switched on	Switch tool on.
	Emergency Stop button activated	Deactivate the Emergency Stop button.
	Tool not initialized	Initialize tool.
	Clamp not inserted correctly (check the strap detection signal)	Insert the clamp correctly.
	Not all the required connectors have been inserted	Insert all the connectors required for the tool.
	Incorrect operating mode	Change the operating mode settings.
	Light curtain activated and light curtain damaged	Repair the light curtain.
	The FAST 3000 is in manual mode	Switch to Automatic mode and initialize the tool.
	Power to the drives not switched on	Press the green button on the control cabinet to switch on the power to the drive.
Initialization of FAST 3000 does not function	Insert a WingGuard® strap clamp into the clamping unit	Remove the strap. To release the clamping lever, it may be necessary to remove a front cover and the strap tensioned out of the crimping cut-off head.
	Strap sensor soiled	Clean the strap sensor.
	Two-hand control panel not connected to the control cabinet	Connect the two-hand control panel to the control cabinet.
	Control cabinet defective	Send the unit back to OETIKER.
	Emergency Stop activated	Press and release the Emergency Stop button. Initialize the FAST 3000.
	Power to the drives not switched on	Press the green button on the control cabinet to switch on the power to the drive.
	One of the fuses in the control cabinet has responded	Check the control cabinet and the device. If test OK, switch on the fuse again.
	Incorrect operating mode	Change the operating mode settings.
	Light curtain activated and light curtain damaged	Repair the light curtain.
	No values stored for the parameters	Use Oetiker Service Center to reset the parameters of the PLC to the factory settings.
	Initialization cannot be performed due to the current operating state	Activate the emergency stop then deactivate it again.

Type of error	Reason for fault	Actions to rectify fault
Tool switched on, no display	Touch panel not connected to the control cabinet	Connect the touch panel to the control cabinet.
	Control cabinet defective	Send the unit back to OETIKER.
	Incorrect network address set on the display or on the controller	Set the network address correctly.
	Incorrect settings on the display	Have the display settings performed by the Oetiker Service Center.
	One of the fuses in the control cabinet has responded	Check the control cabinet and the device. If test OK, switch on the fuse again.
Clamp is crimped on only one side	Crimping jaw broken	Replace the crimping jaws as a set.
	Crimping jaw pivot pin broken	Replace the pivot pin
Strap is not cut off	Cut-off die broken	Replacing the cut-off die
	Cut-off die guide not installed correctly	Perform the installation of the cut-off die guide (see Section 9.3.3).
The crimping jaws cut into the clamp housing	Cut-off die guide not installed correctly	Perform the installation of the cut-off die guide (see Section 9.3.3).
	Incorrect horizontal positioning of the FAST 3000	Check the correct positioning of the horizontal stop, in order to ensure the correct position of the clamp housing.
	When the WingGuard® clamp is closed, the tool head is not in the right position	Check whether a part is blocking the path of the tool head to its correct position as the clamp closes.
An inserted clamp cannot be removed from the FAST 3000 during the production	The WingGuard® clamp is blocked by the pushed-in clamping lever.	Use the deblocking function (see Section 6.8.1).
	Initialization cannot be performed due to an inserted clamp	<p>If the unblocking function does not perform correctly, continue with the following steps:</p> <p>Switch the FAST 3000 off securely.</p> <p>Remove one of the front side covers and the cover of the crimping cut-off head.</p> <p>Slacken the fastening screws of the crimping cut-off head by a few revolutions and pull the head back slightly.</p> <p>The push rod of the clamping lever can now be loosened, so that the strap end of the WingGuard® clamp can be removed from the clamping unit and the head.</p> <p>Assemble the FAST 3000.</p> <p>Switch the device on and initialize it.</p>
Crimping force level too high	Crimping jaws not broken in	Close some WingGuard® clamps. The crimping jaws will broke in and the crimping force will take on the usual values.

Type of error	Reason for fault	Actions to rectify fault
Inserted clamp cannot be removed after the FAST 3000 was switched on	Drives cannot be initialized as the tool is detecting a clamp in the clamping unit.	<p>Switch off the FAST 3000.</p> <p>Remove a front cover and push the clamping lever rod in the direction of the crimping cut-off head.</p> <p>Remove the clamp strap from the crimping cut-off head. The FAST 3000 is now ready for initialization.</p> <p>Mount the front cover and switch on the FAST 3000.</p> <p>Initialize the FAST 3000.</p>
No response of the FAST 3000 to the inputs (such as the strap locking button)	The FAST 3000 is in "Control via external PLC" or "Control via I/O" mode	Deactivate "Control via external PLC" or "Control via I/O".
	The I/O module is not correctly plugged in to the PLC (connector or module)	<p>Attach the connector correctly.</p> <p>Connect the module correctly.</p>
	EtherCAT-Bus not ready for operation	Check whether all the devices are connected correctly, particularly the connections for the measurement amplifier of the tensioning forces and the connections of the crimping force monitoring devices.
Tool error	Servo drive error	Refer to the manual for the drive "LH7N".


13.3 Error messages and their resolution

13.3.1 Warnings

War_101: Error acknowledge

Errors and warnings have been acknowledged. No action necessary.

War_102: Button contact error

	NOTICE
	<p>For reasons of safety, the two start buttons on the manual control each have two channels. Every time a button is pressed, a plausibility check is performed. If the button is pressed too slowly this results in an error War_102.</p> <ul style="list-style-type: none"> ▶ Use the deblocking function (see Section 6.8.1) to move the tool into a status where initialization can be performed.

- ▶ Use the deblocking function (see Section 6.8.1)


If at the next cycle the FAST 3000 operates correctly:

- ▶ **Depress the start buttons quickly.**

If at the next cycle despite the buttons being quickly the FAST 3000 once again exhibits the same error:

- ▶ Replace the start button contacts.
- ▶ Check the wiring of the buttons.


War_103: No power supply – press Start -> Init

	NOTICE
	<p>The power supply of the drive is not activated.</p>

Remedy:

- ▶ Press the start button on the control cabinet door.
The start button will light up green.
- ▶ Initialize the device.


War_104: CFM units warning

	NOTICE
	<p>This warning occurs when the Parker PLC is unable to communicate with the Kistler units when outside of a closing process.</p>

Remedy:

- ▶ Perform an error analysis for both crimping force monitoring devices.


War_105: Service due soon

	NOTICE
	This warning occurs when the service counter reaches the cycle warning limit (cycle for service (defaulted to 100,000 cycles) - warning service cycles(defaulted to 100 cycles)), the message appears periodically every ten closures.

Remedy:

- Perform the service and reset the service counter.


War_106: Service due

	NOTICE
	This warning occurs when the service counter reaches the cycle for service (defaulted to 100,000 cycles), the message appears periodically every two closures.

Remedy:


- Perform the service and reset the service counter.

War_107: Stop triggered by the light curtain

	NOTICE
	This warning occurs when the light curtain circuit has been broken.

- Prevent the light curtain tripping.

War_108: CFM mode teach-in active

	NOTICE
	The message appears when the “CFM teach” mode is active. As long as this mode remains active, the results of the CFM will be ignored. The message appears after five closures.

Remedy:

- Activate the “CFM Production Mode setting” in the “Settings” menu “Tool Parameters” sub-menu.




Fig. 134: Set parameters Tool Page 1

War_109: No power to tool**NOTICE**

The power supply to the motion link or to the pulling drive is not activated.

Remedy:

- ▶ Restore power supply to the tool. Switch on at the green button on the control cabinet door and initialize the tool.

War_110: No power supply – external enable, press Start**NOTICE**

The power supply of the drive is not activated.

Remedy:

- ▶ Press the start button on the control cabinet door.
- ▶ The start button will light up green.
- ▶ No response to the start switch: Check that the supervisory system enable flag is present (DI or BUS “Power enable”).

War_111: Remove strap**NOTICE**

This warning appears during initialization. For safety reasons it may happen that during initialization the pulling unit moves to the ejection position and then the message appears that surplus pieces of the clamping strap must be removed.

Remedy:

- ▶ Check that there is no strap material present in the pulling unit and that the crimping cut-off head is free of foreign bodies (such as the WingGuard® clamp housing).

War_119: Manual mode: Run command before last run end(Pulling Unit)**NOTICE**

In manual mode -> Manual drive function --> pulling unit: a new command is sent before the old motion task has been completed.

Remedy:

- ▶ Change the sequence for controlling the run command in the external PLC.

War_120: Manual mode: Run command before last run end (Motion link)



NOTICE

In manual mode --> Manual drive function --> Motion Link: a new command is sent before the old motion task has been completed.

Remedy:

- Change the sequence for controlling the run command in the external PLC.

War_121: Friction Test: Target outside tolerance



NOTICE

The target values for the friction test function are outside the limits. The target values are limited to the limit values

Remedy:

- Change the target values for the end position and the speed setting for the friction test. Limits: See in the mapping list.

War_122: Verification Crimp Force: Target outside tolerance



NOTICE

The target values for the verification Crimp force test function are outside the limits. The target values are limited to the limit values.

Remedy:

- Change the target values for the end position and the Cal01 value for the verification Crimp force. Limits: See in the mapping list.

War_123: Verification Pulling Unit: Target outside tolerance



NOTICE

The target values for the verification pulling unit function are outside the limits. The target values are limited to the limit values.

Remedy:

- Change the target values for the end position and the Cal01 value for the verification pulling unit. Limits: See in the mapping list.



NOTICE

Warnings 112-118 will be described in the next manual release, listed in section 7.4.9

13.3.2 Tool errors

ToErr_201: (W) strap present -> remove & acknowledge



NOTICE

At each closure cycle a check is performed to determine whether the strap end has fallen from the clamping unit: The strap sensor checks whether the strap end is still present in the ejection position of the clamping unit. If it is, the warning War_111 is output.

During initialization the tool checks whether a strap is present or not. The check is performed before the tool seeks to position the drives in the home position. If a clamp is present in the tool and the housing is not correctly positioned, this can lead to incorrect home positions of the drives.

Remedy:

If a strap end is present in the clamping unit:

- ▶ Remove one of the front covers.
- ▶ Press the ejector tensioning rod in the direction of the crimping cut-off head and remove the strap end.




Fig. 135: Clamping unit

If the strap sensor is covered with particles of metal:

- ▶ Clean the area around the strap detection sensor. To clean the sensor it may be necessary to remove a front cover and push back the clamping unit slide.




Fig. 136: Clamping unit

If the strap sensor fails the I/O test:

- ▶ Check the function of the sensor.
- ▶ Check the connection of the strap sensor plug.
- ▶ Check the connection of the extension cable in the tool socket.
- ▶ Check the I/O module in the FAST 3000 PLC.

ToErr_202: Clamping unit not in the home position STO -> Initialize



NOTICE

Before starting the closure cycle the tool performs a safety check to determine whether the clamping unit is in its home position. (If for instance the clamping unit is set in motion inadvertently when a finger is present between the clamp and the parts to be connected, this can lead to injuries.) If the position sensor detects that the clamping unit is not in its home position, both the electrical drives are switched off. A plausibility check is performed during every closing cycle (to check whether the signal has changed its status).

Remedy:

If the tool performs initialization successfully:

The errors have been resolved.

If the clamping unit position sensor fails the I/O test:

- ▶ Check the function of the sensor.




Fig. 137: Standstill sensor

- ▶ Check the connection of the sensor cable in the tool socket.
- ▶ Check the attachment condition of the force load cell as described in the Service Instructions.
- ▶ Check the I/O module in the FAST 3000 PLC.

If the clamping unit position sensor is dirty:

- ▶ Clean the sensor.

ToErr_204: Position sensor defective

The clamping unit position sensors failed the plausibility test.



NOTICE

This error occurs when the clamping unit position sensor fails the position sensor test.

Remedy:


See Section "ToErr_202: Clamping unit not in the home position STO -> Initialize"

If the clamping unit position sensor is dirty:

- ▶ Clean the sensor.
- ▶ Check the function of the sensor.
- ▶ Check the connection of the sensor cable to the tool socket.
- ▶ Check the fastening distances of the force load cell according to the service instructions.
- ▶ Check the I/O module in the FAST 3000 PLC.

ToErr_205: Drive error active

If the green power enable button on the control cabinet door fails to light up:

	NOTICE This error occurs when a drive error is active.
---	---

- ▶ Press the green power enable button.

If one of the miniature circuit breakers in the control cabinet has tripped:

- ▶ Switch the miniature circuit breaker back on.

If the EtherCAT interfaces are not correctly connected:

- ▶ Make sure that the Ethernet cables correct are correctly connected at the control cabinet and to the force monitoring devices.
- ▶ Check the Ethernet cables for damage.


If the servo drive is not correctly installed:

- ▶ Make sure that the Ethernet cables correct are correctly connected to the servo drive amplifier in the control cabinet.

If the servo drive is experiencing an error:

- ▶ Report the cabinet to your local Oetiker Power Tool Center

ToErr_206: Emergency stop circuit open / ToErr_214: Emergency Stop

	NOTICE This error occurs when the E-Stop circuit is open.
---	--

If the emergency stop-button is pressed:

Unlatch the emergency stop button.

If the emergency stop-button is not pressed:

- ▶ Check the cabling between the emergency stop-button and the two-hand control desk.
- ▶ Check that the two-hand dongle is plugged in correctly.
- ▶ Check that the external emergency stop is connected correctly or that the thin two-hand dongle is plugged in correctly.

ToErr_207: Light curtain active during the initialization routine



NOTICE

The light curtain trips during initialization. The drives are stopped and the process is aborted.

Remedy:

- ▶ Prevent the light curtain tripping during the initialization procedure.

ToErr_208: Verifying the crimping force (phase 1)



NOTICE

The error occurs if an excessive force is present during the first phase (the lever moves at a pre-defined speed into position 1). The lever then moves back into the home position and the verification is aborted.

Remedy:

- ▶ Check for foreign bodies in the area of the crimping jaws which deform the WingGuard® clamp strap.
- ▶ Check that the correct SKS is fitted with the correct jaws.

ToErr_209: Verifying the crimping force (phase 2)



NOTICE

The error occurs if the end force (Target force) is not achieved during the second phase (the motion link moves into position 2). The motion link then moves back into the home position and the verification is aborted. (see Section 5.1)

Remedy:

- ▶ Check that the crimping force monitoring devices are correctly set.
- ▶ Check that the crimping force monitoring devices are activated.
- ▶ Check that the target value the crimping force is not too great.

ToErr_210: Verifying the crimping force: No force increase



NOTICE

The error occurs if for a period of 5 seconds during the second phase the crimping force fails to increase.

Remedy:

- ▶ Check that the crimping force monitoring devices are switched on.
- ▶ Check that the crimping force monitoring devices are correctly set.
- ▶ Check that the crimping force monitoring devices are activated.

ToErr_211: Checking the strap waste

	NOTICE
	This error occurs when a band is still detected after moving to the eject position.

Remedy:

- ▶ Move manually into the ejection position and check the respective sensor for damage.
- ▶ Check that the strap waste has been ejected.

ToErr_212: CFM general error

	NOTICE
	This error occurs when the Parker PLC is unable to communicate with the Kistler units when in the closing process.

Remedy:

- ▶ Check the crimping force monitoring devices in respect of their settings, damage and error messages.
- ▶ Restart the crimping force monitoring devices.
- ▶ For further information see the crimping force monitoring devices manual.

ToErr_213: Check pulling force sensor

	NOTICE
	During the clamping cycle the pulling force sensor checks that the value satisfies certain criteria when the motion link is in the home position and when it is in the insert position. The value (Preload force) in home position depends on various factors. The value is set in the function «Zero Balance». Typically the value is around -80N for the home position and 0N for the insert position. In the function of the setting, the value must be between -60N and -180N. If the value is greater than -60N, the value is set to -60N. If the value is less than -180N, the value is set to -180N. The tolerance is ± 20 N

Remedy:

- ▶ Check that the crimping cut-off head is installed correctly.
- ▶ Make sure that no unauthorized parts come into contact with the clamping unit of the FAST 3000 during the closing cycle (see Section 6.5.3).
- ▶ Check the tool mechanism, in particular that the linear guide of the clamping unit runs easily without jerking, and check the correct alignment of the clamping unit to the crimping head (see Section 9.5.1).
- ▶ In the “Settings” menu and the “Force verification” sub-menu, perform a zero offset of the force sensor. Caution! During this procedure, it is essential that the “Set offset to zero” button is pressed (see Section 6.8.3). This command will then determine the new value for the home position.

The screenshot shows the OETIKER control interface. At the top, there is a status bar with the OETIKER logo, date/time (2018/06/27 16:37:49), user (User: Superuser), and a language icon (UK). Below this is a 'Setting' menu with several options: 'Force verification' (selected), 'Parameter Tool', 'Pulling unit', 'Crimping', 'Zero balance', 'Force verification', 'band locking', 'Set offset to zero', 'Verification activation', 'Quit routine', and 'Quit routine'. On the right side, there are two input fields: 'Target force' with a value of 800 N and 'Ist Kraftmittelwert' with a value of 1 N. Below these, there are two more input fields: 'Ext. Force value "CAL"' with a value of 500 N and 'Average value' with a value of 0 N. At the bottom, there is a status bar with 'Local / Manual' (highlighted), a green arrow icon, and the text 'Waiting for clamp and fixation....'. On the right side of the bottom status bar, there are two counters: 'Cycle counter' with a value of 677 and 'Service counter' with a value of 99323.

- ▶ Check the scaling factor and correct it if necessary (see Section 9.5).
- ▶ After the scaling factor has been corrected, perform a zero offset and a force verification.
- ▶ Check the measurement amplifier (connections, signaling display on the measurement amplifier).

ToErr_216: During cycle, Drives Tool lost power

	NOTICE
	The power supply to the motion link or to the pulling drive has been interrupted.

Remedy:

- ▶ Restore power supply to the tool. Switch on at the green button on the control cabinet door and initialize the tool.
Make sure that the supervisory system enable flag for activating the servo drives is set, or that the bypass is activated is ("Settings" menu, "Tool parameters" sub-menu).


ToErr_217: Verification pulling force; Target force not reached

	NOTICE
	Pulling force is not reached during the verification of the Pulling Unit

Remedy:

- ▶ Repeat Verification with a new Pull Band
- ▶ Replace clamping lever (See section 9.3.6)
- ▶ Set Force Sensor scaling to 4950, by executing steps 1, 4, 7, 9 of section 9.5.2 In step 9 use 4950.
- ▶ Repeat now the verification.
Important: If ToErr 217 does not occur anymore, Adjusting the load cell according to chapter 9.5.2 is mandatory!
- ▶ Check Measurement amplifier, the load cell and the cable of the load cell
- ▶ Contact PTC

ToErr_218 Tool blocked by an external signal


	NOTICE
	The tool is blocked by the signal: W-DW0: Control Word Bit 14 locking tool

The cycle cannot be restarted as long as the signal is present.

Remedy:

- ▶ Cancel the signal.


ToErr_219: Manual Mode: More than 1 run Command Pulling Unit

	NOTICE
	In manual mode with the Manual drive function: More than one command is sent to the pulling unit device. No drive command is executed.

Remedy:


- Change the sequence into the external PLC for controlling the run command.

ToErr_220: Manual Mode: More than 1 run Command Motion Link

	NOTICE
	In manual mode with the Manual drive function: More than one command is sent to the motion link device. No drive command is executed.

Remedy:

- Change the sequence into the external PLC for controlling the run command.

	NOTICE
	ToErr_221-224 are reserved Errors but not used currently: <ul style="list-style-type: none"> ► ToErr_221 Error friction test ► ToErr_222 Error Verification Crimp Force ► ToErr_223 Error Verification Pulling Force ► ToErr_224 Error Zero Balance


ToErr_225: Motion Link undervoltage

	NOTICE
	The servo amplifier of the motion link detects an undervoltage.

Remedy:

- Switch on the voltage with the green button in the control cabinet door or via industrial communication.
- Change the tool settings to the correct connected voltage.

ToErr_226: Pulling Unit undervoltage

	NOTICE
	The servo amplifier of the pulling unit detects an undervoltage.

Remedy:

- Switch on the voltage with the green button in the control cabinet door or via industrial communication.
- Change the tool settings to the correct connected voltage.

13.3.3 Process errors

PrErr_301: Maximum pulling travel exceeded



NOTICE

The pulling travel can be limited. This can provide a check on whether the correct clamp diameter was used. (There are limitations to this function, since the WingGuard® strap end is detected even before it is fully inserted into the clamping unit.) Therefore the closure travel varies slightly (see Section 5.5.1 - 5.1.7).

Remedy:

The wrong clamp size was used:

- Use a clamp of the correct diameter.

Wrong parts to be connected were used:

- Use the correct parts.

Is the strap end broken?

- Check that the closing force is correctly set (see Section 7.4.7)
- Perform a closing force test (see the Operating Instructions).

The strap has slipped out of the clamping unit:

- Check the clamping lever, particularly its teeth, and replace it if necessary.
- Check the clamping unit slide. If it is worn, replace it.
- Check the clamping lever pivot pin. If it is worn, replace it.
- Check the clamping unit rail. If it is worn, replace it.

If the maximum pulling travel does not correspond to the required reduction in the clamp diameter:

- Adjust the max. pulling travel setting in the pulling unit parameters. For changing this setting you must be logged in as Superuser.

If the closure parameters are wrongly set:

Adjust the closure parameters (see Section 5.1.1–5.1.7).

PrErr_302: Maximum pulling time exceeded



NOTICE

This error occurs when the time spent pulling exceeds predefined time value.

Remedy:

If the closure parameters are wrongly set:

- Adjust the closure parameters (see Section 5.1.1–5.1.7).

If the holding time setting is too long:

- Reduce the holding time (see Section 5.1.7).


PrErr_303: Crimping error CFM1 envelope curve 1

	NOTICE
	<p>This error occurs when CFM Left force curve is outside of EO1.</p>

Remedy:

- ▶ Check the crimping jaws for damage and wear.
- ▶ Check the curve settings in the crimping force monitoring device 1.
- ▶ Check the FAST 3000 for correct positioning (see Section 6.5).
- ▶ Check the correct routing of the connecting cable: during closure the crimping cut-off head must push down against the housing of the WingGuard® clamp.

PrErr_304: Crimping error CFM1 envelope curve 2

	NOTICE
	<p>This error occurs when CFM Left force curve is outside of EO2.</p>

Remedy:

- ▶ Check the crimping jaws for damage and wear.
- ▶ Check the curve settings in the crimping force monitoring device 1.
- ▶ Check the FAST 3000 for correct positioning (see Section 6.5).
- ▶ Check the correct routing of the connecting cable:
During closure the crimping cut-off head must push down against the housing of the WingGuard® clamp.

If the WingGuard® clamp batch exhibits an unusual crimping force curve.

- ▶ Re-teach the force curve 2 (see Section 6.8.6).


PrErr_305: Crimping error CFM1 NoPass

	NOTICE
	<p>This error occurs when during crimping the force at the crimping jaws increases too early.</p>

Remedy:

- ▶ Check the setting of the crimping force monitoring device 1.
- ▶ Check the positioning of the FAST 3000.
- ▶ Check that the fastening screws of the crimping cut-off head are tightened to the correct tightening torque (see Section 9.3.3).
- ▶ Check the correct routing of the connecting cable:
During closure the crimping cut-off head must push down against the housing of the WingGuard® clamp.

PrErr_306: Crimping error CFM1 wear

	<div style="background-color: #003366; color: white; padding: 5px;">NOTICE</div> <p>This error occurs when CFM Left force curve EO4 exit value is higher than the enter value.</p>
---	--

Remedy:

- ▶ Check the crimping jaws for wear.
- ▶ Check the setting of the crimping force monitoring device 1.
- ▶ Check the positioning of the FAST 3000.
- ▶ Check the correct routing of the connecting cable:
During closure the crimping cut-off head must push down against the housing of the WingGuard® clamp.
- ▶ If the WingGuard® clamp is subjected to guidance by parts other than the crimping cut-off head, make sure that this additional guidance is correctly centered relative to the crimping cut-off head.
In addition, we recommend that the additional guidance is not too precise, instead it must allow approx. 0.7 mm clearance on each side of the clamp strap.
- ▶ If necessary, adjust the parameter "Tool wear value", see Sections 5.2.4 and 7.4.7.

PrErr_307: Crimping error CFM2 envelope curve 1

	<div style="background-color: #003366; color: white; padding: 5px;">NOTICE</div> <p>This error occurs when CFM Right force curve is outside of EO1.</p>
--	---

Remedy:

- ▶ Check the crimping jaws for damage and wear.
- ▶ Check the curve settings in the crimping force monitoring device 2.
- ▶ Check the positioning of the FAST 3000 (see Section 6.5).
- ▶ Check the correct routing of the connecting cable:
During closure the crimping cut-off head must push down against the housing of the WingGuard® clamp.

PrErr_308: Crimping error CFM2 envelope curve 2

	<div style="background-color: #003366; color: white; padding: 5px;">NOTICE</div> <p>This error occurs when CFM Right force curve is outside of EO2.</p>
---	---

Remedy:

- ▶ Check the crimping jaws for damage and wear.
- ▶ Check the curve settings in the crimping force monitoring device 2.

Check the positioning of the FAST 3000 (see Section 6.5).

- ▶ Check the correct routing of the connecting cable:
During closure the crimping cut-off head must push down against the housing of the WingGuard® clamp.

If the WingGuard® clamp batch exhibits an unusual crimping force curve.

- ▶ Re-teach the force curve 2 (see Section 6.8.6).

PrErr_309: Crimping error CFM2 NoPass**NOTICE**

This error occurs when during crimping the force at the crimping jaws increases too early.

Remedy:

- ▶ Check the setting of the crimping force monitoring device 2.
- ▶ Check the positioning of the FAST 3000.
- ▶ Check that the fastening screws of the crimping cut-off head are tightened to the correct tightening torque (see Section 9.3.3).
- ▶ Check the correct routing of the connecting cable:
During closure the crimping cut-off head must push down against the housing of the WingGuard® clamp.

PrErr_310: Crimping error CFM2 wear**NOTICE**

This error occurs when CFM Right force curve EO4 exit value is higher than the enter value.

Remedy:

- ▶ Check the crimping jaws for wear.
- ▶ Check the setting of the crimping force monitoring device 2.
- ▶ Check the positioning of the FAST 3000.
- ▶ Check the correct routing of the connecting cable: during closure the crimping cut-off head must push down against the housing of the WingGuard® clamp.
- ▶ If the WingGuard® clamp is subjected to guidance by parts other than the crimping cut-off head, make sure that this additional guidance is correctly centered relative to the crimping cut-off head. In addition, we recommend that the additional guidance is not too precise, instead it must allow approx. 0.7 mm clearance on each side of the clamp strap.
- ▶ If necessary, adjust the parameter "Tool wear value", see Sections 5.2.4 and 7.4.7.

PrErr_311: General error at crimping**NOTICE**

This error occurs when the current of the motion link exceeds predefined limits during the crimping phase. The limits are given by the variables min. crimp current and max. crimp current, they are set by default at 500mA and 3000mA.

Remedy:

Subject the WingGuard® clamps closed during this cycle to visual inspection for defects especially in the wing formation area.

If a crimping jaw is broken:

- ▶ Replace both crimping jaws.

If the crimping wedge is exhibiting wear:

- ▶ Replace the crimping wedge.

If the crimping jaw pivot pins are exhibiting wear:

- ▶ Replace the crimping pivot pins.

If the FAST 3000 is not correctly positioned:

- Move the FAST 3000 into the correct position (see Section 6.1).

If the crimping cut-off head is being pulled upwards by the connecting cable:

- Arrange for the connecting cable (see Section 6.1) to be better secured.

If adjoining parts are obstructing the free movement of the FAST 3000:

- Ensure that the FAST 3000 can move freely and not accidentally come into contact with other parts.

If the current of the drive link is not within the predefined limits during the crimping process:

- Have the limit values for the current of the motion link (crimping) adjusted by the Oetiker service team.
- Replace or repair the drive if it has an excessive current consumption.
- Check whether the crimping head and the motion link are intact and easy to move.

PrErr_312: Error at cutting off



NOTICE

This error occurs when the current of the motion link exceeds predefined limits during the cutting phase. The limits are given by the variables min. cut current and max. cut current, they are set by default at 500mA and 3000mA.

Remedy:

Subject the cut-off die to a visual inspection for defects.

If the cut-off die is broken:

- Replace the cut-off die.

If the current of the drive link is not within the predefined limits during the cutting process.

- Have the limit values for the current of the motion link (cutting) adjusted by the Oetiker service team.
- Replace or repair the drive if it has an excessive current consumption.
- Check whether the crimping head and the motion link are intact and easy to move.

PrErr_313: Force overshoot



NOTICE

This error occurs when the pulling force is above the tolerance of the target force during the first and second phase. Tolerance is set by default at +/-100N.

Remedy:

- Check that the closure parameters are correctly set.
- Increase the switch point reduction or reduce the speed phase 1 and speed phase 2.

PrErr_314: Max. pulling stroke exceeded

NOTICE

Pulling force is greater than target force + tolerance in force control during the third phase. Tolerance is set by default at +/-100N.

Remedy:

- ▶ Check closing force graph on the closing data tab. Is it oscillating? If yes, make sure that there are no external oscillations coupled into the system.
- ▶ If the application permits it, reduce the closing force holding time to a smaller value. See section 7.4.2
- ▶ Contact PTC with a picture of the closing force graph

PrErr_315: Closing force outside tolerance

NOTICE

This error occurs when the closing force is outside of its tolerance range. The closing force correspond to the average of the last 40 measured values (40*2ms). Tolerance is set by default at +/-100N.

Remedy:

If the closure parameters are not correctly set:

- ▶ Check the curve profile (see Section 5.1).
- ▶ Adjust the closure parameters (see Section 5.1.1–5.1.7).
- ▶ Check that no external influences are preventing the correct control of the closing force.
- ▶ Check the tool mechanism, in particular that the linear guide of the clamping unit runs easily without jerking, and check the correct alignment of the clamping unit to the crimping head (see Section 9.5.1).




Fig. 138: Closing parameters

PrErr_316: Max force when the light curtain breached



NOTICE

This error occurs if the predefined force threshold is reached and the Light Curtain has been broken.

Remedy:

- ▶ Prevent the light curtain being breached during the cycle.
- ▶ Check that the light curtain system is correctly installed and operational.

PrErr_317: Max force travel in ejection position



NOTICE

After the strap has been cut off the pulling force is monitored during the journey to the ejection position. During this time the force should be almost 0 N, otherwise the strap has not been correctly cut off.

Remedy:

- ▶ Check the cut-off die.
- ▶ Check the pulling force sensor.
- ▶ Check that no external influences are preventing the correct control of the closing force.
- ▶ Check the tool mechanism, in particular that the linear guide of the clamping unit runs easily without jerking, and check the correct alignment of the clamping unit to the crimping head (see Section 9.5.1).
- ▶ Check the cut edge of the end of the strap at the WingGuard® clamp.
- ▶ If the cut edge is not square, the cut-off die may be defective.

PrErr_318: Process aborted



NOTICE

This message appears when the process has been aborted. As a rule it appears as a second or later message after the first message has been acknowledged.

Remedy:

- ▶ Acknowledge the message.

PrErr_319: Max force reached on interruption by bus stop



NOTICE

This error occurs if during the clamping cycle a stop command is sent via the communication system.

Remedy:

- ▶ Check the operation of the supervisory system.

14 Appendix

- Circuit diagram
- Industrial communication
- EU Declaration of Conformity
- Oetiker production checklist
- FAST 3000 capability measurements
- Control cabinet test certificate
- HBM force sensor test certificate
- Kistler test certificates
- Operating Instructions for crimping force monitoring devices

15 Help and Support

If you need help or technical support, contact your local Oetiker Service Center.

For further information see www.oetiker.de.

EMEA	
E-mail	ptsc.hoe@oetiker.com
Tel. number	+49 7642 6 84 0

America & Canada	
E-mail	ptsc.oea@oetiker.com
Tel. number	+1 989 635 3621

China	
E-mail	ptsc.cn.tianjin@oetiker.com
Tel. number	+86 22 2697 1183

Japan	
E-mail	ptsc.jp.yokohama@oetiker.com
Tel. number	+81 45 949 3151

South Korea	
E-mail	ptsc.kr.seoul@oetiker.com
Tel. number	+82 2 2108 1239

India	
E-mail	ptsc.in.mumbai@oetiker.com
Tel. number	+91 9600526454

