


ROLLER BLIND FITTING INSTALLATION GUIDE

CASSETTE HEADRAIL

The installation of this product should be conducted by someone competent in DIY. Please read the instructions before installing or operating this product. If in doubt, consult a professional. Please take care when unpacking your blind, do not use a knife or any sharp object.

PARTS IDENTIFIED	TOOLS REQUIRED	ADDITIONAL PARTS
	 Pencil  Screwdriver  Drill  Tape Measure	 Screws*  Brackets


* Before you start fitting your blind make sure the screws are suitable for the surface you are fitting into. Some surfaces will require wall plugs and different screws to the ones we provide.

FITTING INSTRUCTIONS

1. MEASURE

Measure 50mm inside each side of your window frame.


This is where the brackets need to be fitted. Additional brackets to be spaced evenly.



2. FIX BRACKETS

Choose whether you need to fit your brackets via top fix or face fix. Hold the brackets up to the pencil marks made in Step 1. Mark the relevant hole with a pencil.


Drill holes and use suitable screws to fix the brackets. With a spirit level, check the brackets are level.



3. HOOK, TILT, CLICK

Hook ridge of cassette into lip of bracket.


Push and tilt cassette until it clicks into place.



4. FIX THE P-CLIP

Secure chain inside of P-Clip and screw into the wall.

Ensure the chain is fully taut.




GRAHAM & BROWN

OPERATING YOUR BLIND

Pull the chain to raise and lower your blind.

Do not continue pulling when the blind is fully retracted as you will damage it.




REMOVING THE BLIND

Unclip from Brackets

Press the release tab on all brackets.

Tilt cassette backwards and ease out of brackets.



CLEANING INSTRUCTIONS

Use a dry lint free cloth to wipe over the fabric of the blind.


WARNING

Young children can be strangled by loops in pull cords, tapes and inner cords that operate the product.

To avoid strangulation and entanglement, keep cords out of reach of young children.

Cords may become wrapped around a child's neck. Move beds, cots and furniture away from window covering cords.

Do not tie cords together. Make sure cords do not twist and create a loop.



GRAHAM & BROWN