

Shear Assessment for Cell-Culture Clarification in a Disc-Stack Centrifuge

Naveenganes Muralidharan, Tyler Younger, Grace Chan, and Mark Davis

Clarification of bulk cell-culture broth is the first step in biologics purification. Solid particles such as cells and cellular debris are removed, and the resulting material is processed through 0.2- μm filters in preparation for primary affinity-chromatography steps. Typically, clarification involves either two-stage depth filtration or centrifugation followed by one-stage depth filtration. Beckett reports that although two-stage, cellulose-based depth filters are an established clarification technology, associated cost and space constraints limit depth-filtration—only processes to culture volumes of 4,000 L (1). For larger capacities, biomanufacturers prefer to use a disc-stack centrifuge (DSC) for the first clarification step (1).

DSC processes can be scaled up by maintaining a constant ratio of centrifuge feed-flow rate (Q) to gravity equivalent settling area (Σ). The latter variable represents the area required for particle settling under gravity for specific operation conditions and

PRODUCT FOCUS: Antibodies and other recombinant proteins


PROCESS FOCUS: Purification

AUDIENCE: Process development and manufacturing

KEYWORDS: Clarification, scale-up, particle settling, particle-eddy length, tip speed, power dissipation

LEVEL: Intermediate

Figure 1: Fluid and particle flow between discs in a disc-stack centrifuge



equipment designs (2). Thus, the Q/Σ ratio serves as a surrogate measure of a centrifuge's particle-settling capacity. Application of the ratio assumes that the solid particles subjected to centrifugal force are shear resistant and that they remain intact during centrifugation. However, mammalian cells are sensitive to shear, and damaging them can release intracellular components — e.g., host-cell DNA (hcDNA), proteins (HCPs), and proteases — that increase impurity loads in clarified harvest material and that reduce therapeutic-protein levels in resulting products (3, 4).

As companies transition biologics production from small-scale processes in single-use equipment to large-scale manufacturing, process engineers must consider the effects of shear from DSCs. Operating conditions for such equipment should be selected based on a design space that balances particle-

settling capacity (Q/Σ) and shear. Although available literature includes extensive discussions about the Q/Σ ratio, it provides no straightforward scale-up methodology for assessing shear generated during disc-stack centrifugation. Herein, we discuss three methods for shear assessment in a DSC as a function of centrifuge design and operational parameters: the eddy-length, tip-speed, and power-dissipation models. Furthermore, we illustrate the operational design space for a DSC, showing a balance between particle-settling capacity and shear.

METHOD 1: PARTICLE-EDDY LENGTH Fluid-Flow Velocity (v_L): The particle-eddy length model assumes that fluid flow between the disc spacing is laminar, that flow is divided evenly among all available disc spaces, and that settled particles do not return to the annular spaces between discs (5).

Abbreviations for Equations

A_{avg} : average cross-sectional area for fluid flow between disc spacing

C_d : drag coefficient

CDI: cell damage index

d_p : particle diameter

$d_{p,min}$: minimum particle diameter

EDR: energy dissipation rate

ϵ_p : cell-specific EDR

Σ : gravity-equivalent setting area

F_d : drag force

g : gravitational acceleration

h : distance between centrifuge discs

LDH: lactate dehydrogenase (in ppm)

ℓ_{eddy} : Kolmogorov particle-eddy length

N : centrifuge bowl speed (in RPM)

n_{ds} : number of centrifuge-disc spaces

P_{dis} : power dissipation in disc-stack centrifuge feed zone

ρ_L : fluid dynamic density

ρ_p : particle density

Re_p : Reynolds number for a particle in flowing fluid

R_i : inner disc radius

R_o : outer disc radius

Q : centrifuge feed-flow rate

t_{RB} : residence time in centrifuge bowl

t_c : cell residence time along the axial distance in the annular disc space

τ_{avg} : average shear stress for fluid flow over the rotating surface of a disc

τ_{max} : maximum shear stress for fluid flow over the rotating surface of a disc

Θ : half-cone angle of disc (in radians)

ϑ_f : fluid velocity between the disc space

ϑ_L : fluid-flow velocity

ϑ_p : relative particle velocity (slip velocity)

ϑ_{pcf} : velocity of a particle under centrifugal force

ϑ_p : tip velocity of centrifuge disc

μ_L : fluid dynamic viscosity

V_b : centrifuge-bowl volume

ω : centrifuge-bowl angular velocity

ν : fluid kinematic viscosity

Equations 1-7: Shear assessment based on the eddy-length method

$$\text{Equation 1: } \vartheta_L = \frac{Q}{n_{ds} \times A_{avg}} ; A_{avg} = 2 \times \pi ((R_o + h)^2 - R_o^2) + ((R_i + h)^2 - R_i^2)^*$$

$$\text{Equation 2: } \vartheta_{pcf} = \frac{d_p^2 (\rho_p - \rho_L) \times \omega^2 \times R}{18\mu_L} ; \omega = \frac{2 \times \pi \times N}{60}$$

$$\text{Equation 3: } F_d = C_d \frac{\rho_L}{2} \vartheta_p^2 \left(\frac{\pi d_p^2}{4} \right) ; \vartheta_p = \vartheta_{pcf} - \vartheta_f ; C_d = \frac{24}{Re}^{**}$$

$$\text{Equation 4: } Re_p = \frac{\rho_L \times d_p \times \vartheta_p}{\mu_L} \quad \text{Equation 5: } EDR = F_d \times \vartheta_p$$

$$\text{Equation 6: } \epsilon_p = (EDR \div \left(\frac{\pi d_p^3}{6} \right)) \div \rho_L \quad \text{Equation 7: } \ell_{eddy} = \left(\frac{\nu^3}{\epsilon_p} \right)^{1/4}$$

* A_{avg} is the average cross-sectional area between the outer and inner radii of concentric discs.

** This expression is for spherical particles in a Stokes-flow regime.

Given those assumptions, Equation 1 calculates the velocity of fluid flowing through the annular spaces between discs (Figure 1A) (5). Here, Q represents the centrifuge feed flow rate in m^3/s , n_{ds} denotes the number of disc spaces, and A_{avg} is the average cross-sectional area for fluid flow between the disc spacing. R_o and R_i are the outer and inner radii of a centrifuge's conical discs, and h is the distance or spacing between discs.

Particle Velocity Under Centrifugal Force (ϑ_{pcf}) in Static Fluid Conditions: As a centrifuge bowl rotates, centrifugal force accelerates particles outward from the center axis. Equation 2 gives the centrifugal velocity of a particle in a static liquid (5). Therein, ρ_L and μ_L represent the fluid's dynamic density and dynamic viscosity, respectively; $\rho_L = 1015 \text{ kg/m}^3$ and $\mu_L = 1.05 \times 10^{-3} \text{ P.s}$ are good approximations for a typical cell-culture broth at harvest (4, 6). The variable d_p denotes the particle diameter.

Maschke et al. report that Chinese hamster ovary (CHO) cell size follows a Gaussian normal distribution ranging 10–20 μm and with an expected average size of $\sim 14.45 \mu\text{m}$ (16). Thus, d_p often is assumed to be $14.5 \mu\text{m}$ for applications of cell-culture harvest (4). However, a more stringent value of $20 \mu\text{m}$ is recommended in DSC applications for cell recirculation to bioreactors operating in perfusion mode because most types of (viable) mammalian cells can range in size up to $20 \mu\text{m}$ in diameter. N is the centrifuge bowl speed in rotations per minute (RPM), ω is the angular velocity (in 1/s), and R is the radius of rotation.

For shear assessment, R is assumed to be R_o as a conservative approach.

Drag Force (F_d): Drag force refers to the force of friction on a particle that resists its motion through a fluid. Under centrifugation, bulk fluid flows opposite to particles' settling direction, and during settling, particles experience a drag force due to relative motion between the fluid and particles. Drag acts in the direction opposite to a particle's motion (the same direction as fluid flow). Therefore, the *relative particle velocity*, also called the *slip velocity* (ϑ_p), equals the difference between the particle centrifugal settling velocity for a static liquid (ϑ_{pcf}) and the fluid velocity between the disc space (ϑ_f) (Figure 1B). Balance between the drag force and centrifugal force acting on the particles enables those particles to achieve a constant ϑ_p velocity (7).

Based on Stokes's law, Equation 3 gives the drag force that acts on a moving particle placed in a fluid flowing in the opposite direction (8). The formula depends on four assumptions: As particles pass through a centrifuge, they remain spherical in shape and do not aggregate or break. Particle concentration in the suspension is low enough to prevent settling hindrances. Centrifuged particles move in a radial direction and do not move tangentially at any time during the process. And particle-settling velocity falls in the laminar-flow (Stokes) region; thus, the Reynolds number (Re) should be < 0.4 throughout the process.

Drag Coefficient (C_d): For spherical particles in a Stokes-flow regime, C_d is

Because lactate dehydrogenase is released during cell rupture, analysts often use it during shear assessments as an indicator of **CELL DAMAGE**.

calculated as a function of the Re value, as shown in Equation 3 (9–11).

The *Reynolds number* is a dimensionless quantity calculated as the ratio of inertial to viscous forces within a fluid flow, assuming that inertial force causes the flow and that viscous force resists it. Therefore, flows with low Re values are characterized as laminar and smooth, whereas flows with high values are deemed to be turbulent. Clark and Blanch consider $Re < 0.4$ to be a laminar-flow (Stokes) regime, $Re = 0.4–500$ to be a transition-flow (Allen) regime, and $Re > 500$ to be a turbulent-flow (Newton) regime (9). The writers also report that cell and protein settling under centrifugation typically occurs under a laminar (Stokes) regime (9). As shown in Equation 4, Mei presents an expression for determining the Re value for a moving particle in flowing liquid (12, 13).


Energy Dissipation Rate (EDR):

During settling in a centrifugation process, the EDR represents how quickly a flowing fluid loses kinetic energy as particles move through and experience drag. The rate depends on both particle speed and drag-force magnitude (Equation 5) (8). The specific EDR (ϵ_p) per cell equals the EDR divided by the cell volume (Equation 6) (8).

Kolmogorov Eddy Length (ℓ_{eddy}):

During centrifugation, a fluid's kinetic energy dissipates from large eddies and cascades into smaller ones. Eddies that are shorter than a cell's diameter can kill the cell. Equation 7 shows how to calculate the Kolmogorov eddy length, which for our purposes represents the shortest eddy in a centrifugation process. An ℓ_{eddy} value can be used as a scalable parameter to maintain the same amount of cell shear across DSCs (9). In Equation 7, ν refers to a fluid's kinematic viscosity (m^2/s).

Figure 2: Demonstration of shear prediction for a disc-stack centrifuge using the Kolmogorov eddy-length method; Est. = estimated value, LDH = lactate dehydrogenase concentration, Prb. = probability, Std. Err. = standard error



Equations 8–10: Particle-settling capacity

$$\text{Equation 8: } Q/\Sigma = Q \div \frac{2\pi n\omega^2 (R_o^3 - R_i^3)}{3g \tan \Theta}$$

$$\text{Equation 9: } \frac{(\rho_p - \rho_L) \times g \times d_p^2}{18\mu_L} = Q/\Sigma \rightarrow d_{p,\min} = \left((Q \div \Sigma) \times \frac{18\mu_L}{(\rho_p - \rho_L) \times g} \right)^{1/2}$$

$$\text{Equation 10: } g\text{-force} = \frac{R_o \times \omega^2}{g}$$

Equations 11–15: Shear assessment based on the tip-speed method

$$\text{Equation 11: } \tau_{\max} = 0.322 \times \mu_L \times \vartheta_{\text{tip}} \times \left(\frac{\rho_L \times \vartheta_{\text{tip}}}{\mu_L \times R} \right)^{1/2}; \vartheta_{\text{tip}} = \frac{2 \times \pi \times R_o \times N^*}{60}$$

$$\text{Equation 12: } \tau_{\text{avg}} = \frac{\tau_{\max,o} + \tau_{\max,i}}{2}$$

$$\text{Equation 13: } t_s = \frac{\pi \times (R_o^2 - R_i^2) \times d_\alpha}{Q}; d_\alpha = \frac{R_o - R_i}{\sin \Theta}$$

$$\text{Equation 14: } \text{CDI} = k \times \tau_{\text{avg}}^\alpha \times t_s^\beta \quad \text{Equation 15: } \text{LDH} = 3.8 \times \tau_{\text{avg}}^{1.3} \times t_s^{0.43}$$


* $R = R_o$ for τ_{\max} at R_o ; $R = R_i$ for τ_{\max} at R_i

Cell Damage Index (CDI) and Model Fitting: Lactate dehydrogenase (LDH) is an enzyme present in mammalian cells. Because it is released during cell rupture, analysts often use it during shear assessments as an indicator of cell damage. For instance, Shekhawata et al. present shear-stress values for a cell-culture clarification process using a Culturefuge 100 (BTPX305H) DSC system from Alfa Laval (13). The team applied computational fluid dynamics (CFD) to predict shear levels, then verified the resulting projections against measured LDH values for different combinations of centrifuge bowl speed and feed flow rate.

Using the writers' LDH values as response variables and using ℓ_{eddy}

values calculated from Equation 7 as explanatory variables, we applied the Fit Model function and Standard Least Squares personality in JMP software (version 16.0) to evaluate the eddy-length model's prediction of shear levels in a DSC system (Figure 2). Figure 2 shows a linear relationship between LDH concentrations and calculated ℓ_{eddy} values. The data exhibited p -values of 0.0008 and <0.0001 for the eddy length and intercept, respectively. Both values are <0.05, indicating that the strength of association between the input variable (ℓ_{eddy}) and output prediction (LDH concentration) has a high degree of statistical significance. Thus, application of a constant ℓ_{eddy} value

Figure 3: Setting an operational design space for a BRPX 618 HGV-34 disc-stack centrifuge (Alfa Laval)



Because an LDH concentration of ~1,200 ppm is recommended to set a shear-proof design space, ℓ_{eddy} values should be set to <22 μm as part of a **CONSERVATIVE** approach.

damage during most CHO-cell cultures (17). Because most mammalian cells are <20 μm in diameter (8), setting ℓ_{eddy} to <20 μm should ensure that a centrifuge operates in a shear-proof zone. However, in a study on CDIs, Shekhawat et al. recommend an LDH concentration of ~1,200 ppm for a shear-proof design (13). That value is equivalent to an ℓ_{eddy} length of 22 μm . Therefore, a conservative approach requires that ℓ_{eddy} values be set to <22 μm .

Setting a DSC Design Space — Gravitational Force: The relative centrifugal force (g-force) is radial force generated by rotation in a centrifuge relative to gravitational force (Equation 10) (4). Doran explains that DSCs are designed to generate 5,000–15,000g to minimize settling time and centrifuge processing time (18). Cell-culture harvest is a clean process but not a sterile one. Thus, manufacturers aim to complete DSC harvest operations for large-scale (20,000-L) cultures in four to six hours to minimize microbial proliferation. Pham (4) and Monica, Whiteley, and Aktiengesellschaft (19) indicate that they have applied 6,500–7,500g and 8,000–9,000g, respectively, for DSC-based cell-culture harvest. We set the g-force to >5,000g for timely process completion.

Figure 3 presents a contour plot showing ℓ_{eddy} , g-force, Q/Σ , and $d_{p,\text{min}}$ values as a function of centrifuge feed-flow rate and bowl speed. Values were generated for a 60-L BRPX 618 HGV-34 DSC system (Alfa Laval) used in our company's biomanufacturing facility, which can perform cell cultures of 20,000 L. The plot displays both risk zones related to shear and settling

could be an effective method of shear assessment during DSC-process scale-up.

Particle-Settling Capacity of the Centrifuge: To maintain the same settling capacity across different makes and models of centrifuges, we applied a constant Q/Σ ratio. Equation 8 shows how to calculate that ratio for a DSC (4, 9). Therein, g denotes gravitational acceleration (9.8 m/s^2), and θ represents the half-cone angle of centrifuge discs (in radians). Centrifuge manufacturers typically report that angle in degrees ($^\circ$), but the half-cone angle can be converted from degrees to radians by multiplying the angle by a factor of $\pi/180^\circ$.

Stokes's law for the settling of solid particles enables calculation of the smallest particle size that can be removed under centrifugation (Equation 9) (4, 9). Ambler reports that such calculations are based on sigma theory and thus give nominal rather than absolute values (14). Pham adds that only 50% separation efficiency is

achieved for the calculated particle size ($d_{p,\text{min}}$) for a given Q/Σ ratio (4).

Setting a Design Space for DSC Operation — Cutoff Criteria for Settling Capacity:

Pham reports an average particle size of 0.5 μm for a cell-culture harvest clarified using a DSC (4). Parau et al. report that MilliporeSigma's Millistak DOHC filters — which can be used as the first stage in a two-step, cellulose-based depth-filtration process — have a nominal rating of 0.6–9 μm (15). Biomanufacturers often apply such filters and DSCs interchangeably depending on operational scale (1). Thus, setting a cutoff value ($d_{p,\text{min}}$) of <0.6 μm is a good approach for controlling particle size and settling capacity in a DSC-operation design space.

Setting a Design Space for DSC Operation — Eddy Length:

For CHO cells in the stationary phase of growth, Maschke et al. observe an average cell size of $13.57 \mu\text{m} \pm 1.02 \mu\text{m}$ (16). Nienow reports that maintaining eddy sizes of >18 μm should prevent fluid-dynamic

Equations 16–19: Shear assessment based on the power-dissipation method

Equation 16: $P_{dis} = (0.5 \times Q \times \rho_L \times R_o^2 \times \omega^2) + (0.5 \times Q \times \rho_L \times (R_o^2 - R_i^2) \times \omega^2)$

wherein, $\omega = \frac{2 \times \pi \times N}{60}$

Equation 17: $t_{RB} = \frac{V_b}{Q}$ **Equation 18:** $CDI = LDH \text{ (ppm)} = k \times P_{dis}^\alpha \times t_{RB}^\beta$

Equation 19: $LDH \text{ (ppm)} = 0.16 \times P_{dis}^{0.98} \times t_{RB}^{1.4}$

capacity and an operational space that prevents cell damage while maintaining a reasonable settling capacity. The figure also indicates a narrow Q/Σ range (3.1×10^{-9} m/s to 4.1×10^{-9} m/s) as the preferred operating zone. For cell-culture clarification using a DSC, Pham recommends a Q/Σ value ranging from 10^{-9} m/s to 2.6×10^{-8} m/s (4). However, experiments described by Maybury et al. and Iammarino et al. show a 6–10% reduction in clarification efficiency as Q/Σ increases from 3.4×10^{-9} m/s to 1.35×10^{-8} m/s (20, 21). Those observations align with the centrifuge design space presented in Figure 3.

METHOD 2: TIP SPEED

Average Shear Stress: Boychyn et al. state that the maximum level of shear stress (τ_{max}) for fluid flow over the rotating surface of a disc can be determined using Equation 11 (22). Therein, v_{tip} represents the tip velocity of a disc at radius R . The mean shear across a disc is given by averaging the shear levels at the outer and inner disc radii (R_o and R_i , respectively) (Equation 12).

Shear-Stress Exposure Time:

The degree to which shear harms mammalian cells depends not only on its magnitude, but also on its duration. Ludwig et al. demonstrate that long periods of shear (e.g., 24 hours) can compromise cell morphology at forces of $0.75\text{--}1.0$ N/m²; however, for short periods (up to an hour), cells can tolerate stresses up to 20 N/m² (23). Bae et al. write that shear stress of >250 N/m² is required to induce mechanical damage in CHO cells (24). Thus, biomanufacturers should consider duration of exposure to a shear field when modeling cell damage during clarification. Equation 13 calculates cell residence time along the axial distance in the annular spaces between DSC

discs (t_s) (4). Using a power-law model, Pham et al. describe cell damage as a function of both shear stress and duration of shear-field exposure (Equation 14) (25).

CDI and Model Fitting for Shear Stress at a Given Tip Speed: Using the Fit Model function in JMP software, we obtained values for the constants in Equation 14. We based our calculations on LDH concentrations from Shekhawata et al. for different operating conditions in a Culturefuge 100 system, using those data points as response variables (13). The τ_{avg} and t_s values calculated from Equations 12 and 13, respectively, served as explanatory variables. Those inputs yielded values of $k = 3.8$, $\alpha = 1.3$, and $\beta = 0.43$, which we used to generate a prediction expression (Equation 15).

Figure 4 shows a linear relationship between reported LDH concentrations and Equation 15. An R^2 value of 0.98 demonstrates that the predictive expression reliably fits the observed data points. Similarly, the p -value of <0.0001 indicates that the strength of association between the input variable (prediction expression) and output prediction (LDH concentration) has a high degree of statistical significance and that 99.99% of variability in the observed LDH concentrations is explained by the prediction expression. Thus, holding the expression constant could be an effective method for maintaining similar shear levels across scales of DSC operation.

METHOD 3: POWER DISSIPATION

Average Shear Stress: Murrell demonstrates that power dissipated in a DSC feed zone (P_{dis}) can be calculated using Equation 16, wherein ω represents the angular velocity (in 1/s) (26). As with the tip-speed model, the impact of dissipated power on cell integrity depends on the exposure duration,

Figure 4: Predictability of shear produced in a disc-stack centrifuge according to the tip-speed method; RMSE = root-mean-square error





Figure 5: Predictability of shear produced in a disc-stack centrifuge based on the power-dissipation method; RMSE = root-mean-square error



which can be calculated as the centrifuge-bowl residence time (t_{RB}) using Equation 17. Therein, V_b signifies the centrifuge-bowl volume. Based on those calculations, the cell damage index can be expressed by a power law as a function of both dissipated power and bowl residence time (Equation 18). We identified the constants in Equation 18 as $k = 0.16$, $\alpha = 0.98$, and $\beta = 1.4$ based on the CDI and model-fitting method described above. Those values yield the prediction expression shown in Equation 19.

Figure 5 shows a linear relationship between LDH concentrations and Equation 19. The R^2 value of 0.98 demonstrates the reliability of the predictive expression. The p -value of <0.0001 indicates that the strength of association between the input variable and output prediction have a high degree of statistical significance, with 99.99% of variability in LDH values explained by Equation 19. Thus, holding the prediction expression constant could help to ensure similar shear levels across scales of DSC operation.

CONCLUSIONS ABOUT SHEAR ASSESSMENT FOR DSC OPERATION

Biomanufacturers often use DSCs for cell-culture clarification during large-scale biomanufacturing. Although a well-established Q/ε method is available for scaling centrifuge operating conditions based on particle-settling efficiency, current knowledge about shear assessment for DSC operation remains esoteric. Above, we presented shear-assessment calculations using three methods. We also illustrated applications using a contour profile that presents a balance between particle-settling capacity and shear as a function of bowl speed and centrifuge-feed flow rate.

REFERENCES

- 1 Depth Filtration Versus Centrifugation: Determining the Best Approach for Carrying Out Clarification Operations. *Gen. Eng. Biotechnol. News* 1 September 2014; <https://www.genengnews.com/news/depth-filtration-vs-centrifugation>.
- 2 Richardson A, Walker J. Continuous Solids-Discharging Centrifugation: A Solution to the Challenges of Clarifying High-Cell-Density Mammalian Cell Cultures. *BioProcess Int.* 16(4) 2018: 38–47; <https://bioprocessintl.com/downstream-processing/separation-purification/continuous-solids-discharging-centrifugation-a-solution-to-the-challenges-of-clarifying-high-cell-density-mammalian-cell-cultures>.
- 3 Joseph A, et al. A Scale-Down Mimic for Mapping the Process Performance of Centrifugation, Depth, and Sterile Filtration. *Biotechnol. Bioeng.* 113(9) 2016: 1934–1941; <https://doi.org/10.1002/bit.25967>.
- 4 Pham CY. Patent 7157276B2. *Use of Depth Filtration in Series with Continuous Centrifugation To Clarify Mammalian Cell Cultures*. US Patent and Trademark Office: Washington, DC, 2004; <https://image-ppubs.uspto.gov/dirsearch-public/print/downloadPdf/7157276>.
- 5 Mannweiler K. The Recovery of Biological Particles in High-Speed Continuous Centrifuges with Special Reference to Feed-Zone Break-Up Effects (PhD Thesis). University of London: London, UK, 1989; <https://discovery.ucl.ac.uk/id/eprint/1318045>.
- 6 Poon C. Measuring the Density and Viscosity of Culture Media for Optimized Computational Fluid Dynamics Analysis of In Vitro Devices. *bioRxiv* 26 November 2020; <https://doi.org/10.1101/2020.08.25.266221>.
- 7 de Nevers N, Silcox GD. *Fluid Mechanics for Chemical Engineers*, 4th Edition. McGraw Hill: New York, NY, 2021; <https://www.mheducation.com/highered/product/fluid-mechanics-chemical-engineers-de-nevers/M9781260475524.html>.
- 8 Muralidharan N. Shear-Proof Design Space: Scaling Stirred-Tank Bioreactors for Cell Culture Processes. *BioProcess Int.* 21(1–2) 2023: 35–37, 45; <https://bioprocessintl.com/upstream-processing/bioreactors/shear-proof-design-space-scaling-stirred-tank-bioreactors-for-cell-culture-processes>.
- 9 Clark DS, Blanch HW. *Biochemical Engineering*, 2nd Edition. CRC Press: Boca Raton, FL, 1997; <https://www.routledge.com/Biochemical-Engineering/Clark-Blanch/p/book/9780824700997>.
- 10 Sylaymon AH, Alward AI. Prediction of Drag Coefficient for Accelerated Single Sphere in Power Law Fluids. *Arab Univ. J. Eng. Sci.* 23(1) 2016: 141–153; <https://jaaru.org/index.php/auisseng/article/view/86/62>.
- 11 Clift R, Grace JR, Weber ME. *Bubbles, Drops, and Particles*. Dover: Mineola, NY, 2013; <https://store.doverpublications.com/products/9780486317748>.
- 12 Mei R. An Approximate Expression for the Shear Lift Force on a Spherical Particle at Finite Reynolds Number. *Int. J. Multiphase Flow* 18(1) 1992: 145–147; [https://doi.org/10.1016/0301-9322\(92\)90012-6](https://doi.org/10.1016/0301-9322(92)90012-6).
- 13 Shekhawat LK, et al. Application of CFD in Bioprocessing: Separation of Mammalian Cells Using Disc Stack Centrifuge During Production of Biotherapeutics. *J. Biotechnol.* 267, 2018: 1–11; <https://doi.org/10.1016/j.jbiotec.2017.12.016>.
- 14 Ambler CM. The Theory of Scaling Up Laboratory Data for the Sedimentation Type Centrifuge. *J. Biochem. Microbiol. Technol. Eng.* 1(2) 1959: 185–205; <https://doi.org/10.1002/jbmt.390010206>.
- 15 Parau M, et al. Analysis of Fouling and Breakthrough of Process Related Impurities During Depth Filtration Using Confocal Microscopy. *Biotechnol. Prog.* 38(2) 2022: e3233; <https://doi.org/10.1002/btpr.3233>.
- 16 Maschke RW, et al. Determination of Culture Design Spaces in Shaken Disposable Cultivation Systems for CHO Suspension Cell Cultures. *Biochem. Eng. J.* 177, 2022: 108224; <https://doi.org/10.1016/j.bej.2021.108224>.
- 17 Nienow AW. The Impact of Fluid Dynamic Stress in Stirred Bioreactors – The Scale of the Biological Entity: A Personal View. *Chem. Ingen. Technik* 93(1–2) 2020: 17–30; <https://doi.org/10.1002/cite.202000176>.
- 18 Doran PM. *Bioprocess Engineering Principles*, 2nd Edition. Academic Press: Waltham, MA, 2013; <https://shop.elsevier.com/books/bioprocess-engineering-principles/doran/978-0-08-091770-2>.
- 19 Monica TJ, Whiteley EM, Aktiengesellschaft S. Patent 6773909B2. *Concentration and Lysis of Adenovirus-Infected Cells in a Single Unit Operation*. US Patent and Trademark Office: Washington, DC, 10 August 2004; <https://image-ppubs.uspto.gov/dirsearch-public/print/downloadPdf/6773909>.
- 20 Maybury JP, Hoare M, Dunnill P. The Use of Laboratory Centrifugation Studies To Predict Performance of Industrial Machines: Studies of Shear-Insensitive and Shear-Sensitive Materials. *Biotechnol. Bioeng.* 67(3) 2000: 265–273; <https://pubmed.ncbi.nlm.nih.gov/10620256>.
- 21 Iammarino M, et al. Impact of Cell Density and Viability on Primary Clarification of Mammalian Cell Broth. *BioProcess Int.* 5(11) 2007: 38–50; <https://bioprocessintl.com/downstream-processing/filtration/impact-of-cell-density-and-viability-on-primary-clarification-of-mammalian-cell-broth-110120075>.
- 22 Boychyn M, et al. Characterization of Flow Intensity in Continuous Centrifuges for the Development of Laboratory Mimics. *Chem. Eng. Sci.* 56(16) 2001: 4759–4770; [https://doi.org/10.1016/S0009-2509\(01\)00139-7](https://doi.org/10.1016/S0009-2509(01)00139-7).
- 23 Ludwig A, Kretzmer G, Schügerl K. Determination of a “Critical Shear Stress Level” Applied to Adherent Mammalian Cells. *Enzyme Microb. Technol.* 14(3) 1992: 209–213; [https://doi.org/10.1016/0141-0229\(92\)90068-y](https://doi.org/10.1016/0141-0229(92)90068-y).
- 24 Bae YB, et al. Microfluidic Assessment of Mechanical Cell Damage By Extensional Stress. *Lab on a Chip* 16(1) 2016: 96–103; <https://doi.org/10.1039/c5lc01006c>.
- 25 Pham OL, et al. Distribution and History of Extensional Stresses on vWF Surrogate Molecules in Turbulent Flow. *Sci. Rep.* 12, 2022: 171; <https://doi.org/10.1038/s41598-021-04034-9>.
- 26 Murrell NJ. An Engineering Study of the Recovery of Shear Sensitive Biological Materials By High Speed Disk Stack Centrifugation (PhD thesis). University College London: London, UK, 1998; https://discovery.ucl.ac.uk/id/eprint/10099092/1/An_engineering_study_of_the_re.pdf.

Tyler Younger and Grace Chan are process engineers in manufacturing science and technology (MSAT), **Mark Davis** is director of the MSAT team, and corresponding author **Naveenganes Muralidharan** (nmural@agcbio.com) is senior manager of the MSAT team, all at AGC Biologics, 5550 Airport Boulevard, Boulder, CO 80301; <https://www.agcbio.com>.

To share this in PDF or professionally printed form, contact Lisa Payne: lpayne@mossbergco.com, reprints@mossbergco.com; 1-219-561-2036.