


BUILDING INFORMATION MODELLING

Wavin BIM Manual

The easiest way to “as built”
design of construction project



BIM



- No matter what design software you prefer to use Wavin offers you the service to generate a Wavin specific «as built» design.
- Wavin has a wide BIM content library for both above and below ground systems.
- Wavin BIM content library are freely available in the external libraries such as Focus Vardak and Novapoint in both 2D and 3D formats, and on the local website (ask your local representant).

A Quick Guide to Wavin Revit content packages



1. Import packages following Wavin's instructions

- ⦿ Wavin Revit packages contain a lot of additional intelligence, a special Wavin validation view and pipe & fittings schedules.
- ⦿ Please import files as described by Wavin to give you all the benefits of the Revit packages

See chapter 1.1 on how to correctly import the Wavin packages.

2. Insert pipes and fittings using the plumbing and piping panel and the properties window

- ⦿ Select the desired pipe type and diameter and then start drawing a pipework - appropriate default fittings will be inserted automatically.
- ⦿ By selecting the inserted default fitting, you can change it to another type by using a drop down list from the Properties window.
- ⦿ In some fittings, Wavin offers the possibility to modify their features via the "Graphics" or "Constraints" section of the "Properties" window.
- ⦿ Via the "Pipe Fitting" or "Pipe Accessory" button in the Systems ribbon, you can manually insert desired fittings, which are not included in routing preferences.

Please read next chapters on a more detailed description on how to draw pipes and insert fittings. System-specific fittings are described in dedicated product range chapters.

3. Various pipe types available

- ⦿ Revit only offers plain-end pipes. Wavin however has made working with socket, and plain-end pipes possible.
- ⦿ Wavin supports working with DN as well as OD pipe sizes and various colours.

See chapter 2.1 on a full overview of the pipe types you can select for your project.

4. Changing orientation and type of fittings

- ⦿ Wavin added checkboxes in "Properties" window to easily:
 - switch from an equal to an unequal Tee or from a straight 90° Tee to a swept Tee,
 - change the orientation of a fitting or rotate an eccentric reducer,
 - change many other features of the selected fitting.
- ⦿ Creating non-existent fittings will result in creation of custom fittings or an error message.

See chapter 2.3.5 for an overview of all possibilities Wavin has included in the packages.

5. Implemented solutions for Tee

- ⦿ Intelligence allows inserting Tee along with reducers, if needed.
- ⦿ If applicable, a proper sequence of reducers are inserted automatically. The user does not require full knowledge of catalogues.

See chapters 2.2 and 2.3 for a full overview of selecting the right Tee and reducers for your project.

Table of contents

1. Revit package - General information	5
1.1. Importing Wavin Revit packages.....	5
1.2. Nested families	8
1.3. Product Validation View.....	8
1.4. Custom fittings	9
2. Wavin Revit packages – General information	10
2.1. Working with Pipe Types in Wavin Revit packages.....	10
2.2. Working with Reducers in Wavin Revit packages.....	14
2.3. Working with Bends in Wavin Revit packages.....	15
2.4. Working with Branches in Wavin Revit packages.....	16
2.5. Working with Unions in Wavin Revit packages.....	17
3. S&W - General information	18
3.1. Bend	18
3.2. Branch	20
3.3. Double Branch.....	21
3.4. Reducer	23
3.5. Union	24
3.6. Access Pipe.....	25
3.7. End cap	26
3.8. Transition	26
4. Hot&Cold - General information	27
4.1. Bends	27
4.2. Branches.....	28
4.3. Multi-Reducers	29
4.4. Unions.....	29
4.5. Wall flanges	30
4.6. Working with Threaded connections.....	31
4.7. Working with insulated pipes	33
4.8. Working with single/coiled pipes	33

1. Revit package

- General information

1.1. Importing Wavin Revit packages


In order to make designing with Revit more user-friendly Wavin decided not only to create Revit families representing the products, but also to add intelligence. This will help the user to make correct connections and transitions between pipes of different diameters. If correctly used, Wavin's Revit packages will grant user power not only to design the system, but also access to the data, names and catalogue codes of every part used in the system.

This additional functionality only becomes available if the Wavin Revit packages are imported correctly. Below are a few steps required to import the families with tags, Wavin Validation View, and specific Wavin schedules.

Importing families:


1] Open the Revit package to be imported.

- Starting view is opened automatically. Starting view contains various pipe types, tags and possibly some fittings.




- Wavin has created ready-to-use tags. While annotating the user can choose type of tag and data which is required to be shown in the project.
- Starting view may also include pipe fittings and pipe accessories, which are not included in the routing preferences. They should also be copied in order to include them in the project.

- 2] Having opened the Starting view, select a pipe type(s) along with fittings and all tags to be used in the project.
 - ⦿ There is no need to copy all the pipe types visible in Starting view if the user does not want to work with every pipe type. Only one pipe type required for the project e.g. DN vs. OD or socket vs. plain and or standard vs. insulated, can be used. To learn more about available pipe types go to the section 2.2.
 - ⦿ Do not use DN and OD type of the same pipe in one project.
 - ⦿ Copying only one pipe transfers all the fittings and pipe segments included in its routing preferences
- 3] Choose the “Copy to clipboard” option.
 - ⦿ This way of copying is required in order to transfer the intelligence correctly.





- 4] Go to the target project.
- 5] Open any 2D view or a locked 3D view.
- 6] Use “Paste from clipboard” function.
 - ⦿ In Revit 2014 and Revit 2015, after clicking “Paste from clipboard” a warning informing that copied types already exist in the project may be displayed. Just click “OK”.



7] Paste the selected elements in an empty, unused space in the project.

⦿ In Revit 2014, after pasting family a warning informing that custom fitting was created may be displayed. Just click “OK”.



8] Click the ‘Finish” button in Modify ribbon.

9] Select pasted elements and delete them.

10] The families are now successfully stored in the project and accessible through System ribbon.

Wavin Validation View:

Wavin Revit packages allows the user to check correctness of the items used in the project by highlighting incorrect, or custom fittings using a colour code. Follow the instruction below to import this view.

1] Create a new 3D view in the project or duplicate an existing one.

2] Go to the Manage ribbon and click Transfer Project Standards.

3] A list Select Items to Copy appears.

4] Choose the source project name on the top of the list.


⦿ If multiple projects are open, make sure to select the Wavin Revit package.

5] Only “View templates” should be selected. Click “OK”.

6] Go to the Properties bar of the view. Find Identity Data and click “View Template”.

7] A window Apply View Template appears.

8] Choose “Wavin Validation View” from the list and click “OK”.




Usage of validation tool is described in section 1.3.

Schedules:

Follow the steps below to import schedules.

- 1] Go to the Project Browser in Wavin Revit package. Find Schedules/Quantities.
- 2] Select all Wavin schedules and after right clicking choose “Copy to clipboard”.
 - ⦿ Number of schedules may vary between the systems, depending on the product range.



- 3] Go to the target project.
- 4] Go to the Modify ribbon and click “Paste from clipboard”.
- 5] Fully functional bills of material are transferred to the project.

1.2. Nested families


Nested families are components of compound families. Thanks to them, there is no need to insert each item manually.

- ⦿ Nested components should never be inserted into the project manually.


1.3. Product Validation View

The view template in the Wavin package allows the user to check whether or not the dimensions or eccentricity of an individual pipe-fitting are valid.


- ⦿ To check validation of the products, go to the 3D view, which have already been created according to the “Product Validation View” in the section 1.1.
- ⦿ If a pipe is longer than available, it will be orange.



- ⓘ If a fitting is not available in the product portfolio or a reducer is NOT set to “eccentric” it will be red with an exclamation mark.




A centric reducer.



An eccentric reducer.


To learn how to work with reducers go to the section 2.2.

- ⓘ If a created fitting is not a Wavin product, it will be green.



1.4. Custom fittings

From time to time user will obtain a message of creating the custom fitting while inserting a reducer or a branch with reducer (nested component). It means that in order to connect elements Revit had to create a fitting which does not exist in the product range. The file will be workable, and all connections will be valid, however custom fittings will not have catalogue numbers in the bill of materials.



If some parts were left in the project as custom fittings they can be easily found later. If the fitting is custom, it will have an exclamation mark next to the connection. It will be easier to notice in the product Validation View, where custom fittings will be highlighted in red.

If there is an exclamation mark next to the reducer, it means that the connection requires further user action. The warning will disappear if the reducer is changed from centric to eccentric, in that case:

- 1] Select custom fitting.
- 2] Switch on checkbox “eccentric”, which can be found in the “Properties” window.
- 3] Reducer is set to eccentric now.

2. Wavin Revit packages



General information

2.1. Working with Pipe Types in Wavin Revit packages

Standard Revit ← versus → Wavin package

Standard Revit utilises US pipe types only. Only plain-end pipes are supported and they can be drawn in any length.


Uses diameters and pipe lengths available in a specific product portfolio. Both plain-end and socket-end pipes are available.



In Wavin's "as built" package the following challenges were addressed:

1] A product portfolio always contains specific diameters and might contain different colours and socket-end pipes.

- ⦿ If a product portfolio has multiple colours and/or plain-end pipe and socket-end pipes, Wavin has created a dedicated Pipe Type in the Wavin Revit package.
- ⦿ Wavin gives the user the option to draw pipes selecting the right OD (Outer Diameter) or DN (Nominal Diameter).
- ⚠ Mixing OD and DN Pipe Types will cause errors in the project. Choose either the DN or OD Pipe Type for the project.
- ⦿ Standard Revit only provides working with plain-ended pipes. For the product portfolios, which also have socket-end pipes, Wavin has engineered a work around. Wavin added a virtual socket on each spigot of the fittings when connected to a socket-end pipe.



Furthermore Wavin has created a separate Pipe Schedule for socket-end pipes next to one for plain-end pipes.


WAVIN					
<Wavin AS Plain End Pipes>					
A	B	C	D	E	F
Diameter		Length (total)	EAN	Article Nr.	Article Descr.
DN	Outer				
56	58 mm	4,3 m	4026294046179	71595000	AS Pipe DN56 L=3
58	58 mm	3,5 m	4026294046179	71595000	AS Pipe DN56 L=3
70	78 mm	3,0 m	4026294024221	34045000	AS Pipe DN70 L=3
78	78 mm	4,1 m	4026294024221	34045000	AS Pipe DN70 L=3
90	90 mm	2,6 m	4026294318986	03087786	AS Pipe DN90 L=3
90	90 mm	12,1 m	4026294021329	30821000	AS Pipe DN90 L=2
100	110 mm	6,0 m	4026294024238	03106160	AS Pipe DN100 L=2
110	110 mm	6,0 m	4026294024238	03106160	AS Pipe DN100 L=2
125	135 mm	2,9 m	4026294024269	34096000	AS Pipe DN125 L=3
135	135 mm	2,8 m	4026294024269	34096000	AS Pipe DN125 L=3
150	160 mm	3,6 m	4026294024276	34100000	AS Pipe DN150 L=3
160	160 mm	3,8 m	4026294024276	34100000	AS Pipe DN150 L=3
200	200 mm	6,2 m	4026294130410	03014592	AS Pipe DN200 L=3

2] Splitting pipe into available lengths.


- ⦿ Standard Revit does not have any restrictions on a pipe length. To improve work with Wavin Revit packages, Wavin provides a solution to use pipe lengths, which are available in the product portfolio.
- ⦿ To check whether pipes used in the project are available in the product portfolio, open “Wavin Validation View” in the “Project Browser” window.
- ⦿ If a pipe is orange, it requires further action and its length needs to be split into any dimension available in the product portfolio.
- ⦿ Changing pipe length:
 - a. find and select an orange pipe in a “Wavin Validation View”,




- b. locate the pipe in the Floor Plan,
- c. split the pipe into sections according to maximum length available,



d. insert a dimension (using “Aligned Dimension” function) starting at the end of the pipe and reference to the coupler,



e. select the coupler and click at the dimension to change it into e.g. 3000 mm,



f. if pipe is split properly and it's length is available in the product portfolio, the pipe will not be highlighted in the “Wavin Validation View” anymore.


⦿ Also an incorrect length can easily be found by using a “Pipe Schedule”. Lengths that are not available will be highlighted orange.

Wavin					
<Wavin AS Plain End Pipes>					
A	B	C	D	E	F
Diameter		Length (total)	EAN	Article Nr.	Article Descr.
DN	Outer				
56	58 mm	0,8 m	4026294046179	71595000	AS Pipe DN56 L=3
90	90 mm	0,4 m	4026294021329	30821000	AS Pipe DN90 L=2
125	135 mm	1,3 m	4026294024269	34096000	AS Pipe DN125 L=3
125	135 mm	4,6 m	not applicable	not applicable	not applicable
150	160 mm	0,8 m	4026294024276	34100000	AS Pipe DN150 L=3

3] Working with plain-end and socket-end pipes.

Standard Revit provides plain-end pipes, but in Wavin Revit packages Wavin improved usage of them by adding a coupler, while connecting a pipe with any pipe fitting. See an example working with plain-end pipe and a coupler below:


- a. Draw a plain-end pipe (choose a proper pipe type in the Properties window).
- b. Split the pipe.
- c. A coupler is inserted.



As standard Revit does not provide socket-end pipes, Wavin made it possible to visualize them.

Follow the procedure below to learn how to work with socket-end pipes:

- a. Draw a socket-end pipe (choose a proper pipe type in the Properties window).
- b. Split the pipe.
- c. A socket is inserted.




In Wavin AS it should be correct, whether the elements connecting pipes to fittings are correct for the chosen pipe-type, as both pipe-types are available.

To learn more about working with plain-end and socket-end pipes go to the chapter 3.


2.2. Working with Reducers in Wavin Revit packages

Standard Revit ← versus → Wavin package

Every reducer connecting any two diameter is possible and is always visualised in the same way.



In soil and waste systems only eccentric reducers should be used keeping the top of the two pipes at the same level.



Often more than one reducer is required.


In Wavin's "as built" package the following challenges were addressed:

1] Often more than one fitting is required to connect the two different diameters

- ⦿ If more fittings are required, the intelligence of the Wavin Revit package automatically inserts the right combination of reducers.

2] In soil and waste ranges eccentric reducers should be used. The eccentricity should be positioned keeping the top of the two pipes at the same level. Centric reducers will be treated as custom fittings.

- ⦿ By default, Revit places the centre line of the two different diameters at the same level.
- ⦿ Due to this, a temporary "custom fitting", a centric reducer is placed and the user will be notified by an exclamation mark next to the fitting that this product does not exist in the portfolio.
- ⦿ In the dedicated Wavin Validation View supplied with the Revit package, all custom fittings will be red.
- ⦿ If reducers are available in both a short as well as a long version, by default the short version is placed. Changing to a long version by selecting the checkbox "Reducer Long".



3] Hot and cold Wavin Revit packages provide multireducers, which enable automatic connection with any diameter.

- ⦿ In hot and cold systems reducers are always centric, therefore do not require changes after insertion.

2.3. Working with Bends in Wavin Revit packages


Standard Revit

← versus →

Wavin package

It is possible to create a bend with any angle and it is always visualised in the same way. Only symmetric spigot bend with the same working lengths is available.

Only bends that are available in the product portfolio can be designed. A great variety of bends is provided – symmetric and asymmetric, spigoted and socketed.



In Wavin's "as built" package the following challenges were addressed:

1] Great variety of bend types available in Wavin product portfolio

- Depending on a specific product range, various bend types can be inserted. The default type is a standard bend available in all sizes. It can be changed it into a specific bend type afterwards.

2] Specific diameters and angles of bends available



- According to product portfolios, the 15°, 22°, 30°, 45°, 67° and 90° bends can be drawn. Most of them can be inserted automatically by drawing two pipes at a proper angle. Go to the chapter soil and waste and hot and cold issues to learn more about specific bends.

3] In hot and cold systems usually symmetric bends are used. In soil and waste the usage of symmetric and asymmetric bends is possible.

- For symmetric bends the working length of the pipe is the same. For asymmetric bends the working length differs.

4] Depending on the water flow direction, bends may need to be reversed in soil and waste systems.

- Depending on the direction of drawing some bends may require changing the flow direction. In such event use the checkbox "Reverse Direction" in the Properties window.





2.4. Working with Branches in Wavin Revit packages

Standard Revit ← versus → Wavin package

Branch connecting any diameter is possible to insert and it is always visualised in the same way. Only equal branches with centric reducers are available.

Only branches available in the product portfolio can be designed. According to product range a great variety of specific types of branches is provided, both equal and unequal ones.



In Wavin's "as built" package the following challenges were addressed:

1] Specific diameters and angles of branches available

- ⚠ In order to draw a branch upgrade an existing elbow by pressing a "+" or connect two pipes together. Some branches need to be inserted manually. Go to the section soil and waste or hot and cold general issues to find more specific information.

2] Great variety of branch types and their functionalities in Wavin product portfolio

- 🕒 Depending on product range, various branch types can be inserted. Soil and waste Wavin Revit packages provide equal and unequal tees, with centric or eccentric reducers.
- 🕒 In soil and waste the default type is a horizontal branch connected to a vertical main pipe.
- 🕒 In hot and cold there is only one available branch type.

3] By putting intelligence into Wavin Revit packages, there is no need to insert reducers manually.

- 🕒 If applicable, a proper reducer or set of reducers is inserted automatically (as a nested component) so the user do not need to assemble it themselves.

2.5 . Working with Unions in Wavin Revit packages


Standard Revit

← versus →

Wavin package

Standard Revit provides only visualization of a coupler.
The working length of the fitting is not correct.

According to product range a great variety of specific types of unions are provided. The working length of the unions is correct.



In Wavin's "as built" package the following challenges were addressed:

1] Correct working lengths enable correct pipe connections

- ⌚ While splitting a pipe, the connection points account for the depth of the socket.

2] A wide variety of union types are available in product ranges.

- ⚠ In soil and waste different couplers can be chosen, as: access pipes, pipe sockets, compensator sockets, double sockets, repair couplers, transitions and expansion sockets.
- ⚠ Hot and cold Wavin Revit packages provide a wide range of standard and threaded couplers and transitions to other systems.
- ⚠ In soil and waste systems, depending on a pipe-type, a proper type of union should be used. For plain-end pipes a coupler is set as a default union. For socket-end pipes a dummy socket will be used instead of a coupler.

3. Soil and Waste

General information


3.1. Bend

Inserting a specific bend type

By drawing two pipes at the correct angle a default bend will be inserted.

To change it into a specific bend type follow steps below:

- Draw a standard bend connecting two pipes.
- Select the bend.
- Go to the “Properties” window and open the list by clicking the bend picture as shown below.



- Turn on “Constrain to routing preferences” checkbox to limit the list of various bend types. This additional functionality allows to avoid inserting a nested component.
- Choose a bend type from the list.
- Move the mouse to the Main window or click the “Apply” button at the bottom of the “Properties” window to see the changes.

Working with 67° bends

67° bends may require a different way of insertion than other angles.

To insert 67° bend, there is a need to follow the procedure below:

- Draw two pipes connected at 90° angle.
- Select a pipe and drag one end of the pipe until it reaches 67° angle.




Replacing 90° bend with two 45° bends

In soil and waste two 45° bends can be used instead of one 90° bend.

They are provided as a nested component, as they cannot be inserted automatically.

To put two 45° bends in a project, follow the procedure below:

- Draw a 90° bend.
- Select the bend and choose Bend 2x45° from the list in the “Properties” window.
- To insert a pipe between two bends turn on “Add Pipe” checkbox.
- To change the default pipe length, type the required length into the box.



Changing features and properties of bends

Wavin Revit packages provide additional functionalities, which enable changing properties of bends. Some of them are available only for specific bend types.


To change the properties of the fitting go to the “Properties” window. By selecting checkboxes the following functions can be turned on/off:

- Reverse direction – to change a direction of the bend,
- Bend Long DN100 – to change bend into a long one. Possible for DN100 (only in Wavin AS),
- Add Pipe – to insert a pipe between two 45° bends,
- Force Socket Connection – to choose socket as a connecting element,
- Show Spigot End – to remove connecting elements (for example when connecting fitting to another fitting).


3.2. Branch

Three different options of tee connections provided


Considering usage of the tee, hydraulics optimization and avoiding negative pressures, the following solutions can be chosen:



*Horizontal branch
entering a vertical main pipe
(set as a default option)*



*Vertical branch
entering a horizontal main pipe*





*Horizontal branch
entering a horizontal main pipe*

- ⦿ For a horizontal branch connected to a vertical main pipe and for a vertical branch to a horizontal main pipe both an equal and an unequal tee can be used.
- ⦿ For a horizontal branch connected to a horizontal main pipe it is recommended to use an equal tee, for other cases use an unequal tee if possible.

A horizontal branch entering a vertical main pipe is set as a default. To change it into another option follow the procedure below:


- a. Go to the “Properties” window and open the list by clicking the branch picture as shown below.



- b. Choose a branch type from the list.
- c. Click the “Apply”.

Working with reducers

In soil and waste every instance or reducer, or reducer group “eccentricity” needs to be turned on manually since Revit automatically inserts reducers as centric ones, which may not be available in the product range. A red exclamation mark will be displayed along with a warning in the “Constraints” chapter of the “Properties”.



Changing features and properties of branches

Wavin Revit packages provide additional functionalities which enable changing features and properties of the branches. Some of them are available only for specific branch types. To change properties of the fitting go to the “Properties” window. By selecting checkboxes the following functions can be turned on/off:

- Force Socket Connection – to choose the socket as a connecting element,
- Show Spigot End – to remove connecting elements (for example when connecting fitting to other fitting),
- Tee Equal – to change a tee between equal and an unequal one,
- Tee Swept – to change a tee type between swept standard,
- Tee 67° - to change an angle of the branch from 90° to 67°.
In the next point a procedure of how to insert a 67° tee will be presented,
- Tee 45° - to change an angle of the branch from 90° to 45°.
In the next point a procedure of how to insert a 45° tee will be presented.

Working with 45° and 67° branches

To change an angle into 45° or 67° follow the steps below:


- Draw a branch 90°.
- Change the tee connection from default (main vertical and branch horizontal) into main horizontal and branch vertical or main and vertical horizontal both.
- Now select the checkbox “Tee 45°” or “Tee 67°”.

3.3. Double Branch

Inserting a double branch

Soil and waste Revit packages contain also a great variety of double branches with different family types, dimensions and angles. To insert a standard double branch follow the steps below:

- Draw a standard branch.
- Select a branch.
- Click the “+” to create a new connector.
- This will insert a double branch, start drawing pipe from the new connector.



⚠ In PVC-HT and SiTech+ packages it is recommended to insert a double branch manually, using Pipe Fitting function (see the procedure of inserting in the section 4.6). As placing a double branch like described above might cause some disconnection between the fitting and the pipes.

Changing a double branch type


Depending on the system, other double branch family types are available and can be inserted into the project:

- Having a standard double branch inserted, select it.
- Go to the Properties window and choose another type of double branch.
- Click the “Apply”.

Changing features and properties of double branches

To set other properties of the Double Branch go to the “Properties” window. By selecting checkboxes the following function can be turned on/off:

- Show Spigot End – to remove connecting elements (for example when connecting fitting to other fitting).





3.4. Reducer

Changing a reducer from centric to eccentric

Only eccentric reducers should be used, in this case follow steps below to replace a centric reducer with an eccentric one:

- Apply slopes to horizontal pipes before changing centric reducers into eccentric.
- Select the custom fitting (centric reducer).
- Select checkbox “Reducer Eccentric”.
- Click the “Apply”.
- If required, rotate the reducer by either selecting Reducer Rotate 90° resp. 180° or by using the standard Revit Rotate functionality.

 Keep the top of the two pipes at the same level.




3.5. Union

Inserting a union

A union is inserted when a pipe is split into two elements. For plain-ended pipes a coupler is set as a default union. For socketed pipes a socket is set as a default union. To insert a union follow the steps below:

- Draw a pipe.
- Select pipe and split it.
- A default union is inserted.



Changing a union

To replace a default union type into a specific one follow the steps below:


- Insert a default union as shown above.
- Select union.
- Choose another type of union from the “Properties” window to replace it.
- Click “Apply”.

There are exceptions and some unions require to be inserted in another way. See the chapter 4.

Changing features and properties of unions

Wavin Revit packages provide additional functionalities which enable changing features and properties of the unions. Some of them are available for specific union types. To change properties of the fitting go to the “Properties” window. By selecting checkboxes the following functions can be turned on/off:

- Reverse Direction – to change a direction of the union,
- Force Socket Connection – to choose socket as a connecting element,
- Show Spigot End – to remove connecting elements (for example when connecting the fitting to an other fitting).





3.6. Access Pipe

Inserting access pipe

Wavin Revit packages for soil and waste systems provide access pipes with different dimensions, depending on the product range. Please follow the steps below to insert an access pipe:

- Draw a coupler (according to procedure in section 3.5).
- Select the coupler.
- Go to the Properties window and choose an access Pipe from the list.
- Click the “Apply”. A coupler has been replaced by the access pipe.



Changing features and properties of access pipes

To set other properties of the access Pipe go to the “Properties” window. By selecting checkboxes the following functions can be turned on/off:

- Reverse Direction - to change a direction of the bend,
- Show Spigot End – to remove connecting elements (for example when connecting fitting to other fitting),
- Force Socket Connection – to choose socket as a connecting element,
- 45_degrees – to change an angle (only in PE),
- Coupler – to insert a coupler (only in Wadal).

Rotating a fitting




To rotate the access Pipe use the standard Revit function.

3.7. End cap

Inserting an end cap

Wavin has supplied packages with end caps to cover the end of a pipe or a pipe fitting. To insert an end cap follow the procedure below:

- Select a pipe or a pipe fitting, which has at least one connector not in use.
- Go to the Modify ribbon and click “Cap Open Ends” function.
- The end cap is inserted automatically.



Changing features and properties of end caps

To set other properties of the End Cap go to the “Properties” window. By selecting checkboxes the following functions can be turned on/off:

- Show Spigot End – to remove connecting elements (for example when connecting fitting to other fitting),
- Force Socket Connection – to choose socket as a connecting element,
- Pipe Cap – it is used because of the difference between the depth of the socket for pipes and pipe fittings,
- Coupler – to insert a coupler (only in Wadal).

⚠ “Pipe Cap” function is provided only in SiTech+ package. Because of the difference between the depth of the sockets for pipes and pipe fittings, there is a necessity to use function “Pipe Cap”. Turn on checkbox “Pipe Cap” while capping an end of a pipe. While connecting an end cap to a pipe fitting, the checkbox must be turned off.

3.8. Transition

When two pipes of different properties meet, a transition will be created. This group consist of reducers, couplers and transitions to other systems.

4. Hot & Cold

General information



4.1. Bends

🕒 Inserting a specific bend type

By drawing two pipes at the correct angle a default bend will be inserted.

To change it into a specific bend type follow steps below:

- Draw a standard bend connecting two pipes.
- Select the bend.
- Go to the “Properties” window and open the list by clicking the bend picture as shown below.



- Turn on “Constrain to routing preferences” checkbox to limit the list of various bend types. This additional functionality avoids inserting a nested component.
- Choose a bend type from the list.
- Click the “Apply”.

🕒 Changing features and properties of bends

Wavin Revit packages provide additional functionalities which enable changing properties of bends. Some of them are available only for specific bend types. To change properties of the fitting go to the “Properties” window. By selecting checkboxes the following functions can be turned on/off:



- M1 - to change between K1 and M1,
- Reverse Direction – to change direction of the bend,
- Prefer Spigot – to change between a socket and a spigot end.

4.2. Branches

↳ Inserting a specific branch type

Each hot and cold system has different default branch type. To change it into another type follow steps below:

- Draw a standard branch.
- Select the branch.
- Go to the “Properties” window and open the list by clicking the branch picture.



- Choose a branch type from the list.
- Click the “Apply”.

- ↳ In Ekoplastik Wavin Revit package pipes might be connected using a tee or a saddle. Tee connections are available for pipes with equal diameter, using saddle is possible for pipes with unequal diameters greater than Ø50.

↳ Changing features and properties of branches

To change properties of the fitting go to the “Properties” window. By selecting checkboxes the following function can be turned on/off:

- M1 - to change between K1 and M1.

4.3. Multi-Reducers


- ⓘ In hot and cold systems only centric reducers are available.

Centric reducers are set as a default. They enable automatic connection with any diameter.

- ⓘ Inserting multi-reducers

To insert a multi-reducer connecting any diameters, follow steps below:

- Draw a pipe.
- Insert a coupler by splitting pipe.
- Select one pipe and change the diameter.
- Coupler will be replaced by a multi-reducer automatically.



- ⚠ Changing features and properties of multi-reducers

To change properties of the fitting go to the “Properties” window.

By selecting checkboxes the following functions can be turned on/off:

- M1 - to change between K1 and M1,
 - Additional coupler – to insert a coupler (only in Ekoplastik).
- ⓘ In Ekoplastik Revit package it is required to turn on “Coupler at beginning” checkbox.

4.4. Unions

- ⓘ Inserting a union

An union is inserted when a pipe is split into two elements. To insert a union follow steps below:

- Draw a pipe.
- Select pipe and split it.
- A default union is inserted.



- ⓘ Changing features and properties of unions

To change properties of the fitting go to the “Properties” window.

By selecting checkboxes the following function can be turn on/off:

- M1 - to change between K1 and M1


4.5. Wall flanges

Wavin Revit packages provide various types of wall flanges. Most of them can be put into projects by changing standard elbows or junctions. Others need to be placed manually.


Inserting wall flanges manually

To insert any wall flange type, follow the procedure below:

- Go to the Systems ribbon and choose Pipe Fitting function.
- Select desired wall flange type from the list in the Properties window.
- Hover a fitting over the pipe to be connected, and click the mouse button to place it.
- The fitting is inserted.



Various types of wall flanges

					
Hep2O Wall Screw Elbow	Hep2O Wall Flange PF-FMT	Tigris Wall Flange Corner K1.M1 FMT	Tigris Wall Flange Elbow K1.M1 FMT	Tigris Wall Flange U-Turn K1.M1 FMT	Tigris Wall Passage K1.M1
Change from elbow	Change from elbow	Insert manually	Change from elbow	Insert manually	Change from elbow

Working with wall flanges

To rotate a wall flange use standard Revit Rotate functionality. To reverse the direction of the fitting, use “Flip Fitting” function.

Changing features and properties of wall flanges

To change properties of the fitting go to the “Properties” window. By selecting checkboxes the following functions can be turned on/off:



- Long – to change between long and short version of the fitting (available only for Tigris Wall Passage K1.M1),
- M1 – to change between K1 and M1

4.6. Working with Threaded connections

Wavin product ranges are equipped with many transitions working as threaded connections. This allows connecting Wavin systems to metal pipes or multiple accessories such as faucets, valves, pumps, etc.



Inserting straight transitions

- To insert a straight transition just connect a pipe directly to the Threaded element.
- This will create a custom fitting.
- Select the fitting, and change it into a transition to threaded connection.




Inserting elbow transitions

- Elbow transitions include elbows with threaded ends, and wall flange elbows.
- To create an elbow transition, connect a pipe to the item's connector at a right angle
- This will create a custom fitting.
- Select the bend and change it into a transitions bend.



Inserting junction transition

- Junction transitions include tees with threaded ends and wall flanged tees.
- To create a junction transition, create an elbow transition using steps described above.
- Add a new connector using standard Revit functionality.
- Select the junction and change it into a transition junction.



⚠ NOTE: Revit cannot automatically tell the difference between internal (female) and external (male) thread. The user has to choose the correct family from the list. Choose between FMT (Female thread) and MMT (Male thread) Revit families depending on the connected item.


⚠ ALSO NOTE: In some cases Revit will create a short piece of pipe between threaded fitting and accessory. User should account for this and if required delete it and reconnect the fitting to accessory.

Wavin Revit packages are compatible with threaded connections as long as their diameter is expressed in inches, or metric DN. For example a ½" inch can be described as ½", 12,7mm, or DN15.


4.7. Working with insulated pipes

Some hot and cold ranges contain pre-insulated pipes. They come in different colors and insulation thicknesses. Both those qualities have to be set independently.

- To choose color select a desired pipe type from the list.



- To choose a desired insulation thickness the user needs to select the pipe lengths and change pipe segment in the properties window.




4.8 . Working with single/coiled pipes

In hot and cold systems the user can choose between single and coiled pipes. To make the choice, go to the pipe's properties and choose the pipe segment which represents desired pipe.

In Hep2O system the user can choose the best coil length that suits his needs. This must be done via bill of materials for pipes. The user can choose between default 50m coil, and optional 25, and 100m coils. Every time a new pipe is created, its coil length has to be defined by the user. To do this go to bill of materials for pipes.

⚠ NOTE: By default Revit engages both available checkboxes, causes the pipe parameters to be invalid. To rectify this the user has to make sure that only one, or neither of the checkboxes are engaged. If neither box is toggled on, the default will be used. Please note that even grayed-out checkboxes are editable.



 <Wavin Hep2O Pipes>												
A	B	C	D	E	F	G	H	I	J	K	L	M
Nr	Diameters		Length (total)	Art. Number	Product Description	Coil Usage	Coil 25m	Coil 100m	Coil Length	EAN	Pipe Clips (pcs)	Smart Sleeve (pcs)
	DN	Outer										
Coil Pipes												
2	15	22 mm	1,7 m			0,03	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			3	4
1	20	28 mm	1,5 m	HXP50/28W	Hep2O Standard Pipe WT 28 L=50	0,03	<input type="checkbox"/>	<input type="checkbox"/>	Coil 50m (default)	5027888271037	2	2

Utforsk vår portefølje på wavin.no

Skann koden og motta vår markedsinformasjon



Wavin er en del av Orbia, et fellesskap av selskaper som arbeider sammen for å takle noen av verdens mest komplekse utfordringer. Vi har et felles mål: Å fremme livet i hele verden.



Norsk Wavin AS | Karihaugveien 89 | 1086 Oslo | Telefon +47 63 85 20 20 | Internet www.wavin.no
E-mail ordre.no@wavin.com / tilbud.no@wavin.com | www.wavin.com

Wavin arbeider kontinuerlig med produktutvikling og forbeholder seg derfor retten til, uten forutgående varsel, å endre eller rette (tekniske) spesifikasjoner av produktene. Alle opplysninger i denne håndboken er gitt i god tro og antas å være korrekte på det tidspunktet den ble utgitt. Wavin påtar seg ikke ansvar for feil, mangler eller feiltolkninger basert på håndboken. Installasjoner og montering må alltid følge den gjeldende monteringsveiledningen. Gratis bistand/serviceytelser som teknisk veiledning, måltaking, beregning av kvantitet og tegningsmateriale mv. er utelukkende en service, hvis riktighet, anvendelighet mv. Nordisk Wavin A/S ikke påtar seg noe ansvar for. © 2022 Wavin