

FACTORY AUTOMATION

Mitsubishi Electric AC Servo System MELSERVO-J5

Innovate Together



GLOBAL IMPACT OF MITSUBISHI ELECTRIC



Through Mitsubishi Electric's vision, "Changes for the Better" are possible for a brighter future.

Changes for the Better

"Changes for the Better" represents the Mitsubishi Electric Group's attitude to "always strive to achieve something better", as we continue to change and grow. Each one of us shares a strong will and passion to continuously aim for change, reinforcing our commitment to creating "an even better tomorrow".

> Our advances in Al and IoT are adding new value to society in

Mitsubishi Electric is involved in many areas including the following:

Energy and Electric Systems

A wide range of power and electrical products from generators to large-scale displays.

Electronic Devices

A wide portfolio of cutting-edge semiconductor devices for systems and products.

Home Appliance

Dependable consumer products like air conditioners and home entertainment systems.

Information and Communication Systems

Commercial and consumer-centric equipment, products and systems.

Industrial Automation Systems

Maximizing productivity and efficiency with cutting-edge automation technology.





OVERVIEW

Concept4
■ Product Lines ······ 10
■ Servo System ······ 14
■ Servo System Controllers24
■ Embedded Type Servo System Controller 54
■ MELSERVO-J5 62
■ Mitsubishi Electric Solutions/Partners/FA Global Website ······ 90
■ Common Specifications (Combinations of Servo Motors and Servo Amplifiers, etc.) ········ 1-1
■ Product Specifications of Servo System Controllers2-1
■ MELSERVO-J5 Product Specifications
Servo Amplifiers3-1Direct Drive Motors6-1Rotary Servo Motors4-1Options/Peripheral Equipment7-1Linear Servo Motors5-1Low-Voltage Switchgear/Wires8-1
■ Product List ······ 9-1
■ Precautions ······· 10-1
■ Support11-1



Create new value with MELSERVO-J5. Unlock performance with a total drive solution.

Maximize system performance

Progressiveness

Performance Maximization

Heritage

Connectivity

MELSER/O

Maintainability

Usability

Progressiveness



For evolution of machines

- ₩____
- Performance improvementProgram standardization

Connectivity



For flexible system configurations

Integration with connectable devices

Usability



For quick operation start

- Tool enhancement
- Improved drive system usability

Maintainability



For prompt detection and diagnosis of failures

- Predictive/preventative maintenance
- Corrective maintenance

Heritage



For utilization of existing devices

 Interchangeability with previous generation models

Maximize the performance of your system and equipment with MELSERVO-J5 total drive solutions

Progressiveness



For evolution of machines

The dramatically improved basic performance of MELSERVO-J5 and CC-Link IE TSN enable total drive solutions that help to increase production efficiency and keep your equipment on the cutting edge.

Performance improvement

- High-speed/high-accuracy/multi-axis
- Vibration suppression
- Compact and energy efficient

Program standardization

- Conforms to IEC 61131-3
- Function blocks for motion control
- Synchronous control /cam control

Connectivity



For flexible system configurations

CC-Link IE TSN enables a high degree of compatibility with IoT technology. Our servo system provides new opportunities for value creation with highly integrated connectable devices and a dramatically expanded range of compatible devices.

Integration with connectable devices

- CC-Link IE TSN
- Connection with TCP/IP devices

Usability



For quick operation start

Our intuitive and user-friendly products are designed to make program development as simple as possible. From system design to maintenance, efficiency is improved at each step of the development process through software and sizing tool enhancement.

Tool enhancement

- Simple programming
- Motor sizing/model selection software
- Collaboration with partners

Improved drive system usability

- Single connector/one-touch lock
- Single/dual cable types
- Servo adjustment



Performance Maximization



Heritage

Connectivity





Usability



Maintainability



For prompt detection and diagnosis of failures

Thanks to years of technical know-how and experience designing state of the art drive technology, we have created predicative and planned maintenance functions that allow you to quickly discover, diagnose, and resolve errors when they occur.

Predictive/preventive maintenance

Corrective maintenance

Machine diagnosis

Servo system recorder NEW

Zero-maintenance

Batteryless absolute position encoder

Heritage



For utilization of existing devices

Incorporate existing manufacturing devices into your new system and benefit from reduced costs and faster construction speed.

Interchangeability with previous generation models

Simple Motion mode NEW

Created using a brand-new approach, this new-generation servo system contributes to reducing the TCO through improved productivity

Focused on improving total performance.

The MELSERVO-J5 series servo system boasts industry-leading level basic performance.

The high-speed, high-precision capabilities of MELSERVO-J5 help to increase the productivity of your machines.

MELSEC IQ-F MELSEC IQ-F MELSEC IQ-R MELSEC IQ-R MUN EN PROGRAM RUM PROGRAM RUM D LINK SD/RD CARD READY CARD READY CARD ACCESS FX5-40SSC-G RD78GH RD78GH RD78G RD78GH RD78G Simple Motion mode added Motion Module



*1. The values are applicable when RD78GH is used

CC-Link IE TSN

CC-Link IE TSN supports TCP/IP communications and applies it to industrial architectures through its support of TSN enabling real-time communications. With its flexible system architecture and extensive setup and troubleshooting features make CC-Link IE TSN ideal for building an IIoT infrastructure across the manufacturing enterprise.

* TSN: Time Sensitive Networking * IIoT: Industrial Internet of Things

CC-Línk IE TSN

CC-Link IE TSN

Personal Computer Embedded Type Servo System Controller



Motion Control Software SWM-G NEW





*2. The minimum operation cycle depends on the number of control axes and the CPU of the personal computer.

Servo System Controllers

The personal computer-compatible SWM-G Motion Control Software is newly available in our product line in addition to MELSEC iQ-R/iQ-F Motion modules.

Motion Modules

The Motion modules utilize a multi-core processor to achieve enhanced basic performance.

The Simple Motion mode is newly available in addition to PLCopen® motion control FB mode.

Motion Control Software

SWM-G Motion Control Software enables software-based motion control in a PC environment.





Servo Amplifiers

The MELSERVO-J5 series high-performance, industry-leading servo amplifiers feature a unique control engine that is more powerful than ever before.

These servo amplifiers can connect to CC-Link IE TSN to perform high-speed, high-precision control.

Each multi-axis servo amplifier drives a maximum of either two or three servo motors (depending on the model of servo amplifier chosen), simplifying wiring and enabling a compact machine at a lower cost.

400 V Class Servo Amplifiers



The MELSERVO-J5 series releases MR-J5-G4/MR-J5-A4 400 V servo amplifiers and MR-J5D-G4 drive units (converter separate type). The drive unit is available in 1/2/3-axis types. Combined with an MR-CV_4 power regeneration converter unit, MR-J5D-G4 can create an energy-saving, space-saving, and less-wiring servo system.

Rotary Servo Motors

equipped with a 26-bit

NEW

The HK series rotary servo motors are equipped with a 26-bit resolution batteryless absolute position encoder.

The following series are newly added to the product lines: HK-MT series (small capacity and ultra-low inertia) featuring the maximum speed of 10000 r/min and HK-RT series (medium capacity and ultra-low inertia) featuring high-speed and compact size with high power rate.

Batteryless Absolute Position Encoders

Mitsubishi Electric's unique multi-revolution detection method allows the saving of absolute position data without a battery.

Single Connector/One-Touch Lock/Single Cable Type

The servo motor power supply, encoder, and electromagnetic brake can be connected using only a single cable. The one-touch lock makes wiring easy.

Innovate Together

CONTROLLER








INTERFACE

CC-Link IE TSN

CC-Línk**IE TSN**


SERVO AMPLIFIER



- * MR-J5-G/MR-J5D1-G4 are also compatible with CC-Link IE Field Network Basic.

 * MR-J5-G-N1/MR-J5W2-G-N1/MR-J5W3-G-N1/MR-J5D1-G4-N1/MR-J5D2-G4-N1/MR-J5D3-G4-N1 are compatible with EtherCAT®.

SERVO MOTOR





We take full advantage of Mitsubishi Electric's technological capability that achieved development of FA devices, along with our connectivity technology which makes it possible to connect FA with IT.


e-F@ctory optimizes manufacturing overall by connecting all devices and equipment, and then analyzing and utilizing the vast amount of data collected.

Create new value with MELSERVO-J5. Unlock performance with a total drive solution









CC-Link IE TSN

Pulse Train/ Analog Voltage



* An MR-CV (400 V class) is required for the drive units.




CONVERTER



* 200 V class



* 400 V class







Through powerful alliances between Mitsubishi Electric, who boasts a broad-ranging product appeal in the FA domain, and partners that participate in the FA partnership program (e-F@ctory Alliance) promoted by Mitsubishi Electric, we will achieve new business creation and new monozukuri.

■Servo System Controllers

	Servo system controller	Number of control axes	Features
Motion	RD78G RD78GH	RD78G: 4, 8, 16, 32, 64 RD78GH: 128, 256	 MELSEC iQ-R series CC-Link IE TSN-compatible Motion module The module performs motion control (positioning, synchronous, cam, speed, and torque control) The max. number of connectable stations is 120 stations (Note 2) The min. operation cycle of RD78G is 62.5 [μs], RD78GH is 31.25 [μs]. The number of slots occupied by RD78G is one slot, RD78GH is two slots.
modules	FX5-SSC-G	FX5-40SSC-G: 4 FX5-80SSC-G: 8	MELSEC iQ-F series CC-Link IE TSN-compatible Motion module • The module performs motion control (positioning, synchronous, cam, speed, and torque control) • The max. number of connectable stations of FX5-40SSC-G is 20 stations, FX5-80SSC-G is 24 stations. (Note 2, 3) • The min. operation cycle is 500 [μs] • The number of connectable modules is 4 modules/FX5U or FX5UC
Motion Control Software	SWM-G	16, 32, 64, 128	CC-Link IE TSN-compatible Motion Control Software for personal computers (Note 1) The software-based controller performs motion control (positioning, synchronous, cam, speed, and torque control) The max. number of connectable stations is 128 stations (Note 2) Real Time OS (RTX64) is included. It enables SWM-G to perform a real-time operation without being affected by the operation on Windows®. Programming language is Visual C++®

Notes: 1. A personal computer and Visual Studio[®] are not included and must be prepared by the user.

2. The multi-axis servo amplifiers MR-J5W2-G/MR-J5W3-G/MR-J5D2-G4/MR-J5D3-G4 occupy one station.

3. Connecting with MR-J5D1-G4/MR-J5D2-G4/MR-J5D3-G4 is planned for a future support.

■Servo Amplifiers

C. Supported C. 11								. i ut	uture support (release) planned –. Not supported																					
							man face		Co	ontro	l mo	de			Co	mpa	tible	ser	vo n	notoi	rser	ies								
ξ	Servo amplifiers	Number of control axes	Power supply specifications (Note 2)	Rated output [kW] (Note 1)	CC-Link IE TSN (Note 3)	EtherCAT® (Note 5)	Pulse train	Analog voltage	Position	Velocity/Speed	Torque	Fully closed loop control	HK-KT	HK-MT	HK-ST	HK-RT	LM-H3	LM-AJ	LM-F	LM-K2	LM-U2	TM-RG2M	TM-RU2M	TM-RFM						
	MR-J5-G	1 axis	200 V AC	0.1, 0.2, 0.4, 0.6, 0.75, 1, 2, 3.5, 5, 7	•	•	-	-	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•						
		i axis	i axis	i axis	i axis	i axis	I axis	I axis	400 V AC	0.6, 1, 2, 3.5	•	•	_	-	•	•	•	•	•	0	•	•	-	-	-	-	-	-	-	_
CC-Lini	MR-J5W-G	2 axes	200 V AC	0.2, 0.4, 0.75, 1	•	•	_	-	•	•	•	•	•	•	•	•	•	•	ı	•	•	•	•	•						
CC-Link IE TSN		3 axes	200 V 710	0.2, 0.4	•	•	_	-	•	•	•	_	•	•	•	-	•	•	_	•	•	•	•	•						
	MR-J5D-G4 (Note 4)	1 axis		1, 2, 3.5, 5, 7	•	•	-	-	•	•	•	•	•	0	•	•	-	-	-	-	-	-	-	-						
		2 axes	400 V AC	1, 2, 3.5, 5, 7	•	•	-	-	•	•	•	•	•	0	•	•	-	-	-	-	-	-	-	-						
		3 axes		1, 2	•	•	_	-	•	•	•	-	•	0	•	•	ı	_	ı	-	ı	ı	-	-						
General-purpose interface	General-	1 axis	200 V AC	0.1, 0.2, 0.4, 0.6, 0.75, 1, 2, 3.5, 5, 7	-	-	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•						
purpose		1 axis	400 V AC	0.6, 1, 2, 3.5	-	-	•	•	•	•	•	•	•	0	•	•	-	-	-	-	-	-	-	-						

Notes: 1. The value listed is the servo amplifier rated output. Refer to "Combinations of Servo Motors and Servo Amplifiers" for compatible servo motors.

2. 200 V AC servo amplifiers are also compatible with DC power supply input as standard.

3. MR-JS-GMR-JSD1-G4 are also compatible with CC-Link IE Frield Network Basic.

4. An MR-CV_4 power regeneration converter unit is required for MR-JSD-G4 drive units.

5. EtherCAT® is supported by MR-JS-G-N1/MR-JSW2-G-N1/MR-J5W3-G-N1/MR-J5D1-G4-N1/MR-J5D2-G4-N1/MR-J5D3-G4-N1.

■Converter Units (Note 1)

Simple converter	Power supply specifications	Capacity [kW]			
MR-CM					
	200 V AC	3			

Power regeneration converter unit	Power supply specifications	Capacity [kW]
MR-CV_4	400 V AC	11, 18, 30, 37, 45, 55, 75

Converter unit features
The converter units support multi-axis systems
and enable the following:

- boosting energy efficiency by using
- regenerative energy effectively

 reducing the number of molded-case circuit breakers and magnetic contactors to be used
- simplifying wiring
- · reducing installation space

■Rota	■Rotary Servo Motors ●: Supported -: Not supported										
Rotary	r servo motor series	Rated speed [r/min] (Note 2)	Rated output [kW] ^(Note 1)	With an electro- magnetic brake (B)	With a gear reducer (G1, G5, G7) (Note 4)	IP rating (Note 3)	Replaceable series	Features	Application examples		
Small	HK-KT series	3000 (6700)	0.05, 0.1, 0.15, 0.2, 0.4, 0.6, 0.75, 1.0, 1.5, 2.0 0.4, 0.6, 0.75, 1.0, 1.5, 2.0	•	•	IP67	HG-KR HG-JR		X-Y tables Semiconductor		
Small capacity	HK-MT series	3000 (6700/ 10000)	0.05, 0.1, 0.15, 0.2, 0.4, 0.6, 0.75, 1.0			IP67	HG-MR	Ultra-low inertia Batteryless absolute position encoder Product line includes high- speed type models. (Note 5) Connects using single connector.	Inserters Mounters Ultra-high-throughput material handling systems		
Medium capacity	HK-ST series	2000/ 3000 (4000/ 6700)	0.5, 1.0, 1.75, 2.0, 3.0, 3.5, 5.0, 7.0 0.5, 1.0, 1.75, 2.0, 3.0, 3.5, 5.0, 7.0	•	•	IP67	HG-SR HG-JR	Medium inertia Batteryless absolute position encoder Product line offers two choices of rated speed.	Material handling systems Battery manufacturing systems Printing systems Food packaging machines		
capacity	HK-RT series	3000 (6700)	1.0, 1.5, 2.0, 3.5, 5.0, 7.0 1.0, 1.5, 2.0, 3.5, 5.0, 7.0	•	-	IP67	HG-RR	Ultra-low inertia Batteryless absolute position encoder Connects using single connector (1 to 2 kW).	X-Y tables Ultra-high-throughput material handling systems		

- Notes: 1. :For 400 V.

 2. The value in brackets indicates the maximum speed. The speed varies by the model type. Refer to "Rotary Servo Motors Specifications" for details.

 3. The shaft-through portion is excluded. For geared servo motors, IP rating of the reducer part is equivalent to IP44.

 4. G1 indicates a gear reducer for general industrial machines, and G5 and G7 indicate a gear reducer for high precision applications. HK-KT series servo motors are available in 200 V only. Refer to "Rotary Servo Motors Specifications" for details.

 5. The high-speed type models (maximum speed of 10000 r/min) are equipped with an incremental encoder.

■Linear Servo Motors

Linear	servo motor series	Maximum speed [m/s]	Continuous thrust [N]	Maximum thrust [N]	Cooling method	Features	Application examples	
	LM-H3 series	3.0	70, 120, 240, 360, 480, 720, 960	175, 300, 600, 900, 1200, 1800, 2400	Natural cooling	Suitable for space-saving. Compact size and high thrust. Maximum speed: 3 m/s.	Mounters Wafer cleaning systems FPD assembly machines Material handlings	
Co	LM-AJ series	2.0 to 6.5 68.1, 117.0, 136.2, 174.5, 223.4, 234.0 348.9, 446.8		214.7, 369.0, 429.4, 550.2, 704.5, 738.1, 1100.4, 1409.1	Natural cooling	Low installation height, and suitable for compact X-Y tables.	Semiconductor manufacturing systems FPD assembly machines	
Core type	LM-F series	2.0	300, 600, 900, 1200	1800, 3600, 5400,	Natural cooling	The integrated liquid-cooling	Press feeders NC machine tools	
		2.0	600, 1200, 1800, 2400	7200	Liquid cooling	everam dollning the continuous	Material handlings	
	LM-K2 series	2.0	120, 240, 360, 720, 1200, 1440, 2400	300, 600, 900, 1800, 3000, 3600, 6000	Natural cooling	Magnetic attraction counter-force	Mounters Wafer cleaning systems FPD assembly machines	
Coreless	LM-U2 series	2.0	50, 75, 100, 150, 225, 400, 600, 800	150, 225, 300, 450, 675, 1600, 2400, 3200	Natural cooling	Magnetic attraction counter-force structure enables longer life of the linear guides and lower audible	Screen printing systems Scanning exposure systems Inspection systems Material handlings	

■Direct Drive Motors

Direct	t drive motor series	Motor outer diameter [mm]	Hollow shaft diameter [mm]	Rated speed [r/min]	Maximum speed [r/min]	Rated torque [N·m]	Maximum torque [N·m]	IP rating	Features	Application examples		
	TM-RG2M/TM-RU2M series	ø130	ø20	300	600	2.2	8.8	IP40	Suitable for low-speed and			
Low-profile	(00)	ø180	ø47	300	600	4.5	13.5		high-torque operations. Smooth operation with	Semiconductor		
file				ø230	ø62	300	600	9	27	IP40	less audible noise. The motor's low profile	manufacturing devices
_	TM-RFM series	ø130	ø20	200	500	2, 4, 6	6, 12, 18	11242	"	Liquid crystal manufacturing		
ligh-r	0000	ø180	ø47	200	500	6, 12, 18	18, 36, 54	IP42		devices Machine tools		
High-rigidity	19	ø230	ø62	200	500	12, 48, 72	36, 144, 216	IP42	stability.			
γ		ø330	ø104	100	200	40, 120, 240	120, 360, 720	IP42	Clean room compatible.			

Notes: 1. Connectors and the gap along the rotor (output shaft) are excluded.

Construct a high-performance servo system using our extensive product line



Servo motors



Collaborating with our extensive group of partners allows us to flexibly support your system needs

Servo systems are constructed using iQ Platform devices such as controllers, servo drivers, actuators, and sensors, and collaboration with our partner companies allows us to expand the number of possibilities available to customers. For example, partner products such as stepping motors, direct drive motors, vision systems, and various types of software are available to keep your equipment on the cutting edge.



Single network

CC-Línk IE TSN



Safety I/O combined module


I/O module

Analog output module



CC-Link IE TSN safety communication function Deterministic control even when mixed with TCP/IP communication and safety communication

CC-Link IE TSN enables mixing of safety and non-safety communications.*1 Safety sub-functions (STO, SS1, SS2, SOS, SLS, SBC, SSM, SDI, SLI, SLT) are also supported for drive-control devices that are on the network. Deterministic performance of cyclic communication is maintained even when mixed with slower information data (non real-time). This enables TCP/IP communication



devices to be used without affecting overall control.




Open integrated networking across the manufacturing enterprise

CC-Línk**IE TSN**


CC-Link IE TSN supports TCP/IP communications and applies it to industrial architectures through its support of TSN enabling real-time communications. With its flexible system architecture and extensive setup and troubleshooting features make CC-Link IE TSN ideal for building an IIoT infrastructure across the manufacturing enterprise.

* TSN: Time Sensitive Networking * IIoT: Industrial Internet of Things



Real-Time Network Performance Even When Integrated with Information Data


TSN technology enables mixing of deterministic communications with IT system information data on the same network. Giving higher priority to CC-Link IE TSN cyclic communications and TCP/IP communications by allocating increased network bandwidth, devices using general Ethernet communications can be connected on the same network while maintaining real-time control communication performance.




Deterministic Control Even When Mixed with TCP/IP Communication

Deterministic performance of cyclic communication is maintained even when mixed with slower information data (non real-time). This enables TCP/IP communication devices to be used without affecting overall control.

* Some devices cannot be connected to CC-Link IE TSN depending on the system configuration.







^{*1.} Class B switching hub supporting CC-Link IE TSN recommended by the CC-Link Partner Association

Integrated Network

Current network systems use multiple networks to enable communication between IT and control systems on the shop floor.

CC-Link IE TSN is a one-stop solution for integrating different networks, thereby realizing flexibility in topology and reducing wiring cost.






High-Speed, High-Accuracy Motion Control


CC-Link IE TSN controls I/O modules while also maintaining high-speed motion control. The single network boosts machine performance.

- Motion control (high-speed processing)
- I/O control (low-speed processing)^{*1}



Time Synchronization


Set time is completely synchronized among servo amplifiers, Motion modules, and PLC CPUs. This time synchronization enables accurate recording of the event history in chronological order, making it simple to identify the cause of errors.



Seamless Connectivity Between TCP/IP Devices and a Servo System


TCP/IP communication (information communication) can be mixed in the same line with the real-time control communications of CC-Link IE TSN.

CC-Link IE TSN slave devices and TCP/IP devices can be connected on the same network, achieving a flexible and integrated network system. Note that the TCP/IP devices must be connected after servo amplifiers and I/O modules.



Large-Capacity Data Communications

CC-Link IE TSN is a high-speed, large-capacity 1 Gbps communications network that is capable of sending and receiving large amounts of data, such as manufacturing, quality, and control data from the production process. The network can transmit large recipe data or traceability data at high speeds without degrading the performance of servo system communications. In addition, Ethernet supported devices can directly and seamlessly connect to controllers on the same network line.



Simple maintenance

Comprehensive diagnostic functions contribute to improved maintenance

Increasing the capacity of your production line is an important factor in this fiercely cost-competitive market. The MELSERVO-J5 series servo system provides various kinds of maintenance functions that predict and prevent unforeseen problems and enable quick recovery when trouble arises.

These functions contribute to reduced downtime and increased productivity while protecting the quality of your products.

MELSERVO-J5 series servo amplifiers and servo motors are equipped with various predictive and preventative maintenance functions.

Predictive Maintenance (CBM)

Predictive maintenance, also known as Condition Based Maintenance (CBM), is the practice of detecting changes in machine vibration and friction so that parts can be replaced accordingly before they fail.

Performing predictive maintenance leads to increased machine capacity and helps to avoid downtime, reduce maintenance time, and improve both productivity and product quality.


Detects Changes in Vibration and Friction to Predict the Service Life of Mechanical Drive Components

[Machine diagnosis function]


The machine diagnosis function detects age-related deterioration based on the frictions and vibrations of mechanical drive components such as ball screws, belts, and gears. This function automatically generates a failure warning limit, detects errors, and outputs a warning upon signs of failure. Results of the failure are transmitted via CC-Link IE TSN to the motion module and IT system and can be used for maintenance and overall machine diagnostics.









 Vibration failure prediction with the vibration estimation function



Estimated friction value is displayed.



 Static friction failure prediction
 Belt tension deterioration prediction



Estimated static friction and belt tension are displayed



Backlash estimation functionGear failure prediction



Estimated backlash value is displayed


Preventative Maintenance (TBM) *1

*1. TBM stands for Time Based Maintenance.

Machine Diagnosis (Mechanical Drive Components)

This function estimates when a machine failure will occur based on the total travel distance of the servo motor, and notifies when it is time for replacement if the rated life of the mechanical drive components is set.


Machine total travel distance failure prediction



Servo Amplifier Life Diagnosis

This function displays the cumulative energization time and the number of inrush relay on/off times. The data can be used to check service life of the parts as a rough guide.


- Cumulative energization time (Smoothing condenser/ cooling fan life span)
- The number of inrush relay on/off times (Inrush relay life)



Corrective Maintenance

Servo System Data Recording

The servo system recorder of RD78G/RD78GH Motion module automatically collects data of all the real drive axes when an error occurs. The drive recorder of the servo amplifier continuously monitors the servo status and records the status transition such as a trigger condition before and after an alarm for a fixed period of time.



An engineering environment that provides common, consistent usability throughout all product development phases

Programmable Controller Engineering Software

MELSOFT GX Works3

Program creation is largely dependent on the ability of the programmer; therefore, an enormous amount of time is often spent on creating a servo program where a high level of programming expertise is required.

"MELSOFT GX Works3" introduces a more intuitive, efficient, and user-friendly programming environment that revolutionizes the programming process and minimizes hassles.

Engineering Environment for Maximizing Your Machine Performance

• Mitsubishi Electric offers a complete, consistent engineering environment which covers all aspects of the product development cycle from sizing motors all the way to programming with function blocks, startup, and maintenance.

System Design

Programming





Network configuration







Useful Servo Software

[Drive system sizing software: "Motorizer"]

Our upgraded motor sizing software enables you to more flexibly select a suitable servo system for your machine. The upgraded features include expansion of selectable load mechanisms (13 types), multiple sizing results, and the ability to size a multi-axis system.

[Model selection software]


Servo amplifiers, servo motors, and indispensable options such as encoder cables can all be selected.



Motor sizing software



Model selection software



All-in-one engineering platform MELSOFT GX Works3 allows you to set different modules in a single project, including the setting
of a wide range of areas from servo amplifier parameters to PLC CPU data.







Monitor





Servo adjustment*1

Event history

Globalization

[PLCopen® Motion Control FB]

PLCopen® Motion Control FB is a standardized interface, and therefore people other than the program designer can understand the programming, leading to reduced design and maintenance time.



[Conforms to IEC 61131-3]

MELSOFT GX Works3 realizes structured programming such as ladder and ST, making project standardization across multiple users even easier.

[Multi-language support for global operations]

To adhere to today's global production needs, MELSOFT GX Works3 supports multilanguage features at various levels, from the multiple language software menu system to device comment language switching features.

Supported languages: English, Japanese, and Chinese.



*1. The servo adjustment is enabled via MR Configurator2.

(0)	MO H	MI	M2
	M2	L MO	
(6)			(END)—





Simple Motion Mode Simple Motion

The Simple Motion mode is a new operation mode that enables the Motion module to utilize an existing project for driving servo amplifiers via CC-Link IE TSN. Reusing the existing projects helps reduce the program development time.

CC-Línk**IE TSN**

Motion Module

MELSEC iQ-R

RD78G

MELSEC iQ-F

FX5-SSC-G





Motion profile table

Advanced synchronous control

Select

Digital oscilloscope


Features of Simple Motion Mode


- Executes positioning control with the motion profile table and synchronous control with parameter settings.
- Connects remote devices via CC-Link IE TSN. The PLC CPU reads/writes the data of the remote devices.
- Supports the digital oscilloscope that collects data synchronized with the motion operation cycle and displays the waveforms data, helping users check the operations.

An example of programming in Simple Motion mode









Product Lines



CC-Línk**IE TSN** MELSEC iQ R

RD78G4: **RD78G8:** 8 axes RD78G16: 16 axes





FX5-40SSC-G: 4 axes NEW FX5-80SSC-G: 8 axes NEW



Progressiveness



PLCopen® Motion Control FB Mode PLCopen®

The PLCopen® motion control FB mode is the operation mode that supports programming with PLCopen® Motion Control FBs, enabling structured/component programming for standardization.

When selecting this mode, the Motion module executes motion control with various advanced technologies such as programming using PLCopen® Motion Control FBs in ST language and logging of motion control data.

CC-Línk**IE TSN**

Motion Module

Select

MELSEC iQ-R

RD78GH RD78G



ST language

PLCopen® Motion Control FB


Logging

Features of PLCopen® Motion Control FB Mode

- Supports ST language for programming while a PLC CPU supports ladder, FBD/LD, and ST language.
- Utilizes the library of PLCopen® Motion Control FBs, which are compliant with international standards, for programming.
- Enables users to analyze the operation status with logging data on GX LogViewer, improving debug efficiency.

An example of programming by PLC CPU


[Programming by PLC CPU only]



A PLC CPU program starts operation of the Motion module, eliminating the need for users to create another program for the Motion module, reducing programming burden.

An example of programming by each module

[Programming by PLC CPU and Motion modules]



Motion modules can execute operations in place of the PLC CPU. This reduces the operation burden on the PLC CPU and results in a shorter cycle time.

Product Lines





RD78GHV: 128 axes RD78GHW: 256 axes



CC-LinkIE TSN MELSEC iO-R

RD78G4: 4 axes RD78G8: 8 axes RD78G16: 16 axes RD78G32: 32 axes RD78G64: 64 axes

Taking evolution to the next step with Simple Motion mode



Combined with a CC-Link IE TSN-compatible servo amplifier, the Motion modules create a high-performance servo system that improves machine capability.

- Connects remote I/O modules and FR-A800-GN inverters via CC-Link IE TSN. The data of these devices can be read/written by a CPU module.
- Connects TCP/IP devices, enabling a flexible system configuration.
- Possible to reuse the existing projects of Simple Motion modules.

Product Lines





MELSEC iQ R **RD78G4 RD78G8 RD78G16**

- Maximum number of control axes: 16 axes/module (RD78G16)
- Minimum operation cycle^{★1}: 250 [µs]
- Compatible servo amplifiers

MR-J5-G MR-J5D-G4



MELSEC iQ F FX5-40SSC-G NEW

FX5-80SSC-G




- Maximum number of control axes: 4 axes/module (FX5-40SSC-G), 8 axes/module (FX5-80SSC-G)
- Minimum operation cycle^{*1}: 500 [µs]
- Maximum number of connected modules*2: 4 modules/system
- Compatible servo amplifiers*3 MR-J5-G
- *1. The operation cycle varies by the number of control axes and the models
- *2. This refers to the total number of the Motion modules and one
- FX5-CCLGN-MS (master station).
 *3. MR-J5D-G4 is planned for a future support.

Reuse of Existing Projects

The existing projects of a Simple Motion module can be reused. This enables reduction in program development time.


RD77MS⇒RD78G

Select [Change Module] in the navigation menu of GX Works3 to convert the Simple Motion project to a Motion module project. After the conversion, set the network parameters, servo amplifier parameters, and other parameters.



QD77MS⇒RD78G

Select [Import Simple Motion Module Data] in the navigation menu of GX Works3 to import the parameters of QD77MS. After the import, set the network parameters, servo amplifier parameters, and other parameters.





Improved Performance

Simple Motion

The minimum operation cycle of RD78G in Simple Motion mode is approximately 1.7 to 3.5 times faster than that of the previous models. The data from the servo amplifiers and input/output signals can be received at high speeds, which reduces the cycle time.




System Configuration

Simple Motion

The Motion module can function as a master station of CC-Link IE TSN.*1

This feature enables users to create a system more flexibly by connecting various devices, such as servo amplifiers, remote I/O modules, and TCP/IP devices, to the Motion module.*5




- *1. The Motion modules are not provided with the following functions: sub-master station, local station, multi-master configuration, and backup/restore function.
- *2. Standard stations refer to slave stations other than motion control stations on CC-Link IE TSN.
- *3. When connecting FR-E800-E to RD78G, set the communication speed of CC-Link IE TSN to 100 Mbps.
- *4. TCP/IP devices are not included in the standard stations.
- *5. When Class B and A devices are mixed in the same system, up to eight Class B devices can be connected Refer to manuals for precautions when Class B and A devices are mixed.
- *6. RD78G can connect up to 120 devices, which is the total number of the motion control stations and standard stations. FX5-40SSC-G/FX5-80SSC-G can connect 16 standard stations and the stations for the number of control axes.

Positioning Control

Simple Motion


Positioning control is easily executed using a motion profile table.

- To meet various application needs, the Motion module offers various types of positioning control, such as linear interpolation, 2-axis circular interpolation, fixedpitch feed, and continuous path control.
- An automatic operation can be executed easily by setting the positioning address, the speed, and other setting items in a sequence program.
- Powerful sub-functions, such as M-code output, skip, speed change, and target position change functions, are available.




Programming

The Motion module easily executes positioning operation with the instruction in a sequence program that starts a positioning data of the motion profile table. To meet various application needs, the Motion module offers various types of control, such as linear interpolation, two-axis circular interpolation, fixed-pitch feed, and continuous path control.




Target Position Change Function

The target position can be changed at any time even when the products are being moved (1-axis linear control). The product is examined with the vision system while being moved to the next line. If a faulty product is found, the target position is changed so that the faulty product is put in a separate tray for those rejected.



..... Change to the rejects tray route




Synchronous Control



Synchronous control can be achieved using software instead of controlling mechanically with gear, shaft, clutch, speed change gear or cam, etc.

- Synchronous control can be flexibly started/ended for each axis, enabling the synchronous control axis and positioning control axis
 to be used within the same program.
- Command generation axis, servo input axis, or synchronous encoder axis can be set as the input axis.
- The output axis is operated with a cam. The following three operations can be performed with the cam functions: linear operation, two-way operation, and feed operation.
- An incremental synchronous encoder*1 can be connected via MR-J5-G(-RJ)/MR-J5W2-G servo amplifier.




^{*1.} When configuring an absolute position system, use an encoder of HK series servo motors.

[Command generation axis]


Command generation axis is the axis that performs only the command generation.

It is controlled independently of other axes connected to servo amplifiers. (not counted as a control axis)

Parameter Settings




Synchronous control is executed by setting parameters of the input axis, output axis, gear, and clutch for synchronous control and turning on the synchronous control start signal.



The cam graph can be flexibly and easily created through drag & drop. The waveform is changed according to the pointer's movement.

Start/Stop

Synchronous control can be executed after synchronous parameters are set for each output axis. When synchronous control start signal is turned on, the synchronous control parameters are analyzed, and the status is changed to during synchronous control. The output axis is operated by the commands transmitted from the input axis.




Selectable Speed Control to Best Fit Your System Needs

Simple Motion

Two types of speed control are available: speed control that includes position loop and speed control that does not include position loop.


Speed Control That Does Not Include Position Loop

- Control mode setting of the servo amplifier: velocity control mode
- Minimizes speed deviation by flexibly responding to speed changes, such as those that occur when the load changes.
- Suitable for machines which keep driving the motors at constant speed, such as a wind/unwind machine.



Speed Control That Includes Position Loop

- Control mode setting of the servo amplifier: position control mode
- Suitable for operations that repeatedly switch between speed and position control.



Belt conveyor

Torque Control



Torque Control

The axes in torque control are controlled to run at the constant torque following the torque command.

When the load is light and the speed increases to the set limit, the torque control switches to speed control.




Application example

[Unwinding axis of converting machines]

Torque control unwinds film at constant tension to prevent wrinkling in the film.


The tension can be kept constant by sequentially controlling the torque commands. This type of control is perfect for unwinding machines that need to keep the tension of unwound materials constant.




Continuous Operation to Torque Control

When using this control, you can switch from position control to torque control continuously without stopping the servo motor.

- The current positions are always tracked even in torque control, and therefore positioning is executed smoothly in position control after switched from the torque control.
- Position control is smoothly switched to torque control without stopping the servo motor.



Application example




Auxiliary Functions

Simple Motion

Virtual Servo Amplifier


The virtual servo amplifier function enables operations of a virtual servo amplifier as if an actual unit is connected. When the virtual servo amplifier is set as a servo input axis of synchronous control, the Motion module executes synchronous control with virtually generated input commands.

In addition, this function is used to simulate an axis without an actual connection.




Read/Write Operation of Standard Stations

- The PLC CPU sends/receives link devices to/from standard stations (remote stations other than the motion control stations) through a Motion module.
- One-to-one communication is possible between the master and remote stations.
- The PLC CPU can be programmed using the signals of the remote stations.




*1. RX and RY are not available for some remote devices



Automatic Return

When slave stations are back to normal status after disconnected due to a data link error, this function automatically returns the disconnected stations to the network and restarts data link.


When defective components need to be replaced in one of the machines in a production line or one of the units in a machine, only the machine or the unit can be partly turned off without powering off the whole system.



Mark Detection

This function latches data responding to a trigger signal input to a servo amplifier.

The compensation amount is calculated based on the latched data, and the error is compensated using a compensation axis.




CC-Link IE TSN Safety Communication Function



CC-Link IE TSN enables control of safety and non-safety communications realizing a flexible system whereby safety communications can be easily incorporated into the main control network.

In the following system which integrates safety and non-safety communications, the safety CPU checks the safety signals received via the safety remote I/O module and outputs the safety signals (STO, etc.) to the servo amplifiers. Outputting safety signals via the network eliminates the need for wiring of safety signals to a safety controller and a servo amplifier.

The CC-Link IE TSN safety communication function is available with iQ-R series Motion modules. When using iQ-F series Motion module, use the safety sub-function of the servo amplifiers.




Optional Data Monitor



Servo operation is monitored with extensive servo data acquired via CC-Link IE TSN. The acquired data can be transferred to IT system or transferred and displayed on any user-created GOT screen in the network. The target data for monitoring can be flexibly changed during operation.



One software, many possibilities



MELSOFT GX Works3 has a variety of features which help users create projects and conduct maintenance more flexibly and easily. Our variety of engineering software (GX Works3, sizing software, and model selection software, etc.) fully covers all stages of development processes from parameter settings to maintenance of Motion module, servo amplifier, and servo motors.

GX Works3

This software supports overall development processes for PLC CPUs from system design to maintenance.

Servo Setup Software MR Configurator2

Tuning, monitor display, diagnosis, reading/writing parameters, and test operations are easily performed on a personal computer. This powerful software tool supports a stable machine system and optimum control, and moreover, shortens setup time.

Model Selection Software

Servo amplifiers, servo motors, and indispensable options such as encoder cables can all be selected.

Simple Motion Module Setting

This software covers various development processes for the Motion module from parameter settings, debug, to maintenance.

Drive System Sizing Software "Motorizer"

The most suitable servo motors, servo amplifiers, and regenerative options for your machine can be selected just by setting machine specifications and operation patterns.




Engineering Environment



Our variety of engineering software (GX Works3, sizing software, model selection software, etc.) fully covers all stages of development processes from parameter settings to maintenance of Motion modules, servo amplifiers, and servo motors.

System Design






Network configuration

- Module configuration
- Network configuration
- Data settings for servo amplifiers
- Settings for remote I/O

Programming (Positioning)



Positioning data setting





Automatic calculation of command speed

- Programming with Ladder, SFC, FBD/LD
- Positioning data settings
- Offline simulation, automatic calculation of command speed

Programming (Synchronous Control) Programming








Cam data creation

- Synchronous control parameter
- Cam data creation, cam data list

Debug/Maintenance







Digital oscilloscope

- Event history
- Current value history, start history, axis monitor
- Servo monitor
- Digital oscilloscope

Unlock new system capabilities together with CC-Link IE TSN



These Motion modules with multiple-core processors enable to configure a high-speed, large system by supporting the CC-Link IE TSN real-time open network.

- Performs positioning control such as linear interpolation using function blocks. The programming is easy: users just need to set
 positioning data to the function blocks.
- Connects to various modules such as servo amplifiers and I/O modules via CC-Link IE TSN. This connectivity allows you to configure a servo system more flexibly.
- Supports a consistent engineering environment that is capable of handling tasks ranging from system design to debugging and maintenance.

Product Lines





CC-Link IE TSN MELSEC iQ-R RD78GHV RD78GHW

- Maximum number of control axes: 128 axes/module (RD78GHV) 256 axes/module (RD78GHW)
- Minimum operation cycle *1: 31.25 μs
- ST language program capacity: Built-in ROM max. 64 MB + SD memory card
- Compatible servo amplifiers MR-J5-G MR-J5D-G4

RD78GHV/RD78GHW are designed with a quad-core processor that enables higher-speed control. These Motion modules can be directly programmed to distribute load control with PLC CPUs.

This ensures that performance will not be degraded even when the number of axes is increased.






- Maximum number of control axes:
 64 axes/module (RD78G64)
- Minimum operation cycle *1: 62.5 µs
- ST language program capacity:
 Built-in ROM max. 16 MB + SD memory card
- Compatible servo amplifiersMR-J5-GMR-J5D-G4

RD78G4/RD78G8/RD78G16/RD78G32/RD78G64 are designed with a dual-core processor, and can be programmed to enable various types of control, such as positioning, synchronous, cam, speed, and torque control.

Inter-Module Synchronization Financed functions


- System expansion is possible by using inter-module synchronization.
- Control load distribution among the PLC CPU and the Motion modules is possible, and therefore the number of axes can be increased without sacrificing performance.



Improved Performance

PLCopen®


The minimum operation cycle of RD78GH in PLCopen® motion control FB mode is approximately 4.1 to 6.2 times faster than that of the previous models, and the number of maximum control axes is 4 to 8 times more. The data from the servo amplifiers and input/output signals can be received at high speeds, which reduces the cycle time.



System Configuration

PLCopen[®]

The Motion Module provides functionality equivalent to a CC-Link IE TSN master/local module *1 and executes motion control while functioning as a master station. This dual functionality results in reduced system costs.



- *1. Compared to the master/local module, the Motion modules are not provided with the following functions: sub-master station, local station, multi-master configuration, backup/restore function, and data communication function between general stations.
- *2. Future support planned
- *3. When connecting FR-E800-E to RD78G, set the communication speed of CC-Link IE TSN to 100 Mbps.

Positioning Control


PLCopen®


Two types of positioning control are available: single-axis and multi-axis positioning control. This variety allows you to meet various control needs.

Item	Control types		
Single-axis	Positioning	Absolute positioning	
		Relative positioning	
control	Homing		
	JOG operation		

Item	Control types			
Multi-axis control	Linear	Absolute linear interpolation		
	interpolation	Relative linear interpolation		
	Circular	Absolute circular interpolation		
	interpolation	Relative circular interpolation		
	Multi-axis path control			


Main Control





Circular interpolation


Multi-axis path control *1



^{*1.} The multi-axis path control is possible using the buffer mode.

Programming

Positioning operation can be executed with a PLCopen® Motion Control FB or a Mitsubishi Electric's original function block. Various patterns of positioning operation can be achieved by setting the travel distance, velocity, acceleration, deceleration, jerk, and buffer mode of the function block.



Acceleration/Deceleration Methods

PLCopen[®]

Three types of acceleration/deceleration methods are available: trapezoidal acceleration/deceleration, jerk acceleration/deceleration, and acceleration/deceleration time fixed.

Trapezoidal acceleration/deceleration

After starting, maximum acceleration is maintained until the target speed is reached.

For example, when a vehicle loaded with a workpiece accelerates suddenly, the workpiece will swing back and forth due to the impact of the sudden acceleration.

To reduce impacts and vibrations in a case such as this, the vehicle must accelerate at a slower rate.


The speed creates a trapezoidal shape.

Jerk acceleration/deceleration


The acceleration changes gradually.

For example, when a vehicle loaded with a workpiece accelerates gradually, the load will not swing back and forth after acceleration. The jerk is maintained during acceleration. When the vehicle has almost reached the target speed, the jerk is decelerated. Adjusting jerk in this way achieves smooth acceleration/deceleration while also shortening the time it takes to reach the target speed. The speed creates a S-curve shape.










Acceleration/deceleration time fixed method

This method executes acceleration/deceleration based on the time specified, regardless of the commanded speed.



^{*1.} Input acceleration.

^{*2.} Specify acceleration time.


High Flexibility in Synchronous Control



Synchronous control is performed using function blocks that operate as software-based mechanical modules such as gear, shaft, speed change gear, and cam.


- The number and the combination of the synchronous modules are flexibly selected, achieving optimized operation.
- The following two types of cam data are available: cam data and cam data for a rotary knife
- Complex cam control is possible by flexibly switching cams.
- Positioning and synchronous control can be performed together in the same program.
- Cam for a rotary knife can be easily created in MELSOFT GX Works3 or by using function blocks.
- Synchronous control using a synchronous encoder is possible.

[An example of packing machine program]



[Time chart]


This program synchronizes all the axes, from the cutting axis through the unwinding axis, with the master axis. The following shows the time chart of the film cutting operation.



Synchronous Encoder

The Motion module easily performs synchronous control by setting a synchronous encoder to "Real encoder axis" and creating a program with function blocks.


The number of command pulses can be adjusted using the function block (MC_Gearin) or a parameter.





Changing Cam No.

The cam being executed can be flexibly switched to another cam, and cam control can smoothly switch to positioning control without stopping the servo motor.



Cam Data

PLCopen[®]

Create operation profile data*1 (cam data) according to your application. The created cam data is used to control output axis. The following three cam operations are available: linear operation, two-way operation, and feed operation. Choose one according to your application.


*1. "Operation profile data" is a general name for waveform data, which is used for various applications.

Operation Profile Data (Cam Data)

Linear operation

The cam pattern is a linear line.

This pattern is used for a ball screw and a rotary table.






Rotary table [Unit: degree]

Two-way operation

The beginning and the end of the cam pattern are the same. Mechanical cams fall into this category.




Feed operation

The beginning and the end of the cam pattern differ.

This pattern is used for fixed-amount feed operations and intermittent operations.

Set the end point for the feed operation to a position of your choice.



Rotary table [Unit: degree]


Application examples

[Machine with all axes synchronized]




All the axes of the machine are in synchronization.

[Machine with only certain of the axes synchronized]




Only two axes are synchronized. The other axes perform positioning operation while the two axes execute synchronous control.



The two arms can avoid interference by synchronizing with each other, shortening the cycle time.


Operation Profile Data PLCopen®

The operation profile data is divided into the following two types of cam data.



Importing Operation Profile Data in CSV Format


The operation profile data in a CSV format on a personal computer can be imported directly to a Motion module.



Easy Cam Creation for a Rotary Knife

Cam data for a rotary knife is automatically generated with MELSOFT GX Works3 or by using a function block.

- (Using function block) The operation profile data (cam data) is created just by setting the sheet length and sheet synchronization width, etc., to the function block and starting it.
- (Using MELSOFT GX Works3) Set the sheet length and sheet synchronization width, etc., which automatically generates cam data for a rotary knife.



Servo Amplifier Control Mode

PLCopen®

The servo amplifier has three control modes: position, velocity, and torque control modes.

[Control mode]

Position control mode: Accurately move to the target position

(Speed control that includes position loop)


Velocity control mode: Drive at the specified speed

(Speed control that does not include position loop)

Torque control mode: Drive at the specified torque

Note 1: Transits at stop completion or error occurrence.

Note 2: Transits when Aborting or Buffered is executed to an instruction other than MC_MoveVelocity/MC_TorqueControl.




Selectable Speed Control to Best Fit Your System Needs



Two types of speed control are available: speed control that includes position loop and speed control that does not include position loop.


Speed Control That Does Not Include Position Loop

- Control mode setting of the servo amplifier: velocity control mode
- Minimizes speed deviation by flexibly responding to speed changes, such as those that occur when the load changes.
- Suitable for machines which keep driving the motors at constant speed, such as a wind/unwind machine.



Speed Control That Includes Position Loop

- Control mode setting of the servo amplifier: position control mode
- Suitable for operations that repeatedly switch between speed and position control.



Belt conveyor

Torque Control

PLCopen®

Torque Control Mode

The motor drives following the commanded torque and keeps the torque constant and stable.

When the load is light and the speed increases to the set limit, the torque control switches to speed control.




Application example

[Unwinding axis of converting machines]

Torque control unwinds film at constant tension to prevent wrinkling in the film.


The tension can be kept constant by sequentially controlling the torque commands. This type of control is perfect for unwinding machines that need to keep the tension of unwound materials constant.




Continuous Operation to Torque Control Mode

When using this mode, you can switch from position control to torque control continuously without stopping the servo motor.

- The current positions are always tracked even in torque control, and therefore positioning after torque control is smoothly executed.
- Position control is smoothly switched to torque control without stopping the servo motor.



Application example




Servo System Recorder




The Motion module automatically collects data of all real drive axes when an error occurs. The collected data, such as the command and the feedback values, greatly helps you analyze the error cause.

- Automatic collection of data, such as the command and feedback values, without programming
- Data collection of all axes, which helps you locate the error cause even when the error is caused by the other axes without an error

[Data collection]








GX LogViewer

The collected data of the Motion module is displayed on GX LogViewer.

The operation status of the Motion module and the servo amplifiers before and after an error is displayed in waveform, which allows you to analyze more operation details and helps you locate the error cause.

[Features]

- Displays the collected data and events graphically.
- Enables users to adjust a graph easily by automatic adjustment function and drag operation.




Analyzing Data

Analyzing operation transition of the Motion modules and the servo amplifiers before and after an error helps you locate the error cause.

[Example]

- 1. An error has occurred.
- 2. The speed and torque dropped to 0 even though the Motion module outputted commands.


By analyzing the data in the recorder (1 and 2 above), users can find out a possible cause of the error, such as a disconnection of a power cable during operation.



Touch Probe Function (Mark Detection Function) Financed PLCopen®

This function latches data responding to a trigger signal input to a servo amplifier.


The compensation amount is calculated based on the latched data, and the error is compensated using a compensation axis. The Motion module in PLCopen® motion control FB mode supports the high-accuracy touch probe function.



Monitoring of Servo Data

PLCopen[®]

Servo operation is monitored with extensive servo data acquired via CC-Link IE TSN. The acquired data can be transferred to IT system or transferred and displayed on any user-created GOT screen in the network. The target data for monitoring can be flexibly changed during operation.




CC-Link IE TSN Safety Communication Function


PLCopen®

CC-Link IE TSN enables control of safety and non-safety communications realizing a flexible system whereby safety communications can be easily incorporated into the main control network.

In the following system which integrates safety and non-safety communications, the safety CPU checks the safety signals received via the safety remote I/O module and outputs the safety signals (STO, etc.) to the servo amplifiers. Outputting safety signals via the network eliminates the need for wiring of safety signals to a safety controller and a servo amplifier. The CC-Link IE TSN safety communication function is available with iQ-R series Motion modules.



One software, many possibilities



MELSOFT GX Works3 has a variety of features which help users create programs and conduct maintenance more flexibly and easily. This software includes motion control setting to support all Motion module development stages - from setting parameters to programming, debugging, and maintenance.

Development Environment Designed for Ease of Use

This all-in-one software covers all aspects of the product development cycle, resulting in boosted efficiency in programming while also improving user-operability by providing a common interface across all the phases.



System Design

- Network configuration settings
- Automatic detection of network configuration

Programming

- Easy programming in ST language
- More intuitive programming, which eliminates the need to remember devices or buffer memory addresses
- Easy access to axis information
- Operation profile data

Debug

- Various monitor functions, such as axis monitor, and ST language program monitor
- A simulator that debugs a program without an actual machine
- Real-time monitor of GX LogViewer

Maintenance

 Various monitor functions, such as axis monitor, and event history




[Network configuration settings]

 Intuitive network settings with drag-and-drop operations and a graphical screen view

Network Configuration Settings

[Automatic detection]

 By clicking the [Connected/Disconnected Module Detection] button, the connection status of slave devices is automatically detected and the CC-Link IE TSN configuration screen is generated.






Operation Profile Data with Simple Settings

Operation profile data, such as cam data and cam data for a rotary knife, is easily created.

- The cam graph can be flexibly and easily created through drag & drop. The waveform is changed according to the pointer's movement.
- Stroke, speed, acceleration, and jerk can be set while monitoring the changes on the graph.
- By setting "5th Curve (Adj)" for the cam curve types, the speed on a section border becomes smooth.
- Operation profile data for a rotary knife can be automatically generated by settings sheet length, synchronization width, cam resolution, etc.
- The created operation profile data can be checked on the list.






- Structured text programs are composed of function blocks, increasing program readability.
- Modularization of the programs increases their reusability.
- The consistent, common operability on a single engineering tool improves usability further.
- A wide selection of programming elements in the MELSOFT Library contributes to reducing programming time.
- The program is created by dragging & dropping programming elements, which simplifies the programming process.
- A startup time is reduced using the simulator of MELSOFT GX Works3 that can debug a program without an actual machine.

Programming Using Labels

- The control axes of the Motion modules and I/O signals are defined as label variables, which enables easy reuse of programs and helps to improve programming efficiency.
- The global labels created in the Motion module project can be used in PLC CPUs.



[Reading label data in Motion module]

The axis label data created in the Motion module can be read by the PLC CPU.


[Writing data to labels in Motion module] Data in the PLC CPU program can be written

Data in the PLC CPU program can be writte to the axis labels in the Motion module.

Axis Information is Easily Accessible

- Axis label variables can be used as an argument to refer axes in positioning function blocks.
- IntelliSense[®] function reduces programming mistakes.
- Access by variable names increases readability.

[Structured text editor]






The graph data of both PLC CPU modules and Motion modules can be viewed on a single tool, GX LogViewer. This tool helps you efficiently analyze data from two different modules. The following two functions are provided for logging: data logging function (offline) and real-time monitor.


Data Logging Function (Offline)

The function performs data logging by a specified time interval based on the logging setting (trigger condition, data collection) written to the motion system from the engineering tool. The results are saved as a data logging file. Up to 10 data settings can be simultaneously logged for the motion system.



Real-Time Monitor


Up to 32 collected motion system data can be displayed in real time.



·

The system simulator enables the Motion module and PLC CPU programs to be simulated interactively.

A program operation can be checked without an actual machine during debugging process, which shortens the startup time.



Event history lists information about executed operations and errors that have occurred on each module in chronological order,

also be used during simulation.


Users can customize the axis

machine, improving debug

monitor items according to their

efficiency. The axis monitor can

Debugging can be executed through both the program monitor and the watch window by using the common interface.





Software-based controller for high-precision motion control



Installed on a personal computer, SWM-G Motion Control Software can perform motion and network control.

- Supports a CC-Link IE TSN servo control system with the personal computer where RTX64 (real-time extension) is installed. (RTX64 is included with SWM-G.)
- Meets various application needs by offering various types of motion control, such as positioning, synchronous, cam, speed, and torque control using API library for motion control.
- Utilizes network control to connect and set various slave devices (remote I/O modules, etc.) and TCP/IP devices.





Motion Control Software*1



- Maximum number of control axes: 128
- Minimum operation cycle*2: 125 μs
- Programming language: Visual C ++®

USB key for Motion Control Software

MR-SWMG32-U: 32 axes MR-SWMG16-U: 16 axes MR-SWMG64-U: 64 axes MR-SWMG128-U: 128 axes

^{*1.} SWM-G Motion Control Software includes SWM-G Engine, SWM-G API, Network API, SWM-G Operating Station, CC-Link IE TSN Configurator, and Real Time OS (RTX64).
*2. The minimum operation cycle depends on the number of control axes and the CPU of the personal computer.

Covering a Wide Range of Multi-Axis Applications

 SWM-G Motion Control Software is available in 16 to 128axis control models, enabling multi-axis synchronization of various scales of machines.









 A CPU core of the industrial personal computer is assigned for running SWM-G processing, and that enables SWM-G to perform a high-speed, real-time operation without being affected by the operation on Windows[®].



Reduced Machine Design and Startup Time

- The integrated test tool SWM-G Operating Station covers the development processes of SWM-G from design to simulation, contributing to reduction in the total cost of ownership.
- The network management tool CC-Link IE TSN Configurator enables users to set the network configuration and check the communication status, leading to reduced design time.





SWM-G Operating Station

CC-Link IE TSN Configurator

Maintenance Solution by MELIPC with SWM-G Installed

When SWM-G is installed and operated on the MELIPC (industrial personal computer), the system offers a powerful maintenance solution utilizing the Edgecross-compatible software.


[Predictive/preventive maintenance]

- The user application collects data of machine diagnosis function, etc. from MR-J5-G through the communication API of SWM-G.
- The MELIPC analyzes the collected data by using the Edgecrosscompatible real-time data analyzer.

Real-time data analyzer Offline analysis Data analysis Diagnosis rule Data accumulation Data collection Feedback


[Corrective maintenance]


 SWM-G collects data from the drive recorder of MR-J5-G through TCP/IP communications, which reduces troubleshooting time.




System Configuration









^{*} Motion Control Software can function as a master station of CC-Link IE TSN.

TCP/IP device

TCP/IP device

TCP/IP device

Integrated Test Tool SWM-G Operating Station



This tool provides a variety of features - parameter settings required for application development and the test operation for JOG, inching, and positioning operations. In addition, each axis status and sampled waveforms can be displayed to help user check the start timing and the operation pattern.

CC-Link IE TSN Configurator (settings for CC-Link IE TSN)

- Communication setting with MR-J5-G (communication cycle)
- Communication status check



SWM-G Operating Station (motion settings, monitor tool)

- Axis parameter setting and axis monitor
- Test operation (for servo ON, JOG, PTP, etc.)



Settings for CC-Link IE TSN-Compatible Devices



The settings of the network and servo amplifiers can be conducted through the single network line of CC-Link IE TSN.

[CC-Link IE TSN Configurator]

CC-Link IE TSN Configurator is the network management tool of CC-Link IE TSN that enables users to set the network and check the communication status.

- Easy network configuration
- System and communication status check

[MR Configurator2*2]

MR Configurator2 enables users to easily set and adjust multiple servo amplifiers through CC-Link IE TSN which enables mixing of TCP/IP communication and other communications.


- Supports MR-J5-G
- Manages a multi-axis system as one project
- Offers an easy-to-set user interface for machine diagnosis function




^{*2.} MR Configurator2 is not included with SWM-G Motion Control Software.

Positioning Control


Linear interpolation




Circular interpolation




Continuous path control (path interpolation)




Helical interpolation



Jerk acceleration/deceleration



Triggered motion



In this method, an axis can be accelerated gradually through adjusting jerk so that the vibrations of the machine can be minimized.

In the example above, the constant positive jerk is applied at the start of the operation to achieve smooth acceleration. When the axis is shifted to the constant-speed operation, the same amount of negative jerk is applied.

Adjusting jerk in this way achieves smooth acceleration/ deceleration while also shortening the time it takes to reach the target speed.

The speed creates a S-curve shape.

The triggered motion is a type of command that delays the execution of the motion command until the specified trigger condition is satisfied.


Axes can be started automatically based on the specified conditions by using this command, reducing the cycle time of conveyor systems, etc.

In the operation example above, right after the axis 2 starts execution of normal motion commands, the axis 1 executes the triggered motion command (delaying the execution of the command until the condition is satisfied).

When the condition is satisfied (start trigger ON) during the axis 2 operation, the axis 1 starts executing the motion command.




Synchronous control (tandem drive)



Motion Control Software enables tandem operation where the same commands can be outputted to master and slave axes.

Gantry home position return



After the master and slave axes pass their respective dogs, the gantry home position return stops both of the axes at the Z-phase of the master axis.

This method enables two or more axes to execute home position return simultaneously, supporting gantry systems.

A Wide Variety of Features



Hot connect (disconnection/reconnection)

The hot connect enables a topology change during operation without requesting a communication stop.

The user application disconnects and reconnects the network through API library.

Position synchronous output (cam switch)

The output signal is turned on when a specified condition is satisfied. This function can be used as an alternative to a limit switch.

Touch probe (mark detection)

Monitoring of servo data

The controller obtains the status data of servo amplifiers, such

as machine diagnosis information and encoder temperature,

via CC-Link IE TSN. This enables visualization of machine

status.

The current value of the servo motor can be read when the touch probe signal is inputted.

Software and hardware touch probes are available. Select the touch probe according to your application.

Pitch error compensation

The set offset is applied at regularly spaced command positions. The position error of ball screws can be compensated, improving the operation accuracy.

Acceleration/deceleration methods

The controller offers 24 types of acceleration/deceleration methods, such as trapezoidal, S-curve, jerk ratio, parabolic, sine curve, time acceleration trapezoidal, etc.

Select the method according to your application.

Backlash compensation

The set offset is applied when the axis changes the travel direction.


The backlash of ball screws can be compensated, which improves operation accuracy of machines.

Programming Utilizing API Library



■ Development environment *1 (Microsoft® Visual Studio®)


Add the SWM-G API library to the project of Microsoft® Visual Studio® and create a user program.



- C++, C# compile
- Debug of C language programs
- *1. Prepare a development environment with Microsoft Visual Studio®.

■ A program that starts positioning


```
User program
void sample()
  Motion::PosCommand pos;
   /* Position command data settings */
                                            /* Axis = axis 0 */
   pos.axis = 0;
   pos.profile.type = ProfileType::Trapezoidal;
                                                    /* Acceleration = trapezoidal */
  pos.profile.velocity = 10000.0;
                                         /* Velocity = 10000.0 [U/s] */
  pos.profile.acc = 10000.0;
                                                    /* Acceleration = 10000.0 [U/s^2] */
  pos.profile.dec = 10000.0;
                                                    /* Deceleration = 10000.0 [U/s^2] */
   pos.target = 30000.0;
                                            /* Travel distance = 30000.0 [U] */
   /* Relative positioning start */
   err = ssclib_cm.motion->StartMov(&pos);
   if (err != ErrorCode::None) { /* Error processing */ }
   /* Waiting for positioning completion */
   sscLib_cm.motion->Wait(0);
}
```





■ A program that continuously starts positioning of another axis based on the specified trigger condition

```
User program
void sample()
{
  Motion::PosCommand pos;
  Motion::TriggerPosCommand tpos;
  /* Position command data settings (axis 0) */
  pos.axis = 0;
                                        /* Axis = axis 0 */
  pos.profile.type = ProfileType::Trapezoidal;
                                             /* Acceleration = trapezoidal */
  pos.profile.velocity = 10000.0;
                                       /* Velocity = 10000.0 [U/s] */
                                              /* Acceleration = 10000.0 [U/s^2] */
  pos.profile.acc = 10000.0;
                                              /* Deceleration = 10000.0 [U/s^2] */
  pos.profile.dec = 10000.0;
  pos.target = 30000.0;
                                       /* Travel distance = 30000.0 [U] */
  /* Relative positioning start (axis 0) */
  err = ssclib_cm.motion->StartMov(&pos);
  if (err != ErrorCode::None) { /* Error processing */ }
  /* Triggered motion position command data settings (axis 1) */
  tpos.axis = 1;
                                        /* Axis = axis 1 */
  tpos.profile.type = ProfileType::Trapezoidal;
                                              /* Acceleration = trapezoidal */
  tpos.profile.acc = 10000.0;
                                             /* Acceleration = 10000.0 [U/s^2] */
  tpos.profile.dec = 10000.0;
                                              /* Deceleration = 10000.0 [U/s^2] */
                                       /* Travel distance = 20000.0 [U] */
  tpos.target = 20000.0;
                                       /* Trigger axis = axis 0 */
  tpos.trigger.triggerAxis = 0;
  tpos.trigger.triggerValue = 1500.0;
                                       /* Remaining distance = 1500.0 [U] */
  /* Triggered motion relative positioning start (axis 1) */
  err = ssclib_cm.motion->StartMov(&tpos);
  if (err != ErrorCode::None) { /* Error processing */ }
  /* Waiting for positioning completion */
  sscLib_cm.motion->Wait(1);
}
```





Driving a wider range of motors with more flexible options





CC-Línk**IE TSN** MR-J5-G(4)

Supports Ethernet-based CC-Link IE TSN, featuring high-speed, large-capacity communication (1 Gbps). Command communication cycle of ≥ 31.25 µs and speed frequency response of 3.5 kHz enable advanced motion control.



CC-Línk**IE TSN** MR-J5W2-G MR-J5W3-G

Drives a maximum of two/three servo motors. This simplifies wiring, saves energy, and enables a compact machine at a lower cost.

Product Lines

Servo amplifier

●: Supported ○: Future support planned -: Not supported

Model	Power supply specifications	Command interface (Note 4)	Fully closed - loop control (Note 2)	Compatible servo motors			
	(Note 1)			Rotary	Linear (Note 3)	Direct drive	
MR-J5-G	200 V AC	CC-Link IE TSN - EtherCAT® (Note 5)	•	•	•	•	
WIN-00-G	400 V AC		•	•	0	-	
MR-J5W2-G	200 V AC		•	•	•	•	
MR-J5W3-G			-	•	•	•	
MR-J5D1-G4			•	•	-	-	
MR-J5D2-G4	400 V AC		•	•	-	-	
MR-J5D3-G4			-	•	-	-	
MR-,15-A	200 V AC	Dules train/Anales valtage	•	•	•	•	
	400 V AC	Pulse train/Analog voltage	•	•	0	-	

- 200 V AC servo amplifiers are also compatible with DC power supply input as standard.

 The indicated servo amplifiers are compatible with a two-wire type serial encoder. For four-wire type serial encoders and pulse train interface (A/B/Z-phase differential output type) encoders, use MR-J5-G-RJ/MR-J5D1-G4/MR-J5-A-RJ servo amplifiers.
 - 3. The indicated servo amplifiers are compatible only with two-wire type and four-wire type serial linear encoders. For a pulse train interface (A/B/Z-phase differential output type) linear encoder, use MR-J5-G-RJ/MR-J5-A-RJ servo amplifiers.

 4. MR-J5-G/RJ/MR-J5D-G4 are also compatible with CC-Link IE Field Network Basic.

 5. EtherCAT® is supported by MR-J5-G-N1/MR-J5W2-G-N1/MR-J5D1-G4-N1/MR-J5D2-G4-N1/MR-J5D3-G4-N1.





CC-LinkIE TSN MR-J5D-G4

The drive unit is a converter separate type servo amplifier (1/2/3-axis type available). Combined with an MR-CV_4 power regeneration converter unit, the drive unit can create an energy-saving servo system.




General purpose interface-compatible

MR-J5-A(4)

Enables position control by pulse train command and speed/torque control by analog voltage command.


The maximum command pulse frequency is 4 Mpulses/s.



63


Tuning Functions

Use the tuning methods that are optimal for your machines.




Quick Tuning

This function automatically performs easy-to-use auto tuning that controls vibration and overshoot just by turning on the servo-on command. Before normal operation, the servo amplifier sets control gain and machine resonance suppression filters in 0.3 seconds by inputting torque to the servo motor automatically. After completing the setting, the servo amplifier starts operation normally.




One-Touch Tuning

This function automatically completes servo gain adjustment according to the mechanical characteristics and reduces the settling time just by turning on the one-touch tuning. The servo gain adjustment includes the machine resonance suppression filter, advanced vibration suppression control II, and the robust filter. Controlling overshoot and vibration is improved, maximizing your machine performance.



Advanced Vibration Suppression Control II

This function suppresses two types of low frequency vibrations, owing to vibration suppression algorithm which supports three-inertia system. This function is effective in suppressing residual vibration with relatively low frequency of approximately 100 Hz or less generated at the end of an arm and in a machine, enabling a shorter settling time. Adjustment is easily performed on MR Configurator2.



Command Notch Filter

The frequency can be set close to the machine vibration frequency because the command notch filter has an applicable frequency range between approximately 1 Hz and 2000 Hz.

Machine Resonance Suppression Filter


The expanded applicable frequency range is between 10 Hz and 8000 Hz. Five filters are simultaneously applicable, improving vibration suppression performance of a machine. The machine resonance frequency is detected by the machine analyzer function in MR Configurator2.

Reduced Energy and Maximized Space with Simplified Wiring (200 V Class)

Simple Converter MR-CM

Utilizing a common bus connection conserves energy through the efficient use of regenerative power. Wiring can be simplified and installation space can be saved by reducing the number of molded-case circuit breakers and magnetic contactors. The MR-CM simple converter can connect to up to six compatible servo amplifiers having a total capacity of 3 kW or lower.

Wiring for the bus and the control circuit power supply can be simplified by using daisy chain power connectors for passing wiring.



Application Examples

[Vertical form, fill & seal]

The simple converter uses regenerative energy of the packing film unwinding axis for other axes such as conveying rollers.




[Wafer prober]

The simple converter saves installation space for semiconductor manufacturing equipment in a clean room.



Multi-Axis Servo Amplifiers J5W2-G J5W3-G

The 2-axis and 3-axis servo amplifiers are available for operating two and three servo motors, respectively. These servo amplifiers enable an energy-saving and compact machine at lower cost. Different types of servo motors including rotary servo motors, linear servo motors, and direct drive motors are freely combined as long as the servo motors are compatible with the servo amplifier.




400 V Class Drive Unit (Converter Separate Type) MR-J5D-G4



- MR-J5D-G4 drive units (converter separate type) are newly added to the product lines of the 400 V class servo amplifiers and are available in 1-axis/2-axis/3-axis types.
- Combined with an MR-CV_4 power regeneration converter unit, MR-J5D-G4 can create an energy-saving, space-saving, and less-wiring servo system.
- MR-J5D-G4 supports safety communication of CC-Link IE TSN, enabling functional safety without a dedicated unit. For multipleaxis servo systems, functional safety can be used just by using a network cable.

Features of MR-J5D-G4 Drive Units

- The common DC bus connection saves energy and space, and reduces wiring.
- MR-J5D2-G4 (2-axis drive unit)/MR-J5D3-G4 (3-axis drive unit) save space and reduce wiring further.
- MR-J5D1-G4/MR-J5D2-G4/MR-J5D3-G4 support safety sub-functions as standard. For multi-axis drive units, the safety sub-functions such as STO can be set for each axis even through the safety communication of CC-Link IE TSN.
- The drive units are equipped with a replaceable cooling fan unit, which can be easily replaced by users.





Space-Saving with 3-Axis Drive Units (Smaller Width)

The 400 V class 3-axis drive units enable space-saving.

For example, when 3-axis drive units in 1 kW are used instead of 1-axis servo amplifiers in 1 kW for driving six axes, the installation width can be reduced by 200 mm.

The number of molded-case circuit breakers and magnetic contactors can also be reduced.





MR-J5-100G4 × 6 units

Energy-Saving with 400 V Class Systems


Further Energy-Saving with Common DC Bus Connection and Power Regeneration System J5D-G4

. . _____


When multiple MR-J5D-G4 drive units are connected to an MR-CV_4 power regeneration converter unit by a common DC bus connection, the regenerative power of one axis can be used for driving other axes, contributing to energy-saving.

The MR-CV_4 power regeneration converter unit has a power regeneration system which returns the regenerative power back to the power supply, enabling the regenerative energy to be used for other systems for further energy-saving. In addition, when the converter unit is used, a regenerative option is not required, resulting in reduction of heat generation.

[Common DC bus connection]



[Power regeneration system]




400 V Servo Amplifiers Providing New Combinations with Servo Motors

The MR-J5 series 400 V class servo amplifiers can drive 50 W to 7 kW servo motors. The HK-KT series, HK-ST series, and HK-RT series are available, which will optimize your machines.



Small capacity, low inertia HK-KT series



Medium capacity, medium inertia HK-ST series



Medium capacity, ultra-low inertia HK-RT series

Motor flange size [unit: mm]

Application Examples


[Printing systems]

Optimal for rotary presses using sectional drive system where each printing unit is driven individually.



[Slitting machines]

Optimal for converting machines consisting of unwinding axes, roller axes, and winding axes.



Predictive Maintenance




The servo amplifiers detect signs of machine failure by monitoring the operation status. Maisart is an abbreviation for "Mitsubishi Electric's AI creates the State-of-the-ART in technology." Mitsubishi Electric is leveraging original AI technology to make devices smarter.


Machine Diagnosis (Ball Screws/Linear Guides)

This function supports predictive maintenance by estimating frictions and vibrations of mechanical drive components such as ball screws and linear guides.

- Friction failure prediction with the friction estimation function
- Vibration failure prediction with the vibration estimation function








Machine Diagnosis (Belts)

This function detects aging deterioration of belts in advance by the static friction failure prediction and the tension deterioration prediction with the belt tension estimation.

- Static friction failure prediction
- Belt tension deterioration prediction





Machine Diagnosis (Gears) *1

With this function, the servo amplifier generates commands automatically, and executes to-and-fro positioning operation to estimate the amount of gear backlash. Gear failure is predicted based on the set nominal values for backlash.

- Backlash estimation function
- Gear failure prediction




*1. The machine diagnosis (gears) does not work during normal operation.

Preventive Maintenance

Machine Diagnosis (Mechanical Drive Components)

This function estimates when a machine failure will occur based on the total travel distance of the servo motor, and notifies when it is time for replacement if the rated life of the mechanical drive components is set.

Machine total travel distance failure prediction



Servo Amplifier Life Diagnosis

This function displays the cumulative energization time and the number of inrush relay on/off times. The data can be used to check life of the parts as a rough guide.


- Cumulative energization time (Smoothing condenser/cooling fan life span)
- The number of inrush relay on/off times (Inrush relay life)



Corrective Maintenance

Drive Recorder

This function continuously monitors the servo status and records the status transition such as a trigger condition before and after an alarm for a fixed period of time. Reading the servo data on MR Configurator2 helps you analyze the cause of the alarm. In addition to the monitor values and the waveform of the past 16-time alarms in the alarm history, the system configuration and the servo parameters are displayed. Alarm occurrence time is also displayed when the servo amplifier and the controller are normally in communication on CC-Link IE TSN. The data can be outputted to a GX LogViewer format file.




Connection/Communication Diagnosis

Disconnection Detection

The servo amplifiers are equipped with both input open-phase detection and output open-phase detection. Input open-phase detection detects an open phase of the main circuit power supply of the servo amplifier, and output open-phase detection detects an open phase of the servo motor power supply. The alarm can be distinguished from other alarms such as the overload alarm, reducing the time required to restore the system.


MR-J5D-G4 drive units support only output openphase detection.



Servo Motor Incorrect Wiring Detection J5W2-G J5W3-G

Multi-axis servo amplifiers MR-J5W2-G/ MRJ5W3-G detect servo motors with a different capacity that are incorrectly connected to the A-axis/B-axis/C-axis, contributing to servo motor protection. The servo amplifiers obtain servo motor capacity information of the connected servo motors from the encoders and check whether the servo motors which are connected to the power connectors match the capacity information. If the information is not matched, an alarm occurs. *1

*1. The incorrect wiring detection does not work for servo motors with the same capacity.



Encoder Communication Diagnosis

The encoder communication diagnosis checks the encoder communication circuit in the servo amplifier. This function is useful for classifying the cause of errors (such as disconnected encoder cables) when the encoder communication alarm occurs.




Path Control

Super Trace Control


This function reduces a position deviation to nearly zero not only during constant-velocity operation, but also during constant acceleration/deceleration.

The path accuracy will be improved in highrigidity machines.



Lost Motion Compensation


This function suppresses quadrant protrusion caused by friction and torsion generated when the servo motor rotates in a reverse direction. Therefore, the accuracy of circular path will be improved in path control used in XY table, etc.



Suppression of quadrant protrusion of circular path

Path Tracking Model Adaptive Control

This function reduces path errors which occur when the servo motor reciprocates. Normally, when positioning control is executed, the model adaptive control adjusts the control to shorten a settling time. Instead, this function reduces overshooting to improve path accuracy, which is suitable for machines that require high-accuracy path control such as processing machines.




Safety Sub-Functions

Built-In Safety Functions and a Wide Range of Safety Sub-Functions J5-G-RJ J5D-G4

MR-J5-G-RJ/MR-J5D-G4 have a built-in safety control part, supporting safety sub-functions without a dedicated unit. When the servo amplifier is combined with HK-_WS servo motors with functional safety, the safety level is enhanced.

The servo amplifiers support the safety sub-functions of STO/SS1/SS2/ SOS/SBC/SLS/SSM/SDI/SLI/SLT at a safety level of SIL 2 or SIL 3.



Servo motors with functional safety support the safety sub-functions at a higher safety level. The functional safety encoders provide the servo motor positions and speeds necessary for the safety sub-functions at a safety level of Category 4 PL e, SIL 3.

Encoder cables for the servo motors with functional safety are the same as for the standard servo motors.


Servo motor with functional safety HK-_WS



Safety Communication via CC-Link IETSN J5-G-RJ J5D-G4

CC-Link IE TSN enables control of safety and non-safety communications realizing a flexible system whereby safety communications can be easily incorporated into the main control network.

When combined with R_SFCPU-SET safety CPU and RD78G Motion module, MR-J5-G-RJ/MR-J5D-G4 can receive safety signal data of the safety CPU through CC-Link IE TSN. Wiring the safety signals to the servo amplifiers is not necessary.



STO Function Compliant with IEC/EN 61800-5-2


STO (Safe torque off) is integrated as standard, enabling easy configuration of a safety system which shuts off power to a servo motor in the machine.

- By using STO, it is not necessary to turn off the control power of the servo amplifier, resulting in a shorter restart time and eliminating the necessity of homing.
- A magnetic contactor for preventing unexpected motor start is not needed.*1

Servo amplifier model	Safety level		
MR-J5-G/MR-J5-A/MR-J5-A-RJ	Category 3 PL e, SIL 3		
MR-J5-G-RJ/MR-J5W2-G/	Cotogon, 4 DL o CII 2 *2		
MR-J5W3-G/MR-J5D-G4	Category 4 PL e, SIL 3 *2		

- *1. Magnetic contactors are not required to meet the STO requirements. However, this illustration recommends the use of a magnetic contactor which shuts off the main circuit power supply of the servo amplifier at an alarm occurrence
- *2. The safety level requires STO wiring to a servo amplifier using safety equipment including a safety programmable controller that is compatible with Category 4. When a switch is connected directly to a servo amplifier as shown in the illustration, the safety level is Category 3. For details of safety sub-functions, refer to "MR-J5 User's Manual".

[Shut-off by STO]



Safety Sub-Functions Compliant with IEC/EN 61800-5-2


MR-J5-G-RJ/MR-J5D-G4 support safety sub-functions, STO/SS1/SS2/SOS/SBC/SLS/SSM/SDI/SLI/SLT.

Refer to "Safety Sub-Functions" in section 1 of this catalog for the safety sub-functions and the safety levels, which vary depending on the combinations of the servo amplifiers and the rotary servo motors (including servo motors with functional safety)/linear servo motors/direct drive motors.

Safe torque off (STO)


Responding to the input signal from external equipment, the STO function shuts off power to the servo motor electronically using the internal circuit (shuts off through secondary-side output).

This function corresponds to the Stop category 0 of IEC/EN 60204-1.




Safely-limited speed (SLS)

This function monitors the speed of the servo motor not to exceed the specified speed limit. If the speed exceeds the limit, the motor power is shut off by the STO.




Safe stop 1 (SS1)

Responding to the input signal from external equipment, the servo motor starts to decelerate. After the set delay time for motor stop is passed, the STO function starts. Monitoring the servo motor deceleration based on the motor deceleration rate is also supported. This function corresponds to the Stop category 1 of IEC/EN 60204-1.




Safe speed monitor (SSM)

The SSM signals are outputted when the speed of the servo motor is below the specified speed limit.



Safe stop 2 (SS2)

Responding to the input signal from external equipment, the servo motor starts to decelerate. After the set delay time for motor stop is passed, the SOS function starts. Monitoring the servo motor deceleration based on the motor deceleration rate is also supported. This function corresponds to the Stop category 2 of IEC/EN 60204-1.




Safe direction (SDI)

This function monitors whether the servo motor moves in the command direction. If the servo motor moves in a different direction from the


command direction, the STO

function is executed.




Safe operating stop (SOS)

This function monitors the position of the servo motor not to deviate from the specified range. Power is still supplied to the servo motor during the SOS function.




Safely-limited increment (SLI)

This function monitors the travel distance of the servo motor not to deviate from the specified range. If the travel distance exceeds the range, the STO function is executed.




Safe brake control (SBC)

The SBC signals are outputted for external brake control.



Safely-limited torque (SLT)

This function monitors the torque (or the thrust) of the servo motor not to deviate from the specified range. If the torque (or the thrust) exceeds the range, the STO function is executed.



Supporting Flexible Driving System


Supporting Fully Closed Loop Control as Standard J5-G

J5W2-G

J5D1-G4

Supporting a fully closed loop control system*1 as standard, MR-J5-G/MR-J5W2-G/ MR-J5D1-G4/MR-J5D2-G4/MR-J5-A servo amplifiers enable further precise positioning.

*1. MR-J5-G/MR-J5W2-G/MR-J5-A servo amplifiers are compatible only with two-wire type serial encoders. For four-wire type serial and pulse train interface (A/B/Z-phase differential output type) encoders, use MR-J5-G-RJ/MR-J5D1-G4/MR-J5-A-RJ.



Scale Measurement Function

J5-G

J5W2-G


J5D1-G4

J5D2-G4

The scale measurement function of MR-J5-G/ MR-J5W2-G/MR-J5D1-G4/MR-J5D2-G4 servo amplifiers*1 enables to transmit position information of a scale measurement encoder to the controller when the scale measurement encoder is connected in semi closed loop control.

The data of linear or scale measurement encoders are transmitted to the servo system controller via the servo amplifier, resulting in less wiring.

*1. Use the servo amplifiers (MR-J5-G/MR-J5-G-RJ/ MR-J5W2-G/MR-J5D1-G4/MR-J5D2-G4) compatible with the scale measurement encoder.



Touch Probe Function

J5-G


J5W2-G

J5W3-G



The servo amplifiers can latch a position feedback value when the probe detects a target. The latched position feedback value read by the controller can be used for measurements and alignment. The touch probe supports the latch accuracy of 1 µs. The standard MR-J5-G*1 newly supports the touch probe function.

*1. Use MR-J5-G manufactured in June 2021 or later. Note that, depending on the stock status, the servo amplifiers with both the former and the new specifications may be distributed in the market around the same time. Contact the local sales office when the touch probe function is needed.



Servo Amplifiers

Supporting Flexible Driving System

Positioning by Using a CC-Link IE TSN-Compatible RJ71GN11-T2




A CANopen-compatible master/local unit RJ71GN11-T2 can control the servo amplifiers. *1 The servo amplifiers support the profile mode (position/velocity *2/torque *2) and the positioning mode (point table). *3 For example, in the profile mode, just by setting parameters such as a target position and a target speed and sending a start signal from the master station, the servo amplifier generates commands to the target position, starting positioning operation.

A positioning system is easily configured without a Positioning module.


- *1. RD78G/FX5-SSC-G Motion modules also support CANopen.
- *2. The profile modes (velocity/torque) are not supported by MR-J5W2-G/MR-J5W3-G/MR-J5D2-G4/MR-J5D3-G4.
- *3. For the modes supported by the master station, refer to the master station specifications.

[Profile position mode continuous operation]



[Profile position mode continuous operation (point table)]

Point table No.	Position data	Servo motor speed	Acceleration time constant	Deceleration time constant	Dwell	Auxiliary function	M code
1	1000	2000	200	200	0	1	1
2	2000	1600	100	100	0	0	2
:	:	:	:	:	:	:	:
255	3000	3000	100	100	0	2	99



Compliance with SEMI-F47

MELSERVO-J5 series servo amplifiers comply with SEMI-F47 standard*1 for semiconductors and FPD manufacturing systems. (SEMI-F47 is not applicable to 1-phase 200 V AC input, DC input, and MR-J5D-G4.)

^{*1.} The control circuit power supply of the servo amplifiers complies with SEMI-F47. Note that the backup capacitor may be required depending on the power impedance and operating situation for the instantaneous power failure of the main circuit power supply. Be sure to perform a test on your machine to meet the SEMI-F47 Voltage Sag Immunity Standard. Please use the 3-phase power supply for the servo amplifier input.


Command Interface

CC-Link IE TSN J5-G J5W2-G J5W3-G

The servo amplifiers drive the servo motors by receiving commands (position/velocity/torque) at regular intervals in synchronous communication with the CC-Link IE TSN-compatible controller. When combined with a Motion module or Motion Control Software, the servo amplifiers enable exact synchronous operation of axes and machines through high-speed, high-precision time synchronization.

The servo amplifiers support CiA 402 drive profile and enable the profile mode (position/velocity*2/ torque*2) and the positioning mode (point table). When combined with the controllers supporting the profile mode, the servo amplifiers generate a positioning command to a target position, reducing loads of the controllers.

- *1. The communication cycle of \geq 31.25 μs is applicable when MR-J5-G/MR-J5D1-G4 are combined with RD78GH.
- *2. The profile modes (velocity/torque) are not supported by MR-J5W2-G/MR-J5W3-G/MR-J5D2-G4/MR-J5D3-G4



CC-Link IE Field Network Basic J5-G

J5D1-G4


Enhanced functions

CC-Link IE Field Network Basic-compatible master stations such as an FX5U CPU module can control MR-J5-G/MR-J5D1-G4 servo amplifiers. The servo amplifier can be operated as a CANopen device via a link device.

The profile mode (position/velocity/torque) and the positioning mode (point table) are supported. MR-J5-G servo amplifiers can be connected to existing systems using MR-J4-GF.


In addition, MR-J5-G newly supports the line topology.*1

*1. When a device which does not support the line topology is used, the line/star



General-Purpose Interface J5-A

Pulse trains and analog input are used as the command interface. The control mode can be switched between position/speed/torque control modes. When an open collector is used, both sink and source inputs are enabled.



EtherCAT® J5-G-N1 J5W2-G-N1 J5W3-G-N1 J5D-G4-N1

EtherCAT®-compatible servo amplifiers are available, enabling higher-performance MR-J5 servo amplifiers with enhanced functions on the EtherCAT® system.

MR-J5-G-RJN1/MR-J5W2-G-N1/MR-J5W3-G-N1/MR-J5D-G4-N1 support the touch probe. (Latch accuracy: 1 µs)

	* * *			
Communication specification	CANopen over EtherCAT® (CoE)			
Drive profile	CiA 402			
Communication cycle *1	125 µs, 250 µs, 500 µs, 1 ms, 2 ms, 4 ms, 8 ms			
	Cyclic synchronous position mode (csp)			
	Cyclic synchronous velocity mode (csv)			
	Cyclic synchronous torque mode (cst)			
Control mode	Profile position mode (pp)			
	Profile velocity mode (pv)*2			
	Profile torque mode (tq)*2			
	Homing mode (hm)			

*1. The minimum communication cycle varies by the model type

^{*2.} The control modes (pv/tq) are not supported by MR-J5W2-G-N1/MR-J5W3-G-N1/MR-J5D2-G4-N1/MR-J5D3-G4-N1



Servo Setup Software MR Configurator2

Tuning, monitor display, diagnosis, reading/writing parameters, and test operations are easily performed on a personal computer. This powerful software tool supports a stable machine system and optimum control, and moreover, shortens setup time.


Parameter setting and docking help

Set parameters using the function display in the list without worries about the parameter No. and digits. Information related to the parameter being set is displayed in the docking help window. The latest e-Manual is also displayed in the docking help.



Supporting multi-axis project

Set parameters and monitor operation for multiple servo amplifiers through connecting to one of the servo amplifiers. Connecting via the Ethernet switching hub and the controller is also possible.




Tuning function

Adjust control gains finely on the [Tuning] window manually for further performance after the quick tuning and the one-touch tuning.




Graph function

Obtain graphs of 7 channels for analog and 8 channels for digital. Various servo statuses are displayed in the waveform at one measurement, supporting setting and adjustment. Convenient functions such as [Overwrite] for overwriting multiple data and [Select history] for displaying graph history are available. Two types of signals can be used as a trigger signal with an OR/AND condition.



Machine analyzer function

Input random torque to the servo motor automatically and analyze frequency characteristics (0.1 Hz to 8 kHz) of a machine system just by clicking the [Start] button. This function supports setting of machine resonance suppression filter, etc.



Software reset


Reset the software for the servo amplifier with this new function. Setting switches and parameters is enabled without turning off the main circuit power supply of the servo amplifier.



Drive System Sizing Software "Motorizer"


Select the most suitable servo motors, servo amplifiers, and regenerative options for your machine just by setting machine specifications and operation patterns. You can select a suitable combination from various results.

This software also supports multi-axis systems, enabling you to set operation patterns and select options for multiple axes.



Flexible support for load mechanisms

- Select a load mechanism from 13 common types.
- Add transmission mechanisms such as a coupling.
- Set an inclination angle of the load mechanisms as desired.




Selection of several patterns

- Displays a list of load to motor inertia ratio, peak torque, etc., of each selection.
- Compatible with the expanded combinations of the servo amplifiers and the servo motors.
- Set threshold values for judgment.
- Displays energy-saving effect by multi-axis system



Compatible with multi-axis systems

- Supports the multi-axis servo amplifiers and the converters.
- Set operation patterns for multiple axes.
- Select regenerative options for a multi-axis system.



Tutorial video


 Illustrates how to use the software and select drive systems in the video.



Selecting Options (Model Selection Software)

Select necessary options such as encoder cables.

Easily create system configuration diagrams and lists of necessary purchases to prevent mistakes when ordering.



Selection of controllers/servo motors/servo amplifiers

Select results from the drive system sizing software.



Configuration

Check a configuration of each axis.



Selection of options

Prevent selection mistakes.



Purchase list

Export to CSV file.

	Purchase	list	Total(€) 0	Mineste	Configurat	ico di	igiam Lit	lock - Delet	0
No.	Item	Mod	del name	Artic	e number	Qty	Price(€)	Total(€)	Des
1	Controller	RD7	8G4			1	0	0	Up
2	Amplifier	MR-	J5-10G			3	0	0	200
3	Motor	HK-	KT053W			3	0	0	
4	Motor cable	MR-	AEP2CBL2M-A	11-H		3	0	0	Cab

e-Manual

Instruction manuals for the MELSERVO-J5 series are available in e-Manual format. These manuals are linked with manuals for other products such as servo motors and controllers, the e-Manual let you obtain necessary information quickly and also allow you to keep an enormous number of manuals as one database.

Currently supported languages: English, Japanese, Chinese

Features

- Use all necessary manuals as one database
- Download and use manuals in your local environment
- Use the e-Manual application on tablets
- Download and update manuals quickly and easily
- Search for desired information across multiple manuals



A broader selection of capacities to match various applications for smart equipment





Small capacity, low inertia

HK-KT Series



Servo motors with a 26-bit batteryless absolute position encoder

Rated speed: 3000 r/min *1 Maximum speed: 6700 r/min *1 Our product line includes 400 V and flat type models.

The servo motors have an all-in-one connector, making the connection simple.

*1. The speed varies by the model type.



Small capacity, ultra-low inertia

HK-MT Series

Servo motors with a 26-bit batteryless absolute position encoder

Rated speed: 3000 r/min Maximum speed: 10000 r/min (available with the high-speed type models*1)

The servo motors have an all-in-one connector, making the connection simple.

*1. The high-speed type models are equipped with an incremental encoder.



Medium capacity, medium inertia

HK-ST Series



Servo motors with a 26-bit batteryless absolute position encoder Rated speed: 2000 r/min, 3000 r/min Two types of rated speed are available.


The cables for the encoder, the electromagnetic brakes, and the power are equipped with one-touch lock.



Medium capacity, ultra-low inertia

NEW

HK-RT Series




an all-in-one connector, making the connection simple.

*1. The speed varies by the model type.



Product Lines

The HK series boasts a product line that offers servo motors of four different capacities and inertia: HK-KT series (small capacity, low inertia), HK-MT series (small capacity, ultra-low inertia), HK-ST series (medium capacity, medium inertia), and HK-RT series (medium capacity, ultra-low inertia). The servo motors are equipped with a batteryless absolute position encoder as standard.



Notes: The motor types are classified by the power class (200 V or 400 V) of the servo motors. The servo motors can be driven regardless of the servo amplifier power supply. For details of the rotary servo motors, refer to "4 Rotary Servo Motors".

Batteryless Absolute Position Encoder as Standard

Eliminate the Need for Purchase/Replacement/Stock Control


Servo motors come equipped with a batteryless absolute position encoder as standard, making it possible to configure absolute position systems without the use of batteries or any other options.

Moreover, maintenance costs are reduced as a result of eliminating the battery replacement and stock control.

No need for replacement, purchase, or stock control Compatible as standard No batteries required. The absolute position data remains stored even when the servo motors are removed.

Reduce Wiring for Multi-Axis Systems


In a conventional multi-axis system, battery cables are necessary between the servo amplifiers. Now that the batteries are not required with the use of the batteryless absolute position encoders, wiring battery cables for multi-axis systems is not required.



Save Time in Transporting

Position data remains stored even when the rotary servo motors are disconnected from the servo amplifiers. Thus, control cabinets can be separated from the machines without losing the position data, making it easy to transport machines for use at a new location.

The encoder does not require lithium metal batteries, allowing machines to be transported by air or sea without special handling.



Single Connector/One-Touch Lock/Single Cable Type

Single Connector/Single Cable Type/One-Touch Lock HK-KT HK-MT HK-RT

The single connector for the HK-KT/HK-MT/HK-RT *1 series combines the motor power supply, encoder, and electromagnetic brake into a single cable. The one-touch lock eliminates the need for tightening screws, making wiring easy. The servo motors are also compatible with the dual cable type. The cables can be mounted either horizontally or vertically according to your selection. Refer to "Options/Peripheral Equipment" for details of servo motor cables.

*1. The single connector is available for 1 to 2 kW of HK-RT series.

Horizontally mounted single cable type with one-touch lock





In the direction of the load side

In the opposite direction of the load side

Vertically mounted single cable type with one-touch lock




Horizontally mounted dual cable type with one-touch lock






, ,,



Vertically mounted dual cable type with one-touch lock



Connection example of one-touch lock with single cable type



One-Touch Lock HK-ST HK-RT

HK-ST/HK-RT *1 series servo motors boast a greatly simplified installation process through use of the one-touch lock system. The one-touch lock can be used to mount connectors for the motor power supply, encoder, and electromagnetic brake, which eliminates the need for tightening screws. The servo motors are compatible with both straight and angle type connectors and also supports traditional screw-tightened connectors.

One-touch lock



^{*1.} The one-touch lock is available for 3.5 to 7 kW of HK-RT series.

Expanding Combinations of Servo Amplifiers and Servo Motors




The combinations of servo amplifiers and servo motors have been expanded to offer more flexible options for driving servo motors, such as combining a large-capacity servo amplifier for increased torque, or combining a servo motor in a different power class.

Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" for details of the combinations.

Increases Maximum Torque by Combining with Larger-Capacity Servo Amplifiers

It is possible to increase the maximum torque and achieve a shorter cycle time by combining the servo motor with a larger-capacity servo amplifier.




*1. When the maximum torque of HK-KT 13W servo motor is increased with the 200 W servo amplifier.

Drives Smaller Capacity Servo Motors


Servo amplifiers are able to drive servo motors with a smaller capacity than the servo amplifier being used, reducing the kinds of spare parts that are needed.


For example, 400 W servo amplifiers are compatible with the following servo motors: 50 W, 100 W, 150 W, 200 W, and 400 W models.



Drives 200 V/400 V Class Servo Motors


The 200 V servo amplifiers can drive both 200 V and 400 V servo motors, and the 400 V servo motors may produce torque that is sufficient for operation when combined with smaller-capacity 200 V servo amplifiers. Lowering of the capacity of the servo amplifier contributes to lower costs and reduced installation space.





Compact Servo Motors with a Batteryless Absolute Position Encoder

HK-KT series servo motors come equipped with a batteryless absolute position encoder and are more compact than the previous generation HG-KR series. Flat types are also available in the HK-KT product line, contributing to a compact machine design.




Improved Environmental Resistance


Servo motors feature enhanced environmental resistance

Ingress protection (IP) rating of the servo motors: IP67 *1
Designed for an ambient temperature of up to 60 °C.*2

- *1. If the IP rating of the servo motor differs from those of option cables and connectors, overall IP rating depends on the lowest of all.
- *2. Derate the speed/torque when using the servo motors at high ambient temperatures.



Application Examples



High-Response Operation by Ultra-Low Inertia Servo Motors



HK-MT series (small capacity, ultra-low inertia) and HK-RT series (medium capacity, ultra-low inertia) are newly added to the product lines.

The ultra-low inertia servo motors enable a high-response operation that reduces the cycle time of an ultra-high-throughput material handling system.

Compact, High-Power Rate Servo Motors for High-Speed Operation Medium-capacity HK-RT series 1 to 7 kW

- (١.	Increased	torque
١.	١.	IIICIEaseu	lulque

Servo motor mod	del	HG-RR103	HK-RT103W		
Rated output of a combined serv	o amplifier [kW]	2.0	1.0 (2.0)	-	Smaller capacity servo amplifier
Flange size	[mm]	100	90	•	Reduced flange size (by 10 %)
Rated torque	[N·m]	3	.2		
Maximum torque	[N·m]	8.0	8.0 (9.5)	-	Increased torque (to 118 %)
Maximum speed	[r/min]	4500	6700	-	Increased speed (to 148 %)
Moment of inertia J	[× 10 ⁻⁴ kg·m ²]	1.50	0.721	•	Lower inertia (by 52 %)
Power rate at rated torque	[kW/s]	67.4	141	-	Increased responsivity (to 209 %)
Motor length	[mm]	145.5	118.9	-	Reduced motor length (by 26.6 mm)

Comparison of HK-KT (low inertia) and HK-RT in 2 kW


-	١.	Increased	torauco


Servo motor mo	del	HK-KT203W	HK-RT203W	
Flange size	[mm]	Ş	90	
Rated torque	[N·m]	6	.4	
Maximum torque	[N·m]	19.1 (25.5)	15.9 (19.1)	
Maximum speed	[r/min]	6000	6700	Increased speed (to 111 %)
Moment of inertia J	[× 10 ⁻⁴ kg·m ²]	5.65	1.28	Lower inertia (by 77 %)
Power rate at rated torque	[kW/s]	71.7	317	Increased responsivity (to 442 %)
Motor length	[mm]	136.9	172.9	·

Maximum Speed of 10000 r/min

Small-capacity HK-MT series 0.05 to 1 kW

The high-power rate servo motors are optimal for packaging machines and material handling systems. Servo motors with maximum speed of 10000 r/min *1 are added to the product lines, contributing to a shorter cycle time.





HK-ST Servo Motors with Rated Speed of 3000 r/min



HK-ST series (medium capacity, medium inertia) releases servo motors with rated speed of 3000 r/min.

Conventional HG-JR servo motors can be replaced with HK-ST series and HK-KT series (small capacity, low inertia) to which new models such as HK-KT63UW are added.


(Motor flange size [mm]: 90 X 90 and 130 X 130)

Servo motors for high-speed, high-accuracy, linear drive systems



Product Lines

Five series are available depending on applications.



Linear Servo Motors

Basic Performance

- Maximum speed: 3 m/s (LM-H3 series), 6.5 m/s (LM-AJ series)
- Maximum thrust range: 150 N to 7200 N. Small size and high thrust are achieved by the increased winding density and the optimized core and magnet geometries as a result of electromagnetic field analysis.
- Five series are available: core (two series), liquid-cooling core, magnetic attraction counter-force core, and coreless types.
- The linear servo motors are compatible with a variety of serial interface linear encoders. The linear encoder resolution ranges from 1 nm and up.
- High-performance systems such as high-accuracy tandem synchronous control are achieved with CC-Link IE TSN.
- The linear servo motors feature environmental resistance, designed for an altitude of 2000 m and an ambient temperature of up to 60 °C. *1,2
- *1. Derate the speed/thrust when using the linear servo motors at an altitude exceeding 1000 m and at high ambient temperatures.
- *2. LM-AJ series is designed for an altitude of 1000 m and an ambient temperature of up to 40 °C.

Higher Machine Performance

For higher machine performance

• Improved productivity due to high-speed driving part.


For easier use

- The linear servo motors enable a simple and compact machine with high rigidity.
- Smooth operation and clean systems are achieved.

For flexible machine configurations

- Multi-head and tandem systems are easily configured.
- The linear servo motors are suitable for long-stroke applications.

[Offers more advantage than conventional ball screw driving systems]




Application Examples

Optimum for a linear drive system which requires a high speed and high accuracy. Easily achieve a tandem configuration or multi-head configuration.



Tandem configuration


The linear servo motors configured in tandem are suitable for large systems that require highly accurate synchronous operation between two axes.




Multi-head configuration

Multi-head systems enable control of two motor coils independently, thereby simplifying machine mechanisms. This system is suitable for machines that require a short cycle time.







Semiconductor/FPD manufacturing systems
Electrical parts assembling/manufacturing systems




Screen printing systems and large FPD coaters



Material handling systems




Multi-head material handling between machines



Compact and robust direct drive motors for high-accuracy applications







TM-RG2M Series

Low-profile table type

TM-RU2M Series

Low-profile for space and weight saving






High torque for high-weight capacity

Product Lines

18 models with 4 different diameters are available.



88

Notes: Use the direct drive motors manufactured in June 2019 or later.

Direct Drive Motors

Basic Performance

High performance with the latest technologies

Our latest magnetic design and winding technologies enable high torque density. In addition, extremely smooth rotation is achieved by the minimized torque ripple.

High-resolution absolute position encoder

The direct drive motors are equipped with a high-resolution absolute position encoder (1,000,000 to 4,000,000 pulses/rev) as standard. High-accuracy machines are achieved.

Enhanced environmental resistance

The direct drive motors feature environmental resistance, designed for an altitude of 2000 m and an ambient temperature of 60 °C. *1

*1. Derate the speed/torque when using the direct drive motors at an altitude exceeding 1000 m o at high ambient temperatures.

Compact and low-profile design

Due to high level of structural design technology, compact and low-profile design is achieved. This design enables a small mounting space and a low center of gravity.

Hollow shaft diameter range: ø20 mm to 104 mm

The motors are equipped with a large hollow shaft resulting from using bearing and encoder with large diameter. It allows cables and air tubing to pass through.

Higher Machine Performance

For higher machine performance

- Suitable for low-speed and high-torque operations.
- High-accuracy positioning is achieved because the motors are directly coupled to a load.

For easier use

- Since mechanical transmission is no longer required, no backlash and no abrasion occurs, enabling smooth operation with less audible noise, a clean system, and easy maintenance.
- Less components are required for the system.

For flexible machine configurations


- A simple, compact, and high-rigid machine is achieved.
- Machine stability is enhanced due to the low-profile design and a low center of gravity.
- The motors have an inner rotor with hollow shaft that allows cables and pipes to pass through.

[No mechanical transmission contributing to no warp or distortion]



Application Examples

Suitable for low speed and high torque applications.




Mitsubishi Electric Solutions

e-F@ctory

Maximize productivity and reduce costs with an intelligent smart factory solution

Intelligent smart factories utilize high-speed networks with large data bandwidths to meet current manufacturing needs. The combination of CC-Link IE TSN and Mitsubishi Electric's e-F@ctory solution ensures robust integration between IT and factory automation systems, providing an intelligent smart factory solution that reduces total cost while improving operations, production yield, and efficient management of the supply chain. e-F@ctory is the Mitsubishi Electric solution for adding value across the manufacturing enterprise by enhancing productivity, thereby simultaneously reducing maintenance and operating costs, and enabling the seamless flow of information throughout the plant. e-F@ctory uses a combination of factory automation and IT technologies in combination with various best-in-class partner products through its alliance program.



Mitsubishi Electric Partners

e-F@ctory Alliance


The e-F@ctory Alliance is a FA manufacturer partnering program that strongly links the connection compatibility of Mitsubishi Electric FA equipment utilizing excellent software and machinery offered by partners, thereby enabling systems to be built by systems integration partners and the proposal of optimal solutions to customers.



Mitsubishi Electric Servo System Partners

Servo system includes controllers, servo drivers, actuators, sensors, etc. The servo system takes a step further to accelerate the equipment revolution by collaborating with our partner companies. Now that a wide variety of partner products are available such as stepping motors, pressure-resistance, explosion-proof type motors, linear encoders, your system will be configured flexibly. The Mitsubishi Electric Servo System Partner Association is a subcommittee of e-F@ctory Alliance.

Partner product lines supporting CC-Link IE TSN and MELSERVO-J5 have been and will continue to be expanded sequentially.



Mitsubishi Electric FA Global Website

Mitsubishi Electric Factory Automation provides a mix of services to support its customers worldwide, through a consolidated global website. It offers a selection of support tools and a window to its local Mitsubishi Electric sales and support network.

Global & Local Websites

Mitsubishi Electric Factory Automation
Global website

www.MitsubishiElectric.com/fa







Local websites

Global website

e-Manual

Instruction manuals are available in e-Manual format.

- Use the e-Manual application on tablets
- Download and update manuals quickly and easily
- Search for desired information across multiple manuals






Model Selection Software

Model selection software is now available, so you can select options such as encoder cables and power cables which are required to use with controllers, servo motors, servo amplifiers, and regenerative options of your choice.

The result can be saved in a CSV format and can be used as a purchase list.



Model selection software

Combinations of Rotary Servo Motors and Servo Amplifiers	1-2
Combinations of Rotary Servo Motors and Drive Units	1-6
Combinations of Linear Servo Motors and Servo Amplifiers	1-7
Combinations of Direct Drive Motors and Servo Amplifiers	1-9
Safety Sub-Functions	1-10
Environment	1-12
Compliance with Global Standards and Regulations	1_1/

 $^{^{\}star}$ Refer to p. 7-70 in this catalog for conversion of units.

Combinations of Rotary Servo Motors and Servo Amplifiers (Note 1)

The torque can be increased by combining a large-capacity servo amplifier. (Note 2)

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

1-axis servo amplifier (200 V)

 \bigcirc : Standard torque \bigcirc : Torque increased

Datami aamia maat	(Note 2)		Servo am	plifier MR-J	l5 (200 V)					
Rotary servo motor (Note 2)			10G/A 20G/A 40G/A 60G/A			60G/A	/A 70G/A 100G/A		200G/A 35	350G/A
		HK-KT053W	0	0	0	-	-	-	-	-
40 × 4	40 × 40	HK-KT13W	0	0	0	-	-	-	-	-
		HK-KT1M3W	-	0	0	0	-	-	-	-
		HK-KT13UW	0	0	0	-	-	-	-	-
	00 00	HK-KT23W	-	0	0	0	-	-	-	-
	60 × 60	HK-KT43W	-	-	0	0	0	-	-	-
		HK-KT63W	-	-	-	-	0	0	0	-
		HK-KT23UW	-	0	0	0	-	-	-	-
IK-KT_W	00 00	HK-KT43UW	-	-	0	0	0	-	-	-
	80 × 80	HK-KT7M3W	-	-	-	-	0	0	0	-
		HK-KT103W	-	-	-	-	-	0	0	0
		HK-KT63UW	-	-	-	0	0	0	-	-
		HK-KT7M3UW	-	-	-	-	0	0	0	-
	00 00	HK-KT103UW	-	-	-	-	-	0	0	0
	90 × 90	HK-KT153W	-	-	-	-	-	-	0	0
		HK-KT203W	-	-	-	-	-	-	0	0
		HK-KT202W	-	-	-	-	-	-	0	0
6		HK-KT434W	-	0	0	0	-	-	-	-
	60 × 60	HK-KT634W	-	-	0	0	0	-	-	-
	00 00	HK-KT7M34W	-	-	0	0	0	-	-	-
IK-KT_4_W	80 × 80	HK-KT1034W	-	-	-	0	0	0	-	-
		HK-KT1534W	-	-	-	-	0	0	0	-
	90 × 90	HK-KT2034W	-	-	-	-	-	0	0	0
		HK-KT2024W	-	-	-	-	-	0	0	0
		HK-MT053W	0	0	0	-	-	-	-	-
	40 × 40	HK-MT13W	0	0	0	-	-	-	-	-
		HK-MT1M3W	-	0	0	-	-	-	-	-
		HK-MT23W	-	0	0	-	-	-	-	-
HK-MT_W (Note 3)	60 × 60	HK-MT43W	-	-	0	-	0	-	-	-
		HK-MT63W	-	-	-	-	0	-	0	-
		HK-MT7M3W	-	-	-	-	0	-	0	-
	80 × 80	HK-MT103W	-	-	-	-	-	0	0	-
		HK-MT053VW	0	0	0	-	-	-	-	-
	40 × 40	HK-MT13VW	0	0	0	-	-	-	-	-
		HK-MT1M3VW	-	0	0	-	-	-	-	-
		HK-MT23VW	-	0	0	-	-	-	-	-
K-MT_VW (Note 3)	60 × 60	HK-MT43VW	-	-	-	0	0	-	-	-
		HK-MT63VW	-	-	-	-	0	-	0	-
		HK-MT7M3VW	-	-	-	-	0	-	0	-
	80 × 80	HK-MT103VW	-	-	-	-	 -	-	0	0

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output.

^{2.} The combinations of servo amplifiers and geared servo motors, servo motors with an electromagnetic brake, or servo motors with functional safety are the same as those described in this table. Note that the torque is not increased for the combinations marked with when a geared servo motor is used.

^{3.} Use the servo amplifiers with firmware version C2 or later. If the servo amplifiers with the previous firmware version are connected, an alarm occurs.

Combinations of Rotary Servo Motors and Servo Amplifiers (Note 1)

The torque can be increased by combining a large-capacity servo amplifier. (Note 2)

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

1-axis servo amplifier (200 V)

○: Standard torque ◎: Torque increased

Dotony com:	or (Note 2)		Servo an	nplifier MR-J	5 (200 V)					
Rotary servo mot	Ol (Note 2)		40G/A	60G/A	70G/A	100G/A	200G/A	350G/A	500G/A	700G/A
		HK-ST52W	-	0	0	0	-	-	-	-
		HK-ST102W	-	-	-	0	0	0	-	-
		HK-ST172W	-	-	-	-	0	0	-	-
	130 × 130	HK-ST202AW	-	-	-	-	0	0	-	-
		HK-ST302W	-	-	-	-	_	0	(Note 4)	
HK-ST_W (Note 3)		HK-ST353W	-	-	-	-		0	0	
		HK-ST503W	-	<u> </u>	-	<u></u>	-	-	0	0
		HK-ST202W	-	-	-	-	0	0	-	
	176 × 176	HK-ST352W	<u> </u>	-	-	-	-	0	(Note 4)	
176 × 176	170 X 176	HK-ST502W	-	-	-	-	-	-	0	0
		HK-ST702W	1-		-	-	_	-	-	0
		HK-ST524W	0	0	0	-	-	-	-	
		HK-ST1024W	<u> </u> -	0	0	0	-		-	
	130 × 130	HK-ST1724W	-		-	0	0	0	-	<u> </u> -
		HK-ST2024AW	-	-	-	0	0	0	-	-
HK-ST_4_W		HK-ST3024W	<u> </u> -	-	-	-	0	0	-	-
		HK-ST2024W	<u></u>		-	-	0	0	<u> </u> -	<u> </u> -
	176 × 176	HK-ST3524W	<u> </u> -		-	-	0	0	-	<u> </u> -
	170 x 170	HK-ST5024W	<u> </u> -		-	-	-	0	(Note 4)	-
		HK-ST7024W	-	-	-	-	-	-	0	0
		HK-RT103W	-	-	-	(Note 5)	0	-	-	-
	90 × 90	HK-RT153W	<u> </u> -	-	-	-	0	-	0	-
HK-RT_W		HK-RT203W	<u> </u> -		-	-	0	0	-	-
ii C i i i _ v v		HK-RT353W	-	-	-	-	-	0	0	-
	130 × 130	HK-RT503W	-	-	-	-	-	-	0	0
		HK-RT703W	-	-	-	-	-	-	-	0

- Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers. Refer to the servo amplifiers with the same rated output.
 - 2. The combinations of servo amplifiers and geared servo motors, servo motors with an electromagnetic brake, or servo motors with functional safety are the same as those described in this table. Note that the torque is not increased for the combinations marked with \odot when a geared servo motor is used.
 - 3. The servo amplifiers for HK-ST152G_ geared servo motor are the same as for HK-ST172W.
 - 4. Use the rotary servo motors manufactured in December 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual" for how to check the date of manufacture.
 - 5. The dynamic brake time constant is longer than that of when the previous HG-RR103 and MR-J4-200_ are combined. When the time constant equivalent to that of the previous series is required, combine HK-RT103W and MR-J5-200_. Refer to "MR-J5 User's Manual" for how to calculate the coasting distance.

Combinations of Rotary Servo Motors and Servo Amplifiers (Note 1)

The torque can be increased by combining a large-capacity servo amplifier. (Note 2)

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

1-axis servo amplifier (400 V)

 \bigcirc : Standard torque \bigcirc : Torque increased

Datamiaamia	-t- (Note 2)		Servo amplifier M	/IR-J5 (400 V)		
Rotary servo motor (Note 2)			60G4/A4	100G4/A4	200G4/A4	350G4/A4
		HK-KT053W	(Note 3)	(Note 3)	-	-
HK-KT_W	40 × 40	HK-KT13W	(Note 3)	(Note 3)	-	-
		HK-KT1M3W	(Note 3)	(Note 3)	-	-
	60 60	HK-KT434W	(Note 3)	(Note 3)	(Note 3)	-
	60 × 60	HK-KT634W	-	(Note 3)	(Note 3)	(Note 3)
	00 00	HK-KT7M34W	-	(Note 3)	(Note 3)	(Note 3)
	80 × 80	HK-KT1034W	-	(Note 3)	(Note 3)	(Note 3)
HK-KT_4_W		HK-KT634UW	0	0	0	-
		HK-KT1034UW	-	0	0	0
90 × 9	90 × 90	HK-KT1534W	-	-	(Note 3)	(Note 3)
		HK-KT2034W	-	-	(Note 3)	(Note 3)
		HK-KT2024W	-	-	(Note 3)	(Note 3)
		HK-ST524W	(Note 4)	(Note 4)	(Note 4)	-
		HK-ST1024W	-	(Note 4)	(Note 4)	(Note 4)
	130 × 130	HK-ST1724W	-	-	(Note 4)	(Note 4)
HK-ST_4_W	130 × 130	HK-ST2024AW	-	-	(Note 4)	(Note 4)
Note 5)		HK-ST3024W	-	-	-	(Note 4)
		HK-ST3534W	-	-	-	0
	176 176	HK-ST2024W	-	-	(Note 4)	(Note 4)
176 × 176	HK-ST3524W	-	-	-	(Note 4)	
		HK-RT1034W	-	0	0	-
IV DT 4W	90 × 90	HK-RT1534W	-	-	0	-
HK-RT_4W		HK-RT2034W	-	-	0	0
	130 × 130	HK-RT3534W	-	-	-	0

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output.

^{2.} The combinations of servo amplifiers and geared servo motors, servo motors with an electromagnetic brake, or servo motors with functional safety are the same as those described in this table. Note that the torque is not increased for the combinations marked with
when a geared servo motor is used.

^{3.} Use the rotary servo motors manufactured in September 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual" for how to check the date of manufacture.

^{4.} Use the rotary servo motors manufactured in December 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual" for how to check the date of manufacture.

^{5.} The servo amplifiers for HK-ST1524G_ geared servo motor are the same as for HK-ST1724W.

Combinations of Rotary Servo Motors and Servo Amplifiers (Note 1)

The torque can be increased by combining a large-capacity servo amplifier. (Note 2)

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

Any combination of the rotary servo motors, the linear servo motors, and the direct drive motors with different series and capacities is possible as long as the servo motors are compatible with the servo amplifier.

Multi-axis servo amplifier (200 V)

○: Standard torque ◎: Torque increased

Rotary servo mot	or (Note 2)		Servo am	olifier MR-J5W2			Servo amp	olifier MR-J5W3
Holary Servo Illoi	Or (Holo 2)		22G	44G	77G	1010G	222G	444G
		HK-KT053W	0	0	-	-	0	0
	40 × 40	HK-KT13W	0	0	-	-	0	0
		HK-KT1M3W	0	0	-	-	0	0
		HK-KT13UW	0	0	-	-	0	0
	60 × 60	HK-KT23W	0	0	-	-	0	0
	00 x 00	HK-KT43W	-	0	0	0	-	0
HK-KT_W		HK-KT63W	-	-	0	0	-	-
1 11Z-1Z 1 _ VV		HK-KT23UW	0	0	-	-	0	0
	80 × 80	HK-KT43UW	-	0	0	0	-	0
	00 x 00	HK-KT7M3W	-	-	0	0	-	-
		HK-KT103W	-	-	-	0	-	-
		HK-KT63UW	-	-	0	0	-	-
	90 × 90	HK-KT7M3UW	-	-	0	0	-	-
		HK-KT103UW	-	-	-	0	-	-
	60 × 60	HK-KT434W	0	0	-	-	0	0
	00 × 00	HK-KT634W	-	0	0	0	-	0
	00 00	HK-KT7M34W	-	0	0	0	-	0
HK-KT_4_W	80 × 80	HK-KT1034W	-	-	0	0	-	-
		HK-KT1534W	-	-	0	0	-	-
	90 × 90	HK-KT2034W	-	-	-	0	-	-
		HK-KT2024W	-	-	-	0	-	-
		HK-MT053W	0	0	-	-	0	0
	40 × 40	HK-MT13W	0	0	-	-	0	0
		HK-MT1M3W	0	0	-	-	0	0
HK-MT_W (Note 3)		HK-MT23W	0	0	-	-	0	0
mk-IVI I _VV (Note o)	60 × 60	HK-MT43W	-	0	0	0	-	0
		HK-MT63W	-	-	0	0	-	-
	80 × 80	HK-MT7M3W	-	-	0	0	-	-
	80 × 80	HK-MT103W	-	-	-	0	-	-
		HK-MT053VW	0	0	-	-	0	0
	40 × 40	HK-MT13VW	0	0	-	-	0	0
		HK-MT1M3VW	0	0	-	-	0	0
HK-MT_VW (Note 3)		HK-MT23VW	0	0	-	-	0	0
	60 × 60	HK-MT43VW	-	-	0	0	-	-
		HK-MT63VW	-	-	0	0	-	-
	80 × 80	HK-MT7M3VW	-	-	0	0	-	-
LIK OT W	120 120	HK-ST52W	-	-	0	0	-	-
HK-ST_W	130 × 130	HK-ST102W	-	-	-	0	-	-
		HK-ST524W	-	0	0	-	-	0
LIK OT A M	120 100	HK-ST1024W	-	-	0	0	-	-
HK-ST_4_W	130 × 130	HK-ST1724W	-	-	-	0	-	-
		HK-ST2024AW	-	-	-	0	-	-
HK-RT_W	90 × 90	HK-RT103W	-	-	-	0	-	-

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output.

^{2.} The combinations of servo amplifiers and geared servo motors, servo motors with an electromagnetic brake, or servo motors with functional safety are the same as those described in this table. Note that the torque is not increased for the combinations marked with

when a geared servo motor is used.

^{3.} Use the servo amplifiers with firmware version C2 or later. If the servo amplifiers with the previous firmware version are connected, an alarm occurs.

Combinations of Rotary Servo Motors and Drive Units (Note 1)

The torque can be increased by combining a large-capacity drive unit. (Note 2)

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

Any combination of the servo motors with different series and capacities is possible as long as the servo motors are compatible with the multi-axis drive unit.

Drive unit (400 V)

○: Standard torque ◎: Torque increased

Rotary servo r	Rotary servo motor (Note 2)		Drive unit MR-J5D1					Drive unit MR-J5D2					Drive unit MR-J5D3	
•			100G4	200G4	350G4	500G4	700G4	100G4	200G4	350G4	500G4	700G4	100G4	200G4
		HK-KT053W	(Note 3)	-	-	-	-	(Note 3)	-	-	-	-	(Note 3)	-
HK-KT_W	40 × 40	HK-KT13W	(Note 3)	-	-	-	-	(Note 3)	-	-	-	-	(Note 3)	-
		HK-KT1M3W	(Note 3)	-	-	-	-	(Note 3)	-	-	-	-	(Note 3)	-
	00 00	HK-KT434W	(Note 3)	(Note 3)	-	-	-	(Note 3)	(Note 3)	-	-	-	(Note 3)	(Note 3)
	60 × 60	HK-KT634W	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note 3)
	00 00	HK-KT7M34W	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note 3)
	80 × 80	HK-KT1034W	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note 3)
HK-KT_4_W		HK-KT634UW	0	0	-	-	-	0	0	-	-	-	0	0
		HK-KT1034UW	0	0	0	-	-	0	0	0	-	-	0	0
	90 × 90	HK-KT1534W	-	(Note 3)	(Note 3)	-	-	-	(Note 3)	(Note 3)	-	-	-	(Note 3)
		HK-KT2034W	-	(Note 3)	(Note 3)	-	-	-	(Note 3)	(Note 3)	-	-	-	(Note 3)
		HK-KT2024W	-	(Note 3)	(Note 3)	-	-	-	(Note 3)	(Note 3)	-	-	-	(Note 3)
		HK-ST524W	(Note 4)	(Note 4)	-	-	-	(Note 4)	(Note 4)	-	-	-	(Note 4)	(Note 4)
		HK-ST1024W	(Note 4)	(Note 4)	(Note 4)	-	-	(Note 4)	(Note 4)	(Note 4)	-	-	(Note 4)	(Note 4)
		HK-ST1724W	-	(Note 4)	(Note 4)	(Note 5)	-	-	(Note 4)	(Note 4)	(Note 5)	-	-	(Note 4)
	130 × 130	HK-ST2024AW	-	(Note 4)	(Note 4)	(Note 5)	-	-	(Note 4)	(Note 4)	(Note 5)	-	-	(Note 4)
		HK-ST3024W	-	-	(Note 4)	(Note 5)	(Note 5)	-	-	(Note 4)	(Note 5)	(Note 5)	-	-
HK-ST_4_W (Note 6)		HK-ST3534W	-	-	0	0	-	-	-	0	0	-	-	-
()		HK-ST5034W	-	-	-	0	0	-	-	-	0	0	-	-
		HK-ST2024W	-	(Note 4)	(Note 4)	(Note 5)	-	-	(Note 4)	(Note 4)	(Note 5)	-	-	(Note 4)
	170 170	HK-ST3524W	-	-	(Note 4)	(Note 5)	(Note 5)	-	-	(Note 4)	(Note 5)	(Note 5)	-	-
	176 × 176	HK-ST5024W	-	-	-	(Note 5)	(Note 5)	-	-	-	(Note 5)	(Note 5)	-	-
		HK-ST7024W	-	-	-	-	(Note 5)	-	-	-	-	(Note 5)	-	-
		HK-RT1034W	0	0	-	-	-	0	0	-	-	-	0	0
	90 × 90	HK-RT1534W	-	0	-	0	-	-	0	-	0	-	-	0
LIK DT 4M		HK-RT2034W	-	0	0	-	-	-	0	0	-	-	-	0
HK-RT_4W		HK-RT3534W	-	-	0	0	-	-	-	0	0	-	-	-
	130 × 130	HK-RT5034W	-	-	-	0	0	-	-	-	0	0	-	-
		HK-RT7034W	-	-	-	-	0	-	-	-	-	0	-	-

Notes: 1. The combinations of servo motors and drive units with special specifications are the same as those of standard drive units.

Refer to the drive units with the same rated output.

^{2.} The combinations of drive units and geared servo motors, servo motors with an electromagnetic brake, or servo motors with functional safety are the same as those described in this table. Note that the torque is not increased for the combinations marked with

when a geared servo motor is used.

^{3.} Use the rotary servo motors manufactured in September 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual" for how to check the date of manufacture.

^{4.} Use the rotary servo motors manufactured in December 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual" for how to check the date of manufacture.

^{5.} Use the rotary servo motors manufactured in April 2021 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual" for how to check the date of manufacture.

^{6.} The drive units for HK-ST1524G_ geared servo motor are the same as for HK-ST1724W.

Combinations of Linear Servo Motors and Servo Amplifiers (Note 1)

1-axis servo amplifier O: Standard thrust

Linear se	ervo motor		Servo a	Servo amplifier MR-J5 20G/A 40G/A 60G/A 70G/A 100G/A 200G/A 350G/A 500G/A							
	Primary side (coil)	Secondary side (magnet)	20G/A	40G/A	60G/A	70G/A	100G/A	200G/A	350G/A	500G/A	700G/A
	LM-H3P2A-07P-BSS0	LM-H3S20-288-BSS0 LM-H3S20-384-BSS0 LM-H3S20-480-BSS0 LM-H3S20-768-BSS0	-	0	-	-	-	-	-	-	-
	LM-H3P3A-12P-CSS0	LM-H3S30-288-CSS0	-	0	-	-	-	-	-	-	-
LM-H3	LM-H3P3B-24P-CSS0	LM-H3S30-384-CSS0	-	-	-	0	-	-	-	-	-
series	LM-H3P3C-36P-CSS0		-	-	-	0	-	-	-	-	-
	LM-H3P3D-48P-CSS0	LM-H3S30-768-CSS0	-	-	-	-	-	0	-	-	-
	LM-H3P7A-24P-ASS0	LM-H3S70-288-ASS0	-	-	-	0	-	-	-	-	-
	LM-H3P7B-48P-ASS0	LM-H3S70-384-ASS0	-	-	-	-	-	0	-	-	-
	LM-H3P7C-72P-ASS0	LM-H3S70-480-ASS0 LM-H3S70-768-ASS0	-	-	-	-	-	0	-	-	-
	LM-H3P7D-96P-ASS0		-	-	-	-	-	-	0	-	-
	LM-AJP1B-07K-JSS0	LM-AJS10-080-JSS0 -LM-AJS10-200-JSS0	-	0	-	-	-	-	-	-	-
	LM-AJP1D-14K-JSS0	LM-AJS10-400-JSS0	-	-	-	0	-	-	-	-	-
	LM-AJP2B-12S-JSS0	LM-AJS20-080-JSS0	-	0	-	-	-	_	_	_	-
		LM-AJS20-200-JSS0									
LM-AJ	LM-AJP2D-23T-JSS0	LM-AJS20-400-JSS0	-	-	-	0	-	-	-	-	-
series	LM-AJP3B-17N-JSS0	LM-AJS30-080-JSS0 -LM-AJS30-200-JSS0	-	0	-	-	-	-	-	-	-
	LM-AJP3D-35R-JSS0	LM-AJS30-400-JSS0	-	-	-	0	-	-	-	-	-
	LM-AJP4B-22M-JSS0	LM-AJS40-080-JSS0	-	0	-	-	-	-	-	-	-
	LM-AJP4D-45N-JSS0	LM-AJS40-200-JSS0	_	_	_	0	-	_	_	_	_
	LM-FP2B-06M-1SS0	LM-AJS40-400-JSS0	_		_	1_	_	0		_	_
	LM-FP2D-12M-1SS0	LM-FS20-480-1SS0	-		-	- -	1_	_		0	
LM-F	LM-FP2F-18M-1SS0	LM-FS20-576-1SS0	-	-	-	-	-	_	-	-	0
series	LM-FP4B-12M-1SS0	LM-FS40-480-1SS0	-	-	-	-	-	-	-	0	-
	LM-FP4D-24M-1SS0	LM-FS40-576-1SS0	-	-	-	-	-	-	-	-	0
	LM-K2P1A-01M-2SS1	LM-K2S10-288-2SS1 LM-K2S10-384-2SS1	-	0	-	-	-	-	-	-	-
	LM-K2P1C-03M-2SS1	LM-K2S10-480-2SS1 LM-K2S10-768-2SS1	-	-	-	-	-	0	-	-	-
	LM-K2P2A-02M-1SS1	LM-K2S20-288-1SS1	-	-	-	0	-	-	-	-	-
LM-K2	LM-K2P2C-07M-1SS1	LM-K2S20-384-1SS1 LM-K2S20-480-1SS1	-	-	-	-	-	-	0	-	-
series	LM-K2P2E-12M-1SS1	LM-K2S20-768-1SS1	-	-	-	-	-	-	-	0	-
	LM-K2P3C-14M-1SS1	LM-K2S30-288-1SS1 LM-K2S30-384-1SS1	-	-	-	-	-	-	0	-	-
	LM-K2P3E-24M-1SS1	LM-K2S30-480-1SS1 LM-K2S30-768-1SS1	-	-	-	-	-	-	-	0	-
	LM-U2PAB-05M-0SS0	LM-U2SA0-240-0SS0	0	-	-	-	-	-	-	-	-
	LM-U2PAD-10M-0SS0	LM-U2SA0-300-0SS0	-	0	-	-	-	-	-	-	-
	LM-U2PAF-15M-0SS0	LM-U2SA0-420-0SS0	-	0	-	-	-	-	-	-	-
LMLIO	LM-U2PBB-07M-1SS0	LM-U2SB0-240-1SS1	0	-	-	-	-	-	-	-	-
LM-U2 series	LM-U2PBD-15M-1SS0	LM-U2SB0-300-1SS1	-	-	0	-	-	-	-	-	-
301103	LM-U2PBF-22M-1SS0	LM-U2SB0-420-1SS1	-	-	-	0	-	-	-	-	-
	LM-U2P2B-40M-2SS0	I M-I 12520-300-2551	-	-	-	-	-	0	-	-	-
	LM-U2P2C-60M-2SS0	LM-U2S20-300-2SS1 LM-U2S20-480-2SS1	-	-	-	-	-	-	0	-	-
	LM-U2P2D-80M-2SS0		-	-	-	-	-	-	-	0	-

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output.

Combinations of Linear Servo Motors and Servo Amplifiers (Note 1)

Any combination of the rotary servo motors, the linear servo motors, and the direct drive motors with different series and capacities is possible as long as the servo motors are compatible with the servo amplifier.

Multi-axis servo amplifier

O: Standard thrust

				nplifier MR-J5	W2		Servo amplifier MR-J5W3		
	Primary side (coil)	Secondary side (magnet)	22G	44G	77G	1010G	222G	444G	
	LM-H3P2A-07P-BSS0	LM-H3S20-288-BSS0 LM-H3S20-384-BSS0 LM-H3S20-480-BSS0 LM-H3S20-768-BSS0	-	0	0	0	-	0	
	LM-H3P3A-12P-CSS0	LM-H3S30-288-CSS0	-	0	0	0	-	0	
LM-H3	LM-H3P3B-24P-CSS0	LM-H3S30-384-CSS0	-	-	0	0	-	-	
series	LM-H3P3C-36P-CSS0	LM-H3S30-480-CSS0 LM-H3S30-768-CSS0	-	-	0	0	-	-	
	LM-H3P7A-24P-ASS0	LM-H3S70-288-ASS0 LM-H3S70-384-ASS0 LM-H3S70-480-ASS0 LM-H3S70-768-ASS0	-	-	0	0	-	-	
	LM-AJP1B-07K-JSS0	LM-AJS10-080-JSS0	-	0	0	0	-	0	
	LM-AJP1D-14K-JSS0	LM-AJS10-200-JSS0 LM-AJS10-400-JSS0	-	-	0	0	-	-	
	LM-AJP2B-12S-JSS0	LM-AJS20-080-JSS0	-	0	0	0	-	0	
LM-AJ	LM-AJP2D-23T-JSS0	LM-AJS20-200-JSS0 LM-AJS20-400-JSS0	-	-	0	0	-	-	
series	LM-AJP3B-17N-JSS0	LM-AJS30-080-JSS0	-	0	0	0	-	0	
	LM-AJP3D-35R-JSS0	LM-AJS30-200-JSS0 LM-AJS30-400-JSS0	-	-	0	0	-	-	
	LM-AJP4B-22M-JSS0	LM-AJS40-080-JSS0	-	0	0	0	-	0	
	LM-AJP4D-45N-JSS0	LM-AJS40-200-JSS0 LM-AJS40-400-JSS0	-	-	0	0	-	-	
LM-K2	LM-K2P1A-01M-2SS1	LM-K2S10-288-2SS1 LM-K2S10-384-2SS1 LM-K2S10-480-2SS1 LM-K2S10-768-2SS1	-	0	0	0	-	0	
series LM-K2P2A-02M-1SS1	LM-K2S20-288-1SS1 LM-K2S20-384-1SS1 LM-K2S20-480-1SS1 LM-K2S20-768-1SS1	-	-	0	0	-	-		
	LM-U2PAB-05M-0SS0	LM-U2SA0-240-0SS0	0	0	-	-	0	0	
	LM-U2PAD-10M-0SS0	LM-U2SA0-300-0SS0	-	0	0	0	-	0	
LM-U2	LM-U2PAF-15M-0SS0	LM-U2SA0-420-0SS0	-	0	0	0	-	0	
series	LM-U2PBB-07M-1SS0	LM-U2SB0-240-1SS1	0	0	-	-	0	0	
	LM-U2PBD-15M-1SS0 LM-U2PBF-22M-1SS0	LM-U2SB0-300-1SS1 LM-U2SB0-420-1SS1	-	-	0	0	-	- -	

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

Combinations of Direct Drive Motors and Servo Amplifiers (Note 1)

The torque can be increased by combining a large-capacity servo amplifier.

The torque characteristics vary by the combinations. Refer to the list of the specifications of each direct drive motor.

Any combination of the rotary servo motors, the linear servo motors, and the direct drive motors with different series and capacities is possible as long as the servo motors are compatible with the servo amplifier.

1-axis servo amplifier

○: Standard torque ◎: Torque increased

Dive et duis e se	-t (Note 2)	Servo am	Servo amplifier MR-J5								
Direct drive me	rect drive motor (Note 2)		40G/A	60G/A	70G/A	100G/A	350G/A	500G/A			
	TM-RG2M002C30 TM-RU2M002C30	0	-	-	-	-	-	-			
TM-RG2M/ TM-RU2M series	TM-RG2M004E30 TM-RU2M004E30	0	0	-	-	-	-	-			
series	TM-RG2M009G30 TM-RU2M009G30	-	0	-	-	-	-	-			
	TM-RFM002C20	0	-	-	-	-	-	-			
	TM-RFM004C20	-	0	-	-	-	-	-			
	TM-RFM006C20	-	-	0	-	-	-	-			
	TM-RFM006E20	-	-	0	-	-	-	-			
	TM-RFM012E20	-	-	-	0	-	-	-			
TM-RFM	TM-RFM018E20	-	-	-	-	0	-	-			
series	TM-RFM012G20	-	-	-	0	-	-	-			
	TM-RFM048G20	-	-	-	-	-	0	-			
	TM-RFM072G20	-	-	-	-	-	0	-			
	TM-RFM040J10	-	-	-	0	-	-	-			
	TM-RFM120J10	-	-	-	-	-	0	-			
	TM-RFM240J10	-	-	-	-	-	-	0			

Multi-axis servo amplifier

○: Standard torque ◎: Torque increased

Discret datas as	- t (Noto 2)	Servo amp	lifier MR-J5W2-	_		Servo amp	lifier MR-J5W3
Direct drive mo	Otor (Note 2)	22G	44G	77G	1010G	222G	444G
TM DCOM/	TM-RG2M002C30 TM-RU2M002C30	0	0	-	-	0	0
TM-RG2M/ TM-RU2M	TM-RG2M004E30 TM-RU2M004E30	0	0	-	-	0	0
series	TM-RG2M009G30 TM-RU2M009G30	-	0	0	0	-	0
	TM-RFM002C20	0	0	-	-	0	0
	TM-RFM004C20	-	0	0	0	-	0
	TM-RFM006C20	-	-	0	0	-	-
ΓM-RFM	TM-RFM006E20	-	-	0	0	-	-
series	TM-RFM012E20	-	-	0	0	-	-
	TM-RFM018E20	-	-	-	0	-	-
	TM-RFM012G20	-	-	0	0	-	-
	TM-RFM040J10	-	-	0	0	-	-

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output.

2. Use the direct drive motors manufactured in June 2019 or later when connecting to MR-J5 servo amplifiers. If the direct drive motors manufactured before that date are connected, an alarm occurs. Refer to "Direct Drive Motor User's Manual" for how to check the date of manufacture.

Safety Sub-Functions (Note 1)

Specifications of servo amplifiers

●MR-J5-G(4)(-N1)/MR-J5-A(4)/MR-J5-A(4)-RJ

	Satistian standards	EN ISO 13849-1:2015 Category 3 PL e, IEC 61508 SIL 3, EN 62061 SIL CL 3, EN 61800-5-2
Safety	Mean time to dangerous failure (MTTFd)	MTTFd ≥ 100 [years] (314a)
,	Diagnostic coverage (DC)	DC = Medium, 97.6 %
	Probability of dangerous Failure per Hour (PFH)	$PFH = 6.4 \times 10^{-9} [1/h]$
	Mission time (T _M) (Note 3)	T _M = 20 [years]

•MR-J5-G(4)-RJ(N1)/MR-J5W_-G(-N1)/MR-J5D_-G4(-N1)

	Satistian standards (Note 2)	EN ISO 13849-1:2015 Category 4 PL e, IEC 61508 SIL 3, EN 62061 SIL CL 3, EN 61800-5-2				
Safety	Mean time to dangerous failure (MTTFd)	MTTFd ≥ 100 [years] (750a)				
performance	Diagnostic coverage (DC)	DC = Medium, 96.5 %				
	Probability of dangerous Failure per Hour (PFH)	PFH = 3 × 10 ⁻⁹ [1/h]				
	Mission time (T _M) (Note 3)	T _M = 20 [years]				

Function specifications

STO	Shut-off response time	8 ms or less (using input device)					
310	(STO input off → energy shut off)	60 ms or less (using the network) (Note 4, 5, 8)					
SS1	Deceleration delay time	0 ms to 60000 ms (functional safety parameter setting)					
SS2	Deceleration delay time	0 ms to 60000 ms (functional safety parameter setting)					
SOS	Observation position	0 rev to 1000 rev (functional safety parameter setting)					
SBC	Shut-off response time	8 ms or less (using input device) 60 ms or less (using the network) (Note 4, 5, 8)					
SLS1/2/3/4	Observation speed	0 r/min (mm/s) to 10000 r/min (mm/s) (functional safety parameter setting) (Note 6)					
SSM	Observation speed	0 r/min (mm/s) to 10000 r/min (mm/s) (functional safety parameter setting)					
SDI	Direction monitor delay time	0 ms to 60000 ms (functional safety parameter setting)					
SLI	Observation position	0 rev to 1000 rev (functional safety parameter setting)					
SLT	Observation torque	-1000.0 % to 1000.0 % (functional safety parameter setting)					
	Number of inputs	1 point × 2 systems					
Input device	Permissible time for mismatched double inputs	0 ms to 60000 ms (functional safety parameter setting)					
•	Noise elimination filter	1.000 ms to 32.000 ms (functional safety parameter setting)					
	Test pulse off time (Note 7)	1 Hz to 25 Hz					
	Number of outputs	1 point × 2 systems					
Output device	Test pulse off time (Note 7)	0.500 ms to 2.000 ms (functional safety parameter setting)					
	Test pulse interval (Note 7)	1 s or less					
	Response time	250 ms (Note 9)					
unication	Transmission interval monitor time	16.0 ms to 1000.0 ms (functional safety parameter setting) (using the network) (Note 8)					
	Safety communication delay time	60 ms or less (using the network) (Note 4, 8)					
	SS2 SOS SBC SLS1/2/3/4 SSM SDI SLI SLT Input device	(STO input off → energy shut off) SS1 Deceleration delay time SS2 Deceleration delay time SOS Observation position SBC Shut-off response time SLS1/2/3/4 Observation speed SSM Observation speed SDI Direction monitor delay time SLI Observation position SLT Observation torque Number of inputs Permissible time for mismatched double inputs Noise elimination filter Test pulse off time (Note 7) Number of outputs Output device Test pulse off time (Note 7) Test pulse interval (Note 7) Response time Transmission interval monitor time					

Notes: 1. Supported safety sub-functions and their safety levels vary by the combinations of the servo amplifier or the drive unit and the servo motor, and the firmware version of

- the servo amplifier. Refer to "List of supported safety sub-functions".

 When DI/O connection (CN8) is used, a diagnosis using test pulses is required to meet Category 4 PL e, SIL 3.

 The performance of special proof tests within the mission time of the product is regarded as not necessary, however, the diagnostic interval is suggested as at least one test per three months for Category 3 PL e, SIL 3 on IEC 61800-5-2:2016.
- 4. This value is applicable when the transmission interval monitor time is 32.0 ms or less.
- 5. Set the communication cycle as follows:
 - \bullet 125 μs or more for MR-J5-G(4)-RJ and MR-J5D1-G4
 - 500 µs or more for MR-J5D2-G4 and MR-J5D3-G4
- 6. The observation speed can be set separately.
 7. The test pulse is a signal for the external circuit to perform self-diagnosis by turning off the signals to the servo amplifier or the drive unit instantaneously at regular intervals.
- 8. The listed value is applicable when the safety sub-functions through the network connection are executed.
- 9. This value is applicable when the transmission interval monitor time is 64.0 ms or less

Safety Sub-Functions (Note 10)

List of supported safety sub-functions

Supported safety sub-functions and their safety levels vary by the combinations of the servo amplifier or the drive unit and the servo motor. Refer to the table below.

			Safety sub-function (IEC/EN 61800-5-2)											
Servo amplifier model	Connection method (connector)	Servo motor type	STO	SS1	SS1-r	SS2 (Note 3)	SOS (Note 3)	SBC	SLS (Note 3)	SSM (Note 3)	SDI (Note 3)	SLI (Note 3)	SLT	
MR-J5-G(4) MR-J5-A(4)(-RJ)	DI/O connection (CN8)	Servo motor with functional safety Rotary servo motor Linear servo motor Direct drive motor	Cat. 3 PL e, SIL 3	- (Note 8)	- (Note 3)	SS2-r	-	-	-	-	-	-	-	C
	DI/O connection	Servo motor with functional safety	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	
MR-J5-G(4)-RJ MR-J5D1-G4	(Note 2, 6) (CN8)	Rotary servo motor Linear servo motor Direct drive motor	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	-	-	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	-	Cat. 3 PL d, SIL 2	1410101
MR-J5D2-G4 (Note 9) MR-J5D3-G4 (Note 9)	Network connection	Servo motor with functional safety	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	Ö
	(Note 1, 5, 7) (CN1A/CN1B)	Rotary servo motor Linear servo motor Direct drive motor	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	-	-	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	-	Cat. 3 PL d, SIL 2	141
MR-J5W2-G (Note 4, 9) MR-J5W3-G (Note 4, 9)	DI/O connection (Note 2, 6) (CN8)	Servo motor with functional safety Rotary servo motor Linear servo motor Direct drive motor	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	-	-	-	Cat. 4 PL e, SIL 3	-	-	-	-	-	
MR-J5-G(4)-N1	DI/O connection (CN8)	Servo motor with functional safety Rotary servo motor Linear servo motor Direct drive motor	Cat. 3 PL e, SIL 3	- (Note 8)	-	-	-	-	-	-	-	-	-	14101010
MR-J5-G(4)-RJN1 MR-J5D1-G4-N1 MR-J5D2-G4-N1 (Note 9) MR-J5D3-G4-N1 (Note 9) MR-J5W2-G-N1 (Note 9) MR-J5W3-G-N1 (Note 9)	DI/O connection (Note 2, 6) (CN8)	Servo motor with functional safety Rotary servo motor Linear servo motor Direct drive motor	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	-	-	-	Cat. 4 PL e, SIL 3	-	-	-	-	-	

Notes: 1. Combine the servo amplifier with an R_SFCPU safety CPU with firmware version of 20 or later.

- 2. The listed safety levels are applicable when a safety CPU or a safety controller that meets Category 4 PL e, SIL 3 executes safety sub-function control. When a forced stop switch, a safety switch, or an enable switch is directly connected to the servo amplifier, the safety level is Category 3 PL d, SIL 2.
- 3. A fully closed loop system does not support SS1-r, SS2, SOS, SLS, SSM, SDI, and SLI.
- 4. The safety sub-functions are supported by MR-J5W_ manufactured in November 2019 or later.
- 5. Set the communication cycle as follows:
 - \bullet 125 μs or more for MR-J5-G(4)-RJ and MR-J5D1-G4
- 500 µs or more for MR-J5D2-G4 and MR-J5D3-G4
 6. When DI/O connection (CN8) is used, a diagnosis using test pulses is required to meet Category 4 PL e, SIL 3.
- 7. The safety sub-functions through the network connection are not available when the servo amplifier uses CC-Link IE Field Network Basic communication.
- 8. The servo amplifiers support SS1-t when combined with MR-J3-D05. Refer to p. 7-45 in this catalog for details.
- 9. The STO function can be set for each axis.
- 10. For 200 V class servo amplifiers, the firmware version B2 or later is required.

Environment

Motion module

Item	Operation	Storage					
Ambient temperature	0 °C to 55 °C	-25 °C to 75 °C (non-freezing)					
Ambient temperature	0 °C to 60 °C (when using the extended temperature range base unit) (Note 2)	-23 O to 73 O (Horr-freezing)					
Ambient humidity	5 %RH to 95 %RH (non-condensing)						
Ambience	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust						
Altitude	2000 m or less						
	Under intermittent vibration (directions of X, Y, and Z axes):						
	5 Hz to 8.4 Hz, displacement amplitude 3.5 mm						
Vibration resistance	8.4 Hz to 150 Hz, acceleration amplitude 9.8 m/s ²						
VIDIALION TESISLANCE	Under continuous vibration:						
	5 Hz to 8.4 Hz, displacement amplitude 1.75 mm						
	8.4 Hz to 150 Hz, acceleration amplitude 4.9 m/s ²						

Servo amplifier/drive unit/simple converter

Item	Operation	Transportation	Storage
Ambient temperature	0 °C to 60 °C (non-freezing) Class 3K3 (IEC 60721-3-3)	-25 °C to 70 °C (non-freezing) Class 2K12 (IEC 60721-3-2)	-25 °C to 70 °C (non-freezing) Class 1K4 (IEC 60721-3-1)
Ambient humidity	5 %RH to 95 %RH (non-condensing)		
Ambience	Indoors (no direct sunlight); no corrosive	e gas, inflammable gas, oil mist or dust	
Altitude/atmospheric pressure	Altitude: 2000 m or less (Note 1)	Overland/sea transportation, or transporting on an airplane whose cargo compartment is pressurized at 700 hPa or higher	Atmospheric pressure: 700 hPa to 1060 hPa (Equivalent to altitudes from -400 m to 3000 m)
Vibration resistance	Under intermittent vibration: 10 Hz to 57 Hz, displacement amplitude 0.075 mm 57 Hz to 150 Hz, acceleration amplitude 9.8 m/s² Class 3M1 (IEC 60721-3-3) Under continuous vibration (directions of X, Y, and Z axes): 10 Hz to 55 Hz, acceleration amplitude 5.9 m/s²	2 Hz to 9 Hz, displacement amplitude (single amplitude) 7.5 mm 9 Hz to 200 Hz, acceleration amplitude 20 m/s ² Class 2M3 (IEC 60721-3-2)	2 Hz to 9 Hz, displacement amplitude (single amplitude) 1.5 mm 9 Hz to 200 Hz, acceleration amplitude 5 m/s ² Class 1M2 (IEC 60721-3-1)

Power regeneration converter unit

Item	Operation	Transportation	Storage
Ambient temperature	0 °C to 55 °C (non-freezing)	-20 °C to 65 °C (non-freezing)	-20 °C to 65 °C (non-freezing)
Ambient temperature	Class 3K3 (IEC 60721-3-3)	Class 2K12 (IEC 60721-3-2)	Class 1K4 (IEC 60721-3-1)
Ambient humidity	5 %RH to 90 %RH (non-condensing)		
Ambience	Indoors (no direct sunlight); no corrosive	e gas, inflammable gas, oil mist or dust	
Altitude	2000 m or less (Note 1)		1000 m or less
Vibration resistance	Under intermittent vibration: 10 Hz to 57 Hz, displacement amplitude 0.075 mm 57 Hz to 150 Hz, acceleration amplitude 9.8 m/s² (IEC 60068-2-6 Test Fc) Under continuous vibration (directions of X, Y, and Z axes): 10 Hz to 55 Hz, acceleration amplitude 5.9 m/s²	2 Hz to 9 Hz, displacement amplitude (single amplitude) 7.5 mm 9 Hz to 200 Hz, acceleration amplitude 20 m/s ² Class 2M3 (IEC 60721-3-2)	2 Hz to 9 Hz, displacement amplitude (single amplitude) 1.5 mm 9 Hz to 200 Hz, acceleration amplitude 5 m/s ² Class 1M2 (IEC 60721-3-1)

Notes: 1. Refer to User's Manuals of each servo amplifier, drive unit, and power regeneration converter unit for the restrictions on using the servo amplifiers, the drive units, and the power regeneration converter units at an altitude exceeding 1000 m and up to 2000 m.

2. The extended temperature range base unit is compatible with RD78G only.

Environment

Rotary servo motor

Item	Operation	Storage	2
Ambient temperature	0 °C to 60 °C (non-freezing) (Note 2)	-15 °C to 70 °C (non-freezing)	2
Ambient humidity	10 %RH to 90 %RH (non-condensing)	10 %RH to 90 %RH (non-condensing)	
Ambience (Note 1)	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust, no object generating a strong magnetic field		
Altitude	2000 m or less (Note 3)		
External magnetic field	10 mT or less		
Vibration resistance	Refer to the specifications of each rotary servo motor.		-

Linear servo motor (LM-H3/LM-F/LM-K2/LM-U2 series)

Item	Operation	Storage	
Ambient temperature	0 °C to 60 °C (non-freezing) (Note 2)	-15 °C to 70 °C (non-freezing)	
Ambient humidity	10 %RH to 80 %RH (non-condensing)	%RH to 80 %RH (non-condensing) 10 %RH to 90 %RH (non-condensing)	
Ambience (Note 1)	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust		
Altitude	2000 m or less (Note 5)		
Vibration resistance	Refer to the specifications of each linear servo motor.		

Linear servo motor (LM-AJ series)

Item	Operation	Storage
Ambient temperature	0 °C to 40 °C (non-freezing)	-15 °C to 70 °C (non-freezing)
Ambient humidity	10 %RH to 80 %RH (non-condensing)	10 %RH to 90 %RH (non-condensing)
Ambience (Note 1)	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust	
Altitude	1000 m or less	
Vibration resistance	Refer to the specifications of each linear servo motor.	

Direct drive motor

Item	Operation	Storage
Ambient temperature	0 °C to 60 °C (non-freezing) (Note 2)	-15 °C to 70 °C (non-freezing)
Ambient humidity	10 %RH to 80 %RH (non-condensing)	10 %RH to 90 %RH (non-condensing)
Ambience (Note 1, 4)	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust	
Altitude	2000 m or less (Note 3)	
Vibration resistance	Refer to the specifications of each direct drive motor.	

Notes: 1. Do not use the servo motors in the environment where the servo motors are exposed to oil mist, oil and/or water.

- 2. Refer to User's Manuals of each servo motor for the restrictions on the ambient temperature.
- 3. Refer to User's Manuals of each servo motor for the derating condition when using the servo motors at an altitude exceeding 1000 m and up to 2000 m.
- 4. Do not place any object (such as a magnet) which generates a magnetic force near the direct drive motor. If it is unavoidable, take a measure such as mounting a shielding plate and so on to cut off the magnetic force.
- 5. Refer to "Linear Servo Motor User's Manual" for the restrictions on using the linear servo motor at an altitude exceeding 1000 m and up to 2000 m.

Compliance with Global Standards and Regulations

Motion module









E	Low voltage directive	-
	EMC directive	EN 61131-2
Europe	Machine directive	-
	RoHS directive	EN 63000
North America	UL standard	UL 61010-1, UL 61010-2-201
North America	CSA standard	CSA C22.2 No. 61010-1, CSA C22.2 No. 61010-2-201
	National Standard of the People's Republic of China (GB standards)	GB/T15969.2
China	Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products (China RoHS)	Article 13 (Names and the content of hazardous substances are described in User's Manuals.) Article 14 (Marking for the Restricted Use of Hazardous Substances is labeled.)
	China Compulsory Certification (CCC)	N/A
Korea	Korea Radio Wave Law (KC)	KN 61131-2

Servo amplifier/drive unit











	-		_	
4	c	ī	7	è
4	3	н	ľ	ı
٩	v	-	•	,
	•	_	_	

	Low voltage directive/Low voltage regulation	EN/BS EN 61800-5-1
	EMC directive/EMC regulation	EN/BS EN IEC 61800-3 Category C2/C3 second environment
Europe/UK	Machine directive/Machine regulation	EN/BS EN ISO 13849-1:2015 Category 3/4 PL e, EN/BS EN 62061 SIL CL 3, EN/BS EN 61800-5-2
	RoHS directive/RoHS regulation	EN/BS EN 63000
North America	UL standard	UL 61800-5-1
North America	CSA standard	CSA C22.2 No. 274
	National Standard of the People's Republic of China (GB standards)	GB 12668.501, GB 12668.3
China	Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products (China RoHS)	Article 13 (Names and the content of hazardous substances are described in User's Manuals.) Article 14 (Marking for the Restricted Use of Hazardous Substances is labeled.)
	China Compulsory Certification (CCC)	N/A
Korea	Korea Radio Wave Law (KC)	KS C 9800-3, KN 61800-3

Rotary servo motor










Hotary Serve motor		CERTIFIED 10 000000000
Furang/III/	Low voltage directive/Low voltage regulation	EN/BS EN 60034-1
	EMC directive/EMC regulation	EN/BS EN IEC 61800-3 Category C3
Europe/UK	Machine directive/Machine regulation	-
	RoHS directive/RoHS regulation	EN/BS EN 63000
North America	UL standard	UL 1004-1, UL 1004-6
North America	CSA standard	CSA C22.2 No. 100
	National Standard of the People's Republic of China (GB standards)	GB/T 755
China	Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products (China RoHS)	Article 13 (Names and the content of hazardous substances are described in User's Manuals.) Article 14 (Marking for the Restricted Use of Hazardous Substances is labeled.)
	China Compulsory Certification (CCC)	N/A
Korea	Korea Radio Wave Law (KC)	N/A

Compliance with Global Standards and Regulations

Linear servo motor (LM-H3/LM-F/LM-K2/LM-U2 series)



Linear servo motor (LM-AJ series)





- Firmana	Low voltage directive	DIN VDE 0580
	EMC directive	-
Europe	Machine directive	-
	RoHS directive	EN 63000
	National Standard of the People's Republic of China (GB standards)	Not subject to GB standards
China	Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products (China RoHS)	Article 13 (Names and the content of hazardous substances are described in User's Manuals.) Article 14 (Marking for the Restricted Use of Hazardous Substances is labeled.)
	China Compulsory Certification (CCC)	N/A

Direct drive motor







T	
	\leq
_	으
	2

Europa (IIII	Low voltage directive/Low voltage regulation	EN/BS EN 60034-1
	EMC directive/EMC regulation	EN/BS EN IEC 61800-3 Category C3
Europe/UK	Machine directive/Machine regulation	-
	RoHS directive/RoHS regulation	EN/BS EN 63000
North America	UL standard	UL 1004-1, UL 1004-6
Notti America	CSA standard	CSA C22.2 No. 100
	National Standard of the People's Republic of China (GB standards)	GB/T 755
	Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products (China RoHS)	Article 13 (Names and the content of hazardous substances are described in User's Manuals.) Article 14 (Marking for the Restricted Use of Hazardous Substances is labeled.)
	China Compulsory Certification (CCC)	N/A
Korea	Korea Radio Wave Law (KC)	N/A

MEMO

Motion Module	2-2
Engineering Software	2-12
Motion Control Software	2-13

^{*} Refer to p. 7-70 in this catalog for conversion of units.

Motion Module (Simple Motion Mode)

Control specifications

		Specifications					
Item		RD78G4	RD78G8	RD78G16			
Maximun	n number of control axes	4 axes	8 axes	16 axes			
Operation cycle (operation cycle setting) [µs]		250, 500, 1000, 2000, 4000					
Interpola	tion function		4 axes), 2-axis circular interpol	•			
Control n	nethod	Positioning control, path cocontrol, continuous operation		peed control, speed-torque control, synchronous			
Accelera	tion/deceleration process	Trapezoidal acceleration/de	eceleration, S-curve acceleration	on/deceleration			
Compen	sation function	Backlash compensation, el	ectronic gear, near pass functi	on			
Synchror	nous control	Synchronous encoder inpu	t, command generation axis, c	am, phase compensation, cam auto-generation			
Cam control	Maximum number of cam registrations (Note 1) Cam data	256 Stroke ratio data format, co	pordinate data format				
	Cam auto-generation	Cam auto-generation for ro	tary knife				
Positioni	ng control method	Motion profile table					
Control u	ınit	mm, inch, degree, pulse					
Number	of positioning data	600 data (positioning data (Can be set with MELSOF	No. 1 to 600)/axis T GX Works3 or a sequence pr	ogram (No. 1 to 600).)			
Backup		Parameters, positioning da	ta, and block start data can be	saved on flash ROM (batteryless backup)			
Home po	osition return	Driver home position return	η (Note 2)				
Positioning control		Linear interpolation control (Up to 4 axes) (vector speed, reference axis speed)), fixed-pitch feed control (up to 4 axes), 2-axis circular interpolation (auxiliary point-specified, central point-specified), helical interpolation control, speed control (up to 4 axes), speed-position switching control (INC mode, ABS mode), position-speed switching control (INC mode), current value change (positioning data, start No. for a current value changing) NOP instruction, JUMP instruction (conditional, unconditional), LOOP, LEND, high-level positioning control (block start, condition start, wait start, simultaneous start, repeated start)					
Manual c	control	magnification (1 to 10000 t	imes), via a CPU (buffer memo				
	orque control	Speed control not including position loop, torque control, continuous operation to torque control					
	position system	Provided					
function	nous encoder operation	Up to the number of axes of the connected servo amplifiers (via a CPU or a servo amplifier)					
Speed lir	mit	Speed limit value, JOG speed limit value					
<u> </u>	mit function	Torque limit value same setting, torque limit value individual setting					
Forced s		Via a buffer memory, valid/invalid setting					
	stroke limit function		feed current value or with mac	nine feed value			
	e stroke limit function	Provided					
Speed ch		Provided					
Override		0 to 300					
	ion/deceleration time change						
	mit change	Provided					
<u>_</u>	osition change		address and a target position is	cnangeable.			
	output function	WITH mode/AFTER mode					
Other	Step function	Deceleration unit step, data No. unit step					
	Skip function	Via a CPU or an external command signal					
Parameter initialization function		Provided					
External input signal select function		Via a CPU or a servo amplifier					
Mark detection function		Continuous detection mode, specified number of detections mode, ring buffer mode					
Mark detection signal		· ·	of the connected servo amplifie	rs			
Mark detection setting		16 settings					
•	data monitor function	Up to 4 points/axis					
Automati	ic return	Provided					
Digital os	scilloscope function	Bit data: 16 channels, word	d data: 16 channels (Note 4)				
lotoe: 1	The number of sem registrations	dananda an tha maman, aanaait,	cam recolution, and number of seard	actos			

Notes: 1. The number of cam registrations depends on the memory capacity, cam resolution, and number of coordinates.

2-2
2. The home position return method set in a driver (servo amplifier) is used.
3. 4-axis linear interpolation control is enabled only at the reference axis speed.
4. Eight channels of each word data and bit data can be displayed in real time.

2, 4, 16 axes (QD77MS2 and QD77MS4 use the

Linear interpolation (up to 4 axes), 2-axis circular

Synchronous encoder input, command generation

axis, cam, phase compensation, cam auto-generation

buffer memory assignment for 4 axes)

QD77MS

interpolation

Positioning control, path control (linear, arc, and helical), speed control, speed-torque control, synchronous

: Items that differ from RD78G

Comparison with the Motion Module (Simple Motion Mode)

Specifications RD77MS

2, 4, 8, 16 axes

[µs] 444, 888, 1777, 3555

Linear interpolation (up to 4 axes), 2-axis circular

control, continuous operation to torque control

Stroke ratio data format, coordinate data format

Synchronous encoder input, cam, phase

compensation, cam auto-generation

Cam auto-generation for rotary knife

Trapezoidal acceleration/deceleration, S-curve acceleration/deceleration

Backlash compensation, electronic gear, near pass function

interpolation, helical interpolation

Simple Motion module specifications (RD77MS/QD77MS)

Maximum number of control axes

Acceleration/deceleration process

Cam data

Maximum number of cam registrations (Note 1)

Cam auto-generation

Acceleration/deceleration time change Provided

Mark detection signal

Mark detection setting

Torque limit change

Other

Target position change M-code output function

functions Skip function

Mark detection function

Automatic return

Step function

Parameter initialization function External input signal select function

Optional data monitor function

Digital oscilloscope function

Operation cycle

Control method

Cam

control

(operation cycle setting)

Compensation function

Synchronous control

Interpolation function

Cam auto-generation	an auto-generation for rotary killie				
Positioning control method	Motion profile table	otion profile table			
Control unit	mm, inch, degree, pulse		VIOIOIO		
Number of positioning data	600 data (positioning data No. 1 to 600)/axis (Can be set with MELSOFT GX Works3 or a sequence program (No. 1 to 100))	600 data (positioning data No. 1 to 600)/axis (Can be set with MELSOFT GX Works2 or a sequence program (QD77MS16 (No. 1 to 100), QD77MS2/QD77MS4 (No. 1 to 600))	7		
Backup	Parameters, positioning data, and block start data can	be saved on flash ROM (batteryless backup)	MOLO		
Home position return	Proximity dog method, count method 1, count method 2, data set method, scale home position signal detection method, driver home position return (Note 2)	Proximity dog method, count method 1, count method 2, data set method, scale home position signal detection method	010		
Positioning control	Linear interpolation control (Up to 4 axes (Note 3) (vector speed, reference axis speed)), fixed-pitch feed control (up to 4 axes), 2-axis circular interpolation (auxiliary point-specified, central point-specified), helical interpolation control, speed control (up to 4 axes), speed-position switching control (INC mode, ABS mode), position-speed switching control (INC mode), current value change (positioning data, start No. for a current value changing) NOP instruction, JUMP instruction (conditional, unconditional), LOOP, LEND, high-level positioning control (block start, condition start, wait start, simultaneous start, repeated start)				
Manual control	JOG operation, inching operation, manual pulse generator operation (up to 1 module (incremental), unit magnification (1 to 10000 times), via an internal interface)				
Speed-torque control	Speed control not including position loop, torque contr	Speed control not including position loop, torque control, continuous operation to torque control			
Absolute position system	Supported when a battery is mounted on a servo amp	lifier	=		
Synchronous encoder operation function	Up to 4 channels Via an internal interface, a CPU (buffer memory), or a servo amplifier				
Speed limit	Speed limit value, JOG speed limit value				
Torque limit function	Torque limit value same setting, torque limit value individual setting				
Forced stop	Via an internal interface or a buffer memory, valid/invalid setting				
Software stroke limit function	Movable range check with feed current value or with machine feed value				
Hardware stroke limit function	Provided				
Speed change	Provided				
Override [%]	0 to 300	1 to 300			
	I				

Speed to a target position address and a target position is changeable

Via an internal interface, a CPU (buffer memory), or a servo amplifier

Connect/disconnect function of SSCNET communication

Bit data: 16 channels, word data: 16 channels (Note 4)

Continuous detection mode, specified number of detections mode, ring buffer mode

4 (2 points for QD77MS2)

(For QD77MS4,QD77MS2,

16 (4 settings for QD77MS4/QD77MS2)

Bit data: 16 channels, word data: 16 channels (Note 4)

Bit data: 8 channels, word data: 4 channels)

1. The number of cam registrations depends on the memory capacity, cam resolution, and number of coordinates.

Up to 4 points/axis

WITH mode/AFTER mode

Deceleration unit step, data No. unit step

Via a CPU or an external command signal

2. The home position return method set in a driver (servo amplifier) is used.

20

3. 4-axis linear interpolation control is enabled only at the reference axis speed.

Provided

4. Eight channels of each word data and bit data can be displayed in real time.

Comparison with the Motion Module (Simple Motion Mode)

	•	0 '" '					
Item		Specifications FX5-40SSC-G	FX5-80SSC-G	FX5-40SSC-S	FX5-80SSC-S		
Mavimum	n number of control axes	4 axes	8 axes	4 axes	8 axes		
Operation	o cycle	500, 1000, 2000, 4000					
	ion function	Linear interpolation (up	o to 4 axes), 2-axis circula	ar interpolation			
Control m	nethod		th control (linear and arc)		orque control, synchronous control,		
Accelerat	ion/docalaration process		<u>'</u>	and a ration /danalaration			
	ion/deceleration process	· ·	on/deceleration, S-curve		П		
	ation function ous control		on, electronic gear, near p		managina com suta ganaration		
Synchion	Maximum number of	Synchronous encoder	input, command generali	The second secon	mpensation, cam auto-generation		
Cam	cam registrations (Note 1)	128		64	128		
control	Cam data		at, coordinate data format				
	Cam auto-generation	Cam auto-generation t	for rotary knife				
	ng control method	Motion profile table					
Control u	nit	mm, inch, degree, puls					
Number o	of positioning data	600 data (positioning of Can be set with MELS	data No. 1 to 600)/axis SOFT GX Works3 or a se	quence program (No. 1	to 100))		
Backup		Parameters, positionin	g data, and block start da	ta can be saved on flas	h ROM (batteryless backup)		
Home pos	sition return	Driver home position r	eturn ^(Note 2)		I, count method 1, count method 2, e home position signal detection position return (Note 2)		
Positionin	ng control	control (up to 4 axes), control (up to 4 axes), control (INC mode), cu NOP instruction, JUMI	2-axis circular interpolation speed-position switching arrent value change (position)	on (auxiliary point-specificontrol (INC mode, ABS ioning data, start No. for unconditional), LOOP, L	e axis speed)), fixed-pitch feed ied, central point-specified), speed 5 mode), position-speed switching r a current value changing) END, high-level positioning control		
Manual control				ng operation, manual pulse generator dule (incremental), unit magnification a an internal interface)			
Speed-to	rque control	Speed control not including position loop, torque control, continuous operation to torque control		eration to torque control			
Absolute	position system	Provided		Supported when a bat	ttery is mounted on a servo amplifier		
Synchron function	ous encoder operation	Up to 4 modules (via a	CPU or a servo amplifie	Up to 4 modules (via a	an internal interface or a CPU)		
Speed limit		Speed limit value, JOG speed limit value					
Torque lin	nit function	Torque limit value same setting, torque limit value individual setting					
Forced st		Via a buffer memory, valid/invalid setting					
Software	stroke limit function	Movable range check with feed current value or with machine feed value					
Hardware	stroke limit function	Provided					
Speed ch	ange	Provided					
Override		1 to 300 [%]					
Acceleration	on/deceleration time change						
	nit change	Provided					
	sition change	Speed to a target position address and a target position is changeable.					
	utput function	WITH mode/AFTER mode					
Other	Step function	Deceleration unit step, data No. unit step					
	Skip function	Via a CPU or an external command signal					
Parameter initialization function		Provided Provided					
External input signal select function		Via a CPU or a servo amplifier					
	ection function		mode, specified number of	of detections mode, ring	buffer mode		
	Mark detection signal		xes of the connected serv				
	Mark detection setting	16 settings					
Optional o	data monitor function	Up to 4 points/axis					
Automatic	return	Provided		Connect/disconnect fu	unction of SSCNET communication		
Digital os	cilloscope function	Bit data: 16 channels,	word data: 16 channels (N	ote 4)			

 The number of cam registrations depends on the memory capacity, cam resolution, and number of coordinates.
 The home position return method set in a driver (servo amplifier) is used. Notes:

^{3. 4-}axis linear interpolation control is enabled only at the reference axis speed.

^{4.} Eight channels of each word data and bit data can be displayed in real time.

Synchronous Control Specifications

Synchronous control

ltem -		Number of settable axes					
		RD78G4	RD78G8	RD78G16	FX5-40SSC-G	FX5-80SSC-G	
Servo input axis	[axes/module]	4	8	16	4	8	
Synchronous encoder input ax	kis [axes/module]	4	8	16	4	4	
Command generation axis	[axes/module]	4	8	16	4	8	
Composite main shaft gear	[module/output axis]	1					
Main shaft main input axis	[module/output axis]	1					
Main shaft sub input axis	[module/output axis]	1					
Main shaft gear	[module/output axis]	1					
Main shaft clutch	[module/output axis]	1					
Auxiliary shaft	[module/output axis]	1					
Auxiliary shaft gear	[module/output axis]	1					
Auxiliary shaft clutch	[module/output axis]	1					
Composite auxiliary shaft gear [module/output axis]		1					
Speed change gear	[module/output axis]	1					
Output axis (cam axis)	[axes/module]	4	8	16	4	8	

Cam control

lt a un			Specifications								
Item		RD78G4	RD780	38	RD78G16		FX5-4	FX5-40SSC-G		FX5-80SSC-G	
Memory	Cam storage a	ırea	256 k bytes					128 k	bytes		
capacity	Cam working a	area	1 M bytes								
Maximum nu	mber of registra	tions	256					128			
Comment			Up to 32 characte	rs for e	ach cam c	lata					
Stroke ratio data type	Maximum number of cam registrations	Cam resolution RD78G FX5-SSC-G	256 256 128	512 128 64	1024 64 32	2048 32 16	4096 16 8	8192 8 4	16384 4 2	32768 2 -	
Com data		Stroke ratio	-214.7483648 to 214.7483647 [%]								
Cam data	Coordinate data type	Maximum number of cam registrations	Cam resolution RD78G FX5-SSC-G	128 256 128	256 128 64	512 64 32	1024 32 16	2048 16 8	4096 8 4	8192 4 2	16384
		Coordinate data	Input value: 0 to 2147483647 Output value: -2147483648 to 2147483647								
Cam auto-ge	neration		Cam for rotary kn	ife							

Motion Module (PLCopen® Motion Control FB Mode)

Control specifications

Item		Specifications				
		Motion module				
		RD78GH	RD78G			
Maximum number of control axes		RD78GHV: 128 axes RD78GHW: 256 axes	RD78G4: 4 axes RD78G8: 8 axes RD78G16: 16 axes RD78G32: 32 axes RD78G64: 64 axes			
Maximum nun	nber of connectable stations	120 stations				
Operation cyc (operation cyc	le ele settings) ^(Note 1) [μs]	31.25, 62.5, 125, 250, 500, 1000, 2000, 4000, 8000	62.5, 125, 250, 500, 1000, 2000, 4000, 8000			
		Real drive axis, virtual drive axis, real encoder ax	tis, virtual encoder axis, virtual linked axis			
Axis	Axes group	0: Unset 1 or later: the axes group No. for the setting axis				
	Real drive axis	Servo amplifier				
	Real encoder axis	Via a servo amplifier				
Interpolation f		Linear interpolation (2 to 4 axes), 2-axis circular i	nterpolation			
Control metho	od	Positioning control, direct control				
	deceleration process	Trapezoidal acceleration/deceleration, jerk acceleration fixed method	eration/deceleration, acceleration/deceleration			
Compensation		Driver unit conversion				
Synchronous		Master axis, cam, gear	de admired en en de de la 1911 et 1			
control	Master axis	Real drive axis, virtual drive axis, real encoder ax	kis, virtual encoder axis, virtual linked axis			
Operation profile	Cam data Motion control FB	Cam data, cam for a rotary knife				
(cam data)	(Cam auto-generation)	Cam for a rotary knife Unit character string and decimal digit can be defined by users.				
Control unit		(The following are given units: mm, inch, degree, pulse) PLC CPU: ladder diagram, function block diagram/ladder diagram, structured text language				
Programming	language	Motion module: structured text language				
Backup		Parameters and programs can be saved on a flash ROM (batteryless backup)				
Start/stop ope		Start, stop, restart, buffer mode, forced stop				
Homing	Homing method	Driver homing method (The homing method set in	n the driver is used.)			
Positioning	Linear control	Linear interpolation (2 to 4 axes)	dive an addited almost an intermediation			
control	2-axis circular interpolation	Border point-specified, central point-specified, radius-specified circular interpolation JOG operation				
Manual contro		·				
Direct control	Speed control Torque control	Speed control not including position loop, speed control including position loop Torque control, continuous operation to torque control				
Absolute posit	· ·	Provided (batteryless)				
	Speed limit	Speed command range				
Functions	Torque limit	Torque limit value (positive/negative direction)				
that limit	Forced stop	Valid/Invalid setting				
control	Software stroke limit	Movable range check with an address of the set	position or the feed machine position.			
	Hardware stroke limit	Provided				
	Command speed change	Provided				
	Current value change	Provided				
Functions that change	Acceleration/deceleration process change	Acceleration/deceleration, acceleration/decelerat	ion time			
control details	Torque limit value change	Provided				
ucians	Target position change	Target position change, movement distance char	nge			
	Override	Provided				
	History data	Event history, position data history				
	Logging	Data logging, real-time monitor				
	Slave emulate	Provided				
Other	Touch probe (mark detection)	Provided				
functions	Monitoring of servo data	Cyclic transmission, transient transmission				
	Servo system recorder	Provided				
	Safety communication	Provided				
	Inter-module synchronization	Provided				

Notes: 1. The number of controllable axes varies depending on the operation cycle.

Motion Module (PLCopen® Motion Control FB Mode)

Program specifications

Item		RD78GH RD78G				
Program capacity		Built-in ROM max. 64 [MB] + SD memory card	Built-in ROM max. 16 [MB] + SD memory card			
Maximum pro	gram capacity memory	160 [MB]	96 [MB]			
Variable memory	Label area	ST language program capacity and label memory capacity are settable.				
Data memory		Equivalent to program capacity				
Maximum	Program	512 files (1 program definable per file)				
number of	FB/FUN	128 files (64 FBs/FUNs definable per file)				
files	Global label	1 file (16384000 labels definable per file)				
Code size per program		Depends on the program memory				

Synchronous control specifications

FB	Description
MC_CamIn	Starts cam operation.
MC_GearIn	Starts gear operation.
MC_CombineAxes	Combines the motion of 2 axes.
MCv_ChangeCycle	Changes the current value per cycle.

Notes: 1. The number of usable function blocks depends on the program capacity.

Operation profile (cam) specifications

Item		RD78GH	RD78G			
Memory capacity		Built-in ROM max. 64 [MB] + SD memory card	Built-in ROM max. 16 [MB] + SD memory card			
Maximum nu	mber of cam registration	60000 (1024 out of 60000 can be set on engineer	ing tool)			
	Cam type	Cam data, cam for a rotary knife				
	Interpolation method	Section interpolation, linear interpolation, spline interpolation				
	Profile ID	1 to 60000				
Cam data	Resolution	8 to 65535 (any resolution within the range)				
	Units for cam length per cycle	mm, inch, pulse, degree, or user-defined units				
	Units for stroke	%, mm, inch, pulse, degree, or user-defined units				
Cam auto-ge	eneration	Cam for a rotary knife				

Motion Module (PLCopen® Motion Control FB Mode)

Function blocks (FB) list

Туре	Name	Description
	MC_CamIn	Starts cam operation.
	MC_CombineAxes	Combines the motion of 2 axes.
	MC_GearIn	Starts gear operation.
	MC_GroupStop	Executes a forced stop for an axes group.
	MC_Home	Executes homing.
	MC_MoveAbsolute	Executes positioning (absolute).
	MC_MoveRelative	Executes positioning (relative).
	MC_MoveVelocity	Executes speed control.
	MC_Stop	Executes a forced stop.
MCFB (motion)	MC_TorqueControl	Executes torque control.
Wich B (Hotion)	MCv_BacklashCompensationFilter	Compensates backlash.
	MCv_DirectionFilter	Restricts rotation direction.
	MCv_Jog	Executes JOG operation.
	MCv_MoveCircularInterpolateAbsolute	Executes circular interpolation control (absolute).
	MCv_MoveCircularInterpolateRelative	Executes circular interpolation control (relative).
	MCv_MoveLinearInterpolateAbsolute	Executes linear interpolation control (absolute).
	MCv_MoveLinearInterpolateRelative	Executes linear interpolation control (relative).
	MCv_SmoothingFilter	Enables smoothing filter.
	MCv_SpeedControl	Executes speed control (including position loop).
	MCv_SpeedLimitFilter	Enables speed limit filter.
	MC_CamTableSelect	Selects cam tables.
	MC_GroupDisable	Disables an axes group.
	MC_GroupEnable	Enables an axes group.
	MC_GroupReset	Resets an axes group error.
	MC_GroupSetOverride	Sets the values of override for an axes group.
	MC_Power	Controls the power stage (ON or OFF) for a single axis.
	MC_Reset	Resets an axis error.
	MC_SetOverride	Sets the values of override.
MCFB (administrative)	MC_SetPosition	Changes the current position.
	MC_TouchProbe	Enables the touch probe.
	MC_AbortTrigger	Disables the touch probe.
	MC_ReadParameter	Reads parameters.
	MC_WriteParameter	Writes parameters.
	MCv_AllPower	Controls the power stage (ON or OFF) for all axes.
	MCv_ChangeCycle	Changes the current value per cycle.
	MCv_MotionErrorReset	Resets motion errors.
	MCv_SetTorqueLimit	Sets torque limits.
General FB	MCv_ReadProfileData	Reads profile data.
General FD	MCv_WriteProfileData	Writes profile data.

Motion Module (PLCopen® Motion Control FB Mode) (Simple Motion Mode)

CC-Link IE TSN

	Motion module				
Item	PLCopen® motion control FB mode	Simple Motion mode			
	RD78GH/RD78G	RD78G	FX5-40SSC-G	FX5-80SSC-G	
Communications speed [bps]	1 G/100 M (Note 1)		1 G		
Maximum number of connectable stations per network	121 stations (including	ng the master station)		25 stations (including the master and eight motion control stations)	
Connection cable	Ethernet cable (cate	gory 5e or higher, do	uble shielded/STP) strai	ght cable	
Maximum distance between stations [m]	100				
Maximum number of networks	239				
Topology (Note 2)	Line, star, line/star n	nixed topologies			
Communications method	Time-sharing metho	d			
Maximum transient transmission capacity	1920 bytes				
Maximum link points per network	Maximum link points per network				
RX/RY	-	16K points	8K points		
RWr/RWw	-	8K points	1K points		
Maximum link points per station					
RX/RY	-	16K points	8K points		
RWr/RWw	-	8K points	1K points		
Safety communications					
Maximum number of safety connections per station	120 connections		-		
Maximum number of link points per safety connection	8 words (input: 8 wo	rds, output: 8 words)	-		
Notes: 1. A 1 Gbps device and a 100 Mbps device cannot be used	on the same network.			-	

Notes: 1. A 1 Gbps device and a 100 Mbps device cannot be used on the same network

2. Use a switching hub (certified class: B) for star topology.


[Note when connecting devices]

Connect class A remote stations after class B remote stations.

Certified Class

CC-Link IE TSN certifies nodes and switches to a specific class level according to its functionality and performance classification. Products can be classified as either class A or B. For the certified classification of each product, please check the CC-Link partner association website or the relevant product catalog or manual. Supported functions and system configuration may differ according to the certified class of products used. For example, products compatible with certified class B are necessary to configure a high-speed motion control system. For details of configuring systems with both class A and class B devices, please refer to relevant master product manual.

System configuration



- Synchronous accuracy of a system varies relative to the combination of connected devices and switches certification class
- Use class B Ethernet switch when configuring a star topology with class B devices
- Use class B devices when configuring a system within ±1 µs high-accuracy synchronization, connect class A devices to a separate branch line from class B devices (for details of system configuration, please refer to relevant master product manual)

Motion Module

Module specifications RD78GH/RD78G

Item	RD78GH	RD78G	
Maximum number of control axes	RD78GHV: 128 axes RD78GHW: 256 axes	RD78G4: 4 axes RD78G8: 8 axes RD78G16: 16 axes RD78G32: 32 axes RD78G64: 64 axes	
Maximum number of connectable stations	121 stations (including the master station)		
Servo amplifier connection method	CC-Link IE TSN		
CC-Link IE TSN certified class	В		
Maximum distance between stations [m]	100		
PERIPHERAL I/F	Via a CPU module (USB, Ethernet)		
Extended memory	SD memory card		
Number of ports for CC-Link IE TSN	2 ports	1 port	
Number of I/O points occupied	48 points (I/O assignment: 16 points (empty slot) + 32 points)	32 points	
Number of slots occupied	2 slots	1 slot	
5 V DC internal current consumption [A]	2.33	1.93	
Mass [kg]	0.44	0.26	
Dimensions [mm]	106.0 (H) × 56.0 (W) × 110.0 (D)	106.0 (H) × 27.8 (W) × 110.0 (D)	

Module specifications FX5-40SSC-G/FX5-80SSC-G

Item	FX5-40SSC-G	FX5-80SSC-G
Maximum number of control axes	4 axes	8 axes
Maximum number of connectable stations	21 stations (including the master and four motion control stations)	25 stations (including the master and eight motion control stations)
Servo amplifier connection method	CC-Link IE TSN	
CC-Link IE TSN certified class	В	
Maximum distance between stations [m]	100	
24 V DC external current consumption [A]	0.24	
Mass [kg]	0.3	
Dimensions [mm]	90 (H) × 50 (W) × 83 (D)	
Applicable CPU (Note 1)	FX5U, FX5UC (Note 2)	

Notes: 1. Use a CPU module with firmware version 1.230 or later.

The following CPU modules can be updated to that firmware version.

• CPU module with serial No. 17X**** or later

■Products on the Market

Manual Pulse Generator

Mitsubishi Electric has confirmed the operation of the following manual pulse generator. Contact the manufacturer for details.

	·		
Product name	Model	Description	Manufacturer
Manual pulse generator (Note 1)	RE46A2CCD2B	Number of pulses per revolution: 25 pulses/rev (100 pulses/rev after magnification by 4)	Tokyo Sokuteikizai Co.,Ltd.

Notes: 1. Connect the manual pulse generator to a CPU module or a high-speed pulse input/output module. Refer to user's manuals and each product manual for details.


[•] FX5UC-32MT/DS-TS and FX5UC-32MT/DSS-TS with serial No. 178**** or later.

^{2.} FX5-CNV-IFC is required to connect the Motion module to an FX5UC CPU module.

Motion Module

Dimensions


RD78G4/RD78G8/RD78G16/ RD78G32/RD78G64





[Unit: mm]


●RD78GHV/RD78GHW




[Unit: mm]


Dimensions

●FX5-40SSC-G







●FX5-80SSC-G



Mounting

RD78G4/RD78G8/RD78G16/RD78G32/RD78G64 RD78GHV/RD78GHW





Notes: 1. Provide clearance of 30 mm or more when the height of a wiring duct is 50 mm or less. In other cases, provide clearance of 40 mm or more.

2. Provide clearance of 20 mm or more when an extension cable is connected/removed without removing a power supply module.

Engineering Software

MELSOFT GX Works3 operating environment (Note 1)

Item	Description
	Microsoft® Windows® 10 (Home, Pro, Enterprise, Education, IoT Enterprise 2016 LTSB (Note 2)) (64 bit/32 bit)
OS	Microsoft® Windows® 8.1 (64 bit/32 bit), Microsoft® Windows® 8.1 (Enterprise, Pro) (64 bit/32 bit)
	Microsoft® Windows® 7 (Enterprise, Ultimate, Professional, Home Premium) (64 bit/32 bit)
Personal computer	Windows® supported personal computer
CPU	Intel® Core™2 Duo Processor 2 GHz or more recommended
Required memory	For 64-bit edition: 2 GB or more recommended
	For 32-bit edition: 1 GB or more recommended
Free hard disk space	For installation: 17 GB or more free hard disk capacity
	For operation: 512 MB or more free virtual memory capacity
Optical drive	DVD-ROM supported disk drive
Monitor	Resolution 1024 × 768 pixels or higher

Notes: 1. Refer to Installation Instructions for precautions and restrictions regarding the operating environment.

Engineering software list

Item	Model	Description	
MELSOFT GX Works3	SW1DND-GXW3-E	Programmable Controller Engineering Software [MELSOFT GX Works3 (Note 1), GX Works2, GX Developer, PX Developer] MITSUBISHI ELECTRIC FA Library	DVD-ROM
MELSOFT iQ Works	SW2DND-IQWK-E	FA engineering software (Note 2) • System Management Software [MELSOFT Navigator] • Programmable Controller Engineering Software [MELSOFT GX Works3 (Note 1), GX Works2, GX Developer, PX Developer] • Motion Controller Engineering Software [MELSOFT MT Works2] • Screen Design Software [MELSOFT GT Works3] • Robot Programming Software [MELSOFT RT ToolBox3 (Note 3)] • Inverter Setup Software [MELSOFT FR Configurator2] • MITSUBISHI ELECTRIC FA Library	DVD-ROM

Notes: 1. The MELSOFT GX Works3 menu is switchable between Japanese, English, and simplified Chinese.

^{2.} The 32-bit edition is not supported.

^{2.} Refer to each product manual for the software supported by the model.
3. RT ToolBox3 mini (simplified version) will be installed if iQ Works product ID is used. When RT ToolBox3 (with simulation function) is required, please purchase RT ToolBox3 product ID.

Motion Control Software

Control specifications

			- 7
Item		Specifications	-
Maximum number of control axes (Note 1)		16, 32, 64, 128 axes	
Communication cy	ycle (operation cycle settings) [µs]	125, 250, 500, 1000, 2000, 4000, 8000	
Network		CC-Link IE TSN	
CC-Link IE TSN	certified class	В	
Communication	specifications	Mixture of hot connect, SDO communication, and TCP/IP communication	
Development en	wironmont	Microsoft® Visual Studio® 2017, 2019	
Development en	viionnent	• Programming languages supported by API library: C/C++, .NET (C#, VB.NET, etc.)	
	Control method	Position, speed, torque	
	Positioning	Up to 128 axes simultaneously (absolute value command, relative value command) Override is possible	
	Acceleration/deceleration processing	Trapezoidal, S-curve, jerk ratio, parabolic, sine, time acceleration trapezoidal, etc. (24 types in total)	
	Interpolation	2- to 4-axis linear interpolation, 2-axis/3-axis circular interpolation, 3-axis helical interpolation, PVT	
	Continuous path	Combination of linear and circular interpolation, spline interpolation, pre-read speed automatic control, linear/circular continuous path with rotation stage	
Functions	JOG operation	Provided	
	Real-time control	Event, triggered motion, position synchronous output	
	Synchronous control	Simple synchronization, synchronous gear ratio, synchronous phase offset, synchronous compensation, dynamic establishment/cancellation of synchronization, multiple pairs (up to 64 pairs) of synchronization between 1 axis and multiple axes (synchronous group)	
	Electronic cam	Cam curves of eight systems can be defined, cam curve per communication cycle, phase operation, clutch	
	Home position return (Note 2)	Home position return using the Z-phase, home position sensor, limit sensor, limit proximity sensor, external input signal, mechanical end, and gantry axis can be performed.	
	I/O size	Input: 8000 bytes, output: 8000 bytes	
	Compensation function	Backlash/pitch error compensation, plane strain (straightness) compensation	
	Auxiliary function	Touch probe, logging	
Notes: 1 The mayir	mum number of control avec differs ar	mong the LISB keys for Motion Control Software	

Notes: 1. The maximum number of control axes differs among the USB keys for Motion Control Software.

2. SWM-G does not support the home position return mode of the servo amplifier.

CC-Link IE TSN

Specifications
1 G/100 M (Note 3)
128 stations
Ethernet cable (category 5e or higher, double shielded/STP) straight cable
100
Line, star, line/star mixed topologies
Time-sharing method
1920 bytes

Notes: 3. A 1 Gbps device and a 100 Mbps device cannot be used on the same network.

4. Use a switching hub (certified class: B) for star topology.

Operating environment

Item	Specifications
Personal computer	Microsoft® Windows® supported personal computer
OS	Microsoft® Windows® 10 (Home, Pro, Enterprise, Education, IoT Enterprise LTSC (Note 5)) (64-bit)
CPU	Intel® Atom™ 2 GHz, 2Core or higher is recommended
Memory	4 GB or more
Free hard disk space	For installation: 5 GB or more
Network interface	Intel® I210 (Vendor ID: 0x8086, Device ID: 0X1533)
(recommended network interface cards)	Intel® I350 (Vendor ID: 0x8086, Device ID: 0X1521)
	Intel® I211-AT (Vendor ID: 0x8086, Device ID: 0X1539)

Notes: 5. Windows® 10 IoT Enterprise LTSC is recommended.

Product list

Product name	Model	Applications	
Motion Control	SW1DNN-SWMG-M	SWM-G Engine SWM-G Operating Station Network API	
Software (Note 6)	3WTDINN-3WING-IN	• SWM-G API • CC-Link IE TSN Configurator • Real Time OS (RTX64)	
	MR-SWMG16-U	Maximum number of control axes: 16 axes, USB key (license)	
USB key for Motion Control	MR-SWMG32-U	Maximum number of control axes: 32 axes, USB key (license)	
Software	MR-SWMG64-U	Maximum number of control axes: 64 axes, USB key (license)	
	MR-SWMG128-U	laximum number of control axes: 128 axes, USB key (license)	

API Library

Simpler programming by using a dedicated library suite for access to Motion Control Software.

■ Main functions of API library

Class	Function	Description
	StartEngine	Starts SWM-G engine.
	StopEngine	Stops SWM-G engine.
CCCAni	CreateDevice	Create a device to interface with the SWM-G engine.
SSCApi	CloseDevice	Closes a device.
	StartCommunication	Starts communication with the servo network.
	StopCommunication	Stops communication with the servo network.
CoreMotion	GetStatus	Reads the current system status from SWM-G engine.
	SetServoOn	Executes servo on or servo off.
	SetAxisCommandMode	Sets the command mode of the axis.
	GetAxisCommandMode	Obtains the command mode of the axis.
AxisControl	GetPosCommand	Obtains the commanded position of the axis.
	GetPosFeedback	Obtains the feedback position of the axis.
	GetVelCommand	Obtains the commanded velocity of the axis.
	GetVelFeedback	Obtains the feedback velocity of the axis.
	SetParam	Sets the system parameters.
	GetParam	Obtains the system parameters.
Config	SetAxisParam	Sets the axis parameters.
Coming	GetAxisParam	Obtains the axis parameters.
	Export	Exports the system and axis parameters to xml file.
	Import	Imports the system and axis parameters from xml file.
Home	StartHome	Starts home position return.
Tiomo	SetCommandPos	Sets the commanded position to a specified value.
	StartPos	Executes positioning (absolute position).
	StartMov	Executes positioning (relative position).
	StartLinearIntplPos	Starts linear interpolation (absolute position).
	StartLinearIntplMov	Starts linear interpolation (relative position).
	StartCircularIntplPos	Starts circular interpolation (absolute position).
	StartCircularIntplMov	Starts circular interpolation (relative position).
	StartHelicalIntplPos	Starts helical interpolation (absolute position).
	StartHelicalIntplMov	Starts helical interpolation (relative position).
	StartJog	Starts JOG operation.
Motion	Stop	Decelerates the axis to stop.
	ExecQuickStop	Decelerates the axis to stop with Quick Stop Dec parameter.
	ExecTimedStop	Decelerates the axis to stop with the specified time.
	Wait	Executes the blocking wait command.
	Pause	Pauses the positioning operation.
	Resume	Restarts the paused positioning operation.
	OverridePos	Overrides the target position (absolute position) during positioning operation.
	OverrideMov	Overrides the target position (relative position) during positioning operation.
	OverrideProfile	Overrides the velocity pattern during positioning, JOG operation, and speed control.
	StopJogAtPos	Decelerates the axis in JOG operation to stop at the specified position.

Class	Function	Description	
Cuma	SetSyncMasterSlave	Establishes synchronization between the master and slave axes.	
Sync	ResolveSync	Cancels synchronization of the specified slave axes.	g
Velocity	StartVel	Starts speed control.	Contro
	Stop	Stops speed control.	ollers
T	StartTrq	Starts torque control.	\cdot
Torque	StopTrq	Stops torque control.	_
	CreatePathIntplBuffer	Assigns the buffer memory for path interpolation to an axis.	
	FreePathIntplBuffer	Frees up the buffer memory for path interpolation.	
A al. () A a & a	StartPathIntplPos	Starts path control (absolute position).	
AdvMotion	StartPathIntplMov	Starts path control (relative position).	
	StartPathIntpl3DPos	Starts 3D path interpolation (absolute position).	
	StartPathIntpl3DMov	Starts 3D path interpolation (relative position).	
A 1 0	StartECAM	Starts E-CAM control.	_
AdvSync	StopECAM	Stops E-CAM control.	NO
	SetEvent	Sets an event.	Motors
	SetSoftwareTouchProbe	Sets the parameter of the software touch probe channel.	_
	GetSoftwareTouchProbeStatus	Obtains the parameters and the current status of software touch probe.	_
Event	SetHardwareTouchProbe	Sets the parameters of hardware touch probe.	_
	GetHardwareTouchProbeStatus	Obtains the parameters and the current status of hardware touch probe.	
	StartPSO	Starts the position synchronous output channel.	Motors
	SetOutBit	Sets the output bit values.	- Sic
	SetOutByte	Sets the output byte values.	_
	SetOutAnalogDataShort	Sets two-byte output data.	
lo	GetInBit	Obtains the input bit values.	_
	GetInByte	Obtains the input byte values.	_ <
	GetInAnalogDataShort	Obtains two-byte input data.	Motors
	SetMBit	Sets the user memory bit values.	— v
	SetMByte	Sets the user memory byte values.	_
	SetMAnalogDataShort	Sets two-byte user memory data.	
UserMemory	GetMBit	Obtains the user memory bit value.	— п
	GetMByte	Obtains the user memory byte value.	— du
	GetMAnalogDataShort	Obtains two-byte user memory data.	Equipment
	StartLog	Starts logging data.	— ₌
Log	StopLog	Stops logging data.	_
Ŭ	SetLog	Specifies the data to be collected by logging operation.	_
	StartHotconnect	Starts the hot connect.	_
	SdoDownload	Downloads the specified SDO data.	_
	SdoUpload	Uploads the specified SDO data.	_
CCLink	SetAxisMode	Sets the control mode of the specified slave axis.	-
	StartAxisHM	Starts HM mode control of the specified slave axis.	
	SImpSendBySlaveId	Transmits SLMP to the specified slave axis.	_

MEMO

3 Servo Amplifiers

Model Designation	3-2
MR-J5-G_ Connections with Peripheral Equipment	3-5
MR-J5-G_ Specifications	3-6
MR-J5-G_ Standard Wiring Diagram Example	3-9
Functional Safety I/O Signal Connector (CN8) Connection Example	3-10
Main/Control Circuit Power Supply Connection Example	3-11
Servo Motor Connection Example (for MR-J5-G(-N1)/MR-J5-A)	3-13
Encoder Connection Specifications	3-18
Servo Motor Connection Example (for MR-J5-G-RJ/MR-J5-G-RJN1/MR-J5-A-RJ)	3-19
MR-J5-G_ Dimensions	
MR-J5W_ Connections with Peripheral Equipment	3-27
MR-J5W_ Specifications	3-28
MR-J5W_ Standard Wiring Diagram Example	3-30
Main/Control Circuit Power Supply Connection Example	3-32
Servo Motor Connection Example	3-33
Encoder Connection Specifications	3-34
MR-J5W_ Dimensions	3-39
MR-J5D_ Connections with Peripheral Equipment	
MR-J5D_ Specifications	3-42
MR-J5D_ Standard Wiring Diagram Example	3-45
Main/Control Circuit Power Supply Connection Example	3-48
Servo Motor Connection Example	3-49
Encoder Connection Specifications	3-50
MR-J5D_ Dimensions	3-54
Positioning Function	3-58
Restrictions	3-60
MR-J5-A_ Connections with Peripheral Equipment	3-61
MR-J5-A_ Specifications	
MR-J5-A_ Standard Wiring Diagram Example	
MR-J5-A_ Dimensions	3-68
MR-CM3K Specifications	3-72
MR-CM3K Wiring Diagram Example	
MR-CM3K Dimensions	
MR-CV_ Specifications	3-75
MR-CV_ Dimensions	
Selection of Converter Unit, Servo Amplifier, and Drive Unit	3-78

G MR-J5-G(-N1) G-RJ MR-J5-G-RJ(N1) WG MR-J5W2-G(-N1)/MR-J5W3-G(-N1)


DG MR-J5D1-G4(-N1)/MR-J5D2-G4(-N1)/MR-J5D3-G4(-N1) A MR-J5-A A-RJ MR-J5-A-RJ


^{*} Refer to p. 7-70 in this catalog for conversion of units.

^{*} In this section, a term of servo amplifier includes a combination of a drive unit and a converter unit.

Model Designation for 1-Axis Servo Amplifier (Note 1)

G G-RJ





Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.


2. For the servo amplifier firmware version compatible with each function, refer to "MR-J5 User's Manual".

^{3.} A dynamic brake which is built in the 7 kW or smaller servo amplifiers is removed. When the servo amplifiers without the dynamic brake are used, the servo motors coast to a stop and do not stop immediately at alarm occurrence or power failure. Take measures to ensure safety on the entire system. Refer to "MR-J5 User's Manual" for details.

^{4.} For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.


Model Designation for Multi-Axis Servo Amplifier (Note 1)

WG



Model Designation for Drive Unit (Note 1)

DG



Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

- 2. A-axis, B-axis, and C-axis indicate names of axes of the multi-axis servo amplifier. The C-axis is available for the 3-axis servo amplifier.
- 3. Dynamic brakes which are built in servo amplifiers or drive units is removed. When the servo amplifiers or drive units without the dynamic brakes are used, the servo motors coast to a stop and do not stop immediately at alarm occurrence or power failure. Take measures to ensure safety on the entire system. Refer to "MR-J5 User's Manual" or "MR-J5D User's Manual" for details.

7

700


7

- 4. MR-J5D1-G4(-N1) supports fully closed loop control four-wire type input and the load-side encoder A/B/Z-phase input as standard.
- 5. A-axis, B-axis, and C-axis indicate names of axes of the multi-axis drive unit. The B-axis is available for the 2-axis drive unit and the 3-axis drive unit. The C-axis is available for the 3-axis drive unit.

Servo Amplifiers


Model Designation for Simple Converter





Model Designation for Power Regeneration Converter Unit


DG



MR-J5-G_ Connections with Peripheral Equipment (Note 1)

G G-RJ

Peripheral equipment is connected to MR-J5-G_ as described below. Connectors, cables, options, and other necessary equipment are available so that users can set up the servo amplifier easily and start using it right away.



Notes: 1. The connection with the peripheral equipment is an example for MR-J5-350G(4)(-RJ(N1)) or smaller servo amplifiers. Refer to "MR-J5 User's Manual" for the actual connections.

- 2. This picture shows when the display cover is open.
- 3. For specifications of the Ethernet cable, refer to "Ethernet Cable Specifications" on p. 7-34 in this catalog.
- 4. This picture is an example for MR-J5-10G.

Servo an	-	lel MR-	-J5(-(RJ)(N1))		20G	40G	60G	70G	100G	200G	350G	500G	700G
Output	Voltage			- 1		C to 240							
	Rated cu	rrent	[A]	1.3	1.8	2.8	3.2	5.8	6.0	11.0	17.0	28.0	37.0
	Voltage/ frequency	y ^(Note 1)	AC input	240 V AC, 50 Hz/60 Hz		3-phase or 1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz (Note 7)		3-phase 200 V AC to 240 V AC, 50 Hz/60 Hz					
Main			DC input (Note 8)	283 V [OC to 3	40 V DC							
circuit	Rated cu	Rated current (Note 6) [A]		0.9	1.5	2.6	3.2	3.8	5.0	10.5	16.0	21.7	28.9
power supply input	Permissible voltage		AC input DC input (Note 8)	264 V A	AC	ohase 170	0 V AC	to		r 1-phase 170 64 V AC (Note 7)	3-phase 17	70 V AC to	264 V AC
	fluctuatio			241 V DC to 374 V DC									
	Permissible frequency fluctuation			±5 % m	naximur	m							
	Voltage/	Voltage/ AC input frequency DC input		1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz									
Control	Rated cu	rrent	· · · · · · · · · · · · · · · · · · ·	0.2									
circuit	Permissil	ble	AC input		e 170 V	/ AC to 20	64 V AC	;				_	
power supply	voltage	_	DC input (Note 8)	241 V [C to 3	74 V DC							
input	fluctuatio		· · · · · · · · · · · · · · · · · · ·										
	fluctuatio		,,	±5 % m	naximur	n							
	Power co	nsump	otion [W]	30									
nterface	power sup	ply		24 V DC ± 10 % (required current capacity: 0.3 A (including CN8 connector signals))									
Control n				Sine-wave PWM control/current control method									
Permissible regenerative power of the built-in regenerative resistor $^{(\text{Note 2, 3})}$ [W]			-	10			30		100		130	170	
Dynamic	brake (Note 4	1)		Built-in Built-in									
CC-Link IE TSN (Note 13) (MR-J5-G(-RJ))			31.25 μs, 62.5 μs, 125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms										
· 			ed class	Class B									
EtherCAT® Communication cycle (MR-J5-G-(RJ)N1) (Note 10, 12)			125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms										
CC-Link IE Field Network Basic (Note 5, 14, 15) (MR-J5-G(-RJ))			Supported										
Commun function		USB		Connect a personal computer (MR Configurator2 compatible)									
	output puls	se		Compatible (A/B/Z-phase pulse)									
Analog m		. 5 40		2 channels									
	ng mode (No		- C(NA)	Point table method									
-ully clos control ^{(No}	sed loop			Two-wire type communication method									
		MR-J5-G-RJ(N1) der MR-J5-G(-N1)		Two-wire/four-wire type communication method Mitsubishi Electric high-speed serial communication									
_oaa-sia nterface	i i			Mitsubishi Electric high-speed serial communication, A/B/Z-phase differential input signal									
interface MR-J5-G-RJ(N1) Servo functions			Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (includin failure prediction), power monitoring function, lost motion compensation function, scale measurement function (Note 5, 12), super trace control (Note 5), continuous operation to torque control mode (Note 5, 12, 16)										
Protective functions			Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection										
Safety su	ub-function	Safety	y performance	Refer to	s "Safe	ty Sub-Fi	unctions	on pp	. 1-10 and 1	-11 in this cata	alog.	T-	
Structure	e (IP rating)			Natural cooling, open (IP20) Force cooling, open (IP20) Force cooling, open (IP20) (IP20) (Note 9)									
Close			supply input	Possibl					T				
mounting	g 1-phase	power	supply input	Possibl	e (Note 11))	4.0		Not possil		<u> -</u>	0.7	0.0
Mass			[kg]	0.8			1.0	1.4		2.2		3.7	6.2

Servo Amplifiers

- Notes: 1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.

 2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.

 - 3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
 - 4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.
 - 5. For the servo amplifier firmware version compatible with this function, refer to "MR-J5 User's Manual".

 - 6. This value is applicable when a 3-phase power supply is used.
 7. When a 1-phase 200 V AC to 240 V AC power supply is used, use the servo amplifiers at 75 % or less of the effective load ratio.
 - 8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".
 - 9. The connector part is excluded.
 - 10. The command communication cycle depends on the controller specifications and the number of slaves connected.
 - 11. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio.
 - 12. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 - A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 μs.
 CC-Link IE Field Network Basic is also supported. For details, refer to "MR-J5 User's Manual".

 - 15. For the restrictions on the communication cycle of CC-Link IE Field Network Basic, refer to "MR-J5 User's Manual".
 - 16. The continuous operation to torque control mode is not available with MR-J5-G-(RJ)N1.

MR-J5-G_ (Network Compatible) Specifications (400 V)

G G-RJ

WII 1-03	- G_ (140	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	K Compath	ole) Specifications	3 (400 V)		a and			
Servo an	nplifier mo	del MR	-J5(-(RJ)(N1))	60G4	100G4	200G4	350G4			
Output Voltage				3-phase 0 V AC to 480 V	AC					
Output	Rated cu	urrent	[A]	1.6	2.8	5.5	8.6			
NA - i		Voltage/ frequency (Note 1) AC input		3-phase 380 V AC to 480 V AC, 50 Hz/60 Hz						
Main circuit	Rated cu	Rated current [A		1.4	2.5	5.1	7.9			
power supply input	Permissi voltage fluctuation	ŭ .		3-phase 323 V AC to 528 V AC						
input	Permissible frequency fluctuation		quency	±5 % maximum						
	Voltage/ frequence		AC input	1-phase 380 V AC to 480						
Control	Rated cu	urrent	[A]	0.1						
circuit power supply	Permissi voltage fluctuation		AC input	1-phase 323 V AC to 528	B V AC					
input	Permiss fluctuation		quency	±5 % maximum						
	Power c	onsum	otion [W]	30		-	-			
Interface	power sup	oply		<u> </u>		(including CN8 connector	signals))			
Control n				Sine-wave PWM control	current control method					
Permissible regenerative power of the built-in regenerative resistor (Note 2, 3) [W]			oower of sistor (Note 2, 3) [W]	15	15	100	120			
Dynamic brake (Note 4)				Built-in						
CC-Link IE TSN (Note 7) (Note 5, 6) (MR-J5-G4(-RJ))		31.25 μs, 62.5 μs, 125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms								
<u> </u>	Certified class		Class B							
EtherCAT® Communication cycle (MR-J5-G4-(RJ)N1) (Note 5, 6)				125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms						
CC-Link IE Field Network Basic (Note 8, 9, 10) (MR-J5-G4(-RJ))			Basic (Note 8, 9, 10)	Supported						
Communication function USB		Connect a personal computer (MR Configurator2 compatible)								
	output pul	se		Compatible (A/B/Z-phase pulse)						
Analog m				2 channels						
Positioning mode (Note 6, 9)				Point table method						
Fully closed loop MR-J5-G4(-N1)		. ,	Two-wire type communication method							
control (No		MR-J5-G4-RJ(N1)		Two-wire/four-wire type communication method						
Load-side encoder MR-J5-G4(-N1)				Mitsubishi Electric high-speed serial communication						
interface		MR-J5	5-G4-RJ(N1)	Mitsubishi Electric high-speed serial communication, A/B/Z-phase differential input signal						
Servo functions				Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, scale measurement function (Note 6), super trace control, continuous operation to torque control mode (Note 6, 11)						
Protective functions				Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection						
Safety su	ub-function	, Safet	y performance	Refer to "Safety Sub-Functions" on pp. 1-10 and 1-11 in this catalog.						
Structure	e (IP rating)		Natural cooling, open (IF	220)	Force cooling, open (IP2	20)			
Close mo				Not possible						
Mass			[kg]	1.6		2.2	2.3			
mase [ng]										


 Rated output and speed of a rotary servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.
 Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
 Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used. Notes:

- 4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio.
- 5. The command communication cycle depends on the controller specifications and the number of slaves connected.
- 6. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 μs.
 CC-Link IE Field Network Basic is also supported. For details, refer to "MR-J5 User's Manual".
 For the servo amplifier firmware version compatible with this function, refer to "MR-J5 User's Manual".

- 10. For the restrictions on the communication cycle of CC-Link IE Field Network Basic, refer to "MR-J5 User's Manual".
- 11. The continuous operation to torque control mode is not available with MR-J5-G4-(RJ)N1.

MR-J5-G_ Standard Wiring Diagram Example





Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2) Note that the number of the connectable slaves depends on the controller specifications.


- 2. This is for sink wiring. Source wiring is also possible.
- 3. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (Class B) recommended by CC-Link Partner Association. When a switching hub (Class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manual for details.
- Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
 Devices for these pins can be changed with [Pr. PD07], [Pr. PD08], and [Pr. PD09].
- 8. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.
- 9. For MR-J5-G(4)-RJ(N1), this device can be changed to TPR3 (Touch probe 3) with [Pr. PD05]. When TPR3 is set, connect by using a normally open contact switch as the same as TPR1 (Touch probe 1) and TPR2 (Touch probe 2)
- 10. For MR-J5-G(4)(-N1), use the servo amplifiers manufactured in June 2021 or later, and the servo amplifier version C0 or later. Note that, depending on the stock status, the servo amplifiers with both the former and the new specifications may be distributed in the market around the same time. Contact the local sales office when the touch probe function is needed
- 11. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog




Functional Safety I/O Signal Connector (CN8) Connection Example G G-RJ WG DG A A-RJ

The following are connection examples of STO function for MR-J5-G. Be sure to read through "MR-J5 User's Manual" or "MR-J5D User's Manual" for the actual wiring and use.

When using a safety door



●When used with MR-J3-D05



Notes: 1. When using the STO function, turn off STO1 and STO2 at the same time. Turn off STO1 and STO2 after the servo motor stops in servo-off state or after the servo motor stops with deceleration by turning off EM2 (Forced stop 2).


- 2. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 3. If the controller does not have a forced stop function, install a forced stop 2 switch (normally closed contact).
- 4. Turn on EM2 (Forced stop 2) before starting the operation.
- 5. The connector and the pin numbers for each signal vary depending on the servo amplifier. Refer to the standard wiring diagram example for the relevant servo amplifier in this catalog for details.
- 6. For MR-J5-G(4)-RJ(N1), MR-J5W_, and MR-J5D_, the input/output signal names of CN8 are different from the indicated names such as STO1 and TOFB1. Refer to "MR-J5 User's Manual" or "MR-J5D User's Manual" for details.
- 7. This is for source wiring. Sink wiring is also possible.




Main/Control Circuit Power Supply Connection Example (Note 6)

G G-RJ A A-RJ


 For 3-phase 200 V AC and driving on/off of main circuit power supply with AC power supply




 For 3-phase 200 V AC and driving on/off of main circuit power supply with DC power supply



 For 1-phase 200 V AC and driving on/off of main circuit power supply with AC power supply



● For 1-phase 200 V AC and driving on/off of main circuit power supply with DC power supply



Notes: 1. For 1-phase 200 V AC to 240 V AC, connect the power supply to L1 and L3 terminals. Do not connect anything to L2.


- 2. Disconnect a short-circuit bar between P3 and P4 when using the power factor improving DC reactor or the simple converter unit.
- 3. Disconnect a short-circuit bar between P+ and D when connecting the regenerative option externally.
- 4. When wires used for L11 and L21 are thinner than those for L1, L2, and L3, use a molded-case circuit breaker or a fuse. Refer to "MR-J5 User's Manual" for details.
- 4. When when used not I and LE i and LE i at thinker than those of le I i, LE, and LD, use a hinded-case cliculi place in learning in user. Here it will be a contactor. So not use the 24 V DC interface power supply for the magnetic contactor.
- 6. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual"
- 7. For MR-J5-500_ and MR-J5-700_ servo amplifiers, CNP1 connector is divided into two connectors, CNP1A (L1/L2/L3) and CNP1B (N1/P3/P4).
- 8. When connecting a linear servo motor with a thermal protector, add a contact to shut off by being interlocked with the thermal protector output of the linear servo motor.
- 9. Do not ground the servo amplifier between L11 and L21 even when the control circuit power supply is separated from the main circuit power supply using a UPS or an isolation transformer.




Main/Control Circuit Power Supply Connection Example

G G-RJ A A-RJ

● For 3-phase 400 V AC and driving on/off of main circuit power supply with AC power supply ● For 3-phase 400 V AC and driving on/off of main circuit power supply with DC power supply





- 1. Disconnect a short-circuit bar between P3 and P4 when using the power factor improving DC reactor.
- 2. Disconnect a short-circuit bar between P+ and D when connecting the regenerative option externally.


 3. When wires used for L11 and L21 are thinner than those for L1, L2, and L3, use a molded-case circuit breaker or a fuse. Refer to "MR-J5 User's Manual" for details.
- 4. Do not use the 24 V DC interface power supply for the magnetic contactor. Provide a dedicated power supply to the magnetic contactor.
- 5. Do not ground the servo amplifier between L11 and L21 even when the control circuit power supply is separated from the main circuit power supply using a UPS or an isolation transformer.




Precautions

Servo Motor Connection Example (Rotary Servo Motor) Semi Closed Loop Control System with MR-J5-G(4)(-N1)/MR-J5-A(4)

●For HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW)



●For HK-ST/HK-RT (3.5 kW to 7.0 kW)



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.


- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals (B1/B2) do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available.
- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.




Servo Motor Connection Example (Rotary Servo Motor) Fully Closed Loop Control System with MR-J5-G(4)(-N1)/MR-J5-A(4)

G A

●For HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW)



●For HK-ST/HK-RT (3.5 kW to 7.0 kW)



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.


- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals (B1/B2) do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available.
- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.
- 9. For fully closed loop control, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used.
- 10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5 User's Manual" for the fully closed loop control with a rotary encoder.
- 11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5 User's Manual" and "Rotary Servo Motor User's Manual"
- 12. When configuring a fully closed loop control system with MR-J5-G(4)(-N1)/MR-J5-A(4), connect MR-J4FCCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set to CN2 connector.




Servo Motor Connection Example (Linear Servo Motor) Linear Servo System with MR-J5-G(-N1)/MR-J5-A

G A

● For LM-H3/LM-F/LM-K2/LM-U2



For LM-AJ




Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.


- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. MR-J4THCBL03M junction cable for linear servo motor is compatible with both two-wire and four-wire type linear encoders.
- 4. When using a linear servo motor with MR-J5-G(-N1)/MR-J5-A, connect MR-J4THCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set to CN2 connector.
- 5. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 6. Create a relay circuit to turn off the main circuit power supply when the thermal protector is opened by overheating. Use a relay designed for a flowing current of 1000 mA or less. If a mechanical relay is used, use a relay designed for a flowing current of 50 mA to 1000 mA.





Linear Encoder Connection Example (for MR-J5-G(4)(-N1)/MR-J5-A(4))


G A











Notes: 1. For the number of the wire pairs for LG and P5, refer to "MR-J5 Partner's Encoder User's Manual".


- 2. When the fully closed loop control system is configured with a rotary servo motor, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used.
- 3. For the fully closed loop control, the signals of 3-pin and 4-pin are as follows:

3-pin: MX 4-pin: MXR




Servo Motor Connection Example (Direct Drive Motor)

●For TM-RG2M/TM-RU2M/TM-RFM (incremental system)



●For TM-RG2M/TM-RU2M/TM-RFM (absolute position detection system)



Notes: 1. An MR-BTAS01 absolute position storage unit, and MR-BAT6V1SET or MR-BAT6V1SET-A battery (sold as options) are required for absolute position detection system. Refer to "MR-J5 User's Manual" and "Direct Drive Motor User's Manual" for details of absolute position detection system.

- 2. Fabricate this encoder cable. Refer to "Direct Drive Motor User's Manual" when fabricating the encoder cable.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.



Servo Amplifiers

Encoder Connection Specifications

a a lo A A lo	G	G-RJ	Α	A-RJ
---------------	---	------	---	------

Refer to the following table for the encoder communication method compatible with each system and for the servo amplifier connector to which a load-side encoder should be connected.

Operation	External encoder	Connector to be connected	d with the external encoder		
mode	communication method	MR-J5-G(4)(-N1)	MR-J5-G(4)-RJ(N1)	MR-J5-A(4)	MR-J5-A(4)-RJ
	Two-wire type	CN2 (Note 1)	CN2 (Note 1)	CN2 (Note 1)	CN2 (Note 1)
Linear servo	Four-wire type	CINZ (INC.)	OINZ (**** ·)	OINZ (**** ·)	CIVE (vere 1)
system (Note 3)	A/B/Z-phase differential output method		CN2L (Note 2)		CN2L (Note 2)
	Two-wire type	CN2 (Note 4, 5)		CN2 (Note 4, 5)	
Fully closed	Four-wire type				
loop control system (Note 6, 7)	A/B/Z-phase differential output method		CN2L		CN2L
	Two-wire type	CN2 (Note 4, 5)			
Scale	Four-wire type		CN2L		
measurement function (Note 6, 7)	A/B/Z-phase differential output method				


Notes: 1. MR-J4THCBL03M junction cable is required.

- 2. Connect a thermistor to CN2 connector.
- 3. Refer to "Combinations of Linear Servo Motors and Servo Amplifiers" in this catalog for servo amplifiers that are compatible with linear servo motors.
- 4. MR-J4FCCBL03M junction cable is required.
 5. MR-J5-G(4)(-N1)/MR-J5-A(4) does not support a servo motor encoder with the four-wire type communication method. Use MR-J5-G(4)-RJ/MR-J5-A(4)-RJ.
- 6. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 7. For the servo amplifier firmware version compatible with this function, refer to "MR-J5 User's Manual".


G-RJ A-RJ

Servo Motor Connection Example (Rotary Servo Motor) Fully Closed Loop Control System with MR-J5-G(4)-RJ/MR-J5-G(4)-RJN1/MR-J5-A(4)-RJ

●For HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW)



●For HK-ST/HK-RT (3.5 kW to 7.0 kW)



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.


- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals (B1/B2) do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available.
- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.
- 9. The load-side encoder and the servo motor encoder are compatible with both two-wire and four-wire type communication methods.
- 10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5 User's Manual" for the fully closed loop control with a rotary encoder.
- 11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5 User's Manual" and "Rotary Servo Motor User's Manual".
- 12. This wiring of the servo motor encoder is applicable for the two-wire type communication method.
- 13. When configuring a fully closed loop control system with MR-J5-G(4)-RJ/MR-J5-G(4)-RJN1/MR-J5-A(4)-RJ, connect a servo motor encoder to CN2 connector and a load-side encoder to CN2L connector. Do not use MR-J4FCCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set.




Servo Motor Connection Example (Linear Servo Motor: LM-H3/LM-F/LM-K2/LM-U2) Linear Servo System with MR-J5-G-RJ/MR-J5-G-RJN1/MR-J5-A-RJ

G-RJ A-RJ

Connecting a serial linear encoder



Connecting an A/B/Z-phase differential output linear encoder



Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.


- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 4. When configuring a linear servo system with MR-J5-G-RJ/MR-J5-G-RJN1/MR-J5-A-RJ servo amplifier and a serial linear encoder, connect MR-J4THCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set to CN2 connector.
- When configuring a linear servo system with MR-J5-G-RJ/MR-J5-G-RJN1/MR-J5-A-RJ and an A/B/Z-phase differential output type linear encoder, connect a thermistor
 to CN2 connector and the linear encoder to CN2L connector. Do not use MR-J4THCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector
 set.
- 6. MR-J4THCBL03M junction cable for linear servo motor is compatible with both two-wire and four-wire type linear encoders.




Servo Motor Connection Example (Linear Servo Motor: LM-AJ) Linear Servo System with MR-J5-G-RJ/MR-J5-G-RJN1/MR-J5-A-RJ

G-RJ A-RJ

Connecting a serial linear encoder



Connecting an A/B/Z-phase differential output linear encoder





Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.


- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 4. Create a relay circuit to turn off the main circuit power supply when the thermal protector is opened by overheating. Use a relay designed for a flowing current of 1000 mA or less. If a mechanical relay is used, use a relay designed for a flowing current of 50 mA to 1000 mA.





Linear Encoder Connection Example (for MR-J5-G(4)-RJ/MR-J5-G(4)-RJN1/MR-J5-A(4)-RJ) G-RJ A-RJ














1. For the number of the wire pairs for LG and P5, refer to "MR-J5 Partner's Encoder User's Manual".

- 2. If the encoder's current consumption exceeds 350 mA, supply power from an external source.
- 3. For the fully closed loop control, the signals of 3-pin, 4-pin, 7-pin, and 8-pin of the CN2L connector are as follows:


3-pin: MR2 4-pin: MRR2 7-pin: MX2 8-pin: MXR2



G G-RJ


MR-J5-G_ Dimensions

- ●MR-J5-10G(-N1), MR-J5-10G-RJ(N1)
- ●MR-J5-20G(-N1), MR-J5-20G-RJ(N1)
- ●MR-J5-40G(-N1), MR-J5-40G-RJ(N1)



[Unit: mm]

●MR-J5-60G(-N1), MR-J5-60G-RJ(N1)



[Unit: mm]


Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.

2. CN2L connector is not available for MR-J5-G(-N1) servo amplifiers.


MR-J5-G_ Dimensions

G G-RJ

- ●MR-J5-70G(-N1), MR-J5-70G-RJ(N1)
- ●MR-J5-100G(-N1), MR-J5-100G-RJ(N1)



- ●MR-J5-200G(-N1), MR-J5-200G-RJ(N1)
- ●MR-J5-350G(-N1), MR-J5-350G-RJ(N1)




Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.


MR-J5-G_ Dimensions

G G-RJ

●MR-J5-500G(-N1), MR-J5-500G-RJ(N1)



●MR-J5-700G(-N1), MR-J5-700G-RJ(N1)




Notes: 1. CNP1A, CNP1B, CNP2, and CNP3 connectors are supplied with the servo amplifier.

2. CN2L connector is not available for MR-J5-G(-N1) servo amplifiers.


MR-J5-G_ Dimensions

G G-RJ

- ●MR-J5-60G4(-N1), MR-J5-60G4-RJ(N1)
- ●MR-J5-100G4(-N1), MR-J5-100G4-RJ(N1)



- ●MR-J5-200G4(-N1), MR-J5-200G4-RJ(N1)
- ●MR-J5-350G4(-N1), MR-J5-350G4-RJ(N1)




Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.
2. CN2L connector is not available for MR-J5-G4(-N1) servo amplifiers.

MR-J5W_ Connections with Peripheral Equipment (Note 1)

WG

Peripheral equipment is connected to MR-J5W_ as described below. Connectors, cables, options, and other necessary equipment are available so that users can set up the servo amplifier easily and start using it right away.



Notes: 1. The connection with the peripheral equipment is an example for MR-J5W3-222G(-N1). CNP3C and CN2C connectors are not available on MR-J5W2-G(-N1). Refer to "MR-J5 User's Manual" for the actual connections of each multi-axis servo amplifier.

- 2. This picture shows when the display cover is open.
 - 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
 - 4. For specifications of the Ethernet cable, refer to "Ethernet Cable Specifications" on p. 7-34 in this catalog.
 - 5. This picture is an example for MR-J5W3-222G.

MR-J5W2-G(-N1) (2-Axis, Network Compatible) Specifications

WG

Servo a	mplifier mod	del MR-	J5W2(-N1)	22G	44G	77G	1010G		
Output	Voltage			3-phase 0 V AC to 240 \	/ AC				
Output	Rated curr	ent (ead	ch axis) [A	1.8	2.8	5.8	6.0		
Main	Voltage/ frequency	(Note 1)	AC input	3-phase or 1-phase 200	3-phase 200 V AC to 240 V AC, 50 Hz/60 Hz				
circuit			DC input (Note 8)	283 V DC to 340 V DC	I	1			
power	Rated current (Note 6)		⁵⁾ [A]	2.9	5.2	7.5	9.8 3-phase 170 V AC to		
supply input	Permissibl voltage	е	AC input	3-phase or 1-phase 170	phase or 1-phase 170 V AC to 264 V AC				
	fluctuation		DC input (Note 8)	241 V DC to 374 V DC					
	Permissibl	e freque	ency fluctuation	±5 % maximum					
	Voltage/		AC input	1-phase 200 V AC to 24	0 V AC, 50 Hz/60 Hz				
Control	frequency		DC input (Note 8)	283 V DC to 340 V DC					
circuit	Rated curr	ent	[A]	0.4					
power	Permissibl voltage	е	AC input	1-phase 170 V AC to 26	4 V AC				
supply input	fluctuation		DC input (Note 8)	241 V DC to 374 V DC					
iiipat	Permissibl	e freque	ency fluctuation	±5 % maximum					
	Power cor	sumptic	on [W]	55					
Interfac	e power sup	ply		24 V DC ± 10 % (require	ed current capacity: 0.35 A	A (including CN8 connect	or signals))		
Control	method			Sine-wave PWM control	/current control method				
	sible regene -in regenera			20 100					
	c brake (Note			Built-in					
CC-Link	IE TSN (Note 9)		unication ote 5, 12)	62.5 μs, 125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms					
(MR-J5)	W2-G)	Certifie		Class B					
EtherCA (MR-J5)	AT® W2-G-N1)	Commi	unication ote 5, 12)	250 μs, 500 μs, 1 ms, 2	ms, 4 ms, 8 ms				
CC-Link	IE Field Ne	etwork E	Basic	Not supported					
Commu	nication	USB		Connect a personal computer (MR Configurator2 compatible)					
Encode	r output pul	se		Compatible (A/B-phase	pulse) (Note 12)				
Analog				2 channels					
Position	ing mode (N	ote 11, 12)		Point table method					
Fully clo	sed loop co	ontrol (Not	e 11, 12)	Two-wire type communication method					
Load-sid	de encoder	interfac	e (Note 10)	Mitsubishi Electric high-speed serial communication					
Servo fu	unctions			Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, scale measurement function (Note 11, 12), super trace control (Note 11), continuous operation to torque control mode (Note 11, 13)					
Protecti	ve functions	3		Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection					
Safety s	sub-function	, Safetv	performance	'	nctions" on pp. 1-10 and	1-11 in this catalog.			
	e (IP rating)			Natural cooling, open (IP20) Force cooling, open (IP20)					
Close m	nountina			Possible (Note 7)					
Mass			ſka	1.5					
	5		ing.						

Notes: 1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the

- servo amplifier is operated within the specified power supply voltage and frequency.

 2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
- 3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
- 4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.
- 5. The command communication cycle depends on the controller specifications and the number of slaves connected.
- 6. This value is applicable when a 3-phase power supply is used.
- 7. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio. 8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".

 9. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 µs.

- 10. Not compatible with pulse train interface (A/B/Z-phase differential output type).
- 11. For the servo amplifier firmware version compatible with this function, refer to "MR-J5 User's Manual".
- 12. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 13. The continuous operation to torque control mode is not available with MR-J5W_-G-N1.

Servo amplifier model MR-J5W3(-N1)				222G 444G				
Output	Voltage			3-phase 0 V AC to 240 V AC				
Output	Rated current (each axis) [A]			[A] 1.8 2.8				
	Voltage/		AC input	3-phase or 1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz				
Main	frequency (N	ote 1)	DC input (Note 8)	283 V DC to 340 V DC				
circuit	Rated curre	nt (Note 6	3)	[A] 4.3 7.8				
power	Permissible		AC input	3-phase or 1-phase 170 V AC to 264 V AC				
supply input	voltage fluctuation		DC input (Note 8)	241 V DC to 374 V DC				
	Permissible	freque	ency fluctuation	±5 % maximum				
	Voltage/		AC input	1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz				
	frequency		DC input (Note 8)	283 V DC to 340 V DC				
Control	Rated curre	nt		[A] 0.4				
circuit	Permissible		AC input	1-phase 170 V AC to 264 V AC				
power supply	voltage fluctuation		DC input (Note 8)	241 V DC to 374 V DC				
input	Permissible	freque	ency fluctuation	±5 % maximum				
	Power cons	umptic	on [W] 55				
Interfac	e power supp	oly		24 V DC ± 10 % (required current capacity: 0.45 A (including CN8 connector signals))				
Control	method			24 V DC ± 10 % (required current capacity: 0.45 A (including CN8 connector signals)) Sine-wave PWM control/current control method				
Permissible regenerative power of the built-in regenerative resistor (Note 2, 3) [W]				wj 30				
	c brake (Note 4)			Built-in				
CC-Link	CC-Link IE TSN (Note 9) Communication cycle (Note 5, 11)			125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms				
(MR-J5	W3-G)	Certified class		Class B				
EtherCA (MR-J5)			nunication (Note 5, 11)	250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms				
Commu		USB		Connect a personal computer (MR Configurator2 compatible)				
CC-Link	IE Field Net	work E	Basic	Not supported				
Encode	r output	MR-J	5W3-G	Compatible only with A-axis and B-axis (A/B-phase pulse) (Note 11, 12)				
pulse		MR-J	5W3-G-N1	Not compatible				
Analoa	monitor			2 channels				
	ning mode (Note	e 10, 11)		Point table method				
	osed loop cor			Not available				
Servo functions				Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, super trace control (Note 10), continuous operation to torque control mode (Note 10), 13)				
Protective functions				Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection				
		Safety	performance	Refer to "Safety Sub-Functions" on pp. 1-10 and 1-11 in this catalog.				
	re (IP rating)			Force cooling, open (IP20)				
Close m	nounting			Possible (Note 7)				
Mass			Г	(g] 1.8				


1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.

- 2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
- 3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
- 4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.

 5. The command communication cycle depends on the controller specifications and the number of slaves connected.
- 6. This value is applicable when a 3-phase power supply is used.
- 7. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio.
- 8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".
- 9. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 μ s
- 10. For the servo amplifier firmware version compatible with this function, refer to "MR-J5 User's Manual".
- 11. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 12. When the command unit selection function (command unit/s) or the touch probe function is enabled, encoder output pulses are not outputted.
- 13. The continuous operation to torque control mode is not available with MR-J5W_-G-N1.

MR-J5W2-G(-N1) Standard Wiring Diagram Example

WG




Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable slaves depends on the controller specifications.

- 2. This is for sink wiring. Source wiring is also possible.
- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (Class B) recommended by CC-Link Partner Association. When a switching hub (Class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manual for details.
- 6. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.
- 7. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 8. The forced stop signal is issued for two axes of the servo amplifier. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 11. These devices can be changed to TPR1 (Touch probe 1), TPR2 (Touch probe 2) and TPR3 (Touch probe 3) with [Pr. PD05] and [Pr. PD51].
- 12. For the servo amplifier firmware version compatible with the touch probe function, refer to "MR-J5 User's Manual".
- 13. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 14. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog.



MR-J5W3-G(-N1) Standard Wiring Diagram Example

WG



Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2) Note that the number of the connectable slaves depends on the controller specifications.

- 2. This is for sink wiring. Source wiring is also possible.
- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (Class B) recommended by CC-Link Partner Association. When a switching hub (Class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manual for details.
- 6. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.
- 7. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 8. The forced stop signal is issued for three axes of the servo amplifier. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used
- 11. These devices can be changed to TPR1 (Touch probe 1), TPR2 (Touch probe 2), and TPR3 (Touch probe 3) with [Pr. PD05]
- 12. For the servo amplifier firmware version compatible with the touch probe function, refer to "MR-J5 User's Manual"
- 13. For the availability of the encoder output pulse, refer to "MR-J5W3-G(-N1) (3-Axis, Network Compatible) Specifications" in this catalog.
- 14. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.


 15. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog.




Main/Control Circuit Power Supply Connection Example (Note 6)

WG


● For 3-phase 200 V AC and driving on/off of main circuit power supply with AC power supply




 For 3-phase 200 V AC and driving on/off of main circuit power supply with DC power supply



 For 1-phase 200 V AC and driving on/off of main circuit power supply with AC power supply



 For 1-phase 200 V AC and driving on/off of main circuit power supply with DC power supply




Notes: 1. For 1-phase 200 V AC to 240 V AC, connect the power supply to L1 and L3 terminals. Do not connect anything to L2.

- 2. Disconnect a short-circuit bar between P+ and D when connecting the regenerative option externally.
- 3. When wires used for L11 and L21 are thinner than those for L1, L2, and L3, use a molded-case circuit breaker or a fuse. Refer to "MR-J5 User's Manual" for details.
- 4. Select either of the following functions for CALM (AND malfunction) with the controller.
 - 1) The contact opens when an alarm occurs on one of the axes.
 - 2) The contact opens when an alarm occurs on all axes.
- 5. Do not use the 24 V DC interface power supply for the magnetic contactor. Provide a dedicated power supply to the magnetic contactor.
- 6. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".
- 7. When connecting a linear servo motor with a thermal protector, add a contact to shut off by being interlocked with the thermal protector output of the linear servo motor.
- 8. Do not ground the servo amplifier between L11 and L21 even when the control circuit power supply is separated from the main circuit power supply using a UPS or an isolation transformer.




Servo Motor Connection Example (Rotary Servo Motor) Semi Closed Loop Control System with MR-J5W_

●For HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW)



●For HK-ST



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.

- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals (B1/B2) do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. CNP3C and CN2C connectors are available for MR-J5W3-G(-N1) servo amplifiers.
- 6. Install a surge absorber between B1 and B2.
- 7. This is for using an option dual cable type. Single cable types are also available.
- 8. Encoder cables are available as an option.
- Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.



Encoder Connection Specifications

WG

Refer to the following table for the encoder communication method compatible with each system and for the servo amplifier connector to which a load-side encoder should be connected.


Operation	External encoder	Connector to be connected with the external encoder					
mode	communication method	MR-J5W2-G(-N1)	MR-J5W3-G(-N1)				
Linear corvo	Two-wire type	CN2A (Note 1)	CN2A (Note 1) CN2B (Note 1) CN2C (Note 1)				
Linear servo system (Note 3)	Four-wire type	CN2R (Note 1)					
Fully closed loop control system (Note 2, 5)	Two-wire type	CN2A (Note 4, 6) CN2B (Note 4, 6)					
Scale measurement function (Note 2, 5)	Two-wire type	CN2A (Note 4, 6) CN2B (Note 4, 6)					

Notes:


- MR-J4THCBL03M junction cable is required.
 For the servo amplifier firmware version compatible with this function, refer to "MR-J5 User's Manual".
- 3. Refer to "Combinations of Linear Servo Motors and Servo Amplifiers" in this catalog for servo amplifiers that are compatible with linear servo motors.
- 4. MR-J4FCCBL03M junction cable is required.
- 5. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 6. MR-J5W2-G(-N1) does not support a servo motor encoder with the four-wire type communication method. Use MR-J5-G(4)-RJ(N1).

Servo Motor Connection Example (Rotary Servo Motor) Fully Closed Loop Control System with MR-J5W2-G(-N1)

●For HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW)



For HK-ST



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.


- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals (B1/B2) do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available.
- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.
- 9. For fully closed loop control, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used.
- 10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5 User's Manual" for the fully closed loop control with a rotary encoder.
- 11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5 User's Manual" and "Rotary Servo Motor User's Manual".
- 12. MR-J5W3-G(-N1) does not support the fully closed loop control.




Servo Motor Connection Example (Linear Servo Motor) Linear Servo System with MR-J5W_

WG

●For LM-H3/LM-K2/LM-U2



For LM-AJ



Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.


- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. MR-J4THCBL03M junction cable for linear servo motor is compatible with both two-wire and four-wire type linear encoders.
- 4. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 5. CNP3C and CN2C connectors are available for MR-J5W3-G(-N1) servo amplifiers.
- 6. Create a relay circuit to turn off the main circuit power supply when the thermal protector is opened by overheating. Use a relay designed for a flowing current of 1000 mA or less. If a mechanical relay is used, use a relay designed for a flowing current of 50 mA to 1000 mA.





Precautions


Linear Encoder Connection Example (for MR-J5W_)


WG












Notes: 1. For the number of the wire pairs for LG and P5, refer to "MR-J5 Partner's Encoder User's Manual".

- 2. For fully closed loop control, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used.
- For the fully closed loop control, the signals of 3-pin and 4-pin are as follows: 3-pin: MX 4-pin: MXR




Servo Motor Connection Example (Direct Drive Motor)

● For TM-RG2M/TM-RU2M/TM-RFM series (incremental system)



● For TM-RG2M/TM-RU2M/TM-RFM series (absolute position detection system)



Notes: 1. Fabricate this encoder cable. Refer to "Direct Drive Motor User's Manual" when fabricating the encoder cable.

- 2. An MR-BTAS01 absolute position storage unit, MR-BT6VCASE battery case, and MR-BAT6V1 batteries (sold as options) are required for absolute position detection system. Refer to "MR-J5 User's Manual" and "Direct Drive Motor User's Manual" for details of absolute position detection system.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. CNP3C and CN2C connectors are available for MR-J5W3-G(-N1) servo amplifiers.




Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

WG


WG

MR-J5W2-G(-N1) Dimensions

- ●MR-J5W2-22G(-N1)
- ●MR-J5W2-44G(-N1)




- ●MR-J5W2-77G(-N1)
- ●MR-J5W2-1010G(-N1)



Notes: 1. CNP1, CNP2, CNP3A, and CNP3B connectors are supplied with the servo amplifier.

MR-J5W3-G(-N1) Dimensions

- ●MR-J5W3-222G(-N1)
- ●MR-J5W3-444G(-N1)




Notes: 1. CNP1, CNP2, CNP3A, CNP3B, and CNP3C connectors are supplied with the servo amplifier.

WG

MR-J5D_ Connections with Peripheral Equipment (Note 1)

DG

Peripheral equipment is connected to MR-J5D_ as described below. Connectors, cables, options, and other necessary equipment are available so that users can set up the drive unit easily and start using it right away.



- Notes: 1. The connection with the peripheral equipment is an example for MR-J5D3-200G4(-N1) or smaller drive units. Refer to "MR-J5D User's Manual" for the actual connections.
 - 2. This illustration shows when the display cover is closed.
 - 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the drive unit for grounding the servo motor.
 - 4. For specifications of the Ethernet cable, refer to "Ethernet Cable Specifications" on p. 7-34 in this catalog.
 - 5. This illustration is an example for MR-J5D3-200G4.

MR-J5D1-G4(-N1) (1-Axis, Network Compatible) Specifications (400 V)

DG

D		, ,	() ()	10001	20004	05004	,	70004	
	model MI			100G4	200G4	350G4	500G4	700G4	
Compatib	le convert	er unit	model	MR-CV_4 (Note 8)					
Output	Voltage			3-phase 0 V AC					
	Rated current [A]			3.0	5.5	8.6	14.0	17.0	
Main circu	uit power s	- 1 1 /	nput	Main circuit pov	wer is supplied from	om the power regene	ration converter unit to	o the drive unit.	
	Voltage/ frequency		AC input		AC to 480 V AC,	50 Hz/60 Hz			
Control	Rated cu	ırrent	[A]	0.2					
circuit power supply	Permissi voltage fluctuation		AC input	1-phase 323 V	AC to 528 V AC				
input	Permissi fluctuation	n		±5 % maximum	1				
	Power co		otion [W]	40					
	power sup	pply					luding CN8 connector	r signals))	
Control m					M control/current	control method			
Dynamic	brake (Note	2)		Built-in					
CC-Link IE (MR-J5D		Communication cycle (Note 3, 4)		31.25 μs, 62.5 μs, 125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms					
(ועורו-מסט	1-04)	Certified class		Class B					
EtherCAT (MR-J5D		Comm (Note 3, 4)	unication cycle	125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms					
CC-Link I		etwork I	Basic (Note 6, 7)	Supported					
Communi	ication	USB		Connect a personal computer (MR Configurator2 compatible)					
Encoder	output pul	se		Compatible (A/B/Z-phase pulse)					
Analog m				2 channels					
Positionin	ng mode (N	ote 4)		Point table method					
	ed loop co		ote 4)	Two-wire/four-wire type communication method					
-	e encoder			Mitsubishi Electric high-speed serial communication, A/B/Z-phase differential input signal					
Servo fun	ections			Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, scale measurement function (Note 4), super trace control, continuous operation to torque control mode (Note 4, 9)					
	e functions			Overcurrent shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection					
-			y performance		Refer to "Safety Sub-Functions" on pp. 1-10 and 1-11 in this catalog.				
Structure	(IP rating))			, open (IP20) (Note	1)		, open (IP20) (Note 1)	
Mass			[kg]	5.5			4.6		

- Notes: 1. IP20 requires a side protection cover (an option).
 2. When using the dynamic brake, refer to "MR-J5D User's Manual" for the permissible load to motor inertia ratio.
 3. The command communication cycle depends on the controller specifications and the number of slaves connected.

 - 4. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 - 5. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 µs.
 - 6. CC-Link IE Field Network Basic is also supported. For details, refer to "MR-J5 User's Manual" and "MR-J5D User's Manual".
 - 7. For the restrictions on the communication cycle of CC-Link IE Field Network Basic, refer to "MR-J5D User's Manual".
 - 8. MR-CV_4 power regeneration converter units require a mounting attachment. Some drive units also require a mounting attachment depending on the power regeneration converter unit to be used. Refer to "Mounting Attachment" in this catalog for details.
 9. The continuous operation to torque control mode is not available with MR-J5D_-G4-N1.

1411 1-03	D2-G4(-14 1 <i>)</i>	(2-413, 1	letwork Com	iput	ibic, ope	omeanons (+t	30 v)	DG	
Drive unit	t model M	R-J5D2	?(-N1)	100G4		200G4	350G4	500G4	700G4	
Compatib	ole conver	ter unit	model	MR-CV_4 (Note	MR-CV_4 (Note 2)					
Voltage			3-phase 0 V A	B-phase 0 V AC to 480 V AC						
Output	Rated cu	urrent (e	each axis)	[A] 3.0		5.5	8.6	14.0	17.0	
Main circ	uit power	supply	input	Main circuit po	ower i	s supplied fro	m the power regene	eration converter unit	to the drive unit.	
	Voltage/ frequence	AC, INDUIT		1-phase 380 \	1-phase 380 V AC to 480 V AC, 50 Hz/60 Hz					
Control	Rated cu	Rated current		[A] 0.2	0.2					
circuit power supply	Permissi voltage fluctuation		AC input	1-phase 323 \	V AC 1	to 528 V AC				
input	Permissi fluctuation		quency	±5 % maximui	m					
	Power c	onsum	otion [W] 40						
Interface	power sup	oply		24 V DC ± 10	% (re	quired curren	t capacity: 0.35 A (ii	ncluding CN8 connec	tor signals))	
Control m	nethod			Sine-wave PV	VM cc	ontrol/current	control method			
Dynamic	brake (Note	4)		Built-in						
	TSN (Note 7)	Comm (Note 5, 6)	unication cyc	le 62.5 μs, 125 μ	62.5 μs, 125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms					
(MR-J5D2-G4)		Certifie	ed class	Class B	Class B					
EtherCAT® Communication cycle (MR-J5D2-G4-N1) (Note 5, 6)			le 250 μs, 500 μ	250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms						
CC-Link I	IE Field No	etwork	Basic	Not supported	1					
Commun function	ication	USB		Connect a per	Connect a personal computer (MR Configurator2 compatible)					
Encoder	output pul	se		Compatible (A	Compatible (A/B-phase pulse) (Note 6, 8)					
Analog m	nonitor			2 channels	2 channels					
Positionir	ng mode (N	ote 6)		Point table me	Point table method					
Fully clos	sed loop co	ontrol (N	ote 6)	Two-wire type	Two-wire type communication method					
Load-side	e encoder	interfac	ce (Note 3)	Mitsubishi Ele	Mitsubishi Electric high-speed serial communication					
Servo functions			one-touch tuni	Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, scale measurement function (Note 6), super trace control, continuous operation to torque control mode (Note 6, 9).						
Protective functions			error protection	Overcurrent shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection						
Safety su	ub-function	, Safet	y performance			b-Functions"	on pp. 1-10 and 1-1	1 in this catalog.		
Structure (IP rating)			Natural cooling	g,		(ID00) (N=+-1)				
Structure	(IP rating)		open (IP20) (No kg] 5.7	ote 1)	Force cooling	g, open (IP20) (Note 1)			

1. IP20 requires a side protection cover (an option).

- 2. MR-CV_4 power regeneration converter units require a mounting attachment. Some drive units also require a mounting attachment depending on the power regeneration converter unit to be used. Refer to "Mounting Attachment" in this catalog for details.
- 3. Not compatible with pulse train interface (A/B/Z-phase differential output type).
- 4. When using the dynamic brake, refer to "MR-J5D User's Manual" for the permissible load to motor inertia ratio.
- 5. The command communication cycle depends on the controller specifications and the number of slaves connected.
- The communication continuous of the communication cycle, refer to "Restrictions" in this catalog.
 A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 μs.
 When the safety sub-function (network connection) is enabled, encoder output pulses are not outputted.
 The continuous operation to torque control mode is not available with MR-J5D_-G4-N1.

MR-J5D3-G4(-N1) (3-Axis, Network Compatible) Specifications (400 V)

DG


Drive unit model MR-J5D3(-N1)			- (-N1)		100G4 200G4				
Compatib					MR-CV_4 (Note 3)				
<u> </u>	Voltage			_	3-phase 0 V AC to 480 V AC				
Output Rated current (each axis) [A]		[A]	3.0 5.5						
Main circu	uit power s	supply i	nput		Main circuit power is supplied from the power regeneration converter unit to the drive unit.				
	Voltage/ frequency		, AC input		1-phase 380 V AC to 480 V AC, 50 Hz/60 Hz				
Control	Rated cu	ırrent		[A]	0.2				
circuit power supply	Permissi voltage fluctuation		AC input		1-phase 323 V AC to 528 V AC				
input	Permissi fluctuation	n	quency		±5 % maximum				
	Power co	onsump	tion [W]					
Interface	power sup	pply			24 V DC ± 10 % (required current capacity: 0.45 A (including CN8 connector signals))				
Control m					Sine-wave PWM control/current control method				
Dynamic I	brake (Note			_	Built-in				
CC-Link IE		Communication cycle (Note 5, 6)		le	250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms				
(MR-J5D3	3-G4)	Certified class			Class B				
	EtherCAT® Communication cycle (MR-J5D3-G4-N1) (Note 5, 6)		le	250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms					
CC-Link I	E Field Ne	etwork E	Basic		Not supported				
Communi function	cation	USB			Connect a personal computer (MR Configurator2 compatible)				
Encoder of	output	MR-J5D3-G4			Compatible only with A-axis and B-axis (A/B-phase pulse) (Note 6, 7)				
pulse	•	MR-J5D3-G4-N1			Not compatible				
Analog m	onitor				2 channels				
Positionin	g mode (N	ote 6)			Point table method				
Fully close	ed loop co	ontrol			Not compatible				
Servo functions					Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, super trace control, continuous operation to torque control mode (Note 6, 8)				
Protective functions					Overcurrent shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection				
			performance	_	Refer to "Safety Sub-Functions" on pp. 1-10 and 1-11 in this catalog.				
Structure	(IP rating))		$\overline{}$	Natural cooling, open (IP20) (Note 1) Force cooling, open (IP20) (Note 1)				
Mass			[]	(g]	5.9 5.8				

Notes: 1. IP20 requires a side protection cover (an option).

- 2. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 µs.
- 3. MR-CV_4 power regeneration converter units require a mounting attachment. Some drive units also require a mounting attachment depending on the power regeneration converter unit to be used. Refer to "Mounting Attachment" in this catalog for details.
- 4. When using the dynamic brake, refer to "MR-J5D User's Manual" for the permissible load to motor inertia ratio.

- 5. The command communication cycle depends on the controller specifications and the number of slaves connected.
 6. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 7. When the command unit selection function (command unit/s), the safety sub-function (network connection), or the touch probe function is enabled, encoder output pulses are not outputted.
- 8. The continuous operation to torque control mode is not available with MR-J5D_-G4-N1.

MR-J5D1-G4(-N1) Standard Wiring Diagram Example




Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable slaves depends on the controller specifications.

- 2. This is for sink wiring. Source wiring is also possible.
- 3. Attach a short-circuit connector supplied with the drive unit when the functional safety (STO function) is not used.
- 4. To prevent an unexpected restart of the drive unit, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off
- 5. When branching off CC-Link IETSN (synchronous communication function) with a switching hub, use a switching hub (Class B) recommended by CC-Link Partner Association. When a switching hub (Class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manual for details.
- 6. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 7. Devices for these pins can be changed with [Pr. PD07], [Pr. PD08], and [Pr. PD09].
- 8. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 9. This device can be changed to TPR3 (Touch probe 3) with [Pr. PD05]. When TPR3 is set, connect by using a normally open contact switch as the same as TPR1 (Touch probe 1) and TPR2 (Touch probe 2).



MR-J5D2-G4(-N1) Standard Wiring Diagram Example

DG



Drive unit


Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable slaves depends on the controller specifications.

- 2. This is for sink wiring. Source wiring is also possible.
- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the drive unit, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (Class B) recommended by CC-Link Partner Association. When a switching hub (Class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manual for details.
- 6. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog
- 7. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 8. The forced stop signal is issued for two axes of the drive unit. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the drive unit when the functional safety (STO function) is not used.
- 11. These devices can be changed to TPR1 (Touch probe 1), TPR2 (Touch probe 2), and TPR3 (Touch probe 3) with [Pr. PD05] and [Pr. PD51].

 12. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 13. For the availability of the encoder output pulse, refer to "MR-J5D2-G4(-N1) (2-Axis, Network Compatible) Specifications (400 V)" in this catalog.



MR-J5D3-G4(-N1) Standard Wiring Diagram Example



Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2).

Note that the number of the connectable slaves depends on the controller specifications.

- 2. This is for sink wiring. Source wiring is also possible.
- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the drive unit, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (Class B) recommended by CC-Link Partner Association. When a switching hub (Class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manual for details.
- 6. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 7. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 8. The forced stop signal is issued for three axes of the drive unit. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the drive unit when the functional safety (STO function) is not used.
- 11. These devices can be changed to TPR1 (Touch probe 1), TPR2 (Touch probe 2), and TPR3 (Touch probe 3) with [Pr. PD05].
- 12. For the restrictions on the communication cycle or the touch probe function, refer to "Restrictions" in this catalog.
- 13. For the availability of the encoder output pulse, refer to "MR-J5D3-G4(-N1) (3-Axis, Network Compatible) Specifications (400 V)" in this catalog.




Main/Control Circuit Power Supply Connection Example (Note 11)

and a street MD OV and MD IED

DG

●For connecting MR-CV_ and MR-J5D_




Notes: 1. To prevent an unexpected restart of the drive unit, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.

- 2. This is for sink wiring. Source wiring is also possible.
- 3. A step-down transformer is required if the power regeneration converter unit is in 400 V class, and coil voltage of the magnetic contactor is in 200 V class.
- 4. When connecting multiple drive units, create a sequence in which the servo system controller stops all axes and a sequence that shuts off the main circuit power if an alarm occurs on one axis.
- 5. Attach a short-circuit connector supplied with the drive unit when the functional safety (STO function) is not used.
- 6. Install an overcurrent protection device (molded-case circuit breaker, fuse, etc.) to protect the branch circuit.
- 7. Terminal varies depending on the capacity of the power regeneration converter unit and the drive unit. Refer to "MR-CV_ Power Regeneration Converter Unit Dimensions" and "MR-J5D_ Dimensions" in this catalog.
- 8. To stop the servo motor by forcibly decelerating with EM2, parameter setting is required. Refer to "MR-J5 User's Manual" for details.
- 9. Refer to the controller user's manual for the forced stop input of the servo system controller.
- 10. The bus bar varies depending on the combination of the power regeneration converter unit and the drive unit. Refer to "Bus Bar" in this catalog for details.
- 11. This example is for when magnetic contactor drive output is enabled.
- 12. The control circuit power supply (L11/L21) can be connected by passing wiring. Refer to "MR-J5D User's Manual" for details.




Servo Motor Connection Example (Rotary Servo Motor) Semi Closed Loop Control System with MR-J5D_

●For HK-KT/HK-RT (1.0 kW to 2.0 kW)



●For HK-ST/HK-RT (3.5 kW to 7.0 kW)



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.

- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals (B1/B2) do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the drive unit for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. CNP3B and CN2B connectors are available for MR-J5D2-G4(-N1) and MR-J5D3-G4(-N1) drive units. CNP3C and CN2C connectors are available for MR-J5D3-G4(-N1) drive units.
- 6. Install a surge absorber between B1 and B2.
- 7. This is for using an option dual cable type. Single cable types are also available.
- Encoder cables are available as an option
- 9. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.



Servo Amplifiers

Encoder Connection Specifications

DG


Refer to the following table for the encoder communication method compatible with each system and for the drive unit connector to which a load-side encoder should be connected.

Operation	External encoder	Connector to be connected with the external encoder					
mode	communication method	MR-J5D1-G4(-N1)	MR-J5D2-G4(-N1)	MR-J5D3-G4(-N1)			
	Two-wire type		CN2A (Note 1, 2) CN2B (Note 1, 2)				
Fully closed loop control	Four-wire type	- CN2AL					
system (Note 3)	A/B/Z-phase differential output method	ONZAL					
Scale	Two-wire type		CN2A (Note 1, 2) CN2B (Note 1, 2)				
measurement	Four-wire type	CN2AL					
function (Note 3)	A/B/Z-phase						
	differential output method						


Notes: 1. MR-J4FCCBL03M junction cable is required.
2. MR-J5D2-G4(-N1) does not support a servo motor encoder with the four-wire type communication method. Use MR-J5D1-G4(-N1).
3. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.

Servo Motor Connection Example (Rotary Servo Motor) Fully Closed Loop Control System with MR-J5D1-G4(-N1)

● For HK-KT/HK-RT (1.0 kW to 2.0 kW)



●For HK-ST/HK-RT (3.5 kW to 7.0 kW)




Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.

- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals (B1/B2) do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the drive unit for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available.
- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.
- 9. The load-side encoder and the servo motor encoder are compatible with both two-wire and four-wire type communication methods.
- 10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5D User's Manual" for the fully closed loop control with a rotary encoder.
- 11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5D User's Manual" and "Rotary Servo Motor User's Manual"
- This wiring of the servo motor encoder is applicable for the two-wire type communication method.
 When configuring a fully closed loop control system with MR-J5D1-G4(-N1), connect a servo motor encoder to CN2A connector and a load-side encoder to CN2AL connector. Do not use MR-J4FCCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set.




Servo Motor Connection Example (Rotary Servo Motor) Fully Closed Loop Control System with MR-J5D2-G4(-N1)

●For HK-KT/HK-RT (1.0 kW to 2.0 kW)



DG

●For HK-ST/HK-RT (3.5 kW to 7.0 kW)



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.


- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals (B1/B2) do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the drive unit for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available
- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables
- 9. For fully closed loop control, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used.
- 10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5D User's Manual" for the fully closed loop control with a rotary encoder.
- 11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5D User's Manual" and "Rotary Servo Motor User's Manual".
- 12. MR-J5D3-G4(-N1) does not support the fully closed loop control.





Precautions


Linear Encoder Connection Example (for MR-J5D1-G4(-N1)/MR-J5D2-G4(-N1))


DG















Notes: 1. For the number of the wire pairs for LG and P5, refer to "MR-J5 Partner's Encoder User's Manual".

- 2. If the encoder's current consumption exceeds 350 mA, supply power from an external source.
- 3. For MR-J5D2-G4(-N1), the signals of 3-pin and 4-pin are as follows: 3-pin: \mbox{MX}
- 4-pin: MXR 4. This is for MR-J5D1-G4(-N1).




MR-J5D_ Dimensions

- ●MR-J5D1-100G4(-N1)
- ●MR-J5D1-200G4(-N1)
- ●MR-J5D1-350G4(-N1)



DG

- ●MR-J5D1-500G4(-N1)
- ●MR-J5D1-700G4(-N1)




Notes: 1. CNP3A connector is supplied with the drive unit.

3-54


DG

MR-J5D_ Dimensions

●MR-J5D2-100G4(-N1)




- ●MR-J5D2-200G4(-N1)
- ●MR-J5D2-350G4(-N1)




Notes: 1. CNP3A and CNP3B connector are supplied with the drive unit.

MR-J5D_ Dimensions

- ●MR-J5D2-500G4(-N1)
- ●MR-J5D2-700G4(-N1)



●MR-J5D3-100G4(-N1)



Notes: 1. CNP3A and CNP3B connectors are supplied with the drive unit.

2. CNP3A, CNP3B, and CNP3C connectors are supplied with the drive unit.


DG

DG

Precautions

MR-J5D_ Dimensions

●MR-J5D3-200G4(-N1)



Notes: 1. CNP3A, CNP3B, and CNP3C connectors are supplied with the drive unit.

Servo Amplifiers

MR-J5-G_/MR-J5W_/MR-J5D_ Positioning Function: Point Table Method

G G-RJ WG DG

Set the position and speed data to the point table, and select the point table No. with the command interface signal to start the positioning operation.

Item		Description					
Command interface		Object dictionary					
Operation specifications		Positioning by specifying the point table No. (255 points)					
System		Signed absolute value command method					
		Setting in the point table					
		Setting range of feed length for one point:					
Position command input	Absolute value	-2147483648 to 2147483647 [μm],					
Position command input	command method	-214748.3648 to 214748.3647 [inch],					
		-2147483648 to 2147483647 [pulse],					
		-360.000 to 360.000 [degree]					
		Set the servo motor speed in the point table.					
		Set the acceleration/deceleration time constants and acceleration/deceleration in the point					
Speed command input		table.					
Speed Command Input		Set the S-pattern acceleration/deceleration time constant in [Pr. PT51].					
		The speed unit can be selected ([r/min], command unit/s)					
		The acceleration/deceleration unit can be selected ([ms], command unit/s²).					
Torque limit		Setting by the servo parameter or object dictionary					
	One positioning	Point table No. input method					
	operation	Perform one positioning operation based on the position command and speed comman					
Point table mode (pt)		Speed change operation (2nd gear to 255th gear)/					
Foint table mode (pt)	Continuous positioning operation						
		Continuous operation to the point table selected at startup/					
		Continuous operation to the point table No. 1					
JOG operation mode (jg)	JOG operation	Perform inching operation in the network communication function based on the speed command.					
		Dog type (rear end detection, Z-phase reference), stopper type (stopper position					
		reference), count type (front end detection, Z-phase reference), dog type (rear end					
		detection, rear end reference), count type (front end detection, front end reference),					
		dog cradle type, dog type last Z-phase reference, dog type front end reference, dogless					
		Z-phase reference,					
		Homing on negative limit switch and index pulse (method 1),					
Homing mode (hm) (Note 1)		Homing on positive limit switch and index pulse (method 2),					
		Homing on positive home switch and index pulse (method 3, 4),					
		Homing on negative home switch and index pulse (method 5, 6),					
		Homing on home switch and index pulse (method 7, 8, 9, 10, 11, 12, 13, 14),					
		Homing without index pulse (method 17, 18, 19, 20, 21, 22, 23, 24, 27, 28),					
		Homing on index pulse (method 33, 34),					
		Homing on current position (method 35, 37)					
Function on positioning ope	eration	Absolute position detection/external limit switch/software position limit/					
anction on positioning op	oration .	function for positioning to the home, etc.					

Notes: 1. For the servo amplifier firmware version compatible with the methods of No. 9, 10, 13, 14, 17, 18, refer to "MR-J5 User's Manual".

Support

MR-J5-G_/MR-J5W_/MR-J5D_ Positioning Function: Point Table Method

G G-RJ WG DG

Absolute value command method: travels to a specified address (absolute value) with reference to the home position

Item	Setting range	Description
Point table No.	1 to 255	Specify a point table in which a target position, servo motor speed, acceleration/deceleration, acceleration time constant/deceleration time constant, dwell, auxiliary function, and M code will be set.
Target position (Note 1) (position data)	-2147483.648 to 2147483.647 [mm] -214748.3648 to 214748.3647 [inch] -360.000 to 360.000 [degree] -2147483648 to 2147483647 [pulse]	Set a travel distance. (1) When using as absolute position command method Set a target address (absolute value). (2) When using as relative position command method Set a travel distance. Reverse rotation command is applied with a minus sign.
Servo motor speed (Note 2)	0 to maximum speed [r/min] 0 to 2147483.647 [mm/s] 0 to 214748.3647 [inch/s] 0 to 2147483.647 [degree/s] 0 to 2147483647 [pulse/s]	Set a command speed for the servo motor in positioning.
Acceleration	0 to 2147483.647 [mm/s ²] 0 to 214748.3647 [inch/s ²] 0 to 2147483.647 [degree/s ²] 0 to 2147483647 [pulse/s ²]	Set an acceleration for the servo motor to reach the set speed. (Acceleration time [s] = Servo motor speed/Acceleration)
Acceleration time constant	0 to 20000 [ms]	Set a time period for the servo motor to reach the rated speed.
Deceleration	0 to 2147483.647 [mm/s²] 0 to 214748.3647 [inch/s²] 0 to 2147483.647 [degree/s²] 0 to 2147483647 [pulse/s²]	Set a deceleration for the servo motor to decelerate from the set speed to a stop. (Deceleration time [s] = Servo motor speed/Deceleration)
Deceleration time constant	0 to 20000 [ms]	Set a time period for the servo motor to decelerate from the set speed to a stop.
Dwell	0 to 20000 [ms]	Set a dwell. When the dwell is set, the position command for the next point table will be started after the position command for the selected point table is completed and the set dwell is passed. The dwell is disabled when the auxiliary function is set to 0 or 2. Continuous operation is enabled when the auxiliary function is set to 1, 3, 8, 9, 10, or 11 and the dwell is set to 0.
Auxiliary function	0 to 3, 8 to 11	Set auxiliary function. (1) When using the point table with the absolute position command method 0: Automatic operation for a selected point table is performed. 1: Automatic continuous operation is performed without a stop to the next point table. 8: Automatic continuous operation is performed without a stop to the point table selected at startup. 9: Automatic continuous operation of the point table No. 1 is performed without a stop. (2) When using the point table with the relative position command method 2: Automatic operation for a selected point table is performed. 3: Automatic continuous operation is performed without a stop to the next point table. 10: Automatic continuous operation for a point table selected at startup is performed. 11: Automatic continuous operation of the point table No. 1 is performed without a stop.
M code	0 to 255	Set a code to be outputted when the positioning is complete.


1. Change the unit to mm/inch/degree/pulse with [Pr. PT01].

2. The speed unit is r/min for the rotary servo motors and the direct drive motors, and mm/s for the linear servo motors.

Example of setting point table data

Point table example

Point table No.	Target position (position data)	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function	M code
1	1000	2000	200	200	0	1	1
2	2000	1600	100	100	0	0	2
:	:	:	:	:	:	:	:
255	3000	3000	100	100	0	2	99



Servo Amplifiers

Restrictions G G-RJ WG DG

The restrictions on the communication cycle for the functions in the list are as follows.

Communication cycle

●For MR-J5-G(4)(-RJ)/MR-J5W_-G/MR-J5D_-G4

		Communicat	ion cycle (min	imum)				
Category	Function	MR-J5-G(4) (Note 1)	MR-J5-G(4)-RJ	MR-J5W2-G (Note 1)	MR-J5W3-G	MR-J5D1-G4	MR-J5D2-G4	MR-J5D3-G4
	Profile position mode (pp)	250 μs	250 μs	500 μs	500 μs	250 μs	500 μs	500 μs
	Profile velocity mode (pv)	250 μs	250 μs	-	-	250 μs	-	-
	Profile torque mode (tq)	250 μs	250 μs	-	-	250 μs	-	-
Control mode	Continuous operation to torque control mode (ct)	62.5 μs	62.5 μs	Not restricted	Not restricted	62.5 μs	Not restricted	Not restricted
	Positioning mode (point table method)	250 μs	250 μs	500 μs	500 μs	250 μs	500 μs	500 μs
Position	Fully closed loop control	125 µs	125 μs	250 μs	-	125 μs	250 μs	-
detection	Scale measurement function	125 µs	125 μs	250 μs	-	125 μs	250 μs	-
I/O, monitor	A/B/Z-phase output	Not restricted	Not restricted	125 μs	250 μs	Not restricted	125 μs	Not restricted
i/O, monitor	Touch probe function	62.5 μs	62.5 μs	250 μs	250 μs	62.5 μs	250 μs	Not restricted
	Safety sub-function (Note 2)	-	125 μs	125 μs	Not restricted	125 μs	125 μs	Not restricted
Functional	Safety sub-function (Network connection) (Note 2)	-	125 μs	-	-	125 μs	500 μs	500 μs
Functional safety	Safety sub-function (position/speed observation by using a servo motor with functional safety) (Note 2)	-	125 μs	-	-	125 μs	500 μs	500 μs
Unit	Command unit selection function (command unit/s) (Note 2)	125 µs	125 μs	250 μs	250 μs	125 μs	250 μs	Not restricted
Onit	Command unit selection function (degree unit) (Note 2)	250 μs	250 μs	500 μs	500 μs	250 μs	500 μs	500 μs

● For MR-J5-G(4)-(RJ)N1/MR-J5W_-G-N1/MR-J5D_-G4-N1


		Communication cycle (minimum)									
Category	Function	MR-J5-	MR-J5-G(4)-	MR-J5W2-	MR-J5W3-	MR-J5D1-	MR-J5D2-	MR-J5D3-			
		G(4)-N1	RJN1	G-N1	G-N1	G4-N1	G4-N1	G4-N1			
	Profile position mode (pp)	250 μs	250 μs	500 μs	500 μs	250 μs	500 μs	500 μs			
	Profile velocity mode (pv)	250 μs	250 μs	-	-	250 μs	-	-			
Control mode	Profile torque mode (tq)	250 μs	250 μs	-	-	250 μs	-	-			
	Positioning mode (point table method)	250 μs	250 μs	500 μs	500 μs	250 μs	500 μs	500 μs			
Unit	Command unit selection function (degree unit) (Note 2)	250 μs	250 μs	500 μs	500 μs	250 μs	500 μs	500 μs			

Notes: 1. When connecting a servo amplifier with a communication cycle of 62.5 µs or less, use the servo amplifier firmware version A6 or later. 2. For details of the function, refer to "MR-J5 User's manual".

MR-J5-A_ Connections with Peripheral Equipment (Note 1)

A A-RJ

Peripheral equipment is connected to MR-J5-A_ as described below. Connectors, cables, options, and other necessary equipment are available so that users can set up the servo amplifier easily and start using it right away.



- Notes: 1. The connection with the peripheral equipment is an example for MR-J5-350A(4)(-RJ) or smaller servo amplifiers. Refer to "MR-J5 User's Manual" for the actual connections.
 - 2. This picture shows when the display cover is open.

V			J5(-RJ)	10A	20A	40A	60A	70A	100A	200A	350A	500A	700A	
	oltage			3-phas	e 0 V A	C to 240	V AC							
Output F	ated currer	nt	[A]	1.3	1.8	2.8	3.2	5.8	6.0	11.0	17.0	28.0	37.0	
fr	oltage/ equency (No	te 1)	AC input			ohase 20 Hz/60 Hz		to		1-phase 200 0 V AC, 50	3-phase 2 50 Hz/60	200 V AC to Hz	240 V AC,	
Main circuit			DC input (Note 8)		OC to 3	40 V DC								
power F	ated currer	nt (Not	e 6) [A]	0.9	1.5	2.6	3.2	3.8	5.0	10.5	16.0	21.7	28.9	
supply F	ermissible oltage		AC input		3-phase or 1-phase 170 V AC to 3-phase or 1-phase 170 V AC to 264 V AC 3-phase 170 V AC to 264 V AC 3-phase 170 V AC to 264 V AC									
fl	uctuation		DC input (Note 8)	241 V [OC to 3	74 V DC								
	ermissible uctuation	frequ	uency	±5 % m	±5 % maximum									
V	oltage/		AC input	1-phas	1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz									
fr	equency		DC input (Note 8)	283 V [OC to 3	40 V DC								
	ated currer	nt	[A]	0.2										
	ermissible		AC input	1-phas	e 170 \	/ AC to 2	64 V AC	;						
supply	oltage uctuation		DC input (Note 8)	241 V [OC to 3	74 V DC								
fl	ermissible uctuation			±5 % m	naximui	m								
	ower consu	ımpt	tion [W]											
nterface po	,								ncluding CN8	connector	signals))			
Control met				Sine-w	ave PV	VM contro	ol/currer	nt contro	ol method					
Permissible he built-in r	regenerative egenerative	res	ower of istor (Note 2, 3) [W]	-	10			30		100		130	170	
Dynamic bra	ynamic brake (Note 4)			Built-in										
communication function								nfigurator2 c	ompatible)					
			RS-422/RS-485											
ncoder out	 					/B/Z-pha	se pulse	∍)						
Analog mon				2 chanı	nels									
	frequenc	у	put pulse	4 Mpulses/s (when using differential receiver), 200 kpulses/s (when using open collector)										
			eedback pulse	Encoder resolution: 26 bits										
Position control mod	factor		ulse multiplying	Electronic gear A/B multiple, A. 1 to 2147403047, B. 1 to 2147403047, 1/10 < A/B < 04000										
			ange setting	0 pulse to ±16777215 pulses (command pulse unit)										
	Error ex		sive	±3 rota							11501			
	Torque li			-					<u> </u>	O V DC to +10		imum torqu	ie)	
			d command	Ť	•				· ·	mmand 1:500 changeable v		12].)		
Speed conti mode		uctu	ation rate	0 V DC to ±10 V DC/rated speed (Speed at 10 V is changeable with [Pr. PC12].) ±0.01 % maximum (load fluctuation: 0 % to 100 %), 0 % (power fluctuation: ±10 %)										
	Torque li									0 °C) only whe				
Torque			ie command						<u> </u>	nce: 10 kΩ to		inani torqo		
control mod	Speed li	mit		Set by	servo p	aramete	rs or ex	ernal ar	nalog input (0 V DC to ± 10	V DC/rate	d speed)		
ully closed	loop MR	-J5-	A	Two-wi	re type	commun	ication	method						
control (Note 5)	MR	-J5-	A-RJ	Two-wi	re/four-	wire type	commi	unicatio	n method					
oad-side e	ncoder MR	l-J5-	A	Mitsubi	shi Ele	ctric high	-speed	serial co	ommunicatio	n				
nterface	MR	l-J5-	A-RJ	Mitsubi	shi Ele	ctric high	-speed	serial co	ommunicatio	n, A/B/Z-phas	e differentia	al input sign	ıal	
Servo functi	ons			Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (includin failure prediction), power monitoring function, lost motion compensation function, super trace contro										
orotective fu	Protective functions			Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servor motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection magnetic pole detection protection, linear servo control fault protection										

Precautions

MR-J5-	MR-J5-A_ (General-Purpose Interface) Specifications (200 V) A A-RJ											
Servo amp	plifier model MR-J5(-RJ)	10A	20A	40A	60A	70A	100A	200A	350A	500A	700A	
Structure	Natura	Natural cooling, open (IP20) Force of				rce cooling, open (IP20)				Force cooling, open (IP20) (Note 9)		
Close	3-phase power supply input	Possib	e (Note 10)									
mounting	1-phase power supply input	Possib	Possible (Note 10)				Not possible					
Mass	[kg]	0.8			1.0	1.4		2.2		3.7	6.2	

- Notes: 1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.
 - 2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
 - 3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
 - 4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.
 - 5. For the servo amplifier firmware version compatible with this function, refer to "MR-J5 User's Manual".

 - 6. This value is applicable when a 3-phase power supply is used.
 7. When a 1-phase 200 V AC to 240 V AC power supply is used, use the servo amplifiers at 75 % or less of the effective load ratio.
 - 8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".
 - 9. The connector part is excluded.
 - 10. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio.

MR-J5-A_ (General-Purpose Interface) Specifications (400 V)

A A-RJ


	fier model MR		60A4	100A4	200A4	350A4				
Output	oltage		3-phase 0 V AC to 480 V	AC						
R	ated current	[A]	1.6	2.8	5.5	8.6				
fr	oltage/ equency (Note 1)	AC input	3-phase 380 V AC to 480	0 V AC, 50 Hz/60 Hz						
Main R	ated current	[A]	1.4	2.5	5.1	7.9				
power supply	ermissible oltage uctuation	AC input	3-phase 323 V AC to 528 V AC							
P	ermissible fre	quency	±5 % maximum							
V	oltage/ equency	AC input	1-phase 380 V AC to 480	O V AC, 50 Hz/60 Hz						
	ated current	[A]	0.1							
power v	ermissible oltage uctuation	AC input	1-phase 323 V AC to 528	3 V AC						
	ermissible freuctuation	quency	±5 % maximum							
	ower consum	ption [W]								
Interface por			<u> </u>		(including CN8 connector	r signals))				
Control meth			Sine-wave PWM control	current control method	T					
the built-in re	egenerative po egenerative res	ower of sistor (Note 2, 3) [W]		15	100	120				
Dynamic bra	ake (Note 4)		Built-in							
Communica	tion function	USB	Connect a personal computer (MR Configurator2 compatible) 1:n communication (up to 32 axes)							
Encoder out	nut nulas	RS-422/RS-485	Compatible (A/B/Z-phase pulse)							
Encoder out Analog mon	· · ·		2 channels	e puise)						
Analog mon	Maximum in frequency		4 Mpulses/s (when using	<u> </u>	0 kpulses/s (when using o	open collector)				
Position control mode	Command	feedback pulse pulse multiplying	Encoder resolution: 26 b		B: 1 to 2147483647, 1/10	0 < A/B < 64000				
	In-position	range setting	0 pulse to ±16777215 pu	ilses (command pulse un	it)					
	Error exces		±3 rotations							
	Torque limit		Set by servo parameters or external analog input (0 V DC to +10 V DC/maximum torque) Analog speed command 1:2000, internal speed command 1:5000							
Speed	Speed cont Analog spe input	ed command			is changeable with [Pr. PC	 C12].)				
control mode	-	uation rate	,		6), 0 % (power fluctuation 10 °C) only when using a	,				
	Torque limit	t	Set by servo parameters	or external analog input	(0 V DC to +10 V DC/max	ximum torque)				
Torque control mode	input	que command	0 V DC to ±8 V DC/maxi	mum torque (input imped	lance: 10 k Ω to 12 k Ω)					
CONTROL HIDGE	Speed limit		· ·		(0 V DC to ± 10 V DC/rate	ed speed)				
Fully closed	loop	MR-J5-A4	Two-wire type communic							
control		MR-J5-A4-RJ	Two-wire/four-wire type of							
Load-side er	ncoder	MR-J5-A4	Mitsubishi Electric high-s	·		in Linea at a laure - 1				
interface		MR-J5-A4-RJ			on, A/B/Z-phase differenti					
Servo function	ons		Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, super trace control							
Protective fu			Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection							
Safety sub-f	unction, Safet	y performance	Refer to "Safety Sub-Functions" on pp. 1-10 and 1-11 in this catalog.							
Structure (IF	rating)		Natural cooling, open (IP20) Force cooling, open (IP20)							
Close moun	ting		Not possible							
Mass		[kg]	1.6		2.2	2.3				

 Rated output and speed of a rotary servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.
 Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
 Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
 When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio. Notes:

MR-J5-A_ Standard Wiring Diagram Example: Position Control Operation

A A-RJ

Connecting to RD75D



Notes: 1. This connection is not necessary for RD75D Positioning module. Note that the connection between LG and the control common terminal is recommended for some Positioning modules to improve noise tolerance.


- 2. This is for sink wiring. Source wiring is also possible.
- 3. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. Pulse train input is available with sink input and source input of open-collector type. When using the source input, use PP2 and NP2 terminals. Refer to "MR-J5 User's Manual" for details.
- 6. The pins with the same signal name are connected in the servo amplifier.



Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

MR-J5-A_ Standard Wiring Diagram Example: Speed Control Operation





Notes: 1. This is for sink wiring. Source wiring is also possible.


- 2. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 3. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 4. The pins with the same signal name are connected in the servo amplifier.



Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

MR-J5-A_ Standard Wiring Diagram Example: Torque Control Operation

A A-RJ



Notes: 1. This is for sink wiring. Source wiring is also possible.

- 2. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 3. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 4. The pins with the same signal name are connected in the servo amplifier.




Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.


Servo Amplifiers

MR-J5-A_ Dimensions

- ●MR-J5-10A, MR-J5-10A-RJ
- ●MR-J5-20A, MR-J5-20A-RJ
- ●MR-J5-40A, MR-J5-40A-RJ



●MR-J5-60A, MR-J5-60A-RJ



[Unit: mm]

[Unit: mm]

A A-RJ


Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.

2. CN2L connector is not available for MR-J5-A servo amplifiers.


A A-RJ

MR-J5-A_ Dimensions

- ●MR-J5-70A, MR-J5-70A-RJ
- ●MR-J5-100A, MR-J5-100A-RJ



- ●MR-J5-200A, MR-J5-200A-RJ
- ●MR-J5-350A, MR-J5-350A-RJ




Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.

2. CN2L connector is not available for MR-J5-A servo amplifiers.


MR-J5-A_ Dimensions

A A-RJ

●MR-J5-500A, MR-J5-500A-RJ



●MR-J5-700A, MR-J5-700A-RJ




Notes: 1. CNP1A, CNP1B, CNP2, and CNP3 connectors are supplied with the servo amplifier.

2. CN2L connector is not available for MR-J5-A servo amplifiers.


A A-RJ

MR-J5-A_ Dimensions

- ●MR-J5-60A4, MR-J5-60A4-RJ
- •MR-J5-100A4, MR-J5-100A4-RJ



- ●MR-J5-200A4, MR-J5-200A4-RJ
- ●MR-J5-350A4, MR-J5-350A4-RJ



CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.
 CN2L connector is not available for MR-J5-A4 servo amplifiers.

Servo Amplifiers


MR-CM3K Specifications (200 V)

MR-CM3K	Specifica	tions (200 V)	G G-RJ WG A A-RJ					
Simple conver	ter unit model		MR-CM3K					
Converter	Rated voltage)	270 V DC to 324 V DC					
output	Rated current	[A]	20					
Main circuit	Voltage/freque	ency	3-phase 200 V AC to 240 V AC, 50 Hz/60 Hz					
power supply	Rated current	[A]	16					
input	Permissible ve	oltage fluctuation	3-phase 170 V AC to 264 V AC					
Thermal sensor			The contact between TH1 and TH2 opens when the thermal sensor detects an overheat condition.					
Overheat		Maximum voltage	110 V AC/DC					
detection function	Contact	Maximum current	3 A at 20 V DC					
Turiction	specification	Minimum current	0.1 mA at 1 V DC					
		Maximum capacity	6 VA					
Compatible se	ervo amplifier		MR-J5-10G/A to MR-J5-200G/A, MR-J5W2-22G to MR-J5W2-1010G, MR-J5W3-222G, MR-J5W3-444G					
Maximum num	nber of connect	able servo amplifiers	6 units					
Total capacity	of servo amplifi	ers to be driven [kW]	3					
Continuous ra	ting	[kW]	3					
Instantaneous	maximum ratir	ng [kW]	9					
Structure (IP ra	ating)		IP20					
Close mountin	ıg		Possible					
Environment			The operating environment is the same as that for the servo amplifiers. Refer to "1. Common Specifications" in this catalog.					
Mass		[kg]	0.7					
Wire size	L1/L2/L3/PE		2 mm ² to 3.5 mm ² (AWG 14 to 12)					
	P4/N-		2 mm ² to 3.5 mm ² (AWG 14 to 12)					
	ngth from P4/N ter to P4/N- of s		5 m or shorter					

G G-RJ WG A A-RJ


Precautions

MR-CM3K Wiring Diagram Example



Notes: 1. Use option daisy chain power connectors when using a simple converter.

- 2. Connect P+ and D.
- 3. The contact between TH1 and TH2 opens when the thermal sensor detects an overheat condition.
- 4. Use a magnetic contactor with an operation delay time of 80 ms or less. The operation delay time is the time interval from current being applied to the coil until closure of contacts
- 5. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 6. Stop the commands from the controller as soon as the main circuit power supply is turned off when an alarm occurs even in one servo amplifier. The following are example methods to turn off the main circuit power supply: Configure a circuit with an I/O module, or connect relays for alarm output corresponding to each servo amplifier to the coil-side of the magnetic contactor in series.
- 7. Install an overcurrent protection device (molded-case circuit breaker, fuse, etc.) to protect the branch circuit.
- 8. Twist or bundle the wires between the simple converter and the servo amplifier and between the servo amplifiers with cable ties to keep the two wires close to each other. Keep the total wiring length between the simple converter and each servo amplifier 5 m or shorter.
- 9. When connecting a linear servo motor with a thermal protector, add a contact to shut off by being interlocked with the thermal protector output of the linear servo motor.
- 10. To turn on/off the main circuit power supply by a DC power supply, wire the circuit as follows. Do not use the 24 V DC interface power supply for the magnetic contactor. Provide a dedicated power supply to the magnetic contactor.



Servo Amplifiers

MR-CM3K Dimensions G G-RJ WG A A-RJ Terminal arrangement CNP1 CNP2 CN10 ø6 mounting hole Approx. 80 (6) 2-M5 screw L1 L2 L3 ī CNP1 CNP2 (168) 156±0.5 PE 165 <u>S</u> <u>CN10</u> Screw size: M4 0 Mounting hole process drawing [Unit: mm]

25.0

Precautions

MR-CV_ Specifications (Note 3) (400 V)

MIN-C	_ Specifications	(" (400 V)							JG
Power rege	eneration converter unit model M	R-CV_	11K4	18K4	30K4	37K4	45K4	55K4	75K4	
Output	Rated voltage		513 V DC to 6	48 V DC			'		'	
Output	Rated current	[A]	21	38	72	82	99	119	150	
Main	Voltage/frequency (Note 1)	3-phase 380 \	/ AC to 480 V A	AC, 50 Hz/60 H	Ηz				
Main circuit	Rated current	[A]	18	35	61	70	85	106	130	
power	Permissible voltage 3-phase 323 V AC to 528 V AC									
input Permissible frequency fluctuation ±3 % maximum										
	Voltage/frequency		1-phase 380 \	/ AC to 480 V A	AC, 50 Hz/60 H	łz				
Control	Rated current	[A]	0.1							
circuit power	Permissible voltage fluctuation		1-phase 323 \	/ AC to 528 V /	AC					
supply input	Permissible frequency fluctuation		±3 % maximu	m						
	Power consumption	[W]	30							
Interface	power supply		24 V DC ± 10	% (required cu	rrent capacity:	0.35 A)				
Capacity	,	[kW]	11	18	30	37	45	55	75	
Protectiv	re functions		MC drive circu protection, ma	Undervoltage protection, regenerative error protection, regenerative overvoltage shut-off, MC drive circuit error protection, open-phase detection, inrush current suppression circuit error protection, main circuit device overheat error protection, cooling fan error protection, overload shut-off electronic thermal)						
Continuo	ous rating	[kW]	7.5	11	20	25		55		
Instantan	neous maximum rating	[kW]		60	92	101	125	175	180	
Structure	e (IP rating)			open (IP20) (N	ote 2)				'	
	_·			,						

Notes: 1. Rated output and speed of a rotary servo motor are applicable when the power regeneration converter unit is operated within the specified power supply voltage and frequency.

2. Terminal blocks are excluded.

Mass

MR-CV_ Connection Example


[kg] 6.1

For the connection example of power regeneration converter units, refer to "Main/Control Circuit Power Supply Connection Example For connecting MR-CV_ and MR-J5D_" in this catalog.


^{3.} MR-CV_4 power regeneration converter units require a mounting attachment. Refer to "Mounting Attachment" in this catalog for details.

MR-CV_ Dimensions

- ●MR-CV11K4
- ●MR-CV18K4



- ●MR-CV30K4
- ●MR-CV37K4
- ●MR-CV45K4



[Unit: mm]


DG

3-76

DG

MR-CV_ Dimensions

- ●MR-CV55K4
- ●MR-CV75K4



Selection of Converter Unit, Servo Amplifier, and Drive Unit

Combination of a simple converter and servo amplifiers

G G-RJ WG A A-RJ

Select a servo amplifier for connection that meets the following conditions.

- · Connectable servo amplifier models
- MR-J5-10_ to MR-J5-200_, MR-J5W2-22G_ to MR-J5W2-1010G_, MR-J5W3-222G_/MR-J5W3-444G_
- The sum of rated capacities [kW] of connected servo amplifiers ≤ 3 kW (MR-CM3K rated output)

 For multi-axis servo amplifiers, the calculation uses the sum of the rated capacities of all axes as the rated capacity of one servo
- Number of connectable servo amplifiers to one MR-CM3K ≤ 6
 A multi-axis servo amplifier is counted as one servo amplifier unit, rather than the number of axes.

	MR-CM3K (200 V)
Maximum number of connectable servo amplifiers	6
Total capacity of connectable servo amplifiers	3 kW
Continuous rating	3 kW
Instantaneous maximum rating	9 kW

Combination of a power regeneration converter unit and drive units

DG

Select a power regeneration converter unit which meets the following conditions. When all the conditions are satisfied, multiple MR-J5D_ drive units can be connected to one power regeneration converter unit. When connecting the multiple MR-J5D_ drive units, install the drive units in descending order of capacity per axis from the right side of the power regeneration converter unit. Refer to "MR-J5D User's Manual" for details of the selection.

- (1) Effective value [kW] of total output power of servo motors ≤ Continuous rating [kW] of MR-CV_
- (2) Maximum value [kW] of total output power of servo motors × 1.2 ≤ Instantaneous maximum rating [kW] of MR-CV_
- (3) Total widths of MR-J5D_ (one side) ≤ 1500 mm

	MR-CV_ (400 V)								
		11K4	18K4	30K4	37K4	45K4	55K4	75K4	
Continuous rating	[kW]	7.5	11	20	25	25	55	55	
Instantaneous maximum rating	[kW]	39	60	92	101	125	175	180	
Total widths of MR-J5D_	norter								

	MR-J5D1(-N1)						MR-J5D2(-N1)				MR-J5D3(-N1)			
			100G4	200G4	350G4	500G4	700G4	100G4	200G4	350G4	500G4	700G4	100G4	200G4
Ī	Unit width	[mm]	60					60			75		60	


Model Designation	4-2
HK-KT Series	
Specifications	1-6
Torque Characteristics	
Dimensions	
Connector Dimensions	
Special Shaft Dimensions	
Geared Servo Motor Specifications	
Geared Servo Motor Dimensions	
Geared Servo Motor Special Shaft Dimensions	
HK-MT Series	
Specifications	4-32
Torque Characteristics	4-34
Dimensions	
Connector Dimensions	
Special Shaft Dimensions	4-39
HK-ST Series	
Specifications	4-40
Torque Characteristics	
Dimensions	
Special Shaft Dimensions	
Geared Servo Motor Specifications	
Geared Servo Motor Dimensions	
Geared Servo Motor Special Shaft Dimensions	4-67
HK-RT Series	
Specifications	4-68
Torque Characteristics	4-70
Dimensions	4-72
Connector Dimensions	4-73
Special Shaft Dimensions	4-73
Power Supply Capacity	4-74

^{*} Refer to p. 7-70 in this catalog for conversion of units.

^{*} In this section, a term of servo amplifier includes a combination of a drive unit and a converter unit.

Model Designation (Note 2)


HK-KT series (low inertia, small capacity)



- Notes: 1. The dimensions are the same regardless of whether or not an oil seal is installed.
 - 2. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.
 - 3. A geared servo motor with an oil seal installed is not available
 - 4. The dimensions of the servo motors with functional safety are the same as those of the standard servo motors.

Model Designation (Note 2)

HK-MT series (ultra-low inertia, small capacity)




Notes: 1. The dimensions are the same regardless of whether or not an oil seal is installed.

2. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

Model Designation (Note 2)

HK-ST series (medium inertia, medium capacity)




Notes: 1. The dimensions are the same regardless of whether or not an oil seal is installed.

- 2. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.
- 3. The standard HK-ST G1/G1H servo motors have a keyed shaft (with a key).
- 4. A geared servo motor with an oil seal installed is not available.
- 5. The dimensions of the servo motors with functional safety are the same as those of the standard servo motors.

Model Designation (Note 2)

HK-RT series (ultra-low inertia, medium capacity)



Notes: 1. The dimensions are the same regardless of whether or not an oil seal is installed.

- 2. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.
- 3. The dimensions of the servo motors with functional safety are the same as those of the standard servo motors.

HK-KT_W (Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	40 × 40			60 × 60					
Rotary servo m	notor model HK-KT	053W	13W	1M3W	13UW	23W	43W	63W		
Continuous	Rated output [kW]	0.05	0.1	0.15	0.1	0.2	0.4	0.6		
running duty (Note 4)	Rated torque (Note 5) [N•m]	0.16 (Note 6)	0.32	0.48	0.32	0.64	1.3	1.9		
Maximum torqu	ue (Note 3) [N•m]	0.56 (0.72)	1.1 (1.4)	1.7 (2.1)	1.1 (1.4)	(2.9)	4.5 (5.7)	6.7 (8.6)		
Rated speed (No	ote 4) [r/min]	3000								
Maximum spee										
Power rate at continuous		6.4	14.8	23.3	8.4	19.4	39.5	61.0		
rated torque [kW/s]	With electromagnetic brake	5.8	14.0	22.4	6.6	16.0	36.7	58.0		
Rated current	[A]	1.3	1.2	1.2	1.1	1.4	2.6	4.5		
Maximum curre	ent (Note 3) [A]	4.6 (6.2)	4.6 (6.0)	4.5 (6.0)	4.6 (6.0)	5.4 (7.1)	9.8 (14)	19 (25)		
Moment of	Without electromagnetic brake	0.0394	0.0686	0.0977	0.121	0.209	0.410	0.598		
inertia J [× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	0.0434	0.0725	0.102	0.153	0.254	0.442	0.629		
Recommended	d load to motor inertia ratio (Note 1)	120 timos or locs (Note 9)			10 times or less (Note 9)	23 times or less (Note 8)	23 times or less	25 times or less		
Speed/position	detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)								
Type		Permanent magnet synchronous motor								
Oil seal		None (Servo motors with an oil seal are available. (HK-KT_J)) (Note 6)								
Electromagneti	ic brake	None (Servo motors with an electromagnetic brake are available. (HK-KT_B))								
Thermistor		None								
Insulation class	3	155 (F)								
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 7)								
Vibration resist	ance ^{*1} [m/s ²]	X: 49, Y: 49								
Vibration rank		V10*3				1				
Permissible	L [mm]					30				
		88				245				
shaft*2		59	l	I	I	98	1. 0	T		
Mass [kg]		0.27	0.37	0.47	0.57	0.77	1.2	1.5		
. 0.	With electromagnetic brake	0.53	0.63	0.73	0.79	1.2	1.6	1.9		

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
 6. The HK-KT053W with an oil seal can be used at a derating rate of 80 %.
- 7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 8. 28 times or less for 6000 r/min or less.
- 9. When the servo motor is combined with a 0.1 kW servo amplifier, the recommended load to motor inertia ratio is for operating the servo motor at the rated speed. If operating the servo motor at a speed exceeding the rated speed, check with the drive system sizing software Motorizer if a regeneration option is required for the operation. A servo amplifier with a larger capacity can be combined.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-KT	053WB	13WB	1M3WB	13UWB	23WB	43WB	63WB	
Type			Spring actuat	Spring actuated type safety brake						
Rated voltage			24 V DC (-10 % to 0 %)							
Power consumption	n	[W] at 20 °C	6.4		7.9					
Electromagnetic brake static [N•m]			0.48 or higher				1.9 or higher			
Permissible	Per braking	[J]	5.6			22				
braking work	Per hour	[J]	56				220			
Electromagnetic	Number of bral	king times	20000							
brake life (Note 2)	Work per braki	ng [J]	5.6			•	22			

1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

^{2.} Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-KT_W (Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	80 × 80							
Rotary servo r	notor model HK-KT	23UW	43UW	7M3W	103W				
Continuous	Rated output [kW]	0.2	0.4	0.75	1.0				
running duty (Note 4)	Rated torque (Note 5) [N•m]	0.64	1.3	2.4	3.2				
Maximum torq	ue (Note 3) [N•m]	1.9 (2.5)	4.5 (5.7)	8.4 (10.7)	11.1 (14.3)				
Rated speed (N	Note 4) [r/min]	` '							
Maximum spe					6500				
Power rate at continuous		9.7	22.3	41.6	60.3				
rated torque [kW/s]	With electromagnetic brake	7.3	18.8	37.7	56.0				
Rated current	[A]	1.5	2.1	4.7	5.0				
Maximum curr	rent (Note 3) [A]	5.9 (9.0)	9.2 (13)	20 (26)	21 (28)				
Moment of inertia J	Without electromagnetic brake	0.419	0.726	1.37	1.68				
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	0.557	0.864	1.51	1.81				
Recommende	d load to motor inertia ratio (Note 1)	10 times or less		16 times or less	17 times or less				
Speed/position	n detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)							
Туре		Permanent magnet synchronous motor							
Oil seal		None (Servo motors with an oil seal are available. (HK-KT_J))							
Electromagne	tic brake	None (Servo motors with an electromagnetic brake are available. (HK-KT_B))							
Thermistor		None							
Insulation clas	S	155 (F)	155 (F)						
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)							
Vibration resis	tance *1 [m/s²]	X: 49, Y: 49							
Vibration rank		V10*3							
Permissible	L [mm]	30		40					
load for the		245		392					
shaft*2		98		147					
Mass [kg]	Without electromagnetic brake	1.2	1.5	2.2	2.4				
Mass [Ng]	With electromagnetic brake	1.6	1.9	2.9	3.1				

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-KT	23UWB	43UWB	7M3WB	103WB			
Type		Spring actuated type sa	Spring actuated type safety brake					
Rated voltage		24 V DC (-10 % to 0 %)	24 V DC (-10 % to 0 %)					
Power consumptio	n [W] at 20 °C	8.2		10				
Electromagnetic briftiction torque	rake static [N·m]	1.3 or higher		3.2 or higher				
Permissible	Per braking [J]	22		64				
braking work	Per hour [J]	220		640				
Electromagnetic	Number of braking times	20000						
brake life (Note 2)	Work per braking [J]	22		64				

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-KT_W (Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	90 × 90							
Rotary servo m	notor model HK-KT	63UW	7M3UW	103UW	153W	203W	202W		
Continuous	Rated output [kW]	0.6	0.75	1.0	1.5	2.0	2.0		
running duty Note 4)	Rated torque (Note 3, 5) [N•m]	1.9 (2.4)	2.4	3.2	4.8	6.4	9.5		
Maximum torqu	ue (Note 3) [N•m]	6.3 (10.3)	8.4 (10.7)	11.1 (14.3)	16.7 (21.5)	19.1 (25.5)	28.6 (38.2)		
Rated speed (No	ote 3, 4) [r/min]	3000 (2400)	3000				2000		
Maximum spee	ed (Note 3, 4) [r/min]	6000 (6700)	6700	6000	6700	6000	3000		
Power rate at continuous rated torque	Without electromagnetic brake	17.3 (27.0)	27.0	37.0	52.0	71.7	111		
(Note 3)	With electromagnetic brake	14.9 (23.3)	23.3	32.9	48.3	67.7	107		
Rated current (Note 3) [A]	3.2 (4.0)	4.0	4.9	8.7	11	9.0		
Maximum curre	ent (Note 3) [A]	12 (20)	16 (22)	21 (27)	34 (46)	34 (48)	30 (41)		
Moment of	Without electromagnetic brake	2.11		2.74	4.38	5.65	8.18		
nertia J × 10 ⁻⁴ kg•m²]	With electromagnetic brake	2.45		3.08	4.72	5.99	8.53		
Recommended	I load to motor inertia ratio (Note 1)	10 times or less 15 times or less							
Speed/position	detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)							
Гуре		Permanent mag	gnet synchronol	us motor					
Oil seal		None (Servo motors with an oil seal are available. (HK-KT_J))							
Electromagneti	c brake	None (Servo motors with an electromagnetic brake are available. (HK-KT_B))							
Thermistor		None							
nsulation class	3	155 (F)							
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)							
Vibration resist	ance *1 [m/s ²]	X: 24.5, Y: 49			X: 24.5, Y: 24.5	5			
/ibration rank		V10 ^{*3}							
Permissible	L [mm]	40							
oad for the	Radial [N]	392							
shaft*2	Thrust [N]	147							
Mace [kg]	Without electromagnetic brake	2.3		2.7	3.6	4.4	5.9		
Mass [kg]	With electromagnetic brake	2.9		3.3	4.7	5.5	7.0		

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

- 6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-KT	63UWB	7M3UWB	103UWB	153WB	203WB	202WB			
Туре			Spring actuated	Spring actuated type safety brake							
Rated voltage			24 V DC (-10 %	24 V DC (-10 % to 0 %)							
Power consumptio	n	[W] at 20 °C	9.0			13.8					
Electromagnetic bi friction torque	Electromagnetic brake static friction torque [N•m]			3.2 or higher			9.5 or higher				
Permissible	Permissible Per braking [J]		66			64					
braking work	Per hour	[J]	660			640					
Electromagnetic	Number of bral	king times	20000			5000					
brake life (Note 2)	Work per braki	ng [J]	33			64					

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

^{2.} Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-KT_4_W (Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

[mm]] 60 × 60		80 × 80		90 × 90				
otor model HK-KT	434W	634W	7M34W	1034W	1534W	2034W	2024W		
Rated output [kW]	0.2	0.3	0.375	0.5	0.75	1.0	1.0		
Rated torque (Note 5) [N•m]	1.3	1.9	2.4	3.2	4.8	6.4	9.5		
e (Note 3) [N•m]	4.5 (5.7)	6.7 (8.6)	8.4 (10.7)	11.1 (14.3)	19.1 (21.5)	22.3 (25.5)	38.2		
e 4) [r/min]	1500						1000		
(Note 4) [r/min]	3500			3000			1500		
Without electromagnetic brake	39.5	61.0	41.6	60.3	52.0	71.7	111		
With electromagnetic brake	36.7	58.0	37.7	56.0	48.3	67.7	107		
[A]	1.3	2.3	2.4	2.5	4.4	5.3	4.5		
nt (Note 3) [A]	4.9 (6.6)	9.1 (13)	9.7 (13)	11 (14)	20 (23)	21 (24)	21		
Without electromagnetic brake	0.410	0.598	1.37	1.68	4.38	5.65	8.18		
With electromagnetic brake	0.442	0.629	1.51	1.81	4.72	5.99	8.53		
load to motor inertia ratio (Note 1)	25 times or less 17 times or less 15 times or less								
detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)								
	Permanent magnet synchronous motor								
	None (Servo motors with an oil seal are available. (HK-KT_J))								
brake	None (Servo motors with an electromagnetic brake are available. (HK-KT_B))								
	None								
	155 (F)								
	Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)								
ince *1 [m/s²]	X: 49, Y: 49 X: 24.5, Y: 24.5								
i dilineolole									
		T		T	1				
-		-					5.9		
With electromagnetic brake	1.6	1.9	2.9	3.1	4.7	5.5	7.0		
	otor model HK-KT Rated output [kW] Rated torque (Note 5) [N•m] Rated torque (Note 5) [Note 3 Note 3 Note 4 Note 5 Note 4 Note 5 Note 3 Note 4 Note 5 Note 4 Note 5 N	Stor model HK-KT 434W 634W 634W	Stor model HK-KT 434W 634W 7M34W 7M34W 634E 7M34W 634E 7M34W 634E 7M34W 634E 7M34W 634E 7M34E 7M34E	Attention Atte	Actor model HK-KT 434W 634W 7M34W 1034W 1534W 15	Note Note		

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-KT	434WB	634WB	7M34WB	1034WB	1534WB	2034WB	2024WB		
Туре			Spring actua	Spring actuated type safety brake							
Rated voltage	Rated voltage				24 V DC (-10 % to 0 %)						
Power consumption	Power consumption [W] at 20 °C			7.9				13.8			
Electromagnetic be friction torque	Electromagnetic brake static friction torque [N•m]				3.2 or highe	3.2 or higher 9.5 or higher		er			
Permissible	Per braking	[J]	22	64							
braking work	oraking work Per hour [J]		220 640								
Electromagnetic	Number of br	Number of braking times		20000							
brake life (Note 2)	Work per bral	king [J]	22		64						

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-KT_W (Low Inertia, Small Capacity)

Specifications when connected with a 400 V servo amplifier

Flange size		[mm]	40 × 40						
Rotary servo m	notor model	HK-KT	053W	13W	1M3W				
Continuous running duty	Rated outp	ut [kW]	0.05	0.1	0.15				
(Note 4)	Rated torqu	ue (Note 5) [N•m]	0.16 (Note 6)	0.32	0.48				
Maximum torqu	ue (Note 3)	[N•m]	0.56 (0.72)	1.1 (1.4)	1.7 (2.1)				
Rated speed (N	ote 4)	[r/min]	,	(1.4)	(2.1)				
Maximum spec		[r/min]							
Power rate at continuous			6.4	14.8	23.3				
rated torque [kW/s]	With electro	omagnetic brake	5.8	14.0	22.4				
Rated current		[A]	1.3	1.2	1.2				
Maximum curre	ent (Note 3)	[A]	4.6 (6.2)	4.6 (6.0)	4.5 (6.0)				
Moment of inertia J	Without ele	ctromagnetic brake	0.0394	0.0686	0.0977				
[x 10 ⁻⁴ kg•m ²]	With electro	omagnetic brake	0.0434	0.0725	0.102				
Recommended	load to	MR-J5	20 times or less						
motor inertia ra	atio (Note 1)	MR-J5D	20 times or less						
Speed/position	detector		Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)						
Type			Permanent magnet synchronous motor						
Oil seal			None (Servo motors with an oil seal are available. (HK-KT_J)) (Note 6)						
Electromagnet	ic brake		None (Servo motors with an electromagnetic brake are available. (HK-KT_B))						
Thermistor			None						
Insulation class	3		155 (F)						
Structure			Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 7)						
Vibration resist	ance*1	[m/s ²]	X: 49, Y: 49						
Vibration rank			V10 '3						
Permissible L [mm]									
load for the Radial [N]									
shaft*2	Thrust	[N]							
Mass [kg]			0.27	0.37	0.47				
	With electro	omagnetic brake	0.53	0.63	0.73				

- 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.
- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. The HK-KT053W with an oil seal can be used at a derating rate of 80 %
- 7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

	o branco opoomioanionio						
Model	HK-KT	053WB	13WB	1M3WB			
Туре		Spring actuated type safety brak	Spring actuated type safety brake				
Rated voltage		24 V DC (-10 % to 0 %)					
Power consumptio	n [W] at 20 °C	6.4					
Electromagnetic bi friction torque	rake static [N•m]	0.48 or higher					
Permissible	Per braking [J]	5.6					
braking work	Per hour [J]	56					
Electromagnetic	Number of braking times	20000					
brake life (Note 2)	Work per braking [J]	5.6					

1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed

HK-KT_4_W (Low Inertia, Small Capacity)

Specifications when connected with a 400 V servo amplifier

Flange size [mm]			n] 60 × 60		80 × 80		
Rotary servo motor model HK-KT			434W	634W	7M34W	1034W	- G
Continuous	Rated outp	out [kW]	0.4	0.6	0.75	1.0	
running duty (Note 4)	Rated torqu	ue (Note 5) [N•m]	1.3	1.9	2.4	3.2	- 9
Maximum torq	ue (Note 3)	[N•m]	4.5 (5.7)	6.7 (8.6)	8.4 (10.7)	11.1 (14.3)	- 0
Rated speed (Note 4)	[r/min]	3000		,		- 2
Maximum speed (Note 4) [r/min]			6700 6500				-
Power rate at continuous rated torque [kW/s] Without electromagnetic brake		ectromagnetic brake	39.5	61.0	41.6	60.3	
		omagnetic brake	36.7	58.0	37.7	56.0	-
Rated current	nt [A]		1.3	2.3	2.4	2.5	-
Maximum current (Note 3) [A]			4.9 (6.6)	9.1 (13)	9.7 (13)	10 (14)	
Moment of inertia J [× 10 ⁻⁴ kg•m ²]	Without electromagnetic brake		0.410	0.598	1.37	1.68	-
	With electromagnetic brake		0.442	0.629	1.51	1.81	- 6
Recommended load to MR-J5			23 times or less	20 times or less (Note 7)	9 times or less (Note 8)	7 times or less (Note 7)	_
motor inertia r	motor inertia ratio (Note 1) MR-J5D		23 times or less	30 times or less	20 times or less	30 times or less	
Speed/position detector			Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)				
Туре			Permanent magnet synchronous motor				_ =
Oil seal			None (Servo motors with an oil seal are available. (HK-KT_J))				- 100
Electromagnetic brake			None (Servo motors with an electromagnetic brake are available. (HK-KT_B))				-
Thermistor			None				_
Insulation class			155 (F)				
Structure			Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)				
Vibration resistance *1 [m/s²]			X: 49, Y: 49				_ =
Vibration rank			V10 '3				- 100
Permissible load for the shaft *2	L [mm]		30 40				
	Radial [N]] 245 392				
	Thrust	[N]] 98 147				
Mass [kg]	Without ele	ectromagnetic brake	1.2	1.5	2.2	2.4	_ p
	With electr	omagnetic brake	1.6	1.9	2.9	3.1	- dubii
Notoc: 1 Conto	at your local cal	on office if the lead to met	or inertia ratio exceeds the va	alue in the table	-		-

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 7. 30 times or less for 3000 r/min or less.
- 8. 20 times or less for 3000 r/min or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

	<u> </u>					
Model HK-KT		434WB	634WB	7M34WB	1034WB	
Туре		Spring actuated type safety brake				
Rated voltage		24 V DC (-10 % to 0 %)				
Power consumptio	n [W] at 20 °C	7.9		10		
Electromagnetic brake static [N•m]		1.9 or higher		3.2 or higher		
Permissible	Per braking [J]	22		64		
braking work	Per hour [J]	220		640		
Electromagnetic	Number of braking times	20000				
brake life (Note 2)	Work per braking [J]	22		64		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-KT_4_W (Low Inertia, Small Capacity)

Specifications when connected with a 400 V servo amplifier

Flange size [mm]			90 × 90					
Rotary servo motor model HK-KT			634UW	1034UW	1534W	2034W	2024W	
Continuous running duty (Note 4)	Rated outp	ut [kW]	0.6	1.0	1.5	2.0	2.0	
	Rated torqu	ue (Note 3, 5) [N•m]	1.9 (2.4)	3.2	4.8	6.4	9.5	
Maximum torque (Note 3) [N•m]			6.3 (10.3)	11.1 (14.3)	16.7 (21.5)	19.1 (25.5)	28.6 (38.2)	
Rated speed (Note 3, 4) [r/min]			3000 (2400)	3000			2000	
Maximum speed (Note 3, 4) [r/min]			6000 (6700)	6000	6700	6000	3000	
Power rate at continuous	Without ele	ectromagnetic brake	17.3 (27.0)	37.0	52.0	71.7	111	
rated torque (Note 3) [kW/s]	With electromagnetic brake		14.9 (23.3)	32.9	48.3	67.7	107	
Rated current (Note 3) [A]			1.6 (2.0)	2.5	4.4	5.3	4.5	
Maximum current (Note 3) [A]			5.6 (9.7)	9.7 (14)	17 (23)	17 (24)	15 (21)	
Moment of	Without ele	ectromagnetic brake	2.11	2.74	4.38	5.65	8.18	
inertia J [x 10 ⁻⁴ kg·m ²]	With electromagnetic brake		2.45	3.08	4.72	5.99	8.53	
Recommended load to MR-J5			10 times or less		11 times or less	10 times or less	15 times or less	
motor inertia ratio (Note 1) MR-J5D		MR-J5D	10 times or less		10 times or less	9 times or less	15 times or less	
Speed/position detector			Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)					
Туре			Permanent magnet synchronous motor					
Oil seal			None (Servo motors with an oil seal are available. (HK-KT_J))					
Electromagnetic brake			None (Servo motors with an electromagnetic brake are available. (HK-KT_B))					
Thermistor			None					
Insulation class			155 (F)					
Structure			Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)					
Vibration resistance *1 [m/s²]			X: 24.5, Y: 49 X: 24.5, Y: 24.5					
			V10 ³					
Permissible	L [mm]							
load for the			392					
shaft*2	Thrust [N]		147	47				
Maga [lea]	Without electromagnetic brake		2.3	2.7	3.6	4.4	5.9	
Mass [kg]	With electromagnetic brake		2.9	3.3	4.7	5.5	7.0	
Notes: 1. Contac	t your local sal	es office if the load to moto	or inertia ratio exceeds t	he value in the table.				

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 7. 30 times or less for 3000 r/min or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model HK-KT		T 634UWB	1034UWB	1534WB	2034WB	2024WB	
Type		Spring actuated type safety brake					
Rated voltage		24 V DC (-10 % to 0 %)					
Power consumption [W] at 20 °C		9.0		13.8			
Electromagnetic brake static friction torque [N•m]		3.2 or higher		9.5 or higher			
Permissible braking work	er braking [J] 66			64			
	Per hour [c	660		640			
Electromagnetic brake life (Note 2)	Number of braking times 20000			5000			
	Work per braking [] 33		64			

1. The electromagnetic brake is for holding. It cannot be used for deceleration applications

^{2.} Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.


HK-KT_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

: For 3-phase 200 V AC -: For 1-phase 200 V AC


HK-KT053W

Standard torque




HK-KT053W

Torque increased




HK-KT13W

Standard torque




HK-KT13W

Torque increased




HK-KT1M3W

Standard torque




HK-KT1M3W

Torque increased




HK-KT13UW

Standard torque




HK-KT13UW

Torque increased




HK-KT23W

Standard torque




HK-KT23W

Torque increased




HK-KT43W

Standard torque




HK-KT43W

Torque increased




HK-KT63W

Standard torque



HK-KT63W

Torque increased




Speed [r/min]

HK-KT_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

: For 3-phase 200 V AC : For 1-phase 200 V AC





Speed [r/min]

Torque increased


3.0
2.5
2.0
Short-duration running range
1.0
Continuous running range

Speed [r/min]











HK-KT7M3WTorque increased


0.0



HK-KT103W Standard torque



HK-KT103W



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC

Precautions


HK-KT_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

: For 3-phase 200 V AC : For 1-phase 200 V AC


HK-KT63UW

Standard torque




HK-KT63UW


Torque increased




HK-KT7M3UW Standard torque




HK-KT7M3UW






HK-KT103UW

Standard torque




HK-KT103UW

Torque increased




HK-KT153W

Standard torque




HK-KT153W

Torque increased




HK-KT203W

Standard torque




HK-KT203W

Torque increased




HK-KT202W

Standard torque



HK-KT202W

Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC


HK-KT_4_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

: For 3-phase 200 V AC -: For 1-phase 200 V AC


HK-KT434W

Standard torque




HK-KT434W

Torque increased




HK-KT634W

Standard torque




HK-KT634W

Torque increased




HK-KT7M34W

Standard torque




HK-KT7M34W

Torque increased




HK-KT1034W

Standard torque




HK-KT1034W

Torque increased




HK-KT1534W

Standard torque




HK-KT1534W

Torque increased




HK-KT2034W

Standard torque




HK-KT2034W

Torque increased



HK-KT2024W

Standard torque



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC


HK-KT_W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier

: For 3-phase 400 V AC : For 3-phase 380 V AC


HK-KT053W

Standard torque




HK-KT053W

Torque increased




HK-KT13W

Standard torque




HK-KT13W

Torque increased




HK-KT1M3W

Standard torque



HK-KT1M3W

Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value.

HK-KT_4_W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier

: For 3-phase 400 V AC : For 3-phase 380 V AC

HK-KT434W Standard torque

Standard torque

6.0

5.0

4.0

5.0

A.0

Short-duration running range

2.0

1.0


Continuous running range

0.0


0 2000 4000 6000 670

Speed [r/min]


HK-KT434WTorque increased



HK-KT634W




HK-KT634W




HK-KT7M34W

Standard torque




HK-KT7M34W




HK-KT1034W

Standard torque



HK-KT1034W





Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC


HK-KT_4_W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier

: For 3-phase 400 V AC -: For 3-phase 380 V AC


HK-KT634UW

Standard torque




HK-KT634UW


Torque increased



HK-KT1034UW Standard torque




HK-KT1034UW



Speed [r/min]


HK-KT1534W

Standard torque




HK-KT1534W

Torque increased




HK-KT2034W

Standard torque




HK-KT2034W

Torque increased




HK-KT2024W

Standard torque



HK-KT2024W


Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC

HK-KT Series Dimensions (Note 3, 4, 5)

HK-KT053W(B), HK-KT13W(B), HK-KT1M3W(B)



Connector



Electromagnetic

Drake (Note 2)	
Pin No.	Signal
I III NO.	name
5	B1
6	B2
•	

nwer sunnly

Power supply		
Pin No.	Signal	
1 111140.	name	
1	E	
2	U	
3	W	
4	V	


Encoder

LIICOUEI	
Pin No.	Signal
	name
11	P5
12	MR
13	LG
14	MRR
	Pin No. 11 12 13

Model	Variable dimensions (Note 1)		
Model	L	KL	
HK-KT053W(B)	55.5	42.8	
HK-K1033W(B)	(90.5)	(77.8)	
LIK KT40M/D)	68	55.3	
HK-KT13W(B)	(103)	(90.3)	
LUZ IZTAMOM/D)	80.5	67.8	
HK-KT1M3W(B)	(115.5)	(102.8)	

[Unit: mm]

HK-KT13UW(B)



Connector



Electromagnetic

nano	
Pin No.	Signal
i iii ivo.	name
5	B1
6	B2

Power supply

	i ower suppry		
	Pin No.	Signal	
		name	
	1	E	
	2	U	
	3	W	
	4	V	

	Pin No.	Signal	
		name	
		11	P5
		12	MR
		13	LG
		14	MRR

Model	Variable dimensions (Note 1)		
iviouei	L	KL	
HK-KT13UW(B)	58.5	46.8	
TK-KT I3UW(D)	(82)	(70.3)	

[Unit: mm]

Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.


- 2. The electromagnetic brake terminals do not have polarity.
- The electromagnetic brake terminals do not have polarity.
 The dimensions are the same regardless of whether or not an oil seal is installed.
- 4. Use a friction coupling to fasten a load.
- 5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
- temperature. Design the machine to allow for sufficient space.

 6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

Precautions

HK-KT Series Dimensions (Note 3, 4, 5)

HK-KT23W(B), HK-KT43W(B), HK-KT63W(B), HK-KT434W(B), HK-KT634W(B)



Connector

Electromagnetic brake (Note 2) Signal Pin No. name 5 B1

ge	6	B2
	Encoder	
.l	Pin No.	Signal
	FIII INO.	name
	11	P5
	12	MR
	13	LG

	12		MR
	13		LG
	14		MRR
Variable dimensions (Note 1)		cione (Note 1)	
vaii	able ullile	_	
L	K		L
67.5		55.8	
(102.1) (90.4		90.4)	
85.5 7		73.8	


[Unit: mm]

Power supply Pin No. name

W

Model	Variable dimensions (Note 1)		
Model	L	KL	
HK-KT23W(B)	67.5	55.8	
HK-K123VV(D)	(102.1)	(90.4)	
HK-KT43W(B)	85.5	73.8	
HK-KT434W(B)	(120.1)	(108.4)	
HK-KT63W(B)	103.5	91.8	
HK-KT634W(B)	(138.1)	(126.4)	
		F1.1	

HK-KT23UW(B), HK-KT43UW(B)



Connector	
13 ①	1/1
5 3	
	motor flang ection →

Signal
name
B1
B2

Electromagnetic

Power supp	ıly	Į
Pin No.	Signal	
1 111 140.	name	l
1	E	
2	U	
3	W	
4	V	l

nal	Pin No.	Signal
ne	I III INO.	name
	11	P5
	12	MR
	13	LG
	14	MRR


Model	Variable o	Variable dimensions (Note 1)	
Model	L	KL	
LIZ ZTOOLIM/D)	65.5	53.8	
HK-KT23UW(B)	(87.5)	(75.8)	
LIZ ZT40LIM/D)	74.5	62.8	
HK-KT43UW(B)	(96.5)	(84.8)	

[Unit: mm]

- Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.
 - 2. The electromagnetic brake terminals do not have polarity.
 - 3. The dimensions are the same regardless of whether or not an oil seal is installed.
 - 4. Use a friction coupling to fasten a load.
 - 5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
 - 6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

HK-KT Series Dimensions (Note 3, 4, 5)

HK-KT7M3W(B), HK-KT103W(B), HK-KT7M34W(B), HK-KT1034W(B)



Connector

13 4

Electromagnetic

rake (NOTE 2)	
Pin No.	Signal
FIII INO.	name
5	B1
6	B2


ower supply		
in No.	Signal	
III INO.	name	
	E	
	U	
	W	
	17	

	Liloodoi	
	Pin No.	Signal
		name
	11	P5
	12	MR
	13	LG
	14	MRR

Model	Variable dimensions (Note 1)	
Model	L	KL
HK-KT7M3W(B)	92.5	80.8
HK-KT7M34W(B)	(128)	(116.3)
HK-KT103W(B)	101.5	89.8
HK-KT1034W(B)	(137)	(125.3)

[Unit: mm]

HK-KT63UW(B), HK-KT7M3UW(B), HK-KT103UW(B), HK-KT153W(B), HK-KT203W(B), HK-KT202W(B), HK-KT634UW(B), HK-KT1034UW(B), HK-KT1534W(B), HK-KT2034W(B), HK-KT2024W(B)



Connector



Electromagnetic

Diane (
Pin No.	Signal
I III INO.	name
5	B1
6	B2
Encoder	

Power supply

	· orror ouppry		
	Pin No.	Signal	
		name	
	1	E	
	2	U	
	3	W	
	4	V	

Pin No.	
---------	--

	Pin No.	Signal					
	1 111 140.	name					
	11	P5					
	12	MR					
	13	LG					
	14	MRR					
_							

Model	Variable dimensions (Note 1)						
Wodel	L	KL					
HK-KT63UW(B) HK-KT634UW(B) HK-KT7M3UW(B)	83.5 (111)	71.8 (99.3)					
HK-KT103UW(B)	92.5	80.8					
HK-KT1034UW(B)	(120)	(108.3)					
HK-KT153W(B)	118.9	107.2					
HK-KT1534W(B)	(158.3)	(146.6)					
HK-KT203W(B)	136.9	125.2					
HK-KT2034W(B)	(176.3)	(164.6)					
HK-KT202W(B)	172.9	161.2					
HK-KT2024W(B)	(212.3)	(200.6)					

[Unit: mm]

1. The dimensions in brackets are for the models with an electromagnetic brake.

2. The electromagnetic brake terminals do not have polarity.

3. The dimensions are the same regardless of whether or not an oil seal is installed.

4. Use a friction coupling to fasten a load.


5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

HK-KT Series Connector Dimensions

Cable direction: load side/opposite to load side

Variable dimensions									
Model	Dual ca	ble type			Single cable type				
	Α	В	С	D	Α	В	С	D	
HK-KT053W HK-KT13W HK-KT1M3W	36.8		12.7		39.6		12.7		
HK-KT13UW HK-KT23W HK-KT43(4)W HK-KT63(4)W	46.6				49.4				
HK-KT23UW HK-KT43UW HK-KT7M3(4)W HK-KT103(4)W	56.6	36	11.7	31.5	59.4	32	11.7	40	
HK-KT63(4)UW HK-KT7M3UW HK-KT103(4)UW HK-KT153(4)W HK-KT203(4)W HK-KT202(4)W	61.6				64.4				




^{*} The drawing shows a dual cable type as an example.

[Unit: mm]

Cable direction: vertical

	Variable dimensions								
Model	Dual cable	type		Single cable type					
	Α	В	С	Α	В	С			
HK-KT053W									
HK-KT13W	63.4		12.7	71.9		12.7			
HK-KT1M3W									
HK-KT13UW									
HK-KT23W	73.2			81.7	32				
HK-KT43(4)W	70.2								
HK-KT63(4)W									
HK-KT23UW				91.7					
HK-KT43UW	83.2	36							
HK-KT7M3(4)W	00.2		11.7			11.7			
HK-KT103(4)W									
HK-KT63(4)UW									
HK-KT7M3UW									
HK-KT103(4)UW	88.2			96.7					
HK-KT153(4)W									
HK-KT203(4)W									
HK-KT202(4)W									



^{*} The drawing shows a dual cable type as an example.

[Unit: mm]

HK-KT Series with Special Shaft Dimensions


Servo motors with the following specifications are also available.

D: D-cut shaft (Note 1)


Model	Variable dimensions					
Model	Q1	Q2				
HK-KT053WD						
HK-KT13WD	21.5	20.5				
HK-KT1M3WD						
HK-KT13UWD	21	20				

L: L-cut shaft (Note 1)

Model	Variable dimensions					
Model	Q1	Q2				
HK-KT053WL						
HK-KT13WL	21.5	20.5				
HK-KT1M3WL						
HK-KT13UWL	21	20				




[Unit: mm]



[Unit: mm]

K: Keyed shaft (with a double round-ended key) (Note 1)


Model	Variable dimensions									
wodei	S	R	Q	W	QK	QL	U	Т	Υ	
HK-KT053WK HK-KT13WK HK-KT1M3WK	8 -0.009	25	21.5	3	14	5	1.8	3	M3 Screw depth:	
HK-KT13UWK			21							
HK-KT23WK HK-KT43(4)WK HK-KT63(4)WK HK-KT23UWK HK-KT43UWK	14-0.011	30	26	5	20	3	3	5	M4 Screw depth: 15	
HK-KT7M3(4)WK HK-KT103(4)WK HK-KT63(4)UWK HK-KT7M3UWK HK-KT103(4)UWK HK-KT153(4)WK HK-KT203(4)WK HK-KT203(4)WK	19 0.013	40	36	6	25	5	3.5	6	M5 Screw depth: 20	



[Unit: mm]

N: Keyed shaft (without a key) (Note 1, 2)

-									
Model	Variable	dimer	isions						
WIOGCI	S	R	Q	W	QK	QL	U	r	Υ
HK-KT053WN									MO
HK-KT13WN	0.0	05	21.5	0 -0 004		_	01	, -	M3
HK-KT1M3WN	8.0.009	25		3-0.004	14	5	1.8 +0.1	1.5	Screw depth:
HK-KT13UWN			21						0
HK-KT23WN									
HK-KT43(4)WN									M4
HK-KT63(4)WN	14 -0.011	30	26	5.0.03	20	3	3 +0.1	2.5	Screw depth:
HK-KT23UWN									15
HK-KT43UWN									
HK-KT7M3(4)WN									
HK-KT103(4)WN									
HK-KT63(4)UWN									M5
HK-KT7M3UWN	19.0013	40	36	6.003	25	5	3.5 +0.1	3	Screw depth:
HK-KT103(4)UWN	19-0.013	40	30	0.0.03	25	3	3.5 0	3	20
HK-KT153(4)WN									20
HK-KT203(4)WN									
HK-KT202(4)WN									
	1				-				



[Unit: mm]

Notes: 1. Do not use the servo motors with a D-cut shaft, an L-cut shaft, or a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft.

2. The servo motor is supplied without a key. The user needs to prepare a key.

HK-KT Series Geared Servo Motor Specifications

With a gear reducer for general industrial machines, flange mounting: G1

			Actual	4 0 011 0		Permissible load to motor inertia	Permi	issible l naft ^{*1}	oad for	Mass [kg]					
Model	Output	Reduction	reduction	Without	With	ratio (Note 2)				Without	With	Lubrication	Mounting		
HK-KT	[kW]	ratio	ratio	electro-	electro-	(when converted	Q	Radial	Thrust	electro-	electro-	method	direction		
			Tallo	magnetic	magnetic	into the servo	[mm]	[N]	[N]	magnetic	magnetic				
				brake	brake	motor shaft)				brake	brake				
		1/5	9/44 0.0764 0.0804		150	200	1.4	1.6							
053G1 0.05	1/12	49/576	0.0984	0.1024	5 times or less	12.5	240	320	1.8	2.0					
		1/20	25/484	0.0804	0.0844	1		370	450	1.8	2.0		Any direction		
		1/5	9/44	0.106	0.110	5 times or less	12.5	150	200	1.5	1.7				
13G1	0.1	1/12	49/576	0.128	0.132			240	320	1.9	2.1				
		1/20	25/484	0.110	0.114			370	450	1.9	2.1				
		1/5	19/96	0.363	0.408			330	350	3.2	3.6	Grease			
23G1	0.2	1/12	961/11664	0.494	0.539	7 times or less	17.5	710	720	3.8	4.2	(filled)			
		1/20	513/9984	0.375	0.420			780	780	3.8	4.2				
		1/5	19/96	0.564	0.596			330	350	3.5	3.9				
43G1	0.4	1/12	961/11664	0.695	0.727	7 times or less	17.5	710	720	4.1	4.5				
		1/20	7/135	0.687	0.719			760	760	5.2	5.6				
		1/5	1/5	1.79	1.93			430	430	5.4	6.1				
7M3G1	0.75	1/12	7/87	1.85	1.99	5 times or less	5 times or less	5 times or less 25	5 times or less 25 62	620	620	6.5	7.2		
		1/20	625/12544	2.52	2.66			970	960	9.4	11				

Item	Specifications					
Mounting method	Flange mounting					
Output shaft rotation direction	Same as the servo motor output shaft direction					
Backlash (Note 4)	minutes or less at gear reducer output shaft					
Maximum torque (Note 5)	Three times of the rated torque (Refer to HK-KT series specifications in this catalog for the rated torque.)					
Maximum speed (at servo motor shaft)	4500 r/min					
IP rating (gear reducer part)	Equivalent to IP44					
Gear reducer efficiency (Note 3)	40 % to 85 %					

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

- 2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.
- 3. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table
- are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.

 4. The backlash can be converted: 1 minute = 0.0167°

 5. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

HK-KT Series Geared Servo Motor Specifications

With a flange-output type gear reducer for high precision applications, flange mounting: G5

			Moment of [x 10 ⁻⁴ kg•1		Permissible load to motor inertia	Permis the sha	sible loa aft ^{*1}	d for	Mass [kg]			
Model HK-KT	Output [kW]	ut Reduction ratio (Note 3)	Without electro-magnetic	With electro-magnetic	ratio (Note 2) (when converted into the servo	L [mm]	Radial	Thrust [N]	Without electro- magnetic	With electro-magnetic	Lubrication method	Mounting direction
			brake	brake	motor shaft)				brake	brake		
		1/5 (40 × 40)	0.0429	0.0469		17	93	431	0.48	0.66		
		1/5 (60 × 60)	0.1074	0.1114		23	177	706	1.1	1.3		
		1/9	0.0419	0.0459		17	111	514	0.49	0.67		
053G5	0.05	1/11	0.0994	0.1034	10 times or less	23	224	895	1.2	1.4		
		1/21	0.0904	0.0944		23	272	1987	1.2	1.4		
		1/33	0.0844	0.0884		23	311	1244	1.2	1.4		
		1/45	0.0844	0.0884		23	342	1366	1.2	1.4		
		1/5 (40 × 40)	0.0721	0.076		17	93	431	0.58	0.76		
		1/5 (60 × 60)	0.137	0.141		23	177	706	1.2	1.4	_	
13G5 C	0.1	1/11	0.129	0.133	10 times or less	23	224	895	1.3	1.5		
	0.1	1/21	0.120	0.124	TO times or less	23	272	1087	1.3	1.5		
		1/33	0.131	0.135		32	733	2581	2.5	2.7		
		1/45	0.130	0.134		32	804	2833	2.5	2.7		
		1/5	0.410	0.455	14 times or less	23	177	706	1.7	2.1		Any
		1/11	0.412	0.457		23	224	895	1.8	2.2		direction
23G5	0.2	1/21	0.707	0.752		32	640	2254	3.3	3.7		
		1/33	0.661	0.706		32	733	2581	3.3	3.7		
		1/45	0.660	0.705		32	804	2833	3.3	3.7		
		1/5	0.611	0.643		23	177	706	2.1	2.5		
		1/11	0.986	1.02		32	527	1856	3.7	4.1		
43G5	0.4	1/21	0.908	0.940	14 times or less	32	640	2254	3.7	4.1		
		1/33	0.960	0.992		57	1252	4992	5.8	6.2		
		1/45	0.954	0.986		57	1374	5478	5.8	6.2	1	
		1/5	2.02	2.16		32	416	1465	4.2	4.9		
		1/11	1.93	2.07		32	527	1856	4.5	5.2		
7M3G5	0.75	1/21	2.12	2.26	⊣	57	1094	4359	6.6	7.3		
		1/33	1.90	2.04		57	1252	4992	6.6	7.3		
		1/45	1.90	2.04		57	1374	5478	6.6	7.3		

Item	Specifications
Mounting method	Flange mounting
Output shaft rotation direction	Same as the servo motor output shaft direction
Backlash (Note 5)	3 minutes or less at gear reducer output shaft
Maximum torque (Note 6)	Three times of the rated torque
Maximum torque (************************************	(Refer to HK-KT series specifications in this catalog for the rated torque.)
Maximum speed (at servo motor shaft)	6000 r/min
IP rating (gear reducer part)	Equivalent to IP44
	HK-KT053G5 1/5 (60 × 60): 12 %
Gear reducer efficiency (Note 4)	HK-KT053G5 1/11, 1/21, 1/33, and 1/45: 22 % to 34 %
	HK-KT053G5 1/5 (40 × 40) and 1/9, and HK-KT13G5 to HK-KT7M3G5: 48 % to 84 %

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

3. The values in brackets represent the dimensions of the flange.

- 4. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.
- 5. The backlash can be converted: 1 minute = 0.0167°
- 6. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

HK-KT Series Geared Servo Motor Specifications

With a shaft-output type gear reducer for high precision applications, flange mounting: G7

			Moment of [× 10 ⁻⁴ kg•	m ²] ^(Note 1)	Permissible load to motor inertia	Permis the sha	sible loa aft ^{*1}	d for	Mass [kg]			
Model HK-KT	Output [kW]	Reduction ratio (Note 3)	Without electro- magnetic brake	With electro- magnetic brake	ratio (Note 2) (when converted into the servo motor shaft)	Q [mm]	Radial [N]	Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method	Mounting direction
		1/5 (40 × 40)	0.0456	0.0496		17	93	431	0.51	0.69		
		1/5 (60 × 60)	0.113	0.117		23	177	706	1.1	1.3		
		1/9	0.0436	0.0476		17	111	514	0.51	0.69		
053G7	0.05	1/11	0.100	0.104	10 times or less	23	224	895	1.2	1.4		
		1/21	0.0904	0.0944		23	272	1987	1.2	1.4		
		1/33	0.0844	0.0884		23	311	1244	1.2	1.4		
		1/45	0.0844	0.0884		23	342	1366	1.2	1.4		
		1/5 (40 × 40)	0.0748	0.0787		17	93	431	0.61	0.79		
		1/5 (60 × 60)	0.143	0.147		23	177	706	1.2	1.4		
13G7	0.1	1/11	0.130	0.134	10 times or less	23	224	895	1.3	1.5		
1307	0.1	1/21	0.120	0.124	10 tilles of less	23	272	1087	1.3	1.5		
		1/33	0.132	0.136		32	733	2581	2.8	3.0		
		1/45	0.130	0.134		32	804	2833	2.8	3.0		
		1/5	0.416	0.461		23	177	706	1.7	2.2	Grease	Any
		1/11	0.412	0.457		23	224	895	1.8	2.3	(filled)	direction
23G7	0.2	1/21	0.709	0.754	14 times or less	32	640	2254	3.7	4.1		
		1/33	0.662	0.707		32	733	2581	3.7	4.1		
		1/45	0.660	0.705		32	804	2833	3.7	4.1		
		1/5	0.617	0.649		23	177	706	2.2	2.6		
		1/11	0.994	1.03		32	527	1856	4.1	4.5		
43G7	0.4	1/21	0.910	0.942	14 times or less	32	640	2254	4.1	4.5		
		1/33	0.966	0.998		57	1252	4992	7.2	7.6		
		1/45	0.957	0.989		57	1374	5478	7.2	7.6		
		1/5	2.06	2.20		32	416	1465	4.6	5.3		
		1/11	1.94	2.08		32	527	1856	4.9	5.6]	
7M3G7	0.75	1/21	2.14	2.28	10 times or less	57	1094	4359	8.0	8.7	1	
		1/33	1.91	2.05		57	1252	4992	8.0	8.7		
		1/45	1.90	2.04		57	1374	5478	8.0	8.7	1	

Item	Specifications	П
Mounting method	Flange mounting	
Output shaft rotation direction	Same as the servo motor output shaft direction	
Backlash (Note 5)	3 minutes or less at gear reducer output shaft	-
Maximum torque (Note 6)	Three times of the rated torque	
Maximum torque (************************************	(Refer to HK-KT series specifications in this catalog for the rated torque.)	
Maximum speed (at servo motor shaft)	6000 r/min	
IP rating (gear reducer part)	Equivalent to IP44	
	HK-KT053G7 1/5 (60 × 60): 12 %	-
Gear reducer efficiency (Note 4)	HK-KT053G7 1/11, 1/21, 1/33, and 1/45: 22 % to 34 %	
	HK-KT053G7 1/5 (40 × 40) and 1/9, and HK-KT13G7 to HK-KT7M3G7: 48 % to 84 %	

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

- Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.
 The values in brackets represent the dimensions of the flange.
- 4. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.
- 5. The backlash can be converted: 1 minute = 0.0167°
- 6. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.


Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

HK-KT Series Geared Servo Motor Dimensions (Note 1, 5)

With a gear reducer for general industrial machines, flange mounting

HK-KT_G1 (Note 6)

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



[Unit: mm]

Model	Reduction ratio	Variable dir	mensions (No	ote 4)													
HK-KT	(Actual reduction ratio)	L	LA	LC	LD	LE	S	LH	LK	KL	LG	Q	LR	M	KA	LT	KC
	1/5	99.2								86.5							
	(9/44)	(134.2)								(121.5)							
053(B)G1	1/12																
033(B)G1	(49/576)	118								105.3							
	1/20	(153)								(140.3)							
	(25/484)		75	60 003	65	50	16 0.011	6.5	8		34.5	25	60.5	7	36.8	12.7	40
	1/5	111.7	7.5	00.03	03	30	10-0.011	0.5	ľ	99	34.3	23	00.5	'	30.0	12.7	40
	(9/44)	(146.7)								(134)							
13(B)G1	1/12																
10(5)41	(49/576)	130.5								117.8							
	1/20	(165.5)								(152.8)							
	(25/484)																
	1/5	120.7								109							
	(19/96)	(155.3)								(143.6)							
23(B)G1	1/12																
20(B)G1	(961/11664)	140.5								128.8							
	1/20	(175.1)	100	82 .0.035	90	75	25 0,013	8		(163.4)	38	35	74				
	(513/9984)		100	OZ .0.035	30	/ 5	20.0.013	ľ			00	000	'-		46.6		60
	1/5	138.7								127					40.0		00
	(19/96)	(173.3)							10	(161.6)				9			
43(B)G1	1/12	158.5							10	146.8				*		11.7	
40(B)G1	(961/11664)	(193.1)								(181.4)						''''	
	1/20	162.5								150.8							
	(7/135)	(197.1)								(185.4)							
	1/5	157.5	115	95.0035	100	83	32 0,016	9.5		145.8	39	50	90				
	(1/5)	(193)	1	00 (0.035	100	00	OZ -0.016	0.0		(181.3)] 00	00					
7M3(B)G1	1/12	179.5								167.8					56.6		80
/WO(D)CI	(7/87)	(215)								(203.3)]50.0		100
	1/20	192.5	140	115 0,035	120	98	40 0,016	11.5	15	180.8	44.5	60	105.5	14			
	(625/12544)	(228)	140	113-0.035	120	30	40 -0.016	11.5	13	(216.3)	44.5	00	100.0	'*			


Notes:

- 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.
- 4. The dimensions in brackets are for the models with an electromagnetic brake.
- 5. Use a friction coupling to fasten a load.
- 6. HK-KT_G1K, a geared servo motor with a keyed shaft (with a key), is also available. Refer to "HK-KT Series Geared Servo Motor Special Shaft Dimensions" in this catalog for details.

HK-KT Series Geared Servo Motor Dimensions (Note 1)

With a flange-output type gear reducer for high precision applications, flange mounting HK-KT_G5

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



W

Pin No.

3

Electromagnetic brake (Note 2)

Pin No. Signal name

5 B1

6 B2

Signal Encode

Pin No. Signal name

11 P5

12 MR

13 LG

14 MRR

[Unit: mm]

Model	Reduction	Variable	dimension	s (Note 4)																	
HK-KT	ratio (Note 5)	L	LA	LB	LC	LD	LE	LF	LG	LH	LK	LM	KL	Т	N	Р	R	М	KA	LT	KC
	1/5 (40 × 40)	95 (130)	46	18	40 .0.025	40	24	5 +0.012	15 +0.25	2.5	5	34.5	82.3 (117.3)	3	3		6	3.4			
	1/5 (60 × 60)	119.5 (154.5)	70	30	56.003	60	40	14 +0.018	21 +0.4	3	8	56	106.8 (141.8)	5	6		7	5.5			
053(B)G5	1/9	95 (130)	46	18	40 .0.025	40	24	5 +0.012	15 +0.25	2.5	5	34.5	82.3 (117.3)	3	3		6	3.4			
	1/11															1			1		
	1/21	119.5	70	30	56.0.03	60	40	14 +0.018	21 +0.4	3	8	56	106.8	_	6	M4	7	5.5			
	1/33	(154.5)	10	30	30.0.03	100	40	14 0	21.05	3	0	36	(141.8)	3	0		'	5.5	36.8	12.7	40
	1/45															_					
	1/5 (40 × 40)	107.5 (142.5)	46	18	40 .0.025	40	24	5 +0.012	15+0.25	2.5	5	34.5	94.8 (129.8)	3	3		6	3.4			
	1/5 (60 × 60)	132											4400			1			1		
13(B)G5	1/11	(167)	70	30	56 .0.03	60	40	14 +0.018	21 +0.4	3	8	56	119.3 (154.3)				7	5.5			
	1/21	(167)											(154.5)								
_	1/33	134.5	105	45	85.0.035	90	59	24 +0.021	27 +0.4	8	10	56.5	121.8			M6	10	9			
	1/45	(169.5)	105	45	OO .0.035	90	59	24 0	27 -0.5	l°	10	36.3	(156.8)			IVIO	10	9			
	1/5	131.5	70	30	56.003	60	40	14+0.018	21 +0.4	3	8	56	119.8]		M4	7	5.5			
	1/11	(166.1)	10	30	30.0.03	00	40	140	21.05	٦	0	30	(154.4)			IVI	'	5.5			
23(B)G5	1/21	138.5											126.8								
	1/33	(173.1)	105	45	85 .0.035	90	59	24 +0.021	27 :0.5	8	10	61	(161.4)			M6	10	9			
	1/45	(170.1)											(101.4)								
	1/5	149.5 (184.1)	70	30	56.003	60	40	14 +0.018	21 :0.4	3	8	56	137.8 (172.4)	5	6	M4	7	5.5	46.6		60
40/D\OF	1/11	156.5	105	45	05.0	00	50	0.4 ±0.021	07+04		40	04	144.8	1		M6	40		1	11.7	
43(B)G5	1/21	(191.1)	105	45	85.0.035	90	59	24 +0.021	27 :0.5	8	10	61	(179.4)			IVIO	10	9		111.7	
	1/33	168.5	135	60	115.0035	120	84	32 +0.025	35 +0.4	13	13	70	156.8	1		M8	12	11	1		
	1/45	(203.1)	135	60	115.0.035	120	84	32 0	35 :0.5	13	13	/0	(191.4)			IVI8	12	' '			
	1/5	170.5	105	45	05.0	00	50	24 +0.021	27 +0.4		40	00	158.8	1			40			1	
	1/11	(206)	105	45	85.0.035	90	59	24 0	27.05	8	10	68	(194.3)			M6	10	9			
'M3(B)G5	1/21	400.5											400.0	1					56.6		80
	1/33	180.5	135	60	115.0.035	120	84	32 +0.025	35 :0.5	13	13	75	168.8			M8	12	11			
	1/45	(216)											(204.3)								


Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.
- 4. The dimensions in brackets are for the models with an electromagnetic brake.
- 5. The values in brackets represent the dimensions of the flange.

HK-KT Series Geared Servo Motor Dimensions (Note 1, 5)

With a shaft-output type gear reducer for high precision applications, flange mounting HK-KT_G7 $^{(\text{Note 7})}$

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



[Unit: mm]

Model	Reduction	Variable di	mensions (N	lote 4)														
HK-KT	ratio (Note 6)	L	LA	LC	LD	LE	S	LG	LH	Q	LR	LK	LM	KL	M	KA	LT	KC
	1/5 (40 × 40)	95 (130)	46	40 -0.025	40	29	10 .0.015	15	2.5	20	42	5	34.5	82.3 (117.3)	3.4			
	1/5 (60 × 60)	119.5 (154.5)	70	56.003	60	40	16 0 0 18	21	3	28	58	8	56	106.8 (141.8)	5.5			
053(B)G7	1/9	95 (130)	46	40 .0.025	40	29	10.0015	15	2.5	20	42	5	34.5	82.3 (117.3)	3.4			
	1/11															1		
	1/21	119.5	70	56.003	60	40	16.0018	21	3	28	58	8	56	106.8	5.5			
	1/33	(154.5)	/0	30.0.03	00	40	10.0.018	21	3	20	36	l°	36	(141.8)	5.5	36.8	12.7	40
	1/45																	
	1/5 (40 × 40)	107.5 (142.5)	46	40 .0.025	40	29	10 0.015	15	2.5	20	42	5	34.5	94.8 (129.8)	3.4			
	1/5 (60 × 60)	132												119.3				
13(B)G7	1/11	(167)	70	56 0.03	60	40	16.0.018	21	3	28	58	8	56	(154.3)	5.5			
	1/21	(107)												<u>'</u>				
	1/33	134.5	105	85.0035	90	59	25 0.021	27	8	42	80	10	56.5	121.8	9			
	1/45	(169.5)	103	00-0.035	30	33	23 -0.021	-		72	00	10	30.5	(156.8)	3			
	1/5	131.5	70	56.003	60	40	16.0018	21	3	28	58	8	56	119.8	5.5			
	1/11	(166.1)					0.016	ļ	-			-		(154.4)				
23(B)G7	1/21	138.5												126.8				
	1/33	(173.1)	105	85 .0.035	90	59	25 .0.021	27	8	42	80	10	61	(161.4)	9			
	1/45	, ,												, ,				
	1/5	149.5 (184.1)	70	56.003	60	40	16 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	21	3	28	58	8	56	137.8 (172.4)	5.5	46.6		60
43(B)G7	1/11	156.5	105	85.0035	90	59	25.0021	27	8	42	80	10	61	144.8	9		11.7	
43(B)G7	1/21	(191.1)	103	03.0.035	30	39	23.0.021	21	0	42	00	10	01	(179.4)	3		111.7	
	1/33	168.5	135	115.0035	120	84	40 .0.025	35	13	82	133	13	70	156.8	11			
	1/45	(203.1)	1.00	110.0.035	120	ļ ·	10 -0.025	00		02	100			(191.4)				
	1/5	170.5	105	85.0.035	90	59	25.0.021	27	8	42	80	10	68	158.8	9			
	1/11	(206)	1.00	0.035	"	00	20 10.021	-'	<u> </u>		100	1.0	00	(194.3)				
7M3(B)G7	1/21	180.5												168.8		56.6		80
	1/33	(216)	135	115 0.035	120	84	40 -0.025	35	13	82	133	13	75	(204.3)	11			
	1/45	(=)												(==0)				

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.
- 4. The dimensions in brackets are for the models with an electromagnetic brake.
- 5. Use a friction coupling to fasten a load.
- 6. The values in brackets represent the dimensions of the flange.
- 7. HK-KT_G7K, a geared servo motor with a keyed shaft (with a key), is also available. Refer to "HK-KT Series Geared Servo Motor Special Shaft Dimensions" in this catalog for details.

HK-KT Series Geared Servo Motor Special Shaft Dimensions

The standard HK-KT_G1 (with a gear reducer for general industrial machines) and HK-KT_G7 (with a shaft-output type gear reducer for high precision applications, flange mounting) have a straight shaft. Note that these motors are also available with a keyed shaft (with a key) as HK-KT_G1K and HK-KT_G7K.

HK-KT_G1K (Note 1, 2)


Keyed shaft (with a double square-ended key)





[Unit: mm]

HK-KI_G/K (Note 1, 2)	
Keyed shaft (with a single pointed ke	y)





[Unit: mm]

	Reduction ratio	Variable	dime	ensio	ns			
Model	(Actual reduction ratio)	S	Q	W	QK	U	Т	Υ
	1/5							
	(9/44)							
LIK KTOFO/D\O4K	1/12	ĺ						
HK-KT053(B)G1K	(49/576)							
	1/20							
	(25/484)	16 -0.011	25	5	20	3	5	M4 Screw
	1/5 (9/44)							depth: 8
	1/12	-						
HK-KT13(B)G1K	(49/576)							
	1/20							
	(25/484)							
	1/5							
	(19/96)	ļ						
HK-KT23(B)G1K	1/12							
` '	(961/11664)							M6 Screw
	(513/9984)	25 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	35	8	30	4	7	depth: 12
	1/5	<u> </u>						deptil. 12
	(19/96)							
LIK KTAO/D\OAK	1/12	ĺ						
HK-KT43(B)G1K	(961/11664)							
	1/20							
	(7/135)	ļ						
	1/5	32 -0.016	50	10	40			M8 Screw
	1/12					5	8	depth: 16
HK-KT7M3(B)G1K	(7/87)							
	1/20							M10 Screw
	(625/12544)	40 -0.016	60	12	50			depth: 20

Model	Reduction	Varia	able dir	nensio	ns			
Model	ratio (Note 3)	S	Q	W	QK	U	Т	Υ
	1/5 (40 × 40)	10	20	4	15	2.5	4	M3 Screw depth: 6
	1/5 (60 × 60)	16	28	5	25	3	5	M4 Screw depth: 8
HK-KT053(B)G7K	1/9	10	20	4	15	2.5	4	M3 Screw depth: 6
	1/11							
	1/21	16	28	5	25	3	5	M4 Screw
	1/33	10	20	3	25	١٥	3	depth: 8
	1/45							
	1/5 (40 × 40)	10	20	4	15	2.5	4	M3 Screw depth: 6
HK-KT13(B)G7K	1/5 (60 × 60) 1/11 1/21	16	28	5	25	3	5	M4 Screw depth: 8
	1/33		+			+	+	M6 Screw
	1/45	25	42	8	36	4	7	depth: 12
	1/5		+					M4 Screw
	1/11	16	28	5	25	3	5	depth: 8
HK-KT23(B)G7K	1/21						1	doptiii o
TIIC TCT20(B)GTTC	1/33	25	42	8	36	4	7	M6 Screw
	1/45					'		depth: 12
	1/5	16	28	5	25	3	5	M4 Screw depth: 8
	1/11		1.0		1	1.	1	M6 Screw
HK-KT43(B)G7K	1/21	25	42	8	36	4	7	depth: 12
	1/33	1.0	1			_	1_	M10 Screw
	1/45	40	82	12	70	5	8	depth: 20
	1/5	٥٦	40	_	00	4	7	M6 Screw
	1/11	25	42	8	36	4	7	depth: 12
HK-KT7M3(B)G7K	1/21				+			M10 Corcili
	1/33	40	82	12	70	5	8	M10 Screw depth: 20
	1/45							GGPIII. 20

Notes: 1. Do not use the servo motors with a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft.

- 2. Dimensions not shown in the tables are respectively the same as those of HK-KT_G1 and HK-KT_G7 with a straight shaft. Refer to "HK-KT_G1" and "HK-KT_G7" of "HK-KT Series Geared Servo Motor Dimensions" in this catalog.
- 3. The values in brackets represent the dimensions of the flange.

HK-MT_W (Ultra-Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size		[mm]	40 × 40			60 × 60			80 × 80	
Rotary servo r	notor model	HK-MT	053W	13W	1M3W	23W	43W	63W	7M3W	103W
Continuous	Rated output	[kW]	0.05	0.1	0.15	0.2	0.4	0.6	0.75	1.0
running duty (Note 4)	Rated torque (Note 5)	[N·m]	0.16 (Note 6)	0.32	0.48	0.64	1.3	1.9	2.4	3.2
Maximum torq	ue (Note 3)	[N•m]	0.48 (0.64)	0.95 (1.3)	1.4 (1.9)	1.9 (2.3)	3.8 (4.5)	5.7 (7.1)	7.2 (8.8)	9.5 (12.4)
Rated speed (Note 4)	[r/min]	3000	,	,	,	,	,	,	,
Maximum spe	ed (Note 4)	[r/min]	6700		,					
Power rate at continuous	Without electromagnet	tic brake	12.5	31.7	52.2	41.5	101.3	155.9	104.6	142.5
rated torque [kW/s]	With electromagnetic b	orake	10.4	28.1	47.8	31.2	84.4	137.1	83.4	119.3
Rated current		[A]	1.2	1.2	1.2	1.6	2.5	5.3	5.8	5.4
Maximum curr	rent (Note 3)	[A]	4.3 (6.3)	4.6 (5.9)	4.6 (6.5)	6.3 (9.8)	9.7 (13)	21 (28)	21 (31)	20 (31)
Moment of inertia J	Without electromagnet	tic brake	0.0203	0.0320	0.0437	0.0976	0.160	0.234	0.545	0.711
[× 10 ⁻⁴ kg•m ²]	With electromagnetic b	orake	0.0243	0.0360	0.0477	0.130	0.192	0.266	0.683	0.849
Recommende	d load to motor inertia ra	atio (Note 1)	35 times or	less (Note 8)	35 times o	rless				
Speed/position	n detector		Batteryless	absolute/in	cremental 2	6-bit encode	er (resolutio	n: 67,108,86	4 pulses/rev	/)
Туре			Permanent	magnet syr	nchronous m	otor				
Oil seal			None (Serv	o motors wi	th an oil sea	l are availal	ble. (HK-MT	_J))		
Electromagne	tic brake		None (Serv	o motors wi	th an electro	magnetic b	rake are av	ailable. (HK-	·MT_B))	
Thermistor			None							
Insulation clas	s		155 (F)							
Structure			Totally encl	osed, natura	al cooling (IF	rating: IP6	7) (Note 2, 7)			
Vibration resis	tance *1	[m/s ²]	X: 49, Y: 49)						
Vibration rank			V10 ^{*3}	_						
Permissible	L	[mm]				30			40	
load for the	Radial	[N]				245			392	
shaft*²	Thrust	[N]	59			98			147	
Mass [kg]	Without electromagnet			0.43	0.54	0.92	1.4	1.8	2.8	3.3
mass [ng]	With electromagnetic b	orake	0.59	0.74	0.82	1.4	1.8	2.2	3.5	3.9

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. The HK-MT053W with an oil seal can be used at a derating rate of 80 %.
- 7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 8. When the servo motor is combined with a 0.1 kW servo amplifier, the recommended load to motor inertia ratio is for operating the servo motor at the rated speed. If operating the servo motor at a speed exceeding the rated speed, check with the drive system sizing software Motorizer if a regeneration option is required for the operation. A servo amplifier with a larger capacity can be combined.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

	· .			1			1				
Model		HK-MT	053WB	13WB	1M3WB	23WB	43WB	63WB	7M3WB	103WB	
Туре			Spring actu	lated type s	afety brake						
Rated voltage			24 V DC (-	10 % to 0 %	(a)						
Power consumption	on	[W] at 20 °C	6.4			7.9			10		
Electromagnetic b friction torque	rake static	[N•m]	0.48 or hig	her	3.2 or high	er					
Permissible	Per braking	[J]	5.6			22		64			
braking work	Per hour	[J]	56 220						640		
Electromagnetic	Number of br	aking times	20000								
brake life (Note 2)	Work per bral	king [J]	J] 5.6 22 64								

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

^{2.} Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-MT_VW (Ultra-Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	40 × 40			60 × 60			80 × 80	
Rotary servo m	notor model HK-MT	053VW	13VW	1M3VW	23VW	43VW	63VW	7M3VW	103VW
Continuous	Rated output [kW]	0.05	0.1	0.15	0.2	0.4	0.6	0.75	1.0
running duty (Note 4)	Rated torque (Note 5) [N•m]	0.16 (Note 6)	0.32	0.48	0.64	1.3	1.9	2.4	3.2
Maximum torqu	ue (Note 3) [N•m]	0.48 (0.64)	0.95 (1.3)	1.4 (1.9)	1.9 (2.3)	3.8 (4.5)	5.7 (7.1)	7.2 (8.8)	9.5 (11.5)
Rated speed (N	ote 4) [r/min]		,	/	/	/	,	,	,
Maximum spee	ed (Note 4) [r/min]	10000							
Power rate at continuous	Without electromagnetic brake	12.5	31.7	52.2	41.5	101.3	155.9	104.6	142.5
rated torque [kW/s]	With electromagnetic brake	10.4	28.1	47.8	31.2	84.4	137.2	83.4	119.3
Rated current	[A]	1.2	1.2	1.2	1.6	3.0	5.3	5.8	8.1
Maximum curre	ent (Note 3) [A]	4.3 (6.3)	4.6 (5.9)	4.6 (6.5)	6.3 (9.8)	12 (15)	21 (28)	21 (31)	30 (37)
Moment of inertia J	Without electromagnetic brake	0.0203	0.0320	0.0437	0.0976	0.160	0.234	0.545	0.711
[x 10 ⁻⁴ kg·m ²]	With electromagnetic brake	0.0243	0.0360	0.0477	0.130	0.192	0.266	0.683	0.849
Recommended	load to motor inertia ratio (Note 1)	24 times or	less (Note 8)	24 times or	less		30 times or	less	
Speed/position	detector	Incrementa	l 26-bit enco	der (resolut	ion: 67,108,	364 pulses/re	ev)		
Туре		Permanent	magnet syn	chronous m	otor				
Oil seal		None (Serv	o motors wi	th an oil sea	l are availab	le. (HK-MT_	VJ))		
Electromagnet	ic brake	None (Serv	o motors wi	th an electro	magnetic br	ake are avai	lable. (HK-N	IT_VB))	
Thermistor		None							
Insulation class	8	155 (F)							
Structure		Totally encl	osed, natura	al cooling (IF	rating: IP67	7) (Note 2, 7)			
Vibration resist	rance *1 [m/s ²]	X: 49, Y: 49)						
Vibration rank		V10 ^{*3}							
Permissible	L [mm]				30			40	
load for the	Radial [N]				245			392	
shaft*2	Thrust [N]	59			98			147	
Mass [kg]	Without electromagnetic brake		0.43	0.54	0.92	1.4	1.8	2.8	3.3
mass [ng]	With electromagnetic brake	0.59	0.74	0.82	1.40	1.8	2.2	3.5	3.9

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. The HK-MT053VW with an oil seal can be used at a derating rate of 80 %.
- 7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 8. When the servo motor is combined with a 0.1 kW servo amplifier, the recommended load to motor inertia ratio is for operating the servo motor at the rated speed. If operating the servo motor at a speed exceeding the rated speed, check with the drive system sizing software Motorizer if a regeneration option is required for the operation. A servo amplifier with a larger capacity can be combined.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

	·								
Model	HK-MT	053VWB	13VWB	1M3VWB	23VWB	43VWB	63VWB	7M3VWB	103VWB
Туре		Spring actu	ated type sa	afety brake					
Rated voltage		24 V DC (-1	10 % to 0 %)					
Power consumption	n [W] at 20 °C	6.4			7.9			10	
Electromagnetic bi friction torque	rake static [N•m]	0.48 or high	ner		1.9 or high	er		3.2 or high	er
Permissible	Per braking [J]	5.6			22			64	
braking work	Per hour [J]	56			220		,	640	
Electromagnetic	Number of braking times	20000							
brake life (Note 2)	Work per braking [J]	5.6			22			64	

1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

HK-MT_W Torque Characteristics (Note 1)

Specifications when connected with a 200 V servo amplifier

: For 3-phase 200 V AC -: For 1-phase 200 V AC

HK-MT053W

0.3

0.2


0.1

0.0


Standard torque 0.7 0.6 0.5 Short-duration

HK-MT053W

Torque increased




HK-MT13W



Speed [r/min]

HK-MT13W

Torque increased




HK-MT1M3W

Standard torque

Continuous


running range

Speed [r/min]




HK-MT1M3W

Torque increased




HK-MT23W

Standard torque




HK-MT23W

Torque increased




HK-MT43W

Standard torque




HK-MT43W

Torque increased




HK-MT63W

Standard torque




HK-MT63W

Torque increased




HK-MT7M3W

Standard torque




HK-MT7M3W

Torque increased




HK-MT103W

Standard torque



HK-MT103W

Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC


HK-MT_VW Torque Characteristics (Note 1)

Specifications when connected with a 200 V servo amplifier

: For 3-phase 200 V AC : For 1-phase 200 V AC


HK-MT053VW

Standard torque




HK-MT053VW


Torque increased




HK-MT13VWStandard torque




HK-MT13VW






HK-MT1M3VW

Standard torque




HK-MT1M3VW

Torque increased




HK-MT23VW

Standard torque




HK-MT23VW

Torque increased




HK-MT43VW

Standard torque




HK-MT43VW

Torque increased




HK-MT63VW

Standard torque




HK-MT63VW

Torque increased




HK-MT7M3VW

Standard torque




HK-MT7M3VW

Torque increased




HK-MT103VW

Standard torque



HK-MT103VW


Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC

HK-MT Series Dimensions (Note 3, 4, 5)

HK-MT053W(B), HK-MT13W(B), HK-MT1M3W(B) HK-MT053VW(B), HK-MT13VW(B), HK-MT1M3VW(B)



Connector



Electromagnetic brake (Note 2)

Pin No.	Signal
FIII NO.	name
5	B1
6	B2

Power supply

i owoi ouppiy				
Pin No.	Signal			
I III INO.	name			
1	E			
2	U			
3	W			
4	V			


Encoder

Pin No.	Signal
1 111140.	name
11	P5
12	MR
13	LG
14	MRR

Model	Variable dimensions (Note 1)			
Iviouei	L	KL		
HK-MT053W(B)	61.3	48.6		
HK-MT053VW(B)	(96.3)	(83.6)		
HK-MT13W(B)	74.8	62.1		
HK-MT13VW(B)	(109.8)	(97.1)		
HK-MT1M3W(B)	88.3	75.6		
HK-MT1M3VW(B)	(123.3)	(110.6)		

[Unit: mm]

HK-MT23W(B), HK-MT43W(B), HK-MT63W(B), HK-MT23VW(B), HK-MT43VW(B), HK-MT63VW(B)



Connector



Electromagnetic

orake (NOTE 2)				
Pin No.	Signal			
	name			
5	B1			
6	B2			

Power supply

Pin No.	Signal name	Pin
1	E	11
2	U	12
3	W	13
4	V	14

Encoder

	Pin No.	Signal
FIII NO.		name
	11	P5
	12	MR
	13	LG
	14	MRR

Model	Variable dimensions (Note 1)			
Model	L	KL		
HK-MT23W(B)	76.6	64.9		
HK-MT23VW(B)	(111.2)	(99.5)		
HK-MT43W(B)	96.1	84.4		
HK-MT43VW(B)	(130.7)	(119)		
HK-MT63W(B)	118.6	106.9		
HK-MT63VW(B)	(153.2)	(141.5)		

[Unit: mm]


Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are the same regardless of whether or not an oil seal is installed.
- 4. Use a friction coupling to fasten a load.
- 5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
- 6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-MT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

Product List

HK-MT Series Dimensions (Note 3, 4, 5)

HK-MT7M3W(B), HK-MT103W(B) HK-MT7M3VW(B), HK-MT103VW(B)



Connector

2



Electromagnetic brake (Note 2 Signal Pin No. name

B1 B2

Power supply Encoder Pin No

	- 7		
).	Signal name	Pin No.	Signal name
	E	11	P5
	U	12	MR
	W	13	LG
	V	14	MRR

Model	Variable dimensions (Note 1)			
iviodei	L	KL		
HK-MT7M3W(B)	110	98.3		
HK-MT7M3VW(B)	(145.5)	(133.8)		
HK-MT103W(B)	129.5	117.8		
HK-MT103VW(B)	(165)	(153.3)		

[Unit: mm]

- Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.
 - 2. The electromagnetic brake terminals do not have polarity.
 - 3. The dimensions are the same regardless of whether or not an oil seal is installed.
 - 4. Use a friction coupling to fasten a load.
 - 5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
 - 6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-MT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.


HK-MT Series Connector Dimensions


Cable direction: load side/opposite to load side

	Variable dimensions							
Model	Dual cable type			Single cable type				
	Α	В	С	D	Α	В	С	D
HK-MT053(V)W								
HK-MT13(V)W	36.8		12.7		39.6		12.7	
HK-MT1M3(V)W								
HK-MT23(V)W]]		00		40
HK-MT43(V)W	46.6	36		31.5	49.4	32		40
HK-MT63(V)W			11.7				11.7	
HK-MT7M3(V)W HK-MT103(V)W	56.6				59.4			
HK-IVI I 103(V)VV								

Cable direction: vertical

	Variable dimensions					
Model	Dual cable type			Single cable type		
	Α	В	С	Α	В	С
HK-MT053(V)W						
HK-MT13(V)W	63.4		12.7	71.9		12.7
HK-MT1M3(V)W						
HK-MT23(V)W		00			00	
HK-MT43(V)W	73.2	36		81.7	32	
HK-MT63(V)W		11.	11.7			11.7
HK-MT7M3(V)W	00.0			04.7		
HK-MT103(V)W	83.2			91.7		






Cable direction: opposite to load side



 * The drawing shows a dual cable type as an example.

[Unit: mm]



 * The drawing shows a dual cable type as an example.

[Unit: mm]

Precautions

HK-MT Series with Special Shaft Dimensions

Servo motors with the following specifications are also available.

D: D-cut shaft (Note 1)


Model	Variable dimensions				
Model	Q1	Q2			
HK-MT053(V)WD					
HK-MT13(V)WD	21.5	20.5			
HK-MT1M3(V)WD					

Q1

[Unit: mm]

L: L-cut shaft (Note 1)


Model	Variable dimensions				
Model	Q1	Q2			
HK-MT053(V)WL					
HK-MT13(V)WL	21.5	20.5			
HK-MT1M3(V)WL					



[Unit: mm]


K: Keyed shaft (with a double round-ended key) (Note 1)

Model	Variable	dimen	sions						
Model	S	R	Q	W	QK	QL	U	Т	Υ
HK-MT053(V)WK									M3
HK-MT13(V)WK	8-0.009	25	21.5	3	14	5	1.8	3	Screw depth:
HK-MT1M3(V)WK									8
HK-MT23(V)WK									M4
HK-MT43(V)WK	14.0.011	30	26	5	20	3	3	5	Screw depth:
HK-MT63(V)WK									15
HK-MT7M3(V)WK									M5
HK-MT103(V)WK	19.0.013	40	36	6	25	5	3.5	6	Screw depth:
TIK-WIT 103(V)VVK									20



N: Keyed shaft (without a key) (Note 1, 2)

Model	Variable dimensions								
Wodel	S	R	Q	W	QK	QL	U	r	Υ
HK-MT053(V)WN HK-MT13(V)WN HK-MT1M3(V)WN	8 .0.009	25	21.5	3-0.004	14	5	1.8 +0.1	1.5	M3 Screw depth: 8
HK-MT23(V)WN HK-MT43(V)WN HK-MT63(V)WN	14 .0.011	30	26	5 -0.03	20	3	3 +0.1	2.5	M4 Screw depth: 15
HK-MT7M3(V)WN HK-MT103(V)WN	19 .0.013	40	36	6-0.03	25	5	3.5 +0.1	3	M5 Screw depth: 20



[Unit: mm]

Notes: 1. Do not use the servo motors with a D-cut shaft, an L-cut shaft, or a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft.

2. The servo motor is supplied without a key. The user needs to prepare a key.

HK-ST_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	130 × 130					
Rotary servo mo	otor model HK-ST	52W	102W	172W	202AW	302W	
Continuous	Rated output [kW]	0.5	1.0	1.75	2.0	3.0	
running duty	Rated torque (Note 3, 5) [N•m]	2.4 (3.2)	4.8 (6.4)	8.4	9.5 (11.6)	14.3	
Maximum torqu	e (Note 3) [N•m]	7.2 (12.7)	14.3 (19.1)	25.1	28.6 (34.7)	43.0 (50.1)	
Rated speed (Not		2000 (1500)	2000 (1500)	2000	2000 (1650)	2000	
Maximum speed	d (Note 4) [r/min]	4000				2500	
Power rate at continuous rated torque	Without electromagnetic brake	9.7 (17.2)	26.3 (46.8)	61.2	53.9 (79.2)	91.5	
(Note 3) [kW/s]	With electromagnetic brake	7.0 (12.4)	20.9 (37.2)	51.1	47.8 (70.3)	83.6	
Rated current (N	ote 3) [A]	3.0 (4.0)	5.3 (7.0)	9.3	11 (13)	11	
Maximum curre	nt (Note 3) [A]	11 (19)	18 (24)	32	34 (42)	34 (40)	
Moment of	Without electromagnetic brake	5.90	8.65	11.4	16.9	22.4	
inertia J [x 10 ⁻⁴ kg•m ²]	With electromagnetic brake	8.15	10.9	13.7	19.1	24.5	
Recommended	load to motor inertia ratio (Note 1)	15 times or less (Note 6) 23 times or less 24 times or less					
Speed/position	detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)					
Туре			t synchronous mote				
Oil seal		None (Servo motors with an oil seal are available. (HK-ST_J))					
Electromagnetic	c brake	`	rs with an electrom	agnetic brake are a	vailable. (HK-ST_B))	
Thermistor		None					
Insulation class		155 (F)					
Structure		•	atural cooling (IP ra	ating: IP67) (Note 2)			
Vibration resista	ance *1 [m/s ²]	X: 24.5, Y: 49					
Vibration rank		V10 *3					
Permissible	L [mm]						
load for the shaft *2		980					
Stidit -		490		l	0.4		
Mass [kg]	Without electromagnetic brake		6.0	7.1	9.1	11	
	With electromagnetic brake	6.8	7.8	8.8	11	13	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. 19 times or less for 3000 r/min or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-S1	52WB	102WB	172WB	202AWB	302WB	
Type		Spring actuated type	Spring actuated type safety brake				
Rated voltage		24 V DC (-10 % to	0 %)				
Power consumption	on [W] at 20 °C	20			23		
Electromagnetic b	orake static [N•m	8.5 or higher			16 or higher		
Permissible	Per braking [J	400					
braking work	Per hour [J	4000					
Electromagnetic	Number of braking times	20000 5000					
brake life (Note 2)	Work per braking [J	200			400		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

HK-ST_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	176 × 176				ICALIONS
Rotary servo m	notor model HK-ST	202W	352W	502W	702W	ons
Continuous	Rated output [kW]	2.0	3.5	5.0	7.0	
running duty (Note 4)	Rated torque (Note 3, 5) [N•m]	9.5 (12.7)	16.7 (20.3)	23.9 (28.9)	33.4	Con
Maximum torqu	ue (Note 3) [N•m]	28.6 (38.2)	50.1 (60.8)	71.6 (86.8)	100	Controllers
Rated speed (No	ote 3, 4) [r/min]	2000 (1500)	2000 (1650)	2000 (1650)	2000	()
Maximum spee	ed (Note 4) [r/min]	4000	3500	4000	3000	
Power rate at continuous rated torque	Without electromagnetic brake	25.1 (44.6)	52.1 (76.5)	80.4 (118)	106	-
(Note 3) [kW/s]	With electromagnetic brake	22.0 (39.2)	47.7 (70.0)	75.2 (110)	101	
Rated current (*	Note 3) [A]	10 (14)	16 (19)	27 (32)	28	~
Maximum curre	ent (Note 3) [A]	32 (45)	52 (66)	90 (110)	102	Viotors
Moment of	Without electromagnetic brake	36.4	53.6	70.8	105	
inertia J [× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	41.4	58.6	75.8	110	
Recommended	load to motor inertia ratio (Note 1)	15 times or less (Note 6)	12 times or less (Note 7)	10 times or less (Note 8)	8 times or less (Note 8)	3
Speed/position	detector	Batteryless absolute/inc	cremental 26-bit encode	r (resolution: 67,108,864	pulses/rev)	Motors
Type		Permanent magnet syn	chronous motor			S
Oil seal		`	th an oil seal are availab			
Electromagneti	ic brake	· '	th an electromagnetic br	ake are available. (HK-S	ST_B))	
Thermistor		None				
Insulation class	3	155 (F)				Motors
Structure			al cooling (IP rating: IP67			Sio
Vibration resist	ance *1 [m/s ²]	X: 24.5, Y: 49		X: 24.5, Y: 29.4		
Vibration rank		V10 ⁺³				
Permissible	L [mm]					
load for the		2058				Equ
shaft*2		980		1		Equipment
Mass [kg]	Without electromagnetic brake		16	20	27	nent
[9]	With electromagnetic brake	18	21	25	31	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. 20 times or less for 3000 r/min or less.
- 7. 22 times or less for 3000 r/min or less
- 8. 22 times or less for 2000 r/min or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

	•						
Model		HK-ST	202WB	352WB	502WB	702WB	
Туре			Spring actuated type sa	Spring actuated type safety brake			
Rated voltage			24 V DC (-10 % to 0 %	4 V DC (-10 % to 0 %)			
Power consumption [W] at 20 °C			34				
Electromagnetic b	orake static	[N•m]	44 or higher				
Permissible	Per braking	[J]	4500				
braking work	Per hour	[J]	45000				
Electromagnetic	Number of bra	ıking times	20000				
brake life (Note 2)	Work per brak	ing [J]	1000				

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

HK-ST_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	130 × 130			
Rotary servo m	otor model HK-ST	353W	503W		
Continuous running duty	Rated output (Note 3) [kW]	2.6 (3.5)	5.0		
(Note 4) Rated torque (Note 3, 5)		8.3 (11.1)	15.9		
Maximum torqu	e (Note 3) [N•m]	24.8 (44.6)	47.8 (63.7)		
Rated speed (Not					
Maximum spee	d (Note 4) [r/min]	6700	6000		
Power rate at continuous rated torque	Without electromagnetic brake	40.5 (73.4)	91.5		
(Note 3) [kW/s]	With electromagnetic brake	35.9 (65.0)	84.7		
Rated current (N	ote 3) [A]	14 (19)	23		
Maximum current (Note 3) [A]		43 (83)	73 (100)		
Moment of inertia J	Without electromagnetic brake	16.9	27.7		
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	19.1	29.9		
Recommended	load to motor inertia ratio (Note 1)	10 times or less			
Speed/position	detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)			
Туре		Permanent magnet synchronous motor			
Oil seal		None (Servo motors with an oil seal are availab	le. (HK-ST_J))		
Electromagnetic	c brake	None (Servo motors with an electromagnetic br	ake are available. (HK-ST_B))		
Thermistor		None			
Insulation class		155 (F)			
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2)			
Vibration resista	ance *1 [m/s ²]	X: 24.5, Y: 49			
Vibration rank		V10 ⁺³			
Permissible	L [mm]	55			
load for the	Radial [N]	980			
shaft*2	Thrust [N]	490			
Mass [kg]	Without electromagnetic brake	9.1	13		
wass [kg]	With electromagnetic brake	11	15		
Notes: 1 Contact	vous local calco office if the local to mote	r inartia ratio avacada tha value in the table			

- Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.
 - 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through
 - 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
 - 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
 - 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

J				
Model	HK-ST	353WB	503WB	
Туре		Spring actuated type safety brake		
Rated voltage		24 V DC (-10 % to 0 %)		
Power consumption	on [W] at 20 °C	23		
Electromagnetic by friction torque	orake static [N•m]	16 or higher		
Permissible	Per braking [J]	400		
braking work	Per hour [J]	4000		
Electromagnetic	Number of braking times	5000		
brake life (Note 2)	Work per braking [J]	400		

1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	Flange size [mm] 130 x 130							
Rotary servo m	otor model HK-ST	524W	1024W	1724W	2024AW	3024W		
Continuous	Rated output [kW]	0.3	0.6	0.85	1.0	1.5		
running duty (Note 4)	Rated torque (Note 5) [N•m]	2.9	5.7	8.1	9.5	14.3		
Maximum torqu	ue (Note 3) [N•m]	11.5	17.2 (20.1)	24.4	33.4	43.0		
Rated speed (No	ote 4) [r/min]	1000	,					
Maximum spee	ed (Note 4) [r/min]	2000				1200		
Power rate at continuous	Without electromagnetic brake	13.9	37.9	57.8	53.9	91.5		
rated torque [kW/s]	With electromagnetic brake	10.1	30.1	48.3	47.8	83.6		
Rated current	[A]	1.8	3.2	4.5	5.2	5.1		
Maximum curre	ent (Note 3) [A]	8.3	11 (13)	17	20	17	ì	
Moment of inertia J	Without electromagnetic brake	5.90	8.65	11.4	16.9	22.4		
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	8.15	10.9	13.7	19.1	24.5		
Recommended	l load to motor inertia ratio (Note 1)	15 times or less	24 times or less		20 times or less	24 times or less		
Speed/position	detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)						
Type		Permanent magnet synchronous motor					_	
Oil seal		None (Servo motor	rs with an oil seal a	re available. (HK-S	T_J))			
Electromagneti	c brake	None (Servo motor	rs with an electrom	agnetic brake are a	vailable. (HK-ST_B))		
Thermistor		None						
Insulation class	S	155 (F)						
Structure		Totally enclosed, n	atural cooling (IP ra	ating: IP67) (Note 2)				
Vibration resist	ance 1 [m/s ²]	X: 24.5, Y: 49						
Vibration rank		V10 ^{*3}						
Permissible	L [mm]	55			-			
load for the		980						
shaft*2	Thrust [N]	490						
Mass [kg]	Without electromagnetic brake		6.0	7.1	9.1	11		
widoo [kg]	With electromagnetic brake	6.8	7.8	8.8	11	13		
Notos: 1 Contact	your local cales office if the load to moto	r inartia ratio avacada th	o value in the table				-	

lotes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

						····		
Model		HK-ST	524WB	1024WB	1724WB	2024AWB	3024WB	
Type			Spring actuated type	Spring actuated type safety brake				
Rated voltage			24 V DC (-10 % to	24 V DC (-10 % to 0 %)				
Power consumption [W] at 20 °C			20			23		
Electromagnetic b	rake static	[N•m]	8.5 or higher			16 or higher		
Permissible	Per braking	[J]	400					
braking work	Per hour	[J]	4000					
Electromagnetic Number of braking times		king times	20000			5000		
brake life (Note 2)	Work per brakir	ng [J]	200			400		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	176 × 176				
Rotary servo m	otor model HK-ST	2024W	3524W	5024W	7024W	
Continuous	Rated output [kW]	1.2	2.0	3.0	4.2	
running duty (Note 4)	Rated torque (Note 5) [N•m]	11.5	19.1	28.6	40.1	
Maximum torqu	e (Note 3) [N•m]	40.1	57.3 (66.8)	85.9	120	
Rated speed (No	te 4) [r/min]	1000				
Maximum spee	d (Note 4) [r/min]	2000	1500	2000	1500	
Power rate at continuous	Without electromagnetic brake	36.1	68.0	116	153	
rated torque [kW/s]	With electromagnetic brake	31.7	62.3	108	146	
Rated current	[A]	6.0	9.0	16	17	
Maximum curre	ent (Note 3) [A]	24	32 (37)	52	60	
Moment of inertia J	Without electromagnetic brake	36.4	53.6	70.8	105	
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	41.4	58.6	75.8	110	
Permissible loa	d to motor inertia ratio (Note 1)	23 times or less			22 times or less	
Speed/position	detector	Batteryless absolute/ind	cremental 26-bit encode	r (resolution: 67,108,864	l pulses/rev)	
Туре		Permanent magnet synchronous motor				
Oil seal		None (Servo motors with an oil seal are available. (HK-ST_J))				
Electromagnetic	c brake	None (Servo motors with an electromagnetic brake are available. (HK-ST_B))				
Thermistor		None				
Insulation class		155 (F)				
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2)				
Vibration resista	ance ^{*1} [m/s ²]	X: 24.5, Y: 49 X: 24.5, Y: 29.4				
Vibration rank		V10 *3				
Permissible	L [mm]	79				
load for the	Radial [N]	2058				
shaft*2	Thrust [N]	980				
Mass [kg]	Without electromagnetic brake	13	16	20	27	
wass [kg]	With electromagnetic brake	18	21	25	31	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

 $Refer\ to\ "Annotations\ for\ Rotary\ Servo\ Motor\ Specifications"\ on\ p.\ 4-79\ in\ this\ catalog\ for\ details\ about\ asterisks\ 1\ to\ 3.$

Electromagnetic brake specifications (Note 1)

Model	HK-ST	2024WB	3524WB	5024WB	7024WB		
Туре		Spring actuated type sa	Spring actuated type safety brake				
Rated voltage		24 V DC (-10 % to 0 %)	24 V DC (-10 % to 0 %)				
Power consumption	on [W] at 20 °C	34					
Electromagnetic brake static [N•m]		44 or higher					
Permissible	Per braking [J]	4500					
braking work	Per hour [J]	45000					
Electromagnetic	Number of braking times	20000					
brake life (Note 2)	Work per braking [J]	1000					

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 400 V servo amplifier

Flange size		[mm]	130 × 130				
Rotary servo m	otor model	HK-ST		1024W	1724W	2024AW	3024W
Continuous	Rated output	[kW]	0.5	1.0	1.75	2.0	3.0
running duty	Rated torque		24	4.8 (6.4)	8.4	9.5 (11.6)	14.3
Maximum torqu	Ie (Note 3)	[N•m]	7.2 (12.7)	14.3 (19.1)	25.1	28.6 (34.7)	43.0 (50.1)
Rated speed (No	ote 3, 4)	[r/min]	2000 (1500)	2000 (1500)	2000	2000 (1650)	2000
Maximum spee	ed (Note 4)	[r/min]	4000				2500
Power rate at continuous	Without elect	romagnetic brake	9.7 (17.2)	26.3 (46.8)	61.2	53.9 (79.2)	91.5
rated torque (Note 3) [kW/s]	With electrom	nagnetic brake	7.0 (12.4)	20.9 (37.2)	51.1	47.8 (70.3)	83.6
Rated current (N	Note 3)	[A]	1.5 (2.0)	2.7 (3.5)	4.7	5.2 (6.3)	5.1
Maximum curre	Maximum current (Note 3) [A]			8.8 (12)	16	17 (21)	17 (20)
Moment of	Without electr	romagnetic brake	5.90	8.65	11.4	16.9	22.4
inertia J [× 10 ⁻⁴ kg•m ²]	With electrom	nagnetic brake	8.15	10.9	13.7	19.1	24.5
Recommended		MR-J5	4 times or less (Note 6)	4 times or less (Note 7)	4 times or less (Note 8)		
motor inertia ra	tio (Note 1)	MR-J5D	19 times or less	16 times or less	11 times or less	7 times or less (Note 8)	24 times or less
Speed/position	detector		4 times or less 14 times or less 15 times or less 16 times or less 16 times or less 17 times or less 7 times or less 16 times or less 17 times or less 17 times or less 18 times or less 19 24 times 19 24 tim				
Type			Permanent magnet synchronous motor				
Oil seal			None (Servo motors with an oil seal are available. (HK-ST_J))				
Electromagneti	c brake		None (Servo motors with an electromagnetic brake are available. (HK-ST_B))				
Thermistor			None				
Insulation class	5		155 (F)				
Structure			None 155 (F) Totally enclosed, natural cooling (IP rating: IP67) (Note 2)				
Vibration resist	ance *1	[m/s ²]	X: 24.5, Y: 49				
Vibration rank			V10 '3				
Permissible	L	[mm]	55				
load for the	Radial	[N]	980				
shaft*2	Thrust	[N]	490				
Mana [kg]	Without elect	romagnetic brake	5.0	6.0	7.1	9.1	11
Mass [kg]	With electrom	nagnetic brake	6.8	7.8	8.8	11	13
	*			*			

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through
- portion.
 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. 19 times or less for 2000 r/min or less.
- 7. 23 times or less for 2000 r/min or less
- 8. 24 times or less for 2000 r/min or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-	ST 52	24WB	1024WB	1724WB	2024AWB	3024WB
Туре		Sp	Spring actuated type safety brake				
Rated voltage			24 V DC (-10 % to 0 %)				
Power consumption [W] at 20 °C			20			23	
Electromagnetic brake static friction torque [N•m]		m] 8.	8.5 or higher		16 or higher		
Permissible	Per braking	[J] 40	00				
braking work Per hour [J]		[J] 40	4000				
Electromagnetic	Number of braking times	20	0000			5000	
brake life (Note 2)	Work per braking	[J] 20	00			400	-

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 400 V servo amplifier

Flange size		[mm]	176 × 176				
Rotary servo mo	otor model	HK-ST	2024W	3524W	5024W	7024W	
Continuous	Rated output	[kW]	2.0	3.5	5.0	7.0	
running duty	Rated torque	(Note 3, 5) [N•m]	9.5 (12.7)	16.7 (20.3)	23.9 (28.9)	33.4	
Maximum torqu	e (Note 3)	[N•m]	28.6 (38.2)	50.1 (60.8)	71.6 (86.8)	100	
Rated speed (Not	te 3, 4)	[r/min]	2000 (1500)	2000 (1650)	2000 (1650)	2000	
Maximum speed	d (Note 4)	[r/min]	4000	3500	4000	3000	
Power rate at continuous rated torque	Without elect	romagnetic brake	25.1 (44.6)	52.1 (76.5)	80.4 (118)	106	
(Note 3) [kW/s]	With electrom	nagnetic brake	22.0 (39.2)	47.7 (70.0)	75.2 (110)	101	
Rated current (Note 3) [A]			5.0 (6.7)	7.9 (9.5)	14 (16)	14	
Maximum current (Note 3) [A]			16 (23)	26 (33)	45 (55)	59	
Moment of	Without electromagnetic brake		36.4	53.6	70.8	105	
inertia J [× 10 ⁻⁴ kg•m ²]	With electromagnetic brake		41.4	58.6	75.8	110	
Recommended		MR-J5	4 times or less (Note 6)	5 times or less (Note 7)	-	-	
motor inertia rat		MR-J5D	2 times or less (Note 8)	4 times or less (Note 9)	2 times or less (Note 10)	2 times or less (Note 11)	
Speed/position	detector				er (resolution: 67,108,864	1 pulses/rev)	
Туре			Permanent magnet synchronous motor				
Oil seal			None (Servo motors with an oil seal are available. (HK-ST_J))				
Electromagnetic	c brake		None (Servo motors with an electromagnetic brake are available. (HK-ST_B))				
Thermistor			None				
Insulation class			155 (F)				
Structure			Totally enclosed, natural cooling (IP rating: IP67) (Note 2)				
Vibration resistance *1 [m/s²]			X: 24.5, Y: 49 X: 24.5, Y: 29.4				
Vibration rank			V10 '3				
Permissible	L	[mm]					
load for the	Radial		2058				
shaft*2	Thrust		980	1			
Mass [kg]			13	16	20	27	
		nagnetic brake	18	21	25	31	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. 20 times or less for 2000 r/min or less.
- 7. 22 times or less for 2000 r/min or less.
- 8. 12 times or less for 2000 r/min or less.
 9. 14 times or less for 2000 r/min or less.
- 10. 10 times or less for 2000 r/min or less.
- 11. 7 times or less for 2000 r/min or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-S1	2024WB	3524WB	5024WB	7024WB		
Туре		Spring actuated type sa	Spring actuated type safety brake				
Rated voltage		24 V DC (-10 % to 0 %	24 V DC (-10 % to 0 %)				
Power consumption	on [W] at 20 °C	34					
Electromagnetic brake static friction torque [N•m]		44 or higher					
Permissible	Per braking [J	4500					
braking work	Per hour [J	45000					
Electromagnetic	Number of braking times	20000					
brake life (Note 2)	Work per braking [J	1000					

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 400 V servo amplifier

			<u>'</u>		ੁ ਂ ਹੋ	
Flange size			130 × 130		nmon fications	
Rotary servo m	otor model	HK-ST	3534W	5034W	n ons	
Continuous	Rated output	t (Note 3) [kW]	2.6 (3.5)	5.0	(O	
running duty (Note 4) Rated	Rated torque	e (Note 3, 5) [N•m]	8.3 (11.1)	15.9	Servo Syster Controllers	
Maximum torque (Note 3) [N•m]		[N•m]	24.8 (44.6)	47.8 (63.7)	Servo System Controllers	
Rated speed (No	ote 4)	[r/min]	3000		٥	
Maximum spee	ed (Note 4)	[r/min]	6700	6000	S	
Power rate at continuous	Without elec	tromagnetic brake	40.5 (73.4)	91.5	Servo Amplifiers	
rated torque (Note 3) [kW/s]	With electror	magnetic brake	35.9 (65.0)	84.7	plifiers	
Rated current (*	Note 3)	[A]	6.9 (9.2)	12	Ro	
Maximum curre	ent (Note 3)	[A]	22 (42)	37 (52)	Rotary Servo Motors	
Moment of	Without elect	tromagnetic brake	16.9	27.7	o vije	
inertia J [x 10 ⁻⁴ kg•m ²]	With electron	nagnetic brake	19.1	29.9		
Recommended		MR-J5	10 times or less	-	_ Ei	
motor inertia ra	tio (Note 1)	MR-J5D	3 times or less (Note 6)	2 times or less (Note 7)	Linear Servo Motors	
Speed/position detector			·	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)		
Туре			Permanent magnet synchronous motor			
Oil seal			None (Servo motors with an oil seal are availa			
Electromagneti	c brake		None (Servo motors with an electromagnetic brake are available. (HK-ST_B))			
Thermistor			None			
Insulation class	S		155 (F)		Direct Drive Motors	
Structure			Totally enclosed, natural cooling (IP rating: IP67) (Note 2)			
Vibration resist	Vibration resistance *1 [m/s²]		X: 24.5, Y: 49			
Vibration rank			V10 ⁻³		0	
Permissible	L	[mm]	55		ptic	
load for the	Radial		980		iguij	
shaft*2	Thrust		490		ions/Periph Equipment	
Mass [kg]	Without elec	tromagnetic brake	9.1	13	Options/Peripheral Equipment	
mado [ng]	With electron	nagnetic brake	11	15	<u>21</u>	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. 20 times or less for 3000 r/min or less.
- 7. 12 times or less for 3000 r/min or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-S	T 3534WB	5034WB	
Type		Spring actuated type safety b	rake	
Rated voltage		24 V DC (-10 % to 0 %)		
Power consumption	on [W] at 20	C 23		
Electromagnetic b friction torque	rake static [N•	n] 16 or higher		
Permissible	Per braking	J] 400		
braking work	Per hour	J] 4000		
Electromagnetic	Number of braking times	5000		
brake life (Note 2)	Work per braking	J] 400		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

LVS/Wires

Product List

Support


HK-ST_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

: For 3-phase 200 V AC -: For 1-phase 200 V AC


HK-ST52W

Standard torque




HK-ST52W

Torque increased




HK-ST102W

Standard torque




HK-ST102W

Torque increased




HK-ST172W

Standard torque




HK-ST202AW

Standard torque




HK-ST202AW

Torque increased




HK-ST302W

Standard torque



HK-ST302W

Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC

Precautions


HK-ST_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

: For 3-phase 200 V AC -: For 1-phase 200 V AC


HK-ST202W

Standard torque




HK-ST202W


Torque increased




HK-ST352W




HK-ST352W






HK-ST502W

Standard torque




HK-ST502W

Torque increased




HK-ST702W

Standard torque




HK-ST353W

Standard torque




HK-ST353W

Torque increased




HK-ST503W

Standard torque



HK-ST503W



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC


HK-ST_4_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

■: For 3-phase 200 V AC -: For 1-phase 200 V AC


HK-ST524W

Standard torque




HK-ST1724W

Standard torque




HK-ST3024W

Standard torque




HK-ST1024W

Standard torque




HK-ST1024W




HK-ST2024AW

Standard torque



HK-ST2024W

Standard torque



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC

Precautions


HK-ST_4_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

: For 3-phase 200 V AC : For 1-phase 200 V AC


HK-ST3524W

Standard torque




HK-ST3524W

Torque increased




HK-ST5024W





HK-ST7024W

Standard torque



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC


HK-ST_4_W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier

: For 3-phase 400 V AC -: For 3-phase 380 V AC


HK-ST524W

Standard torque




HK-ST524W

Torque increased




HK-ST1024W

Standard torque




HK-ST1024W

Torque increased




HK-ST1724W

Standard torque




HK-ST2024AW

Standard torque




HK-ST2024AW

Torque increased




HK-ST3024W

Standard torque



HK-ST3024W

Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC


HK-ST_4_W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier

: For 3-phase 400 V AC -: For 3-phase 380 V AC


HK-ST2024W

Standard torque




HK-ST2024W

Torque increased





HK-ST3524W Standard torque



Speed [r/min]


HK-ST3524W






HK-ST5024W

Standard torque




HK-ST5024W

Torque increased




HK-ST7024W

Standard torque




HK-ST3534W

Standard torque




HK-ST3534W

Torque increased




HK-ST5034W



HK-ST5034W


Torque increased




Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC

HK-ST Series Dimensions (Note 3, 4, 7)

HK-ST52W(B), HK-ST102W(B), HK-ST172W(B), HK-ST202AW(B), HK-ST302W(B), HK-ST524W(B), HK-ST1024W(B), HK-ST1724W(B), HK-ST2024AW(B), HK-ST3024W(B)



HK-ST202W(B), HK-ST352W(B), HK-ST502W(B), HK-ST702W(B), HK-ST2024W(B), HK-ST3524W(B), HK-ST5024W(B), HK-ST7024W(B)




Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are the same regardless of whether or not an oil seal is installed.
- 4. Use a friction coupling to fasten a load.
- 5. Only for the models with an electromagnetic brake
- 6. HK-ST352W(B), HK-ST3524W(B), HK-ST502W(B), HK-ST502W(B), HK-ST702W(B), and HK-ST7024W(B) have screw holes (M8) for eyebolts.
- 7. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

Precautions

HK-ST Series Dimensions (Note 3, 4, 6)

HK-ST353W(B), HK-ST503W(B), HK-ST3534W(B), HK-ST5034W(B)



147.8 [Unit: mm]

103.8

HK-ST3534W(B)

HK-ST503W(B)

HK-ST5034W(B)

(194)

203.5

(238)

Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.


- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are the same regardless of whether or not an oil seal is installed.
- 4. Use a friction coupling to fasten a load.
- 5. Only for the models with an electromagnetic brake.
- 6. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

HK-ST Series with Special Shaft Dimensions

Servo motors with the following specifications are also available.

K: Keyed shaft (with a double round-ended key) (Note 1)


Model	Variable	dimen	sions						
Model	S	R	Q	W	QK	QL	U	Т	Υ
HK-ST52(4)WK									
HK-ST102(4)WK HK-ST172(4)WK									M8
HK-ST202(4)AWK	24 .0.013	55	50	8	36	5	4	7	Screw depth:
HK-ST302(4)WK HK-ST353(4)WK									20
HK-ST503(4)WK									
HK-ST202(4)WK									M8
HK-ST352(4)WK	35 +0.010	79	75	10	55	5	5	8	Screw depth:
HK-ST502(4)WK HK-ST702(4)WK									20



[Unit: mm]

N: Keyed shaft (without a key) (Note 1, 2)

Model	Variable dimensions													
Model	S	R	Q	W	QK	QL	U	r	Υ					
HK-ST52(4)WN HK-ST102(4)WN HK-ST172(4)WN HK-ST202(4)AWN HK-ST302(4)WN HK-ST353(4)WN HK-ST503(4)WN	24 .0.013	55	50	8 -0.036	36	5	4 +0.2	4	M8 Screw depth: 20					
HK-ST202(4)WN HK-ST352(4)WN HK-ST502(4)WN HK-ST702(4)WN	35 +0.010	79	75	10.0036	55	5	5 +0.2	5	M8 Screw depth: 20					



[Unit: mm]

Notes: 1. Do not use the servo motors with a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft. 2. The servo motor is supplied without a key. The user needs to prepare a key.

HK-ST Series Geared Servo Motor Specifications

With a gear reducer for general industrial machines, flange mounting: G1

			Moment of [x 10 ⁻⁴ kg•		Permissible load to	Permis the sha	sible loa aft *1	d for	Mass [kg]		Lubrication	
Model HK-ST		Reduction ratio	Without electro- magnetic brake	With electro-magnetic brake	motor inertia ratio (Note 2) (when converted into the servo motor shaft)	Q [mm]	Radial [N]	Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	method (Note 5)	Mountin direction
		1/6	6.72	8.97		35	2058	1470	17	19		
		1/11	6.29	8.54		35	2391	1470	17	19		
		1/17	6.17	8.42		35	2832	1470	17	19	_	_
52G1 524G1	0.5	1/29	6.11	8.36	4 times or less	35	3273	1470	17	19	Grease (filled)	Any direction
52401		1/35	6.90	9.15		55	5253	2940	27	29	(IIIICa)	anconon
		1/43	6.86	9.11		55	5253	2940	27	29	1	
		1/59	6.82	9.07		55	5880	2940	27	29	1	
		1/6	11.9	14.1		55	2842	2352	29	31		
		1/11	10.4	12.6	-	55	3273	2764	29	31	1	
		1/17	9.95	12.2	-	55	3646	2940	29	31	Grease	Any
102G1		1/29	9.65	11.9		55	4410	2940	29	31	(filled)	direction
1024G1	1.0	1/35	9.65	11.9	4 times or less	55	5253	2940	29	31	1	
		1/43	10.9	13.1		70	6047	3920	48	50	Oil (Note 3)	Shaft
		1/59	16.2	18.4		90	9741	6860	80	82	OII (NOIE 3)	horizonta (Note 4)
		1/6	14.6	16.9		55	2842	2352	30	32		
		1/11	13.1	15.4	-	55	3273	2764	30	32	Grease	Any
					_		_			32	(filled)	direction
152G1		1/17	12.7	15.0	4 6	55	3646	2940	30			
1524G1 Note 6)	oto 6)	1/29	13.8	16.1	4 times or less	70	5135	3920	49	51	-	Shaft
		1/35	13.7	16.0	_	70	6047	3920	49	51	Oil (Note 3)	horizonta
		1/43	19.0	21.3	_	90	8555	6860	81	83	_	(Note 4)
		1/59	18.9	21.2		90	9741	6860	81	83		
		1/6	39.6	44.6		55	2842	2352	37	42	Greace	Δην
		1/11	38.0	43.0		55	3273	2764	37	42		Any direction
202G1		1/17	37.7	42.7		55	3646	2940	37	42	, ,	
202G1 2024G1	2.0	1/29	44.4	49.4	4 times or less	90	7291	6860	88	93		
-02.0.		1/35	44.1	49.1		90 8555 6860 88 93 Oil (Note 3)					Oil (Note 3)	Shaft horizonta
		1/43	43.9	48.9		90	8555	6860	88	93	Oli (iiiii s)	(Note 4)
		1/59	43.8	48.8		90	9741	6860	88	93		
		1/6	62.1	67.1		70	3332	3920	59	63		
		1/11	57.8	62.8		70	3871	3920	59	63	1	
		1/17	56.5	61.5		70	4420	3920	59	63	Oil (Note 3)	Shaft
352G1	3.5	1/29	61.6	66.6	4 times or less	90	7291	6860	91	96	1	horizonta
3524G1		1/35	61.3	66.3		90	8555	6860	91	96	1	(Note 4)
		1/43	80.0	85.0	1	90	11662	9800	135	140		1
		1/59	79.0	84.0	1	90	13132	9800	135	140	Oil	
		1/6	97.1	102		90	5448	5000	94	99	Oil	
		1/11	85.1	90.1	1	90	5488	6292	94	99		1
		1/17	81.1	86.1	1	90	6468	6860	94	99	Oil (Note 3)	Choff
502G1	5.0	1/29	112	117	4 times or less	110	13426	13720	165	170		Shaft horizonta
5024G1		1/35	111	116		110	16072	13720	165	170	1	(Note 4)
		1/43	110	115	-	110	16072	13720	165	170	Oil	
		1/59	109	114	-	110	16072	13720	165	170	+	
		1/6	131	136		90			100	105		
					-		7526	5000			-	
		1/11	144	149	-	90	7526	8085	145	150	-	
702G1		1/17	136	141	4 15	90	8683	9673	145	150	-	Shaft
7024G1	7.0	1/29	146	151	4 times or less	110	13426	13720	170	175	Oil	horizonta (Note 4)
		1/35	146	151	_	110	16072	13720	170	175		
		1/43	221	226		135	22540	19600	240	245	_	
		1/59	220	225		135	22540	19600	240	245		

^{2.} Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

^{3.} The oil lubricated servo motor cannot be used for applications where the servo motor moves. In that case, order a grease lubricated servo motor (special specification). The maximum speed of the grease lubricated servo motor is the same as that of the oil lubricated.

^{4.} Do not mount the servo motor in a way that the servo motor is tilted to the shaft direction or to the shaft rotation direction. Refer to the asterisk 2 of "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog. Servo motors with special specifications may be available to be mounted with other than the shaft horizontal. Refer to "Rotary Servo Motor User's Manual" for the available models.

^{5.} The lubricant oil is removed from the gear reducer before shipment, and thus please purchase the required lubricant oil and fill the oil into the gear reducer.

^{6.} The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) The moment of inertia of HK-ST152(4) is the same as that of HK-ST172(4)W.

HK-ST Series Geared Servo Motor Specifications

With a gear reducer for general industrial machines, flange mounting: G1

Item	Specifications
Mounting method	Flange mounting
Output shaft rotation direction	Opposite from the servo motor output shaft direction
Backlash (Note 3)	40 minutes to 2° at gear reducer output shaft (Note 2)
Maximum torque (Note 4)	Three times of the rated torque
Maximum torque (************************************	(Refer to HK-ST series specifications in this catalog for the rated torque.) (Note 5)
Maximum speed (at servo motor shaft)	Grease lubricated: 3000 r/min
waximum speed (at serve motor shart)	Oil lubricated: 2000 r/min
IP rating (gear reducer part)	Equivalent to IP44
Gear reducer efficiency (Note 1)	85 % to 94 %

Notes: 1. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.

- 2. This is a designed value, not guaranteed value.
- 3. The backlash can be converted: 1 minute = 0.0167°
- 4. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

 5. The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) The moment of inertia of HK-ST152(4) is the same as that of HK-ST172(4)W.

HK-ST Series Geared Servo Motor Specifications

With a gear reducer for general industrial machines, foot mounting: G1H

			Moment of [x 10 ⁻⁴ kg•		Permissible load to	Permis the sha	sible loa aft *1	d for	Mass [kg]		Lubriastia	
Model HK-ST	Output [kW]	Reduction ratio	Without electro- magnetic brake	With electro-magnetic brake	motor inertia ratio (Note 2) (when converted into the servo motor shaft)	Q [mm]	[N]	[N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method (Note 5)	Mounting direction
		1/6	6.72	8.97		35	2058	1470	20	22		
		1/11	6.29	8.54		35	2391	1470	20	22		
00411		1/17	6.17	8.42		35	2832	1470	20	22	0	A
52G1H 524G1H	0.5	1/29	6.11	8.36	4 times or less	35	3273	1470	20	22	Grease (filled)	Any direction
		1/35	6.90	9.15		55	5253	2940	28	30		
		1/43	6.86	9.11		55	5253	2940	28	30		
		1/59	6.82	9.07		55	5880	2940	28	30		
		1/6	11.9	14.1		55	2842	2352	30	32		
		1/11	10.4	12.6	-	55	3273	2764	30	32		
		1/17	9.95	12.2		55	3646	2940	30	32	Grease (filled)	Any direction
102G1H	1.0	1/29	9.65	11.9	4 times or loss	55	4410	2940	30	32	(IIIIea)	airection
1024G1H	1.0	1/35	9.65	11.9	4 times or less	55	5253	2940	30	32	1	
		1/43	10.9	13.1		70	6047	3920	49	51	Oil (Note 3)	Shaft horizontal
		1/59	16.2	18.4		90	9741	6860	85	87	0	(Note 4)
		1/6	14.6	16.9		55	2842	2352	31	33		
		1/11	13.1	15.4	-	55	3273	2764	31	33	Grease	Any
500411		1/17	12.7	15.0	-	55	3646	2940	31	33	(filled)	direction
52G1H 524G1H	1.5	1/29	13.8	16.1	4 times or less	70	5135	3920	50	52		
Note 6)		1/35	13.7	16.0	- 1	70	6047	3920	50	52	-	Shaft
		1/43	19.0	21.3	_	90	8555	6860	86	88	Oil (Note 3)	horizontal
		1/59	18.9	21.2	-	90	9741	6860	86	88	_	(Note 4)
		1/6	39.6	44.6		55	2842	2352	38	43		
		1/11	38.0	43.0	-	55	3273	2764	38	43	Grease	Any
				-	-	55		2940	38	43	(filled)	direction
202G1H		1/17	37.7	42.7	4 4:		3646		93			
2024G1H	2.0	1/29	44.4	49.4	4 times or less	90	7291	6860		98	-	Shaft
		1/35	44.1	49.1	_	90	8555	6860	93	98	Oil (Note 3)	horizontal
		1/43	43.9	48.9	_	90	8555	6860	93	98	_	(Note 4)
		1/59	43.8	48.8		90	9741	6860	93	98		
		1/6	62.1	67.1	-	70	3332	3920	60	64	_	
		1/11	57.8	62.8	-	70	3871	3920	60	64		
352G1H		1/17	56.5	61.5		70	4420	3920	60	64	Oil (Note 3)	Shaft
3524G1H	3.5	1/29	61.6	66.6	4 times or less	90	7291	6860	96	105		horizontal (Note 4)
		1/35	61.3	66.3		90	8555	6860	96	105		
		1/43	80.0	85.0	_	90	11662	9800	140	145	Oil	
		1/59	79.0	84.0		90	13132	9800	140	145		
		1/6	97.1	102	_	90	5448	5000	99	105	Oil	
		1/11	85.1	90.1	_	90	5488	6292	99	105	Oil (Note 3)	
502G1H		1/17	81.1	86.1	_	90	6468	6860	99	105		Shaft
502G111	5.0	1/29	112	117	4 times or less	110	13426	13720	180	185	-	horizontal (Note 4)
		1/35	111	116		110	16072	13720	180	185	Oil	(.1010 4)
		1/43	110	115		110	16072	13720	180	185	1	
		1/59	109	114		110	16072	13720	180	185		
		1/6	131	136		90	7526	5000	105	110	_	
		1/11	144	149		90	7526	8085	145	150		
2000		1/17	136	141		90	8683	9673	145	150		Shaft
'02G1H '024G1H	7.0	1/29	146	151	4 times or less	110	13426	13720	185	190	Oil	horizontal
JE IGIII		1/35	146	151		110	16072	13720	185	190		(Note 4)
		1/43	221	226		135	22540	19600	255	260		
					13							

2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

^{3.} The oil lubricated servo motor cannot be used for applications where the servo motor moves. In that case, order a grease lubricated servo motor (special specification). The maximum speed of the grease lubricated servo motor is the same as that of the oil lubricated.

^{4.} Do not mount the servo motor in a way that the servo motor is tilted to the shaft direction or to the shaft rotation direction. Refer to the asterisk 2 of "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog. Servo motors with special specifications may be available to be mounted with other than the shaft horizontal. Refer to "Rotary Servo Motor User's Manual" for the available models.

^{5.} The lubricant oil is removed from the gear reducer before shipment, and thus please purchase the required lubricant oil and fill the oil into the gear reducer.

^{6.} The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) The moment of inertia of HK-ST152(4) is the same as that of HK-ST172(4)W.

HK-ST Series Geared Servo Motor Specifications

With a gear reducer for general industrial machines, foot mounting: G1H

Item	Specifications
Mounting method	Foot mounting
Output shaft rotation direction	Opposite from the servo motor output shaft direction
Backlash (Note 3)	40 minutes to 2° at gear reducer output shaft (Note 2)
Maximum torque (Note 4)	Three times of the rated torque
Maximum torque (1888 1)	(Refer to HK-ST series specifications in this catalog for the rated torque.) (Note 5)
Maximum speed (at servo motor shaft)	Grease lubricated: 3000 r/min
iviaximum speed (at servo motor shart)	Oil lubricated: 2000 r/min
IP rating (gear reducer part)	Equivalent to IP44
Gear reducer efficiency (Note 1)	85 % to 94 %

Notes: 1. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.

- This is a designed value, not guaranteed value.
 The backlash can be converted: 1 minute = 0.0167°
- 4. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.
- 5. The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) The moment of inertia of HK-ST152(4) is the same as that of HK-ST172(4)W.

HK-ST Series Geared Servo Motor Specifications

With a flange-output type gear reducer for high precision applications, flange mounting: G5

			Moment of [x 10 ⁻⁴ kg•1		Permissible load to	Permis the sha	sible loa aft *1	d for	Mass [kg]			
Model HK-ST		Reduction ratio	Without electro- magnetic brake	With electro- magnetic brake	motor inertia ratio (Note 2) (when converted into the servo motor shaft)	L [mm]	Radial [N]	Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method	Mounting direction
		1/5	6.55	8.80		32	416	1465	7.1	8.8		
5005		1/11	6.46	8.71		32	527	1856	7.5	9.2		
52G5 524G5	0.5	1/21	8.80	11.1	10 times or less	57	1094	4359	11	13		
02.00		1/33	8.60	10.9		57	1252	4992	11	13		
		1/45	8.60	10.9		57	1374	5478	11	13		
		1/5	9.30	11.6		32	416	1465	8.0	9.7		
		1/11	12.0	14.2		57	901	3590	12	14		
102G5 1024G5	1.0	1/21	11.6	13.8	10 times or less	57	1094	4359	12	14		
102403		1/33	13.4	15.6		62	2929	10130	22	23		
		1/45	13.3	15.5		62	3215	11117	22	23		
		1/5	12.1	14.4		32	416	1465	9.0	11		
152G5		1/11	14.7	17.0		57	901	3590	13	15		
1524G5	1.5	1/21	17.1	19.4	10 times or less	62	2558	8845	23	24	Grease	Any
(Note 3)		1/33	16.1	18.4		62	2929	10130	23	24	(filled)	direction
		1/45	16.0	18.3		62	3215	11117	23	24	ĺ` <i>′</i>	
		1/5	41.0	46.0		57	711	2834	20	25		
		1/11	40.8	45.8		57	901	3590	20	25		
202G5 2024G5	2.0	1/21	42.8	47.8	10 times or less	62	2558	8845	30	35		
202403		1/33	41.8	46.8		62	2929	10130	30	35		
		1/45	41.8	46.8		62	3215	11117	30	35		
		1/5	58.2	63.2		57	711	2834	23	28		
352G5 3524G5	3.5	1/11	61.7	66.7	10 times or less	62	2107	7285	33	38		
002400		1/21	60.0	65.0		62	2558	8845	33	38		
502G5	F 0	1/5	80.9	85.9	40 times or loss	62	1663	5751	34	39		
5024G5	5.0	1/11	78.9	83.9	10 times or less	62	2107	7285	36	41		
702G5 7024G5	7.0	1/5	115	120	10 times or less	62	1663	5751	40	45		

Item	Specifications
Mounting method	Flange mounting
Output shaft rotation direction	Same as the servo motor output shaft direction
Backlash (Note 5)	3 minutes or less at gear reducer output shaft
Maximum torque (Note 6)	Three times of the rated torque
Maximum torque (************************************	(Refer to HK-ST series specifications in this catalog for the rated torque.) (Note 3)
Maximum speed (at servo motor shaft)	3000 r/min
IP rating (gear reducer part)	Equivalent to IP44
Gear reducer efficiency (Note 4)	77 % to 92 %

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

- 2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.
- 3. The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) The moment of inertia of HK-ST152(4) is the same as that of HK-ST172(4)W.
- 4. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C. 5. The backlash can be converted: 1 minute = 0.0167°
- 6. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

HK-ST Series Geared Servo Motor Specifications

With a shaft-output type gear reducer for high precision applications, flange mounting: G7

			Moment of [x 10 ⁻⁴ kg•1		Permissible load to	Permis the sha	sible loa aft *1	d for	Mass [kg]			
Model HK-ST		Reduction ratio	Without electro- magnetic brake	With electro- magnetic brake	motor inertia ratio (Note 2) (when converted into the servo motor shaft)	Q [mm]	Radial [N]	Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method	Mounting direction
		1/5	6.59	8.84		32	416	1465	7.5	9.2		
5007		1/11	6.46	8.71		32	527	1856	7.7	9.4		
52G7 524G7	0.5	1/21	8.80	11.1	10 times or less	57	1094	4359	13	14		
		1/33	8.60	10.9		57	1252	4992	13	14		
		1/45	8.60	10.9		57	1374	5478	13	14		
		1/5	9.34	11.6		32	416	1465	8.4	11		
		1/11	12.1	14.3		57	901	3590	14	15		
102G7 1024G7	1.0	1/21	11.6	13.8	10 times or less	57	1094	4359	14	15		
102401		1/33	13.4	15.6		62	2929	10130	25	26		
		1/45	13.4	15.6		62	3215	11117	25	26		
		1/5	12.1	14.4		32	416	1465	9.4	11		
152G7		1/11	14.8	17.1		57	901	3590	15	16		
1524G7	1.5	1/21	17.1	19.4	10 times or less	62	2558	8845	26	27	Grease	Any
(Note 3)		1/33	16.1	18.4		62	2929	10130	26	27	(filled)	direction
		1/45	16.1	18.4		62	3215	11117	26	27	1` ′	
		1/5	41.3	46.3		57	711	2834	21	26	1	
		1/11	40.9	45.9		57	901	3590	22	27	1	
202G7 2024G7	2.0	1/21	42.9	47.9	10 times or less	62	2558	8845	33	38		
202401		1/33	41.8	46.8		62	2929	10130	33	38	1	
		1/45	41.8	46.8		62	3215	11117	33	38		
		1/5	58.5	63.5		57	711	2834	24	29	1	
352G7 3524G7	3.5	1/11	62.0	67.0	10 times or less	62	2107	7285	36	41		
332407		1/21	60.1	65.1		62	2558	8845	36	41	1	
502G7	- 0	1/5	82.3 87.3		40 6	62	1663	5751	37	42		
5024G7	4, IEV		79.2	84.2	10 times or less	62	2107	7285	39	44		
702G7 7024G7		117	122	10 times or less	62	1663	5751	43	48			

Item	Specifications
Mounting method	Flange mounting
Output shaft rotation direction	Same as the servo motor output shaft direction
Backlash (Note 5)	3 minutes or less at gear reducer output shaft
Maximum torque (Note 6)	Three times of the rated torque
Maximum torque (************************************	(Refer to HK-ST series specifications in this catalog for the rated torque.) (Note 3)
Maximum speed (at servo motor shaft)	3000 r/min
IP rating (gear reducer part)	Equivalent to IP44
Gear reducer efficiency (Note 4)	77 % to 92 %

1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

^{2.} Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

^{3.} The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) The moment of inertia of HK-ST152(4) is the same as that of HK-ST172(4)W.

^{4.} The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C. 5. The backlash can be converted: 1 minute = 0.0167°


^{6.} The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

HK-ST Series Geared Servo Motor Dimensions (Note 1, 5)

With a gear reducer for general industrial machines, flange mounting

HK-ST G1 (Note 6)

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws and the oil cap may differ from the drawing.



[Unit: mm]

Model	Reduc-	Variable	dimens	sions (Note	4)																									
HK-ST	tion ratio	L	LA	LC	LD	LG	LK	LR	ΙE	KL	KA	LP	LT	LW	LS	KE	Z	K	Е	Н	KB	KD	KC	Q	QK	S	Т	U	W	Υ
52(B)G1 524(B)G1	1/6 1/11 1/17 1/29	272.5 (307)	134	110:0.036	160	9	150	48	119	55.7 (90.2)	18.8	(56.5)	35.5 (39.5)	13.5	(29)	80	4-φ11	45	3	108	108.8	(79.9)	130	35	32	28 .0.013	7	4	8	M8 Screw depth: 20
524(B)G1	1/35 1/43 1/59	265 (299.5)	180	140 -0.043	210	13	204	69	132	55.7 (90.2)	18.8	(56.5)	35.5 (39.5)	13.5	(29)	80	6-ф11	30	4	117	108.8	(79.9)	130	55	50	38.0.016	8	5	10	dopuii 20
102(B)G1 1024(B)G1	1/6 1/11 1/17 1/29 1/35	276 (310.5)	180	140 -0.043	210	13	204	69	132	55.7 (90.2)	18.8	(56.5)	35.5 (39.5)	13.5	(29)	80	6-ф11	30	4	117	108.8	(79.9)	130	55	50	38 &6	8	5	10	M8 Screw depth: 20
1024(B)Q1	1/43	321.5 (356)	230	200 -0.050	260	15	230	76	145	55.7 (90.2)	18.8	(56.5)	35.5 (39.5)	13.5	(29)	80	6-ф11	60	4	164	108.8	(79.9)	130	70	56	50 .0.016	9	5.5	14	M10 Screw
	1/59	379 (413.5)	310	270 :0.056	340	20	300	89	192	55.7 (90.2)	18.8	(56.5)	35.5 (39.5)	13.5	(29)	80	6-ф11	60	4	219	108.8	(79.9)	130	90	80	60 .0.019	11	7	18	depth: 18
152(B)G1	1/6 1/11 1/17	287 (321.5)	180	140 -0.043	210	13	204	69	132	55.7 (90.2)	18.8	(56.5)	35.5 (39.5)	13.5	(29)	80	6-ф11	30	4	117	108.8	(79.9)	130	55	50	38.0.016	8	5	10	M8 Screw depth: 20
1524(B)G1	1/29	332.5 (367)	230	200 -0.050	260	15	230	76	145	55.7 (90.2)	18.8	(56.5)	35.5 (39.5)	13.5	(29)	80	6-ф11	60	4	164	108.8	(79.9)	130	70	56	50 .0.016	9	5.5	14	M10 Screw
	1/43	390 (424.5)	310	270 :0.056	340	20	300	89	192	55.7 (90.2)	18.8	(56.5)	35.5 (39.5)	13.5	(29)	80	6-ф11	60	4	219	108.8	(79.9)	130	90	80	60 .0.019	11	7	18	depth: 18
202(B)G1	1/6 1/11 1/17	306 (355.5)	180	140 -0.043	210	13	204	69	142	57.8 (107.3)	22.6	(62.5)	35.5 (42.5)	0	(44)	80	6-ф11	30	4	117	140.8	(96.9)	176	55	50	38 .0.016	8	5	10	M8 Screw depth: 20
2024(B)G1	1/29 1/35 1/43 1/59	403 (452.5)	310	270 -0.056	340	20	300	89	181	57.8 (107.3)	22.6	(62.5)	35.5 (42.5)	0	(44)	80	6-ф11	60	4	219	140.8	(96.9)	176	90	80	60 - 0.019	11	7	18	M10 Screw depth: 18
352(B)G1	1/6 1/11 1/17	368.5 (418)	230	200 -0.056	260	15	230	76	145	57.8 (107.3)	22.6	(62.5)	35.5 (42.5)	0	(44)	80	6-ф11	60	4	164	140.8	(96.9)	176	70	56	50 .0.016	9	5.5	14	M10 Screw depth: 18
3524(B)G1	1/29	423 (472.5)	310	270 -0.056	340	20	300	89	181	57.8 (107.3)	22.6	(62.5)	35.5 (42.5)	0	(44)	80	6-ф11	60	4	219	140.8	(96.9)	176	90	80	60 -0.019	11	7	18	
	1/43	462.5 (512)	360	316:0.062	400	22	340	94	181	57.8 (107.3)	22.6	(62.5)	35.5 (42.5)	0	(44)	80	8-ф14	22.5	5	258	140.8	(96.9)	176	90	80	70 -0.019	12	7.5	20	M12 Screw depth: 24
502(B)G1	1/6 1/11 1/17	443 (492.5)	310	270 -0.056	340	20	300	89	181	57.8 (107.3)	22.6	(62.5)	35.5 (42.5)	0	(44)	80	6-ф11	60	4	219	140.8	(96.9)	176	90	80	60.0019	11	7	18	M10 Screw depth: 18
5024(B)G1	1/29 1/35 1/43 1/59	506.5 (556)	390	345 -0.062	430	22	370	110	176	57.8 (107.3)	22.6	(62.5)	35.5 (42.5)	0	(44)	80	8-ф18	22.5	5	279	140.8	(96.9)	176	110	100	80.0.019	14	9	22	M12 Screw depth: 24
	1/6	483 (532.5)	310	270 :0.056	340	20	300	89	181	57.8 (107.3)	22.6	(62.5)	35.5 (42.5)	0	(44)	80	6-ф11	60	4	219	140.8	(96.9)	176	90	80	60 -0.019	11	7	18	M10 Screw depth: 18
702(B)G1 7024(B)G1	1/11 1/17 1/29	522.5 (572) 546.5	360	316 -0.062	400	22	340	94	181	57.8 (107.3) 57.8	22.6	(62.5)	35.5 (42.5) 35.5	0	(44)	80	8-φ14	22.5	5	258	140.8	(96.9)	176	90	80	70 00019	12	7.5	20	M12 Screw depth: 24
	1/35	(596) 602.5	390 450	345 -0.062 400 -0.062 400 -0.051	430	30	370 430	110	176 210	(107.3) 57.8	22.6	(62.5)	(42.5) 35.5	0	(44)	80	8-φ18 12-φ18	22.5	6	279 320	140.8	(96.9)	176 176	110	100	95.0022	14	9	22	M20 Screw
	1/59	(652)								(107.3)		, -=)	(42.5)	Ľ	L,					1		()		1	L		L.,	Ľ		depth: 34

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. Only for the models with an electromagnetic brake.
- 4. The dimensions in brackets are for the models with an electromagnetic brake.
- 5. The lubricant oil is removed from the gear reducer before shipment, and thus please purchase the required lubricant oil and fill the oil into the gear reducer.
- 6. This geared servo motor has a keyed shaft (with a key).


HK-ST Series Geared Servo Motor Dimensions (Note 1, 5)

With a gear reducer for general industrial machines, foot mounting

HK-ST G1H (Note 6)

Model Reduc- Variable dimensions (Note 4)

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws and the oil cap may differ from the drawing.



[Unit: mm]

Model	Reduc-	variable	unnens	SIUIIS (I	NOLE 4)																											
HK-ST	tion ratio	L	LA	LB	LK	LS	LT	LP	LW	Н	KL	KA	KB	KD	KC	KE	Z	FA	FB	FC	FD	FE	FF	FG	FH	Q	QK	S	Т	U	W	Υ
52(B)G1H	1/6 1/11 1/17 1/29	320.5 (355)	100	219	150	(29)	35.5 (39.5)	(56.5)	13.5	121	55.7 (90.2)	18.8	108.8	(79.9)	130	80	11	90	135	60	15	12	40	150	180	35	32	28.0.013	7	4	8	M8 Screw - depth: 20
524(B)G1H	1/35 1/43 1/59	334 (368.5)	120	252	204	(29)	35.5 (39.5)	(56.5)	13.5	131	55.7 (90.2)	18.8	108.8	(79.9)	130	80	14	115	155	82	20	15	55	190	230	55	50	38.0.016	8	5	10	Соры. 20
102(B)G1H	1/6 1/11 1/17 1/29 1/35	345 - (379.5)	120	252	204	(29)	35.5 (39.5)	(56.5)	13.5	131	55.7 (90.2)	18.8	108.8	(79.9)	130	80	14	115	155	82	20	15	55	190	230	55	50	38.0.016	8	5	10	M8 Screw depth: 20
1024(B)G1H	1/43	397.5	150	295	230	(29)	35.5	(56.5)	13.5	170	55.7 (90.2)	18.8	108.8	(79.9)	130	80	18	145	195	100	25	22	65	290	330	70	56	50.016	9	5.5	14	
	1/59	(432) 468 (502.5)	160	352	300	(29)	(39.5) 35.5 (39.5)	(56.5)	13.5	218	55.7 (90.2)	18.8	108.8	(79.9)	130	80	18	150	238	139	44	25	75	370	410	90	80	60.0.019	11	7	18	M10 Screw depth: 18
450/D) O 411	1/6 1/11 1/17	356 (390.5)	120	252	204	(29)	35.5 (39.5)	(56.5)	13.5	131	55.7 (90.2)	18.8	108.8	(79.9)	130	80	14	115	155	82	20	15	55	190	230	55	50	38.0.016	8	5	10	M8 Screw depth: 20
152(B)G1H 1524(B)G1H	1/29	408.5 (443)	150	295	230	(29)	35.5 (39.5)	(56.5)	13.5	170	55.7 (90.2)	18.8	108.8	(79.9)	130	80	18	145	195	100	25	22	65	290	330	70	56	50.0.016	9	5.5	14	M10 Screw
	1/43 1/59	479 (513.5)	160	352	300	(29)	35.5 (39.5)	(56.5)	13.5	218	55.7 (90.2)	18.8	108.8	(79.9)	130	80	18	150	238	139	44	25	75	370	410	90	80	60.019	11	7	18	depth: 18
202(B)G1H	1/6 1/11 1/17	375 (424.5)	120	262	204	(44)	35.5 (42.5)	(62.5)	0	131	57.8 (107.3)	22.6	140.8	(96.9)	176	80	14	115	155	82	20	15	55	190	230	55	50	38.0.016	8	5	10	M8 Screw depth: 20
2024(B)G1H	1/29 1/35 1/43 1/59	492 (541.5)	160	341	300	(44)	35.5 (42.5)	(62.5)	0	218	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	150	238	139	44	25	75	370	410	90	80	60.019	11	7	18	M10 Screw depth: 18
352(B)G1H	1/6 1/11 1/17	444.5 (494)	150	295	230	(44)	35.5 (42.5)	(62.5)	0	170	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	145	195	100	25	22	65	290	330	70	56	50.0.016	9	5.5	14	M10 Screw depth: 18
3524(B)G1H	1/29	512 (561.5)	160	341	300	(44)	35.5 (42.5)	(62.5)	0	218	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	150	238	139	44	25	75	370	410	90	80	60.019	11	7	18	асрии. то
	1/43	556.5 (606)	200	381	340	(44)	35.5 (42.5)	(62.5)	0	262	57.8 (107.3)	22.6	140.8	(96.9)	176	80	22	275	335	125	30	30	80	380	430	90	80	70.019	12	7.5	20	M12 Screw depth: 24
502(B)G1H	1/6 1/11 1/17	532 (581.5)	160	341	300	(44)	35.5 (42.5)	(62.5)	0	218	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	150	238	139	44	25	75	370	410	90	80	60.019	11	7	18	M10 Screw depth: 18
5024(B)G1H	1/29 1/35 1/43 1/59	616.5 (666)	220	405	370	(44)	35.5 (42.5)	(62.5)	0	279	57.8 (107.3)	22.6	140.8	(96.9)	176	80	22	320	380	145	30	30	85	420	470	110	100	80.0.019	14	9	22	M12 Screw depth: 24
	1/6	572 (621.5)	160	341	300	(44)	35.5 (42.5)	(62.5)	0	218	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	150	238	139	44	25	75	370	410	90	80	60.019	11	7	18	M10 Screw depth: 18
702(B)G1H	1/11	616.5 (666)	200	381	340	(44)	35.5 (42.5)	(62.5)	0	262	57.8 (107.3)	22.6	140.8	(96.9)	176	80	22	275	335	125	30	30	80	380	430	90	80	70.0.019	12	7.5	20	M12 Screw
7024(B)G1H	1/29	656.5 (706)	220	405	370	(44)	35.5 (42.5)	(62.5)	0	279	57.8 (107.3)	22.6	140.8	(96.9)	176	80	22	320	380	145	30	30	85	420	470	110	100	80 -0.019	14	9	22	depth: 24
	1/43	747.5 (797)	250	465	430	(44)	35.5 (42.5)	(62.5)	0	330	57.8 (107.3)	22.6	140.8	(96.9)	176	80	26	380	440	170	30	35	90	480	530	135	125	95.0.022	14	9	25	M20 Screw depth: 34


Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. Only for the models with an electromagnetic brake.
- 4. The dimensions in brackets are for the models with an electromagnetic brake.
- 5. The lubricant oil is removed from the gear reducer before shipment, and thus please purchase the required lubricant oil and fill the oil into the gear reducer.
- 6. This geared servo motor has a keyed shaft (with a key).

HK-ST Series Geared Servo Motor Dimensions (Note 1)

With a flange-output type gear reducer for high precision applications, flange mounting HK-ST_G5

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



[Unit: mm]

Model	Reduc-	Variable	e dimen	sions (N	ote 4)																							C
HK-ST	tion ratio	L	LA	LB	LC	LD	LE	LF	LG	LH	LK	LM	LT	KL	LP	LW	LS	Т	N	Р	R	М	кв	KD	кс	KE	Front view	
52(B)G5	1/5	210.5 (245)	105	45	85 0.035	90	59	24 +0.021	27 :0.4	8	10	85	35.5 (39.5)	154.8	(56.5)	13.5	(29)	5	6	M6	10	9	108.8	(79.9)	130	80	А	
524(B)G5	1/21 1/33 1/45	222.5 (257)	135	60	115 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	120	84	32 +0.025	35 +0.4	13	13	94	35.5 (39.5)	166.8	(56.5)	13.5	(29)	5	6	M8	12	11	108.8	(79.9)	130	80	А	-
	1/5	221.5 (256)	105	45	85.0.035	90	59	24 +0.021	27 :0.4	8	10	85	35.5 (39.5)	165.8	(56.5)	13.5	(29)	5	6	M6	10	9	108.8	(79.9)	130	80	А	ואוסוסומ
102(B)G5 1024(B)G5	1/11	233.5 (268)	135	60	115.0000	120	84	32 +0.025	35 +0.4	13	13	94	35.5 (39.5)	177.8	(56.5)	13.5	(29)	5	6	M8	12	11	108.8	(79.9)	130	80	А	S
	1/33	249.5 (284)	190	100	165 .0.063	170	122	47 +0.025	53 +0.5	13	16	107	35.5 (39.5)	193.8	(56.5)	13.5	(29)	7	14	M8	12	14	108.8	(79.9)	130	80	В	
	1/5	232.5 (267)	105	45	85.0.035	90	59	24 +0.021	27 :0.4	8	10	85	35.5 (39.5)	176.8	(56.5)	13.5	(29)	5	6	M6	10	9	108.8	(79.9)	130	80	А	
152(B)G5	1/11	244.5 (279)	135	60	115 0.035	120	84	32 +0.025	35 +0.4	13	13	94	35.5 (39.5)	188.8	(56.5)	13.5	(29)	5	6	M8	12	11	108.8	(79.9)	130	80	А	_
1524(B)G5	1/21 1/33 1/45	260.5 (295)	190	100	165 0.063	170	122	47 +0.025	53 +0.5	13	16	107	35.5 (39.5)	204.8	(56.5)	13.5	(29)	7	14	M8	12	14	108.8	(79.9)	130	80	В	Edulpi
202(B)G5	1/5	267.5 (317)	135	60	115 0.035	120	84	32 +0.025	35 +0.4	13	13	116	35.5 (42.5)	209.7	(62.5)	0	(44)	5	6	M8	12	11	140.8	(96.9)	176	80	А	E E
2024(B)G5	1/21 1/33 1/45	287.5 (337)	190	100	165 -0.063	170	122	47 0025	53 ±0.5	13	16	133	35.5 (42.5)	229.7	(62.5)	0	(44)	7	14	M8	12	14	140.8	(96.9)	176	80	В	
352(B)G5	1/5	287.5 (337)	135	60	115.0.035	120	84	32 +0.025	35 :0.5	13	13	116	35.5 (42.5)	229.7	(62.5)	0	(44)	5	6	M8	12	11	140.8	(96.9)	176	80	А	
3524(B)G5	1/11	307.5 (357)	190	100	165 0.063	170	122	47 +0.025	53 :0.8	13	16	133	35.5 (42.5)	249.7	(62.5)	0	(44)	7	14	M8	12	14	140.8	(96.9)	176	80	В	
502(B)G5 5024(B)G5	1/5	327.5 (377)	190	100	165 .0.063	170	122	47 +0.025	53 :0.8	13	16	133	35.5 (42.5)	269.7	(62.5)	0	(44)	7	14	M8	12	14	140.8	(96.9)	176	80	В	
702(B)G5 7024(B)G5	1/5	367.5 (417)	190	100	165 0.063	170	122	47 +0.025	53 :0.5	13	16	133	35.5 (42.5)	309.7	(62.5)	0	(44)	7	14	M8	12	14	140.8	(96.9)	176	80	В	

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. Only for the models with an electromagnetic brake.
- 4. The dimensions in brackets are for the models with an electromagnetic brake.


 5. HK-ST202(B)G5 to HK-ST702(B)G5 and HK-ST2024(B)G5 to HK-ST7024(B)G5 have the maximum dimensions of 180 mm × 180 mm in this part.
- 6. For the front view B, the screws are not placed at equal intervals.

HK-ST Series Geared Servo Motor Dimensions (Note 1, 5)

With a shaft-output type gear reducer for high precision applications, flange mounting

HK-ST G7 (Note 7)

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



[Unit: mm]

Model	Reduc-	Variable d	imension	s (Note 4)																			
HK-ST	tion ratio	L	LA	LC	LD	LE	S	LG	LH	Q	LR	LK	LM	LT	KL	LP	LW	LS	M	KB	KD	KC	KE
52(B)G7	1/5	210.5 (245)	105	85.0.035	90	59	25 -0.021	27	8	42	80	10	85	35.5 (39.5)	154.8	(56.5)	13.5	(29)	9	108.8	(79.9)	130	80
524(B)G7	1/21 1/33 1/45	222.5 (257)	135	115.0.035	120	84	40 0.025	35	13	82	133	13	94	35.5 (39.5)	166.8	(56.5)	13.5	(29)	11	108.8	(79.9)	130	80
	1/5	221.5 (256)	105	85 -0.035	90	59	25 -8.021	27	8	42	80	10	85	35.5 (39.5)	165.8	(56.5)	13.5	(29)	9	108.8	(79.9)	130	80
102(B)G7 1024(B)G7	1/11	233.5 (268)	135	115.00035	120	84	40 .0.025	35	13	82	133	13	94	35.5 (39.5)	177.8	(56.5)	13.5	(29)	11	108.8	(79.9)	130	80
	1/33	249.5 (284)	190	165 .0.063	170	122	50 -0.025	53	13	82	156	16	107	35.5 (39.5)	193.8	(56.5)	13.5	(29)	14	108.8	(79.9)	130	80
	1/5	232.5 (267)	105	85 -0.035	90	59	25 .0.021	27	8	42	80	10	85	35.5 (39.5)	176.8	(56.5)	13.5	(29)	9	108.8	(79.9)	130	80
152(B)G7	1/11	244.5 (279)	135	115.0.035	120	84	40 -0.025	35	13	82	133	13	94	35.5 (39.5)	188.8	(56.5)	13.5	(29)	11	108.8	(79.9)	130	80
1524(B)G7	1/21 1/33 1/45	260.5 (295)	190	165.0.063	170	122	50 0.025	53	13	82	156	16	107	35.5 (39.5)	204.8	(56.5)	13.5	(29)	14	108.8	(79.9)	130	80
202(B)G7	1/5	267.5 (317)	135	115.0.035	120	84	40 -0.025	35	13	82	133	13	116	35.5 (42.5)	209.7	(62.5)	0	(44)	11	140.8	(96.9)	176	80
2024(B)G7	1/21 1/33 1/45	287.5 (337)	190	165.0.063	170	122	50 0.025	53	13	82	156	16	133	35.5 (42.5)	229.7	(62.5)	0	(44)	14	140.8	(96.9)	176	80
352(B)G7	1/5	287.5 (337)	135	115.0.035	120	84	40 -0.025	35	13	82	133	13	116	35.5 (42.5)	229.7	(62.5)	0	(44)	11	140.8	(96.9)	176	80
3524(B)G7	1/11	307.5 (357)	190	165.0.063	170	122	50 -0.025	53	13	82	156	16	133	35.5 (42.5)	249.7	(62.5)	0	(44)	14	140.8	(96.9)	176	80
502(B)G7 5024(B)G7	1/5	327.5 (377)	190	165.0.063	170	122	50 .0.025	53	13	82	156	16	133	35.5 (42.5)	269.7	(62.5)	0	(44)	14	140.8	(96.9)	176	80
702(B)G7 7024(B)G7	1/5	367.5 (417)	190	165 0.063	170	122	50 0.025	53	13	82	156	16	133	35.5 (42.5)	309.7	(62.5)	0	(44)	14	140.8	(96.9)	176	80

- Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
 - 2. The electromagnetic brake terminals do not have polarity.
 - 3. Only for the models with an electromagnetic brake.
 - 4. The dimensions in brackets are for the models with an electromagnetic brake.
 - 5. Use a friction coupling to fasten a load.
 - 6. HK-ST202(B)G7 to HK-ST702(B)G7 and HK-ST2024(B)G7 to HK-ST7024(B)G7 have the maximum dimensions of 180 mm x 180 mm in this part.
 - 7. HK-ST_G7K, a geared servo motor with a keyed shaft (with a key), is also available. Refer to "HK-ST Series Geared Servo Motor Special Shaft Dimensions" in this catalog for details.


HK-ST Series Geared Servo Motor Special Shaft Dimensions

The standard HK-ST_G7 (with a shaft-output type gear reducer for high precision applications, flange mounting) has a straight shaft. Note that this motor is also available with a keyed shaft (with a key) as HK-ST_G7K.

HK-ST_G7K (Note 1, 2)

Keyed shaft (with a single pointed key)

Model	Reduction ratio	Variab	Variable dimensions									
Model	neduction ratio	S	Q	W	QK	U	Т	Υ				
	1/5	25	42	8	36	4	7	M6 Screw				
HK-ST52(B)G7K	1/11	25	42	0	30	4	<u>'</u>	depth: 12				
HK-ST524(B)G7K	1/21							M10 Screw				
TIK 01324(B)G/TK	1/33	40	82	12	70	5	8	depth: 20				
	1/45							deptii. 20				
	1/5	25	42	8	36	4	7	M6 Screw depth: 12				
HK-ST102(B)G7K	1/11	40	82	12	70	5	8	M10 screw				
HK-ST1024(B)G7K	1/21	140	82	12	/0	5	8	depth: 20				
	1/33	-0	00	14	70		_	M10 Screw				
	1/45	50	82	14	70	5.5	9	depth: 20				
	1/5	25	42	8	36	4	7	M6 Screw depth: 12				
HK-ST152(B)G7K	1/11	40	82	12	70	5	8	M10 Screw depth: 20				
HK-ST1524(B)G7K	1/21							M40 0				
	1/33	50	82	14	70	5.5	9	M10 Screw depth: 20				
	1/45]						depin. 20				
	1/5	40	82	12	70	5	8	M10 Screw				
LIK CTOOO/D\CZK	1/11	140	02	12	//	5	0	depth: 20				
HK-ST202(B)G7K HK-ST2024(B)G7K	1/21							M10 Screw				
TIK-312024(B)G/K	1/33	50	82	14	70	5.5	9	depth: 20				
	1/45							deptii. 20				
HK-ST352(B)G7K	1/5	40	82	12	70	5	8	M10 Screw depth: 20				
HK-ST3524(B)G7K	1/11											
	1/21	1										
HK-ST502(B)G7K	1/5	50	82	14	70	5.5	9	M10 Screw				
HK-ST5024(B)G7K	1/11	130	02	14	10	0.5	9	depth: 20				
HK-ST702(B)G7K HK-ST7024(B)G7K	1/5											



[Unit: mm]

Notes: 1. Do not use the servo motors with a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft.

2. Dimensions not shown in the tables are the same as those of HK-ST_G7 with a straight shaft. Refer to "HK-ST_G7" of "HK-ST Series Geared Servo Motor Dimensions" in this catalog.

HK-RT_W (Ultra-Low Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	90 × 90			130 × 130			
Rotary servo n	notor model HK-RT	103W	153W	203W	353W	503W	703W	
Continuous	Rated output [kW]	1.0	1.5	2.0	3.5	5.0	7.0	
running duty Note 4)	Rated torque (Note 5) [N•m]	3.2	4.8	6.4	11.1	15.9	22.3	
Maximum torq	ue (Note 3) [N•m]	8.0 (9.5)	11.9 (12.9)	15.9 (19.1)	27.9 (33.4)	47.7 (55.7)	66.8	
Rated speed (N	lote 4) [r/min]	3000	,	,	,	,		
Maximum spe	ed (Note 4) [r/min]	6700			6000		5000	
Power rate at continuous	Without electromagnetic brake	141	251	317	280	403	655	
ated torque kW/s]	With electromagnetic brake	95.6	182	249	189	301	512	
Rated current	[A]	5.2	11	9.5	16	25	28	
Maximum curr	ent (Note 3) [A]	17 (21)	34 (42)	30 (37)	51 (62)	90 (110)	102	
Moment of nertia J	Without electromagnetic brake	0.721	0.909	1.28	4.44	6.29	7.58	
x 10 ⁻⁴ kg•m ²]	With electromagnetic brake	1.06	1.25	1.63	6.57	8.41	9.70	
Permissible loa	ad to motor inertia ratio (Note 1)	11 times or less	1		10 times or less	S		
Speed/position	detector	Batteryless abs	olute/increment	al 26-bit encode	r (resolution: 67,	108,864 pulses/r	ev)	
Гуре		Permanent mag	gnet synchronou	is motor				
Oil seal		None (Servo me	otors with an oil	seal are availab	le. (HK-RT_J))			
Electromagnet	ic brake	None (Servo me	otors with an ele	ectromagnetic br	ake are available	e. (HK-RT_B))		
Thermistor		None						
nsulation clas	S	155 (F)						
Structure		Totally enclosed (IP rating: IP67)		g	Totally enclosed	d, natural cooling	J	
/ibration resist	tance *1 [m/s ²]	X: 24.5, Y: 49			X: 24.5, Y: 24.5)		
/ibration rank		V10*3						
Permissible	L [mm]	40			55			
oad for the	Radial [N]	686			980			
shaft*²	Thrust [N]	196			490			
Anna Eleni	Without electromagnetic brake	3.6	4.4	5.9	13	17	20	
Mass [kg]	With electromagnetic brake	4.7	5.5	7.0	15	19	23	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-RT	103WB	153WB	203WB	353WB	503WB	703WB
Туре			Spring actuated	type safety bra	ke			
Rated voltage			24 V DC (-10 %	to 0 %)				
Power consumption	n	[W] at 20 °C	13.8			23		
Electromagnetic be friction torque	rake static	[N·m]	9.5 or higher			16 or higher		
Permissible	Per braking	[J]	64			400		
braking work	Per hour	[J]	640			4000		
Electromagnetic	Number of brak	ing times	5000					
brake life (Note 2)	Work per brakin	ng [J]	64			400		

1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

 $^{2. \ \, \}text{Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.}$

HK-RT_4W (Ultra-Low Inertia, Medium Capacity)

Specifications when connected with a 400 V servo amplifier

Rotary servo motor model	3534W 3.5 11.1 27.9 (33.4) 6000 280 189 7.8 26 (31) 4.44 6.57	5034W 5.0 15.9 47.7 (55.7) 403 301 13 45 (55) 6.29	7034W 7.0 22.3 66.8 5000 655 512 14 51 7.58	
running duty (Note 4) Rated torque (Note 5) [N•m] 3.2 4.8 6.4 Maximum torque (Note 4) [N•m] 8.0 (9.5) (12.9) (12.9) (19.1) 15.9 (9.5) (12.9) (19.1) Rated speed (Note 4) [r/min] 3000 Maximum speed (Note 4) [r/min] 6700 Power rate at continuous rated torque [kW/s] Without electromagnetic brake 141 251 317 Rated current [A] 2.6 5.3 4.7 Maximum current (Note 3) [A] 8.5 (18) (20) (19) Moment of inertia J [x 10-4 kg•m²] Without electromagnetic brake 0.721 0.909 1.28 Inertia J [x 10-4 kg•m²] With electromagnetic brake 1.06 1.25 1.63 Recommended load to motor inertia ratio (Note 1) MR-J5 11 times or less Speed/position detector Batteryless absolute/incremental 26-bit en Type Permanent magnet synchronous motor	11.1 27.9 (33.4) 6000 280 189 7.8 26 (31) 4.44	15.9 47.7 (55.7) 403 301 13 45 (55)	22.3 66.8 5000 655 512 14 51	
Maximum torque (Note 3)	27.9 (33.4) 6000 280 189 7.8 26 (31) 4.44	47.7 (55.7) 403 301 13 45 (55)	66.8 5000 655 512 14 51	
Naximum torque (Note 4) (9.5) (12.9) (19.1)	(33.4) 6000 280 189 7.8 26 (31) 4.44	(55.7) 403 301 13 45 (55)	5000 655 512 14 51	
Maximum speed (Note 4) [r/min] 6700 Power rate at continuous rated torque [kW/s] Without electromagnetic brake 141 251 317 Rated torque [kW/s] With electromagnetic brake 95.6 182 249 Rated current [A] 2.6 5.3 4.7 Maximum current (Note 3) [A] 8.5 18 15 (11) (20) (19) Moment of inertia J [x 10-4 kg•m²] Without electromagnetic brake 0.721 0.909 1.28 Recommended load to motor inertia ratio (Note 1) MR-J5 11 times or less Speed/position detector Batteryless absolute/incremental 26-bit en Type Permanent magnet synchronous motor	280 189 7.8 26 (31) 4.44	301 13 45 (55)	655 512 14 51	
Power rate at continuous rated torque Without electromagnetic brake 141 251 317	280 189 7.8 26 (31) 4.44	301 13 45 (55)	655 512 14 51	— —
continuous rated torque [kW/s] With electromagnetic brake 141 251 317 Rated torque [kW/s] With electromagnetic brake 95.6 182 249 Rated current [A] 2.6 5.3 4.7 Maximum current (Note 3) [A] 8.5 (11) (20) (19) 18 15 (11) Moment of inertia J [x 10-4 kg•m²] Without electromagnetic brake 0.721 0.909 1.28 1.28 Recommended load to motor inertia ratio (Note 1) MR-J5 11 times or less Speed/position detector Batteryless absolute/incremental 26-bit en Type Permanent magnet synchronous motor	7.8 26 (31) 4.44	301 13 45 (55)	512 14 51	_
[kW/s] With electromagnetic brake 95.6 182 249 Rated current [A] 2.6 5.3 4.7 Maximum current (Note 3) [A] 8.5 (11) (20) (19) Moment of inertia J [x 10 ⁻⁴ kg·m²] Without electromagnetic brake 0.721 0.909 1.28 Inertia J [x 10 ⁻⁴ kg·m²] With electromagnetic brake 1.06 1.25 1.63 Recommended load to motor inertia ratio (Note 1) MR-J5 11 times or less Speed/position detector Batteryless absolute/incremental 26-bit en Permanent magnet synchronous motor	7.8 26 (31) 4.44	13 45 (55)	14 51	_
Maximum current (Note 3) [A] 8.5 (11) (20) (19) Moment of inertia J [x 10 ⁻⁴ kg•m²] Without electromagnetic brake of inertia J (Note 1) 0.721 (0.909) (1.28) Recommended load to motor inertia ratio (Note 1) MR-J5 11 times or less Speed/position detector Batteryless absolute/incremental 26-bit en Permanent magnet synchronous motor	26 (31) 4.44	45 (55)	51	= $ $
Maximum current (Note 3) Moment of inertia J [x 10 ⁻⁴ kg•m²] With electromagnetic brake 1.06 1.25 1.63 Recommended load to motor inertia ratio (Note 1) MR-J5	(31) 4.44	(55)		
inertia J [x 10 ⁻⁴ kg•m²] With electromagnetic brake 1.06 1.25 1.63 Recommended load to motor inertia ratio (Note 1) MR-J5 11 times or less Speed/position detector Batteryless absolute/incremental 26-bit en Type Permanent magnet synchronous motor		6.29	7 58	
[x 10 ⁻⁴ kg•m²] With electromagnetic brake 1.06 1.25 1.63 Recommended load to motor inertia ratio (Note 1) MR-J5 11 times or less Speed/position detector Batteryless absolute/incremental 26-bit en Permanent magnet synchronous motor	6 57		700	_
motor inertia ratio (Note 1) MR-J5D 11 times or less Speed/position detector Type Permanent magnet synchronous motor	0.57	8.41	9.70	_
Speed/position detector Speed/position detector Batteryless absolute/incremental 26-bit en Type Permanent magnet synchronous motor	10 times or less	-	-	_
Type Permanent magnet synchronous motor	10 times or le	ess		
71	coder (resolution: 6	7,108,864 puls	ses/rev)	
N (0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1				
Oil seal None (Servo motors with an oil seal are av	ailable. (HK-RT_J))		_
Electromagnetic brake None (Servo motors with an electromagne	tic brake are availa	ble. (HK-RT_B	3))	
Thermistor None		•		
Insulation class 155 (F)				—
Structure Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)	Totally enclos	sed, natural co	oling	_
Vibration resistance 1 [m/s²] X: 24.5, Y: 49	X: 24.5, Y: 24			_
Vibration rank V10 *3				
Permissible L [mm] 40	55			!
load for the Radial [N] 686	980			
shaft ² Thrust [N] 196	490			—
Without electromagnetic brake 3.6 4.4 5.9	13	17	20	—
Mass [kg] With electromagnetic brake 4.7 5.5 7.0		19	23	—

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

- 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.
- 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.
- 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
- 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.
- 6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-RT	1034WB	1534WB	2034WB	3534WB	5034WB	7034WB			
Туре			Spring actuate	d type safety l	orake		·	·			
Rated voltage			24 V DC (-10 % to 0 %)								
Power consumption	n	[W] at 20 °C	13.8			23					
Electromagnetic brake static friction torque [N•m]			9.5 or higher			16 or higher	16 or higher				
Permissible	Per braking	[J]	64			400					
braking work	Per hour	[J]	640			4000					
Electromagnetic Number of braking times			5000								
brake life (Note 2)	Work per brak	king [J]	64			400					

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.


HK-RT_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

: For 3-phase 200 V AC -: For 1-phase 200 V AC


HK-RT103W

Standard torque




HK-RT103W

Torque increased




HK-RT153W

Standard torque




HK-RT153W

Torque increased




HK-RT203W

Standard torque




HK-RT203W

Torque increased




HK-RT353W

Standard torque




HK-RT353W

Torque increased




HK-RT503W

Standard torque




HK-RT503W

Torque increased



HK-RT703W

Standard torque




Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC

HK-RT_4W Torque Characteristics (Note 1)


When connected with a 400 V servo amplifier

: For 3-phase 400 V AC : For 3-phase 380 V AC


HK-RT1034W




HK-RT1034W




HK-RT1534W Standard torque




HK-RT1534W



HK-RT2034W




HK-RT2034W




Speed [r/min]


HK-RT3534W



HK-RT3534W




HK-RT5034W




Speed [r/min]

HK-RT5034W




HK-RT7034W



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC

HK-RT Series Dimensions (Note 3, 4, 5)

HK-RT103W(B), HK-RT153W(B), HK-RT203W(B) HK-RT1034W(B), HK-RT1534W(B), HK-RT2034W(B)



Connector Electromagnetic brake (Note 11 12 Signal Pin No. name B1 Servo motor flange direction → B2


Power sup	pply	Encoder
Pin No.	Signal	Pin No.
FIII NO.	name	FIII INO.
1	E	11
2	U	12
3	W	13
4	V	14
		Variable dim

Encoder	
Pin No.	Signal
I III INO.	name
11	P5
12	MR
13	LG
14	MRR

Model	Variable dime	ensions (Note 1)
Wodel	L	KL
HK-RT103W(B)	118.9	107.2
HK-RT1034W(B)	(158.3)	(146.6)
HK-RT153W(B)	136.9	125.2
HK-RT1534W(B)	(176.3)	(164.6)
HK-RT203W(B)	172.9	161.2
HK-RT2034W(B)	(212.3)	(200.6)

[Unit: mm]

HK-RT353W(B), HK-RT503W(B), HK-RT703W(B) HK-RT3534W(B), HK-RT5034W(B), HK-RT7034W(B)




[Unit: mm]

- 1. The dimensions in brackets are for the models with an electromagnetic brake.
 - 2. The electromagnetic brake terminals do not have polarity.
 - 3. The dimensions are the same regardless of whether or not an oil seal is installed.
 - 4. Use a friction coupling to fasten a load.
 - 5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
 - 6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-RT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.
 - 7. Only for the models with an electromagnetic brake.
 - 8. HK-RT703W(B) and HK-RT7034W(B) have screw holes (M6, screw depth: 10.5 mm) for eyebolts. When using eyebolts, use a washer of ø14 mm or larger. Tighten the bolt until the washer is closely attached to the servo motor's surface.

HK-RT Series Connector Dimensions

Cable direction: load side/opposite to load side

	Variable dimensions											
Model	Dual ca	ble type			Single cable type							
	Α	В	С	D	Α	В	С	D				
HK-RT103(4)W												
HK-RT153(4)W	61.6	36	11.7	31.5	64.4	32	11.7	40				
HK-RT203(4)W												





Cable direction: opposite to load side

C 11.5


* The drawing shows a dual cable type as an example

[Unit: mm]

Cable direction: vertical

	Variable di	Variable dimensions											
Model	Dual cable	type		Single cable type									
	A	В	С	Α	В	С							
HK-RT103(4)W													
HK-RT153(4)W	88.2	36	11.7	96.7	32	11.7							
HK-RT203(4)W													





* The drawing shows a dual cable type as an example.


[Unit: mm]

HK-RT Series with Special Shaft Dimensions

Servo motors with the following specifications are also available.

K: Keyed shaft (with a double round-ended key) (Note 1)


Model	Variable	dimen	sions						
Wodel	S	R	Q	W	QK	QL	U	Т	Υ
HK-RT103(4)WK HK-RT153(4)WK HK-RT203(4)WK	19 -0.013	40	36	6	25	5	3.5	6	M5 Screw depth: 20
HK-RT353(4)WK HK-RT503(4)WK HK-RT703(4)WK	24 -0.013	55	50	8	36	5	4	7	M8 Screw depth: 20



[Unit: mm]

N: Keyed shaft (without a key) (Note 1, 2)

Model	Variable dimensions								
Model	S	R	Q	W	QK	QL	U	r	Υ
HK-RT103(4)WN HK-RT153(4)WN HK-RT203(4)WN	19 0.013	40	36	6 -0.03	25	5	3.5 +0.1	3	M5 Screw depth: 20
HK-RT353(4)WN HK-RT503(4)WN HK-RT703(4)WN	24 -0.013	55	50	8 0 -0.036	36	5	4 +0.2	4	M8 Screw depth: 20



[Unit: mm]

- Notes: 1. Do not use the servo motors with a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft.
 - 2. The servo motor is supplied without a key. The user needs to prepare a key.

Power Supply Capacity

1-axis servo amplifiers (200 V)

Rotary servo	o motor	Servo amplifier	Power supply capacity [kVA] (Note 1)
		MR-J5-10G/A	0.3
	HK-KT053W	MR-J5-20G/A	0.3
		MR-J5-40G/A	0.3
		MR-J5-10G/A	0.3
	HK-KT13W	MR-J5-20G/A	0.3
		MR-J5-40G/A	0.3
		MR-J5-20G/A	0.5
	HK-KT1M3W	MR-J5-40G/A	0.5
		MR-J5-60G/A	0.5
		MR-J5-10G/A	0.3
	HK-KT13UW	MR-J5-20G/A	0.3
		MR-J5-40G/A	0.3
		MR-J5-20G/A	0.5
	HK-KT23W	MR-J5-40G/A	0.5
		MR-J5-60G/A	0.5
		MR-J5-40G/A	0.9
	HK-KT43W	MR-J5-60G/A	0.9
		MR-J5-70G/A	0.9
		MR-J5-70G/A	1.3
	HK-KT63W	MR-J5-100G/A	1.3
		MR-J5-200G/A	1.3
	HK-KT23UW	MR-J5-20G/A	0.5
		MR-J5-40G/A	0.5
LUCIOT M		MR-J5-60G/A	0.5
HK-KT_W		MR-J5-40G/A	0.8
	HK-KT43UW	MR-J5-60G/A	0.8
		MR-J5-70G/A	0.8
		MR-J5-70G/A	1.3
	HK-KT7M3W	MR-J5-100G/A	1.3
		MR-J5-200G/A	1.3
		MR-J5-100G/A	1.9
	HK-KT103W	MR-J5-200G/A	1.9
		MR-J5-350G/A	2.0
		MR-J5-60G/A	1.3
	HK-KT63UW	MR-J5-70G/A	1.3
		MR-J5-100G/A	1.1
		MR-J5-70G/A	1.3
	HK-KT7M3UW	MR-J5-100G/A	1.3
		MR-J5-200G/A	1.3
		MR-J5-100G/A	1.8
	HK-KT103UW	MR-J5-200G/A	1.8
		MR-J5-350G/A	1.8
		MR-J5-200G/A	2.6
	HK-KT153W	MR-J5-350G/A	2.8
		MR-J5-200G/A	3.2
	HK-KT203W	MR-J5-350G/A	3.6
		MR-J5-200G/A	3.3
	HK-KT202W	MR-J5-350G/A	
	I II I I I ZUZVV	MR-J5-350G/A	3.6

Rotary servo	motor	Servo amplifier	Power supply capacity [kVA] (Note 1)
		MR-J5-20G/A	0.6
	HK-KT434W	MR-J5-40G/A	0.6
	111010110111	MR-J5-60G/A	0.6
		MR-J5-40G/A	0.8
	HK-KT634W	MR-J5-60G/A	0.8
	11K-K1034W		
		MR-J5-70G/A	0.8
	LUC 1/T7140 414/	MR-J5-40G/A	0.9
	HK-KT7M34W	MR-J5-60G/A	0.9
		MR-J5-70G/A	0.9
		MR-J5-60G/A	1.1
HK-K I _4_W	HK-KT1034W	MR-J5-70G/A	1.1
		MR-J5-100G/A	1.1
		MR-J5-70G/A	1.5
	HK-KT1534W	MR-J5-100G/A	1.5
		MR-J5-200G/A	1.5
		MR-J5-100G/A	1.9
	HK-KT2034W	MR-J5-200G/A	1.9
		MR-J5-350G/A	2.0
		MR-J5-100G/A	1.9
	HK-KT2024W	MR-J5-200G/A	1.9
		MR-J5-350G/A	2.1
		MR-J5-10G/A	0.3
	HK-MT053W	MR-J5-20G/A	0.3
		MR-J5-40G/A	0.3
	HK-MT13W	MR-J5-10G/A	0.3
		MR-J5-20G/A	0.4
		MR-J5-40G/A	0.4
		MR-J5-20G/A	0.5
	HK-MT1M3W	MR-J5-40G/A	0.5
		MR-J5-20G/A	0.5
HK-MT_W	HK-MT23W	MR-J5-40G/A	
			0.6
	HK-MT43W	MR-J5-40G/A	0.9
		MR-J5-70G/A	0.9
	HK-MT63W	MR-J5-70G/A	1.2
	HK-MT7M3W	MR-J5-200G/A	1.2
		MR-J5-70G/A	1.3
		MR-J5-200G/A	1.6
	HK-MT103W	MR-J5-100G/A	1.8
		MR-J5-200G/A	2.0
		MR-J5-10G/A	0.3
	HK-MT053VW	MR-J5-20G/A	0.3
		MR-J5-40G/A	0.3
		MR-J5-10G/A	0.3
	HK-MT13VW	MR-J5-20G/A	0.4
		MR-J5-40G/A	0.4
	LIZ NATANAON (IA)	MR-J5-20G/A	0.5
	HK-MT1M3VW	MR-J5-40G/A	0.5
	LUCATED S	MR-J5-20G/A	0.5
HK-MT_VW	HK-MT23VW	MR-J5-40G/A	0.6
		MR-J5-60G/A	0.9
	HK-MT43VW	MR-J5-70G/A	0.9
		MR-J5-70G/A	1.2
	HK-MT63VW	MR-J5-200G/A	1.2
			1.3
	HK-MT7M3VW	MR-J5-70G/A	
		MR-J5-200G/A	1.6
	HK-MT103VW	MR-J5-200G/A	2.0
		MR-J5-350G/A	2.0

Notes: 1. The power supply capacity varies depending on the power supply impedance.

2. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

Power Supply Capacity

1-axis servo amplifiers (200 V)

Rotary servo	motor	Servo amplifier	Power supply capacity [kVA] (Note 1)
	HK-ST52W	MR-J5-60G/A	1.0
		MR-J5-70G/A	1.0
		MR-J5-100G/A	1.0
		MR-J5-100G/A	1.7
	HK-ST102W	MR-J5-200G/A	1.7
		MR-J5-350G/A	1.8
	07011	MR-J5-200G/A	3.0
	HK-ST172W	MR-J5-350G/A	3.2
	07000111	MR-J5-200G/A	3.5
	HK-ST202AW	MR-J5-350G/A	3.5
	0.=0.01.	MR-J5-350G/A	4.9
HK-ST_W (Note 3)	HK-ST302W	MR-J5-500G/A	4.9
(14010 0)		MR-J5-350G/A	5.5
	HK-ST353W	MR-J5-500G/A	7.4
		MR-J5-500G/A	7.5
	HK-ST503W	MR-J5-700G/A	10.0
		MR-J5-200G/A	3.5
	HK-ST202W	MR-J5-350G/A	3.5
	HK-ST352W	MR-J5-350G/A	5.5
		MR-J5-500G/A	5.5
	HK-ST502W	MR-J5-500G/A	7.5
		MR-J5-700G/A	7.8
	HK-ST702W	MR-J5-700G/A	10
	11K-31702VV	MR-J5-40G/A	0.7
	HK-ST524W	MR-J5-60G/A	0.7
	11101324	MR-J5-70G/A	0.7
		MR-J5-60G/A	1.3
	HK-ST1024W	MR-J5-70G/A	1.3
		MR-J5-100G/A	1.3
			1.7
	HK-ST1724W	MR-J5-100G/A	
		MR-J5-200G/A	1.7
		MR-J5-350G/A	1.8
	LUC OTOOO 4 AVA	MR-J5-100G/A	1.9
HK-ST_4_W	HK-ST2024AW	MR-J5-200G/A	1.9
		MR-J5-350G/A	2.0
	HK-ST3024W	MR-J5-200G/A	2.6
		MR-J5-350G/A	2.8
	HK-ST2024W	MR-J5-200G/A	2.1
		MR-J5-350G/A	2.2
	HK-ST3524W	MR-J5-200G/A	3.2
		MR-J5-350G/A	3.5
	HK-ST5024W	MR-J5-350G/A	4.9
		MR-J5-500G/A	5.0
	HK-ST7024W	MR-J5-500G/A	6.6
	01702777	MR-J5-700G/A	6.9

Rotary servo	motor	Servo amplifier	Power supply capacity [kVA] (Note 1)
	HK-RT103W	MR-J5-100G/A	1.7
	IIK-N1103W	MR-J5-200G/A	1.7
	HK-RT153W	MR-J5-200G/A	2.5
		MR-J5-500G/A	3.1
	T_W HK-RT203W	MR-J5-200G/A	3.5
HK-RT_W		MR-J5-350G/A	3.5
	HK-RT353W	MR-J5-350G/A	5.5
	UK-H 1333W	MR-J5-500G/A	6.4
	HK-RT503W	MR-J5-500G/A	7.5
	UK-H 190944	MR-J5-700G/A	8.8
	HK-RT703W	MR-J5-700G/A	13.3

- 1. The power supply capacity varies depending on the power supply impedance.
 2. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.
 3. A power supply capacity for HK-ST152G_ is 2.5 kVA.

Power Supply Capacity

1-axis servo amplifiers (400 V)

Rotary servo motor		Servo amplifier	Power supply capacity [kVA] (Note 1)
	LUC ICTOFOLA	MR-J5-60G4/A4	0.3
	HK-KT053W	MR-J5-100G4/A4	0.3
LUZ IZT MA	LUZ IZTAOMA	MR-J5-60G4/A4	0.5
HK-KT_W	HK-KT13W	MR-J5-100G4/A4	0.4
	LUC ICTANOVA	MR-J5-60G4/A4	0.6
	HK-KT1M3W	MR-J5-100G4/A4	0.6
		MR-J5-60G4/A4	1.2
	HK-KT434W	MR-J5-100G4/A4	1.1
		MR-J5-200G4/A4	1.1
		MR-J5-100G4/A4	1.5
	HK-KT634W	MR-J5-200G4/A4	1.6
		MR-J5-350G4/A4	1.6
	HK-KT7M34W	MR-J5-100G4/A4	1.8
		MR-J5-200G4/A4	1.8
		MR-J5-350G4/A4	1.7
		MR-J5-100G4/A4	2.3
	HK-KT1034W	MR-J5-200G4/A4	2.3
HK-KT_4_W		MR-J5-350G4/A4	2.3
ПК-К I _4_VV	HK-KT634UW	MR-J5-60G4/A4	1.3
		MR-J5-100G4/A4	1.3
		MR-J5-200G4/A4	1.5
		MR-J5-100G4/A4	1.7
	HK-KT1034UW	MR-J5-200G4/A4	2.3
		MR-J5-350G4/A4	2.3
	HK-KT1534W	MR-J5-200G4/A4	3.1
	TIK-K11554W	MR-J5-350G4/A4	3.1
	HK-KT2034W	MR-J5-200G4/A4	4.0
	1111-111203477	MR-J5-350G4/A4	4.0
	HK-KT2024W	MR-J5-200G4/A4	4.0
	1111-111202400	MR-J5-350G4/A4	4.0

Rotary servo motor		Servo amplifier	Power supply capacity [kVA] (Note 1)
		MR-J5-60G4/A4	1.0
	HK-ST524W	MR-J5-100G4/A4	1.0
		MR-J5-200G4/A4	1.0
		MR-J5-100G4/A4	1.7
	HK-ST1024W	MR-J5-200G4/A4	1.7
		MR-J5-350G4/A4	1.7
LUCOT 4 M	LUZ OT4704\M	MR-J5-200G4/A4	3.2
(Note 3)	HK-ST1724W	MR-J5-350G4/A4	3.3
	HK-ST2024AW	MR-J5-200G4/A4	3.5
	TK-512024AW	MR-J5-350G4/A4	3.5
	HK-ST3024W	MR-J5-350G4/A4	4.9
	HK-ST3534W	MR-J5-350G4/A4	5.5
	LUC OTOGO ANA	MR-J5-200G4/A4	3.5
	HK-ST2024W	MR-J5-350G4/A4	3.5
	HK-ST3524W	MR-J5-350G4/A4	5.5
	LUC DT4004W	MR-J5-100G4/A4	2.2
	HK-RT1034W	MR-J5-200G4/A4	2.2
LIK DT 4W	HK-RT1534W	MR-J5-200G4/A4	3.1
HK-RT_4W	HK-RT2034W	MR-J5-200G4/A4	3.9
	nn-n i 2034VV	MR-J5-350G4/A4	3.9
	HK-RT3534W	MR-J5-350G4/A4	6.2

Notes: 1. The power supply capacity varies depending on the power supply impedance.
2. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

3. A power supply capacity for HK-ST1524G_ is 2.5 kVA.

Power Supply Capacity

Multi-axis servo amplifiers (200 V)

Rotary servo	motor	Servo amplifier	Power supply capacity [kVA] (Note 1, 2)
		MR-J5W2-22G	0.3
	HK-KT053W	MR-J5W2-44G	0.3
		MR-J5W3-222G	0.3
		MR-J5W3-444G	0.3
		MR-J5W2-22G	0.3
		MR-J5W2-44G	0.3
	HK-KT13W	MR-J5W3-222G	0.3
		MR-J5W3-444G	0.3
		MR-J5W2-22G	0.5
	HK-KT1M3W	MR-J5W2-44G	0.5
		MR-J5W3-222G	0.5
		MR-J5W3-444G	0.5
		MR-J5W2-22G	0.3
	HK-KT13UW	MR-J5W2-44G	0.3
		MR-J5W3-222G	0.3
		MR-J5W3-444G	0.3
		MR-J5W2-22G	0.5
	LIK KTOOM	MR-J5W2-44G	0.5
	HK-KT23W	MR-J5W3-222G	0.5
		MR-J5W3-444G	0.5
		MR-J5W2-44G	0.9
HK-KT_W		MR-J5W2-77G	0.9
	HK-KT43W	MR-J5W2-1010G	0.9
		MR-J5W3-444G	0.9
		MR-J5W2-77G	
	HK-KT63W		1.3
		MR-J5W2-1010G	1.3
	HK-KT23UW	MR-J5W2-22G	0.5
		MR-J5W2-44G	0.5
		MR-J5W3-222G	0.5
		MR-J5W3-444G	0.5
	HK-KT43UW	MR-J5W2-44G	0.8
		MR-J5W2-77G	0.8
		MR-J5W2-1010G	0.8
		MR-J5W3-444G	0.8
		MR-J5W2-77G	1.3
	HK-KT7M3W	MR-J5W2-1010G	1.3
	HK-KT103W	MR-J5W2-1010G	1.9
	11101011	MR-J5W2-77G	1.3
	HK-KT63UW	MR-J5W2-1010G	
			1.3
	HK-KT7M3UW	MR-J5W2-77G	1.3
		MR-J5W2-1010G	1.3
	HK-KT103UW	12 12 12/1/O 4O4OO	
	1110000	MR-J5W2-1010G	1.3
	THE TET TOO OV	MR-J5W2-22G	0.6
	HK-KT434W	MR-J5W2-22G	0.6
		MR-J5W2-22G MR-J5W2-44G	0.6 0.6
		MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G	0.6 0.6 0.6
	HK-KT434W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G	0.6 0.6 0.6 0.6 0.8
		MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G	0.6 0.6 0.6 0.6 0.8 0.8
	HK-KT434W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G	0.6 0.6 0.6 0.6 0.8 0.8
	HK-KT434W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G	0.6 0.6 0.6 0.6 0.8 0.8 0.8 0.8
HK-KT_4_W	HK-KT434W HK-KT634W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G	0.6 0.6 0.6 0.8 0.8 0.8 0.8 0.9
HK-KT_4_W	HK-KT434W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G	0.6 0.6 0.6 0.8 0.8 0.8 0.8 0.9
HK-KT_4_W	HK-KT434W HK-KT634W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-44G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G	0.6 0.6 0.6 0.8 0.8 0.8 0.8 0.9 0.9
HK-KT_4_W	HK-KT434W HK-KT634W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G	0.6 0.6 0.6 0.8 0.8 0.8 0.8 0.9 0.9 0.9
HK-KT_4_W	HK-KT434W HK-KT634W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W2-77G MR-J5W2-77G	0.6 0.6 0.6 0.8 0.8 0.8 0.8 0.9 0.9 0.9 0.9
HK-KT_4_W	HK-KT434W HK-KT634W HK-KT7M34W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W3-444G MR-J5W3-444G MR-J5W3-444G MR-J5W3-1010G	0.6 0.6 0.6 0.8 0.8 0.8 0.8 0.9 0.9 0.9 0.9 1.1 1.1
HK-KT_4_W	HK-KT634W HK-KT7M34W HK-KT1034W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W3-444G MR-J5W3-444G MR-J5W3-444G MR-J5W3-77G MR-J5W3-1010G MR-J5W3-1010G	0.6 0.6 0.6 0.8 0.8 0.8 0.8 0.9 0.9 0.9 1.1 1.1 1.5
HK-KT_4_W	HK-KT434W HK-KT634W HK-KT7M34W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W3-444G MR-J5W3-444G MR-J5W3-444G MR-J5W3-1010G	0.6 0.6 0.6 0.8 0.8 0.8 0.9 0.9 0.9 0.9 1.1 1.1 1.5 1.5
HK-KT_4_W	HK-KT634W HK-KT7M34W HK-KT1034W	MR-J5W2-22G MR-J5W2-44G MR-J5W3-222G MR-J5W3-444G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W2-44G MR-J5W2-77G MR-J5W2-1010G MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G MR-J5W3-444G MR-J5W3-444G MR-J5W3-444G MR-J5W3-77G MR-J5W3-1010G MR-J5W3-1010G	0.6 0.6 0.6 0.8 0.8 0.8 0.8 0.9 0.9 0.9 1.1 1.1 1.5

motor			
	1		4
	-		
HK-MT053W			-
			- - -
			-
		-	_
HK-MT13W	MR-J5W2-44G	0.4	_
11101111011	MR-J5W3-222G	0.4	
	MR-J5W3-444G	0.4	
	MR-J5W2-22G	0.5	
LUC NATANAOVA	MR-J5W2-44G	0.5	
HK-MITIM3W	MR-J5W3-222G	0.5	-
	MR-J5W3-444G	0.5	
			-
			1
HK-MT23W	-		-
			-
			-1
			- 1
HK-MT43W			-
			_
HK-MT63W	MR-J5W2-77G	1.2	_
LIK-INI I 02 VV	MR-J5W2-1010G	1.2	
LIK MTZM2M	MR-J5W2-77G	1.3	
HK-MT7M3W	MR-J5W2-1010G	1.3	
HK-MT103W	MR-J5W2-1010G	1.8	-
	MR-J5W2-22G	0.3	ï
HK-MT053VW			-
			-
			-
			-
		-	-
HK-MT13VW		-	.
		-	-
		-	-
	MR-J5W2-22G	0.5	_
HK-MT1M3VW	MR-J5W2-44G	0.5	_
I II C IVIT TIVIO V VV	MR-J5W3-222G	0.5	
	MR-J5W3-444G	0.5	
	MR-J5W2-22G	0.5	
LUC MTOOMA	MR-J5W2-44G	0.5	
HK-M123VW	MR-J5W3-222G	0.5	-
	MR-J5W3-444G	0.5	-
			-
HK-MT43VW	-		-
			-
HK-MT63VW			-
			-
HK-MT7M3VW			-
		+	-
HK-ST52W			-
	MR-J5W2-1010G	1.0	_
HK-ST102W	MR-J5W2-1010G	1.7	ij
	MR-J5W2-44G	0.7	
HK-ST524W	MR-J5W2-77G	0.7	
	MR-J5W3-444G	0.7	
0=	MR-J5W2-77G	1.3	
HK-ST1024W	MR-J5W2-1010G	1.3	-
		1	- 1
HK-ST1724W		1 7	
HK-ST1724W HK-ST2024AW	MR-J5W2-1010G MR-J5W2-1010G	1.7	- [
	HK-MT053W HK-MT13W HK-MT1M3W HK-MT23W HK-MT63W HK-MT7M3W HK-MT103W HK-MT103W HK-MT103W HK-MT13VW HK-MT13VW HK-MT13VW HK-MT23VW HK-MT23VW HK-MT23VW HK-MT23VW	HK-MT053W HK-MT13W HK-MT13W HK-MT13W HK-MT13W HK-MT13W HK-MT1M3W HK-MT23W HK-MT23W HK-MT43W HK-MT43W HK-MT43W HK-MT63W HK-MT103W HK-MT63W HK-MT7M3W HK-MT7M3W HK-MT103W HK-MT7M3W HK-MT7M3W HK-MT63W HK-MT103W HK-J5W2-22G MR-J5W2-22G MR-J5W3-222G MR-J5W3-244G MR-J5W3-222G MR-J5W3-222G MR-J5W3-222G MR-J5W3-222G MR-J5W3-244G MR-J5W3-222G MR-J5W3-22	MR-J5W2-22G 0.3 MR-J5W2-22G 0.3 MR-J5W2-22G 0.3 MR-J5W2-22G 0.4 MR-J5W3-222G 0.4 MR-J5W3-222G 0.4 MR-J5W3-222G 0.4 MR-J5W3-222G 0.5 MR-J5W3-244G 0.5 MR-J5W3-222G 0.5 MR-J5W3-222G 0.5 MR-J5W3-444G 0.5 MR-J5W3-222G 0.5 MR-J5W3-444G 0.5 MR-J5W3-444G 0.5 MR-J5W3-244G 0.9 MR-J5W3-1010G 0.9 MR-J5W3-1010G 0.9 MR-J5W3-1010G 1.2 MR-J5W3-1010G 1.2 MR-J5W3-1010G 1.3 MR-J5W3-222G 0.3 MR-J5W3-222G 0.3 MR-J5W3-222G 0.3 MR-J5W3-222G 0.3 MR-J5W3-222G 0.3 MR-J5W3-222G 0.4 MR-J5W3-222G 0.4 MR-J5W3-222G 0.5 MR-J5W3-244G 0.4 MR-J5W3-222G 0.5 MR-J5W3-244G 0.5 MR-J5W

^{2.} The listed values are the power supply capacity for one servo motor. For the multi-axis servo amplifiers, calculate the power supply capacity with the equation below: Power supply capacity [kVA] = Sum of power supply capacity [kVA] of the connected servo motors

Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers.
 Refer to the servo amplifiers with the same rated output.

Power Supply Capacity

Drive unit (400 V)

Select power supply capacity on the basis of the capacity of the power regeneration converter unit.

Power regeneration converter unit	Power supply capacity [kVA] (Note 1, 2)
MR-CV11K4	16
MR-CV18K4	27
MR-CV30K4	43
MR-CV37K4	53
MR-CV45K4	64
MR-CV55K4	78
MR-CV75K4	107


Notes: 1. Select power supply capacity on the basis of the capacity of the power regeneration converter unit even when multiple drive units are connected to the converter unit. Calculate the total output wattage of the servo motors driven by the drive units which are connected to the power regeneration converter unit. If this wattage is smaller than the capacity of the converter unit, the power supply capacity can be lower than the value in the table.

^{2.} An acceleration of the servo motor requires a current of 2 to 2.5 times the rated current. Secure the voltage of the main circuit power supply terminals (L1/L2/L3) of the power regeneration converter unit within the permissible voltage fluctuation. The power supply capacity varies depending on the power supply impedance.


Annotations for Rotary Servo Motor Specifications

*1. The vibration direction is shown in the diagram below. The numerical value indicates the maximum value of the component (commonly the bracket in the opposite direction

Fretting tends to occur on the bearing when the servo motor stops. Thus, maintain vibration level at approximately one-half of the allowable value.




*2. Refer to the diagram below for the permissible load for the shaft. Ensure that loads applied on the shaft do not exceed the values specified in the table. The values in the table are applicable when each load is applied singly.




L: Distance between the flange mounting surface and the center of load

*3. V10 indicates that the amplitude of the servo motor itself is 10 µm or less. The following shows mounting orientation and measuring position of the servo motor during the measurement:





*4. Refer to the diagram below for the shaft-through portion.



Annotations for Geared Servo Motor Specifications

*1. Refer to the diagram below for the permissible load for the shaft. Ensure that loads applied on the shaft do not exceed the values specified in the table. The values in the table are applicable when each load is applied singly







With a gear reducer for general industrial machines (G1/G1H)

With a shaft-output type gear reducer for high precision applications, flange mounting (G7)

With a flange-output type gear reducer for high precision applications, flange mounting (G5)

- *2. Do not mount the following servo motor in a way that the servo motor is tilted to the shaft direction or to the shaft rotation direction.
 - HK-ST102(4)G1/G1H 1/43, 1/59
 - HK-ST152(4)G1/G1H 1/29, 1/35, 1/43, 1/59
 - HK-ST202(4)G1/G1H 1/29, 1/35, 1/43, 1/59
 - · HK-ST352(4)G1/G1H all reduction ratios
 - HK-ST502(4)G1/G1H all reduction ratios
 - HK-ST702(4)G1/G1H all reduction ratios





MEMO

Linear Servo Motors


Model Designation	5-2
Specifications	
LM-H3 series	5-8
LM-AJ series	
LM-F series	5-12
LM-K2 series	5-14
LM-U2 series	5-16
Power Supply Capacity	5-18
Dimensions	
LM-H3 series	5-20
LM-AJ series	5-22
LM-F series	5-26
LM-K2 series	
LM-U2 series	5-30
List of Linear Encoders	5-32
Determining the Number of the Secondary-Side (Magnet) Blocks	5-33


 $^{^{\}star}$ Refer to p. 7-70 in this catalog for conversion of units.

Linear Servo Motors

Model Designation (Note 1)

●LM-H3 series





Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

LM-AJS20-400

LM-AJS30-080

LM-AJS30-200

LM-AJS30-400

LM-AJS40-080

LM-AJS40-200

LM-AJS40-400

JSS0

Model Designation (Note 1) LM-AJ series L M - A J P 1 B - 0 7 K - ☐ (Primary side: coil) Symbol Linear servo motor model LM-AJP1B-07K Symbol | Maximum speed [m/s] LM-AJP1D-14K M 2.0 LM-AJP2B-12S Ν 2.5 LM-AJP2D-23T JSS0 R 3.5 LM-AJP3B-17N S 4.0 LM-AJP3D-35R Τ 5.0 LM-AJP4B-22M Κ 6.5 LM-AJP4D-45N Symbol | Continuous thrust [N] 07 68.1 Symbol Length (nominal) [mm] 12 117.0 96 14 136.2 D 176 17 174.5 22 223.4 Symbol Width (nominal) [mm] 23 234.0 35 348.9 75 45 446.8 3 100 125 - (Primary side: coil) L M - A J S 1 0 - 0 8 0 - ☐ (Secondary side: magnet) Symbol Linear servo motor model LM-AJS10-080 LM-AJS10-200 LM-AJS10-400 LM-AJS20-080 LM-AJS20-200 Symbol Length (nominal) [mm]

Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

Width (nominal) [mm]

Symbol

2

3

4

50

75

100

125 (Secondary side: magnet) 080

200

400

80


200


400

Linear Servo Motors

Model Designation (Note 1)

●LM-F series







Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

Model Designation (Note 1)

●LM-K2 series







Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

Linear Servo Motors


Model Designation (Note 1)


●LM-U2 (medium thrust) series





●LM-U2 (large thrust) series





Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

LM-H3 Series Specifications

	servo motor model	LM-H3	IDOM NOD BEEN	P3A-12P- CSS0	P3B-24P- CSS0	P3C-36P- CSS0	P3D-48P- CSS0	P7A-24P- ASS0	P7B-48P- ASS0	P7C-72P- ASS0	P7D-96P- ASS0
Linear servo motor model Secondary side (magnet) Linear servo motor model LM-H3			S20-288-BSS0 S20-384-BSS0	0 S30-288-CSS0 0 S30-384-CSS0 0 S30-480-CSS0				\$70-288-A\$\$0 \$70-384-A\$\$0 \$70-480-A\$\$0 \$70-768-A\$\$0			
Cooling	method		Natural cooling								
Thrust	Continuous (Note 2)	[N]	70	120	240	360	480	240	480	720	960
IIIust	Maximum	[N]	175	300	600	900	1200	600	1200	1800	2400
Maximu	ım speed (Note 1)	[m/s]	3.0								
Magnet	tic attraction force	[N]	630	1100	2200	3300	4400	2200	4400	6600	8800
Rated of	current	[A]	1.8	1.7	3.4	5.1	6.8	3.4	6.8	10.2	13.6
Maximu	ım current	[A]	5.8	5.0	9.9	14.9	19.8	9.6	19.1	28.6	38.1
Recom	mended load to motor mas	s ratio	35 times or less								
Туре			Permanent magnet synchronous motor								
Thermi	stor		Built-in								
Insulati	on class		155 (F)								
Structu	re		Open (IP rating: IP00)								
Vibratio	n resistance	[m/s ²]	49								
	Primary side (coil)	[kg]	0.9	1.3	2.3	3.3	4.3	2.2	3.9	5.6	7.3
Mass Secondary side (magnet) [kg]			288 mm/pc: 0.7 288 mm/pc: 1.0 384 mm/pc: 0.9 384 mm/pc: 1.4 480 mm/pc: 1.1 480 mm/pc: 1.7 768 mm/pc: 1.8 768 mm/pc: 2.7					288 mm/pc: 2.8 384 mm/pc: 3.7 480 mm/pc: 4.7 768 mm/pc: 7.4			

Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.


^{2.} Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.

3. This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.


Product

LM-H3 Series Thrust Characteristics


LM-H3P2A-07P-BSS0 (Note 1, 2, 3)




LM-H3P3A-12P-CSS0 (Note 1, 2, 3)




$LM\text{-}H3P3B\text{-}24P\text{-}CSS0~^{\text{(Note 1, 2, 3)}}$




LM-H3P3C-36P-CSS0 (Note 1, 2, 3)




LM-H3P3D-48P-CSS0 (Note 1, 2, 3)




LM-H3P7A-24P-ASS0 (Note 1, 2, 3)




LM-H3P7B-48P-ASS0 (Note 1, 2, 3)



LM-H3P7C-72P-ASS0 (Note 1, 2, 3)



LM-H3P7D-96P-ASS0 (Note 1, 3)



Notes: 1. For 3-phase 200 V AC.

- 2. ---: For 1-phase 200 V AC.
- 3. Thrust drops when the power supply voltage is below the specified value.

LM-AJ Series Specifications


Linear	servo motor model	LM-AJ	P1B-	P1D-	P2B-	P2D-	P3B-	P3D-	P4B-	P4D-
Primary	/ side (coil)	LIVI-AJ	07K-JSS0	14K-JSS0	12S-JSS0	23T-JSS0	17N-JSS0	35R-JSS0	22M-JSS0	45N-JSS0
Linear	servo motor model		S10-080-JSS0		S20-080-JSS0		S30-080-JSS0		S40-080-JSS0	
	lary side (magnet)	LM-AJ	S10-200-JS	S0	S20-200-JS		S30-200-JS		S40-200-JSS0	
OCCOTIC	iary side (magnet)		S10-400-JS	S0	S20-400-JS	S0	S30-400-JS	S0	S40-400-JS	S0
Cooling	method		Natural cool	ing						
Thrust	Continuous (Note 2)	[N]	68.1	136.2	117.0	234.0	174.5	348.9	223.4	446.8
Tillust	Maximum	[N]	214.7	429.4	369.0	738.1	550.2	1100.4	704.5	1409.1
Maximu	um speed (Note 1)	[m/s]	6.5		4.0	5.0	2.5	3.5	2.0	2.5
Magnet	tic attraction force	[N]	378.8	757.6	651.1	1302.1	970.7	1941.4	1242.9	2485.9
Rated o	current	[A]	2.3	4.6	2.3	4.6	2.3	4.6	2.3	4.6
Maximu	um current	[A]	9.0	18.0	9.0	18.0	9.0	18.0	9.0	18.0
Recom	mended load to motor ma	ss ratio	10 times or	25 times or	20 times or	25 times or	30 times or less			
(Note 3)			less	less	less	less	So times or less			
Type			Permanent magnet synchronous motor							
Thermi	stor		None							
Therma	al protector		Built-in							
Insulati	on class		105 (A)							
Structu	re		Open (IP rat	ing: IP00)						
Vibratio	on resistance	[m/s ²]	49							
	Primary side (coil)	[kg]	0.6	1.1	0.9	1.7	1.2	2.3	1.5	2.9
Mass			80 mm/pc: 0	.26	80 mm/pc: 0		80 mm/pc: 0		80 mm/pc: 0	
IVIGOS	Secondary side (magnet)) [kg]	200 mm/pc:	0.65	200 mm/pc:		200 mm/pc:		200 mm/pc:	
			400 mm/pc:	1.30	400 mm/pc:	2.00	400 mm/pc:	2.80	400 mm/pc:	3.50

Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed. 2. Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.


^{3.} This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.

LM-AJ Series Thrust Characteristics


LM-AJP1B-07K-JSS0 (Note 1, 2, 3)




LM-AJP1D-14K-JSS0 (Note 1, 2, 3)




LM-AJP2B-12S-JSS0 (Note 1, 2, 3)




LM-AJP2D-23T-JSS0 (Note 1, 2, 3)




LM-AJP3B-17N-JSS0 (Note 1, 2, 3)




LM-AJP3D-35R-JSS0 (Note 1, 2, 3)



LM-AJP4B-22M-JSS0 (Note 1, 2, 3)



LM-AJP4D-45N-JSS0 (Note 1, 2, 3)



lotes: 1. For 3-phase 200 V AC.

- 2. Contact your local sales office for the thrust characteristics for 1-phase 200 V AC.
- 3. Thrust drops when the power supply voltage is below the specified value.

LM-F Series Specifications

	Linear servo motor model Primary side (coil)		P2B-06M-1SS0	P2D-12M-1SS0	P2F-18M-1SS0	P4B-12M-1SS0	P4D-24M-1SS0				
Linear servo motor model			S20-480-1SS0		S40-480-1SS0						
Secon	dary side ((magnet)	LIVI-F	S20-576-1SS0	S20-576-1SS0 S40-576-1SS0						
Cooling	g method			Natural cooling or lie	quid cooling						
	Continuo (natural c	ooling) (Note 2)	[N]	300	600	900	600	1200			
Thrust	Continuo (liquid co	us oling) ^(Note 2)	[N]	600	1200	1800	1200	2400			
	Maximum	1	[N]	1800	3600	5400	3600	7200			
Maxim	um speed	(Note 1)	[m/s]	2.0	2.0						
Magne	tic attracti	on force	[N]	4500	9000	13500	9000	18000			
Datad		Natural cooling	[A]	4.0	7.8	12	7.8	15			
Rated	current	Liquid cooling	[A]	7.8	16	23	17	31			
Maxim	um curren	t	[A]	30	58	87	57	109			
Recom	mended lo	oad to motor mas									
Туре				Permanent magnet synchronous motor							
Therm	istor			Built-in							
Insulat	ion class			155 (F)							
Structu	ıre			Open (IP rating: IP00)							
Vibratio	Vibration resistance [m/s²			49							
	Primary s	ide (coil)	[kg]	9.0	18	27	14	28			
Mass		ry side (magnet)	[kg]	480 mm/pc: 7.0 576 mm/pc: 9.0	1		480 mm/pc: 12 576 mm/pc: 15	1			


Notes:

 ^{1.} The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.
 2. Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.
 3. This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.


Precautions

LM-F Series Thrust Characteristics


LM-FP2B-06M-1SS0 (Note 1, 2, 3)




LM-FP2D-12M-1SS0 (Note 1, 3)




LM-FP2F-18M-1SS0 (Note 1, 3)



LM-FP4B-12M-1SS0 (Note 1, 3)



LM-FP4D-24M-1SS0 (Note 1, 3)



Notes: 1. For 3-phase 200 V AC.

- 2. ---: For 1-phase 200 V AC.
- 3. Thrust drops when the power supply voltage is below the specified value.
- Continuous running range (liquid cooling)
 Continuous running range (natural cooling)

LM-K2 Series Specifications

Linear	servo motor model	L NA 1/2	P1A-01M-	P1C-03M-	P2A-02M-	P2C-07M-	P2E-12M-	P3C-14M-	P3E-24M-
Primary	/ side (coil)	LM-K2	2SS1	2SS1	1SS1	1SS1	1SS1	1SS1	1SS1
			S10-288-2SS1		S20-288-1SS	S20-288-1SS1			31
	servo motor model	LM-K2	S10-384-2SS	1	S20-384-1SS	1		S30-384-1SS1	
Second	dary side (magnet) (Note 2)	LIVITIVE	S10-480-2SS1			S20-480-1SS1			31
			S10-768-2SS	1	S20-768-1SS	1		S30-768-1S	31
Cooling	method		Natural coolin	g					
Thrust	Continuous (Note 3)		120	360	240	720	1200	1440	2400
THIUSE	Maximum	[N]	300	900	600	1800	3000	3600	6000
Maximum speed (Note 1) [m/s			2.0						
Magne	tic attraction force (Note 4)	[N]	0						
	tic attraction force de) ^(Note 5)	[N]	800	2400	1100	3200	5300	6400	10700
Rated of	current	[A]	2.3	6.8	3.7	12	19	15	25
Maximu	um current	[A]	7.6	23	13	39	65	47	79
Recom (Note 6)	mended load to motor ma	ass ratio	30 times or less						
Туре			Permanent magnet synchronous motor						
Thermi	stor		Built-in						
Insulati	on class		155 (F)						
Structu	re		Open (IP rating: IP00)						
Vibratio	on resistance	[m/s ²]	49	,					
	Primary side (coil)	[kg]	2.5	6.5	4.0	10	16	18	27
			288 mm/pc: 1	.5	288 mm/pc: 1	.9		288 mm/pc:	5.5
Mass	0	4\ [[cm]	384 mm/pc: 2		384 mm/pc: 2			384 mm/pc:	
	Secondary side (magne	t) [kg]	480 mm/pc: 2	.5	480 mm/pc: 3	.2		480 mm/pc:	9.2
			768 mm/pc: 3		768 mm/pc: 5	.0		768 mm/pc:	14.6

- 2. LM-K2 series has a structure of magnetic attraction counter-force and requires at least two blocks of identical secondary side (magnet).

 3. Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.

 4. Magnetic attraction force is caused by assembly precision, etc.

 5. Magnetic attraction force which occurs on one side of the secondary side is shown.


- 6. This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.

Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.


Precautions

LM-K2 Series Thrust Characteristics


LM-K2P1A-01M-2SS1 (Note 1, 4)




LM-K2P1C-03M-2SS1 (Note 2, 3, 4)




LM-K2P2A-02M-1SS1 (Note 1, 4)




LM-K2P2C-07M-1SS1 (Note 2, 4)




LM-K2P2E-12M-1SS1 (Note 2, 4)



LM-K2P3C-14M-1SS1 (Note 2, 4)



LM-K2P3E-24M-1SS1 (Note 2, 4)



Notes: 1. : For 3-phase 200 V AC or 1-phase 200 V AC.

2. For 3-phase 200 V AC.

3. ---: For 1-phase 200 V AC.

4. Thrust drops when the power supply voltage is below the specified value.

LM-U2 Series Specifications

	servo motor model	LM-U2	PAB-05M-	_	PAF-15M-	PBB-07M-	PBD-15M-		P2B-40M-	P2C-60M-		
Primary	y side (coil)		0SS0		0SS0	1SS0	1SS0	1SS0	2SS0	2SS0	2SS0	
Linear	Linear servo motor model		SA0-240-0SS0			SB0-240-1SS1			S20-300-2SS1			
	dary side (magnet)	LM-U2	SA0-300-0SS0			SB0-300-1			S20-480-2SS1			
	aury ordo (magnot)		SA0-420-0SS0			SB0-420-1	SS1		020 100 2			
Cooling	method		Natural cooling									
Thrust	Continuous (Note 2)	[N]	50	100	150	75	150	225	400	600	800	
Tillust	Maximum	[N]	150	300	450	225	450	675	1600	2400	3200	
Maximi	um speed (Note 1)	[m/s]	2.0									
Magne	tic attraction force	[N]	0)								
Rated	current	[A]	0.9	1.9	2.7	1.5	3.0	4.6	6.6	9.8	13.1	
Maximi	um current	[A]	2.7	5.5	8.3	4.5	8.9	13.7	26.7	40.3	53.7	
Recom (Note 3)	mended load to motor ma	ss ratio	30 times or less									
Туре			Permanent magnet synchronous motor									
Thermi	stor		Built-in									
Insulati	on class		155 (F)									
Structu	re		Open (IP ra	Open (IP rating: IP00)								
Vibratio	on resistance	[m/s ²]	49									
	Primary side (coil)	[kg]	0.3	0.6	0.8	0.4	0.8	1.1	2.9	4.2	5.5	
Mass	Casandan, sida (magnat)	\ [lea]		240 mm/pc: 2.0 240 mm/pc				•		300 mm/pc: 9.6		
	Secondary side (magnet)		300 mm/pc 420 mm/pc			300 mm/pc: 3.2 420 mm/pc: 4.5			480 mm/pc: 15.3			

Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.


2. Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.

3. This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.


Precautions

LM-U2 Series Thrust Characteristics


LM-U2PAB-05M-0SS0 (Note 1, 4)




LM-U2PAD-10M-0SS0 (Note 1, 4)




LM-U2PAF-15M-0SS0 (Note 1, 4)




LM-U2PBB-07M-1SS0 (Note 1, 4)




LM-U2PBD-15M-1SS0 (Note 1, 4)




LM-U2PBF-22M-1SS0 (Note 1, 4)




LM-U2P2B-40M-2SS0 (Note 2, 3, 4)



LM-U2P2C-60M-2SS0 (Note 2, 4)



LM-U2P2D-80M-2SS0 (Note 2, 4)



Notes: 1. For 3-phase 200 V AC or 1-phase 200 V AC.

2. For 3-phase 200 V AC.

3. ---: For 1-phase 200 V AC.

4. Thrust drops when the power supply voltage is below the specified value.

Power Supply Capacity

Linear servo mo	tors (primary side)	Servo amplifiers (Note 3)	Power supply capacity [kVA] (Note 1, 2)
	LM-H3P2A-07P-BSS0	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G, MR-J5W2-1010G	0.9
		MR-J5W3-444G	10
	LM-H3P3B-24P-CSS0	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.3
M-H3 series	LM-H3P3C-36P-CSS0 LM-H3P3D-48P-CSS0	,	3.5
	LW-H3P3D-48P-C550	MR-J5-200G, MR-J5-200A	3.5
	LM-H3P7A-24P-ASS0	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.3
	LM-H3P7B-48P-ASS0	MP IS 2000 MP IS 2004	3.5
	LM-H3P7C-72P-ASS0	MR-J5-200G, MR-J5-200A	3.8
	LM-H3P7D-96P-ASS0	MR-J5-350G, MR-J5-350A	5.5
	LM-AJP1B-07K-JSS0	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G, MR-J5W2-1010G MR-J5W3-444G	0.9
	LM-AJP1D-14K-JSS0	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.3
	LM-AJP2B-12S-JSS0	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G, MR-J5W2-1010G MR-J5W3-444G	0.9
_M-AJ series	LM-AJP2D-23T-JSS0	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.3
, 10 001103	LM-AJP3B-17N-JSS0	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G, MR-J5W2-1010G MR-J5W3-444G	0.9
	LM-AJP3D-35R-JSS0	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.3
	LM-AJP4B-22M-JSS0	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G, MR-J5W2-1010G MR-J5W3-444G	0.9
	LM-AJP4D-45N-JSS0	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.3

Notes: 1. The power supply capacity varies depending on the power supply impedance.
2. The listed values are the power supply capacity for one servo motor. For the multi-axis servo amplifiers, calculate the power supply capacity with the equation below:

Power supply capacity [kVA] = Sum of power supply capacity [kVA] of the connected servo motors

3. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

Power Supply Capacity

Linear servo mo	tors (primary side)	Servo amplifiers (Note 3)	Power supply capacity [kVA] (Note 1, 2)	
	LM-FP2B-06M-1SS0	MR-J5-200G, MR-J5-200A	3.5	
	LM-FP2D-12M-1SS0	MR-J5-500G, MR-J5-500A	7.5	
LM-F series	LM-FP2F-18M-1SS0	MR-J5-700G, MR-J5-700A	10	
	LM-FP4B-12M-1SS0	MR-J5-500G, MR-J5-500A	7.5	
	LM-FP4D-24M-1SS0	MR-J5-700G, MR-J5-700A	10	
	LM-K2P1A-01M-2SS1	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G, MR-J5W2-1010G MR-J5W3-444G	0.9	
	LM-K2P1C-03M-2SS1	MR-J5-200G, MR-J5-200A	3.5	
_M-K2 series	LM-K2P2A-02M-1SS1	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.3	
	LM-K2P2C-07M-1SS1	MR-J5-350G, MR-J5-350A	5.5	
	LM-K2P2E-12M-1SS1	MR-J5-500G, MR-J5-500A	7.5	
	LM-K2P3C-14M-1SS1	MR-J5-350G, MR-J5-350A	5.5	
	LM-K2P3E-24M-1SS1	MR-J5-500G, MR-J5-500A	7.5	
	LM-U2PAB-05M-0SS0	MR-J5-20G, MR-J5-20A MR-J5W2-22G, MR-J5W2-44G MR-J5W3-222G, MR-J5W3-444G	0.5	
	LM-U2PAD-10M-0SS0	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G,	0.9	
	LM-U2PAF-15M-0SS0	MR-J5W2-1010G MR-J5W3-444G	0.9	
LM-U2 series	LM-U2PBB-07M-1SS0	MR-J5-20G, MR-J5-20A MR-J5W2-22G, MR-J5W2-44G MR-J5W3-222G, MR-J5W3-444G	0.5	
	LM-U2PBD-15M-1SS0	MR-J5-60G, MR-J5-60A MR-J5W2-77G, MR-J5W2-1010G	1.0	
	LM-U2PBF-22M-1SS0	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.3	
	LM-U2P2B-40M-2SS0	MR-J5-200G, MR-J5-200A	3.5	
	LM-U2P2C-60M-2SS0	MR-J5-350G, MR-J5-350A	5.5	
	LM-U2P2D-80M-2SS0	MR-J5-500G, MR-J5-500A	7.5	

- Notes: 1. The power supply capacity varies depending on the power supply impedance.


 2. The listed values are the power supply capacity for one servo motor. For the multi-axis servo amplifiers, calculate the power supply capacity with the equation below:

 Power supply capacity [kVA] = Sum of power supply capacity [kVA] of the connected servo motors

 3. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the
 - same rated output.

LM-H3 Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-H3P2A-07P-BSS0




[Unit: mm]

●LM-H3P3A-12P-CSS0

●LM-H3P3B-24P-CSS0

●LM-H3P3C-36P-CSS0

●LM-H3P3D-48P-CSS0




[Unit: mm]

●LM-H3P7A-24P-ASS0

●LM-H3P7B-48P-ASS0

●LM-H3P7C-72P-ASS0

●LM-H3P7D-96P-ASS0



Model	Variable dimensions						
Wodei	L	М	A	В			
LM-H3P7A-24P-ASS0	128	64	32	3 × 2			
LM-H3P7B-48P-ASS0	224	2 × 64 = 128	64	3 × 3			
LM-H3P7C-72P-ASS0	320	4 × 64 = 256	32	3 × 5			
LM-H3P7D-96P-ASS0	416	5 × 64 = 320	64	3 × 6			

[Unit: mm]


Notes: 1. Power, grounding and thermistor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.


^{2.} Minimum bending radius of the lead wire equals to six times the standard overall diameter of the lead wire.

LM-H3 Series Secondary Side (Magnet) Dimensions

- ●LM-H3S20-288-BSS0
- ●LM-H3S20-384-BSS0
- ●LM-H3S20-480-BSS0

●LM-H3S20-768-BSS0







Model	Variable dimensions				
Model	L	М	В		
LM-H3S20-288-BSS0	288	5 × 48 = 240	2 × 6		
LM-H3S20-384-BSS0	384	7 × 48 = 336	2 × 8		
LM-H3S20-480-BSS0	480	9 × 48 = 432	2 × 10		
LM-H3S20-768-BSS0	768	15 × 48 = 720	2 × 16		

[Unit: mm]

- ●LM-H3S30-288-CSS0
- ●LM-H3S30-384-CSS0
- ●LM-H3S30-480-CSS0

●LM-H3S30-768-CSS0







Model	Variable dimensions					
Model	L	М	В			
LM-H3S30-288-CSS0	288	5 × 48 = 240	2 × 6			
LM-H3S30-384-CSS0	384	7 × 48 = 336	2 × 8			
LM-H3S30-480-CSS0	480	9 × 48 = 432	2 × 10			
LM-H3S30-768-CSS0	768	15 × 48 = 720	2 × 16			

[Unit: mm]

- ●LM-H3S70-288-ASS0
- ●LM-H3S70-384-ASS0
- ●LM-H3S70-480-ASS0

●LM-H3S70-768-ASS0






Model	Variable dimensions					
Model	L	М	В			
LM-H3S70-288-ASS0	288	5 × 48 = 240	2 × 6			
LM-H3S70-384-ASS0	384	$7 \times 48 = 336$	2 × 8			
LM-H3S70-480-ASS0	480	9 × 48 = 432	2 × 10			
LM-H3S70-768-ASS0	768	15 × 48 = 720	2 × 16			

[Unit: mm]

5-21


LM-AJ Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AJP1B-07K-JSS0



[Unit: mm]

●LM-AJP1D-14K-JSS0




[Unit: mm]

LM-AJ Series Secondary Side (Magnet) Dimensions

●LM-AJS10-080-JSS0

●LM-AJS10-200-JSS0

●LM-AJS10-400-JSS0




Model	Varial	Variable dimensions					
Model	L	M	В				
LM-AJS10-080-JSS0	80	1 × 40 = 40	2 × 2				
LM-AJS10-200-JSS0	200	4 × 40 = 160	2 × 5				
LM-AJS10-400-JSS0	400	9 × 40 = 360	2 × 10				
			[Unit: mm]				


Notes: 1. Power, grounding and thermal protector lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

2. Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

LM-AJ Series Primary Side (Coil) Dimensions (Note 1, 2)


●LM-AJP2B-12S-JSS0





[Unit: mm]

●LM-AJP2D-23T-JSS0




[Unit: mm]

LM-AJ Series Secondary Side (Magnet) Dimensions

●LM-AJS20-080-JSS0

●LM-AJS20-200-JSS0

●LM-AJS20-400-JSS0



Model	Varia	Variable dimensions						
Wodei	L	M	В					
LM-AJS20-080-JSS0	80	1 × 40 = 40	2 × 2					
LM-AJS20-200-JSS0	200	4 × 40 = 160	2 × 5					
LM-AJS20-400-JSS0	400	9 × 40 = 360	2 × 10					
		1	I Init: mm1					

Approx. 0.8 Approx. 10.3

Approx. 6

Approx.


Secondary side

Notes: 1. Power, grounding and thermal protector lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

^{2.} Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

LM-AJ Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AJP3B-17N-JSS0



●LM-AJP3D-35R-JSS0

Power lead wire (U): brown, (V): white, (W): gray Grounding lead wire (E): yellow/green, 4 wires-AWG 21 Thermal protector lead wire: pink and blue, 2 wires-AWG 24 Standard OD: 7.4 mm Effective length: 3000 mm Approx. 16.2 Approx. 0.8 152 (cumulative pitch error: ±0.3) Approx. 12 12. Approx. 10.3 24 ф Protective tube 100

-ф-4×6-M3 screw depth 3.5 Structure (for primary-side mounting) Secondary side

[Unit: mm]


[Unit: mm]

LM-AJ Series Secondary Side (Magnet) Dimensions

●LM-AJS30-080-JSS0

●LM-AJS30-200-JSS0

●LM-AJS30-400-JSS0



1. Power, grounding and thermal protector lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead Notes: wires from repetitive bending.

2. Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

[Unit: mm]

[Unit: mm]

LM-AJ Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AJP4B-22M-JSS0

Power lead wire (U): brown, (V): white, (W): gray Grounding lead wire (E): yellow/green, 4 wires-AWG 21 Thermal protector lead wire: pink and blue, 2 wires-AWG 24 d OD: 7.4 mm 34.3±0.1 Effective length: 3000 mm 23.2 Approx. 0.8 Approx. 10.3 Approx. 6 96 3000±40 Approx. 60 ±0.3) 3×24=72 (cumulative pitch error: 24±0.3 12 22.5 4x20=80 cumulative pitch error: ±0.3) Protective tube 125 125 105 5x4-M3 screw depth 3.5 (for primary-side mounting) Secondary side 2 or longer

●LM-AJP4D-45N-JSS0

Power lead wire (U): brown, (V): white, (W): gray
Grounding lead wire (E): yellow/green, 4 wires-AWG 21
Thermal protector lead wire: pink and blue, 2 wires-AWG 24

Standard OD: 7.4 mm
Effective length: 3000 mm

176

152

Approx. 60

Approx. 10.3

Approx. 10.3

Approx. 10.3

Approx. 10.3

Approx. 60

Shield

Protective tube

LM-AJ Series Secondary Side (Magnet) Dimensions

pprox.

●LM-AJS40-080-JSS0

●LM-AJS40-200-JSS0


5x6-M3 screw depth 3.5 (for primary-side mounting)

●LM-AJS40-400-JSS0

2 or longer 0 0

Structure

Secondary side




Model	Variable dimensions					
IVIOGEI	L	М	В			
LM-AJS40-080-JSS0	80	1 × 40 = 40	2 × 2			
LM-AJS40-200-JSS0	200	4 × 40 = 160	2 × 5			
LM-AJS40-400-JSS0	400	9 × 40 = 360	2 × 10			


[Unit: mm]

Notes: 1. Power, grounding and thermal protector lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

^{2.} Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

LM-F Series Primary Side (Coil) Dimensions (Note 1, 2)





LM-FP2F-18M-1SS0

770

8 × 80 = 640

2 × 9 [Unit: mm]

Notes: 1. Power and thermistor cables do not have a long bending life. Fix the cables led from the primary side (coil) to a moving part to prevent the cables from repetitive bending.


2. Minimum bending radius of the cable equals to six times the standard overall diameter of the cable.

Precautions

LM-F Series Secondary Side (Magnet) Dimensions

●LM-FS20-480-1SS0

●LM-FS20-576-1SS0




Model	Variable dimensions						
Model	L	M	В	K			
LM-FS20-480-1SS0	480	4 × 96 = 384	2 × 5	432			
LM-FS20-576-1SS0	576	5 × 96 = 480	2 × 6	528			

[Unit: mm]

●LM-FS40-480-1SS0

●LM-FS40-576-1SS0




Model	Variable dimensions					
Model	L	M	В	K		
LM-FS40-480-1SS0	480	4 × 96 = 384	2 × 5	432		
LM-FS40-576-1SS0	576	5 × 96 = 480	2 × 6	528		

[Unit: mm]

LM-K2 Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-K2P1A-01M-2SS1


●LM-K2P1C-03M-2SS1



●LM-K2P2A-02M-1SS1


●LM-K2P2C-07M-1SS1

●LM-K2P2E-12M-1SS1



●LM-K2P3C-14M-1SS1

●LM-K2P3E-24M-1SS1




Notes: 1. Power, grounding and thermistor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

Minimum bending radius of the lead wire equals to six times the standard overall diameter of the lead wire.

LM-K2 Series Secondary Side (Magnet) Dimensions

- ●LM-K2S10-288-2SS1
- ●LM-K2S10-384-2SS1
- ●LM-K2S10-480-2SS1


LM-K2S10-768-2SS1



[Unit: mm]

- ●LM-K2S20-288-1SS1
- ●LM-K2S20-384-1SS1
- ●LM-K2S20-480-1SS1


LM-K2S20-768-1SS1



[Unit: mm]

- ●LM-K2S30-288-1SS1
- ●LM-K2S30-384-1SS1
- ●LM-K2S30-480-1SS1

●LM-K2S30-768-1SS1



LM-U2 Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-U2PAB-05M-0SS0

0.45±0.1

Secondary side

(0.8)


(8.7

(62)

C0.5

●LM-U2PAD-10M-0SS0

●LM-U2PAF-15M-0SS0



Model	Variable dimensions			Power/grounding lead wire		
Model	L	M	В	Size	Standard OD	
LM-U2PAB-05M-0SS0	130	2 × 60 = 120	2 × 3		1.58	
LM-U2PAD-10M-0SS0	250	4 × 60 = 240	2 × 5	AWG 26		
LM-U2PAF-15M-0SS0	370	6 × 60 = 360	2 × 7			

[Unit: mm]

●LM-U2PBB-07M-1SS0


6.4

(0.8)

(8.7)

●LM-U2PBD-15M-1SS0

●LM-U2PBF-22M-1SS0




Model	Model	Variable dimensions			Power/grounding lead wire		
	Wiodei	L	M	В	Size	Standard OD	
	LM-U2PBB-07M-1SS0	130	2 × 60 = 120	2 × 3		1.58	
	LM-U2PBD-15M-1SS0	250	4 × 60 = 240	2 × 5	AWG 26		
	LM-U2PBF-22M-1SS0	370	6 × 60 = 360	2 × 7			

[Unit: mm]

●LM-U2P2B-40M-2SS0

●LM-U2P2C-60M-2SS0

●LM-U2P2D-80M-2SS0



1. Power, grounding and thermistor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.


5-302. Minimum bending radius of the lead wire equals to six times the standard overall diameter of the lead wire.

LM-U2 Series Secondary Side (Magnet) Dimensions

●LM-U2SA0-240-0SS0

●LM-U2SA0-300-0SS0

●LM-U2SA0-420-0SS0




Model	Variable dimensions						
	L	M	В	K	N		
LM-U2SA0-240-0SS0	240	$3 \times 60 = 180$	4	180	$3 \times 60 = 180$		
LM-U2SA0-300-0SS0	300	4 × 60 = 240	5	240	4 × 60 = 240		
LM-U2SA0-420-0SS0	420	6 × 60 = 360	7	360	6 × 60 = 360		

[Unit: mm]



●LM-U2SB0-300-1SS1

●LM-U2SB0-420-1SS1




Model	Variable dimensions						
Model	L	M	В	K	N		
LM-U2SB0-240-1SS1	240	$3 \times 60 = 180$	4	180	3 × 60 = 180		
LM-U2SB0-300-1SS1	300	4 × 60 = 240	5	240	4 × 60 = 240		
LM-U2SB0-420-1SS1	420	$6 \times 60 = 360$	7	360	6 × 60 = 360		

[Unit: mm]

●LM-U2S20-300-2SS1

●LM-U2S20-480-2SS1



| L N B K | LM-U2S20-300-2SS1 | 300 | 3 × 60 = 180 | 4 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270 | 270

List of Linear Encoders (Note 1)


Contact your local sales office for compatible linear encoders.

Linear encode	r type	Manufacturer	Model	Resolution	Rated speed (Note 2)	Maximum effective measurement length (Note 3)	Communication method	
			SR77	0.05 μm/	3.3 m/s	2040 mm	Two-wire type	
			SR87	0.01 μm	0.0 11//0	3040 mm	Two who type	
		Magnescale	SR27A	-0.01 μm	3.3 m/s	2040 mm	Two-wire type/	
		Co., Ltd.	SR67A	ο.στ μπ	0.0 11//3	3640 mm	Four-wire type	
			SmartSCALE SQ47	-0.005 μm	3.3 m/s	3740 mm	(Note 6)	
			SmartSCALE SQ57	0.003 μπ	0.0 11//3	3770 mm		
			AT343A	0.05 μm	2.0 m/s	3000 mm		
			AT543A-SC	0.03 μπ	2.5 m/s	2200 mm		
		Mitutovo	AT545A-SC	20 μm/4096 (Approx. 0.005 μm)	2.5 m/s	2200 mm		
		Mitutoyo	ST743A				Two-wire type	
		Corporation	ST744A	0.1 μm	5.0 m/s	6000 mm		
			ST748A					
	Absolute		ST1341A	0.01 μm	0.0/-	12000 mm		
	type		ST1342A	0.001 μm	8.0 m/s	4200 mm		
			DECOLUTE DI 40M	1 nm	100/-	2100 mm		
		Renishaw	RESOLUTE RL40M	50 nm	100 m/s	20990 mm	Two-wire type	
			EVOLUTE EL40M	50 nm/100 nm/500 nm	100 m/s	10010 mm		
		Heidenhain	LC 495M	0.001 μm/	0.0 /-	2040 mm	Four-wire type	
			LC 195M	0.01 μm	3.0 m/s	4240 mm	(Note 6)	
Mitsubishi			LIC 4193M			3040 mm		
Electric serial			LIC 4195M	0.005 μm/ 0.01 μm	100 /-	28440 mm		
interface			LIC 4197M		10.0 m/s	6040 mm	Two-wire type/ Four-wire type	
compatible			LIC 4199M			1020 mm		
			LIC 2197M	0.05 μm/	10.0 /-	6020 mm		
			LIC 2199M	0.1 μm	10.0 m/s	6020 mm	(1000 0)	
		RSF Elektronik	MC15M	0.05 μm/ 0.1 μm	10.0 m/s	3020 mm		
		Lioittioriiit	SR75	0.05 μm/	0.0 /	2040 mm		
			SR85	0.01 μm	3.3 m/s	3040 mm	Two-wire type	
		Magnescale	SL710 + PL101-RM/RHM	0.1 μm	10.0 m/s	100000 mm	1	
		Co., Ltd.	SQ10 + PQ10 + MQ10	0.1 μm/ 0.05 μm	10.0 m/s	3800 mm	Two-wire type/ Four-wire type	
			LIDA 483 + EIB 392M (/16384)			3040 mm		
			LIDA 485 + EIB 392M (/16384)	20 µm/16384		30040 mm		
			LIDA 487 + EIB 392M (/16384)	(Approx. 1.22 nm)		6040 mm		
	Incremental type		LIDA 489 + EIB 392M (/16384)	(pp	4.0 m/s	1020 mm	Four-wire type	
	type	Heidenhain	LIDA 287 + EIB 392M (/16384)	200 μm/16384	1		(Note 6)	
,	1,700		LIDA 289 + EIB 392M (/16384)	(Approx. 12.2 nm)		10000 mm	- -	
			LIF 481 + EIB 392M (/4096)	4 μm/4096	1.6 m/s	1020 mm		
		Nista a Ossalasa	LIP 6081 + EIB 392M (/4096)	(Approx. 0.977 nm)		1440 mm		
		Nidec Sankyo Corporation	PSLH041	0.1 μm	5.0 m/s	2400 mm	Two-wire type	
A/B/Z-phase differential output type (Note 4, 7)		Not designated	- acturer for details on operating env	0.001 μm to 5 μm ^(Note 5)	Depends on the linear encoder	Depends on the linear encoder	A/B/Z-phase differential output method	

Notes: 1. Contact the relevant linear encoder manufacturer for details on operating environment and specifications of the linear encoder such as ambient temperature, vibration resistance and IP rating.

- 3. The listed values are the manufacturer's specifications. The maximum length of the encoder cable between linear encoder and servo amplifier is 30 m.
- 4. When using the A/B/Z-phase differential output type linear encoder, use MR-J5-G-RJ/MR-J5-G-RJN1/MR-J5-A-RJ servo amplifier.
- 5. Select the linear encoder within this range.
- 6. When using the four-wire type linear encoder in the fully closed loop control, use MR-J5-G-RJ/MR-J5-G-RJN1/MR-J5-A-RJ servo amplifier. The scale measurement function is supported only by MR-J5-G servo amplifier.
- function is supported only by MR-J5-G_ servo amplifier.

 7. The phase difference of the A-phase pulse and the B-phase pulse, and the width of the Z-phase pulse must be 200 ns or wider. The output pulse of A-phase and B-phase of the A/B/Z-phase differential output linear encoder is in the multiply-by-four count method. For linear encoders without Z-phase, some of the homing modes cannot be used. Refer to "MR-J5 User's Manual" for details.




^{2.} The listed values are the manufacturer's specifications. When combined with MELSERVO-J5 Series servo amplifiers, the specification is the lower value of either the listed value or the servo motor rated speed.

Precautions

Determining the Number of the Secondary-Side (Magnet) Blocks

The number of the secondary-side (magnet) blocks is determined according to the total distance calculated from the following equation $(Note\ 2)$:

(Total length of aligned secondary side (magnet)) ≥ (Maximum feed distance) + (Length of the primary side (coil))



Notes: 1. Keep the cumulative pitch error of the mounting screw holes within ±0.2 mm. When two or more secondary sides (magnets) are mounted lined up, there may be a gap between each block, depending on the mounting method and the number of the blocks.

2. LM-K2 series has a structure of magnetic attraction counter-force and requires at least two blocks of identical secondary side (magnet). Therefore, the total number of the secondary side necessary equals to twice the number determined from the equation.

МЕМО

Direct Drive Motors

Model Designation	6-2
Specifications	
TM-RG2M/TM-RU2M Series	6-4
TM-RFM Series	6-6
Machine Accuracy	6-9
Power Supply Capacity	6-10
Dimensions	
TM-RG2M Series	6-12
TM-RU2M Series	6-14
TM-RFM Series	6-16


 $^{^{\}star}$ Refer to p. 7-70 in this catalog for conversion of units.

Direct Drive Motors


Model Designation (Note 1, 2)

Low-profile series

Flange type



■Table type




Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

2. Use the direct drive motors manufactured in June 2019 or later when connecting to MR-J5 servo amplifiers.

If the direct drive motors manufactured before the date above are connected, an alarm occurs.

Model Designation (Note 1, 2) **High-rigidity series**



Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

2. Use the direct drive motors manufactured in June 2019 or later when connecting to MR-J5 servo amplifiers.

If the direct drive motors manufactured before the date above are connected, an alarm occurs.

Direct Drive Motors

TM-RG2M/TM-RU2M Series Specifications

Direct drive m	otor model TM-RG2M- TM-RU2M-	002C30	004E30	009G30		
Motor outer di (frame dimens	[mm]	ø130	ø180	ø230		
Continuous	Rated output (Note 4) [W]	69	141 (188)	283		
running duty	Rated torque (Note 3, 4) [N•m]	2.2	4.5 (6)	9		
Maximum toro	lue (Note 4) [N•m]	8.8	13.5 (18)	27		
Rated speed	[r/min]	300				
Maximum spe	ed [r/min]	600				
Power rate at rated torque (N	k\/\/\c	6.1	3.4 (6.0)	5.5		
Rated current	(Note 4) [A]	1.2	1.3 (1.7)	2.2		
Maximum cur	rent (Note 4) [A]	4.9	4.0 (5.3)	6.7		
Moment of ine	ertia J [x 10 ⁻⁴ kg•m ²]	7.88	60.2	147		
Recommende (Note 1)	d load to motor inertia ratio	50 times or less 20 times or less				
Absolute accu	racy (Note 5) [s]	±15 ±12.5				
Speed/ position detector	Absolute/incremental *1	21-bit encoder 22-bit encoder 4194304 pulses/rev				
Type		Permanent magnet synchronous motor				
Thermistor		Built-in				
Insulation class	SS	155 (F)				
Structure		Totally enclosed, natural cooling (IP rating: IP40) (Note 2)				
Vibration resis	stance *2 [m/s²]	X: 49, Y: 49				
Vibration rank		V10*4	V10*4			
Rotor permissible	Moment load [N·m]	15	49	65		
load *3	Axial load [N]	770	2300	3800		
Mass	[kg]	2.7	5.5	8.3		
Notes 4 October		and the standard of the second				

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

Refer to "Annotations for Direct Drive Motor Specifications" on p. 6-11 in this catalog for the details about asterisks 1 to 4.

^{2.} Connectors and a gap along the rotor (output shaft) are excluded.

^{3.} When unbalanced torque is generated, such as in a vertical lift machine, use the absolute position detection system, and keep the unbalanced torque under 70 % of the servo motor rated torque.


^{4.} The value in brackets is applicable when the torque is increased in combination with a larger-capacity servo amplifier. Refer to "Combinations of Direct Drive Motors and Servo Amplifiers" in this catalog for the combinations.

5. Absolute accuracy varies according to the mounting state of load and the surrounding environment.


Support

TM-RG2M/TM-RU2M Series Torque Characteristics


TM-RG2M002C30, TM-RU2M002C30 (Note 1, 2, 3)




TM-RG2M004E30, TM-RU2M004E30 (Note 1, 2, 3)



TM-RG2M004E30, TM-RU2M004E30 (Note 1, 2, 3, 4) (when torque is increased)



TM-RG2M009G30, TM-RU2M009G30 (Note 1, 2, 3)




Notes: 1. For 3-phase 200 V AC or 1-phase 230 V AC.


- 2. ---: For 1-phase 200 V AC.
- 3. Torque drops when the power supply voltage is below the specified value.
- 4. This value is applicable when the torque is increased in combination with a larger-capacity servo amplifier. Refer to "Combinations of Direct Drive Motors and Servo Amplifiers" in this catalog for the combinations.

Mounting of TM-RG2M/TM-RU2M Series

Flange type (with pilot)



■Table type (with positioning pin holes)



Precautions when mounting the direct drive motor

- Fix the direct drive motor securely on a high-rigid mounting surface because a machine resonance may occur if the rigidity of the mounting surface is low.
- Fix the mounting screws of the direct drive motor and a rotating table securely to ensure enough rigidity.
- To ensure heat dissipation and accuracy, mount the direct drive motor on a high-rigid mounting surface which has enough heat dissipation area without gaps between the bottom of the direct drive motor and the mounting surface.
- The flange type has a higher mounting accuracy than the table type. When a high-mounting accuracy is required, select the flange type.

 Refer to "Direct Drive Motor Machine Accuracy" on p. 6-9 in this catalog for the machine accuracy of each direct drive motor, and refer to the dimensions in this catalog for the dimensional tolerance.

Direct Drive Motors

TM-RFM Series Specifications

Direct drive m	otor model	TM-RFM	002C20	004C20	006C20	006E20	012E20	018E20	
Motor outer diameter (frame dimensions) [mm]			ø130	ø130			ø180		
Continuous	Rated output	[W]	42	84	126	126	251	377	
running duty	Rated torque	(Note 3) [N•m]	2	4	6	6	12	18	
Maximum tord	que	[N•m]	6	12	18	18	36	54	
Rated speed		[r/min]	200						
Maximum spe	eed	[r/min]	500						
Power rate at rated torque	continuous	[kW/s]	3.7	9.6	16.1	4.9	12.9	21.8	
Rated current		[A]	1.3	2.2	3.2	3.0	3.8	6.0	
Maximum cur	rent	[A]	3.9	6.6	9.6	9.0	12	18	
Moment of ine	ertia J	$[\times 10^{-4} \text{ kg} \cdot \text{m}^2]$	10.9	16.6	22.4	74.0	111	149	
Recommende (Note 1)	ed load to motor	r inertia ratio	50 times or less						
Absolute accu	ıracy (Note 4)	[s]	±15 ±12.5						
Speed/positio	n detector		Absolute/incremental 20-bit encoder *1 (resolution: 1048576 pulses/rev)						
Type			Permanent magnet synchronous motor						
Thermistor			Built-in						
Insulation class	SS		155 (F)						
Structure			Totally enclosed, natural cooling (IP rating: IP42) (Note 2)						
Vibration resis	stance *2	[m/s ²]	X: 49, Y: 49						
Vibration rank	(V10 ⁻⁴						
Rotor permissible	Moment load	[N•m]	22.5			70			
load *3	Axial load	[N]	1100			3300	3300		
Mass		[kg]	5.2	6.8	8.4	11	15	18	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

Refer to "Annotations for Direct Drive Motor Specifications" on p. 6-11 in this catalog for the details about asterisks 1 to 4.

^{2.} Connectors and a gap along the rotor (output shaft) are excluded.

^{3.} When unbalanced torque is generated, such as in a vertical lift machine, use the absolute position detection system, and keep the unbalanced torque under 70 % of the servo motor rated torque.

4. Absolute accuracy varies according to the mounting state of load and the surrounding environment.

TM-RFM Series Specifications

Direct drive motor model TM-RFM			012G20	048G20	072G20	040J10	120J10	240J10	
Motor outer diameter (frame dimensions) [mm]			ø230			ø330			
Continuous	Rated output	[W]	251	1005	1508	419	1257	2513	
running duty	Rated torque (Note 3	3) [N•m]	12	48	72	40	120	240	
Maximum torque [N•m]			36	144	216	120	360	720	
Rated speed		[r/min]	200			100			
Maximum speed [r/min]			500			200			
Power rate at continuous rated torque [kW/s]		6.0	37.5	59.3	9.4	40.9	91.4		
Rated current [A]		3.6	11	16	4.3	11	19		
Maximum current [A]			11	33	48	13	33	57	
Moment of inertia J [x 10 ⁻⁴ kg•m ²]			238	615	875	1694	3519	6303	
Recommended load to motor inertia ratio (Note 1)			50 times or less						
Absolute accuracy (Note 4) [s]			±12.5 ±10			±10			
Speed/positio	n detector		Absolute/incremental 20-bit encoder 1 (resolution: 1048576 pulses/rev)						
Туре			Permanent magnet synchronous motor						
Thermistor			Built-in						
Insulation class	SS		155 (F)						
Structure			Totally enclosed, natural cooling (IP rating: IP42) (Note 2)						
Vibration resistance *2 [m/s²]			X: 49, Y: 49			X: 24.5, Y: 24.5			
Vibration resistance *2 [m/s²] X: 49, Y: 49 Vibration rank V10 *4									
permissible	Moment load	[N•m]	93			350			
	Axial load	[N]	5500			16000			
Mass [kg]			17	36	52	53	91	146	
Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.									

1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.


- 2. Connectors and a gap along the rotor (output shaft) are excluded.
- 3. When unbalanced torque is generated, such as in a vertical lift machine, use the absolute position detection system, and keep the unbalanced torque under 70 % of the servo motor rated torque.

 4. Absolute accuracy varies according to the mounting state of load and the surrounding environment.


Refer to "Annotations for Direct Drive Motor Specifications" on p. 6-11 in this catalog for the details about asterisks 1 to 4.

TM-RFM Series Torque Characteristics


TM-RFM002C20 (Note 1, 2, 3)




TM-RFM004C20 (Note 1, 2, 3)




TM-RFM006C20 (Note 1, 2, 3)




TM-RFM006E20 (Note 1, 2, 3)




TM-RFM012E20 (Note 1, 2, 3)




TM-RFM018E20 (Note 1, 2, 3)




TM-RFM012G20 (Note 1, 2, 3)




TM-RFM048G20 (Note 1, 3)




TM-RFM072G20 (Note 1, 3)




TM-RFM040J10 (Note 1, 2, 3)



TM-RFM120J10 (Note 1, 3)



TM-RFM240J10 (Note 1, 3)



: For 3-phase 200 V AC or 1-phase 230 V AC.

The following direct drive motors are compatible with 1-phase 230 V AC:
TM-RFM002C20, TM-RFM004C20, TM-RFM006C20, TM-RFM006E20, TM-RFM012E20, TM-RFM018E20, TM-RFM012G20, and TM-RFM040J10

2. ---: For 1-phase 200 V AC.

3. Torque drops when the power supply voltage is below the specified value.


Precautions

Direct Drive Motor Machine Accuracy


The machine accuracy related to the direct drive motor rotor (output shaft) and mounting is indicated below:

Item	Measuring position	Accuracy [mm]
Runout of flange surface about rotor (output shaft)	а	0.05
Runout of fitting outer diameter of flange surface	b	0.07
Runout of rotor (output shaft)	С	0.04
Runout of rotor (output shaft) end	d	0.02


●TM-RG2M series



●TM-RU2M series



●TM-RFM series



Direct Drive Motors

Power Supply Capacity

Direct drive mo	otor	Servo amplifier (Note 3)	Power supply capacity [kVA] (Note 1, 2)
	TM-RG2M002C30	MR-J5-20G, MR-J5-20A MR-J5W2-22G, MR-J5W2-44G	0.25
	TM-RU2M002C30	MR-J5W3-222G, MR-J5W3-444G	
	TM-RG2M004E30	MR-J5-20G, MR-J5-20A MR-J5W2-22G	0.5
TM-RG2M/	TM-RU2M004E30	MR-J5W3-222G	
TM-RU2M series	TM-RG2M004E30	MR-J5-40G, MR-J5-40A MR-J5W2-44G	0.7
	TM-RU2M004E30	MR-J5W3-444G	
	TM-RG2M009G30	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G,	0.0
	TM-RU2M009G30	MR-J5W2-1010G MR-J5W3-444G	0.9
	TM-RFM002C20	MR-J5-20G, MR-J5-20A MR-J5W2-22G, MR-J5W2-44G MR-J5W3-222G, MR-J5W3-444G	0.25
	TM-RFM004C20	MR-J5-40G, MR-J5-40A MR-J5W2-44G, MR-J5W2-77G, MR-J5W2-1010G MR-J5W3-444G	0.38
	TM-RFM006C20	MR-J5-60G, MR-J5-60A MR-J5W2-77G, MR-J5W2-1010G	0.53
	TM-RFM006E20	MR-J5-60G, MR-J5-60A MR-J5W2-77G, MR-J5W2-1010G	0.46
	TM-RFM012E20	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	0.81
TM-RFM series	TM-RFM018E20	MR-J5-100G, MR-J5-100A MR-J5W2-1010G	1.3
	TM-RFM012G20	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	0.71
	TM-RFM048G20	MR-J5-350G, MR-J5-350A	2.7
	TM-RFM072G20	MR-J5-350G, MR-J5-350A	3.8
	TM-RFM040J10	MR-J5-70G, MR-J5-70A MR-J5W2-77G, MR-J5W2-1010G	1.2
	TM-RFM120J10	MR-J5-350G, MR-J5-350A	3.4
	TM-RFM240J10	MR-J5-500G, MR-J5-500A	6.6

Notes: 1. The power supply capacity varies depending on the power supply impedance.

2. The listed values are the power supply capacity for one servo motor. For the multi-axis servo amplifiers, calculate the power supply capacity with the equation below:

Power supply capacity [kVA] = Sum of power supply capacity [kVA] of the connected servo motors

3. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

TM-RFM series

Precautions


Annotations for Direct Drive Motor Specifications

- *1. Connect the following options for absolute position detection system.

 MR-J5-G_/MR-J5-A_: battery (MR-BAT6V1SET or MR-BAT6V1SET-A) and absolute position storage unit (MR-BTAS01)
 - MR-J5W_: battery case (MR-BT6VCASE), battery (MR-BAT6V1) x 5 pcs, and absolute position storage unit (MR-BTAS01) Refer to "MR-J5 User's Manual" for details.
- *2. The vibration direction is shown in the diagram below. The numerical value indicates the maximum value of the component. Fretting tends to occur on the bearing when the direct drive motor stops. Thus, maintain vibration level at approximately one-half of the allowable value.



*3. The following is calculation examples of axial and moment loads to the rotor (output shaft) of the direct drive motor. The axial and moment loads must be maintained equal to or below the permissible value.



Moment load


	(i ramo amonolono)	TIVI-TIOZIVI SETIES	
*	ø130	20.6	19.1
or	ø180	20.7	20.2
	ø230	18.0	24.4
	ø330	-	32.5

TM-RG2M series

Motor outer diameter Dimension A [mm]

[mm]


*4. V10 indicates that the amplitude of the direct drive motor itself is 10 µm or less. The following shows mounting posture and measuring position of the direct drive motor during the measurement:



Direct Drive Motors


TM-RG2M Series Dimensions (Note 1, 2)

●TM-RG2M002C30



[Unit: mm]

●TM-RG2M004E30



[Unit: mm]


Notes: 1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing.

2. indicates rotor.

Precautions

TM-RG2M Series Dimensions (Note 1, 2)

●TM-RG2M009G30




[Unit: mm]

 General tolerances are applied to the dimensions in which tolerances are not given in the drawing.
 Indicates rotor. Notes:

Direct Drive Motors


TM-RU2M Series Dimensions (Note 1, 2)

●TM-RU2M002C30



[Unit: mm]

●TM-RU2M004E30




[Unit: mm]

Notes: 1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing.

2. indicates rotor.

TM-RU2M Series Dimensions (Note 1, 2)

●TM-RU2M009G30




[Unit: mm]


 General tolerances are applied to the dimensions in which tolerances are not given in the drawing.
 Indicates rotor. Notes:

TM-RFM Series Dimensions (Note 1, 2)

●TM-RFM002C20, TM-RFM004C20, TM-RFM006C20



●TM-RFM006E20, TM-RFM012E20, TM-RFM018E20




[Unit: mm]

Notes: 1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing. The actual dimensions may be 1 mm to 3 mm larger than the dimensions indicated. Make allowances for the tolerance when designing a machine.


indicates rotor.

TM-RFM Series Dimensions (Note 1, 2)

●TM-RFM012G20, TM-RFM048G20, TM-RFM072G20



●TM-RFM040J10, TM-RFM120J10, TM-RFM240J10



[Unit: mm]

Notes: 1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing. The actual dimensions may be 1 mm to 3 mm larger than the dimensions indicated. Make allowances for the tolerance when designing a machine.

indicates rotor.

Direct Drive Motors

MEMO

Servo amplifier

C D L WC DC A A D L

	G	G-RJ	WG	DG	Α	A-RJ	: Applicable
Introducing MELSERVO Model Selection Software		•				•	7-2
Cable and Connector Selection Table for Servo Motors	•	•	•	•	•	•	7-2
Configuration Example for Servo Motors	•	•	•	•		•	7-4
Details of Option Connectors for Servo Motors	•	•	•	•	•	•	7-19
Products on the Market for Servo Motors	•	•	•			•	7-23
Configuration Example for MR-J5G(-RJ)/MR-J5WG	•	•	•				7-28
Configuration Example for MR-J5DG4				•			7-29
Configuration Example for MR-J5A(-RJ)					•	•	7-30
Ethernet Cable Specifications	•	•	•				7-34
Bus Bar				•			7-35
Configuration Example for MR-CM	•	•	•			•	7-36
Configuration Example for MR-J3-D05	•	•	•	•	•	•	7-37
Details of Option Connectors for Servo Amplifiers/MR-CV_/MR-CM/MR-J3-D05	•	•	•	•		•	7-38
Products on the Market for Servo Amplifiers	•	•	•		•	•	7-42
Safety Logic Unit	•	•	•	•		•	7-45
Regenerative Option	•	•	•		•	•	7-47
Multifunction Regeneration Converter	•	•				•	7-50
Battery and Battery Case	•	•	•		•	•	7-52
Absolute Position Storage Unit	•	•	•			•	7-54
Replacement Fan Unit	•	•	•	•	•	•	7-54
Cabinet-Mounting Attachment		•	•			•	7-55
Grounding Terminal Attachment	•	•			•	•	7-55
Mounting Attachment				•			7-56
Side Protection Cover				•			7-56
Junction Terminal Block		•	•			•	7-57
Radio Noise Filter/Line Noise Filter/Data Line Filter	•	•	•	•	•	•	7-59
Surge Killer		•	•	•		•	7-59
EMC Filter	•	•	•	•	•	•	7-60
Surge Protector		•	•	•		•	7-62
Power Factor Improving Reactor	•	•	•		•	•	7-63
AC Reactor				•			7-67
Servo Support Software	•	•	•	•	•	•	7-68
Unit Conversion Table	•		•			•	7-70

G MR-J5-G(-N1) G-RJ MR-J5-G-RJ(N1) WG MR-J5W2-G(-N1)/MR-J5W3-G(-N1)

DG MR-J5D1-G4(-N1)/MR-J5D2-G4(-N1)/MR-J5D3-G4(-N1) A MR-J5-A A-RJ MR-J5-A-RJ


^{*} Note that options/peripheral equipment necessary for servo amplifiers or drive units with special specifications are the same as those for standard servo amplifiers or standard drive units. Refer to the servo amplifiers or drive units with the same rated output.

^{*} Refer to p. 7-70 in this catalog for conversion of units.

 $^{^{\}star}$ In this section, a term of servo amplifier includes a combination of a drive unit and a converter unit.

Introducing MELSERVO Model Selection Software

Model selection software is now available, so you can select options such as encoder cables and power cables which are required to use with controllers, servo motors, servo amplifiers, and regenerative options of your choice.



Cable and Connector Selection Table for Servo Motors

Necessary option cables and connectors vary depending on the servo motor series. Refer to the following tables for necessary options.

Cables for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW) servo motors

Cable ype	Cable length	IP rating	Electromagnetic brake wires	Cable direction	Bending life (Note 5)	Model	Reference		
				In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2CBL_M-A1-L In the opposite direction of the load side Vertical (Note 4) Long bending life MR-AEPB2CBL_M-A5-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2CBL_M-A5-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2CBL_M-A5-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2CBL_M-A5-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2CBL_M-A5-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J10CBL03M-A1-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J20CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J20CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J20CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J20CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J20CBL03M-A5-L, MR-AEKCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J20CBL03M-A5-L, MR-AERSCBL_M-L In the direction of the load side Vertical (Note 4) Long bending life MR-AEPB2J					
				of the load side	Standard	MR-AEPB2CBL_M-A1-L	1		
			Available		Long bending life	MR-AEPB2CBL_M-A2-H			
			Available		Standard	MR-AEPB2CBL_M-A2-L			
	10 m or shorter			Vortical (Note 4)	Long bending life	MR-AEPB2CBL_M-A5-H			
	(direct	IP65 (Note 3)		vertical (100 1)	Standard	MR-AEPB2CBL_M-A5-L	n 7-6		
	connection			In the direction	Long bending life	MR-AEP2CBL_M-A1-H	p. 7-6		
type)	type)			of the load side	Standard	MR-AEP2CBL_M-A1-L			
		Not available		Long bending life	MR-AEP2CBL_M-A2-H				
		TVOT GVGIIGBIO		Standard	MR-AEP2CBL_M-A2-L				
				Vertical (Note 4)	Long bending life	MR-AEP2CBL_M-A5-H	7		
					Standard	MR-AEP2CBL_M-A5-L	1		
			Available	In the direction	Long bending life	MR-AEPB2J10CBL03M-A1-L, MR-AEKCBL_M-H			
				of the load side	Standard	MR-AEPB2J10CBL03M-A1-L, MR-AEKCBL_M-L]		
				Long bonding inc print ALI BEOTO BEOOM AL E, WIT ALIX		MR-AEPB2J10CBL03M-A2-L, MR-AEKCBL_M-H			
				Standard	MR-AEPB2J10CBL03M-A2-L, MR-AEKCBL_M-L				
			Not available	Martinal (Note 4)	Long bending life	MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-H	1		
Jal		IDOO		vertical (Note 4)	Standard	MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-L	Ī		
ible pe		IP20		In the direction	Long bending life	MR-AEP2J10CBL03M-A1-L, MR-AEKCBL_M-H	p. /-/		
þe				of the load side	Standard	MR-AEP2J10CBL03M-A1-L, MR-AEKCBL_M-L			
					Long bending life	MR-AEP2J10CBL03M-A2-L, MR-AEKCBL_M-H			
					Standard	MR-AEP2J10CBL03M-A2-L, MR-AEKCBL_M-L			
	_			Martina I (Note 4)	Long bending life	MR-AEP2J10CBL03M-A5-L, MR-AEKCBL_M-H			
	Over 10 m			vertical (Note 4)	Standard	MR-AEP2J10CBL03M-A5-L, MR-AEKCBL_M-L			
	(junction type)			In the direction	Long bending life	MR-AEPB2J20CBL03M-A1-L, MR-AENSCBL_M-H			
	,			of the load side	Standard	MR-AEPB2J20CBL03M-A1-L, MR-AENSCBL_M-L	1		
			Available		Long bending life	MR-AEPB2J20CBL03M-A2-L, MR-AENSCBL_M-H			
			rwanasio		Standard	MR-AEPB2J20CBL03M-A2-L, MR-AENSCBL_M-L			
				Vortical (Note 4)	Long bending life	MR-AEPB2J20CBL03M-A5-L, MR-AENSCBL_M-H			
		IP65		vertical	Standard	MR-AEPB2J20CBL03M-A5-L, MR-AENSCBL_M-L	n 70		
		(Note 3)		In the direction	Long bending life	MR-AEP2J20CBL03M-A1-L, MR-AENSCBL_M-H	p. 7-0		
				of the load side	Standard	MR-AEP2J20CBL03M-A1-L, MR-AENSCBL_M-L			
			Not available		Long bending life	MR-AEP2J20CBL03M-A2-L, MR-AENSCBL_M-H			
			TTO CE		Standard	MR-AEP2J20CBL03M-A2-L, MR-AENSCBL_M-L			
				Vertical (Note 4)	Long bending life	MR-AEP2J20CBL03M-A5-L, MR-AENSCBL_M-H			
				vertical (********	Standard	MR-AEP2J20CBL03M-A5-L, MR-AENSCBL_M-L	7		

^{2.} The two types of cables indicated are required.

^{3.} When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

^{4.} When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

^{5.} Long bending life cables and standard cables are for moving parts and fixed parts respectively.

Cable and Connector Selection Table for Servo Motors

Cables for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW) servo motors

Cable type	Cable length	IP rating	Electromagnetic brake wires	Cable direction	Bending life (Note 5)	Model	Reference	
				In the direction	Long bending life	MR-AEPB1CBL_M-A1-H		
			of the load side	Standard	MR-AEPB1CBL_M-A1-L			
a. 10 m or shorte			Aveilable	In the opposite direction of the	Long bending life	MR-AEPB1CBL_M-A2-H		
		or shorter	Available	Available	load side	Standard	MR-AEPB1CBL_M-A2-L	
	horter		Vertical (Note 4)	Long bending life	MR-AEPB1CBL_M-A5-H			
Single cable	(direct		IP65	IP65	P65	Vertical	Standard	MR-AEPB1CBL_M-A5-L
type	connection	(Note 3)	(Note 3)	In the direction of the load side	Long bending life	MR-AEP1CBL_M-A1-H	p. 7-9	
typo	type)				Standard	MR-AEP1CBL_M-A1-L		
		Not available	Not available	In the opposite	Long bending life	MR-AEP1CBL_M-A2-H		
			load side	Standard	MR-AEP1CBL_M-A2-L			
				Vertical (Note 4)	Long bending life	MR-AEP1CBL_M-A5-H		
					vertical (Note 1)	Standard	MR-AEP1CBL_M-A5-L	

Cables for HK-ST/HK-RT (3.5 kW to 7.0 kW) servo motors

Application	Compatible servo motor	IP rating (Note 1)	Bending life	Length	Model	Reference
	HK-ST/ HK-RT353(4)W, 503(4)W, 703(4)W	IDC7	Long	2 m to 10 m	MR-J3ENSCBL_M-H	
Encoder			bending life	20 m to 50 m	MR-AENSCBL_M-H	n 70
		IP67	Ot a seed a seed	2 m to 10 m	MR-J3ENSCBL_M-L	p. 7-8
			Standard	20 m to 30 m	MR-AENSCBL_M-L	

Connectors for HK-ST/HK-RT (3.5 kW to 7.0 kW) servo motors

Application	Compatible servo motor	IP rating (Note 1)	Connector shape	Type of connection	Model (Note 2)	Reference
	LIK OT		Ctroight	One-touch	MR-J3SCNS	p. 7-10
dor	HK-ST/	IP67	Straight	Screw	MR-ENCNS2	
Encoder	HK-RT353(4)W, 503(4)W, 703(4)W		Anglo	One-touch	MR-J3SCNSA	
			Angle	Screw	MR-ENCNS2A	
Daniel	HK-S1202(4)(W), 352(4)(W)		Straight	One-touch	MR-APWCNS4	
Power supply (Note 6)	HK-ST202(4)(W), 352(4)(W), 502(4)(W), 702(4)(W)/ HK-RT353(4)W, 503(4)W, 703(4)W	IP67		One-touch	MR-APWCNS5	p. 7-10
	LUC OT		Ctroight	One-touch	MR-BKCNS1	
Electromagnetic	HK-ST/	ID67	Straight	Screw	MR-BKCNS2	
brake	HK-RT353(4)WB, 503(4)WB, 703(4)WB	IP67	Anglo	One-touch	MR-BKCNS1A	
	/U3(4)VVD		Angle	Screw	MR-BKCNS2A	


- 2. Use the option connector set indicated to fabricate a cable.
- 3. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 4. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.
- 5. Long bending life cables and standard cables are for moving parts and fixed parts respectively.
- $6. \ Connectors \ for \ HK-ST152(4)G1/G1H/G5/G7 \ geared \ servo \ motors \ are \ the \ same \ as \ those \ for \ HK-ST172(4)W.$

Configuration Example for Rotary Servo Motors (Note 2)


G G-RJ WG DG A A-RJ

HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW) (Cable direction: load side/opposite to load side/vertical) (Note 4, 5)


Cable length of 10 m or shorter



●Cable length of over 10 m




HK-ST/HK-RT (3.5 kW to 7.0 kW)



Notes: 1. Secure this cable as it does not have a long bending life.

- 2. Cables drawn with dashed lines need to be fabricated by users. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.
- 3. This is for the servo motors with an electromagnetic brake.
- 4. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.
- 5. The cable direction in the configuration examples is in the opposite direction to the load side. Cables can be led out in the direction of the load side, the opposite to the load side, and vertical, depending on the option to be used. These cable directions are shown below.




G-RJ DG A-RJ

Servo amplifier


Precautions

Configuration Example for Rotary Servo Motors (Note 2)

For fully closed loop control (MR-J5-G_, MR-J5W2-G, MR-J5D2-G4, MR-J5-A_ and rotary servo motors) (Note 3)



For fully closed loop control (MR-J5-G_-RJ, MR-J5D1-G4, MR-J5-A_-RJ and rotary servo motors) (Note 3)



Notes: 1. Contact the relevant linear encoder manufacturers for connectors to connect with the head cables.

- 2. Cables drawn with dashed lines need to be fabricated by users. Refer to "Rotary Servo Motor User's Manual" when fabricating the cables.
- 3. Connections other than mentioned are the same as those for each rotary servo motor. Refer to cables and connectors for relevant servo motors in this catalog.
- 4. Necessary encoder cables vary depending on the servo motor series. Refer to cables and connectors for relevant servo motors in this catalog.

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models. Encoder cables are not subject to European Low Voltage Directive (50 V AC to 1000 V AC and 75 V DC to 1500 V DC).

For HK-KT/ HK-MT/ HK-RT103(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires (4) For HK-KT/ HK-RT103(4)WB, 203(4)WB Copposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-RT103(4)WB, 203(4)WB Copposite to For HK-KT/ HK-RT103(4)WB Copposite to For HK-KT/ HK-RT103(4)WB Copposite to F	No.	Item	Application	Bending life	Cable length	Model	Description/IP r	ating (Note 1)
(1) HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires (2) With electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (4) With electromagnetic brake wires (5) When the dectromagnetic brake wires (6) With electromagnetic brake wires (7) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (8) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (9) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (10) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (10) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (10) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (10) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (2) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (3) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (4) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (5) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (6) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (7) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (8) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (8) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (9) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (9) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (9) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (9) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (9) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (9) WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires (9) WB, 203(4)WB Opposite to load-side lead With					2 m	MR-AEPB2CBL2M-A1-H		
(2) Standard	(1)		1		5 m	MR-AEPB2CBL5M-A1-H		0 177
Load-side lead With electromagnetic brake wires Standard MR-AEPB2CBL2M-A1-L 10 m MR-AEPB2CBL10M-A1-L 2 m MR-AEPB2CBL2M-A2-H 5 m MR-AEPB2CBL2M-A2-H 5 m MR-AEPB2CBL10M-A2-H 10 m MR-AEPB2CBL10M-A2-H 10 m MR-AEPB2CBL10M-A2-H 10 m MR-AEPB2CBL2M-A2-L 5 m MR-AEPB2CBL10M-A2-L 10 m MR-AEPB2CBL10M-A2-L 10 m MR-AEPB2CBL10M-A2-L 10 m MR-AEPB2CBL10M-A2-L 10 m MR-AEPB2CBL10M-A2-L 2 m MR-AEPB2CBL10M-A2-L 5 m MR-AEPB2CBL10M-A2-L 10 m MR-AEPB2CBL10M-A2-L 5 m MR-AEPB2CBL10M-A2-L 10 m MR-AEPB2CBL5M-A3-H 10 m MR-AEPB3CBL5M-A3-H 10 m MR-A				bending inc	10 m	MR-AEPB2CBL10M-A1-H	connector	
With electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-MT/ (4) With electromagnetic brake wires Standard Standard Standard Standard MR-AEPB2CBL5M-A2-H 5 m MR-AEPB2CBL5M-A2-H 10 m MR-AEPB2CBL10M-A2-H 2 m MR-AEPB2CBL10M-A2-H 10 m MR-AEPB2CBL2M-A2-L 5 m MR-AEPB2CBL2M-A2-L 10 m MR-AEPB2CBL5M-A2-L 10 m MR-AEPB2CBL5M-A2-L 10 m MR-AEPB2CBL5M-A2-L 5 m MR-AEPB2CBL10M-A2-L 2 m MR-AEPB2CBL5M-A2-L 5 m MR-AEPB2CBL5M-A2-L 10 m MR-AEPB2CBL5M-A2-L 5 m MR-AEPB2CBL5M-A2-L 10 m MR-AEPB2CBL5M-A3-L 10 m MR-AEPB3CBL5M-A3-L 10 m MR-AEPB3CBL5M-					2 m	MR-AEPB2CBL2M-A1-L		
brake wires For HK-KT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-MT/ When the composite of the content of the	(2)			Standard	5 m	MR-AEPB2CBL5M-A1-L	IP65	
HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-MT/ Bending life 5 m MR-AEPB2CBL5M-A2-H 10 m MR-AEPB2CBL5M-A2-L 10 m MR-AEPB2CBL10M-A2-L 2 m MR-AEPB2CBL10M-A2-L 2 m MR-AEPB2CBL10M-A2-L 5 m MR-AEPB2CBL5M-A5-H 5 m MR-AEPB2CBL5M-A					10 m	MR-AEPB2CBL10M-A1-L		
HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-MT/ HK-MT/ Long bending life bending life 5 m MR-AEPB2CBL5M-A2-H 10 m MR-AEPB2CBL10M-A2-H 2 m MR-AEPB2CBL2M-A2-L 10 m MR-AEPB2CBL5M-A2-L 10 m MR-AEPB2CBL5M-A2-L 2 m MR-AEPB2CBL10M-A2-L 5 m MR-AEPB2CBL5M-A2-L 5 m MR-AEPB2CBL5M-A2-L 5 m MR-AEPB2CBL5M-A3-H 5 m MR-AEPB2CBL5M-A3-H 5 m MR-AEPB2CBL5M-A3-H 5 m MR-AEPB2CBL5M-A3-H 5 ervo motor connector servo motor servo motor connector servo motor servo motor connector servo motor connector servo motor servo motor servo motor connector servo motor connector servo motor servo motor servo motor servo motor connector servo motor s			For HK-KT/		2 m	MR-AEPB2CBL2M-A2-H		
(4) 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-MT/ HK-MT/ HK-MT/ HK-MT/ Servo motor Servo amplifier connector bending life 10 m MR-AEPB2CBL10M-A2-H 2 m MR-AEPB2CBL5M-A2-L 10 m MR-AEPB2CBL5M-A2-L 2 m MR-AEPB2CBL10M-A2-L 5 m MR-AEPB2CBL2M-A5-H 5 m MR-AEPB2CBL2M-A5-H 5 m MR-AEPB2CBL5M-A5-H Servo motor Connector Servo amplifier connector Conne	(3)	(3)			5 m	MR-AEPB2CBL5M-A2-H		0
Opposite to load-side lead With electromagnetic brake wires Standard Standard Standard Standard MR-AEPB2CBL5M-A2-L 10 m MR-AEPB2CBL10M-A2-L For HK-KT/ HK-MT/ HK-MT/ Bending life Servo motor connector serve amplifier serve am			. , ,	bending ine	10 m	MR-AEPB2CBL10M-A2-H	connector	Servo amplifier connector
(4) With electromagnetic brake wires Standard 5 m MR-AEPB2CBL5M-A2-L IP65 10 m MR-AEPB2CBL10M-A2-L For HK-KT/ HK-MT/ HK-MT/ bending life bending					2 m	MR-AEPB2CBL2M-A2-L		
For HK-KT/ HK-MT/ Long bending life Servo motor	(4)		1	Standard	5 m	MR-AEPB2CBL5M-A2-L	IP65	
HK-MT/ Long bending life MR-AEPB2CBL5M-A5-H Servo motor	(4)	brake wires		10 m	MR-AEPB2CBL10M-A2-L			
bending life b m MR-AEPB2CBL5M-A5-H Serve motor Serve amplifier connector Serve amplifier connector Serve amplifier connector serve motor			For HK-KT/		2 m	MR-AEPB2CBL2M-A5-H		
HK-RT103(4)WB. Deficility life connector Servo amplifier connector	(3)	HK-RT103(4)WB,		5 m	MR-AEPB2CBL5M-A5-H			
IIICICIOSCIANDO INDICATOR				10 m	MR-AEPB2CBL10M-A5-H		Servo amplifier connector	
Vertical load (Note 5) 2 m MR-AEPB2CBL2M-A5-L		-	153(4)WB, 203(4)WB Vertical lead (Note 5)		2 m	MR-AEPB2CBL2M-A5-L		
(6) Motor cable (Note 2, 3) With electromagnetic Standard 5 m MR-AEPB2CBL5M-A5-L IP65	(6)			Standard	5 m	MR-AEPB2CBL5M-A5-L	IP65	
(dual cable type/ brake wires 10 m MB-AFPB2CBI 10M-A5-I	(dual cable type/			10 m	MR-AEPB2CBL10M-A5-L	1		
direct connection type for 10 m or			For HK-KT/	Long bending life	2 m	MR-AEP2CBL2M-A1-H		
(7) Shorter) HK-MT/ Serve motor	(7)		HK-RT103(4)W,		5 m	MR-AEP2CBL5M-A1-H		
HK-R1103(4)W, 10 m MB-AFP2CBI 10M-A1-H connector Servo amplifier connector		0.101101)			10 m	MR-AEP2CBL10M-A1-H	connector	Servo amplifier connector
153(4)W, 203(4)W Load-side lead 2 m MR-AEP2CBL2M-A1-L					2 m	MR-AEP2CBL2M-A1-L		
(8) Without electromagnetic Standard 5 m MR-AEP2CBL5M-A1-L IP65	(8)	- Gliotter)		Standard	5 m	MR-AEP2CBL5M-A1-L	IP65	
brake wires 10 m MR-AEP2CBL10M-A1-L			_		10 m	MR-AEP2CBL10M-A1-L	1	
For HK-KT/ 2 m MR-AEP2CBL2M-A2-H			For HK-KT/		2 m	MR-AEP2CBL2M-A2-H		
(9) HK-MT/ Long bending life 5 m MR-AEP2CBL5M-A2-H Servo motor connector Servo amplifier connector Servo amplifier connector some connector s	(9)				5 m	MR-AEP2CBL5M-A2-H		
110 m MR-AFP2CBI 10M-A2-H			() /	bending life	10 m	MR-AEP2CBL10M-A2-H	connector	Servo amplifier connector
153(4)W, 203(4)W Opposite to load-side lead 2 m MR-AEP2CBL2M-A2-L					2 m	MR-AEP2CBL2M-A2-L		
(10) Without electromagnetic Standard 5 m MR-AEP2CBL5M-A2-L IP65	(10)			Standard	5 m	MR-AEP2CBL5M-A2-L	IP65	
brake wires 10 m MR-AEP2CBL10M-A2-L					10 m	MR-AEP2CBL10M-A2-L	1	
For HK-KT/ 2 m MR-AEP2CBL2M-A5-H		-	For HK-KT/		2 m	MR-AEP2CBL2M-A5-H		
(11) HK-MT/ Long 5 m MR-AEP2CBL5M-A5-H Servo motor	(11)			, ,	5 m	MR-AEP2CBL5M-A5-H		
HK-RT103(4)W, Deriding life III MARK AFP2CRI 10M AF H connector Servo amplifier connect			. , ,	bending life 🛭	10 m	MR-AEP2CBL10M-A5-H		Servo amplifier connector
153(4)W, 203(4)W Vertical lead (Note 5) 2 m MR-AEP2CBL2M-A5-L					2 m	MR-AEP2CBL2M-A5-L		
(12) Without electromagnetic Standard 5 m MR-AEP2CBL5M-A5-L	(12)		Vertical lead (Note 5) Without electromagnetic	Standard	5 m	MR-AEP2CBL5M-A5-L	IP65	
brake wires 10 m MR-AEP2CBL10M-A5-L	,		_		10 m	MR-AEP2CBL10M-A5-L	1	

- 2. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 3. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 4. Long bending life cables and standard cables are for moving parts and fixed parts respectively.
- 5. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models. Encoder cables are not subject to European Low Voltage Directive (50 V AC to 1000 V AC and 75 V DC to 1500 V DC).

			Ronding life	Cabla		Description/IP rating (Note 1)
No.	Item	Application	Bending life	length	Model	Description/IP rating (Note 1)
(13)		For HK-KT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J10CBL03M-A1-L	Servo motor connector Junction connector IP20 IP65
(14)		For HK-KT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J10CBL03M-A2-L	Servo motor connector Junction connector IP20 IP65
(15)	Motor cable (Note 3, 5) (dual cable type/	For HK-KT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead (Note 8) With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J10CBL03M-A5-L	Servo motor connector Junction connector IP20 IP65
(16)	junction type for over 10 m)	For HK-KT/ HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J10CBL03M-A1-L	Servo motor connector Junction connector IP20 IP65
(17)		For HK-KT/ HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J10CBL03M-A2-L	Servo motor connector Junction connector IP20 IP65
(18)		For HK-KT/ HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 8) Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J10CBL03M-A5-L	Servo motor connector Junction connector IP20 IP65
(19)	Encoder cable (Note 4, 5)	For HK-KT/ HK-MT/ HK-RT103(4)W,	Long bending life	20 m 30 m 40 m 50 m	MR-AEKCBL20M-H MR-AEKCBL30M-H MR-AEKCBL40M-H MR-AEKCBL50M-H	Junction connector Servo amplifier connector
(20)	20)	153(4)W, 203(4)W	Standard	20 m 30 m	MR-AEKCBL20M-L MR-AEKCBL30M-L	
(21)	Encoder connector set (Note 2, 4, 6)	For HK-KT/ HK-MT/ HK-RT103(4)W, 153(4)W,203(4)W, For connecting a load-side encoder	-	-	MR-ECNM	Junction connector Servo amplifier connector IP20 Applicable cable Wire size: AWG 26 to 22 Cable OD: 7 mm to 9 mm

- 2. The crimping tool (91529-1) manufactured by TE Connectivity Ltd. Company is required. Contact the manufacturer directly.
- 3. Use this cable in combination with an option from (19) to (21).
- 4. When using this cable or connector set for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW), use it in combination with an option from (13) to (18).
- 5. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 6. Use MR-EKCBL_M-H or MR-ECNM to connect to an output cable for AT343A, AT543A-SC or AT545A-SC scales manufactured by Mitutoyo Corporation.
- 7. Long bending life cables and standard cables are for moving parts and fixed parts respectively.
- 8. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models. Encoder cables are not subject to European Low Voltage Directive (50 V AC to 1000 V AC and 75 V DC to 1500 V DC).

No.	Item	Application	Bending life	length	Model	Description/IP rating (Note 1)
(22)		For HK-KT/HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires	Standard		MR-AEPB2J20CBL03M-A1-L	Servo motor connector Junction connector IP65
(23)	Motor cable (Note 4, 6, 7) (dual cable type/	For HK-KT/HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J20CBL03M-A2-L	Servo motor connector Junction connector IP65
(24)		For HK-KT/HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead (Note 9) With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J20CBL03M-A5-L	Servo motor connector Junction connector IP65
(25)	(dual cable type/ junction type for over 10 m)	For HK-KT/HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J20CBL03M-A1-L	Servo motor connector Junction connector IP65
(26)		For HK-KT/HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J20CBL03M-A2-L	Servo motor connector Junction connector IP65
(27)		For HK-KT/HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 9) Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J20CBL03M-A5-L	Servo motor connector Junction connector IP65
(28)		For HK-ST/ HK-RT353(4)W,	Long bending life	2 m 5 m	MR-J3ENSCBL2M-H MR-J3ENSCBL5M-H	
		503(4)W, 703(4)W		10 m 20 m	MR-J3ENSCBL10M-H MR-AENSCBL20M-H	_
		For HK-KT/HK-MT/	Long	30 m	MR-AENSCBL30M-H	Junction connector Servo amplifier
29)	Encoder cable		bending life		MR-AENSCBL40M-H	or encoder connector connector
	(Note 5, 6)			50 m	MR-AENSCBL50M-H	
		For HK-ST/		2 m	MR-J3ENSCBL2M-L	IP67
(30)		HK-RT353(4)W,	Standard	5 m	MR-J3ENSCBL5M-L	
		503(4)W, 703(4)W		10 m	MR-J3ENSCBL10M-L	
(31)		For HK-KT/HK-MT/	Standard	20 m	MR-AENSCBL20M-L	
()		HK-ST/HK-RT		30 m	MR-AENSCBL30M-L	
(32)	Encoder connector set (Note 2, 3, 5) (one-touch connection type)	For HK-KT/HK-MT/ HK-ST/HK-RT	-	-	MR-J3SCNS	Junction connector or encoder connector IP67 Applicable cable Wire size: 0.5 mm² (AWG 20) or smaller

- 2. Cable clamps and bushings for cable \overrightarrow{OD} of 5.5 mm to 7.5 mm and of 7.0 mm to 9.0 mm are included in the set.
- 3. The connector set contains a plug and contacts. Using contacts for other plugs may damage the connector. Use the enclosed contacts.
- 4. Use this cable in combination with (29), (31), or (32).

 5. When using this cable or connector set for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW), use it in combination with an option from (22) to (27).
- 6. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 8. Long bending life cables and standard cables are for moving parts and fixed parts respectively.
- 9. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

Precautions

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

For HK-KT/ HK-MT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)WB, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)W, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)W, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)WB, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)WB, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)W, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)W, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)W, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)WB, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)WB, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)WB, 203(4)WB Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)WB, 203(4)WB Opposite to load-side lead Witho	No.	Item	Application	Bending life	Cable length	Model	Description/IP rati	ing (Note 1)		
Sample S			-		2 m	MR-AEPB1CBL2M-A1-H				
10 m MR-AEPBICBLIOM-A1-H Servo ampillier connector	(33)				5 m	MR-AEPB1CBL5M-A1-H				
Coad-side lead With electromagnetic brake wires Standard S			` ' '	boriaing ino	10 m	MR-AEPB1CBL10M-A1-H				
With electromagnetic brake wires For HK-KT7 HK-MT7 HK-MT103(4)WB, 203(4)WB Opposite to load-side lead wires For HK-KT7 HK-MT17 HK-MT103(4)WB, 203(4)WB Opposite to load-side lead wires For HK-KT7 HK-MT17 HK-RT103(4)WB, 203(4)WB Opposite to load-side lead wires For HK-KT7 HK-MT17 HK-RT103(4)WB, 203(4)WB Opposite to load-side lead wires For HK-KT7 HK-MT17 HK-RT103(4)WB, 203(4)WB Opposite to load-side lead wires For HK-KT7 HK-MT17 HK-RT103(4)WB, 203(4)WB Opposite to load-side lead wires For HK-KT7 HK-MT17 HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead wires For HK-KT7 HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead wires For HK-KT7 HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead wires For HK-KT7 HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead wires For HK-KT7 HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-MT1/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-MT1/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-MT1/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-MT1/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-MT1/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-MT1/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-MT1/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT7 HK-MT1/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead without electromagnetic brake wires For HK-KT0/ HK-MT1/ HK-MT1/ HK-					2 m	MR-AEPB1CBL2M-A1-L				
10 m MR-AEPB1CBL10M-A1-L 1865 1870	(34)			Standard	5 m	MR-AEPB1CBL5M-A1-L		Come amplifier connector		
HK-MT7			_		10 m	MR-AEPB1CBL10M-A1-L	connector	Servo amplifier connector		
Sample S			For HK-KT/		2 m	MR-AEPB1CBL2M-A2-H				
133(4)WB, 203(4)WB	(35)		I IIX-IVI I/		5 m	MR-AEPB1CBL5M-A2-H	IP65			
(36) Copposite to load-side lead With electromagnetic brake wires Standard Standar			` ' '	bending me	10 m	MR-AEPB1CBL10M-A2-H				
With electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 203(4)W Load-side lead Wires Standard Stan					2 m	MR-AEPB1CBL2M-A2-L				
Composite to load-side lead Wiftout electromagnetic brake wires	(36)	(36)		Standard	5 m	MR-AEPB1CBL5M-A2-L				
1			brake wires		10 m	MR-AEPB1CBL10M-A2-L				
Motor cable (Note 2, 3) HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead (Note 5) With electromagnetic brake wires			For HK-KT/		2 m	MR-AEPB1CBL2M-A5-H		Servo amplifier connector		
10 m MR-AEPBICBL10M-A5-L 2 m MR-AEPBICBL2M-A5-L 2 m MR-AEPBICBL10M-A5-L 2 m MR-AEPBICBL2M-A1-H 3 m MR-AEPBICBL2M-A2-H 3 m MR-AEPBICBL2M-A3-H 3 m MR-AEPBICB	(37)	(37)			5 m	MR-AEPB1CBL5M-A5-H				
Motor cable (Noise 2.3) With electromagnetic brake wires Standard Sta			` ' '	bending life	10 m	MR-AEPB1CBL10M-A5-H	_			
Motor cable (Note 2.3) (single cable type/ direct connection type for 10 m or shorter)						2 m	MR-AEPB1CBL2M-A5-L			
Single cable type direct connection type for 10 m or shorter	(38)			Standard	5 m	MR-AEPB1CBL5M-A5-L	IP65			
(39) type for 10 m or shorter) For HK-K17 HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires Long bending life 5 m MR-AEP1CBL5M-A1-H 10 m MR-AEP1CBL5M-A1-H 10 m MR-AEP1CBL5M-A1-L 5 m MR-AEP1CBL5M-A1-L 5 m MR-AEP1CBL5M-A1-L 10 m MR-AEP1CBL5M-A2-H 10 m MR-AEP1CBL5M-A2-L 5 m MR-AEP1CBL5M-A2-L 5 m MR-AEP1CBL5M-A2-L 10 m MR-AEP1CBL5M-A2-L 10 m MR-AEP1CBL5M-A2-L 10 m MR-AEP1CBL5M-A2-L 10 m MR-AEP1CBL5M-A5-H 10 m MR-AEP1CBL5M-A5-L 10 m MR-AEP1CBL5M					10 m	MR-AEPB1CBL10M-A5-L				
HK-MT/			HK-MT/ HK-RT103(4)W, Long bend	For HK-KT/		2 m	MR-AEP1CBL2M-A1-H			
HK-RT103(4)W, 203(4)W Load-side lead Without electromagnetic brake wires Sm MR-AEP1CBL5M-A1-L Servo motor connector Servo amplifier Servo	(39)	71			5 m	MR-AEP1CBL5M-A1-H				
Load-side lead Without electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-KT/ HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)W, 203(4)W Without electromagnetic brake wires For HK-KT/ HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic Standard Standard MR-AEP1CBL2M-A2-H 5 m MR-AEP1CBL10M-A2-H 10 m MR-AEP1CBL10M-A2-L 5 m MR-AEP1CBL2M-A5-H 10 m MR-AEP1CBL2M-A5-H 5 m MR-AEP1CBL2M-A5-H 10 m MR-AEP1CBL10M-A5-H 5 m MR-AEP1CBL10M-A5-H 5 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL10M-A5-H 5 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL10M-A5-H 5 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL5M-A5-L		,		bending me	10 m	MR-AEP1CBL10M-A1-H				
(40) Without electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-MT/ HK-MT/ HK-MT/ HK-MT/ HK-MT/ HK-MT/ HK-MT/ HK-RT103(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic (44) Standard Sta					2 m	MR-AEP1CBL2M-A1-L				
Contract	(40)			Standard	5 m	MR-AEP1CBL5M-A1-L				
HK-MT/			_		10 m	MR-AEP1CBL10M-A1-L	connector	Servo amplifier connector		
(42) HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic Standard (44) Standard			For HK-KT/		2 m	MR-AEP1CBL2M-A2-H			1	
(42) 10 m MR-AEP1CBL10M-A2-H 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic Standard 10 m MR-AEP1CBL2M-A2-L 5 m MR-AEP1CBL5M-A2-L 2 m MR-AEP1CBL2M-A5-H 5 m MR-AEP1CBL5M-A5-H 10 m MR-AEP1CBL5M-A5-H 2 m MR-AEP1CBL5M-A5-H 10 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL2M-A5-L 10 m MR-AEP1CBL5M-A5-L 10 m MR-AEP1C	(41)				5 m	MR-AEP1CBL5M-A2-H	IP65			
Opposite to load-side lead Without electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic Without electromagnetic Standard MR-AEP1CBL2M-A2-L 5 m MR-AEP1CBL10M-A2-L 2 m MR-AEP1CBL2M-A5-H 5 m MR-AEP1CBL5M-A5-H 10 m MR-AEP1CBL5M-A5-H 5 m MR-AEP1CBL10M-A5-H 2 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL2M-A5-H 5 m MR-AEP1CBL10M-A5-H 10 m MR-AEP1CBL5M-A5-H 10 m MR-AEP1CBL5M-A5-			` ' '	bending life	10 m	MR-AEP1CBL10M-A2-H				
(42) Without electromagnetic brake wires For HK-KT/ HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic Without electromagnetic brake wires Standard Standard Standard MR-AEP1CBL5M-A2-L 10 m MR-AEP1CBL2M-A5-H 5 m MR-AEP1CBL5M-A5-H 10 m MR-AEP1CBL5M-A5-H 2 m MR-AEP1CBL10M-A5-H 2 m MR-AEP1CBL2M-A5-L Servo motor connector Servo amplifier connector Servo amplifier connector Servo motor connector 10 m MR-AEP1CBL5M-A5-L					2 m	MR-AEP1CBL2M-A2-L				
brake wires	(42)			Standard	5 m	MR-AEP1CBL5M-A2-L				
HK-MT/ HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic HK-MT/ bending life 5 m MR-AEP1CBL5M-A5-H 10 m MR-AEP1CBL2M-A5-H 2 m MR-AEP1CBL2M-A5-L Servo motor connector 9 m MR-AEP1CBL2M-A5-L 1P65					10 m	MR-AEP1CBL10M-A2-L			4	
HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic Without electromagnetic Without electromagnetic Without electromagnetic S m MR-AEP1CBL5M-A5-H To m MR-AEP1CBL2M-A5-L Servo amplifier connector Servo amplifier connector MR-AEP1CBL5M-A5-L IP65		-	For HK-KT/		2 m	MR-AEP1CBL2M-A5-H				
153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic Vertical lead (Note 5) Without electromagnetic Vertical lead (Note 5) Without electromagnetic	(43)	(43) H			5 m	MR-AEP1CBL5M-A5-H				
Vertical lead (Note 5) Without electromagnetic Standard S				bending life	10 m	MR-AEP1CBL10M-A5-H		Servo amplifier connector		
(44) Without electromagnetic Standard 5 m MR-AEP1CBL5M-A5-L IP65					2 m	MR-AEP1CBL2M-A5-L			Ĩ	
Third state of the	(44)			Standard	5 m	MR-AEP1CBL5M-A5-L	IP65			
		brake wires		10 m	MR-AEP1CBL10M-A5-L					

- 2. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

 3. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 4. Long bending life cables and standard cables are for moving parts and fixed parts respectively.
- 5. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)	
(45)	Encoder connector set (Note 2, 3, 4) (screw type)	For HK-ST/ HK-RT353(4)W, 503(4)W, 703(4)W (straight type)	-	-	MR-ENCNS2	Encoder connector Servo amplifier connector IP67 Applicable cable Wire size: 0.5 mm ² (AWG 20) or smaller Cable OD: 5.5 mm to 9.0 mm	
(46)	Encoder connector set (Note 2, 3, 4) (one-touch connection type)	For HK-ST/ HK-RT353(4)W, 503(4)W, 703(4)W (angle type)	-	-	MR-J3SCNSA	Encoder connector Servo amplifier connector	
(47)	Encoder connector set (Note 2, 3, 4) (screw type)	For HK-ST/ HK-RT353(4)W, 503(4)W, 703(4)W (angle type)	-	-	MR-ENCNS2A	Applicable cable Wire size: 0.5 mm² (AWG 20) or smaller Cable OD: 5.5 mm to 9.0 mm	
(48)	Power connector set (Note 4, 5, 6) (one-touch connection type)	HK-ST52(4)W, 102(4)(W), 172(4)(W), 202(4)AW, 302(4)W, 353(4)W, 503(4)W (Note 7)	-	-	MR-APWCNS4	Power connector IP67 Applicable cable Wire size: 3.5 mm² (AWG 12) or smaller Cable OD: 11 mm to 14.1 mm	
(49)	Power connector set (Note 4, 5) (one-touch connection type)	HK-ST202(4)(W), 352(4)(W), 502(4)(W), 702(4)(W)/ HK-RT353(4)W, 503(4)W, 703(4)W	-	-	MR-APWCNS5	Power connector IP67 Applicable cable Wire size: 8 mm² (AWG 8) or smaller Cable OD: 12.9 mm to 16 mm	
(50)	Electromagnetic brake connector set (Note 3, 4) (one-touch connection type)	For HK-ST/ HK-RT353(4)WB, 503(4)WB, 703(4)WB	-	-	MR-BKCNS1	Electromagnetic brake connector IP67	
(51)	Electromagnetic brake connector set (Note 3, 4) (screw type)	(straight type)	-	-	MR-BKCNS2	Applicable cable Wire size: 1.25 mm² (AWG 16) or smaller Cable OD: 9.0 mm to 11.6 mm	
(52)	Electromagnetic brake connector set (Note 3, 4) (one-touch connection type)	For HK-ST/ HK-RT353(4)WB, 503(4)WB, 703(4)WB	-	-	MR-BKCNS1A	Electromagnetic brake connector IP67	
(53)	Electromagnetic brake connector set (Note 3, 4) (screw type)	(angle type)	- against increas	- of dust a	MR-BKCNS2A	Applicable cable Wire size: 1.25 mm² (AWG 16) or smaller Cable OD: 9.0 mm to 11.6 mm	

- 2. Cable clamps and bushings for cable OD of 5.5 mm to 7.5 mm and of 7.0 mm to 9.0 mm are included in the set.
- 3. The connector set contains a plug and contacts. Using contacts for other plugs may damage the connector. Use the enclosed contacts.
- 4. For fabricating cables with these connectors, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
- 5. When the screw type is required, refer to "Products on the Market for Rotary Servo Motors" in this catalog.
 6. Connectors for HK-ST152(4)G1/G1H/G5/G7 geared servo motors are the same as those for HK-ST172(4)W.
- 7. When using HK-ST503W for a machine that is required to comply with UL/CSA standards, do not use MR-APWCNS4. Use a cable (SC-PWC403C_M-SBLL or SC-PWC403C_M-SBLH) manufactured by Mitsubishi Electric System & Service Co., Ltd., and fabricate an extension cable with wires of AWG 10. For details of SC-PWC403C_M-SBLL and SC-PWC403C_M-SBLH, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)
(54)	Encoder cable	For connecting a load-side encoder	Long	2 m	MR-EKCBL2M-H	Junction connector Servo amplifier connector
(54)	(Note 2, 3)		bending life	5 m	MR-EKCBL5M-H	IP20
(55)	Encoder connector set	For connecting a load-side encoder	-	-	MR-J3CN2	Servo amplifier connector
(56)	Junction cable for fully closed loop control (Note 4)	For branching a load-side encoder	Standard	0.3 m	MR-J4FCCBL03M	Junction connector Servo amplifier connector
(57)	Connector set	For fully closed loop control	-	-	MR-J3THMCN2	Junction connector Servo amplifier connector

- 2. Use MR-EKCBL_M-H or MR-ECNM to connect to an output cable for AT343A, AT543A-SC or AT545A-SC scales manufactured by Mitutoyo Corporation.

 3. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)


 4. Servo system will not operate correctly when the junction cables for fully closed loop control and for linear servo motors are used mistakenly or interchangeably. Make
- sure of the model before placing an order.
- 5. Long bending life cables and standard cables are for moving parts and fixed parts respectively.

Configuration Example for Linear Servo Motors (Note 3)


G WG A

MR-J5-G/A or MR-J5W -G, and LM-H3/LM-K2/LM-U2

When using a junction cable




When not using a junction cable




MR-J5-G/A and LM-F

When using a junction cable



When not using a junction cable




- 1. Contact the relevant linear encoder manufacturers for connectors to connect with the head cables.
 - 2. Refer to "Products on the Market for Linear Servo Motors" in this catalog for these connectors.
 - 3. Cables drawn with dashed lines need to be fabricated by users. Refer to "Linear Servo Motor User's Manual" when fabricating the cables.

Configuration Example for Linear Servo Motors (Note 3)


G-RJ A-RJ

MR-J5-G-RJ/A-RJ and LM-H3/LM-K2/LM-U2 with a serial linear encoder

When using a junction cable




When not using a junction cable




MR-J5-G-RJ/A-RJ and LM-F with a serial linear encoder

When using a junction cable



When not using a junction cable




Notes: 1. Contact the relevant linear encoder manufacturers for connectors to connect with the head cables

- 2. Refer to "Products on the Market for Linear Servo Motors" in this catalog for these connectors.
- 3. Cables drawn with dashed lines need to be fabricated by users. Refer to "Linear Servo Motor User's Manual" when fabricating the cables.


Configuration Example for Linear Servo Motors (Note 3)

G-RJ A-RJ

MR-J5-G-RJ/A-RJ and LM-H3/LM-K2/LM-U2 with an A/B/Z-phase differential output type linear encoder



MR-J5-G-RJ/A-RJ and LM-F with an A/B/Z-phase differential output type linear encoder




Notes: 1. Contact the relevant linear encoder manufacturers for connectors to connect with the head cables.

- 2. Refer to "Products on the Market for Linear Servo Motors" in this catalog for these connectors.
- 3. Cables drawn with dashed lines need to be fabricated by users. Refer to "Linear Servo Motor User's Manual" when fabricating the cables.


Configuration Example for Linear Servo Motors (Note 2)

G G-RJ WG A

MR-J5-G(-RJ)/A(-RJ) or MR-J5W_-G, and LM-AJ with a serial linear encoder



MR-J5-G-RJ/A-RJ and LM-AJ with an A/B/Z-phase differential output type linear encoder



Notes: 1. Contact the relevant linear encoder manufacturers for connectors to connect with the head cables.

2. Cables drawn with dashed lines need to be fabricated by users. Refer to "Linear Servo Motor User's Manual" when fabricating the cables.

Cables and Connectors for Linear Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models. Encoder cables are not subject to European Low Voltage Directive (50 V AC to 1000 V AC and 75 V DC to 1500 V DC).

No.	Item	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)	
(1)	Encoder cable	For connecting a linear	Long	2 m	MR-EKCBL2M-H	Junction connector Servo amplifier connector	
(1)	(Note 3, 4)	encoder	bending life	5 m	MR-EKCBL5M-H	IP20	
(2)	Encoder connector set (Note 2, 3)	For connecting a linear encoder	-	-	MR-ECNM	Junction connector Servo amplifier connector IP20 Applicable cable Wire size: AWG 26 to 22 Cable OD: 7 mm to 9 mm	
(3)	Encoder connector set	For connecting a linear encoder or a thermistor	-	-	MR-J3CN2	Servo amplifier connector	
(4)	Junction cable for linear servo motors	For branching a thermistor	Standard	0.3 m	MR-J4THCBL03M	Junction connector Servo amplifier connector	
(5)	Connector set	For branching a thermistor	-	-	MR-J3THMCN2	Junction connector Servo amplifier connector	

- Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.
 - 2. The crimping tool (91529-1) manufactured by TE Connectivity Ltd. Company is required. Contact the manufacturer directly.
 - 3. Use MR-EKCBL_M-H or MR-ECNM to connect to an output cable for AT343A, AT543A-SC or AT545A-SC scales manufactured by Mitutoyo Corporation.
 - 4. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
 - 5. Servo system will not operate correctly when the junction cables for fully closed loop control and for linear servo motors are used mistakenly or interchangeably. Make sure of the model before placing an order.
 - 6. Long bending life cables and standard cables are for moving parts and fixed parts respectively.


Precautions

Configuration Example for Direct Drive Motors (Note 1)


G G-RJ V

TM-RG2M/TM-RU2M/TM-RFM

Incremental system



Absolute position detection system



Notes: 1. Cables drawn with dashed lines need to be fabricated by users. Refer to "Direct Drive Motor User's Manual" when fabricating the cables.

Cables and Connectors for Direct Drive Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)
(1)	Encoder connector set	For TM-RG2M/ TM-RU2M/TM-RFM (for connecting a direct drive motor and a servo amplifier, or an absolute position storage unit and a servo amplifier)	-	-	MR-J3DDCNS	Encoder connector or absolute position storage connector unit connector IP67 Applicable cable Wire size: 0.25 mm² to 0.5 mm² (AWG 23 to 20) Cable OD: 7.8 mm to 8.2 mm
(2)	Encoder connector set	For TM-RG2M/ TM-RU2M/TM-RFM (for connecting a direct drive motor and an absolute position storage unit)	-	-	MR-J3DDSPS	Absolute position storage unit connector IP67 IP67 Applicable cable Wire size: 0.25 mm² to 0.5 mm² (AWG 23 to 20) Cable OD: 7.8 mm to 8.2 mm
(3)	Power connector set (Note 2)	For TM-RG2M_, TM-RU2M_, TM-RFM_C20, and TM-RFM_E20	-	-	MR-PWCNF	Power connector IP67 Applicable cable Wire size: 0.3 mm² to 1.25 mm² (AWG 22 to 16) Cable OD: 8.3 mm to 11.3 mm
(4)	Power connector set (Note 2)	For TM-RFM_G20	-	-	MR-PWCNS4	Power connector IP67 Applicable cable Wire size: 2 mm² to 3.5 mm² (AWG 14 to 12) Cable OD: 10.5 mm to 14.1 mm
(5)	Power connector set (Note 2)	For TM-RFM040J10 and TM-RFM120J10	-	-	MR-PWCNS5	Power connector IP67 Applicable cable Wire size: 5.5 mm² to 8 mm² (AWG 10 to 8) Cable OD: 12.5 mm to 16 mm
(6)	Power connector set (Note 2)	For TM-RFM240J10	-	-	MR-PWCNS3	Power connector IP67 Applicable cable Wire size: 14 mm² to 22 mm² (AWG 6 to 4) Cable OD: 22 mm to 23.8 mm

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor/absolute position storage unit.

If the IP rating of the servo motor/absolute position storage unit differs from that of these connectors, overall IP rating depends on the lowest of all.

2. For fabricating cables with these connectors, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION.

(Email: osb.webmaster@melsc.jp)

Details of Option Connectors for Servo Motors

MR-AEPB2CBL_M-A1-H			
MR-AEPB2CBL_M-A1-L MR-AEPB2CBL_M-A2-H			
MR-AEPB2CBL_M-A2-L MR-AEP2CBL_M-A1-H MR-AEP2CBL_M-A1-L MR-AEP2CBL_M-A2-H MR-AEP2CBL_M-A2-L	Connector set: MT50W-8D/2D4ES-CVLD(7.5) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)	
Model	Servo motor connector	Servo amplifier connector	
MR-AEPB2CBL_M-A5-H MR-AEPB2CBL_M-A5-L MR-AEP2CBL_M-A5-H MR-AEP2CBL_M-A5-L	Connector set: MT50W-8D/2D4ES-CVSD(7.5) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)	
Model	Servo motor connector	Junction connector	
MR-AEPB2J10CBL03M-A1-L MR-AEPB2J10CBL03M-A2-L			
MR-AEP2J10CBL03M-A1-L MR-AEP2J10CBL03M-A2-L	Connector set: MT50W-8D/2D4ES-CVLD(7.5) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Contact: 170361-4 Housing: 1-172169-9 Cable clamp: 316454-1 (TE Connectivity Ltd. Company)	
Model	Servo motor connector	Junction connector	
MR-AEPB2J10CBL03M-A5-L MR-AEP2J10CBL03M-A5-L	Connector set: MT50W-8D/2D4ES-CVSD(7.5) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Contact: 170361-4 Housing: 1-172169-9 Cable clamp: 316454-1 (TE Connectivity Ltd. Company)	
Model	Junction connector	Servo amplifier connector	-
MR-AEKCBL_M-H MR-AEKCBL_M-L	Housing: 1-172161-9 Connector pin: 170359-1 (TE Connectivity Ltd. Company) or an equivalent product Cable clamp: MTI-0002 (Toa Electric Industrial Co., Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)	
Model	Junction connector	Servo amplifier connector	
MR-ECNM MR-EKCBL_M-H	Housing: 1-172161-9 Connector pin: 170359-1 (TE Connectivity Ltd. Company) or an equivalent product Cable clamp: MTI-0002 (Toa Electric Industrial Co., Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)	
Model	Servo motor connector	Junction connector	
MR-AEPB2J20CBL03M-A1-L MR-AEPB2J20CBL03M-A2-L MR-AEP2J20CBL03M-A1-L MR-AEP2J20CBL03M-A2-L	Connector set: MT50W-8D/2D4ES-CVLD(7.5) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA	Cable receptacle: CMV1-CR10P-M2 (DDK Ltd.)	

Details of Option Connectors for Servo Motors

Model	Servo motor connector	Junction connector
MR-AEPB2J20CBL03M-A5-L MR-AEP2J20CBL03M-A5-L	Connector set: MT50W-8D/2D4ES-CVSD(7.5) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Cable receptacle: CMV1-CR10P-M2 (DDK Ltd.)
Model	Encoder connector	Servo amplifier connector
MR-J3ENSCBL_M-H (Note 2) MR-J3ENSCBL_M-L (Note 2)	Straight plug: CMV1-SP10S-M1 Socket contact: CMV1-#22ASC-C1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)
Model	Junction connector/encoder connector	Servo amplifier connector
MR-AENSCBL_M-H (Note 2) MR-AENSCBL_M-L (Note 2)	Straight plug: CMV1-SP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)
Model	Junction connector/encoder connector	Servo amplifier connector
MR-J3SCNS (Note 1, 2, 3)	Straight plug: CMV1-SP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)
Model	Servo motor connector	Servo amplifier connector
MR-AEPB1CBL_M-A1-H MR-AEPB1CBL_M-A1-L MR-AEPB1CBL_M-A2-H MR-AEPB1CBL_M-A2-L MR-AEP1CBL_M-A1-H MR-AEP1CBL_M-A1-L MR-AEP1CBL_M-A2-H MR-AEP1CBL_M-A2-L	Connector set: MT50W-8D/2D4ES-CVL(11.9) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)
Model	Servo motor connector	Servo amplifier connector
MR-AEPB1CBL_M-A5-H MR-AEPB1CBL_M-A5-L MR-AEP1CBL_M-A5-H MR-AEP1CBL_M-A5-L	Connector set: MT50W-8D/2D4ES-CVS(11.9) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)

Notes:

Cable clamps and bushings for cable OD of 5.5 mm to 7.5 mm and of 7.0 mm to 9.0 mm are included in the set.
 Some cables or connector sets may contain the connectors of different shapes. However, these connectors are all usable.

3. The connector set contains a plug and contacts. Using contacts for other plugs may damage the connector. Use the enclosed contacts.

Details of Option Connectors for Servo Motors

Model	Encoder connector	Servo amplifier connector	
			de callorio
MR-ENCNS2 (Note 2, 3)	Straight plug: CMV1S-SP10S-M2 Socket contact: CMV1-#22ASC-S1-100	Receptacle: 36210-0100PL Shell kit: 36310-3200-008	
mit Errorroz	(DDK Ltd.)	(3M)	5
		or Connector set: 54599-1019	Collidor
		(Molex, LLC)	<u>a</u>
Model	Encoder connector	Servo amplifier connector	
MR-J3SCNSA (Note 1, 2, 3)	Angle plug: CMV1-AP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)	
		or Connector set: 54599-1019 (Molex, LLC)	\
Model	Encoder connector	Servo amplifier connector	NIO!O
MR-ENCNS2A (Note 2, 3)	Angle plug: CMV1S-AP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)	NOTO
		or Connector set: 54599-1019 (Molex, LLC)	
Model	Power connector		
MR-APWCNS4		Plug: JL10-6A18-10SE-EB (straight) Cable clamp: JL04-18CK(13)-R (Japan Aviation Electronics Industry, Limited)	NOCOLO
Model	Power connector		
MR-APWCNS5		Plug: JL10-6A22-22SE-EB (straight) Cable clamp: JL04-2022CK(14)-R (Japan Aviation Electronics Industry, Limited)	пquip
Model	Electromagnetic brake connector		
MR-BKCNS1 (Note 1, 2)		Straight plug: CMV1-SP2S-L Socket contact: CMV1-#22BSC-S2-100 (DDK Ltd.)	
Model	Electromagnetic brake connector		
MR-BKCNS2 (Note 2)		Straight plug: CMV1S-SP2S-L Socket contact: CMV1-#22BSC-S2-100	
		(DDK Ltd.)	
Model	Electromagnetic brake connector	(DDK Ltd.)	
MR-BKCNS1A (Note 1, 2)	Electromagnetic brake connector	Angle plug: CMV1-AP2S-L Socket contact: CMV1-#22BSC-S2-100 (DDK Ltd.)	
	Electromagnetic brake connector Electromagnetic brake connector	Angle plug: CMV1-AP2S-L Socket contact: CMV1-#22BSC-S2-100	

- Notes: 1. Some cables or connector sets may contain the connectors of different shapes. However, these connectors are all usable.

 2. The connector set contains a plug and contacts. Using contacts for other plugs may damage the connector. Use the enclosed contacts.

 3. Cable clamps and bushings for cable OD of 5.5 mm to 7.5 mm and of 7.0 mm to 9.0 mm are included in the set.

Details of Option Connectors for Servo Motors

Model	Servo amplifier connector				
MR-J3CN2	Receptacle: 36210-0100PL or Shell kit: 36310-3200-008 (3M)	Connector set: 54599-1019 (Molex, LLC)			
Model	Junction connector	Servo amplifier connector			
MR-J4FCCBL03M MR-J4THCBL03M MR-J3THMCN2	Plug: 36110-3000FD Shell kit: 36310-F200-008 (3M)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)			
Model	Encoder connector/absolute position storage unit connector	Servo amplifier connector			
MR-J3DDCNS	Plug: RM15WTPZK-12S Cord clamp: JR13WCCA-8(72) (Hirose Electric Co., Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)			
Model	Encoder connector	Absolute position storage unit connector			
MR-J3DDSPS	Plug: RM15WTPZK-12S Cord clamp: JR13WCCA-8(72) (Hirose Electric Co., Ltd.)	Plug: RM15WTPZ-12P(72) Cord clamp: JR13WCCA-8(72) (Hirose Electric Co., Ltd.)			
Model	Power connector				
MR-PWCNF		Plug: CE05-6A14S-2SD-D (straight) (DDK Ltd.) Cable clamp: YSO14-9 to 11 (Daiwa Dengyo Co., Ltd.)			
Model	Power connector				
MR-PWCNS4		Plug: CE05-6A18-10SD-D-BSS (straight) Cable clamp: CE3057-10A-1-D (DDK Ltd.)			
Model	Power connector				
MR-PWCNS5		Plug: CE05-6A22-22SD-D-BSS (straight) Cable clamp: CE3057-12A-1-D (DDK Ltd.)			
Model	Power connector				
MR-PWCNS3		Plug: CE05-6A32-17SD-D-BSS (straight) Cable clamp: CE3057-20A-1-D (DDK Ltd.)			

Products on the Market for Rotary Servo Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.

Encoder connector (servo amplifier side)



Application	Connector (3M)
	Receptacle: 36210-0100PL Shell kit: 36310-3200-008
Servo amplifier CN2 connector	Connector (Molex, LLC)
CINZ CONNECTOR	54599-1019 (gray)
	54599-1016 (black)

Load-side/opposite to load-side lead

Vertical lead



Connector for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW) (for dual cable type) Rotary

Applicable servo motor		(Hirose Electric Co. Ltd.)		Contact (Hirose Electric Co., Ltd.)	Applicable cable example	
Servo motor		Cable direction	Model	(Hilose Electric Co., Ltd.)		
HK-KT/		In the direction of the	MT50W-8D/			
HK-MT/		load side/In the opposite	2D4ES CVI D/7 5)	For power supply: MT50E-1820SCFA	Refer to "Rotary Servo	
HK-RT103(4)W,	IP67	direction of the load side	2D4L3-CVLD(7.5)	For signal, MT50D, 2004SCEA	Motor User's Manual" for	
153(4)W,		Vartical (Note 3)	MT50W-8D/	For signal: MT50D-2224SCFA	the applicable cables.	
		Vertical (Note 3)		1		

2D4ES-CVSD(7.5)

Load-side/opposite to load-side lead

Vertical lead





Connector for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW) (for single cable type) Rotary

Applicable servo motor	IP rating (Note 1)	Connector set (Hirose Electric Co., Ltd.))	Contact (Hirose Electric Co., Ltd.)	Applicable cable example	
Servo motor		Cable direction	Model	(Hilose Electric Co., Ltd.)		
HK-KT/		In the direction of the	MT50W-8D/			
HK-MT/		lload eida/In the onnoeita		For power supply: MT50E-1820SCFA	Refer to "Rotary Servo Motor User's Manual" for the applicable cables.	
HK-RT103(4)W,	IP67	direction of the load side	, ,	For signal: MT50D-2224SCFA		
153(4)W,		Vertical (Note 3)	MT50W-8D/			
203(4)W	Vertical (Note 3)		2D4ES-CVS(11.9)			

Straight type

Angle type





Encoder connector for HK-ST/HK-RT (3.5 kW to 7.0 kW) Rotary

Applicable	IP rating (Note 1)	Connector	(DDK Ltd.)	Applicable cable example		
servo motor		Туре	Type of connection	Plug	Socket contact	Cable OD [mm]
		Straight	One-touch	CMV1-SP10S-M1	Select a solder or press	5.5 to 7.5
			connection type	CMV1-SP10S-M2		7.0 to 9.0
HK-ST/			Screw type	CMV1S-SP10S-M1		5.5 to 7.5
HK-RT353(4)W,	1007			CMV1S-SP10S-M2		7.0 to 9.0
503(4)W,	IP67	Angle	One-touch connection type	CMV1-AP10S-M1		5.5 to 7.5
703(4)W				CMV1-AP10S-M2		7.0 to 9.0
			Screw type	CMV1S-AP10S-M1		5.5 to 7.5
				CMV1S-AP10S-M2		7.0 to 9.0

				CIVIV 13-AF 103-1VIZ		7.0 10 9.0	
		1					
Contact		Socket cor	tact (DDK Ltd.)		Wire size (Note 2)		
Solder type CMV1-#22ASC-S1-100					0.5 mm ² (AWG 20) or smaller		
		CMV1-#22ASC-C1-100			0.2 mm ² to 0.5 mm ² (AWG 2	24 to 20)	
Press bonding type		CIVIV I-#22	ASC-C1-100		Crimping tool (357J-53162T) is required.		
		CMV1-#22ASC-C2-100			0.08 mm2 to 0.2 mm2 (AWG	28 to 24)	
					Crimping tool (357J-53163T) is required.		

- Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.
 - 2. The wire size shows wiring specifications of the connector.
 - 3. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

203(4)W

Linear Linear servo motor

Products on the Market for Rotary Servo Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.





Power connector for HK-ST/HK-RT (3.5 kW to 7.0 kW) (Note 3) Rotary

Applicable servo	IP rating	Plug (Japan A	viation Electronics In	dustry, Limited)	Cable clamp (Japan Aviation	Applicable cable example		
motor	(Note 1)	Туре	Type of connection	Model	Electronics Industry, Limited)	Wire size (Note 2)	Cable OD [mm]	
LUC OTTO (A) (AA)			One-touch	JL10-6A18-10SE-EB	JL04-18CK(10)-R			
HK-ST52(4)(W), 102(4)(W),		Straight	connection type		JL04-18CK(13)-R		Cable OD [mm] 8 to 11 11 to 14.1 9.5 to 13 12.9 to 16 9.5 to 13	
172(4)W,			Screw type	JL04V-6A18-10SE-EB-R	JL04-18CK(10)-R	4	n² (AWG 12) 11 to 14.1	
202(4)AW,				02011 07110 1002 22 11	JL04-18CK(13)-R	3.5 mm ² (AWG 12)	Vire size (Note 2) Cable OD [mm] 8 to 11 11 to 14.1 9.5 to 13 12.9 to 16 9.5 to 13	
302(4)W,			One-touch	JL10-8A18-10SE-EB	JL04-18CK(10)-R	or smaller		
353(4)W,		Anglo	connection type	0E10-0A10-103E-EB	JL04-18CK(13)-R		11 to 14.1	
503(4)W		Angle	Screw type	JL04V-8A18-10SE-EBH-R	JL04-18CK(10)-R		8 to 11	
	IP67		Screw type		JL04-18CK(13)-R	8 to 11 11 to 14.1 8 to 11 11 to 14.1 9.5 to 13 12.9 to 16		
			One-touch	JL10-6A22-22SE-EB	JL04-2022CK(12)-R		9.5 to 13	
HK-ST202(4)(W),		Ctroight	connection type		JL04-2022CK(14)-R	((14)-R 12.9		
352(4)(W),		Straight	Screw type	JL04V-6A22-22SE-EB-R	JL04-2022CK(12)-R		9.5 to 13	
502(4)(W),			Screw type	3L04V-0A22-223L-LB-N	JL04-2022CK(14)-R	8 mm ² (AWG 8) or	12.9 to 16	
702(4)(W)/ HK-RT353(4)W,			One-touch	JL10-8A22-22SE-EB	JL04-2022CK(12)-R	smaller	9.5 to 13	
503(4)W,		Angle	connection type	JL10-6A22-225E-ED	JL04-2022CK(14)-R		12.9 to 16	
703(4)W		Aligie	Screw type	JL04V-8A22-22SE-EBH-R	JL04-2022CK(12)-R		9.5 to 13	
			Screw type	JLU4 V-0A22-223E-EDH-N	JL04-2022CK(14)-R		12.9 to 16	

Straight type

Angle type

Electromagnetic brake connector for HK-ST/HK-RT (3.5 kW to 7.0 kW) Rotary



Applicable servo	IP rating (Note 1)	Connector	r (DDK Ltd.)			Applicable cable example Cable OD [mm] 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.7 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6
motor	ir rating (1888)	Туре	Type of connection	Plug	Socket contact	Cable OD [mm]
				CMV1-SP2S-S		4.0 to 6.0
			One-touch	CMV1-SP2S-M1		Cable OD [mm] 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 7.0 to 9.0 9.0 to 11.6 7.0 to 9.0 9.0 to 11.6
			connection type	CMV1-SP2S-M2		
		Ctroight		CMV1-SP2S-L		9.0 to 11.6
		Straight		CMV1S-SP2S-S		4.0 to 6.0
			Corous tupo	CMV1S-SP2S-M1		5.5 to 7.5
HK-ST/		Screw type	CMV1S-SP2S-M2]	7.0 to 9.0	
HK-RT353(4)WB,	IP67			CMV1S-SP2S-L	Select a solder or press	9.0 to 11.6
503(4)WB,	IF67			CMV1-AP2S-S	bonding type. (Refer to the table below.)	Cable OD [mm] 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0
703(4)WB			One-touch	CMV1-AP2S-M1	(Florer to the table below.)	
			connection type	CMV1-AP2S-M2		7.0 to 9.0
		Anglo		CMV1-AP2S-L		9.0 to 11.6
		Angle		CMV1S-AP2S-S		Cable OD [mm] 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6 4.0 to 6.0 5.5 to 7.5 7.0 to 9.0 9.0 to 11.6
			Corous tupo	CMV1S-AP2S-M1		
			Screw type	CMV1S-AP2S-M2		7.0 to 9.0
				CMV1S-AP2S-L	1	9.0 to 11.6

Contact Socket contact (DDK Ltd.)		Wire size (Note 2)	
Solder type	CMV1-#22BSC-S2-100	1.25 mm² (AWG 16) or smaller	
Proce bonding type	CMV1-#22BSC-C3-100	0.5 mm ² to 1.25 mm ² (AWG 20 to 16)	
Press bonding type	CIVIV 1-#22B3C-C3-100	Crimping tool (357J-53164T) is required.	

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

2. The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection.

3. Connectors for HK-ST152(4)G1/G1H/G5/G7 geared servo motors are the same as those for HK-ST172(4)W.

Linear Linear servo motor



Products on the Market for Linear Servo Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.

Thermistor junction connector for LM-H3/LM-K2/LM-U2/LM-F Linear



Applicable	IP rating (Note 1)	Connector (3M)	Applicable cable example		
servo motor	ir railing (too 1)	Plug	Shell kit	Applicable cable example	
LM-H3/					
LM-K2/		36110-3000FD	36310-F200-008	Wire size: 0.3 mm ² (AWG 22) or smaller	
LM-U2/	-	30110-30001 D	30310-1 200-008	Cable OD: 7 mm to 9 mm	
LM-F					

Thermistor connector for LM-F Linear



Applicable servo motor	IP rating (Note 1)	•	Cable clamp (DDK Ltd.)	Applicable cable example
LM-F	-	D/MS3101A14S-9S	D/MS3057A-6A	Wire size: 0.3 mm² to 1.25 mm² (AWG 22 to 16) Cable OD: 7.9 mm or smaller

Power connector for LM-F Linear



Applicable IP rating (Note 1)		Cable receptacle	Cable clamp	Applicable cable example		
servo motor	(DDK Ltd.)		(DDK Ltd.)	Wire size (Note 2)	Cable OD [mm]	
LM-FP2B, 2D, 2F	-	D/MS3101A18-10S	ID/MS3057-10A		14.3 or smaller (bushing ID)	
LM-FP4B, 4D	-	D/MS3101A24-22S	D/MS3057-16A		19.1 or smaller (bushing ID)	

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

2. The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection.

Products on the Market for Direct Drive Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.

Encoder connector for TM-RG2M/TM-RU2M/TM-RFM and absolute position storage unit connector (servo amplifier side) Direct



Applicable Application		IP rating	Plug (Hirose Electric Co., Ltd.)			Applicable cable example	
servo motor	otor Application		Туре	Plug	Cord clamp	Applicable cable example	
TM-RG2M/ TM-RU2M/ TM-RFM	For an encoder or absolute position storage unit (servo amplifier side)	IP67	Straight	RM15WTPZK-12S	JR13WCCA-8(72)	Wire size: 0.5 mm² (AWG 20) or smaller Cable OD: 7.8 mm to 8.2 mm Wire example: Vinyl jacket cable 20276 VSVPAWG#23 × 6P KB-0492 Bando Densen Co., Ltd. (Note 2)	

Encoder connector for TM-RG2M/TM-RU2M/TM-RFM and absolute position storage unit connector (encoder side) Direct



Applicable	· · Application	IP rating	Plug (Hirose Electric Co., Ltd.)			Applicable cable example
servo motor		(Note 1)	Type Plug Cord clamp	Applicable cable example		
TM-RG2M/ TM-RU2M/ TM-RFM	For an absolute position storage unit (encoder side)	IP67	Straight	RM15WTPZ-12P(72)	JR13WCCA-8(72)	Wire size: 0.5 mm² (AWG 20) or smaller Cable OD: 7.8 mm to 8.2 mm Wire example: Vinyl jacket cable 20276 VSVPAWG#23 × 6P KB-0492 Bando Densen Co., Ltd. (Note 2)

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor/absolute position storage unit. If the IP rating of the servo motor/absolute position storage unit differs from that of these connectors, overall IP rating depends on the lowest of all.

2. Contact Toa Electric Industrial Co., Ltd.

Products on the Market for Direct Drive Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.

Power connector for TM-RFM Direct



Applicable	IP rating (Note 1)	Plug (with backshell) (DDK Ltd.) Type Model		Cable clamp (DDK Ltd.)	Applicable cable example		
servo motor				Model	Wire size (Note 2)	Cable OD [mm]	
	IP67		CE05-6A18-10SD-D-BSS	CE3057-10A-2-D	2 mm² to 3.5 mm²	8.5 to 11	
TM-RFM012G20, 048G20, 072G20	II 07	_		CE3057-10A-1-D	(AWG 14 to 12)	10.5 to 14.1	
	-		D/MS3106B18-10S	D/MS3057-10A	2 mm ² to 3.5 mm ² (AWG 14 to 12)	14.3 or smaller (bushing ID)	
		Straight	CE05-6A22-22SD-D-BSS	CE3057-12A-2-D	5.5 mm ² to 8 mm ²	9.5 to 13	
TM-RFM040J10, 120J10		Straight	0L03-0A22-220D-D-033	CE3057-12A-1-D	(AWG 10 to 8)	12.5 to 16	
	-		D/MS3106B22-22S	D/MS3057-12A	5.5 mm ² to 8 mm ² (AWG 10 to 8)	15.9 or smaller (bushing ID)	
TM-RFM240J10	IP67		CE05-6A32-17SD-D-BSS	CE3057-20A-1-D	14 mm ² to 22 mm ² (AWG 6 to 4)	22 to 23.8	
TM-RFM240J10	-		D/MS3106B32-17S	D/MS3057-20A	14 mm ² to 22 mm ² (AWG 6 to 4)	23.8 or smaller (bushing ID)	

Power connector for TM-RG2M/TM-RU2M/TM-RFM Direct



Applicable		Plug (DDK Ltd.)	Cable cla	mp		Applicable cable example	
servo motor	IP rating (Note 1)		Туре	Model	Manufacturer	Wire Size (Note 2)	Cable OD [mm]
TM-RG2M_,			Straight	C2KD0814		0.3 mm ² to 1.25 mm ²	4 to 8
TM-RU2M_, TM-RFM002C20,	IP67	CE05-6A14S-2SD-D		C2KD1214	Manufacturing Co., Ltd. (Note 3)		8 to 12
004C20, 006C20,				YSO14-5 to 8	Daiwa Dengyo		5 to 8.3
006E20,				YSO14-9 to 11	Co., Ltd.		8.3 to 11.3
012E20, 018E20	-	D/MS3106B14S-2S	Straight	D/MS3057-6A	DDK Ltd.	0.3 mm ² to 1.25 mm ² (AWG 22 to 16)	7.9 or smaller (bushing ID)


Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

2. The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection.

3. Contact: Sankei Manufacturing Co., Ltd. and Mikuni Electric Co., Ltd.


Configuration Example for MR-J5-_G(-RJ)

G G-RJ



Configuration Example for MR-J5W_-_G


WG



Notes: 1. Refer to "Junction Terminal Block" in this catalog.

- 2. The battery, or the battery and the battery case are required to configure an absolute position detection system with a direct drive motor. Refer to "Battery" or "Battery Case and Battery" in this catalog.
- 3. CN2L connector is available for MR-J5-G-RJ servo amplifiers.
- 4. MR-J5W_-G servo amplifiers have CN6 connector on the top of the unit.
- 5. CNP3C and CN2C connectors are available for MR-J5W3-G servo amplifiers.
- 6. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (Class B) recommended by CC-Link Partner Association. When a switching hub (Class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manuals for details.
- 7. Refer to p. 7-42 in this catalog for details.
- 8. Refer to "Ethernet Cable Specifications" in this catalog for specifications of the Ethernet cable.
- 9. For MR-J5-500_ and MR-J5-700_ servo amplifiers, CNP1 connector is divided into two connectors, CNP1A (L1/L2/L3) and CNP1B (N1/P3/P4).

For MR-CV_ and MR-J5D_-_G4




Notes: 1. CNP3C and CN2C connectors are available for MR-J5D3-_G4 drive units.

- 2. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (Class B) recommended by CC-Link Partner Association. When a switching hub (Class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manuals for details.
- 3. Refer to "Ethernet Cable Specifications" in this catalog for specifications of the Ethernet cable.
- 4. Arrange the drive units in descending order of capacity per axis from the right side of the power regeneration converter unit. When the drive units with the same capacity are used, there are no restrictions on the order.

Configuration Example for MR-J5-_A(-RJ) (Note 4)





1. Refer to "Junction Terminal Block" in this catalog. Notes:

- The battery, or the battery and the battery case are required to configure an absolute position detection system with a direct drive motor. Refer to "Battery" or "Battery Case and Battery" in this catalog.
 CN2L connector is available for MR-J5-A-RJ servo amplifiers.
- 4. Cables drawn with dashed lines need to be fabricated by users. Refer to "MR-J5 User's Manual" when fabricating the cables.
- 5. Refer to p. 7-44 in this catalog for details.
- 6. For MR-J5-500_ and MR-J5-700_ servo amplifiers, CNP1 connector is divided into two connectors, CNP1A (L1/L2/L3) and CNP1B (N1/P3/P4).

Servo Amplifiers

Cables and Connectors for Servo Amplifiers

Refer to "Details of Option Connectors for Servo Amplifiers" in this catalog for the detailed models.

No.		Item	Application	Cable length	Model	Description	on		
			For MR-J5-100G(-RJ) or smaller/ MR-J5-100A(-RJ) or smaller				CNP2 connector wire size (Note 1) D: 3.9 mm or	CNP3 connector	Open tool
			For MR-J5-200G(-RJ)/ MR-J5-200A(-RJ)/ MR-J5-350G(-RJ)/ MR-J5-350A(-RJ)			CNP1 connector CNP1/CNP Applicable v	CNP2 connector 3 connector wire size (Note 1 D: 4.7 mm or	CNP3 connector	Open tool
						Insulator OI CNP1A connector	CNP1B connector	CNP3 connector	Open tool
VP3B/CNP3C			For MR-J5-500G(-RJ)/ MR-J5-500A(-RJ)/ MR-J5-700G(-RJ)/			Applicable v Insulator OI	P1B/CNP3 co wire size (Note 1 D: 7.6 mm or): AWG 18 to 8	
NP3/CNP3A/CN		Servo amplifier power connector set	MR-J5-700A(-RJ)): AWG 18 to smaller	Open tool
CNP1/CNP1A/CNP1B/CNP2/CNP3/CNP3A/CNP3B/CNP3C	(1)		For MR-J5-350G4(-RJ) or smaller/ MR-J5-350A4(-RJ) or smaller	_	(Standard accessory)	CNP1 connector Applicable	CNP2 connector	CNP3 connector	Open tool
For CNP1/CNP1			For MR-J5W2-44G or smaller/ MR-J5W3-444G or smaller			CNP1 connector	CNP2 connector wire size (Note 1) D: 3.9 mm or	CNP3_ (Note 2) connector	- -
			For MR-J5W2-77G or larger			CNP1 connector CNP1 conn Applicable v Insulator Of CNP2, CNF	CNP2 connector ector wire size (Note 1) D: 4.7 mm or P3_ connector	CNP3_ (Note 2) connector D: AWG 16 to smaller	<u> </u>
		Drive unit power connector set	For MR-J5DG4			Insulator OI CNP3_ (Note connector CNP3_ cor	D: 3.9 mm or		Open tool*
Notes			cifications of the connector. Refer to "Selecti	on Evamr	la in HIV Wires for Serve Mete	Applicable Insulator O * The open open tool	wire size (Note to D: 10 mm or tool is not su must be prep	pplied with a cared by users	drive unit. The

Notes: 1. The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection. 2. MR-J5W2-_G: CNP3A/CNP3B, MR-J5W3-_G: CNP3A/CNP3B/CNP3C
3. MR-J5D1-_G4: CNP3A, MR-J5D2-_G4: CNP3A/CNP3B, MR-J5D3-_G4: CNP3A/CNP3B/CNP3C

Cables and Connectors for Servo Amplifiers

Refer to "Details of Option Connectors for Servo Amplifiers" in this catalog for the detailed models.

No.		Item	Application	Cable length	Model	Description
				0.5 m	MR-J2HBUS05M	Servo amplifier Junction terminal
	(2)	Junction terminal block cable	For connecting MR-J5G_(-RJ) and PS7DW-20V14B-F	1 m	MR-J2HBUS1M	connector block connector
				5 m	MR-J2HBUS5M	
	(3)	Connector set	For MR-J5G_(-RJ)	-	MR-CCN1	Servo amplifier connector
	(4)	Junction terminal block cable	For connecting MR-J5W - G and	0.5 m	MR-TBNATBL05M	Servo amplifier Junction terminal connector block connector
က			MR-TB26A	1 m	MR-TBNATBL1M	
For CN3	(5)	Connector set (Qty: 1 pc.)	For MR-J5WG	-	MR-J2CMP2	Servo amplifier connector
ш	(6)	Connector set (Qty: 20 pcs.)	For MR-J5WG	-	MR-ECN1	Solve displined controlled
	(7)	I/O and monitor connector	For MR-J5DG4	-	MR-ADCN3	Drive unit connector
	(8)	Junction terminal block	For connecting	0.5 m	MR-J2M-CN1TBL05M	Junction terminal block Servo amplifier connector connector
	(0)	cable	MR-J5A_(-RJ) and MR-TB50	1 m	MR-J2M-CN1TBL1M	
	(9)	Connector set	For MR-J5A_(-RJ)	-	MR-J3CN1	Servo amplifier connector

Cables and Connectors for Servo Amplifiers

Refer to "Details of Option Connectors for Servo Amplifiers" in this catalog for the detailed models.

No.		Item	Application	Cable length	Model	Description	ommon cifications
	(10)	Battery cable	For connecting MR-J5G(-RJ)/ MR-J5WG/ MR-J5A(-RJ) and	0.3 m	MR-BT6V1CBL03M	Servo amplifier Battery case connector connector	
For CN4			MR-BT6VCASE	1 m	MR-BT6V1CBL1M		Servo System Controllers
For	(11)	Junction battery cable	For MR-J5G(-RJ)/ MR-J5W - G/	0.3 m	MR-BT6V2CBL03M	Servo amplifier connector	
	(11)	oundion battery dable	MR-J5A(-RJ)	1 m	MR-BT6V2CBL1M	Junction connector	Servo Amplifiers
For CN5	(12)	Personal computer communication cable (USB cable)	For MR-J5G_(-RJ)/ MR-J5WG/ MR-J5DG4/ MR-J5A_(-RJ)	3 m	MR-J3USBCBL3M	Servo amplifier connector Personal computer connector A connector	
For CN6	(13)	Monitor cable	For MR-J5G_(-RJ)/ MR-J5A_(-RJ)	1 m	MR-ACN6CBL1M	Servo amplifier connector	Rotary Servo Motors
For	(14)	Monitor cable	For MR-J5WG	1 m	MR-J3CN6CBL1M		Vo
	(15)	Short-circuit connector	For MR-J5G_(-RJ)/ MR-J5WG/ MR-J5DG4/ MR-J5A_(-RJ)	-	(Standard accessory)	This connector is required when the STO function is not used.	Linear Servo Motors
For CN8	(16)	STO cable	For connecting MR-J3-D05 or another safety control device with MR-J5G_(-RJ)/ MR-J5WG/ MR-J5DG4/ MR-J5A_(-RJ)	3 m	MR-D05UDL3M-B	Servo amplifier connector	Direct Drive Motors
er regeneration converter CN4/drive unit CN40A	(17)	Protection coordination cable	For MR-J5DG4/ MR-CV_	0.2 m	MR-ACDL02M	Power regeneration Drive unit connector converter unit connector	Options/Peripheral Equipment
For power rege unit CN4/dr		coordination cable	Will FOV_	0.5 m	MR-ACDL05M		LVS/Wires
For drive unit CN40A/CN40B	(18)	Protection coordination cable	For MR-J5DG4	0.2 m	MR-ADDL02M	Drive unit connector Drive unit connector	Product List
For power regeneration converter unit CN24	(19)	Connector set (Note 1)	For MR-CV_	-	MR-CVCN24S	Power regeneration converter unit connector	Precautions
For power regeneration converter unit CN23	(20)	Magnetic contactor wiring connector	For MR-CV_	-	(Standard accessory)	Power regeneration Open tool converter unit connector	Support

Notes: 1. A crimping tool (357J-22733) manufactured by DDK Ltd. is required. Contact the manufacturer directly.

Ethernet Cable Specifications

Item		CC-Link IE TSN (Note 1, 2)	EtherCAT®		
		Category 5e or higher, (double shielded/STP) straight cable			
Ethernet Cable	Standard	The cable must meet the following: • IEEE802.3 (1000BASE-T) • ANSI/TIA/EIA-568-B (Category 5e)	The cable must meet the following: • IEEE802.3 (100BASE-TX) • ANSI/TIA/EIA-568-B (Category 5e)		
	Connector	RJ-45 connector with shield			

Notes: 1. Use wiring parts recommended by CC-Link Partner Association for wiring the CC-Link IE TSN.

2. Cables for CC-Link IE Controller Network cannot be used with CC-Link IE TSN.

[Products on the Market] **Ethernet Cable**


Item		Model	Specifications		
	For indoor	SC-E5EW-S_M	_: cable length (0.5 m, 1 to 100 m (unit of 1 m))		
Ethernet Cable	For indoor and moving part	SC-E5EW-S M-MV	_: cable length (0.1, 0.2, 0.3, 0.5 m, 1 to 45 m (unit of 1 m))	Double shielded cable (Category 5e)	
	For indoor/outdoor	SC-E5EW-S_M-L	_: cable length (1 to 100 m (unit of 1 m))		

For details, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

^{*} When using CC-Link IE TSN, refer to the website of CC-Link Partner Association for cables on the market other than above. https://www.cc-link.org/en/

Bus Bar DG

For connecting L+/L- terminals between a converter unit and a drive unit and between drive units, use bus bars. Each of the bar models in the table includes a set of two bus bars.



(1) Between power regeneration converter unit and drive unit

Unit mounted on the left side (Note 1)	Unit mounted on the right side (Note 1)	Bus bar model
MR-CV11K4 MR-CV18K4	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR077-B02
	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR092-B02
MR-CV30K4 MR-CV37K4	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR097-B02
MR-CV45K4	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR112-B02
MR-CV55K4 MR-CV75K4	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR099-B03
	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR114-B03

(2) Between drive units

Unit mounted on the left side (Note 1)	Unit mounted on the right side (Note 1)	Bus bar model
MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR077-B02
MR-J5D3-200G4 or smaller	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR092-B02
MR-J5D2-500G4, MR-J5D2-700G4	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR077-B02
	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR092-B02

(3) For final drive unit


When an even number of drive units is connected to the power regeneration converter unit, a space is formed between the bus bars and the TE2 terminal block of the final drive unit. To fill this space, place adjustment bars (MR-DCBAR024-B05) between the bus bars and the TE2 terminal block, and tighten the screws.

Total number of drive units	Adjustment bar model
Even	MR-DCBAR024-B05
Odd	Not required


Configuration Example for MR-CM

Connectors for MR-CM





Connectors for daisy chain wiring (Note 2)



Cables and Connectors for MR-CM

Refer to "Details of Option Connectors for MR-CM" in this catalog for the detailed models.

No.	Item	Application	Model	Description
(1)	Simple converter connector set	For MR-CM3K	(Standard accessory)	CNP1 CNP2 CNP10 Open tool connector connector CNP1, CNP2 connector Applicable wire size (Note 1): AWG 16 to 10
				Insulator OD: 4.7 mm or smaller CNP10 connector Applicable wire size (Note 1): AWG 18 to 14 Insulator OD: 3.9 mm or smaller
		For MR-J5-100G(-RJ) or smaller/ MR-J5W2-44G or smaller/ MR-J5W3-444G or smaller/ MR-J5-100A(-RJ) or smaller		CNP1 CNP2 connector connector
			MR-J5CNP12-J1	CNP1 connector Applicable wire size (Note 1): AWG 18 to 10 Insulator OD: 4.7 mm or smaller CNP2 connector Applicable wire size (Note 1): AWG 18 to 14
(2)	Daisy chain power connector	For MR-J5-200G(-RJ)/ MR-J5W2-77G or larger/ MR-J5-200A(-RJ)		Insulator OD: 3.9 mm or smaller CNP1 CNP2 connector connector
			MD ISONIDAO IO	
			MR-J5CNP12-J2	CNP1 connector Applicable wire size (Note 1): AWG 16 to 10 Insulator OD: 4.7 mm or smaller
				CNP2 connector Applicable wire size (Note 1): AWG 18 to 14 Insulator OD: 3.9 mm or smaller


Notes: 1. The wire size shows wiring specifications of the connector. Refer to "Wires, Molded-Case Circuit Breakers, and Magnetic Contactors" in this catalog for examples of wire size selection

^{2.} When mounting the servo amplifiers, follow the restrictions indicated in "MR-J5 User's Manual".

G G-RJ WG DG

Precautions

Configuration Example for MR-J3-D05



Cables and Connectors for MR-J3-D05

Refer to "Details of Option Connectors for MR-J3-D05" in this catalog for the detailed models.

No.		Item	Application	Cable length	Model	Description
For CN8	(1)	STO cable	For connecting MR-J3-D05 or another safety control device with MR-J5G_(-RJ)/ MR-J5WG/ MR-J5DG4/ MR-J5A_(-RJ)	3 m	MR-D05UDL3M-B	Servo amplifier connector
For CN9	(2)	Connector	For MR-J3-D05	-	(Standard accessory of MR-J3-D05)	Safety logic unit connector
For CN10	(3)	Connector	For MR-J3-D05	-	(Standard accessory of MR-J3-D05)	Safety logic unit connector

Notes: 1. Attach a short-circuit connector supplied with the servo amplifier when the STO function is not used.

Details of Option Connectors for Servo Amplifiers

Model	CNP1 connector	CNP2 connector	CNP3 connector	Open tool
WOUGI		ON Z CONTIGUO	ON O COMPECTOR	Open tool
Servo amplifier power connector set For MR-J5-100G(-RJ) or smaller/ MR-J5-100A(-RJ) or smaller				ST
(standard accessory)	06JFAT-SAXGDK-K7.5 (LA) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-K5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	03JFAT-SAXGDK-K7.5 (LA) (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT-K (J.S.T. Mfg. Co., Ltd.)
Model	CNP1 connector	CNP2 connector	CNP3 connector	Open tool
Servo amplifier power connector set For MR-J5-200G(-RJ)/ MR-J5-200A(-RJ)/ MR-J5-350G(-RJ)/ MR-J5-350A(-RJ) (standard accessory)	06JFAT-SAXGFK-XL (LA) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-H5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	03JFAT-SAXGFK-XL (LA) (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT-EXL (J.S.T. Mfg. Co., Ltd.)
(,	-	(0.0.1. Wilg. 00., Etd.)	(0.0.1. Wilg. 00., Etd.)	(0.0.1. Wilg. 00., Ltd.)
Model	CNP1A/CNP1B connector	CNP2 connector	CNP3 connector	Open tool
Servo amplifier power connector set For MR-J5-500G(-RJ)/ MR-J5-500A(-RJ)/ MR-J5-700G(-RJ)/ MR-J5-700A(-RJ)	CNP1A connector 03JFAT-SAXGDK-P15 (LA)			For CNP1A/CNP1B/CNP3 connectors J-FAT-OT-P (J.S.T. Mfg. Co., Ltd.) For CNP2 connector
(standard accessory)	(J.S.T. Mfg. Co., Ltd.) CNP1B connector 03JFAT-SAYGDK-P15 (LB) (J.S.T. Mfg. Co., Ltd.)	CNP2 connector 05JFAT-SAXGDK-H5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	CNP3 connector 03JFAT-SAZGDK-P15 (LC) (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT (N) (J.S.T. Mfg. Co., Ltd.)
Model	CNP1 connector	CNP2 connector	CNP3 connector	Open tool
Servo amplifier power connector set For MR-J5-350G4(-RJ) or smaller/ MR-J5-350A4(-RJ) or smaller (standard accessory)	06JFAT-SAXGDK-HT10.5 (LA)	05JFAT-SAXGDK-HT7.5 (LA)	03JFAT-SAXGDK-HT10.5 (LA)	J-FAT-OT-XL
	(J.S.T. Mfg. Co., Ltd.)	(J.S.T. Mfg. Co., Ltd.)	(J.S.T. Mfg. Co., Ltd.)	(J.S.T. Mfg. Co., Ltd.)
Model	CNP1 connector	CNP2 connector	CNP3_ connector	Open tool
Servo amplifier power connector set For MR-J5W2-44G or smaller/ MR-J5W3-444G or smaller (standard accessory)	06JFAT-SAXGDK-K7.5 (LB)	05JFAT-SAXGDK-K5.0 (LA)	04JFAT-SAGG-G-KK	J-FAT-OT-K
	(J.S.T. Mfg. Co., Ltd.)	(J.S.T. Mfg. Co., Ltd.)	(J.S.T. Mfg. Co., Ltd.)	(J.S.T. Mfg. Co., Ltd.)
Model	CNP1 connector	CNP2 connector	CNP3_ connector	Open tool
Servo amplifier power connector set For MR-J5W2-77G or larger (standard accessory)				
	06JFAT-SAXGFK-XL (LB) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-H5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	04JFAT-SAGG-G-KK (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT-EXL (J.S.T. Mfg. Co., Ltd.)
Model	CNP3_ connector		Open tool *	
Drive unit power connector set For MR-J5DG4 (standard accessory)			SDS 0.8X4.5X125 (Weidmüller Interface GmbH & Co. KG)	
	BVF 7.62HP/04/180MF4 SN BK BX LRP (Weidmüller Interface GmbH & Co. KG)		* The open tool is not supplied with a drive unit. The open tool must be prepared by users.	

Details of Option Connectors for Servo Amplifiers

Model	Servo amplifier connector	Junction terminal block connector	C
			CIIICAIIOIIO
MR-J2HBUS_M	Connector: 52316-2019 Shell kit: 52370-2070 (Molex, LLC) or an equivalent product or Press bonding type (Note 2) Connector: 10120-6000EL Shell kit: 10320-3210-000	Connector: 52316-2019 Shell kit: 52370-2070 (Molex, LLC) or an equivalent product or Press bonding type (Note 2) Connector: 10120-6000EL Shell kit: 10320-3210-000	
	(3M) or an equivalent product	(3M) or an equivalent product	
Model	Servo amplifier connector		
MR-CCN1		Solder type (Note 1) Connector: 10120-3000PE Shell kit: 10320-52F0-008 (3M) or an equivalent product	141
Model	Servo amplifier connector	Junction terminal block connector	14101010
MR-TBNATBL_M	Connector: 10126-6000EL Shell kit: 10326-3210-000 (3M) or an equivalent product	Connector: 10126-6000EL Shell kit: 10326-3210-000 (3M) or an equivalent product	MIOTOLO

Notes: 1. The press bonding type (connector: 10120-6000EL and shell kit: 10320-3210-000) (3M) is also usable. Contact the manufacturer directly.

2. The solder type (connector: 10120-3000PE and shell kit: 10320-52F0-008) (3M) is also usable. Contact the manufacturer directly.

Precautions

Details of Option Connectors for Servo Amplifiers

Model	Servo amplifier connector	
MR-J2CMP2 MR-ECN1		Connector: 10126-3000PE Shell kit: 10326-52F0-008 (3M) or an equivalent product
Model	I/O and monitor connector	
MR-ADCN3		Connector: DFMC 1,5/16-STF-3,5 (Phoenix Contact)
Model	Junction terminal block connector	Servo amplifier connector
MR-J2M-CN1TBL_M	Connector: D7950-B500FL (3M)	Press bonding type (Note 1) Connector: 10150-6000EL Shell kit: 10350-3210-000 (3M)
Model	Servo amplifier connector	
MR-J3CN1		Connector: 10150-3000PE Shell kit: 10350-52F0-008 (3M) or an equivalent product
Model	Servo amplifier connector	Battery case connector
MR-BT6V1CBL_M	Contact: SPHD-001G-P0.5 Housing: PAP-02V-O (J.S.T. Mfg. Co., Ltd.)	Solder type (Note 2) Connector: 10114-3000PE Shell kit: 10314-52F0-008 (3M) or an equivalent product
Model	Servo amplifier connector	Junction connector
MR-BT6V2CBL_M	Contact: SPHD-001G-P0.5 Housing: PAP-02V-O (J.S.T. Mfg. Co., Ltd.)	Contact: SPAL-001GU-P0.5 Housing: PALR-02VF-O (J.S.T. Mfg. Co., Ltd.)
Model	Servo amplifier connector	
MR-ACN6CBL1M		Housing: SHR-03V-S Contact: SSH-003T-P0.2-H (J.S.T. Mfg. Co., Ltd.)
Model	Servo amplifier connector	
MR-J3CN6CBL1M		Housing: 51004-0300 Terminal: 50011-8100 (Molex, LLC)
Model	Servo amplifier connector	
MR-D05UDL3M-B		Connector set: 2069250-1 (TE Connectivity Ltd. Company)
Model	Power regeneration converter unit connector	Drive unit connector
MR-ACDL_M	Plug: 10120-3000PE Shell kit: 10320-56F0-008 (3M) or an equivalent product	Plug: HDR-E26MG1+ Shell kit: HDR-E26LPJP+ (Honda Tsushin Kogyo Co., Ltd.)
Model	Drive unit connector	Drive unit connector
MR-ADDL02M	Connector: IX30G-A-10S- CV(7.0) (Hirose Electric Co., Ltd.)	Plug: HDR-E26MG1+ Shell kit: HDR-E26LPJP+ (Honda Tsushin Kogyo Co., Ltd.)

Notes: 1. The solder type (connector: 10150-3000PE and shell kit: 10350-52F0-008) (3M) is also usable. Contact the manufacturer directly.

2. The press bonding type (connector: 10114-6000EL and shell kit: 10314-3210-000) (3M) is also usable. Contact the manufacturer directly.

Details of Option Connectors for MR-CV_

Model	Power regeneration converter unit connector		
MR-CVCN24S		Connector: DK-2100D-08R Contact: DK-2RECSLP1-100 (DDK Ltd.)	
Model	Power regeneration converter unit connector	Open tool	
Magnetic contactor wiring connector (Standard accessory of power			
regeneration converter unit)	Connector: 03JFAT-SAXGSA-L (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT-EXL (J.S.T. Mfg. Co., Ltd.)	

Details of Option Connectors for MR-CM

Model	CNP1 connector	CNP2 connector	CNP10 connector	Open tool
Simple converter connector set (standard accessory)		000 000 000 000	000	(T)
	03JFAT-SAYGFK-XL (LB) (J.S.T. Mfg. Co., Ltd.)	02(16.0)JFAT-SAZGFK-XL (LA) (J.S.T. Mfg. Co., Ltd.)	02(3-2)JFAT-SAYDFK-K7.5 (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT-EXL (J.S.T. Mfg. Co., Ltd.)
Model	CNP1 connector		CNP2 connector	
MR-J5CNP12-J1	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		q	
	06JFAT-SAXGDK-KC7.5 (LA) (J.S.T. Mfg. Co., Ltd.)		05JFAT-SAXGDK-KC5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	
Model	CNP1 connector		CNP2 connector	
MR-J5CNP12-J2				000
	06JFAT-SAXGFK-XLC (LA) (J.S.T. Mfg. Co., Ltd.)		05JFAT-SAXGDK-HC5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	

Details of Option Connectors for MR-J3-D05

Model	Servo amplifier connector	
MR-D05UDL3M-B		ector set: 2069250-1 Connectivity Ltd. Company)
Model	Safety logic unit connector	
Connector for CN9 of safety logic unit (Standard accessory of MR-J3-D05)		ector: 1-1871940-4 Connectivity Ltd. Company)
Model	Safety logic unit connector	
Connector for CN10 of safety logic unit (Standard accessory of MR-J3-D05)		ector: 1-1871940-8 Connectivity Ltd. Company)

Products on the Market for Servo Amplifiers

Mitsubishi Electric Engineering

Network amplifier junction terminal block


Features


- The spring clamp type reduces the installation area by about 40 % compared to the screw type (based on the research of Mitsubishi Electric Engineering).
- When multiple servo amplifiers are connected, the interface power supply can be connected in series across terminal blocks.

Connection with servo amplifier

Dimensions

■DG2SV3TB





Product models

Item		Model	Description
			For network-connectable 1-axis servo amplifier, sink/source common type
Netw	ork amplifier junction terminal block	DG2SV3TB	External power supply voltage: 24 V DC ± 10 %
			Maximum usable current: 0.5 A for signal/6 A for common line
		DG4SV2CB05	Length: 0.5 m
	Servo amplifier connection cable	DG4SV2CB10	Length: 1 m
		DG4SV2CB50	Length: 5 m

Junction terminal block for servo motors with brakes


Features


- Easy to build a brake sequence circuit recommended for MR-J5-G servo amplifiers.
- The new terminal block reduces the installation area by up to 50 % compared to preceding types. In addition, fewer wires are required inside the cabinet.

Connection with servo amplifier

Dimensions

■DG2BK1TB





* The DG2BK1TB-D is without mounting tabs.

Product models

Item	Model	Description	
Junction terminal block for motor with brake	IDG9RK1TR	Screw mounting/ DIN rail installation	Applicable servo motor capacity: 50 W to 22 kW External power supply voltage
For network-connectable 1-axis servo amplifier Sink/source common type*	DG2BK1TB-D	For DIN rail installation	For servo amplifier interface: 24 V DC (-5 % to 10 %), 0.3 A (max.) For electromagnetic brake: 24 V DC (-10 % to 0 %), 1.43 A (max.) Relay: DSP1a-DC24V (Panasonic Corporation)
	DG4SV2CB05	Length: 0.5 m	
Servo amplifier connection cable	DG4SV2CB10	Length: 1 m	
	DG4SV2CB50	Length: 5 m	

^{*} The sink/source common type of junction terminal block for motors with brakes will be available in the near future.


The product line is different while the conventional models are manufactured. For details, please refer to the latest Mitsubishi Electric Engineering catalog or other information sources.

Features


- Compact terminal blocks designed specifically for the FLS/RLS (stroke limit) and DOG (proximity dog) signals.
- Long cables are available to install the terminal block near the machine. (Long bending life cables are also available.)



Connection with servo amplifier




Dimensions




Dimensions

■ DG2SV2TB2 (for 2-axis)



Dimensions

■ DG2SV2TB3 (for 3-axis)



Product models

Item	Model	Description
FLS/RLS/DOG signal-specialized network amplifier terminal block (for 1-axis)		For network-connectable 1-axis servo amplifier Sink/source common type, dedicated for FLS/RLS/DOG signals External power supply voltage: 24 V DC ± 10 % Maximum usable current: 0.5 A for signal / 6 A for common line
Oints interfered and a small firm a small firm a shift of the small firm and the small fi	DG4SV2CB05	Length: 0.5 m
Sink-interface servo amplifier connection cable (for 1-axis servo amplifier)	DG4SV2CB10	Length: 1 m
(IOI 1-axis servo ampilier)	DG4SV2CB50	Length: 5 m
Sink-interface servo amplifier connection cable	DG4SV2CB50H	Length: 5 m
(for 1-axis servo amplifier / long bending life)	DG4SV2CB100H	Length: 10 m
0	DG4SV2CB05-P01	Length: 0.5 m
Source-interface servo amplifier connection cable	DG4SV2CB10-P01	Length: 1 m
(for 1-axis servo amplifier)	DG4SV2CB50-P01	Length: 5 m
Source-interface servo amplifier connection cable	DG4SV2CB50H-P01	Length: 5 m
(for 1-axis servo amplifier / long bending life)	DG4SV2CB100H-P01	Length: 10 m
FLS/RLS/DOG signal-specialized (for 2-axis/ 3-axis servo	DG2SV2TB2	For network-connectable 2-axis integrated servo amplifier Sink/source common type, dedicated for FLS/RLS/DOG signals External power supply voltage: 24 V DC ± 10 % Maximum usable current: 0.5 A for signal / 6 A for common line
network amplifier terminal block amplifier)	DG2SV2TB3	For network-connectable 3-axis integrated servo amplifier Sink/source common type, dedicated for FLS/RLS/DOG signals External power supply voltage: 24 V DC ± 10 % Maximum usable current: 0.5 A for signal / 6 A for common line
0:1:1:4	DG4SV3CB05	Length: 0.5 m
Sink-interface servo amplifier connection cable	DG4SV3CB10	Length: 1 m
(for 2-axis/3-axis servo amplifier)	DG4SV3CB50	Length: 5 m
Sink-interface servo amplifier connection cable	DG4SV3CB50H	Length: 5 m
(for 2-axis/3-axis servo amplifier / long bending life)	DG4SV3CB100H	Length: 10 m
	DG4SV3CB05-P01	Length: 0.5 m
Source-interface servo amplifier connection cable (for 2-axis/3-axis servo amplifier)	DG4SV3CB10-P01	Length: 1 m
(for 2-axis/3-axis servo ampliner)	DG4SV3CB50-P01	Length: 5 m
Source-interface servo amplifier connection cable	DG4SV3CB50H-P01	Length: 5 m
(for 2-axis/3-axis servo amplifier / long bending life)	DG4SV3CB100H-P01	Length: 10 m

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Servo amplifier connection cable for pulse train Positioning modules


Features

■ This servo amplifier connection cable for pulse train Positioning modules enables easy wiring when the MELSEC Positioning module is used to control the MR-J5-A.




Dimensions

■FA-CBLQ75M2J3, FA-CBLQ75PM2J3



■ FA-CBLQ75M2J3-P



Product models

Item	Model	Description
Servo amplifier connection cable for pulse train	FA-CBLQ75M2J3-P	Supported Positioning module: RD75D2, RD75D4, FX5-20PG-D Length: 2 m, with pulsar cables
	FA-CBLQ75M2J3	Supported Positioning module: RD75D2, RD75D4, FX5-20PG-D Length: 2 m, without pulsar cables
	FA-CBLQ75PM2J3	Supported Positioning module: RD75P2, RD75P4, FX5-20PG-P Length: 2 m, without pulsar cables


General-purpose interface amplifier junction terminal block

Features

- The spring clamp type reduces the installation area by 50 % compared to the screw type (based on the research of Mitsubishi Electric Engineering).
- When multiple servo amplifiers are connected, the interface power supply can be connected in series across up to four terminal blocks.




Connection with servo amplifier



Dimensions

■ DG2SV1TB



Product models

Item		Model	Description
Gen	General-purpose interface amplifier junction terminal block DG2SV1TB		For general-purpose interface servo amplifier, sink/source common type
bloc			External power supply voltage: 24 V DC ± 10 %, current capacity 1 A (max.)
	Servo amplifier connection cable	DG4SV1CB05	Length: 0.5 m
		DG4SV1CB10	Length: 1 m

For inquiries about Mitsubishi Electric Engineering products, please contact us at the following email address. (Supported languages: English and Japanese).

fagoods.products.faq@mitsubishielectricengineering.com

Precautions

Safety Logic Unit (MR-J3-D05)

G G-RJ WG DG A A-RJ

The safety logic unit (MR-J3-D05) has SS1 (Safe Stop1) and STO functions. A combination of the servo amplifier and the safety logic unit achieves SS1 function.

Specifications

Safety logic unit model MR-J3-D05		MR-J3-D05
Combinal	Voltage	24 V DC
Control circuit power	Permissible voltage fluctuation	24 V DC ± 10 %
supply	Required current [A]	0.5 (Note 1, 2)
Compatible s	system	2 systems (A-axis, B-axis independent)
Shut-off input	t	4 points (2 points × 2 systems) SDI_: source/sink compatible (Note 3)
Shut-off relea	ase input	2 points (1 point × 2 systems) SRES_: source/sink compatible (Note 3)
Feedback inp	out	2 points (1 point × 2 systems) TOF_: source compatible (Note 3)
Input type		Photocoupler insulation, 24 V DC (external supply), internal limited resistance 5.4 kΩ
Shut-off outp	ut	8 points (4 points × 2 systems) STO_: source compatible (Note 3) SDO_: source/sink compatible (Note 3)
Output type		Photocoupler insulation, open-collector type Permissible current: 40 mA or less per output, Inrush current: 100 mA or less per output
Delay time se	etting	A-axis: select from 0 s, 1.4 s, 2.8 s, 5.6 s, 9.8 s or 30.8 s B-axis: select from 0 s, 1.4 s, 2.8 s, 9.8 s or 30.8 s Accuracy: ±2 %
Safety sub-fu	ınction	STO, SS1 (IEC/EN 61800-5-2) EMG STOP, EMG OFF (IEC/EN 60204-1)
	Satisfied standards	ISO 13849-1:2015 Category 3 PL d, IEC 61508 SIL 2, IEC 62061 SIL CL 2, IEC 61800-5-2
O-f-t-	Response performance (when delay time is set to 0 s) (Note 4)	10 ms or less (STO input OFF → shut-off output OFF)
Safety performance	Mean time to dangerous failure (MTTFd)	MTTFd ≥ 100 [years] (516a)
	Diagnostic coverage (DC)	DC = Medium, 93.1 [%]
	Probability of dangerous Failure per Hour (PFH)	4.75 × 10 ⁻⁹ [1/h]
Satisfied Standards CE marking LVD: EN 61800-5-1 EMC: EN 61800-3		
Structure (IP	rating)	Natural cooling, open (IP00)
,	Ambient temperature	Operation: 0 °C to 55 °C (non-freezing), storage: -20 °C to 65 °C (non-freezing)
Ambient humidity		Operation/storage: 5 %RH to 90 %RH (non-condensing)
Environment	Ambience	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust
	Altitude	1000 m or less
	Vibration resistance	5.9 m/s ² at 10 Hz to 55 Hz (directions of X, Y and Z axes)
Mass	[kg]	0.2 (including CN9 and CN10 connectors)
Notes: 1 Inrush		anapulsity when the nower is switched on. Select an appropriate capacity of a power supply considering the invise current


Notes: 1. Inrush current of approximately 1.5 A flows instantaneously when the power is switched on. Select an appropriate capacity of a power supply considering the inrush current.

- Power-on duration of the safety logic unit is 100,000 times.
 _ in signal name indicates a number and axis name.
- 4. Contact your local sales office for test pulse input.

Safety Logic Unit (MR-J3-D05)

G G-RJ WG DG A A-RJ


Connection example



Notes: 1. Set delay time of STO output with SW1 and SW2.

This connection is for source interface.

Dimensions



Regenerative Option

G G-RJ WG A A-RJ

For 200 V

	Permissible re	egenera	tive pow	er [W] ^{(N}	lote 2)								
	Regenerative option												
Servo amplifier	Built-in	MR-RB											
model	regenerative resistor	032	12	14	30	3N (Note 3)	31 (Note 3)	3Z (Note 3, 4)	34 (Note 3)	50 (Note 1)	5N (Note 1)	51 (Note 1)	5Z (Note 1, 4)
		40 Ω	40 Ω	26 Ω	13 Ω	9 Ω	6.7 Ω	5.5 Ω	26 Ω	13 Ω	9 Ω	6.7 Ω	5.5 Ω
MR-J5-10G/A	-	30	-	-	-	-	-	-	-	-	-	-	-
MR-J5-20G/A	10	30	100	-	-	-	-	-	-	-	-	-	-
MR-J5-40G/A	10	30	100	-	-	-	-	-	-	-	-	-	-
MR-J5-60G/A	10	30	100	-	-	-	-	-	-	-	-	-	-
MR-J5-70G/A	30	-	-	100	-	-	-	-	300	-	-	-	-
MR-J5-100G/A	30	-	-	100	-	-	-	-	300	-	-	-	-
MR-J5-200G/A	100	-	-	-	300	-	-	-	-	500	-	-	-
MR-J5-350G/A	100	-	-	-	-	300	-	-	-	-	500	-	-
MR-J5-500G/A	130	-	-	-	-	-	300	-	-	-	-	500	-
MR-J5-700G/A	170	-	-	-	-	-	-	300	-	-	-	-	500
MR-J5W2-22G	20	-	-	100	-	-	-	-	-	-	-	-	-
MR-J5W2-44G	20	-	-	100	-	-	-	-	-	-	-	-	-
MR-J5W2-77G	100	-	-	-	-	300	-	-	-	-	-	-	-
MR-J5W2-1010G	100	-	-	-	-	300	-	-	-	-	-	-	-
MR-J5W3-222G	30	-	-	100	-	-	-	-	300	-	-	-	-
MR-J5W3-444G	30	-	-	100	-	-	-	-	300	-	-	-	-

For 400 V


	Permissible re	Permissible regenerative power [W] (Note 2)										
0		Regenerative opt	Regenerative option									
	Built-in	MR-RB	MR-RB									
	regenerative resistor	1H-4	3M-4 (Note 1) 3G-4 (Note 1)		3Y-4 (Note 1)	5G-4 (Note 1)	5Y-4 (Note 1)					
		82 Ω	120 Ω	47 Ω	36 Ω	47 Ω	36 Ω					
MR-J5-60G4/A4	15	100	300	-	-	-	-					
MR-J5-100G4/A4	15	100	300	-		-	-					
MR-J5-200G4/A4	100	-	-	300	-	500	-					
MR-J5-350G4/A4	120	-	-	-	300	-	500					

Notes: 1. Cool the unit forcibly with a cooling fan (92 mm x 92 mm, minimum air flow: 1.0 m³/min). The cooling fan must be prepared by users.


- 2. The power values in this table are resistor-generated powers, not rated powers.
- 3. Depending on the operating environment, it may be necessary to cool the unit forcibly with a cooling fan (92 mm x 92 mm, minimum air flow: 1.0 m³/min). Refer to "MR-J5 User's Manual" for details. The cooling fan must be prepared by users.
- 4. Use the servo amplifier with firmware version B6 or later.

* Precautions when installing and connecting the regenerative option

- 1. The regenerative option causes a temperature rise of 100 °C or higher relative to the ambient temperature. Fully examine heat dissipation, installation position, wires used before installing the unit. Use flame-retardant wires or apply flame retardant on wires, and keep the wires clear of the unit.
- 2. Use twisted wires for connecting the regenerative option to the servo amplifier, and keep the wire length to a maximum of 5 m.
- Use twisted wires for connecting a thermal sensor so that the sensor does not fail to work properly because of inducted noise.
 There are restrictions on the mounting direction of the regenerative option. Refer to "MR-J5 User's Manual" for details.



Create a sequence circuit that turns off the magnetic contactor when abnormal overheating occurs.
 G3 and G4 terminals are thermal sensor. G3-G4 opens when the regenerative option overheats abnormally.
 The wire size shows wiring specifications of the connector. Refer to "Wires, Molded-Case Circuit Breakers, and Magnetic Contactors" in this catalog for examples of wire



 Create a sequence circuit that turns off the magnetic contactor when abnormal overheating occurs.
 When using MR-RB3M-4, MR-RB3G-4, MR-RB3Y-4, MR-RB5D, MR-RB5N, MR-RB51, MR-RB5Z, MR-RB5G-4, or MR-RB5Y-4, cool the unit forcibly with a cooling fan (92) mm \times 92 mm, minimum air flow: 1.0 m 3 /min). The cooling fan must be prepared by users.

17

217

5.6

MR-RR5N

MR-RB51

MR-RB5Z MR-RB5G-4 MR-RB5Y-4

- 3. When MR-RB30, MR-RB3N, MR-RB31, MR-RB3Z, or MR-RB34 is used, it may be necessary to cool the unit forcibly with a cooling fan (92 mm x 92 mm, minimum air flow: 1.0 m³/min), depending on the operating environment. Refer to "MR-J5 User's Manual" for details. The cooling fan must be prepared by users.
- 4. G3 and G4 terminals are thermal sensor. G3-G4 opens when the regenerative option overheats abnormally.

Multifunction Regeneration Converter (FR-XC, FR-XC-H) (Note 5)

G G-RJ A A-RJ

FR-XC multifunction regeneration converter is suitable for 200 V class servo amplifiers ranged from 100 W to 7 kW and FR-XC-H for 400 V class servo amplifiers ranged from 600 W to 3.5 kW. The multifunction regeneration converter is not compatible with multi-axis servo amplifiers and drive units.

Use the common bus regeneration mode with the harmonic suppression function disabled. The power regeneration mode and the harmonic suppression function are not supported.

200 V class

Multifunction regen	eration converter	FR-XC-	7.5K	11K	15K	22K	30K	37K	55K	
Capacity		[kW]	7.5	11	15	22	30	37	55	
Maximum number of	Maximum number of connectable servo amplifiers 10									
Total capacity of co	nnectable servo amplifiers (Note 1)	[kW]	3.5 (5.5)	5.5 (7.5)	7.5 (11)	22	30	37	55	
Continuous output	Note 1)	[kW]	3.5 (5.5)	5.5 (7.5)	7.5 (11)	18.5	22	30	45	
Rated input	Power driving		33	47	63	92	124	151	223	
current [A]	Regenerative driving		26	37	51	74	102	125	186	
Overload current ra	ating		100 % con	tinuous / 150	0 % 60 s					
	Rated input AC voltage/frequen	су	3-phase 20	0 V AC to 2	40 V AC, 50	Hz/60 Hz				
Power source	Permissible AC voltage fluctuat	ion	3-phase 17	0 V AC to 2	64 V AC, 50	Hz/60 Hz				
rower source	Permissible frequency fluctuation	on	±5 %							
	Power supply capacity	[kVA]	17	20	28	41	52	66	100	
IP rating (IEC 6052	P rating (IEC 60529) Open type (IP00)									
Cooling system			Forced air							
	Ambient temperature		-10 °C to 50 °C (non-freezing)							
	Ambient humidity		90 %RH or less (non-condensing)							
	Storage temperature		-20 °C to 65 °C							
Environment	Ambience		Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt)							
	Altitude		2500 m or less (For the installation at an altitude above 1000 m, consider a 3 %							
	Allitude		reduction in the rated current per 500 m increase in altitude.)							
	5.9 m/s2 at	10 Hz to 55	Hz (directio	ns of X, Y, a	nd Z axes)	•				
Molded-case circuit breaker or earth-leakage current			100 AF 60 A	100 AF 75 A	225 AF 125 A	225 AF 175 A	225 AF 225 A	400 AF 250 A	400 AF 250 A	
breaker (Note 4)	(30 AF 30 A)	(50 AF 50 A)	(100 AF 75 A)	(100 AF 100 A)	(125 AF 125 A)	(125 AF 125 A)	(225 AF 175 A)			
Magnetic centerte	(Note 4)		S-T35	S-T50	S-T65	S-T100	S-N125	S-N150	S-N220	
Magnetic contactor	(Note 4)		(S-T21)	(S-T35)	(S-T50)	(S-T65)	(S-T80)	(S-T100)	(S-N125)	

400 V class

Multifunction regen	eration converter FF	R-XC-H	7.5K	11K	15K	22K	30K	37K	55K		
Capacity		[kW]	7.5	11	15	22	30	37	55		
Maximum number of	of connectable servo amplifiers		10	•							
Total capacity of co	nnectable servo amplifiers (Note 1)	[kW]	3.5 (5.5)	5.5 (7.5)	7.5 (11)	22	30	37	55		
Continuous output	Note 1)	[kW]	3.5 (5.5)	5.5 (7.5)	7.5 (11)	18.5	22	30	45		
Rated input	Power driving		18	25	34	49	65	80	118		
current [A]	Regenerative driving		14	20	27	39	54	66	98		
Overload current ra	iting		100 % cont	inuous / 150	% 60 s						
	Rated input AC voltage/frequence	y (Note 2)	3-phase 38	0 to 500 V A	C, 50/60 Hz	:					
Power source	Permissible AC voltage fluctuation	n (Note 3)	3-phase 32	3 to 550 V A	C, 50/60 Hz	:					
rower source	Permissible frequency fluctuation	า	±5 %								
	Power supply capacity [kVA]			20	28	41	52	66	100		
IP rating (IEC 6052	9)		Open type	(IP00)							
Cooling system			Forced air								
	Ambient temperature		-10 °C to 50 °C (non-freezing)								
	Ambient humidity		90 %RH or less (non-condensing)								
	Storage temperature		-20 °C to 65 °C								
Environment	Ambience		Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt)								
	Altitudo		2500 m or less (For the installation at an altitude above 1000 m, consider a 3 %								
Altitude			reduction in the rated current per 500 m increase in altitude.)								
	Vibration resistance	5.9 m/s ² at	10 Hz to 55	Hz (direction	ns of X, Y, ar	nd Z axes)					
Molded-case circuit breaker or earth-leakage current			30 AF 30 A	50 AF 50 A	100 AF 60 A	100 AF 100 A	225 AF 125 A	225 AF 150 A	225 AF 200 A		
breaker (Note 4)			(30 AF 15 A)	(30 AF 20 A)	(30 AF 30 A)	(50 AF 50 A)	(60 AF 60 A)	(100 AF 75 A)	(100 AF 100 A)		
Magnetic contector	(Note 4)		S-T21	S-T25	S-T35	S-T50	S-T65	S-T80	S-N125		
Magnetic contactor (Note 4)		0-121	(S-T21)	(S-T21)	(S-T25)	(S-T35)	(S-T50)	(S-T65)			

1. The values in brackets are applicable when the number of connected servo amplifiers is six or less.

- 2. When connecting to a servo amplifier, use with a voltage range of 380 V to 480 V.
- 3. When connecting to a servo amplifier, use with a voltage range of 323 V to 528 V.
 4. The models in brackets are applicable when the capacity [kW] of FR-XC-(H) ≥ Total rated capacity [kW] of servo amplifiers connected to FR-XC-(H) × 2.
- 5. The following are specifications at the time of July 2021.
 - For selecting an FR-XC-(H) multifunction regeneration converter, refer to the latest "FR-XC Instruction Manual" and "MR-J5 User's Manual".


* Precautions when selecting the multifunction regeneration converter

- 1. Total rated capacity [kW] of servo amplifiers connected to FR-XC-(H) ≤ Capacity [kW] of FR-XC-(H)
- 2. Effective value [kW] of total output power of servo motors \leq Continuous output [kW] of FR-XC-(H)
- 3. Maximum value [kW] of total output power of servo motors ≤ FR-XC-(H) capacity [kW] × 1.5

Multifunction Regeneration Converter (FR-XC, FR-XC-H)

G-RJ A A-RJ

Connection example



Notes: 1. Create a sequence that shuts off the main circuit power when either: An alarm occurs on FR-XC-(H) or the servo amplifier, or

- EM1 (Forced stop 1) is enabled. 2. For the servo amplifier, create a sequence that switches the servo-on after FR-XC-(H) is ready.
- 3. Create a sequence that stops the servo motor with the emergency stop input to the controller when an alarm occurs on FR-XC-(H). When the emergency stop input is not available in the controller, stop the servo motor with the forced stop input to the servo amplifier as shown in the diagram
- 4. Disconnect the short-circuit bar between P3 and P4 when using FR-XC-(H).
- 5. Set [Pr. PA04.3] and [Pr. PA04.2] to "0" to enable EM1 (Forced stop 1).
- 6. When wires used for L11 and L21 are thinner than those for L1, L2, and L3, use a molded-case circuit breaker.
- 7. When using a separate power supply for the control circuit, remove the short-circuit bars between R/L1 and R1/L11, and S/L2 and S1/L21
- 8. When FR-XC-H is used, a step-down transformer is required if coil voltage of the magnetic contactor is in 200 V class.
- 9. Use twisted wires for connecting the DC power supply between FR-XC-(H) and the servo amplifiers, and keep the wire length to a maximum of 5 m. 10. Install a fuse between each FR-XC-(H) and servo amplifier.
- 11. Do not connect anything to the P4 terminal of FR-XC-(H).
- 12. Inputs/outputs (main circuit) of FR-XC-(H) and the servo amplifier include high frequency components, and they may interfere with peripheral communication devices In that case, the interference can be reduced with the installation of a radio noise filter (FR-BIF or FR-BIF-H) or line noise filter (FR-BSF01 or FR-BLF)
- 13. When using 7 kW or smaller servo amplifiers, do not disconnect the short-bar between P+ and D.
- 14. For convenience of illustration, the diagram shows separate 24 V DC power supplies for input and output signals. However, the input and output signals can share a common power supply.
- 15. When using FR-XC-(H), use the following dedicated stand-alone reactor (FR-XCL or FR-XCL-H). Do not use a power factor improving AC reactor (FR-HAL or FR-HAL-H) or a power factor improving DC reactor (FR-HEL or FR-HEL-H) with FR-XC-(H).

	,
Multifunction regeneration converter	Dedicated stand-alone reactor
FR-XC-7.5K	FR-XCL-7.5K
FR-XC-11K	FR-XCL-11K
FR-XC-15K	FR-XCL-15K
FR-XC-22K	FR-XCL-22K
FR-XC-30K	FR-XCL-30K
FR-XC-37K	FR-XCL-37K
FR-XC-55K	FR-XCL-55K


Multifunction regeneration converter	Dedicated stand-alone reactor
FR-XC-H7.5K	FR-XCL-H7.5K
FR-XC-H11K	FR-XCL-H11K
FR-XC-H15K	FR-XCL-H15K
FR-XC-H22K	FR-XCL-H22K
FR-XC-H30K	FR-XCL-H30K
FR-XC-H37K	FR-XCL-H37K
FR-XC-H55K	FR-XCL-H55K

Battery

G G-RJ A A-RJ



Use the battery to configure an absolute position detection system with a direct drive motor. The absolute position data can be retained when the battery is mounted on the servo amplifier. The battery is not required for rotary servo motors and linear servo motors. When the battery life runs out, please replace the built-in MR-BAT6V1 battery. Refer to "MR-J5 User's Manual" for installation of the battery.



[[]g] 55 (including MR-BAT6V1 battery) * MR-J3BAT battery cannot be used because of the difference in voltage.

To transport lithium metal batteries and lithium metal batteries contained in equipment, take actions to comply with the following regulations: the United Nations Recommendations on the Transport of Dangerous Goods, the Technical Instruction (ICAO-TI) by the International Civil Aviation Organization (ICAO), and the International Maritime Dangerous Goods Code (IMDG Code) by the International Maritime Organization (IMO). To transport the batteries, check the latest standards or the laws of the destination country and take actions. Contact your local sales office for more details.

Mass

MR-BAT6V1 is an assembled battery composed of lithium metal batteries of CR17335A. This battery is not subject to the dangerous goods (Class 9) of the UN Recommendations.

^{*} Please dispose of the battery according to your local laws and regulations.

G-RJ WG


Precautions

Battery Case (MR-BT6VCASE) and Battery (MR-BAT6V1)


amplifiers and multi-axis servo amplifiers.

Absolute position data of up to four axes of direct drive motors can be retained when the battery case and the batteries are used. Direct drive motors used in incremental systems are also included in the number of the connectable axes. The synchronous encoders used for load side in the fully closed loop control system are also included in the number of the connectable axes. The linear servo motors are not included in the number of the connectable axes. The battery cases and batteries can be used in systems including 1-axis servo

The case stores five batteries by connecting to the connectors. The batteries are not included in the battery case. Please purchase the batteries separately.



- * MR-BAT6V1 is an assembled battery composed of lithium metal batteries of CR17335A. This battery is not subject to the dangerous goods (Class 9) of the UN Recommendations. To transport lithium metal batteries and lithium metal batteries contained in equipment, take actions to comply with the following regulations: the United Nations Recommendations on the Transport of Dangerous Goods, the Technical Instruction (ICAO-TI) by the International Civil Aviation Organization (ICAO), and the International Maritime Dangerous Goods Code (IMDG Code) by the International Maritime Organization (IMO). To transport the batteries, check the latest standards or the laws of the destination country and take actions. Contact your local sales office for more details.
- * Please dispose of the battery according to your local laws and regulations




 $Notes: \quad \hbox{1. This is an option cable. Refer to "Cables and Connectors for Servo Amplifiers" in this catalog.}$

Absolute Position Storage Unit (MR-BTAS01)

G G-RJ WG A A-RJ

This absolute position storage unit is required for configuring an absolute position detection system using the direct drive motor. This unit is not required when the servo system is used in incremental system.



Notes: 1. When mounting the absolute position storage unit outside a cabinet, mount the surface A with four screws. When mounting the unit inside a cabinet, mounting the surface B with two screws is also possible.

Replacement Fan Unit (MR-J5-FAN)



The cooling fan of the servo amplifier has a fan and a fan cover as a unit. Replace the fan unit when the fan needs to be replaced. Refer to "MR-J5 User's Manual" or "MR-J5D User's Manual" for replacement of the cooling fan.

Servo amplifier model	Replacement fan unit model
MR-J5-70G/A	MR-J5-FAN1
MR-J5-100G/A	
MR-J5-200G/A	
MR-J5-350G/A	MR-J5-FAN2
MR-J5-200G4/A4	WIT 65 TARE
MR-J5-350G4/A4	
MR-J5-500G/A	MR-J5-FAN3
MR-J5-700G/A	MR-J5-FAN4
MR-J5W2-44G	MR-J5W-FAN1
MR-J5W2-77G	MR-J5W-FAN3
MR-J5W2-1010G	IMIT-05VV-I AINO
MR-J5W3-222G	MR-J5W-FAN2
MR-J5W3-444G	WIN-USVV-FAINZ
MR-J5D1-500G4	
MR-J5D1-700G4	
MR-J5D2-200G4	MR-J5D-FAN1
MR-J5D2-350G4	
MR-J5D3-200G4	
MR-J5D2-500G4	MR-J5D-FAN2
MR-J5D2-700G4	WIN-JOU-FAINZ


Cabinet-Mounting Attachment (J5-CHP07-10P)

G G-RJ WG A A-RJ

G G-RJ A A-RJ

The cabinet-mounting attachment is used when a servo amplifier is mounted on a cabinet with a screwdriver. A screw can be tightened horizontally at the upper side of the servo amplifier.


Compatible model: MR-J5-350G_/A_ or smaller/MR-J5W_/MR-CM3K



Grounding Terminal Attachment (J5-CHP08)

The grounding terminal attachment extends grounding terminals to the front side of the servo amplifier and clamps cables at the front side.

Compatible servo amplifier: MR-J5-350G_/A_ or smaller



Notes: 1. For a bundle diameter other than that of the attachment, aluminum clamps in ALC series (manufactured by Takeuchi Industry Co., Ltd.) can be used.

2. When a battery (MR-BAT6V1SET or MR-BAT6V1SET-A) is used, the grounding terminal attachment cannot be used.

Mounting Attachment DG

Power regeneration converter unit attachment

Attach a mounting attachment to a power regeneration converter unit.

Power regeneration Attachment model			dimensi	ons [mm]	Dimension with		
converter unit model	Attachment model	D	Da	Db	Dc	attachment [Unit: mm]		
MR-CV11K4 MR-CV18K4	MR-ADCACN090	280	80	255.5	258.5	D Da 23		
MR-CV30K4 MR-CV37K4 MR-CV45K4	MR-ADCACN150					000		
MR-CV55K4 MR-CV75K4	MR-ADCACN300	310	110	285.5	288.5	Db Dc		


Drive unit attachment

Select a drive unit attachment that supports a power regeneration converter unit to be connected.

Power regeneration converter unit model Drive unit model	MR-CV11K4 MR-CV18K4	MR-CV30K4 MR-CV37K4 MR-CV45K4 MR-CV55K4 MR-CV75K4	Dimension with attachment
MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	Attachment not required	MR-ADACN060	310
MR-J5D2-500G4 MR-J5D2-700G4	Attachment not required	MR-ADACN075	288.5

Side Protection Cover (MR-J5DCASE01)

By attaching a side protection cover to the outside of the final drive unit, the terminal block conforms to IP20.



DG

Notes: 1. Attaching the side protection cover does not change the dimensions of the drive unit.

7-56


Precautions


[Products on the Market]

Junction Terminal Block (DG2SV3TB), Servo Amplifier Connection Cable (DG4SV2CB_)

G G-R

This terminal block is used for wiring signals.






[Products on the Market]

Junction Terminal Block (PS7DW-20V14B-F)

G G-RJ


This terminal block is used for wiring signals.



Junction Terminal Block (MR-TB26A)

WG

This terminal block is used for wiring signals.




Notes: 1. The lengths in brackets are applicable when the junction terminal block is mounted on a 35 mm wide DIN rail.

Junction Terminal Block (MR-TB50)

A A-RJ


This terminal block is used for wiring signals.




[Products on the Market]

Junction Terminal Block (DG2SV1TB), Servo Amplifier Connection Cable (DG4SV1CB_) A A-RJ

This terminal block is used for wiring signals.





Mitsubishi Electric Engineering Co., Ltd.

Applicable wire: 1.5 mm² maximum (Wire insulator OD: ø2.8 mm or smaller)

Support


G-RJ WG A A-RJ

G G-RJ WG DG A

G G-RJ WG A A-RJ


Radio Noise Filter (FR-BIF, FR-BIF-H)

This filter suppresses noise from the power supply side of the servo amplifier, especially effective for the radio frequency bands of 10 MHz or lower. The radio noise filter is designed to be installed on the input side.



Line Noise Filter (FR-BSF01, FR-BLF)

This filter is effective in suppressing noise emitted from the power supply side or the output side of the servo amplifier, and also in suppressing high-frequency leakage current (zero-phase current), especially within 0.5 MHz to 5 MHz band.



Data Line Filter

This filter is effective in preventing noise when attached to the pulse output cable of the pulse train output controller or the motor

Example) ESD-SR-250 (manufactured by TOKIN Corporation) ZCAT3035-1330 (manufactured by TDK) GRFC-13 (manufactured by Kitagawa Industries Co., Ltd.) E04SRM563218 (manufactured by Seiwa Electric Mfg. Co., Ltd.)

Surge Killer

G G-RJ WG DG A A-RJ Attach surge killers to AC relays and AC valves around the servo amplifier. Attach diodes to DC relays and DC valves.

Surge killer: CR-50500 (manufactured by Okaya Electric Industries Co., Ltd.)

Diode: A diode with breakdown voltage four or more times greater than the relay drive voltage, and with current capacity two or more times greater than the relay drive current.

EMC Filter G G-RJ WG DG A A-RJ

For servo amplifiers

The following filters are recommended as a filter compliant with the EMC directive for the power supply of the servo amplifier.

A surge protector is separately required to use the filters. Refer to "MR-J5 User's Manual" for details.

Fulfill the following requirements when connecting one or more units of servo amplifiers to one EMC filter.

- Rated voltage [V] of EMC filter ≥ Rated input voltage [V] of servo amplifier
- Rated current [A] of EMC filter ≥ Total rated input current [A] of servo amplifiers connected to EMC filter

		EMC filter						
Operating environment	Total length of servo motor power cables	Model	Rated current [A]	Rated voltage [V AC]	Operating temperature [°C]	Mass [kg]	Fig.	Manufacturer
		FSB-10-254-HU	10					
		FSB-20-254-HU	20	250	-40 to 85	1.8	Α	COSEL Co., Ltd.
IEC/EN 61800-3		FSB-30-254-HU	30	250				
Category C2/C3 (Note 1)	50 m or shorter	FSB-40-324-HU	40			3.3	В	
		FSB-10-355	10	500		1.8	Α	
		FSB-20-355	20	300		1.0		
		HF3010C-SZB	10	500	-20 to 50	0.9		
		HF3020C-SZB	20			1.3	E	
		HF3030C-SZB	30	300	-20 10 50	1.3		
IEC/EN 61800-3		HF3040C-SZB	40			2.0	F	Soshin Electric Co., Ltd.
Category C3 (Note 1)	100 m or shorter	HF3030C-SZL	30			1.3	G	308iliii Electric Co., Ltd.
	200 m or shorter	HF3060C-SZL	60	500	-20 to 50	2.1	G	
	250 m or shorter	HF3100C-SZL	100	500	-20 10 50	5.8	Н	
	250 m or shorter	HF3150C-SZL	150			9.0	I	

For power regeneration converter units

The following filters are recommended as a filter compliant with the EMC directive for the power supply of the power regeneration converter unit.

A surge protector is separately required to use the filters. Refer to "MR-CV Power Regeneration Converter Unit User's Manual" for details.

Fulfill the following requirements when connecting one or more power regeneration converter units to one EMC filter.


- Rated voltage [V] of EMC filter ≥ Rated input voltage [V] of power regeneration converter unit
- Rated current [A] of EMC filter ≥ Total rated input current [A] of power regeneration converter units connected to EMC filter

	EMC filter							
Operating environment	Model curre [A]		Rated voltage [V AC]	Operating temperature [°C]	Mass [kg]	Fig.	Manufacturer	
	FSB-20-355	20			1.8	А		
	FSB-30-355	30		-40 to 85	1.0		COSEL Co., Ltd.	
IEC/EN 61800-3	FSB-40-355	40	500		3.3	В		
Category C2, C3 (Note 1)	FSB-80-355	80			6.3	С		
	FSB-100-355	100			0.5			
	FSB-150-355	150			8.8	D		
	HF3030C-SZL	30			1.3	G		
IEC/EN 61800-3	HF3060C-SZL	60	500	-20 to 50	2.1	G	Soshin Electric Co., Ltd.	
Category C3 (Note 1)	HF3100C-SZL	100	500	-20 10 50	5.8	Н		
	HF3150C-SZL	150			9.0	I	1	

Notes: 1. Category C2: Intended to be installed in either the first environment (residential environment) by a professional or in the second environment (commercial, light industrial, and industrial environments).

Category C3: Intended to be installed in the second environment (commercial, light industrial, and industrial environments).

Support



Attach surge protectors of RSPD series (manufactured by Okaya Electric Industries Co., Ltd.) or LT-CS-WS series (manufactured by Soshin Electric Co., Ltd.) to the servo amplifiers.

Precautions

Power Factor Improving DC Reactor (FR-HEL, FR-HEL-H)

G-RJ A A-RJ


This boosts the power factor of servo amplifier and reduces the power supply capacity. Use either the DC reactor or the AC reactor.

As compared to the AC reactor (FR-HAL, FR-HAL-H), the DC reactor (FR-HEL, FR-HEL-H) is more recommended since the DC reactor is more effective in power factor improvement, smaller and lighter, and its wiring is easier. (The DC reactor uses two wires, while the AC reactor uses six wires.)

Connections

Servo amplifier model	Power factor improving DC reactor model	Fig.	
MR-J5-10G/A	model		
MR-J5-20G/A	FR-HEL-0.4K		
MR-J5-40G/A	FR-HEL-0.75K		
MR-J5-60G/A	ED LIEL 4 EK	Α	
MR-J5-70G/A	FR-HEL-1.5K		
MR-J5-100G/A	FR-HEL-2.2K		
MR-J5-200G/A	FR-HEL-3.7K		
MR-J5-350G/A	FR-HEL-7.5K	В	
MR-J5-500G/A	FR-HEL-11K	Ь	
MR-J5-700G/A	FR-HEL-15K		
MR-J5-60G4/A4	FR-HEL-H1.5K	С	
MR-J5-100G4/A4	FR-HEL-H2.2K	C	
MR-J5-200G4/A4	FR-HEL-H3.7K	D	
MR-J5-350G4/A4	FR-HEL-H7.5K	<i>D</i>	






Notes: 1. Disconnect a short-circuit bar between P3 and P4 when using the power factor improving DC reactor.


Dimensions

Α

В



Model	Variabl	e dimer	nsions [r	nm]		Mass Terminal Wire size (Not					
lviodei	W	W1	Н	D	d	[kg]	screw size	[mm ²]			
FR-HEL-0.4K	70	60	71	61	M4	0.4	M4	2 (AWG 14)			
FR-HEL-0.75K	85	74	81	61	M4	0.5	M4	2 (AWG 14)			
FR-HEL-1.5K	85	74	81	70	M4	0.8	M4	2 (AWG 14)			
FR-HEL-2.2K	85	74	81	70	M4	0.9	M4	2 (AWG 14)			



Model	Varia	ble di	mensi	ons [r	nm]				Mass	lass Terminal Wire size (Note				
iviodei	W	W1	Н	D	D1	D2	D3	d	[kg]	screw size	[mm ²]			
FR-HEL-3.7K	77	55	92	82	66	57	37	M4	1.5	M4	2 (AWG 14)			
FR-HEL-7.5K	86	60	113	98	81	72	43	M4	2.5	M5	3.5 (AWG 12)			
FR-HEL-11K	105	64	133	112	92	79	47	M6	3.3	M6	5.5 (AWG 10)			
FR-HEL-15K	105	64	133	115	97	84	48.5	M6	4.1	M6	8 (AWG 8)			

Notes: 1. Use this mounting hole for grounding.

- 2. This indicates the maximum dimension. The dimension varies depending on the bending degree of the input/output lines.

 3. The wire size is applicable when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used.

Options/Peripheral Equipment

Power Factor Improving DC Reactor (FR-HEL, FR-HEL-H) G G-RJ A A-RJ Dimensions 0000 D or shorter (D3) С Terminal Variable dimensions [mm] Wire size (Note 2) Mass Model screw W D1 D2 D3 d [kg] [mm²] size FR-HEL-H1.5K 66 50 100 80 74 54 37 M4 1.0 M3.5 2 (AWG 14) W1 FR-HEL-H2.2K 76 2 (AWG 14) 50 110 80 74 54 37 M4 1.3 M3.5 D or shorter (D3) D Variable dimensions [mm] Mass Wire size (Note 2) Model screw [mm²] [kg] D D1 D3 size

FR-HEL-H3.7K 86

FR-HEL-H7.5K 96

55

60

120 95

89 69 45

128 105 100 80

M4 2.3 M4

50

M5 3.5

M4

2 (AWG 14)

2 (AWG 14)

Notes:

W1

1. Use this mounting hole for grounding.
 2. The wire size is applicable when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used.

D1±1

Precautions

This boosts the power factor of servo amplifier and reduces the power supply capacity.

MR-J5-G/A, MR-CM3K

Servo amplifier/ simple converter model	Power factor improving AC reactor model (Note 2)	Fig.
MR-J5-10G/A	FR-HAL-0.4K	
MR-J5-20G/A	FR-HAL-0.4K	
MR-J5-40G/A	FR-HAL-0.75K	
MR-J5-60G/A	ED HAL 4 EK	
MR-J5-70G/A	FR-HAL-1.5K	
MR-J5-100G/A		
(3-phase power	FR-HAL-2.2K	
supply input)		^
MR-J5-100G/A		Α
(1-phase power		
supply input)	FR-HAL-3.7K	
MR-J5-200G/A		
(3-phase power		
supply input)		
MR-J5-200G/A		
(1-phase power	FR-HAL-5.5K	
supply input)		
MR-J5-350G/A	FR-HAL-7.5K	
MR-CM3K	I H-HAL-7.5K	_
MR-J5-500G/A	FR-HAL-11K	В
MR-J5-700G/A	FR-HAL-15K	
MR-J5-60G4/A4	FR-HAL-H1.5K	
MR-J5-100G4/A4	FR-HAL-H2.2K	С
MR-J5-200G4/A4	FR-HAL-H3.7K	
MR-J5-350G4/A4	FR-HAL-H7.5K	D

MR-J5W2-G (Note 1)

Total output of rotary servo motors	Total continuous thrust of linear servo motors	Total output of direct	Power factor improving AC reactor model (Note 2)	Fig.
450 W or less	150 N or less	100 W or less	FR-HAL-0.75K	
Over 450 W to 600 W	Over 150 N to 240 N	Over 100 W to 377 W	FR-HAL-1.5K	^
Over 600 W to 1 kW	Over 240 N to 300 N	Over 377 W to 545 W	FR-HAL-2.2K	Α
Over 1 kW to 2 kW	Over 300 N to 720 N	Over 545 W to 838 W	FR-HAL-3.7K	

MR-J5W3-G (Note 1)

Total output of rotary servo motors	Total continuous thrust of linear servo motors	Total output of direct drive motors	Power factor improving AC reactor model (Note 2)	Fig.
450 W or less	150 N or less	-	FR-HAL-0.75K	
Over 450 W to 600 W	Over 150 N to 240 N	378 W or less	FR-HAL-1.5K	_
Over 600 W to 1 kW	Over 240 N to 300 N	-	FR-HAL-2.2K	А
Over 1 kW to 2 kW	Over 300 N to 450 N	-	FR-HAL-3.7K	


Notes: 1. Refer to "MR-J5 User's Manual" for selecting a power factor improving AC reactor when combining multiple servo motors among the rotary servo motor, the linear servo motor or the direct drive motor.

motor or the direct drive motor.


2. When using the power factor improving AC reactor, install one reactor for each servo amplifier.

Connections

3-phase 200 V AC 3-phase 400 V AC




1-phase 200 V AC





Notes: 1. Connect the power supply to L1 and L3 terminals. Do not connect anything

Power Factor Improving AC Reactor (FR-HAL, FR-HAL-H)

G G-RJ WG A A-RJ







D2


RXSYTZ

. W1

W±2

4-d mounting hole (Note 1) (ø5 groove)

Madal	Variable dimensions [mm] Mass Term								Terminal
Model	W	W1	Н	D	D1	D2	d	[kg]	screw size
FR-HAL-H1.5K	135	120	115	59	59.6	45	M4	1.5	M3.5
FR-HAL-H2.2K	135	120	115	59	59.6	45	M4	1.5	M3.5
FR-HAL-H3.7K	135	120	115	69	70.6	57	M4	2.5	M3.5




Model	Variable	e dimens	sions [mr	m]				Mass Terminal				
Model	W	W1	Н	D	D1	D2	d	[kg]	screw size			
FR-HAL-H7.5K	160	145	142	91	91	75	M4	5.0	M4			


Notes: 1. Use this mounting hole for grounding.

2. This indicates the maximum dimension. The dimension varies depending on the bending degree of the input/output lines.

С

110 1100010101 (1111		
Power regeneration converter unit model	AC reactor model	Fig.
MR-CV11K4	MR-AL-11K4	
MR-CV18K4	MR-AL-18K4	
MR-CV30K4	MR-AL-30K4	
MR-CV37K4	MR-AL-37K4	A
MR-CV45K4	MR-AL-45K4	
MR-CV55K4	MR-AL-55K4	
MR-CV75K4	MR-AL-75K4	





Model	Variable	e dimens	Mass	Terminal				
	W	D	Н	W1	Х	d	[kg]	screw size
MR-AL-11K4	145	175	155	75	55	M6	3.7	M5
MR-AL-18K4	145	175	155	105	55	M6	5.3	M6
MR-AL-30K4	145	175	155	110	55	M6	6.0	M6
MR-AL-37K4	150	215	175	110	70	M6	8.5	M6
MR-AL-45K4	160	215	175	120	70	M6	9.8	M6
MR-AL-55K4	230	220	210	120	200	M8	10.5	M6
MR-AL-75K4	230	250	215	143	230	M8	13.0	M6

Options/Peripheral Equipment

Servo Support Software Drive System Sizing Software Motorizer

Specifications

Item	Description						
Types of motor/drive Servo, Inverter, Sensorless servo							
Types of load mechanism	Ball screw, Rack and pinion, Roll feed, Rotary table, Cart, Elevator/Hoist, Conveyor, Fan, Pump, Crank, Generic (Rotary), Generic (Linear), Linear servo						
Types of transmission mechanism Coupling, External gear reducer, V belt and pulley, Toothed belt/roller chain							
Operation pattern	Constant speed/Pause, Acceleration/Deceleration, Trapezoid, Triangle, Speed CSV File, MELSOFT GX LogViewer file						
Types of input support of moment of inertia calculation function	Solid cylinder, Hollow cylinder, Disk, Rectangular solid, Truncated cone, Sphere, Generic						
Sizing results	Result, Motor type, Power supply voltage, Motor, Motor capacity, Drive, Drive capacity, Effective torque, Torque effective load rate, Peak torque, Peak load rate, Effective torque at stop, Effective load rate at stop, Motor output, Motor output rate, Maximum speed, Maximum speed rate, Maximum load inertia moment, Inertia moment ratio, Regenerative power, Regenerative load ratio, Regenerative option, Maximally increased torque, Rated speed, Brake, Oil seal, Structure specification, Graph of Motor side speed/Motor side torque/Motor output						
Printing of output of results	Prints load mechanism, transmission mechanism, operation pattern, and sizing results.						
Data saving	Load mechanism, transmission mechanism, operation pattern, motor selection, drive selection, and sizing results are saved with a file name.						

Operating environment (Note 1)

Item	Description						
	Microsoft® Windows® 10 (64-bit/32-bit)						
OS	Microsoft® Windows® 8.1 (64-bit/32-bit)						
	Microsoft® Windows® 7 (64-bit/32-bit) [Service Pack1 or later]						
.NET Framework	.NET Framework 4.6 or later						
CPU	Desktop PC: Intel® Celeron® processor 2.4 GHz or more recommended						
CFO	Laptop PC: Intel® Pentium® processor 1.9 GHz or more recommended						
Memory	1 GB or more recommended (32-bit OS)						
Memory	2 GB or more recommended (64-bit OS)						
Free hard disk space	For installation: 1 GB or more free hard disk capacity						
Free flard disk space	For operation: 512 MB or more free virtual memory capacity						
Monitor	Resolution 1024 × 768 or more (XGA)						
WOULD	Compatible with above personal computers						

Notes: 1. This software may not run correctly on some personal computers.

Precautions

Servo Support Software MR Configurator2 (SW1DNC-MRC2-E) (Note 1)

MR Configurator2 can be obtained by either of the following:

- · Purchase MR Configurator2 alone.
- Purchase GX Works3 or MT Works2: MR Configurator2 is included in GX Works3 and MT Works2 with software version 1.34L or later.
- Download MR Configurator2: If you have MELSOFT iQ Works, GX Works3, GX Works2, MT Works2, EM Software Development Kit, or CW Configurator, MR Configurator2 is available for free download.

Specification (Note 2)

Item	Description
Project	New/Open/Save/Save As/Delete Project, Read Other Format, Write Other Format, System Setting, Print
Parameter	Parameter setting, network parameter, axis name setting, parameter converter
Safety	Safety parameter setting, Change password, Initialize password
Positioning-data	Point Table, Program, Indirect Addressing, Cam Data
Monitor	Display All, I/O Monitor, Graph, ABS Data Display, Object Monitor
Diagnosis	Alarm Display, Alarm Onset Data, Drive recorder, No Motor Rotation, System Configuration, Life Diagnosis, Machine Diagnosis, Linear Diagnosis, Fully Closed Loop Diagnosis, Gear Failure Diagnosis, Encoder Communication Diagnosis
Test Operation	JOG Operation, Positioning Operation, Motor-Less Operation, DO Forced Output, Program Operation, Single-Step Feed, Test Operation Information
Adjustment	One-Touch Tuning, Tuning, Machine Analyzer, Advanced Gain Search
Others	Servo Assistant, Update Parameter Setting Range, Machine Unit Conversion Setting, Switch Display Language, Help

1. MELSERVO-J5 series is supported by MR Configurator2 with software version 1.100E or later.

2. Supported items vary depending on the servo amplifiers. Refer to "MR Configurator2 SW1DNC-MRC2-E Installation Guide" for details.

Operating environment (Note 1)

Description			
Microsoft® Windows® 10 Education	Microsoft® Windows® 7 Enterprise		
Microsoft® Windows® 10 Enterprise	Microsoft® Windows® 7 Ultimate		
Microsoft® Windows® 10 Pro	Microsoft® Windows® 7 Professional		
Microsoft® Windows® 10 Home	Microsoft® Windows® 7 Home Premium		
Microsoft® Windows® 8.1 Enterprise	Microsoft® Windows® 7 Starter		
Microsoft® Windows® 8.1 Pro			
Microsoft® Windows® 8.1			
Microsoft® Windows® 8 Enterprise			
Microsoft® Windows® 8 Pro			
Microsoft® Windows® 8			
Desktop PC: Intel® Celeron® processor 2	2.8 GHz or more		
Laptop PC: Intel® Pentium® M processor	r 1.7 GHz or more		
1 GB or more (32-bit OS), 2 GB or more	e (64-bit OS)		
1.5 GB or more	1.5 GB or more		
Resolution 1024 x 768 or more, 16-bit high color,			
Compatible with above personal comput	ters		
MR-J3USBCBL3M			
	Microsoft® Windows® 10 Education Microsoft® Windows® 10 Enterprise Microsoft® Windows® 10 Pro Microsoft® Windows® 10 Home Microsoft® Windows® 8.1 Enterprise Microsoft® Windows® 8.1 Pro Microsoft® Windows® 8.1 Microsoft® Windows® 8 Enterprise Microsoft® Windows® 8 Pro Microsoft® Windows® 8 Pro Microsoft® Windows® 8 Desktop PC: Intel® Celeron® processor 2 Laptop PC: Intel® Pentium® M processor 1 GB or more (32-bit OS), 2 GB or more 1.5 GB or more Resolution 1024 × 768 or more, 16-bit h Compatible with above personal compu	Microsoft® Windows® 10 Education Microsoft® Windows® 7 Enterprise Microsoft® Windows® 10 Enterprise Microsoft® Windows® 7 Ultimate Microsoft® Windows® 10 Pro Microsoft® Windows® 7 Professional Microsoft® Windows® 10 Home Microsoft® Windows® 7 Home Premium Microsoft® Windows® 8.1 Enterprise Microsoft® Windows® 7 Starter Microsoft® Windows® 8.1 Pro Microsoft® Windows® 8.1 Pro Microsoft® Windows® 8 Enterprise Microsoft® Windows® 8 Pro Microsoft® Windows® 8 Pro Microsoft® Windows® 8 Pro Microsoft® Windows® 8 Desktop PC: Intel® Celeron® processor 2.8 GHz or more Laptop PC: Intel® Pentium® M processor 1.7 GHz or more 1 GB or more (32-bit OS), 2 GB or more (64-bit OS) 1.5 GB or more Resolution 1024 × 768 or more, 16-bit high color, Compatible with above personal computers	

Notes: 1. This software may not run correctly on some personal computers.

Options/Peripheral Equipment

Unit Conversion Table

Quantity	SI (metric) unit	U.S. customary unit
Mass	1 [kg]	2.2046 [lb]
Length	1 [mm]	0.03937 [in]
Torque	1 [N•m]	141.6 [oz•in]
Moment of inertia	1 [(× 10 ⁻⁴ kg•m²)]	5.4675 [oz•in²]
Load (thrust load/axial load)	1 [N]	0.2248 [lbf]
Temperature	n [°C]	n × 9/5 + 32 [°F]

Low-Voltage Switchgear/ Wires

Wires, Molded-Case Circuit Breakers, and Magnetic Contactors	.8-2
Selection Example Compliant with IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274	.8-5
Type E Combination Motor Controller	.8-8
Selection Example in HIV Wires for Servo Motors	.8-9

G MR-J5-G(-N1) G-RJ MR-J5-G-RJ(N1) WG MR-J5W2-G(-N1)/MR-J5W3-G(-N1)

DG MR-J5D1-G4(-N1)/MR-J5D2-G4(-N1)/MR-J5D3-G4(-N1) A MR-J5-A A-RJ MR-J5-A-RJ

^{*} Note that low-voltage switchgears/wires necessary for servo amplifiers/drive units with special specifications are the same as those for standard servo amplifiers/drive units. Refer to the servo amplifiers/drive units with the same rated output.

^{*} Refer to p. 7-70 in this catalog for conversion of units.

Wires, Molded-Case Circuit Breakers, and Magnetic Contactors

G G-RJ A A-RJ

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used. The wire size for U/V/W/E varies depending on the servo motor. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for details on wires for each servo motor.

Wires and molded-case circuit breakers (MR-J5-G/MR-J5-A)

Servo amplifier model	Molded-case circuit breaker	Wire size [mm²] (Note 4)			
Servo ampimer moder (Note	(Note 4, 5, 6)	L1/L2/L3/	L11/L21	P+/C (Note 1)	U/V/W/E
MR-J5-10G/A	30 A frame 5 A (30 A frame 5 A)				
MR-J5-20G/A	30 A frame 5 A (30 A frame 5 A)			2 (AWG 14)	
MR-J5-40G/A	30 A frame 10 A (30 A frame 5 A)				
MR-J5-60G/A	30 A frame 15 A (30 A frame 10 A)				0.75 to 2 (AWG 18 to 14) (Note 3)
MR-J5-70G/A	30 A frame 15 A (30 A frame 10 A)	2 (AWG 14)	1.25 to 2 (AWG 16 to 14)		
MR-J5-100G/A (3-phase power input)	30 A frame 15 A (30 A frame 10 A)				
MR-J5-100G/A (1-phase power input)	30 A frame 15 A (30 A frame 15 A)				
MR-J5-200G/A (3-phase power input)	30 A frame 20 A (30 A frame 20 A)				
MR-J5-200G/A (1-phase power input)	30 A frame 20 A (30 A frame 20 A)	-3.5 (AWG 12)			0.75 to 5.5 (AWG 18 to 10) (Note 3)
MR-J5-350G/A	30 A frame 30 A (30 A frame 30 A)	-3.5 (AWG 12)	10)		
MR-J5-500G/A	50 A frame 50 A (50 A frame 50 A)	5.5 (AWG 10)			0.75 to 8
MR-J5-700G/A	100 A frame 75 A (60 A frame 60 A)	8 (AWG 8)			(AWG 18 to 8) (Note 3)

Wires and molded-case circuit breakers (MR-J5-G4/MR-J5-A4)

Servo amplifier model	Molded-case circuit breaker	Wire size [mm²] (Note 4)			
	(Note 4, 5, 6)	L1/L2/L3/	L11/L21	P+/C (Note 1)	U/V/W/E
MR-J5-60G4/A4	30 A frame 5 A (30 A frame 5 A)	-	1.25 to 2 (AWG 16 to 14)	2 (AWG 14)	0.75 to 2 (AWG 18 to 14) (Note 3)
MR-J5-100G4/A4	30 A frame 10 A (30 A frame 5 A)				
MR-J5-200G4/A4	30 A frame 15 A (30 A frame 10 A)	2 (AWG 14)			
MR-J5-350G4/A4	30 A frame 20 A (30 A frame 15 A)				

Magnetic contactors (MR-J5-G/MR-J5-A)

	Magnetic contactor (Note 2, 5)		
Servo amplifier model	On/off of main circuit power supply		
	AC power supply	DC power supply	
MR-J5-10G/A			
MR-J5-20G/A			
MR-J5-40G/A		SD-T12	
MR-J5-60G/A	S-T10		
MR-J5-70G/A			
MR-J5-100G/A			
MR-J5-200G/A		SD-T21	
MR-J5-350G/A	S-T21	3D-121	
MR-J5-500G/A	S-T25	SD-T35	
MR-J5-700G/A	S-T35	SD-T50	

Magnetic contactors (MR-J5-G4/MR-J5-A4)

	Magnetic contactor (Note 2, 5)		
Servo amplifier model	On/off of main circuit power supply		
	AC power supply	DC power supply	
MR-J5-60G4/A4			
MR-J5-100G4/A4	S-T10	SD-T12	
MR-J5-200G4/A4			
MR-J5-350G4/A4	S-T21	SD-T21	

Notes: 1. Keep the wire length to the regenerative option within 5 m.

- 2. Use a magnetic contactor with an operation delay time of 80 ms or less. The operation delay time is the time interval from current being applied to the coil until closure of contacts.
- 3. The wire size shows applicable size for the servo amplifier connector.
- 4. When complying with IEC/EN/UL/CSA standard, refer to "Selection Example Compliant with IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274" in this catalog.

 5. These selection examples are for when one molded-case circuit breaker and one magnetic contactor are installed for one unit of servo amplifier. When connecting multiple
- These selection examples are for when one molded-case circuit breaker and one magnetic contactor are installed for one unit of servo amplifier. When connecting multiple units of servo amplifiers, refer to "MR-J5 User's Manual".
- 6. When using a power improving reactor, use a molded-case circuit breaker listed in the brackets.

Support

Wires, Molded-Case Circuit Breakers, and Magnetic Contactors

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used. The wire size for U/V/W/E varies depending on the servo motor. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for details on wires for each servo motor.

Wires (MR-J5W2-G/MR-J5W3-G)

Com to amountified mandal	Wire size [mm²] (Note 3)			
Servo amplifier model	L1/L2/L3/	L11/L21	P+/C (Note 5)	U/V/W/E
MR-J5W2-22G				
MR-J5W2-44G				
MR-J5W2-77G	2 (4)4(0,14)	2 (4)4(5,14)	2 (4)4(0.14)	0.75 to 2
MR-J5W2-1010G	2 (AWG 14)	2 (AWG 14)	2 (AWG 14)	(AWG 18 to 14) (Note 2)
MR-J5W3-222G				
MR-J5W3-444G				

Molded-case circuit breakers (MR-J5W2-G) (Note 4)

Total output of rotary servo motors	Total continuous thrust of linear servo motors	Total output of direct drive motors	Molded-case circuit breaker (Note 3, 6)
300 W or less	-	-	30 A frame 5 A
Over 300 W to 600 W	150 N or less	100 W or less	30 A frame 10 A
Over 600 W to 1 kW	Over 150 N to 300 N	Over 100 W to 252 W	30 A frame 15 A
Over 1 kW to 2 kW	Over 300 N to 720 N	Over 252 W to 838 W	30 A frame 20 A

Magnetic contactor (MR-J5W2-G) (Note 4)

	Total continuous thrust of linear servo motors		Magnetic contactor (Note 1, 6)	
		Total output of direct drive motors	On/off of main circuit power supply	
motors	linear servo motors		AC power supply	DC power supply
300 W or less	-	-		
Over 300 W to 600 W	150 N or less	100 W or less	S-T10	SD-T11
Over 600 W to 1 kW	Over 150 N to 300 N	Over 100 W to 252 W		
Over 1 kW to 2 kW	Over 300 N to 720 N	Over 252 W to 838 W	S-T21	SD-T21

Molded-case circuit breakers (MR-J5W3-G) (Note 4)

Total output of rotary servo motors	Total continuous thrust of linear servo motors	Total output of direct drive motors	Molded-case circuit breaker (Note 3, 6)
450 W or less	150 N or less	-	30 A frame 10 A
Over 450 W to 800 W	Over 150 N to 300 N	252 W or less	30 A frame 15 A
Over 800 W to 1.5 kW	Over 300 N to 450 N	Over 252 W to 378 W	30 A frame 20 A

Magnetic contactor (MR-J5W3-G) (Note 4)

Total output of rotary servo motors Total continuou linear servo motors	Total continuous thrust of	Total output of direct drive motors On/off of main circuit powe		(Note 1, 6)
				it power supply
	linear servo motors	A	AC power supply	DC power supply
450 W or less	150 N or less	-	S-T10	SD-T11
Over 450 W to 800 W	Over 150 N to 300 N	252 W or less	3-110	30-111
Over 800 W to 1.5 kW	Over 300 N to 450 N	Over 252 W to 378 W	S-T21	SD-T21

Notes: 1. Use a magnetic contactor with an operation delay time of 80 ms or less. The operation delay time is the time interval from current being applied to the coil until closure of contacts.

- 2. The wire size shows applicable size for the servo amplifier connector.
- 3. When complying with IEC/EN/UL/CSA standard, refer to "Selection Example Compliant with IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274" in this catalog.
- 4. When multiple different types of servo motors (rotary servo motor, linear servo motor, or direct drive motor) are connected to the multi-axis servo amplifier, refer to "MR-J5 User's Manual" for selecting a molded-case circuit breaker and a magnetic contactor.
- 5. Keep the wire length to the regenerative option within 5 m.
- 6. These selection examples are for when one molded-case circuit breaker and one magnetic contactor are installed for one unit of servo amplifier. When connecting multiple units of servo amplifiers, refer to "MR-J5 User's Manual".

Wires, Molded-Case Circuit Breakers, and Magnetic Contactors

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used. The wire size for U/V/W/E varies depending on the servo motor. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for details on wires for each servo motor.

Wires (MR-J5D1-G4/MR-J5D2-G4/MR-J5D3-G4)

Drive unit model (Note 1)	Wire size [mm²] (Note 2, 3)		
Drive unit moder (1888 1)	L11/L21/@	U/V/W/E	
MR-J5D1-100G4		4.05.4.0	
MR-J5D1-200G4		1.25 to 2 (AWG 16 to 14)	
MR-J5D1-350G4		(AVVG 10 to 14)	
MR-J5D1-500G4		3.5 (AWG 12)	
MR-J5D1-700G4		5.5 (AWG 10)	
MR-J5D2-100G4	1.25 to 5.5		
MR-J5D2-200G4	(AWG 16 to 10) (Note 8)	1.25 to 2 (AWG 16 to 14)	
MR-J5D2-350G4		(AVVG 10 to 14)	
MR-J5D2-500G4		3.5 (AWG 12)	
MR-J5D2-700G4		5.5 (AWG 10)	
MR-J5D3-100G4		1.25 to 2	
MR-J5D3-200G4		(AWG 16 to 14)	

Wires (MR-CM3K)

G	G-RJ	WG	Α	A-RJ

Simple converter unit	Wire size [mm ²] (Note 2, 3)	
model	L1/L2/L3/	P4/N-
MR-CM3K	3.5 (AWG 12)	3.5 (AWG 12)

Molded-case circuit breaker and magnetic contactor (MR-CM3K)

Simple converter unit model		Molded-case circuit breaker	Magnetic contactor (Note 4, 6) On/off of main circuit power	Magnetic contactor (Note 4, 6) On/off of main circuit power supply	
		(Note 3, 5, 6)	AC power supply	DC power supply	
MR-CM3K	Less than 2 kW	30 to 125 A frame 15 to 20 A (30 to 125 A frame 15 to 20 A)	S-T21	SD-T21	
	2 kW or over	30 to 125 A frame 20 to 30 A (30 to 125 A frame 20 to 30 A)	S-T21	SD-T21	

Wires, molded-case circuit breaker, and magnetic contactor (MR-CV_4)

DG

Power regeneration converter unit	Molded-case circuit	Magnetic contactor (Note 4, 6)	Wire size [mm²] (Note 2, 3)	
model (Note 1)	breaker (Note 3, 6)		L1/L2/L3/@	L11/L21
MR-CV11K4	30 A frame 30 A	S-T21	5.5 (AWG 10)	
MR-CV18K4	50 A frame 50 A	S-T35	8 (AWG 8)	
MR-CV30K4	100 A frame 80 A	S-T65	14 (AWG 6)	1 05 +- 0
MR-CV37K4	100 A frame 100 A	S-T80	22 (AWG 4)	1.25 to 2 (AWG 16 to 14)
MR-CV45K4	125 A frame 125 A	S-T100	22 (AVVG 4)	(AVVG 10 to 14)
MR-CV55K4	225 A frame 150 A	S-N125	38 (AWG 2)	
MR-CV75K4	225 A frame 200 A	S-N150	60 (AWG 2/0)	

Notes: 1. When connecting the wires to the terminal blocks, use the screws attached to the terminal blocks.

- 2. Wires are selected based on the highest rated current among the servo motors to be combined.
- 3. When complying with IEC/EN/UL/CSA standard, refer to "Selection Example Compliant with IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274" in this catalog.
- 4. Use a magnetic contactor with an operation delay time of 80 ms or less. The operation delay time is the time interval from current being applied to the coil until closure of contacts.
- When using a power improving reactor, use a molded-case circuit breaker listed in the brackets.
- 6. Install one molded-case circuit breaker and one magnetic contactor for one converter unit.
- 7. The sum of rated capacities [kW] of connected servo amplifiers ≤ 3 kW (MR-CM3K rated output)

 When using a multi-axis servo amplifier, calculate the sum of the rated capacities of all axes as the rated capacity of the servo amplifier.
- 8. The National Electrical Code recommends that the wire size should be a minimum of AWG 14 (2 mm²).

G G-RJ WG A A-RJ

DG

Selection Example Compliant with IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274

The following are examples of molded-case circuit breakers and semiconductor fuses selected on the basis of the rated inputs/outputs of the servo amplifiers or the converter units.

Servo amplifier model	Molded-case circuit breaker (240 V AC) SCCR 50 kA (Mitsubishi Electric)	Semiconductor fuse (700 V) SCCR 100 kA (BUSSMAN)	
MR-J5-10G/A			
MR-J5-20G/A			
MR-J5-40G/A		170M1408 (10 A)	
MR-J5-60G/A (3-phase power input)			
MR-J5-60G/A (1-phase power input)	NE405 0\/LL454 (405 A frame o 45 A)	170M1409 (16 A)	
MR-J5-70G/A (3-phase power input)	NF125-SVU-15A (125 A frame 15 A)	170M1408 (10 A)	
MR-J5-70G/A (1-phase power input)		170M1409 (16 A)	
MR-J5-100G/A (3-phase power input)		170W1409 (16 A)	
MR-J5-100G/A (1-phase power input)		170M1412 (32 A)	
MR-J5-200G/A (3-phase power input)			
MR-J5-200G/A (1-phase power input)	NF125-SVU-20A (125 A frame 20 A)	170M1413 (40 A)	
MR-J5-350G/A	NF 125-5 VO-20A (125 A frame 20 A)	170W1413 (40 A)	
MR-J5-500G/A	NF125-SVU-30A (125 A frame 30 A) (Note 1)	170M1415 (63 A)	
MR-J5-700G/A	NF125-SVU-40A (125 A frame 40 A) (Note 1)	170M1416 (80 A)	
MR-J5W2-22G (3-phase power input)		170M1408 (10 A)	
MR-J5W2-22G (1-phase power input)		170M1409 (16 A)	
MR-J5W2-44G (3-phase power input)	NF125-SVU-15A (125 A frame 15 A)	170111400 (10 A)	
MR-J5W2-44G (1-phase power input)		170M1412 (32 A)	
MR-J5W2-77G (3-phase power input)		1701011412 (02 A)	
MR-J5W2-77G (1-phase power input)	NF125-SVU-20A (125 A frame 20 A)	170M1413 (40 A)	
MR-J5W2-1010G		170M1412 (32 A)	
MR-J5W3-222G (3-phase power input)	NF125-SVU-15A (125 A frame 15 A)	170M1409 (16 A)	
MR-J5W3-222G (1-phase power input)	141 125 5 V G 15A (125 A II alie 15 A)	170M1412 (32 A)	
MR-J5W3-444G (3-phase power input)		17 OWITH 2 (OZ A)	
MR-J5W3-444G (1-phase power input)	NF125-SVU-20A (125 A frame 20 A)	170M1413 (40 A)	

Molded-case circuit breakers/semiconductor fuses (MR-J5-G4/MR-J5-A4)

morada dado direan breaner	ordering ordered rades (initiated a minitiate)	All)
Conta amplifiar model	Molded-case circuit breaker (480 V AC)	Semiconductor fuse (700 V)
Servo amplifier model	SCCR 30 kA (Mitsubishi Electric)	SCCR 100 kA (BUSSMAN)
MR-J5-60G4/A4		170M1408 (10 A)
MR-J5-100G4/A4	NET OF CVIII 15 A (105 A frame 15 A) (Note 1)	170W1408 (10 A)
MR-J5-200G4/A4	NF125-SVU-15A (125 A frame 15 A) (Note 1)	170M1409 (16 A)
MR-J5-350G4/A4		170M1412 (32 A)

Molded-case circuit breakers/semiconductor fuses (MR-CM3K)

Simple converter unit model	Total capacity of	Molded-case circuit breaker (240 V AC)	Semiconductor fuse (700 V)
Simple converter unit moder	servo amplifiers	SCCR 50 kA (Mitsubishi Electric)	SCCR 100 kA (BUSSMAN)
	Less than 2 kW	NF125-SVU-15A	170M1400 (16.4)
MR-CM3K	Less than 2 KVV	(125 A frame 15 A)	170M1409 (16 A)
	0.1414/ 0.11.011	NF125-SVU-20A	170141410 (40.4)
	2 kW or over	(125 A frame 20 A)	170M1413 (40 A)

Semiconductor fuses (MR-CV_4)

Power regeneration	Semiconductor fuse (700 V)
converter unit model (Note 2)	SCCR 100 kA (BUSSMAN)
MR-CV11K4	170M1413 (40 A)
MR-CV18K4	170M1416 (80 A)
MR-CV30K4	170M1419 (160 A)
MR-CV37K4	170W1419 (160 A)
MR-CV45K4	170M1420 (200 A)
MR-CV55K4	170M1421 (250 A)
MR-CV75K4	170M1422 (315 A)

Notes: 1. When using the servo amplifiers for a machine that is required to comply with UL/CSA standards, use semiconductor fuses.

^{2.} When connecting the wires to the terminal blocks, use the screws attached to the terminal blocks.

Low-Voltage Switchgear/Wires

Selection Example Compliant with IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274

The following are examples of recommended wire sizes selected on the basis of the rated inputs/outputs of the servo amplifiers.

Recommended wires (MR-J5-0	G/MR-J5W2-G/MR-J	5W3-G/MR-J5-A)	G G-RJ	WG A A-RJ
Comic amountifier mandal	75 °C stranded wire [AWG]			
Servo amplifier model	L1/L2/L3/@	L11/L21	P+/C	U/V/W/E
MR-J5-10G/A				
MR-J5-20G/A				
MR-J5-40G/A				
MR-J5-60G/A	14			14
MR-J5-70G/A				14
MR-J5-100G/A				
MR-J5-200G/A (3-phase power input)				
MR-J5-200G/A (1-phase power input)	12			
MR-J5-350G/A	12	14	14	12
MR-J5-500G/A	10			8
MR-J5-700G/A	8			0
MR-J5W2-22G				
MR-J5W2-44G				
MR-J5W2-77G	14			14
MR-J5W2-1010G	14			14
MR-J5W3-222G				
MR-J5W3-444G				
Recommended wires (MR-J5-0	G4/MR-J5-A4)		G	G-RJ A A-RJ
Convo amplifier model	75 °C stranded wire [AW	G]		
Servo amplifier model	L1/L2/L3/	L11/L21	P+/C	U/V/W/E
MR-J5-60G4/A4				
MR-J5-100G4/A4	14	14	14	14
MR-J5-200G4/A4] 14	14		14
MR-J5-350G4/A4				

G G-RJ WG A A-RJ

DG

Selection Example Compliant with IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274

The following are examples of recommended wire sizes selected on the basis of the rated inputs/outputs of the drive units and the converter units.

Recommended wires (MR-J5D1-G4/MR-J5D2-G4/MR-J5D3-G4)

DG

Drive unit model (Note 1)	75 °C stranded wire [AWG]		
Drive unit model (************************************	L11/L21/⊕	U/V/W/E	0
MR-J5D1-100G4			-
MR-J5D1-200G4		14	-
MR-J5D1-350G4			
MR-J5D1-500G4		12	
MR-J5D1-700G4		10	
MR-J5D2-100G4	14		
MR-J5D2-200G4	14	14	
MR-J5D2-350G4			
MR-J5D2-500G4		12	
MR-J5D2-700G4		10	
MR-J5D3-100G4		14	3
MR-J5D3-200G4		14	5

Recommended wires (MR-CM3K)

Simple converter unit model	75 °C stranded wire [AWG]		
Simple converter unit model	L1/L2/L3/ (P4/N-	
MR-CM3K	14/12 (Note 2)	14/12 ^(Note 2)	

Recommended wires (MR-CV_4)

Power regeneration	75 °C stranded wire [AWG]		
converter unit model (Note 1)	L1/L2/L3/⊕	L11/L21	
MR-CV11K4	10		
MR-CV18K4	8		
MR-CV30K4	6		
MR-CV37K4	4	14	
MR-CV45K4	74		
MR-CV55K4	2		
MR-CV75K4	1/0		

Notes: 1. When connecting the wires to the terminal blocks, use the screws attached to the terminal blocks.

^{2.} The wire size varies depending on a total current of connected servo amplifiers. When the total current is larger than 12 A, use AWG 12.

Low-Voltage Switchgear/Wires

Type E Combination Motor Controller

G G-RJ WG A A-RJ

The Type E Combination Motor Controller is comprised of the Manual Motor Starter, Short-circuit Display Unit "UT-TU", and Power Side Terminal Cover Kit "UT-CV3".

	D		Manual Motor Starter				
Serve amplitier	Rated input voltage AC [V]	Input phase (Note 2)	Model	Data database AO DA	Rated current [A]	SCCR [kA] (Note 1)	
	voitage AC [v]		(Mitsubishi Electric)	Rated voltage AC [V]	(Heater design)		
MR-J5-10G/A					1.6		
MR-J5-20G/A					2.5		
MR-J5-40G/A					4		
MR-J5-60G/A					6.3	50	
MR-J5-70G/A					6.3		
MR-J5-100G/A					8		
MR-J5-200G/A					18		
MR-J5-350G/A	200 to 240	3-phase	MMP-T32	240	25	25	
MR-J5-500G/A (Note 3)					32	25	
MR-J5W2-22G					6.3		
MR-J5W2-44G					8		
MR-J5W2-77G					13	50	
MR-J5W2-1010G					18	50	
MR-J5W3-222G	1				8		
MR-J5W3-444G]				13		

1. The value is applicable when the Type E Combination Motor Controller is combined with the servo amplifier. 2. 1-phase power input is not supported. Notes:

^{3.} When using the servo amplifiers for a machine that is required to comply with UL/CSA standards, use semiconductor fuses.

Selection Example in HIV Wires for Servo Motors

G G-RJ WG DG A A-RJ

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) with a length of 30 m are used.

Rotary servo motor model		Wire size [mm²] (Note 6)		
notary servo motor me	odei	For power and grounding (U/V/W/E)	For electromagnetic brake (B1/B2)	
	HK-KT053W			
	HK-KT13W			
	HK-KT1M3W			
	HK-KT13UW			
	HK-KT23W			
	HK-KT43W			
	HK-KT63W			
	HK-KT23UW	0.75 (AWG 18) (Note 1, 2, 3)		
HK-KT_W	HK-KT43UW			
	HK-KT7M3W			
	HK-KT103W			
	HK-KT63UW			
	HK-KT7M3UW		0.0 (4) 4/0.0 (1) (4) (4) (5)	
	HK-KT103UW		0.2 (AWG 24) (Note 4, 5)	
	HK-KT153W			
	HK-KT203W	0.75 (AWG 18) (Note 1, 3, 7)		
	HK-KT202W			
	HK-KT434W			
	HK-KT634W			
	HK-KT7M34W			
	HK-KT1034W			
HK-KT_4_W	HK-KT634UW	0.75 (AWG 18) (Note 1, 2, 3)		
	HK-KT1034UW			
	HK-KT1534W			
	HK-KT2034W			
	HK-KT2024W			
	HK-MT053W			
	HK-MT13W			
	HK-MT1M3W			
	HK-MT23W			
HK-MT_W	HK-MT43W			
	HK-MT63W			
	HK-MT7M3W			
	HK-MT103W		2 2 (1) 1/2 2 1) 1/4 1/5	
	HK-MT053VW	0.75 (AWG 18) (Note 1, 2, 3)	0.2 (AWG 24) (Note 4, 5)	
	HK-MT13VW			i i
	HK-MT1M3VW			
LUZ NAT. NOW	HK-MT23VW			
HK-MT_VW	HK-MT43VW			
	HK-MT63VW			
	HK-MT7M3VW			
	HK-MT103VW			

1. Use fluorine resin wires of 0.75 mm² (AWG 18) for wiring to the servo motor power supply. Notes:

- 2. This size is applicable for wiring length of 10 m or shorter. For over 10 m, use MR-AEPB2J10CBL03M-_-L, MR-AEP2J10CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, or MR-AEP2J20CBL03M-_-L, and extend it with HIV wires of 1.25 mm² (AWG 16).
- 3. Use a cable provided by Mitsubishi Electric or Mitsubishi Electric System & Service Co., Ltd. When fabricating a cable, select wires applicable for the usage. The National Electrical Code recommends that the wire size should be a minimum of AWG 14 (2 mm²).
- 4. Use fluorine resin wires of 0.2 mm² (AWG 24) for wiring to the electromagnetic brake.
- 5. This size is applicable for wiring length of 10 m or shorter. For over 10 m, extend the wires with HIV wires of 1.25 mm² (AWG 16).
- 6. The same wire size is applicable when the torques are increased.
- 7. This size is applicable for wiring length of 10 m or shorter. For over 10 m, use MR-AEPB2J10CBL03M-_-L, MR-AEP2J10CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, or MR-AEP2J20CBL03M-_-L, and extend it with HIV wires of 2 mm2 (AWG 14).

Low-Voltage Switchgear/Wires

Selection Example in HIV Wires for Servo Motors

G	G-RJ	WG	DG	Α	A-RJ
---	------	----	----	---	------

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) with a length of 30 m are used. Refer to "Rotary Servo Motor User's Manual" when using cab-tire cables for supplying power (U/V/W) to HK-ST or HK-RT series.

Detam con company model		Wire size [mm²] (Note 6)			
Rotary servo motor mode	II	For power and grounding (U/V/W/E)	For electromagnetic brake (B1/B2)		
	HK-ST52W	1.25 (AWG 16) (Note 5)			
	HK-ST102W	1.25 (AWG 16) (Note 5)			
	HK-ST172W	2 (AWG 14)			
	HK-ST202AW	2 (AWG 14)			
	HK-ST302W	2 (AWG 14)			
HK-ST_W (Note 7)	HK-ST353W	3.5 (AWG 12)	1.25 (AWG 16)		
	HK-ST503W	3.5 (AWG 12) (Note 8)			
	HK-ST202W	2 (AWG 14)			
	HK-ST352W	3.5 (AWG 12)			
	HK-ST502W	8 (AWG 8)			
	HK-ST702W	8 (AWG 8)			
	HK-ST524W	1.25 (AWG 16) (Note 5)			
	HK-ST1024W	1.25 (AWG 16) (Note 5)			
	HK-ST1724W	1.25 (AWG 16) (Note 5)			
	HK-ST2024AW	1.25 (AWG 16) (Note 5)			
	HK-ST3024W	1.25 (AWG 16) (Note 5)			
HK-ST_4_W (Note 7)	HK-ST3534W	2 (AWG 14)	1.25 (AWG 16)		
	HK-ST5034W	2 (AWG 14)			
	HK-ST2024W	1.25 (AWG 16) (Note 5)			
	HK-ST3524W	2 (AWG 14)			
	HK-ST5024W	3.5 (AWG 12)			
	HK-ST7024W	3.5 (AWG 12)			
	HK-RT103W	0.75 (AWG 18) (Note 1, 2, 5)			
	HK-RT153W	0.75 (AWG 18) (Note 1, 3, 5)	0.2 (AWG 24) (Note 4, 9)		
HK-RT W	HK-RT203W	0.75 (AVVG 16) (1888 1, 5, 5)			
UK-UI_W	HK-RT353W	3.5 (AWG 12)			
	HK-RT503W	5.5 (AWG 10)	1.25 (AWG 16)		
	HK-RT703W	5.5 (AWG 10)			
	HK-RT1034W				
	HK-RT1534W	0.75 (AWG 18) (Note 1, 2, 5)	0.2 (AWG 24) (Note 4, 9)		
LUZ DT. AM	HK-RT2034W				
HK-RT_4W	HK-RT3534W	1.25 (AWG 16) (Note 5)			
	HK-RT5034W	2 (AWG 14)	1.25 (AWG 16)		
	HK-RT7034W	2 (AWG 14)			

- Notes: 1. Use fluorine resin wires of 0.75 mm² (AWG 18) for wiring to the servo motor power supply.

 2. This size is applicable for wiring length of 10 m or shorter. For over 10 m, use MR-AEPB2J10CBL03M-_-L, MR-AEP2J10CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, or MR-AEP2J20CBL03M-_-L, and extend it with HIV wires of 1.25 mm² (AWG 16).
 - 3. This size is applicable for wiring length of 10 m or shorter. For over 10 m, use MR-AEPB2J10CBL03M-_-L, MR-AEP2J10CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, or MR-AEP2J20CBL03M-_-L, and extend it with HIV wires of 2 mm2 (AWG 14).
 - 4. Use fluorine resin wires of 0.2 mm² (AWG 24) for wiring to the electromagnetic brake.
 - 5. The National Electrical Code recommends that the wire size should be a minimum of AWG 14 (2 mm²). Refer to "Rotary Servo Motor User's Manual" for details.
 - 6. The same wire size is applicable when the torques are increased.
 - 7. Wires for HK-ST152(4)G1/G1H/G5/G7 geared servo motors are the same as those for HK-ST172(4)W.
 - 8. When using HK-ST503W for a machine that is required to comply with UL/CSA standards, use a cable (SC-PWC403C_M-SBLL or SC-PWC403C_M-SBLH) manufactured by Mitsubishi Electric System & Service Co., Ltd., and fabricate an extension cable with wires of AWG 10. For details of SC-PWC403C_M-SBLL and SC-PWC403C_M-SBLH, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
 - 9. This size is applicable for wiring length of 10 m or shorter. For over 10 m, extend the wires with HIV wires of 1.25 mm² (AWG 16).

Selection Example in HIV Wires for Servo Motors

30 m are used.

Common Specifications of

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

Selection Example in HIV Wires for Servo Motors	G	G-RJ	WG	Α	A-RJ
The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride in	sulated	wires (HI	/ wires)	with a le	ength of

Linear servo motor model		Wire size [mm²]		
Primary side		For power and grounding (U/V/W/E)	For thermistor (G1/G2)	
LM-H3P2A-07P-BSS0		1.25 (AWG 16) (Note 1)		
LM-H3P3A-12P-CSS0		1.25 (AWG 16) (Note 1)		
LM-H3P3B-24P-CSS0		1.25 (AWG 16) (Note 1)		
LM-H3P3C-36P-CSS0		1.25 (AWG 16) (Note 1)		
LM-H3P3D-48P-CSS0		2 (AWG 14)		
LM-H3P7A-24P-ASS0		1.25 (AWG 16) (Note 1)		
LM-H3P7B-48P-ASS0		2 (AWG 14)		
LM-H3P7C-72P-ASS0		2 (AWG 14)		
LM-H3P7D-96P-ASS0		3.5 (AWG 12)		
LM FDOD OGM 1000	Natural cooling	2 (AMC 14)		
LM-FP2B-06M-1SS0	Liquid cooling	2 (AWG 14)		
LM FD0D 10M 1000	Natural cooling	2 (AWG 14)		
LM-FP2D-12M-1SS0	Liquid cooling	3.5 (AWG 12)		
LM FD0F 10M 1000	Natural cooling	2 (AWG 14)		
LM-FP2F-18M-1SS0	Liquid cooling	3.5 (AWG 12) (Note 3)		
LM FD4D 40M 4000	Natural cooling	E E (AMO 40)	0.0 (AMC 04)	
LM-FP4B-12M-1SS0	Liquid cooling	5.5 (AWG 10)	0.2 (AWG 24)	
LM FRAR CAMA ACCO	Natural cooling	5 5 (AMO 40)		
LM-FP4D-24M-1SS0	Liquid cooling	5.5 (AWG 10)		
LM-K2P1A-01M-2SS1		1.25 (AWG 16) (Note 1)		
LM-K2P1C-03M-2SS1		2 (AWG 14)		
LM-K2P2A-02M-1SS1		1.25 (AWG 16) (Note 1)		
LM-K2P2C-07M-1SS1		3.5 (AWG 12)		
LM-K2P2E-12M-1SS1		5.5 (AWG 10)		
LM-K2P3C-14M-1SS1		3.5 (AWG 12)		
LM-K2P3E-24M-1SS1		5.5 (AWG 10)		
LM-U2PAB-05M-0SS0, LM-U2PAD-	-10M-0SS0,			
LM-U2PAF-15M-0SS0, LM-U2PBB-	07M-1SS0,	1.25 (AWG 16) (Note 1)		
LM-U2PBD-15M-1SS0, LM-U2PBF-	-22M-1SS0			
LM-U2P2B-40M-2SS0		2 (AWG 14)		
LM-U2P2C-60M-2SS0		3.5 (AWG 12)		
LM-U2P2D-80M-2SS0		5.5 (AWG 10)		
Linear servo motor model		Wire size [mm²]		
Primary side		For power and grounding (U/V/W/E)	For thermal protector	—
LM-AJP1B-07K-JSS0		To power and grounding (6/1/1/1/2)	Tor thermal protector	—
LM-AJP1D-14K-JSS0		-		
		-		_
LM-AJP2B-12S-JSS0		-		
LM-AJP2D-23T-JSS0		1.25 (AWG 16) (Note 1)	0.2 (AWG 24)	
LM-AJP3B-17N-JSS0		_		
LM-AJP3D-35R-JSS0		-		
LM-AJP4B-22M-JSS0		_		
LM-AJP4D-45N-JSS0				_
		Wire size [mm²]		
Direct drive motor model		For power and grounding (LI/V/M/F)		

Direct drive motor model	Wire size [mm ²]
Direct drive motor model	For power and grounding (U/V/W/E)
TM-RG2M002C30, TM-RG2M004E30, TM-RG2M009G30, TM-RU2M002C30, TM-RU2M004E30, TM-RU2M009G30	0.75 (AWG 18) (Note 1, 2)
TM-RFM002C20, TM-RFM004C20, TM-RFM006C20,	
TM-RFM006E20, TM-RFM012E20, TM-RFM018E20,	1.25 (AWG 16) (Note 1)
TM-RFM012G20	
TM-RFM048G20, TM-RFM072G20	3.5 (AWG 12)
TM-RFM040J10	1.25 (AWG 16) (Note 1)
TM-RFM120J10	3.5 (AWG 12)
TM-RFM240J10	5.5 (AWG 10)

- Notes: 1. The National Electrical Code recommends that the wire size should be a minimum of AWG 14 (2 mm²). Refer to the servo motor User's Manual for details.

 - The same wire size is applicable when the torques are increased.
 Use a wire which has a heat resistance temperature of 105 °C for wiring to the servo motor power supply.

Servo system controllers

Item	Model	Application		
	RD78G4	Maximum number of control axes: 4 axes	CC-Link IE TSN master station	
	RD78G8	Maximum number of control axes: 8 axes	CC-Link IE TSN master station	
	RD78G16	Maximum number of control axes: 16 axes	CC-Link IE TSN master station	
	RD78G32	Maximum number of control axes: 32 axes	CC-Link IE TSN master station	
Motion module	RD78G64	Maximum number of control axes: 64 axes	CC-Link IE TSN master station	
	RD78GHV	Maximum number of control axes: 128 axes	CC-Link IE TSN master station	
	RD78GHW	Maximum number of control axes: 256 axes	CC-Link IE TSN master station	
	FX5-40SSC-G	Maximum number of control axes: 4 axes	CC-Link IE TSN master station	
	FX5-80SSC-G	Maximum number of control axes: 8 axes	CC-Link IE TSN master station	
Motion Control Software (Note 1)	CWADNIN CWMC M	SWM-G Engine SWM-G Operating Station		
Motion Control Software	SVV IDININ-SVVIVIG-IVI	• SWM-G API • CC-Link IE TSN Configurator • Real Time OS (RTX64)		
	MR-SWMG16-U	Maximum number of control axes: 16 axes, USB key (license)		
USB key for Motion Control	MR-SWMG32-U	Maximum number of control axes: 32 axes, USB key (license)		
Software	MR-SWMG64-U	Maximum number of control axes: 64 axes, USB key (license)		
23	MR-SWMG128-U	Maximum number of control axes: 128 axes, USB key (license)		

Notes:

Engineering software

Item	Model	Application
MELSOFT iQ Works	SW2DND-IQWK-E	FA Engineering Software
MELSOFT GX Works3	SW1DND-GXW3-E	Programmable Controller Engineering Software (including motion control setting)

^{1.} Download and install Motion Control Software from Mitsubishi Electric FA global website.

Servo amplifiers

Item		Model	Rated output	Main circuit power supply	7	
		MR-J5-10G	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC		
		MR-J5-20G	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_ :	
		MR-J5-40G	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
		MR-J5-60G	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
Servo amplifier	200 V	MR-J5-70G	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_ 0	
MR-J5-G	class	MR-J5-100G	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
		MR-J5-200G	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
		MR-J5-350G	3.5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
		MR-J5-500G	5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
		MR-J5-700G	7 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC		
		MR-J5-60G4	0.6 kW	3-phase 380 V AC to 480 V AC	_ 3	
Servo amplifier	400 V	MR-J5-100G4	1 kW	3-phase 380 V AC to 480 V AC		
MR-J5-G4	class	MR-J5-200G4	2 kW	3-phase 380 V AC to 480 V AC		
		MR-J5-350G4	3.5 kW	3-phase 380 V AC to 480 V AC	_	
		MR-J5-10G-RJ	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Motors	
		MR-J5-20G-RJ	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	<u> </u>	
		MR-J5-40G-RJ	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
		MR-J5-60G-RJ	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
Servo amplifier	200 V	MR-J5-70G-RJ	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC		
MR-J5-G-RJ	class	MR-J5-100G-RJ	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
		MR-J5-200G-RJ	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	- F	
		MR-J5-350G-RJ	3.5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Ldalbillelie	
		MR-J5-500G-RJ	5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC		
		MR-J5-700G-RJ	7 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
		MR-J5-60G4-RJ	0.6 kW	3-phase 380 V AC to 480 V AC		
Servo amplifier	400 V	MR-J5-100G4-RJ	1 kW	3-phase 380 V AC to 480 V AC	_	
MR-J5-G4-RJ	class	MR-J5-200G4-RJ	2 kW	3-phase 380 V AC to 480 V AC	_	
		MR-J5-350G4-RJ	3.5 kW	3-phase 380 V AC to 480 V AC		
		MR-J5W2-22G	0.2 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	-	
Servo amplifier	200 V	MR-J5W2-44G	0.4 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
MR-J5W2-G	class	MR-J5W2-77G	0.75 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC		
		MR-J5W2-1010G	1 kW x 2 axes	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC		
Servo amplifier	200 V	MR-J5W3-222G	0.2 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	
MR-J5W3-G	class	MR-J5W3-444G	0.4 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_	

Servo amplifiers

Item		Model	Rated output	Main circuit power supply
		MR-J5-10G-N1	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-20G-N1	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-40G-N1	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-60G-N1	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5-70G-N1	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5-G-N1	class	MR-J5-100G-N1	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-200G-N1	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-350G-N1	3.5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-500G-N1	5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-700G-N1	7 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-60G4-N1	0.6 kW	3-phase 380 V AC to 480 V AC
Servo amplifier	400 V	MR-J5-100G4-N1	1 kW	3-phase 380 V AC to 480 V AC
MR-J5-G4-N1	class	MR-J5-200G4-N1	2 kW	3-phase 380 V AC to 480 V AC
		MR-J5-350G4-N1	3.5 kW	3-phase 380 V AC to 480 V AC
		MR-J5-10G-RJN1	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-20G-RJN1	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-40G-RJN1	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-60G-RJN1	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5-70G-RJN1	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5-G-RJN1	class	MR-J5-100G-RJN1	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-200G-RJN1	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-350G-RJN1	3.5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-500G-RJN1	5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-700G-RJN1	7 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-60G4-RJN1	0.6 kW	3-phase 380 V AC to 480 V AC
Servo amplifier	400 V	MR-J5-100G4-RJN1	1 kW	3-phase 380 V AC to 480 V AC
MR-J5-G4-RJN1	class	MR-J5-200G4-RJN1	2 kW	3-phase 380 V AC to 480 V AC
		MR-J5-350G4-RJN1	3.5 kW	3-phase 380 V AC to 480 V AC
		MR-J5W2-22G-N1	0.2 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5W2-44G-N1	0.4 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5W2-G-N1	class	MR-J5W2-77G-N1	0.75 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5W2-1010G-N1	1 kW x 2 axes	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5W3-222G-N1	0.2 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5W3-G-N1	class	MR-J5W3-444G-N1	0.4 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC

Drive units

Item		Model	Rated output	Main circuit power supply
		MR-J5D1-100G4	1 kW	
Deive veit	400.14	MR-J5D1-200G4	2 kW	
Drive unit MR-J5D1-G4	400 V class	MR-J5D1-350G4	3.5 kW	Main circuit power is supplied from the power regeneration converter unit to the drive unit.
WIX-33D 1-04	Class	MR-J5D1-500G4	5 kW	Converter unit to the drive unit.
		MR-J5D1-700G4	7 kW	
		MR-J5D2-100G4	1 kW x 2 axes	
D: "	400.14	MR-J5D2-200G4	2 kW x 2 axes	
Drive unit MR-J5D2-G4	400 V class	MR-J5D2-350G4	3.5 kW x 2 axes	Main circuit power is supplied from the power regeneration converter unit to the drive unit.
WIN-33D2-04	Class	MR-J5D2-500G4	5 kW x 2 axes	converter unit to the drive unit.
		MR-J5D2-700G4	7 kW x 2 axes	
Drive unit	400 V	MR-J5D3-100G4	1 kW x 3 axes	Main circuit power is supplied from the power regeneration
MR-J5D3-G4	class	MR-J5D3-200G4	2 kW x 3 axes	converter unit to the drive unit.
		MR-J5D1-100G4-N1	1 kW	
D: "	400.14	MR-J5D1-200G4-N1	2 kW	
Drive unit MR-J5D1-G4-N1	400 V class	MR-J5D1-350G4-N1	3.5 kW	Main circuit power is supplied from the power regeneration converter unit to the drive unit.
WIX-33D 1-04-N 1	Class	MR-J5D1-500G4-N1	5 kW	converter unit to the drive unit.
		MR-J5D1-700G4-N1	7 kW	
		MR-J5D2-100G4-N1	1 kW x 2 axes	
D: "	400.14	MR-J5D2-200G4-N1	2 kW x 2 axes	
Drive unit MR-J5D2-G4-N1	400 V class	MR-J5D2-350G4-N1	3.5 kW x 2 axes	Main circuit power is supplied from the power regeneration converter unit to the drive unit.
WIK-J3D2-G4-N1	ciass	MR-J5D2-500G4-N1	5 kW x 2 axes	converter unit to the drive unit.
		MR-J5D2-700G4-N1	7 kW x 2 axes	
Drive unit	400 V	MR-J5D3-100G4-N1	1 kW x 3 axes	Main circuit power is supplied from the power regeneration
MR-J5D3-G4-N1	class	MR-J5D3-200G4-N1	2 kW x 3 axes	converter unit to the drive unit.

Servo amplifiers

Item		Model	Rated output	Main circuit power supply
		MR-J5-10A	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-20A	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-40A	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-60A	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5-70A	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5-A	class	MR-J5-100A	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-200A	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-350A	3.5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-500A	5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-700A	7 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-60A4	0.6 kW	3-phase 380 V AC to 480 V AC
Servo amplifier	400 V	MR-J5-100A4	1 kW	3-phase 380 V AC to 480 V AC
MR-J5-A4	class	MR-J5-200A4	2 kW	3-phase 380 V AC to 480 V AC
		MR-J5-350A4	3.5 kW	3-phase 380 V AC to 480 V AC
		MR-J5-10A-RJ	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-20A-RJ	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-40A-RJ	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-60A-RJ	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5-70A-RJ	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5-A-RJ	class	MR-J5-100A-RJ	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-200A-RJ	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-350A-RJ	3.5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-500A-RJ	5 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-700A-RJ	7 kW	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-60A4-RJ	0.6 kW	3-phase 380 V AC to 480 V AC
Servo amplifier	400 V	MR-J5-100A4-RJ	1 kW	3-phase 380 V AC to 480 V AC
MR-J5-A4-RJ	class	MR-J5-200A4-RJ	2 kW	3-phase 380 V AC to 480 V AC
		MR-J5-350A4-RJ	3.5 kW	3-phase 380 V AC to 480 V AC

Converter units

Item		Model	Rated output	Main circuit power supply
Simple converter MR-CM	200 V class	MR-CM3K	3 kW	3-phase 200 V AC to 240 V AC
		MR-CV11K4	11 kW	3-phase 380 V AC to 480 V AC
		MR-CV18K4	18 kW	3-phase 380 V AC to 480 V AC
Power regeneration	400.17	MR-CV30K4	30 kW	3-phase 380 V AC to 480 V AC
converter unit	400 V class	MR-CV37K4	37 kW	3-phase 380 V AC to 480 V AC
MR-CV	Class	MR-CV45K4	45 kW	3-phase 380 V AC to 480 V AC
		MR-CV55K4	55 kW	3-phase 380 V AC to 480 V AC
		MR-CV75K4	75 kW	3-phase 380 V AC to 480 V AC

Item		Flange size [mm]	Model	Rated output	Rated speed
	Τ		HK-KT053W(B)	0.05 kW	3000 r/min
		40 x 40	HK-KT13W(B)	0.1 kW	3000 r/min
			HK-KT1M3W(B)	0.15 kW	3000 r/min
			HK-KT13UW(B)	0.1 kW	3000 r/min
		00 00	HK-KT23W(B)	0.2 kW	3000 r/min
		60 x 60	HK-KT43W(B)	0.4 kW	3000 r/min
			HK-KT63W(B)	0.6 kW	3000 r/min
			HK-KT23UW(B)	0.2 kW	3000 r/min
	HK-KT W		HK-KT43UW(B)	0.4 kW	3000 r/min
	_	80 x 80	HK-KT7M3W(B)	0.75 kW	3000 r/min
			HK-KT103W(B)	1.0 kW	3000 r/min
HK-KT series			HK-KT63UW(B)	0.6 kW	3000 r/min
IK-KT Selles			HK-KT7M3UW(B)	0.75 kW	3000 r/min
3: With an electromagnetic			HK-KT103UW(B)	1.0 kW	3000 r/min
brake		90 x 90	HK-KT153W(B)	1.5 kW	3000 r/min
			HK-KT203W(B)	2.0 kW	3000 r/min
			HK-KT202W(B)	2.0 kW	2000 r/min
			HK-KT434W(B)	0.4 kW	3000 r/min
		60 x 60	HK-KT634W(B)	0.6 kW	3000 r/min
			HK-KT7M34W(B)	0.75 kW	3000 r/min
	HK-KT_4_W	80 x 80	HK-KT1034W(B)	1.0 kW	3000 r/min
		-	HK-KT634UW(B)	0.6 kW	3000 r/min
		90 x 90	` '	1.0 kW	3000 r/min
			HK-KT1034UW(B)	1.5 kW	3000 r/min
			HK-KT1534W(B)		
			HK-KT2034W(B)	2.0 kW	3000 r/min
			HK-KT2024W(B)	2.0 kW	2000 r/min
		40 x 40	HK-KT053W(B)WS	0.05 kW	3000 r/min
			HK-KT13W(B)WS	0.1 kW	3000 r/min
		60 x 60	HK-KT1M3W(B)WS	0.15 kW	3000 r/min
			HK-KT13UW(B)WS	0.1 kW	3000 r/min
			HK-KT23W(B)WS	0.2 kW	3000 r/min
			HK-KT43W(B)WS	0.4 kW	3000 r/min
			HK-KT63W(B)WS	0.6 kW	3000 r/min
			HK-KT23UW(B)WS	0.2 kW	3000 r/min
	HK-KT_W_WS	80 x 80	HK-KT43UW(B)WS	0.4 kW	3000 r/min
			HK-KT7M3W(B)WS	0.75 kW	3000 r/min
Servo motors with functional			HK-KT103W(B)WS	1.0 kW	3000 r/min
afety			HK-KT63UW(B)WS	0.6 kW	3000 r/min
HK-KT series			HK-KT7M3UW(B)WS	0.75 kW	3000 r/min
2: With an alcotromagnetic		90 x 90	HK-KT103UW(B)WS	1.0 kW	3000 r/min
3: With an electromagnetic rake			HK-KT153W(B)WS	1.5 kW	3000 r/min
Turko			HK-KT203W(B)WS	2.0 kW	3000 r/min
			HK-KT202W(B)WS	2.0 kW	2000 r/min
		60 x 60	HK-KT434W(B)WS	0.4 kW	3000 r/min
	1		HK-KT634W(B)WS	0.6 kW	3000 r/min
	1	80 x 80	HK-KT7M34W(B)WS	0.75 kW	3000 r/min
	1		HK-KT1034W(B)WS	1.0 kW	3000 r/min
	HK-KT_4_W_WS		HK-KT634UW(B)WS	0.6 kW	3000 r/min
	1		HK-KT1034UW(B)WS	1.0 kW	3000 r/min
	1	90 x 90	HK-KT1534W(B)WS	1.5 kW	3000 r/min
	1		HK-KT2034W(B)WS	2.0 kW	3000 r/min
		I	HK-KT2024W(B)WS	2.0 kW	2000 r/min

Item		Model		Rated output	Rated speed	Reduction ratio
		HK-KT053(B)G1	1/5	0.05 kW	3000 r/min	1/5
		HK-KT053(B)G1	1/12	0.05 kW	3000 r/min	1/12
		HK-KT053(B)G1	1/20	0.05 kW	3000 r/min	1/20
		HK-KT13(B)G1	1/5	0.1 kW	3000 r/min	1/5
		HK-KT13(B)G1	1/12	0.1 kW	3000 r/min	1/12
HK-KT series		HK-KT13(B)G1	1/20	0.1 kW	3000 r/min	1/20
With a gear reducer for		HK-KT23(B)G1	1/5	0.2 kW	3000 r/min	1/5
general industrial machines	HK-KT_G_	HK-KT23(B)G1	1/12	0.2 kW	3000 r/min	1/12
B: With an electromagnetic		HK-KT23(B)G1	1/20	0.2 kW	3000 r/min	1/20
brake		HK-KT43(B)G1	1/5	0.4 kW	3000 r/min	1/5
		HK-KT43(B)G1	1/12	0.4 kW	3000 r/min	1/12
		HK-KT43(B)G1	1/20	0.4 kW	3000 r/min	1/20
		HK-KT7M3(B)G1	1/5	0.75 kW	3000 r/min	1/5
		HK-KT7M3(B)G1	1/12	0.75 kW	3000 r/min	1/12
		HK-KT7M3(B)G1	1/20	0.75 kW	3000 r/min	1/20
		HK-KT053(B)G5	1/5 (40 x 40)	0.05 kW	3000 r/min	1/5 (flange dimensions: 40 mm x 40 mm)
		HK-KT053(B)G5	1/5 (60 x 60)	0.05 kW	3000 r/min	1/5 (flange dimensions: 60 mm x 60 mm)
		HK-KT053(B)G5	1/9	0.05 kW	3000 r/min	1/9
		HK-KT053(B)G5	1/11	0.05 kW	3000 r/min	1/11
		HK-KT053(B)G5	1/21	0.05 kW	3000 r/min	1/21
		HK-KT053(B)G5	1/33	0.05 kW	3000 r/min	1/33
		HK-KT053(B)G5	1/45	0.05 kW	3000 r/min	1/45
		HK-KT13(B)G5	1/5 (40 x 40)	0.1 kW	3000 r/min	1/5 (flange dimensions: 40 mm x 40 mm)
		HK-KT13(B)G5	1/5 (60 x 60)	0.1 kW	3000 r/min	1/5 (flange dimensions: 60 mm x 60 mm)
		HK-KT13(B)G5	1/11	0.1 kW	3000 r/min	1/11
		HK-KT13(B)G5	1/21	0.1 kW	3000 r/min	1/21
HK-KT series		HK-KT13(B)G5	1/33	0.1 kW	3000 r/min	1/33
With a flange-output type gear		HK-KT13(B)G5	1/45	0.1 kW	3000 r/min	1/45
reducer for high precision applications, flange mounting	HK-KT G	HK-KT23(B)G5	1/5	0.2 kW	3000 r/min	1/5
applications, hange mounting	1110-101_0_	HK-KT23(B)G5	1/11	0.2 kW	3000 r/min	1/11
B: With an electromagnetic		HK-KT23(B)G5	1/21	0.2 kW	3000 r/min	1/21
brake		HK-KT23(B)G5	1/33	0.2 kW	3000 r/min	1/33
		HK-KT23(B)G5	1/45	0.2 kW	3000 r/min	1/45
		HK-KT43(B)G5	1/5	0.4 kW	3000 r/min	1/5
		HK-KT43(B)G5	1/11	0.4 kW	3000 r/min	1/11
		HK-KT43(B)G5	1/21	0.4 kW	3000 r/min	1/21
		HK-KT43(B)G5	1/33	0.4 kW	3000 r/min	1/33
		HK-KT43(B)G5	1/45	0.4 kW	3000 r/min	1/45
		HK-KT7M3(B)G5	1/5	0.75 kW	3000 r/min	1/5
		HK-KT7M3(B)G5	1/11	0.75 kW	3000 r/min	1/11
I				0.75.134/	2000 =/==:=	4/04
		HK-KT7M3(B)G5	1/21	0.75 kW	3000 r/min	1/21
		HK-KT7M3(B)G5 HK-KT7M3(B)G5	1/21	0.75 kW 0.75 kW	3000 r/min	1/33

Item		Model		Rated output	Rated speed	Reduction ratio
		HK-KT053(B)G7	1/5 (40 x 40)	0.05 kW	3000 r/min	1/5 (flange dimensions: 40 mm x 40 mm)
		HK-KT053(B)G7	1/5 (60 x 60)	0.05 kW	3000 r/min	1/5 (flange dimensions: 60 mm x 60 mm)
		HK-KT053(B)G7	1/9	0.05 kW	3000 r/min	1/9
		HK-KT053(B)G7	1/11	0.05 kW	3000 r/min	1/11
		HK-KT053(B)G7	1/21	0.05 kW	3000 r/min	1/21
		HK-KT053(B)G7	1/33	0.05 kW	3000 r/min	1/33
		HK-KT053(B)G7	1/45	0.05 kW	3000 r/min	1/45
		HK-KT13(B)G7	1/5 (40 x 40)	0.1 kW	3000 r/min	1/5 (flange dimensions: 40 mm x 40 mm)
		HK-KT13(B)G7	1/5 (60 x 60)	0.1 kW	3000 r/min	1/5 (flange dimensions: 60 mm x 60 mm)
		HK-KT13(B)G7	1/11	0.1 kW	3000 r/min	1/11
		HK-KT13(B)G7	1/21	0.1 kW	3000 r/min	1/21
HK-KT series	HK-KT_G_	HK-KT13(B)G7	1/33	0.1 kW	3000 r/min	1/33
With a shaft-output type gear		HK-KT13(B)G7	1/45	0.1 kW	3000 r/min	1/45
reducer for high precision applications, flange mounting		HK-KT23(B)G7	1/5	0.2 kW	3000 r/min	1/5
applications, hange mounting		HK-KT23(B)G7	1/11	0.2 kW	3000 r/min	1/11
B: With an electromagnetic		HK-KT23(B)G7	1/21	0.2 kW	3000 r/min	1/21
brake		HK-KT23(B)G7	1/33	0.2 kW	3000 r/min	1/33
		HK-KT23(B)G7	1/45	0.2 kW	3000 r/min	1/45
		HK-KT43(B)G7	1/5	0.4 kW	3000 r/min	1/5
		HK-KT43(B)G7	1/11	0.4 kW	3000 r/min	1/11
		HK-KT43(B)G7	1/21	0.4 kW	3000 r/min	1/21
		HK-KT43(B)G7	1/33	0.4 kW	3000 r/min	1/33
		HK-KT43(B)G7	1/45	0.4 kW	3000 r/min	1/45
		HK-KT7M3(B)G7	1/5	0.75 kW	3000 r/min	1/5
		HK-KT7M3(B)G7	1/11	0.75 kW	3000 r/min	1/11
		HK-KT7M3(B)G7	1/21	0.75 kW	3000 r/min	1/21
		HK-KT7M3(B)G7	1/33	0.75 kW	3000 r/min	1/33
		HK-KT7M3(B)G7	1/45	0.75 kW	3000 r/min	1/45

Item		Flange size [mm]	Model	Rated output	Rated speed
			HK-MT053W(B)	0.05 kW	3000 r/min
		40 x 40	HK-MT13W(B)	0.1 kW	3000 r/min
			HK-MT1M3W(B)	0.15 kW	3000 r/min
	HK-MT W		HK-MT23W(B)	0.2 kW	3000 r/min
	I IIX-IVI I _VV	60 x 60	HK-MT43W(B)	0.4 kW	3000 r/min
			HK-MT63W(B)	0.6 kW	3000 r/min
HK-MT series		80 x 80	HK-MT7M3W(B)	0.75 kW	3000 r/min
			HK-MT103W(B)	1.0 kW	3000 r/min
B: With an electromagnetic		40 x 40	HK-MT053VW(B)	0.05 kW	3000 r/min
brake			HK-MT13VW(B)	0.1 kW	3000 r/min
			HK-MT1M3VW(B)	0.15 kW	3000 r/min
	LUZ NAT NAM		HK-MT23VW(B)	0.2 kW	3000 r/min
	HK-MT_VW	60 x 60	HK-MT43VW(B)	0.4 kW	3000 r/min
			HK-MT63VW(B)	0.6 kW	3000 r/min
		80 x 80	HK-MT7M3VW(B)	0.75 kW	3000 r/min
		00 x 00	HK-MT103VW(B)	1.0 kW	3000 r/min

Item		Flange size [mm]	Model	Rated output	Rated speed
			HK-ST52W(B)	0.5 kW	2000 r/min
			HK-ST102W(B)	1.0 kW	2000 r/min
			HK-ST172W(B)	1.75 kW	2000 r/min
		130 x 130	HK-ST202AW(B)	2.0 kW	2000 r/min
			HK-ST302W(B)	3.0 kW	2000 r/min
	HK-ST_W		HK-ST353W(B)	3.5 kW	3000 r/min
			HK-ST503W(B)	5.0 kW	3000 r/min
			HK-ST202W(B)	2.0 kW	2000 r/min
		176 x 176	HK-ST352W(B)	3.5 kW	2000 r/min
HK-ST series		176 X 176	HK-ST502W(B)	5.0 kW	2000 r/min
			HK-ST702W(B)	7.0 kW	2000 r/min
B: With an electromagnetic			HK-ST524W(B)	0.5 kW	2000 r/min
brake			HK-ST1024W(B)	1.0 kW	2000 r/min
			HK-ST1724W(B)	1.75 kW	2000 r/min
		130 x 130	HK-ST2024AW(B)	2.0 kW	2000 r/min
			HK-ST3024W(B)	3.0 kW	2000 r/min
	HK-ST_4_W		HK-ST3534W(B)	3.5 kW	3000 r/min
			HK-ST5034W(B)	5.0 kW	3000 r/min
		176 x 176	HK-ST2024W(B)	2.0 kW	2000 r/min
			HK-ST3524W(B)	3.5 kW	2000 r/min
			HK-ST5024W(B)	5.0 kW	2000 r/min
			HK-ST7024W(B)	7.0 kW	2000 r/min
			HK-ST52W(B)WS	0.5 kW	2000 r/min
			HK-ST102W(B)WS	1.0 kW	2000 r/min
			HK-ST172W(B)WS	1.75 kW	2000 r/min
		130 x 130	HK-ST202AW(B)WS	2.0 kW	2000 r/min
	HK-ST_W_WS		HK-ST302W(B)WS	3.0 kW	2000 r/min
			HK-ST353W(B)WS	3.5 kW	3000 r/min
			HK-ST503W(B)WS	5.0 kW	3000 r/min
			HK-ST202W(B)WS	2.0 kW	2000 r/min
Servo motors with functional		170 170	HK-ST352W(B)WS	3.5 kW	2000 r/min
safety		176 x 176	HK-ST502W(B)WS	5.0 kW	2000 r/min
HK-ST series			HK-ST702W(B)WS	7.0 kW	2000 r/min
			HK-ST524W(B)WS	0.5 kW	2000 r/min
B: With an electromagnetic			HK-ST1024W(B)WS	1.0 kW	2000 r/min
brake			HK-ST1724W(B)WS	1.75 kW	2000 r/min
		130 x 130	HK-ST2024AW(B)WS	2.0 kW	2000 r/min
			HK-ST3024W(B)WS	3.0 kW	2000 r/min
	HK-ST_4_W_WS		HK-ST3534W(B)WS	3.5 kW	3000 r/min
			HK-ST5034W(B)WS	5.0 kW	3000 r/min
			HK-ST2024W(B)WS	2.0 kW	2000 r/min
		470 470	HK-ST3524W(B)WS	3.5 kW	2000 r/min
		176 x 176	HK-ST5024W(B)WS	5.0 kW	2000 r/min
			HK-ST7024W(B)WS	7.0 kW	2000 r/min

Item		Model	Rated output	Rated speed	Reduction ratio
		HK-ST52(B)G1(H) 1/6	0.5 kW	2000 r/min	1/6
		HK-ST52(B)G1(H) 1/11	0.5 kW	2000 r/min	1/11
		HK-ST52(B)G1(H) 1/17	0.5 kW	2000 r/min	1/17
		HK-ST52(B)G1(H) 1/29	0.5 kW	2000 r/min	1/29
		HK-ST52(B)G1(H) 1/35	0.5 kW	2000 r/min	1/35
		HK-ST52(B)G1(H) 1/43	0.5 kW	2000 r/min	1/43
		HK-ST52(B)G1(H) 1/59	0.5 kW	2000 r/min	1/59
		HK-ST102(B)G1(H) 1/6	1.0 kW	2000 r/min	1/6
		HK-ST102(B)G1(H) 1/11	1.0 kW	2000 r/min	1/11
		HK-ST102(B)G1(H) 1/17	1.0 kW	2000 r/min	1/17
		HK-ST102(B)G1(H) 1/29	1.0 kW	2000 r/min	1/29
		HK-ST102(B)G1(H) 1/35	1.0 kW	2000 r/min	1/35
		HK-ST102(B)G1(H) 1/43	1.0 kW	2000 r/min	1/43
		HK-ST102(B)G1(H) 1/59	1.0 kW	2000 r/min	1/59
		HK-ST152(B)G1(H) 1/6	1.5 kW	2000 r/min	1/6
		HK-ST152(B)G1(H) 1/11	1.5 kW	2000 r/min	1/11
		HK-ST152(B)G1(H) 1/17	1.5 kW	2000 r/min	1/17
		HK-ST152(B)G1(H) 1/29	1.5 kW	2000 r/min	1/29
		HK-ST152(B)G1(H) 1/35	1.5 kW	2000 r/min	1/35
		HK-ST152(B)G1(H) 1/43	1.5 kW	2000 r/min	1/43
		HK-ST152(B)G1(H) 1/59	1.5 kW	2000 r/min	1/59
HK-ST series		HK-ST202(B)G1(H) 1/6	2.0 kW	2000 r/min	1/6
With a gear reducer for		HK-ST202(B)G1(H) 1/11	2.0 kW	2000 r/min	1/11
general industrial machines		HK-ST202(B)G1(H) 1/17	2.0 kW	2000 r/min	1/17
	HK-ST_G_	HK-ST202(B)G1(H) 1/29	2.0 kW	2000 r/min	1/29
B: With an electromagnetic	1111 01_0_	HK-ST202(B)G1(H) 1/35	2.0 kW	2000 r/min	1/35
brake G1: Flange mounting		HK-ST202(B)G1(H) 1/43	2.0 kW	2000 r/min	1/43
G1H: Foot mounting		HK-ST202(B)G1(H) 1/59	2.0 kW	2000 r/min	1/59
OTT. TOOL MOUNTING		HK-ST352(B)G1(H) 1/6	3.5 kW	2000 r/min	1/6
		HK-ST352(B)G1(H) 1/11	3.5 kW	2000 r/min	1/11
		HK-ST352(B)G1(H) 1/17	3.5 kW	2000 r/min	1/17
		HK-ST352(B)G1(H) 1/29	3.5 kW	2000 r/min	1/29
		HK-ST352(B)G1(H) 1/35	3.5 kW	2000 r/min	1/35
		. , , ,	3.5 kW		1/43
		() ()	3.5 kW	2000 r/min 2000 r/min	1/59
		. , , ,	5.0 kW	2000 r/min	1/6
		. , , ,			1/11
		HK-ST502(B)G1(H) 1/11	5.0 kW	2000 r/min	1/17
		HK-ST502(B)G1(H) 1/17	5.0 kW	2000 r/min	
		HK-ST502(B)G1(H) 1/29	5.0 kW	2000 r/min	1/29
		HK-ST502(B)G1(H) 1/35	5.0 kW	2000 r/min	1/35
		HK-ST502(B)G1(H) 1/43	5.0 kW	2000 r/min	1/43
		HK-ST502(B)G1(H) 1/59	5.0 kW	2000 r/min	1/59
		HK-ST702(B)G1(H) 1/6	7.0 kW	2000 r/min	1/6
		HK-ST702(B)G1(H) 1/11	7.0 kW	2000 r/min	1/11
		HK-ST702(B)G1(H) 1/17	7.0 kW	2000 r/min	1/17
		HK-ST702(B)G1(H) 1/29	7.0 kW	2000 r/min	1/29
		HK-ST702(B)G1(H) 1/35	7.0 kW	2000 r/min	1/35
		HK-ST702(B)G1(H) 1/43	7.0 kW	2000 r/min	1/43
		HK-ST702(B)G1(H) 1/59	7.0 kW	2000 r/min	1/59

Rotary servo motors	Rotar	servo	motors
---------------------	-------	-------	--------

tem		Model	Rated output	Rated speed	Reduction ratio
		HK-ST524(B)G1(H) 1/6	0.5 kW	2000 r/min	1/6
		HK-ST524(B)G1(H) 1/11	0.5 kW	2000 r/min	1/11
		HK-ST524(B)G1(H) 1/17	0.5 kW	2000 r/min	1/17
		HK-ST524(B)G1(H) 1/29	0.5 kW	2000 r/min	1/29
		HK-ST524(B)G1(H) 1/35	0.5 kW	2000 r/min	1/35
		HK-ST524(B)G1(H) 1/43	0.5 kW	2000 r/min	1/43
		HK-ST524(B)G1(H) 1/59	0.5 kW	2000 r/min	1/59
		HK-ST1024(B)G1(H) 1/6	1.0 kW	2000 r/min	1/6
		HK-ST1024(B)G1(H) 1/11	1.0 kW	2000 r/min	1/11
		HK-ST1024(B)G1(H) 1/17	1.0 kW	2000 r/min	1/17
		HK-ST1024(B)G1(H) 1/29	1.0 kW	2000 r/min	1/29
		HK-ST1024(B)G1(H) 1/35	1.0 kW	2000 r/min	1/35
		HK-ST1024(B)G1(H) 1/43	1.0 kW	2000 r/min	1/43
		HK-ST1024(B)G1(H) 1/59	1.0 kW	2000 r/min	1/59
		HK-ST1524(B)G1(H) 1/6	1.5 kW	2000 r/min	1/6
		HK-ST1524(B)G1(H) 1/11	1.5 kW	2000 r/min	1/11
		HK-ST1524(B)G1(H) 1/17	1.5 kW	2000 r/min	1/17
		HK-ST1524(B)G1(H) 1/29	1.5 kW	2000 r/min	1/29
		HK-ST1524(B)G1(H) 1/35	1.5 kW	2000 r/min	1/35
		HK-ST1524(B)G1(H) 1/43	1.5 kW	2000 r/min	1/43
		HK-ST1524(B)G1(H) 1/59	1.5 kW	2000 r/min	1/59
K-ST series		HK-ST2024(B)G1(H) 1/6	2.0 kW	2000 r/min	1/6
ith a gear reducer for		HK-ST2024(B)G1(H) 1/11	2.0 kW	2000 r/min	1/11
eneral industrial machines		HK-ST2024(B)G1(H) 1/17	2.0 kW	2000 r/min	1/17
With an electromagnetic	HK-ST_4_G_	HK-ST2024(B)G1(H) 1/29	2.0 kW	2000 r/min	1/29
ake		HK-ST2024(B)G1(H) 1/35	2.0 kW	2000 r/min	1/35
G1: Flange mounting		HK-ST2024(B)G1(H) 1/43	2.0 kW	2000 r/min	1/43
1H: Foot mounting		HK-ST2024(B)G1(H) 1/59	2.0 kW	2000 r/min	1/59
		HK-ST3524(B)G1(H) 1/6	3.5 kW	2000 r/min	1/6
		HK-ST3524(B)G1(H) 1/11	3.5 kW	2000 r/min	1/11
		HK-ST3524(B)G1(H) 1/17	3.5 kW	2000 r/min	1/17
		HK-ST3524(B)G1(H) 1/29	3.5 kW	2000 r/min	1/29
		HK-ST3524(B)G1(H) 1/35	3.5 kW	2000 r/min	1/35
		HK-ST3524(B)G1(H) 1/43	3.5 kW	2000 r/min	1/43
		HK-ST3524(B)G1(H) 1/59	3.5 kW	2000 r/min	1/59
		HK-ST5024(B)G1(H) 1/6	5.0 kW	2000 r/min	1/6
		HK-ST5024(B)G1(H) 1/11	5.0 kW	2000 r/min	1/11
		HK-ST5024(B)G1(H) 1/17	5.0 kW	2000 r/min	1/17
		HK-ST5024(B)G1(H) 1/29	5.0 kW	2000 r/min	1/29
		HK-ST5024(B)G1(H) 1/35	5.0 kW	2000 r/min	1/35
		HK-ST5024(B)G1(H) 1/43	5.0 kW	2000 r/min	1/43
		HK-ST5024(B)G1(H) 1/59	5.0 kW	2000 r/min	1/59
		HK-ST7024(B)G1(H) 1/6	7.0 kW	2000 r/min	1/6
		HK-ST7024(B)G1(H) 1/11	7.0 kW	2000 r/min	1/11
		HK-ST7024(B)G1(H) 1/17	7.0 kW	2000 r/min	1/17
		HK-ST7024(B)G1(H) 1/29	7.0 kW	2000 r/min	1/29
		HK-ST7024(B)G1(H) 1/35	7.0 kW	2000 r/min	1/35
		HK-ST7024(B)G1(H) 1/43	7.0 kW	2000 r/min	1/43
		HK-ST7024(B)G1(H) 1/59	7.0 kW	2000 r/min	1/59

Item		Model		Rated output	Rated speed	Reduction ratio
		HK-ST52(B)G5	1/5	0.5 kW	2000 r/min	1/5
		HK-ST52(B)G5	1/11	0.5 kW	2000 r/min	1/11
		HK-ST52(B)G5	1/21	0.5 kW	2000 r/min	1/21
		HK-ST52(B)G5	1/33	0.5 kW	2000 r/min	1/33
		HK-ST52(B)G5	1/45	0.5 kW	2000 r/min	1/45
		HK-ST102(B)G5	1/5	1.0 kW	2000 r/min	1/5
		HK-ST102(B)G5	1/11	1.0 kW	2000 r/min	1/11
		HK-ST102(B)G5	1/21	1.0 kW	2000 r/min	1/21
		HK-ST102(B)G5	1/33	1.0 kW	2000 r/min	1/33
		HK-ST102(B)G5	1/45	1.0 kW	2000 r/min	1/45
		HK-ST152(B)G5	1/5	1.5 kW	2000 r/min	1/5
		HK-ST152(B)G5	1/11	1.5 kW	2000 r/min	1/11
		HK-ST152(B)G5	1/21	1.5 kW	2000 r/min	1/21
	HK-ST_G_	HK-ST152(B)G5	1/33	1.5 kW	2000 r/min	1/33
		HK-ST152(B)G5	1/45	1.5 kW	2000 r/min	1/45
		HK-ST202(B)G5	1/5	2.0 kW	2000 r/min	1/5
		HK-ST202(B)G5	1/11	2.0 kW	2000 r/min	1/11
		HK-ST202(B)G5	1/21	2.0 kW	2000 r/min	1/21
		HK-ST202(B)G5	1/33	2.0 kW	2000 r/min	1/33
		HK-ST202(B)G5	1/45	2.0 kW	2000 r/min	1/45
		HK-ST352(B)G5	1/5	3.5 kW	2000 r/min	1/5
		HK-ST352(B)G5	1/11	3.5 kW	2000 r/min	1/11
		HK-ST352(B)G5	1/21	3.5 kW	2000 r/min	1/21
HK-ST series		HK-ST502(B)G5	1/5	5.0 kW	2000 r/min	1/5
With a flange-output type gear		HK-ST502(B)G5	1/11	5.0 kW	2000 r/min	1/11
reducer for high precision		HK-ST702(B)G5	1/5	7.0 kW	2000 r/min	1/5
applications, flange mounting		HK-ST524(B)G5	1/5	0.5 kW	2000 r/min	1/5
D. Mitter on all attracts and the		HK-ST524(B)G5	1/11	0.5 kW	2000 r/min	1/11
B: With an electromagnetic brake		HK-ST524(B)G5	1/21	0.5 kW	2000 r/min	1/21
biake		HK-ST524(B)G5	1/33	0.5 kW	2000 r/min	1/33
		. ,	1/45	0.5 kW	2000 r/min	1/45
		HK-ST524(B)G5 HK-ST1024(B)G5	1/43	1.0 kW	2000 r/min	1/5
		. , ,	1/11	1.0 kW	2000 r/min	1/11
		HK-ST1024(B)G5				
		HK-ST1024(B)G5	1/21	1.0 kW	2000 r/min	1/21
		HK-ST1024(B)G5	1/33	1.0 kW 1.0 kW	2000 r/min	1/33
		HK-ST1024(B)G5	1/45		2000 r/min	1/5
		HK-ST1524(B)G5		1.5 kW	2000 r/min	1/11
		HK-ST1524(B)G5	1/11	1.5 kW	2000 r/min	1/21
	HK-ST_4_G_	HK-ST1524(B)G5	1/21	1.5 kW	2000 r/min	
		HK-ST1524(B)G5	1/33	1.5 kW	2000 r/min	1/33
		HK-ST1524(B)G5	1/45	1.5 kW	2000 r/min	1/45
		HK-ST2024(B)G5	1/5	2.0 kW	2000 r/min	1/5
		HK-ST2024(B)G5	1/11	2.0 kW	2000 r/min	1/11
		HK-ST2024(B)G5	1/21	2.0 kW	2000 r/min	1/21
		HK-ST2024(B)G5	1/33	2.0 kW	2000 r/min	1/33
		HK-ST2024(B)G5	1/45	2.0 kW	2000 r/min	1/45
		HK-ST3524(B)G5	1/5	3.5 kW	2000 r/min	1/5
		HK-ST3524(B)G5	1/11	3.5 kW	2000 r/min	1/11
		HK-ST3524(B)G5	1/21	3.5 kW	2000 r/min	1/21
		HK-ST5024(B)G5	1/5	5.0 kW	2000 r/min	1/5
		HK-ST5024(B)G5	1/11	5.0 kW	2000 r/min	1/11
		HK-ST7024(B)G5	1/5	7.0 kW	2000 r/min	1/5

Item		Model		Rated output	Rated speed	Reduction ratio	
		HK-ST52(B)G7	1/5	0.5 kW	2000 r/min	1/5	
		HK-ST52(B)G7	1/11	0.5 kW	2000 r/min	1/11	
		HK-ST52(B)G7	1/21	0.5 kW	2000 r/min	1/21	
		HK-ST52(B)G7	1/33	0.5 kW	2000 r/min	1/33	
		HK-ST52(B)G7	1/45	0.5 kW	2000 r/min	1/45	
		HK-ST102(B)G7	1/5	1.0 kW	2000 r/min	1/5	
		HK-ST102(B)G7	1/11	1.0 kW	2000 r/min	1/11	
		HK-ST102(B)G7	1/21	1.0 kW	2000 r/min	1/21	
		HK-ST102(B)G7	1/33	1.0 kW	2000 r/min	1/33	
		HK-ST102(B)G7	1/45	1.0 kW	2000 r/min	1/45	
		HK-ST152(B)G7	1/5	1.5 kW	2000 r/min	1/5	
		HK-ST152(B)G7	1/11	1.5 kW	2000 r/min	1/11	
	OT C	HK-ST152(B)G7	1/21	1.5 kW	2000 r/min	1/21	
	HK-ST_G_	HK-ST152(B)G7	1/33	1.5 kW	2000 r/min	1/33	
		HK-ST152(B)G7	1/45	1.5 kW	2000 r/min	1/45	
		HK-ST202(B)G7	1/5	2.0 kW	2000 r/min	1/5	
		HK-ST202(B)G7	1/11	2.0 kW	2000 r/min	1/11	
		HK-ST202(B)G7	1/21	2.0 kW	2000 r/min	1/21	
		HK-ST202(B)G7	1/33	2.0 kW	2000 r/min	1/33	
		HK-ST202(B)G7	1/45	2.0 kW	2000 r/min	1/45	
		` '					
		HK-ST352(B)G7	1/5	3.5 kW	2000 r/min	1/5	
		HK-ST352(B)G7	1/11	3.5 kW	2000 r/min	1/11	
U/ OT serios		HK-ST352(B)G7	1/21	3.5 kW	2000 r/min	1/21	
K-ST series ith a shaft-output type gear		HK-ST502(B)G7	1/5	5.0 kW	2000 r/min	1/5	
vitn a snaπ-output type gear educer for high precision		HK-ST502(B)G7	1/11	5.0 kW	2000 r/min	1/11	
pplications, flange mounting		HK-ST702(B)G7	1/5	7.0 kW	2000 r/min	1/5	
, , ,		HK-ST524(B)G7	1/5	0.5 kW	2000 r/min	1/5	
: With an electromagnetic		HK-ST524(B)G7	1/11	0.5 kW	2000 r/min	1/11	
rake		HK-ST524(B)G7	1/21	0.5 kW	2000 r/min	1/21	
		HK-ST524(B)G7	1/33	0.5 kW	2000 r/min	1/33	
		HK-ST524(B)G7	1/45	0.5 kW	2000 r/min	1/45	
		HK-ST1024(B)G7	1/5	1.0 kW	2000 r/min	1/5	
		HK-ST1024(B)G7	1/11	1.0 kW	2000 r/min	1/11	
		HK-ST1024(B)G7	1/21	1.0 kW	2000 r/min	1/21	
		HK-ST1024(B)G7	1/33	1.0 kW	2000 r/min	1/33	-
		HK-ST1024(B)G7	1/45	1.0 kW	2000 r/min	1/45	
		HK-ST1524(B)G7	1/5	1.5 kW	2000 r/min	1/5	
		HK-ST1524(B)G7	1/11	1.5 kW	2000 r/min	1/11	
		HK-ST1524(B)G7	1/21	1.5 kW	2000 r/min	1/21	
	HK-ST_4_G_	HK-ST1524(B)G7	1/33	1.5 kW	2000 r/min	1/33	
		HK-ST1524(B)G7	1/45	1.5 kW	2000 r/min	1/45	
		HK-ST2024(B)G7	1/5	2.0 kW	2000 r/min	1/5	
		HK-ST2024(B)G7	1/11	2.0 kW	2000 r/min	1/11	
		HK-ST2024(B)G7	1/11	2.0 kW	2000 r/min	1/21	
		. ,		2.0 kW		1/33	
		HK-ST2024(B)G7	1/33		2000 r/min		
		HK-ST2024(B)G7	1/45	2.0 kW	2000 r/min	1/45	
		HK-ST3524(B)G7	1/5	3.5 kW	2000 r/min	1/5	
		HK-ST3524(B)G7	1/11	3.5 kW	2000 r/min	1/11	
		HK-ST3524(B)G7	1/21	3.5 kW	2000 r/min	1/21	
		HK-ST5024(B)G7	1/5	5.0 kW	2000 r/min	1/5	
		HK-ST5024(B)G7	1/11	5.0 kW	2000 r/min	1/11	
		HK-ST7024(B)G7	1/5	7.0 kW	2000 r/min	1/5	

Item		Flange size [mm]	Model	Rated output	Rated speed
			HK-RT103W(B)	1.0 kW	3000 r/min
		90 x 90	HK-RT153W(B)	1.5 kW	3000 r/min
	HK-RT W		HK-RT203W(B)	2.0 kW	3000 r/min
	LIV-K1_W		HK-RT353W(B)	3.5 kW	3000 r/min
IK-RT series		130 x 130	HK-RT503W(B)	5.0 kW	3000 r/min
			HK-RT703W(B)	7.0 kW	3000 r/min
: With an electromagnetic			HK-RT1034W(B)	1.0 kW	3000 r/min
rake		90 x 90	HK-RT1534W(B)	1.5 kW	3000 r/min
HK-f	HK-RT 4W		HK-RT2034W(B)	2.0 kW	3000 r/min
	HK-K1_4VV	130 x 130	HK-RT3534W(B)	3.5 kW	3000 r/min
			HK-RT5034W(B)	5.0 kW	3000 r/min
			HK-RT7034W(B)	7.0 kW	3000 r/min
	HK-RT_W_WS	90 x 90	HK-RT103W(B)WS	1.0 kW	3000 r/min
			HK-RT153W(B)WS	1.5 kW	3000 r/min
			HK-RT203W(B)WS	2.0 kW	3000 r/min
ervo motors with functional		130 x 130	HK-RT353W(B)WS	3.5 kW	3000 r/min
afety			HK-RT503W(B)WS	5.0 kW	3000 r/min
HK-RT series			HK-RT703W(B)WS	7.0 kW	3000 r/min
			HK-RT1034W(B)WS	1.0 kW	3000 r/min
B: With an electromagnetic brake		90 x 90	HK-RT1534W(B)WS	1.5 kW	3000 r/min
	UK DT 4W WC		HK-RT2034W(B)WS	2.0 kW	3000 r/min
	HK-RT_4W_WS	130 x 130	HK-RT3534W(B)WS	3.5 kW	3000 r/min
			HK-RT5034W(B)WS	5.0 kW	3000 r/min
			HK-RT7034W(B)WS	7.0 kW	3000 r/min

Linear servo motors

Item	Model	Continuous thrust	Maximum thrust	Maximum speed	Length
	LM-H3P2A-07P-BSS0	70 N	175 N	3.0 m/s	_
	LM-H3P3A-12P-CSS0	120 N	300 N	3.0 m/s	_
	LM-H3P3B-24P-CSS0	240 N	600 N	3.0 m/s	_
	LM-H3P3C-36P-CSS0	360 N	900 N	3.0 m/s	_
.M-H3 series orimary side (coil)	LM-H3P3D-48P-CSS0	480 N	1200 N	3.0 m/s	_
illiary side (coil)	LM-H3P7A-24P-ASS0	240 N	600 N	3.0 m/s	_
	LM-H3P7B-48P-ASS0	480 N	1200 N	3.0 m/s	_
	LM-H3P7C-72P-ASS0	720 N	1800 N	3.0 m/s	_
	LM-H3P7D-96P-ASS0	960 N	2400 N	3.0 m/s	_
	LM-H3S20-288-BSS0	_	_	_	288 mm
	LM-H3S20-384-BSS0		_	_	384 mm
	LM-H3S20-480-BSS0	_	_	_	480 mm
	LM-H3S20-768-BSS0	_	_	_	768 mm
	LM-H3S30-288-CSS0	_	_	_	288 mm
M-H3 series	LM-H3S30-384-CSS0				384 mm
econdary side (magnet)	LM-H3S30-480-CSS0	_	_	_	480 mm
,	LM-H3S30-768-CSS0	_			768 mm
	LM-H3S70-288-ASS0				288 mm
	LM-H3S70-384-ASS0				384 mm
	LM-H3S70-384-ASS0				480 mm
	LM-H3S70-768-ASS0				768 mm
		68.1 N		6.5 m/s	700 111111
	LM-AJP1B-07K-JSS0			6.5 m/s	
	LM-AJP1D-14K-JSS0	136.2 N	429.4 N		
	LM-AJP2B-12S-JSS0	117.0 N	369.0 N	4.0 m/s	
.M-AJ series	LM-AJP2D-23T-JSS0	234.0 N	738.1 N	5.0 m/s	
rimary side (coil)	LM-AJP3B-17N-JSS0	174.5 N	550.2 N	2.5 m/s	
	LM-AJP3D-35R-JSS0	348.9 N	1100.4 N	3.5 m/s	
	LM-AJP4B-22M-JSS0	223.4 N	704.5 N	2.0 m/s	
	LM-AJP4D-45N-JSS0	446.8 N	1409.1 N	2.5 m/s	_
	LM-AJS10-080-JSS0	_	_	_	80 mm
	LM-AJS10-200-JSS0		_	_	200 mm
	LM-AJS10-400-JSS0		_	_	400 mm
	LM-AJS20-080-JSS0		_	_	80 mm
	LM-AJS20-200-JSS0	_	_	_	200 mm
M-AJ series	LM-AJS20-400-JSS0	_	_	_	400 mm
econdary side (magnet)	LM-AJS30-080-JSS0	_	_	_	80 mm
	LM-AJS30-200-JSS0	_	_	_	200 mm
	LM-AJS30-400-JSS0	_	_	_	400 mm
	LM-AJS40-080-JSS0	_	_	_	80 mm
	LM-AJS40-200-JSS0	_	_	_	200 mm
	LM-AJS40-400-JSS0	_	_	_	400 mm
LM-F series primary side (coil)	LM-FP2B-06M-1SS0	300 N (natural cooling)/ 600 N (force cooling)	1800 N	2.0 m/s	_
	LM-FP2D-12M-1SS0	600 N (natural cooling)/ 1200 N (force cooling)	3600 N	2.0 m/s	_
	LM-FP2F-18M-1SS0	900 N (natural cooling)/ 1800 N (force cooling)	5400 N	2.0 m/s	_
	LM-FP4B-12M-1SS0	600 N (natural cooling)/ 1200 N (force cooling)	3600 N	2.0 m/s	_
	LM-FP4D-24M-1SS0	1200 N (natural cooling)/ 2400 N (force cooling)	7200 N	2.0 m/s	_
	LM-FS20-480-1SS0	_	_	_	480 mm
M-F series	LM-FS20-576-1SS0	_	_	_	576 mm
econdary side (magnet)	LM-FS40-480-1SS0	_	_	_	480 mm
	LM-FS40-576-1SS0	i	i	i	576 mm

Linear servo motors

Item	Model	Continuous thrust	Maximum thrust	Maximum speed	Length
	LM-K2P1A-01M-2SS1	120 N	300 N	2.0 m/s	_
	LM-K2P1C-03M-2SS1	360 N	900 N	2.0 m/s	_
LM-K2 series	LM-K2P2A-02M-1SS1	240 N	600 N	2.0 m/s	_
primary side (coil)	LM-K2P2C-07M-1SS1	720 N	1800 N	2.0 m/s	_
primary state (equi)	LM-K2P2E-12M-1SS1	1200 N	3000 N	2.0 m/s	_
	LM-K2P3C-14M-1SS1	1440 N	3600 N	2.0 m/s	_
	LM-K2P3E-24M-1SS1	2400 N	6000 N	2.0 m/s	_
	LM-K2S10-288-2SS1	_	_	_	288 mm
	LM-K2S10-384-2SS1	_	_	_	384 mm
	LM-K2S10-480-2SS1	_	_	_	480 mm
	LM-K2S10-768-2SS1	_	_	_	768 mm
	LM-K2S20-288-1SS1	_	_	_	288 mm
LM-K2 series	LM-K2S20-384-1SS1	_	_	_	384 mm
secondary side (magnet)	LM-K2S20-480-1SS1	_	_	_	480 mm
	LM-K2S20-768-1SS1	_	_	_	768 mm
	LM-K2S30-288-1SS1	_	_	_	288 mm
	LM-K2S30-384-1SS1	_	_	_	384 mm
	LM-K2S30-480-1SS1	_	_	_	480 mm
	LM-K2S30-768-1SS1	_	_	_	768 mm
	LM-U2PAB-05M-0SS0	50 N	150 N	2.0 m/s	_
	LM-U2PAD-10M-0SS0	100 N	300 N	2.0 m/s	_
	LM-U2PAF-15M-0SS0	150 N	450 N	2.0 m/s	_
M HO	LM-U2PBB-07M-1SS0	75 N	225 N	2.0 m/s	_
_M-U2 series primary side (coil)	LM-U2PBD-15M-1SS0	150 N	450 N	2.0 m/s	_
oninary side (coil)	LM-U2PBF-22M-1SS0	225 N	675 N	2.0 m/s	_
	LM-U2P2B-40M-2SS0	400 N	1600 N	2.0 m/s	_
	LM-U2P2C-60M-2SS0	600 N	2400 N	2.0 m/s	_
	LM-U2P2D-80M-2SS0	800 N	3200 N	2.0 m/s	_
	LM-U2SA0-240-0SS0	_	_	_	240 mm
	LM-U2SA0-300-0SS0	_	_	_	300 mm
	LM-U2SA0-420-0SS0	_	_	_	420 mm
LM-U2 series	LM-U2SB0-240-1SS1	_	<u> </u>	_	240 mm
secondary side (magnet)	LM-U2SB0-300-1SS1	_	<u> </u>	_	300 mm
	LM-U2SB0-420-1SS1	_	_	_	420 mm
	LM-U2S20-300-2SS1	_		_	300 mm
	LM-U2S20-480-2SS1	i_	L	_	480 mm

Direct drive motors

tem	Model	Rated torque	Maximum torque	Rated speed
	TM-RG2M002C30	2.2 N•m	8.8 N•m	300 r/min
M-RG2M series	TM-RG2M004E30	4.5 N•m	13.5 N•m	300 r/min
	TM-RG2M009G30	9 N•m	27 N•m	300 r/min
	TM-RU2M002C30	2.2 N•m	8.8 N•m	300 r/min
M-RU2M series	TM-RU2M004E30	4.5 N•m	13.5 N•m	300 r/min
	TM-RU2M009G30	9 N•m	27 N•m	300 r/min
	TM-RFM002C20	2 N•m	6 N•m	200 r/min
	TM-RFM004C20	4 N•m	12 N•m	200 r/min
	TM-RFM006C20	6 N•m	18 N•m	200 r/min
	TM-RFM006E20	6 N•m	18 N•m	200 r/min
	TM-RFM012E20	12 N•m	36 N•m	200 r/min
M-RFM series	TM-RFM018E20	18 N•m	54 N•m	200 r/min
IVI-REIVI SELIES	TM-RFM012G20	12 N•m	36 N•m	200 r/min
	TM-RFM048G20	48 N•m	144 N•m	200 r/min
	TM-RFM072G20	72 N•m	216 N•m	200 r/min
	TM-RFM040J10	40 N•m	120 N•m	100 r/min
	TM-RFM120J10	120 N•m	360 N•m	100 r/min
	TM-RFM240J10	240 N•m	720 N•m	100 r/min

Cables for rotary servo motors

Item	Model	Length	Bending life	IP rating	Application
	MR-AEPB2CBL2M-A1-H	2 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB
	MR-AEPB2CBL5M-A1-H	5 m	Long bending life	IP65	
	MR-AEPB2CBL10M-A1-H	10 m	Long bending life	IP65	
	MR-AEPB2CBL2M-A1-L	2 m	Standard	IP65	Load-side lead
	MR-AEPB2CBL5M-A1-L	5 m	Standard	IP65	With electromagnetic brake wires
	MR-AEPB2CBL10M-A1-L	10 m	Standard	IP65	
	MR-AEPB2CBL2M-A2-H	2 m	Long bending life	IP65	
	MR-AEPB2CBL5M-A2-H	5 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)WB,
	MR-AEPB2CBL10M-A2-H	10 m	Long bending life	IP65	153(4)WB, 203(4)WB
	MR-AEPB2CBL2M-A2-L	2 m	Standard	IP65	Opposite to load-side lead
	MR-AEPB2CBL5M-A2-L	5 m	Standard	IP65	With electromagnetic brake wires
	MR-AEPB2CBL10M-A2-L	10 m	Standard	IP65	1
	MR-AEPB2CBL2M-A5-H	2 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead With electromagnetic brake wires
	MR-AEPB2CBL5M-A5-H	5 m	Long bending life	IP65	
	MR-AEPB2CBL10M-A5-H	10 m	Long bending life	IP65	
	MR-AEPB2CBL2M-A5-L	2 m	Standard	IP65	
Notor cable	MR-AEPB2CBL5M-A5-L	5 m	Standard	IP65	
(dual cable type/	MR-AEPB2CBL10M-A5-L	10 m	Standard	IP65	
lirect connection type for 10 m or	MR-AEP2CBL2M-A1-H	2 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires
shorter)	MR-AEP2CBL5M-A1-H	5 m	Long bending life	IP65	
	MR-AEP2CBL10M-A1-H	10 m	Long bending life	IP65	
	MR-AEP2CBL2M-A1-L	2 m	Standard	IP65	
	MR-AEP2CBL5M-A1-L	5 m	Standard	IP65	
	MR-AEP2CBL10M-A1-L	10 m	Standard	IP65	
	MR-AEP2CBL2M-A2-H	2 m	Long bending life	IP65	
	MR-AEP2CBL5M-A2-H	5 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)W,
	MR-AEP2CBL10M-A2-H	10 m	Long bending life	IP65	153(4)W, 203(4)W
	MR-AEP2CBL2M-A2-L	2 m	Standard	IP65	Opposite to load-side lead
	MR-AEP2CBL5M-A2-L	5 m	Standard	IP65	Without electromagnetic brake wires
	MR-AEP2CBL10M-A2-L	10 m	Standard	IP65	1
	MR-AEP2CBL2M-A5-H	2 m	Long bending life	IP65	
	MR-AEP2CBL5M-A5-H	5 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)W,
	MR-AEP2CBL10M-A5-H	10 m	Long bending life	IP65	153(4)W, 203(4)W
	MR-AEP2CBL2M-A5-L	2 m	Standard	IP65	Vertical lead
	MR-AEP2CBL5M-A5-L	5 m	Standard	IP65	Without electromagnetic brake wires
	MR-AEP2CBL10M-A5-L	10 m	Standard	IP65	1

Cables for rotary servo motors

Item	Model	Length	Bending life	IP rating	Application
	MR-AEPB2J10CBL03M-A1-L	0.3 m	Standard	IP20	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires
	MR-AEPB2J10CBL03M-A2-L	0.3 m	Standard	IP20	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires
Motor cable (Note 3) (dual cable type/	MR-AEPB2J10CBL03M-A5-L	0.3 m	Standard	IP20	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead With electromagnetic brake wires
junction type for over 10 m)	MR-AEP2J10CBL03M-A1-L	0.3 m	Standard	IP20	For HK-KT/HK-MT/HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires
	MR-AEP2J10CBL03M-A2-L	0.3 m	Standard	IP20	For HK-KT/HK-MT/HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires
	MR-AEP2J10CBL03M-A5-L	0.3 m	Standard	IP20	For HK-KT/HK-MT/HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead Without electromagnetic brake wires
	MR-AEKCBL20M-H	20 m	Long bending life	IP20	
	MR-AEKCBL30M-H	30 m	Long bending life	IP20	
Encoder cable (Note 1)	MR-AEKCBL40M-H	40 m	Long bending life	IP20	For HK-KT/HK-MT/HK-RT103(4)W,
Elicodel cable	MR-AEKCBL50M-H	50 m	Long bending life	IP20	153(4)W, 203(4)W
	MR-AEKCBL20M-L	20 m	Standard	IP20	
	MR-AEKCBL30M-L	30 m	Standard	IP20	
Motor cable ^(Note 2) (dual cable type/ junction type for over 10 m)	MR-AEPB2J20CBL03M-A1-L	0.3 m	Standard	IP65	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires
	MR-AEPB2J20CBL03M-A2-L	0.3 m	Standard	IP65	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires
	MR-AEPB2J20CBL03M-A5-L	0.3 m	Standard	IP65	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead With electromagnetic brake wires
	MR-AEP2J20CBL03M-A1-L	0.3 m	Standard	IP65	For HK-KT/HK-MT/HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires
	MR-AEP2J20CBL03M-A2-L	0.3 m	Standard	IP65	For HK-KT/HK-MT/HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires
	MR-AEP2J20CBL03M-A5-L	0.3 m	Standard	IP65	For HK-KT/HK-MT/HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead Without electromagnetic brake wires

^{1.} Use this cable in combination with MR-AEPB2J10CBL03M-_-L or MR-AEP2J10CBL03M-_-L.

^{2.} Use this cable in combination with MR-AENSCBL_M-H, MR-AENSCBL_M-L, or MR-J3SCNS.

^{3.} Use this cable in combination with MR-AEKCBL_M-H, MR-AEKCBL_M-L, or MR-ECNM.

Cables for rotary servo motors

Encoder cable Encoder cable Encoder cable MR. MR. MR. MR. MR. MR. MR. MR	R-J3ENSCBL2M-H R-J3ENSCBL5M-H R-J3ENSCBL10M-H R-AENSCBL20M-H (Note 1) R-AENSCBL30M-H (Note 1) R-AENSCBL30M-H (Note 1) R-AENSCBL50M-H (Note 1) R-AENSCBL50M-L R-J3ENSCBL5M-L R-J3ENSCBL5M-L R-J3ENSCBL5M-L R-J3ENSCBL5M-L R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L R-AENSCBL30M-L R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H	2 m 5 m 10 m 20 m 30 m 40 m 50 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m 10 m	Long bending life Standard Standard Standard Standard Uong bending life Long bending life Long bending life Long bending life Standard Long bending life Long bending life Standard Standard Standard Standard Standard Standard	rating	For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires
Incoder cable Incode	R-J3ENSCBL10M-H R-AENSCBL20M-H (Note 1) R-AENSCBL30M-H (Note 1) R-AENSCBL30M-H (Note 1) R-AENSCBL40M-H (Note 1) R-AENSCBL50M-L R-J3ENSCBL2M-L R-J3ENSCBL5M-L R-J3ENSCBL5M-L R-AENSCBL20M-L (Note 1) R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	10 m 20 m 30 m 40 m 50 m 2 m 5 m 10 m 20 m 30 m 20 m 30 m 20 m 30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Long bending life Standard Standard Standard Standard Standard Long bending life Long bending life Long bending life Standard Long bending life Standard Standard Standard Standard Standard Standard Standard	IP67	503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
Incoder cable Incode	R-AENSCBL20M-H (Note 1) R-AENSCBL30M-H (Note 1) R-AENSCBL40M-H (Note 1) R-AENSCBL50M-H (Note 1) R-J3ENSCBL50M-L R-J3ENSCBL5M-L R-J3ENSCBL5M-L R-J3ENSCBL10M-L R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	20 m 30 m 40 m 50 m 2 m 5 m 10 m 20 m 30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Long bending life Long bending life Long bending life Long bending life Standard Standard Standard Standard Standard Long bending life Long bending life Long bending life Standard Standard Long bending life Long bending life Standard Standard Standard Standard Standard	IP67	For HK-KT/HK-MT/HK-ST/HK-RT For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
Incoder cable MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AENSCBL30M-H (Note 1) R-AENSCBL40M-H (Note 1) R-AENSCBL50M-H (Note 1) R-J3ENSCBL5M-L R-J3ENSCBL5M-L R-J3ENSCBL10M-L R-AENSCBL20M-L (Note 1) R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	30 m 40 m 50 m 2 m 5 m 10 m 20 m 30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Long bending life Long bending life Long bending life Standard Standard Standard Standard Standard Long bending life Long bending life Long bending life Standard Standard Long bending life Long bending life Standard Standard Standard Standard Long bending life	IP67	For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
Incoder cable MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AENSCBL40M-H (Note 1) R-AENSCBL50M-H (Note 1) R-J3ENSCBL5M-L R-J3ENSCBL5M-L R-J3ENSCBL10M-L R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	40 m 50 m 2 m 5 m 10 m 20 m 30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Long bending life Long bending life Standard Standard Standard Standard Standard Long bending life Long bending life Long bending life Standard Standard Standard Long bending life Long bending life Standard Standard Standard Long bending life	IP67	For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
MR-	R-AENSCBL40M-H (Note 1) R-AENSCBL50M-H (Note 1) R-J3ENSCBL5M-L R-J3ENSCBL5M-L R-J3ENSCBL10M-L R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	50 m 2 m 5 m 10 m 20 m 30 m 2 m 5 m 10 m 2 m 5 m	Long bending life Standard Standard Standard Standard Standard Long bending life Long bending life Long bending life Standard Standard Standard Standard Long bending life	IP67	For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
MR-	R-AENSCBL50M-H (Note 1) R-J3ENSCBL2M-L R-J3ENSCBL10M-L R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	2 m 5 m 10 m 20 m 30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Standard Standard Standard Standard Standard Long bending life Long bending life Long bending life Standard Standard Standard Standard Long bending life	IP67	503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
MR-	R-J3ENSCBL2M-L R-J3ENSCBL5M-L R-J3ENSCBL10M-L R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL10M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-L	5 m 10 m 20 m 30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Standard Standard Standard Standard Long bending life Long bending life Long bending life Standard Standard Standard Long bending life	IP67	503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
MR-	R-J3ENSCBL10M-L R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL10M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	10 m 20 m 30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Standard Standard Standard Long bending life Long bending life Long bending life Standard Standard Standard Long bending life	IP67	503(4)W, 703(4)W For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
MR-	R-AENSCBL20M-L (Note 1) R-AENSCBL30M-L (Note 1) R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL10M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL10M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL2M-A2-L	20 m 30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Standard Standard Long bending life Long bending life Long bending life Standard Standard Standard Long bending life	IP67	For HK-KT/HK-MT/HK-ST/HK-RT For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
MR-	R-AENSCBL30M-L (Note 1) R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL10M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	30 m 2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Standard Long bending life Long bending life Long bending life Standard Standard Standard Long bending life	IP67	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
MR-	R-AENSCBL30M-L (Note 1) R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL10M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	2 m 5 m 10 m 2 m 5 m 10 m 2 m 5 m	Long bending life Long bending life Long bending life Standard Standard Standard Long bending life	IP65 IP65 IP65 IP65 IP65	For HK-KT/HK-MT/HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead
MR-	R-AEPB1CBL2M-A1-H R-AEPB1CBL5M-A1-H R-AEPB1CBL10M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL10M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	5 m 10 m 2 m 5 m 10 m 2 m 5 m	Long bending life Long bending life Standard Standard Standard Long bending life	IP65 IP65 IP65 IP65 IP65	153(4)WB, 203(4)WB Load-side lead
MR-	R-AEPB1CBL10M-A1-H R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL10M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	10 m 2 m 5 m 10 m 2 m 5 m	Long bending life Standard Standard Standard Long bending life	IP65 IP65 IP65 IP65	153(4)WB, 203(4)WB Load-side lead
MR-	R-AEPB1CBL2M-A1-L R-AEPB1CBL5M-A1-L R-AEPB1CBL10M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	2 m 5 m 10 m 2 m 5 m	Standard Standard Standard Long bending life	IP65 IP65 IP65	153(4)WB, 203(4)WB Load-side lead
MR-	R-AEPB1CBL5M-A1-L R-AEPB1CBL10M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	5 m 10 m 2 m 5 m	Standard Standard Long bending life	IP65 IP65	Load-side lead
MR-	R-AEPB1CBL10M-A1-L R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	10 m 2 m 5 m	Standard Long bending life	IP65	With electromagnetic brake wires
MR-	R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	2 m 5 m	Long bending life		With electromagnetic brake wires
MR-	R-AEPB1CBL2M-A2-H R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	5 m	ů ů	1	1
MR-	R-AEPB1CBL5M-A2-H R-AEPB1CBL10M-A2-H R-AEPB1CBL2M-A2-L	_	1	IP65	
MR-	R-AEPB1CBL2M-A2-L	_	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)WB,
MR-	R-AEPB1CBL2M-A2-L	10 111	Long bending life	IP65	153(4)WB, 203(4)WB
MR- MR- MR- MR- MR- MR- MR- MR- ingle cable type/ irect connection type for 10 m or norter) MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	AEDD40D1534 40 1	2 m	Standard	IP65	Opposite to load-side lead With electromagnetic brake wires
MR- MR- MR- MR- MR- Ingle cable type/ rect connection type for 10 m or norter) MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AEPB1CBL5M-A2-L	5 m	Standard	IP65	
MR- MR- MR- MR- MR- Ingle cable type/ rect connection type for 10 m or norter) MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AEPB1CBL10M-A2-L	10 m	Standard	IP65	1
MR- MR- Iotor cable ingle cable type/ rect connection type for 10 m or norter) MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AEPB1CBL2M-A5-H	2 m	Long bending life	IP65	
MR- Interpretable to the proof of the proof	R-AEPB1CBL5M-A5-H	5 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)WB,
MR- lotor cable MR- ingle cable type/ rect connection type for 10 m or norter) MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AEPB1CBL10M-A5-H	10 m	Long bending life	IP65	153(4)WB, 203(4)WB Vertical lead With electromagnetic brake wires
otor cable MR- ingle cable type/ rect connection type for 10 m or norter) MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AEPB1CBL2M-A5-L	2 m	Standard	IP65	
ingle cable type/ rect connection type for 10 m or norter) MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AEPB1CBL5M-A5-L	5 m	Standard	IP65	
rect connection type for 10 m or MR- morter) MR- MR- MR- MR- MR- MR- MR- MR- MR- MR	R-AEPB1CBL10M-A5-L	10 m	Standard	IP65	
MR-	R-AEP1CBL2M-A1-H	2 m	Long bending life	IP65	
MR-	R-AEP1CBL5M-A1-H	5 m	Long bending life	IP65	For HV VT/HV MT/HV PT103/4\\\
MR-	R-AEP1CBL10M-A1-H	10 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)W,
MR- MR- MR- MR- MR- MR-	R-AEP1CBL2M-A1-L	2 m	Standard	IP65	153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires
MR- MR- MR- MR- MR-	R-AEP1CBL5M-A1-L	5 m	Standard	IP65	
MR- MR- MR- MR-	R-AEP1CBL10M-A1-L	10 m	Standard	IP65	1
MR- MR- MR-	R-AEP1CBL2M-A2-H	2 m	Long bending life	IP65	
MR- MR- MR-	R-AEP1CBL5M-A2-H	5 m	Long bending life	IP65	For LIK KT/LIK MT/LIK DT400/4004
MR- MR-	R-AEP1CBL10M-A2-H	10 m	Long bending life	IP65	For HK-KT/HK-MT/HK-RT103(4)W,
MR-	R-AEP1CBL10M-A2-H	2 m	Standard	IP65	153(4)W, 203(4)W Opposite to load-side lead
	R-AEP1CBL5M-A2-L	5 m	Standard	IP65	Without electromagnetic brake wires
	R-AEP1CBL5M-A2-L	10 m	Standard	IP65	ď
	R-AEP1CBL10M-A2-L R-AEP1CBL2M-A5-H	2 m	Long bending life	IP65	
			Long bending life		<u> </u>
<u></u>	R-AEP1CBL5M-A5-H	5 m		IP65	For HK-KT/HK-MT/HK-RT103(4)W,
	R-AEP1CBL10M-A5-H	10 m	Long bending life	IP65	153(4)W, 203(4)W Vertical lead
	R-AEP1CBL2M-A5-L	2 m	Standard	IP65	Without electromagnetic brake wires
	R-AEP1CBL5M-A5-L	5 m	Standard	IP65	d
		10 m	Standard	IP65	
ncoder cable ——	R-AEP1CBL10M-A5-L	2 m	Long bending life	IP20	For connecting a load-side encoder
MR- unction cable or fully closed loop control		5 m	Long bending life Standard	IP20 	For branching a load-side encoder

 $^{1.} When using this cable for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW), use it in combination with MR-AEPB2J20CBL03M-_-L or MR-AEP2J20CBL03M-_-L.\\$

Connector sets for rotary servo motors

Item	Model	Description I		Application
	MR-ECNM (Note 1)	Encoder connector × 1 Servo amplifier connector × 1		For HK-KT/HK-MT/HK-RT103(4)W, 153(4)W, 203(4)W For connecting a load-side encoder
	MR-J3SCNS (Note 2)	Junction connector or encoder connector × 1 Servo amplifier connector × 1	IP67	For HK-KT/HK-MT/HK-ST/HK-RT (one-touch connection type)
	MR-ENCNS2	Encoder connector × 1 Servo amplifier connector × 1		For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W (straight type) (screw type)
	MR-J3SCNSA	Encoder connector × 1 Servo amplifier connector × 1		For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W (angle type) (one-touch connection type)
	MR-ENCNS2A	Encoder connector × 1 Servo amplifier connector × 1		For HK-ST/HK-RT353(4)W, 503(4)W, 703(4)W (angle type) (screw type)

Connector sets for rotary servo motors

Item	Model	Description	IP rating	Application
Power connector set	MR-APWCNS4	Power connector × 1		For HK-ST52(4)(W), 102(4)(W), 172(4)W, 202(4)AW, 302(4)W, 353(4)W, 503(4)W ^(Note 3) (one-touch connection type)
	MR-APWCNS5	Power connector × 1		For HK-ST202(4)(W), 352(4)(W), 502(4)(W), 702(4)(W)/ HK-RT353(4)W, 503(4)W, 703(4)W (one-touch connection type)
Electromagnetic brake connector set	MR-BKCNS1	Electromagnetic brake connector × 1		For HK-ST/HK-RT353(4)WB, 503(4)WB, 703(4)WB (straight type) (one-touch connection type)
	MR-BKCNS2	Electromagnetic brake connector × 1		For HK-ST/HK-RT353(4)WB, 503(4)WB, 703(4)WB (straight type) (screw type)
	MR-BKCNS1A	Electromagnetic brake connector × 1		For HK-ST/HK-RT353(4)WB, 503(4)WB, 703(4)WB (angle type) (one-touch connection type)
	MR-BKCNS2A	Electromagnetic brake connector × 1	IP67	For HK-ST/HK-RT353(4)WB, 503(4)WB, 703(4)WB (angle type) (screw type)
Encoder connector set	MR-J3CN2	Servo amplifier connector × 1	_	For connecting a load side encoder
Connector set	MR-J3THMCN2	Junction connector × 2 Servo amplifier connector × 1	_	For fully closed loop control

- 1. When using this connector set for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW), use it in combination with MR-AEPB2J10CBL03M-_-L or MR-AEP2J10CBL03M-_-L.
- 2. When using this connector set for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW), use it in combination with MR-AEPB2J20CBL03M-_-L or MR-AEP2J20CBL03M-_-L.
- 3. When using HK-ST503W for a machine that is required to comply with UL/CSA standards, do not use MR-APWCNS4.

 Use a cable (SC-PWC403C_M-SBLL or SC-PWC403C_M-SBLH) manufactured by Mitsubishi Electric System & Service Co., Ltd., and fabricate an extension cable with wires of AWG 10. For details of SC-PWC403C_M-SBLL and SC-PWC403C_M-SBLH, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Cables and connector sets for linear servo motors

Item	Model	Description		IP rating	Application
Encoder cable	MR-EKCBL2M-H	2 m	Long bending life	IP20	For connecting a linear encoder
	MR-EKCBL5M-H	5 m	Long bending life	IP20	For connecting a linear encoder
Junction cable for linear servo motors	MR-J4THCBL03M	0.3 m	Standard		For branching a thermistor
Encoder connector set	MR-ECNM	Junction connector × 1 Servo amplifier connector × 1		IP20	For connecting a linear encoder
	MR-J3CN2	Servo amplifier connector × 1			For connecting a linear encoder or a thermistor
Connector set	MR-J3THMCN2	Junction connector × 2 Servo amplifier connector × 1			For branching a thermistor

Connector sets for direct drive motors

Item	Model	Description	IP rating	Application
Encoder connector set	MR-J3DDCNS	Encoder connector or absolute position storage unit connector × 1 Servo amplifier connector × 1		For TM-RG2M/TM-RU2M/TM-RFM (For connecting a direct drive motor and a servo amplifier, or an absolute position storage unit and a servo amplifier)
	MR-J3DDSPS	Encoder connector × 1 Absolute position storage unit connector × 1		For TM-RG2M/TM-RU2M/TM-RFM (For connecting a direct drive motor and an absolute position storage unit)
	MR-PWCNF	Power connector × 1	IP67	For TM-RG2M_, TM-RU2M_, TM-RFM_C20, and TM-RFM_E20
Power connector set	MR-PWCNS4	Power connector × 1	IP67	For TM-RFM_G20
	MR-PWCNS5	Power connector × 1	IP67	For TM-RFM040J10 and TM-RFM120J10
	MR-PWCNS3	Power connector × 1	IP67	For TM-RFM240J10

Connectors for servo amplifiers/drive units

Item	Model	Description	IP rating	Application (Note 1)
	MR-CCN1	Servo amplifier connector × 1		For MR-J5G_
	MR-J2CMP2	Servo amplifier connector × 1	_	For MR-J5W - G
Connector set	MR-ECN1	Servo amplifier connector × 20	_	Fol MR-35WG
	MR-ADCN3	Drive unit connector × 1	-	For MR-J5DG4
	MR-J3CN1	Servo amplifier connector × 1	_	For MR-J5A_
	MR-CVCN24S	Power regeneration converter unit connector × 1	_	For MR-CV_

Bus bars

Bue buile			
Item	Model	Length	Application (Note 1)
	MR-DCBAR077-B02	_	For connecting between power regeneration converter unit and drive unit,
	MR-DCBAR092-B02	_	and between drive units
Bus bar	MR-DCBAR097-B02	_	
Bus bai	MR-DCBAR112-B02	AR112-B02 —	For connecting between power regeneration converter unit and drive unit
	MR-DCBAR099-B03	_	Troi connecting between power regeneration converter unit and unive unit
	MR-DCBAR114-B03	_]
Adjustment bar (Note 2)	MR-DCBAR024-B05		-

- 1. Note that options/peripheral equipment necessary for servo amplifiers with special specifications are the same as those for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.
- 2. When an even number of MR-J5D_-G4 drive units is connected to the power regeneration converter unit, use the adjustment bars. Each of the bar models in the table includes a set of two bus bars.

Junction terminal blocks/Junction terminal block cables

Item	Model	Length	Application (Note 1)
Junction terminal block (26 pins)	MR-TB26A	_	For MR-J5WG
Junction terminal block (50 pins)	MR-TB50	_	For MR-J5A_
	MR-J2HBUS05M	0.5 m	
	MR-J2HBUS1M	1 m	For connecting MR-J5G_ and PS7DW-20V14B-F
	MR-J2HBUS5M	5 m	
Junction terminal block cable	MR-TBNATBL05M	0.5 m	For connecting MR-J5W - G and MR-TB26A
	MR-TBNATBL1M	1 m	For connecting MR-JSWG and MR-1626A
	MR-J2M-CN1TBL05M	0.5 m	For connecting MR-J5- A and MR-TB50
	MR-J2M-CN1TBL1M	1 m	TO CONTINUE CAND MICE-123- A AND MICE-1230

Batteries/Battery cases/Battery cables

Item	Model	Length	Application (Note 1)
	MR-BAT6V1SET	_	For MR-J5- G and MR-J5- A
Battery	MR-BAT6V1SET-A	_	TO MIX-33G and MIX-33A
	MR-BAT6V1	_	For MR-BAT6V1SET, MR-BAT6V1SET-A, and MR-BT6VCASE
Battery case	MR-BT6VCASE	_	For MR-J5G, MR-J5WG, and MR-J5A
Battery cable	MR-BT6V1CBL03M	0.3 m	For connecting MR-J5G, MR-J5WG, or MR-J5A
Ballery Cable	MR-BT6V1CBL1M	1 m	with MR-BT6VCASE
Junction battery cable	MR-BT6V2CBL03M	0.3 m	For MR-J5G, MR-J5WG, and MR-J5A
Junction battery cable	MR-BT6V2CBL1M	1 m	roi wix-556, wix-55w6, and wix-55A

Regenerative options

Item	Model	Permissible regenerative power	Resistance value	Application (Note 1)
	MR-RB032	30 W	40 Ω	For MR-J5-10G to 60G and MR-J5-10A to 60A
	MR-RB12	100 W	40 Ω	For MR-J5-20G to 60G and MR-J5-20A to 60A
	MR-RB14	100 W	26 Ω	For MR-J5-70G, 100G, MR-J5-70A, 100A, MR-J5W2-22G, 44G, and MR-J5W3-222G, 444G
	MR-RB30	300 W	13 Ω	For MR-J5-200G and MR-J5-200A
Regenerative option (200 V)	MR-RB3N	300 W	9 Ω	For MR-J5-350G, MR-J5-350A, and MR-J5W2-77G, 1010G
	MR-RB31	300 W	6.7 Ω	For MR-J5-500G and MR-J5-500A
	MR-RB3Z	300 W	5.5 Ω	For MR-J5-700G and MR-J5-700A
	MR-RB34	300 W	26 Ω	For MR-J5-70G, 100G, MR-J5-70A, 100A, and MR-J5W3-222G, 444G
	MR-RB50	500 W	13 Ω	For MR-J5-200G and MR-J5-200A
	MR-RB5N	500 W	9 Ω	For MR-J5-350G and MR-J5-350A
	MR-RB51	500 W	6.7 Ω	For MR-J5-500G and MR-J5-500A
	MR-RB5Z	500 W	5.5 Ω	For MR-J5-700G and MR-J5-700A
	MR-RB1H-4	100 W	82 Ω	For MR-J5-60G4, 100G4, and MR-J5-60A4, 100A4
(400.10)	MR-RB3M-4	300 W	120 Ω	For MR-J5-60G4, 100G4, and MR-J5-60A4, 100A4
Regenerative option (400 V)	MR-RB3G-4	300 W	47 Ω	For MR-J5-200G4 and MR-J5-200A4
	MR-RB3Y-4	300 W	36 Ω	For MR-J5-350G4 and MR-J5-350A4
	MR-RB5G-4	500 W	47 Ω	For MR-J5-200G4 and MR-J5-200A4
	MR-RB5Y-4	500 W	36 Ω	For MR-J5-350G4 and MR-J5-350A4

^{1.} Note that options/peripheral equipment necessary for servo amplifiers with special specifications are the same as those for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

Peripheral units

Item	Model	Application (Note 1)	-
Safety logic unit	MR-J3-D05	For MR-J5G_, MR-J5WG, MR-J5DG4, and MR-J5A_	
Absolute position storage unit	MR-BTAS01	For MR-J5G, MR-J5WG, and MR-J5A	
	MR-J5-FAN1	For MR-J5-70G/A and MR-J5-100G/A	
	MR-J5-FAN2	For MR-J5-200G_/A_ and MR-J5-350G_/A_	
	MR-J5-FAN3	For MR-J5-500G/A	
	MR-J5-FAN4	For MR-J5-700G/A	
	MR-J5W-FAN1	For MR-J5W2-44G	
Replacement fan unit	MR-J5W-FAN3	For MR-J5W2-77G and MR-J5W2-1010G	
	MR-J5W-FAN2	For MR-J5W3-222G and MR-J5W3-444G	
	MR-J5D-FAN1	For MR-J5D1-500G4, MR-J5D1-700G4, MR-J5D2-200G4, MR-J5D2-350G4, and MR-J5D3-200G4	
	MR-J5D-FAN2	For MR-J5D2-500G4 and MR-J5D2-700G4	
	MR-AL-11K4	For MR-CV11K4	
	MR-AL-18K4	For MR-CV18K4	
	MR-AL-30K4	For MR-CV30K4	
AC reactor	MR-AL-37K4	For MR-CV37K4	
	MR-AL-45K4	For MR-CV45K4	
	MR-AL-55K4	For MR-CV55K4	
	MR-AL-75K4	For MR-CV75K4	

Peripheral cables/connector sets

Item	Model	Length	Application (Note 1)
Personal computer communication cable (USB cable)	MR-J3USBCBL3M	3 m	For MR-J5G_, MR-J5WG, MR-J5DG4, and MR-J5A_
Monitor cable	MR-ACN6CBL1M	1 m	For MR-J5G_ and MR-J5A_
Monitor cable	MR-J3CN6CBL1M	1 m	For MR-J5WG
STO cable	MR-D05UDL3M-B	3 m	For connecting MR-J3-D05 or a safety control device with MR-J5G_, MR-J5WG, MR-J5DG4, and MR-J5A_
	MR-ACDL02M	0.2 m	For connecting between power regeneration converter unit and drive unit
Protection coordination cable	MR-ACDL05M	0.5 m	Prof conflecting between power regeneration converter unit and drive unit
	MR-ADDL02M	0.2 m	For connecting between drive units
Daisy chain power connector	MR-J5CNP12-J1	_	For MR-J5-10G/A to MR-J5-100G/A, MR-J5W2-22G, MR-J5W2-44G, MR-J5W3-222G, and MR-J5W3-444G
	MR-J5CNP12-J2 —		For MR-J5-200G/A, MR-J5W2-77G, and MR-J5W2-1010G

Peripheral attachments

Item	Model	Description	Application (Note 1)
Cabinet-mounting attachment	J5-CHP07-10P	Components (1 pc.) Attachment × 1 Flat head screw (M4 × 10) × 1 Packing quantity: 10 pcs./packing	For MR-J5-10G_/A_ to MR-J5-350G_/A_, MR-J5WG, and MR-CM3K
Grounding terminal attachment	J5-CHP08	Attachment × 1 Cable clamp × 2 Screw (M4 × 12) × 4	For MR-J5-10G_/A_ to MR-J5-350G_/A_
Mounting attachment (Power regeneration converter unit attachment)	MR-ADCACN090	Attachment × 1	For MR-CV11K4 and MR-CV18K4
	MR-ADCACN150	Attachment × 1	For MR-CV30K4 to MR-CV45K4
	MR-ADCACN300	Attachment × 1	For MR-CV55K4 to MR-CV75K4
Mounting attachment (Drive unit attachment)	MR-ADACN060	Attachment × 1	For MR-J5D1-100G4 to MR-J5D1-700G4, MR-J5D2-100G4 to MR-J5D2-350G4, MR-J5D3-100G4, and MR-J5D3-200G4
	MR-ADACN075	Attachment × 1	For MR-J5D2-500G4 and MR-J5D2-700G4
Side protection cover	MR-J5DCASE01	Side protection cover × 1	For MR-J5DG4

^{1.} Note that options/peripheral equipment necessary for servo amplifiers with special specifications are the same as those for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

Servo support software

Item	Model	Application
MELSOFT MR Configurator2 (Note1)	SW1DNC-MRC2-E	Servo setup software for AC servo

^{1.} MR Configurator2 is included in GX Works3 and MT Works2 with software version 1.34L or later.

If you have MELSOFT iQ Works, GX Works3, GX Works2, MT Works2, EM Software Development Kit, or CW Configurator, MR Configurator2 is available for free download.

MEMO

For your safety

- To use the products given in this catalog safely, be sure to read the User's Manuals and the appended document prior to use.
- In this catalog, the safety instruction levels are classified into "WARNING" and "CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight injury.

Note that the CAUTION level may lead to a serious consequence depending on conditions.

Please follow the instructions of both levels because they are important to personnel safety.

In the following precautions, a term of servo amplifier includes a combination of a drive unit and a converter unit.

Safety instructions



[Wiring]

- To prevent an electric shock, turn off the servo amplifier power and wait for 15 minutes or more before starting wiring and/or inspection.For the drive unit, wait for 20 minutes or more before starting wiring and/or inspection.
- To prevent an electric shock, ground the servo amplifier.
- To prevent an electric shock, any person who is involved in wiring should be fully competent to do the work.
- To prevent an electric shock, mount the servo amplifier and the servo motor before wiring.
- To prevent an electric shock, connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier protective earth (PE) terminal.
- To prevent an electric shock, do not touch the conductive parts.
- To prevent an electric shock and burn injury, do not operate the servo amplifier and the servo motor with wet hands.

[Operation]

• To prevent an electric shock and burn injury, do not operate the servo amplifier and the servo motor with wet hands.


[Maintenance]

- To prevent an electric shock, any person who is involved in wiring should be fully competent to do the work.
- To prevent an electric shock and burn injury, do not operate the servo amplifier and the servo motor with wet hands.

↑ CAUTION

[Transportation/installation]

- To prevent injury, transport the products correctly according to their mass.
- To prevent injury, do not touch the sharp edges of the servo motor, shaft keyway, or others with bare hands when handling the servo motor.
- For the linear servo motor, attraction force is generated between the permanent magnet on the secondary side and the magnetic materials. To prevent injury to fingers and other body parts due to the attraction force between the secondary side and the magnetic material side, take special care in handling the linear servo motor.



[Operation]

 To prevent injury, do not touch the rotor of the servo motor during operation.

[Disposal of linear servo motors]

 To prevent burn injury, do not touch the secondary side after the demagnetization of the secondary side by heating over 300 °C until it becomes cool enough.


For proper use

- To use the products given in this catalog properly, be sure to read the User's Manuals and the appended document prior to use.
- In this catalog, instructions for incorrect handling which may cause physical damage, instructions for other functions, and so on are classified into "NOTICES".
- In the following precautions, a term of servo amplifier includes a combination of a drive unit and a converter unit.

! NOTICES

[Model selection]

- Select a rotary servo motor or a direct drive motor which has the rated torque equal to or higher than the continuous effective torque.
- Select a linear servo motor which has the continuous thrust equal to or higher than the continuous effective load thrust.
- When the linear servo motor is used for vertical axis, it is necessary to have an anti-drop mechanism using springs and counter balances in the machine side.
- For the system where the unbalanced torque occurs, such as a vertical axis, the unbalanced torque of the machine should be kept at 70 % or lower of the rated torque.
- Create operation patterns by considering the settling time (ts) to complete positioning.
- Load to motor inertia ratio or load to mass ratio must be below the recommended ratio.
 If the ratio is too large,



the expected performance may not be achieved, and the dynamic brake may be damaged.

• Use the servo motor with the specified servo amplifier.

[Transportation/installation]

- To prevent a malfunction, do not drop or strike the servo amplifier and servo motor.
- When fumigants that contain halogen materials, such as fluorine, chlorine, bromine, and iodine, are used for disinfecting and protecting wooden packaging from insects, they cause a malfunction when entering our products. Please take necessary precautions to ensure that any residual materials from fumigant do not enter our products, or perform disinfection and pest control using methods other than fumigation, such as heat treatment. Perform disinfection and pest control at timbering stage before packing the products.
- Do not get on or place heavy objects on the servo amplifier or the servo motor.
- The system must withstand high speeds and high acceleration/ deceleration.
- To enable high-accuracy positioning, ensure the machine rigidity, and keep the machine resonance point at a high level.
- Install the servo amplifier and the servo motor on incombustible material. Installing them directly or close to combustibles will lead to smoke or a fire. In addition, the servo amplifier must be installed in a metal cabinet.
- The regenerative option becomes hot (the temperature rise of 100 °C or higher) with frequent use. Do not install within combustibles or objects subject to thermal deformation. Make sure that wires do not come into contact with the unit.
- Securely fix the servo motor onto the machine. If attached insecurely, the motor may come off during operation.
- Install electrical and mechanical stoppers at the stroke end.
- Mount the servo amplifier on a perpendicular wall in the correct vertical direction.

- To prevent a malfunction, do not block the intake and exhaust areas of the servo amplifier.
- When installing multiple servo amplifiers in a row in a sealed cabinet, leave space around the servo amplifiers as described in User's Manuals. To ensure the life and reliability of the servo amplifiers, prevent heat accumulation by keeping space as open as possible toward the top plate.
- Do not disassemble, repair, or modify the product.

[Environment]

- Use the servo amplifier and the servo motor in the designated environment
- Avoid installing the servo amplifier and the servo motor in areas with oil mist or dust. When installing in such areas, be sure to enclose the servo amplifier in a sealed cabinet, and protect the servo motor by furnishing a cover or by taking similar measures.
- In the condition where cutting fluid or lubricating oil are constantly applied, and condensation occurs due to excessive humidity, continuous operation of the servo motor for a long period of time may result in the deterioration on the insulation of the servo motor. Provide measures such as oil proof, dust proof cover, and dew condensation prevention to protect the servo motor.
- To prevent a malfunction or a failure, do not use the servo system products under a strong electric field, magnetic field, or radiation environment.

Wirinal

- The grounding must be connected to prevent faults such as a position mismatch
- Do not supply power to the output terminals (U/V/W) of the servo amplifier or the input terminals (U/V/W) of the servo motor.
 Doing so damages the servo amplifier and the servo motor.
- To prevent abnormal operation and malfunction, connect the servo amplifier power outputs (U/V/W) to the servo motor power inputs (U/ V/W) directly. Do not connect a magnetic contactor and others between them.
- The phases (U/V/W) of the servo amplifier power outputs and the phases (U/V/W) of the servo motor power inputs should match with each other.
- Check the wiring and sequence program thoroughly before switching the power on.
- Carefully select the cable clamping method, and make sure that bending stress and the stress of the cable's own weight are not applied on the cable connection section.
- In an application where the servo motor moves, determine the cable bending radius based on the cable bending life and wire type.
- To prevent malfunction, avoid bundling the servo amplifier's power lines (input/output) and signal cables together or running them in parallel to each other. Separate the power lines from the signal cables.

[Initial settings]

- For MR-J5-A_, select a control mode from position, speed or torque with [Pr. PA01.0]. Position control mode is set as default. Change the parameter setting value when using the other control modes. For MR-J5_-G_, the control mode is set by the controller.
- When using the regenerative option, change [Pr. PA02.0-1]. The regenerative option is disabled as default.

[Operation]

- Do not use a product which is damaged or has missing parts. In that case, replace the product.
- Turn on the stroke limit signals (FLS/RLS), or the stroke end signals (LSP/LSN) in position or speed control mode. The servo motor will not start if the signals are off.
- When a magnetic contactor is installed on the primary side of the servo amplifier, do not perform frequent starts and stops with the magnetic contactor. Doing so may damage the servo amplifier.

- Do not use the dynamic brake to stop in a normal operation as it is the function to stop in emergency.
- Note that the number of operation times of the dynamic brake is limited. For example, when a machine operates at the recommended load to motor inertia ratio or less and decelerates from the rated speed to a stop once in 10 minutes, the estimated number of operation times is 1000.
- If the protective functions of the servo amplifier activate, turn the power off immediately. Remove the cause before turning the power on again.
- The servo amplifier, the regenerative resistor, and the servo motor can be very hot during or after operation. Take safety measures such as covering them.

[Maintenance]

- When an error occurs, ensure safety by turning the power off, etc., before dealing with the error. Otherwise, it may cause an accident.
- Before wiring or inspection, turn off the power, wait for 15 minutes or more until the charge light turns off, and then check the voltage between P+ and N- with a voltage tester. For the drive unit, turn off the power, wait for 20 minutes or more until the charge light turns off, and then check the voltage between L+ and L- with a voltage tester.
- In a maintenance inspection, make sure that the emergency stop circuit operates properly such that an operation can be stopped immediately and a power can be shut off by the emergency stop switch

[Use of rotary servo motors and direct drive motors]

- To prevent a malfunction on the encoder, do not apply shocks, e.g. hit with a hammer, when coupling the shaft end of the rotary drive motor.
- When mounting a pulley to the rotary servo motor with a keyed shaft, use the screw hole in the shaft end.
- When removing the pulley, use a pulley remover to protect the shaft from excessive load and impact.
- Do not apply a load exceeding the tolerable load onto the rotary servo motor shaft or the direct drive motor rotor. The shaft or the rotor may
- When the rotary servo motor is mounted with the shaft vertical (shaft up), provide measures so that the servo motor is not exposed to oil and water entering from the machine side, gear box, etc.
- Mount the rotary servo motor in a direction described in "Rotary Servo Motor User's Manual".
- When the direct drive motor is used in a machine such as vertical axis which generates unbalanced torque, be sure to use it in absolute position detection system.
- Do not use the 24 V DC interface power supply for the electromagnetic brake. To prevent malfunction, use the power supply designed exclusively for the electromagnetic brake.
- Do not apply the electromagnetic brake when the servo is on. Doing so may cause the servo amplifier overload or shorten the brake life.
 Apply the electromagnetic brake when the servo is off.
- Torque may drop due to temperature increase of the rotary servo motor or the direct drive motor. Be sure to use the motor within the specified ambient temperature.
- The temperature rise of the rotary servo motors and the direct drive motors varies depending on the installation environment and the operation conditions. Conduct a test run on the servo motors before an actual operation to make sure that no alarm occurs.

[Use of linear encoders]

- When the linear encoder is incorrectly installed, an alarm or a position mismatch may occur. In this case, refer to the following checking points for the linear encoder to check the mounting condition.
- Checking points for the linear encoder
 - (a) Check that the gap between the head and scale is proper.
 - (b) Check the scale head for rolling and yawing (decrease in rigidity

- of scale head section).
- (c) Check the scale surface for dust and scratches.
- (d) Check that the vibration and temperature are within the specified range.
- (e) Check that the speed is within the permissible range without overshooting.

[Use of linear servo motors]

- The linear servo system uses powerful magnets on the secondary side. Magnetic force is inversely proportional to the square of the distance from the magnetic material. Therefore, the magnetic force will be significantly stronger as closer to the magnetic material. When mounting the secondary side of linear servo motor, ensure the sufficient distance from the magnetic bodies around it and securely fix those magnetic bodies.
- One who uses a medical device like a pacemaker must keep away from the product and equipment.
- Do not wear metals such as watches, pierced earrings, necklaces, etc
- Do not put magnetic cards, watches, portable phones, etc. close to the motor.
- Place a caution sign such as "CAUTION! POWERFUL MAGNET" to give warning against the machine.
- Use non-magnetic tools, when installing or working near the linear servo motor.
 - e.g., explosion-proof beryllium copper alloy safety tools (BEALON manufactured by NGK Insulators, Ltd.)
- If the linear servo motor is used in such an environment where there is magnetic powder, the powder may adhere to the permanent magnets of the secondary side and cause a damage. In that case, take measures to prevent the magnetic powder or pieces from being attracted to the permanent magnets of the secondary side or from going into the gap between primary side and secondary side.
- The linear servo motor is rated IP00. Provide protection measures to prevent dust and oil, etc., as necessary.
- Install the linear servo motor so that the thrust is applied to the center of gravity of the moving part. Failing to do so will cause a moment to occur.
- The cables such as the power cable deriving from the primary side cannot withstand the long-term bending action. Avoid the bending action by fixing the cables to the moving part or others. Also, use the cable that can withstand the long-term bending action for the wiring to the servo amplifier.
- Increase in the temperature of the linear servo motor causes a thrust drop. Be sure to use the motor within the specified ambient temperature.

[Disposal of linear servo motors]

- Dispose the primary side as industrial waste.
- Demagnetize the secondary side with a heat of 300 °C or higher, and dispose as industrial waste.
- Do not leave the product unattended.

For safety enhancement

Even though the MR-J5 series servo amplifiers, options, and peripheral equipment are certified to various safety standards, this does not guarantee that the systems in which they are installed will also be certified. The entire system shall observe the following:

- For safety circuits, use parts and/or devices whose safety are confirmed or which satisfy safety standards.
- (2) For details regarding the use of the servo amplifiers and other cautionary information, refer to relevant User's Manuals.
- (3) Perform risk assessment on the entire machine/system. Using Certification Body for final safety certification is recommended.

Servo system controller

Warranty

1. Warranty period and coverage

We will repair any failure or defect (hereinafter referred to as "failure") in our FA equipment (hereinafter referred to as the "Product") arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit is repaired or replaced.

[Term]

For terms of warranty, please contact your original place of purchase.

[Limitations]

- You are requested to conduct an initial failure diagnosis by yourself, as a general rule.
 - It can also be carried out by us or our service company upon your request and the actual cost will be charged.
 - However, it will not be charged if we are responsible for the cause of the failure.
- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases;
 - a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
 - (ii) a failure caused by any alteration, etc. to the Product made on your side without our approval
 - (iii) a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
 - (iv) a failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
 - (v) any replacement of consumable parts (battery, fan, smoothing capacitor, etc.)
 - (vi) a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
 - (vii) a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
 - (viii) any other failures which we are not responsible for or which you acknowledge we are not responsible for

2. Term of warranty after the stop of production

- (1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.
- (2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product. However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA Center for details

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

6. Application and use of the Product

- (1) For the use of our servo system controller, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in the servo system controller, and a backup or fail-safe function should operate on an external system to the servo system controller when any failure or malfunction occurs.
- (2) Our servo system controller is designed and manufactured as general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.
 In addition, applications which may be substantially influential to

In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used.

We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

AC servo

Warranty

1. Warranty period and coverage

We will repair any failure or defect hereinafter referred to as "failure" in our FA equipment hereinafter referred to as the "Product" arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit is repaired or replaced.

[Term]

For terms of warranty, please contact your original place of purchase.

[Limitations]

- (1) You are requested to conduct an initial failure diagnosis by yourself, as a general rule. It can also be carried out by us or our service company upon your request and the actual cost will be charged. However, it will not be charged if we are responsible for the cause of the failure.
- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases;
 - a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
 - (ii) a failure caused by any alteration, etc. to the Product made on your side without our approval
 - (iii) a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
 - (iv) a failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
 - (v) any replacement of consumable parts (battery, fan, smoothing capacitor, etc.)
 - (vi) a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
 - (vii) a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
 - (viii) any other failures which we are not responsible for or which you acknowledge we are not responsible for

2. Term of warranty after the stop of production

- (1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.
- (2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product. However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA Center for details

Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

6. Application and use of the Product

- (1) For the use of our AC Servo, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in AC Servo, and a backup or fail-safe function should operate on an external system to AC Servo when any failure or malfunction occurs.
- (2) Our AC Servo is designed and manufactured as a general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.

In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used.

We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

Extensive global support coverage providing expert help whenever needed

■ Global FA centers

■ EMEA

Europe FA Center

MITSUBISHI ELECTRIC EUROPE B.V. Polish Branch

Tel: +48-12-347-65-00

Germany FA Center

MITSUBISHI ELECTRIC EUROPE B.V. German Branch

Tel: +49-2102-486-0

UK FA Center

MITSUBISHI ELECTRIC EUROPE B.V. UK Branch

Tel: +44-1707-27-8780

Czech Republic FA Center
MITSUBISHI ELECTRIC EUROPE B.V. Czech Branch

Tel: +420-255 719 200

Italy FA Center

MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch

Tel: +39-039-60531

Russia FA Center

MITSUBISHI ELECTRIC (RUSSIA) LLC

St. Petersburg Branch

Tel: +7-812-633-3497

Turkey FA Center

MITSUBISHI ELECTRIC TURKEY A.S. Umraniye Branch

Tel: +90-216-526-3990

■ Asia-Pacific

China

Beijing FA Center

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD.

Beijing FA Center

Tel: +86-10-6518-8830

Guangzhou FA Center

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD.

Guangzhou FA Center

Tel: +86-20-8923-6730

Shanghai FA Center

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD.

Shanghai FA Center

Tel: +86-21-2322-3030

Tianjin FA Center

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD.

Tianjin FA Center

Tel: +86-22-2813-1015

Taiwan

Taipei FA Center

SETSUYO ENTERPRISE CO., LTD.

Tel: +886-2-2299-9917

Korea

Korea FA Center

MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD.

Tel: +82-2-3660-9630

Thailand

Thailand FA Center

MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO., LTD.

Tel: +66-2682-6522 to 31

ASEAN

ASEAN FA Center

MITSUBISHI ELECTRIC ASIA PTE. LTD.

Tel: +65-6470-2475

Indonesia

Indonesia FA Center

PT. MITSUBISHI ELECTRIC INDONESIA

Cikarang Office

Tel: +62-21-2961-7797

Vietnam

Hanoi FA Center

MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED

Hanoi Branch Office

Tel: +84-24-3937-8075

Ho Chi Minh FA Center

MITSUBISHI FLECTRIC VIETNAM COMPANY LIMITED

Tel: +84-28-3910-5945

India

India Ahmedabad FA Center
MITSUBISHI ELECTRIC INDIA PVT. LTD.

Ahmedabad Branch

Tel: +91-7965120063

India Bangalore FA Center

MITSUBISHI ELECTRIC INDIA PVT. LTD.

Bangalore Branch

Tel: +91-80-4020-1600

India Chennai FA Center MITSUBISHI ELECTRIC INDIA PVT. LTD. Chennai Branch

Tel: +91-4445548772

India Gurgaon FA Center MITSUBISHI ELECTRIC INDIA PVT. LTD. Gurgaon Head Office

Tel: +91-124-463-0300

India Pune FA Center
MITSUBISHI ELECTRIC INDIA PVT. LTD.

Pune Branch

Tel: +91-20-2710-2000

■ Americas

JSA

North America FA Center
MITSUBISHI ELECTRIC AUTOMATION, INC.

Tel: +1-847-478-2100

Mexico

Mexico City FA Center

MITSUBISHI ELECTRIC AUTOMATION, INC. Mexico Branch

Tel: +52-55-3067-7511

Mexico FA Center

MITSUBISHI ELECTRIC AUTOMATION, INC.

Queretaro Office Tel: +52-442-153-6014

Mexico Monterrey FA Center

MITSUBISHI ELECTRIC AUTOMATION, INC. Monterrey Office


Tel: +52-55-3067-7521

Brazil

Brazil FA Center

MITSUBISHI ELECTRIC DO BRASIL COMERCIO E SERVICOS LTDA.

Tel: +55-11-4689-3000



Support

List of Instruction Manuals

Relevant manuals are listed below:

Servo System Controller

Manual name	Manual No.
MELSEC iQ-R Motion Module User's Manual (Startup)	IB-0300406ENG
MELSEC iQ-R Motion Module User's Manual (Application)	IB-0300411ENG
MELSEC iQ-R Motion Module User's Manual (Network)	IB-0300426ENG
MELSEC iQ-R Programming Manual (Motion Module Instructions, Standard Functions/Function Blocks)	IB-0300431ENG
MELSEC iQ-R Programming Manual (Motion Control Function Blocks)	IB-0300533ENG
MELSEC iQ-F FX5 Motion Module/Simple Motion Module User's Manual (Startup)	IB-0300251ENG
MELSEC iQ-F FX5 Motion Module/Simple Motion Module User's Manual (Application)	IB-0300253ENG
MELSEC iQ-F FX5 Motion Module/Simple Motion Module User's Manual (Advanced Synchronous Control)	IB-0300255ENG
MELSEC iQ-F FX5 Motion Module User's Manual (CC-Link IE TSN)	IB-0300568ENG
MELSEC iQ-F FX5 Motion Module/Simple Motion Module Function Block Reference	BCN-B62005-719
Motion Control Software SWM-G User's Manual (Startup)	IB-0300562ENG
Motion Control Software SWM-G Operating Manual	IB-0300563ENG

Servo Amplifier

Manual name	Manual No.
MR-J5-G/MR-J5W-G User's Manual (Introduction)	SH-030294ENG
MR-J5-G-N1/MR-J5W-G-N1 User's Manual (Introduction)	SH-030366ENG
MR-J5-A User's Manual (Introduction)	SH-030296ENG
MR-J5 User's Manual (Hardware)	SH-030298ENG
MR-J5 User's Manual (Function)	SH-030300ENG
MR-J5-G/MR-J5W-G User's Manual (Communication Function)	SH-030302ENG
MR-J5-G-N1/MR-J5W-G-N1 User's Manual (Communication Function)	SH-030371ENG
MR-J5-G/MR-J5W-G User's Manual (Object Dictionary)	SH-030304ENG
MR-J5-G-N1/MR-J5W-G-N1 User's Manual (Object Dictionary)	SH-030376ENG
MR-J5 User's Manual (Adjustment)	SH-030306ENG
MR-J5-G/MR-J5W-G User's Manual (Parameters)	SH-030308ENG
MR-J5-A User's Manual (Parameters)	SH-030310ENG
MR-J5 User's Manual (Troubleshooting)	SH-030312ENG
MR-J5D-G User's Manual (Introduction)	IB-0300538ENG
MR-J5D-G-N1 User's Manual (Introduction)	IB-0300543ENG
MR-J5D User's Manual (Hardware)	IB-0300548ENG
MR-CV Power Regeneration Converter Unit User's Manual	IB-0300553ENG

Servo Motor

Manual name	Manual No.
Rotary Servo Motor User's Manual (HK Series)	SH-030314ENG
Linear Servo Motor User's Manual (LM-H3/LM-U2/LM-F/LM-K2)	SH-030316ENG
Linear Servo Motor User's Manual (LM-AJ)	IB-0300518ENG
Direct Drive Motor User's Manual	SH-030318ENG

Others

Manual name	Manual No.
EMC Installation Guidelines	IB-67310
MR-J5 Partner's Encoder User's Manual	SH-030320ENG

Android and Google Play are trademarks of Google Inc.

Apple, iPad, iPad Air, iPad mini, and App Store are trademarks of Apple Inc., registered in the U.S. and other countries.

Microsoft, Windows, Visual C++, Visual Studio, and IntelliSense are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Celeron and Pentium are either registered trademarks or trademarks of Intel Corporation in the United States and/or other countries.

PLCopen and related logos are registered trademarks of PLCopen.

EtherCAT is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

All other company names and product names used in this document are trademarks or registered trademarks of their respective companies.

Precautions before use

This publication explains the typical features and functions of the products herein and does not provide restrictions or other information related to usage and module combinations. Before using the products, always read the product user manuals. Mitsubishi Electric will not be held liable for damage caused by factors found not to be the cause of Mitsubishi Electric; opportunity loss or lost profits caused by faults in Mitsubishi Electric products; damage, secondary damage, or accident compensation, whether foreseeable or not, caused by special factors; damage to products other than Mitsubishi Electric products; or any other duties.



🚹 For safe use

- To use the products given in this publication properly, always read the relevant manuals before beginning operation.
- The products have been manufactured as general-purpose parts for general industries, and are not designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the products for special purposes such as nuclear power, electric power,
- aerospace, medicine or passenger-carrying vehicles, consult with Mitsubishi Electric. The products have been manufactured under strict quality control. However, when installing the products where major accidents or losses could occur if the products fail, install appropriate backup or fail-safe functions in the system.



YOUR SOLUTION PARTNER



Mitsubishi Electric offers a wide range of automation equipment from PLCs and HMIs to CNC and EDM machines.



Low voltage: MCCB, MCB, AC



Medium voltage: VCB, VCC



Power monitoring, energy management



Compact and Modular Controllers



Inverters, Servos and Motors



Visualization: HMIs



Numerical Control (NC)



Industrial / Collaborative Robots



Processing machines: EDM, Lasers, IDS



Transformers, Air conditioning, Photovoltaic systems

A NAME TO TRUST

Since its beginnings in 1870, some 45 companies use the Mitsubishi name, covering a spectrum of finance, commerce and industry.

The Mitsubishi brand name is recognized around the world as a symbol of premium quality.

Mitsubishi Electric Corporation, established in 1921, is active in space development, transportation, semi-conductors, energy systems, communications and information processing, audio visual equipment and home electronics, building and energy management and automation systems, and has 183 factories, laboratories and offices worldwide in over 140 countries

This is why you can rely on Mitsubishi Electric automation solution - because we know first hand about the need for reliable, efficient, easy-to-use automation and control in our own factories.

As one of the world's leading companies with a global turnover of over 4 trillion Yen (over \$40 billion), employing over 146,000 people, Mitsubishi Electric has the resource and the commitment to deliver the ultimate in service and support as well as the best products.

^{*} Not all products are available in all countries.

Mitsubishi Electric AC Servo System MELSERVO-J5

Country/Region Sales office USA Mitsubishi Electric Automation, Inc. Tel: +1-847-478-2100 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A. Mitsubishi Electric Automation, Inc. Mexico Branch Tel: +52-55-3067-7512 Mexico Boulevard Miguel de Cervantes Saavedra 301, Torre Norte Piso 5, Ampliacion Granada, Miguel Hidalgo, Ciudad de Mexico, Mexico, C.P.11520 Mitsubishi Electric do Brasil Comercio e Servicos Ltda. Brazil Tel: +55-11-4689-3000 Avenida Adelino Cardana, 293, 21 andar, Bethaville, Barueri SP, Brazil Mitsubishi Electric Europe B.V. German Branch Tel: +49-2102-486-0 Germany Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany UK Mitsubishi Electric Europe B.V. UK Branch Tel: +44-1707-28-8780 Travellers Lane, UK-Hatfield, Hertfordshire, AL10 8XB, U.K. Mitsubishi Electric Europe B.V. Italian Branch Tel: +39-039-60531 Italy Centro Direzionale Colleoni - Palazzo Sirio, Viale Colleoni 7, 20864 Agrate Brianza (MB), Italy Mitsubishi Electric Europe B.V. Spanish Branch Spain Tel: +34-935-65-3131 Carretera de Rubi, 76-80-Apdo. 420, E-08174 Sant Cugat del Valles (Barcelona), Spain France Mitsubishi Electric Europe B.V. French Branch Tel: +33-1-55-68-55-68 25, Boulevard des Bouvets, 92741 Nanterre Cedex, France Czech Republic Mitsubishi Electric Europe B.V. Czech Branch, Prague Office Tel: +420-255-719-200 Pekarska 621/7, 155 00 Praha 5, Czech Republic Mitsubishi Electric Europe B.V. Polish Branch Poland Tel: +48-12-347-65-00 ul. Krakowska 48. 32-083 Balice. Poland Mitsubishi Electric (Russia) LLC St. Petersburg Branch Russia Tel: +7-812-449-51-34 Startovaya street, 8, BC "Aeroplaza", office 607; 196210, St. Petersburg, Russia Mitsubishi Electric Europe B.V. (Scandinavia) Tel: +46-8-625-10-00 Sweden Hedvig Mollersgata 6, 223 55 Lund, Sweden Turkey Mitsubishi Electric Turkey A.S. Umraniye Branch Tel: +90-216-969-2500 Serifali Mah. Kale Sok. No:41 34775 Umraniye - Istanbul, Turkey Mitsubishi Electric Europe B.V. Dubai Branch UAE Tel: +971-4-3724716 Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E. South Africa Adroit Technologies Tel: +27-11-658-8100 20 Waterford Office Park, 189 Witkoppen Road, Fourways, South Africa China Mitsubishi Electric Automation (China) Ltd. Tel: +86-21-2322-3030 Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Shanghai, China SETSUYO ENTERPRISE CO., LTD. Taiwan Tel: +886-2-2299-2499 6F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan Mitsubishi Electric Automation Korea Co., Ltd. Tel: +82-2-3660-9529 Korea 7F to 9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 07528, Korea Mitsubishi Electric Asia Pte. Ltd. Tel: +65-6473-2486 Singapore 307 Alexandra Road, Mitsubishi Electric Building, Singapore 159943 Thailand Mitsubishi Electric Factory Automation (Thailand) Co., Ltd. Tel: +66-2092-8600 True Digital Park Building Sukhumvit 101 Sukhumvit Road, Bang Chak, Prakanong, Bangkok, Indonesia PT. Mitsubishi Electric Indonesia Tel: +62-21-3192-6461 Gedung Jaya 8th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia Vietnam Mitsubishi Electric Vietnam Company Limited Tel: +84-28-3910-5945 11th & 12th Floor, Viettel Tower B, 285 Cach Mang Thang 8 Street, Ward 12, District 10, Ho Chi Minh City, Vietnam Mitsubishi Electric India Pvt. Ltd. Pune Branch India Tel: +91-20-2710-2000 Emerald House, EL-3, J Block, M.I.D.C., Bhosari, Pune - 411026, Maharashtra, India Australia Mitsubishi Electric Australia Pty. Ltd. Tel: +61-2-9684-7777 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS: 1-14, YADA-MINAMI 5, HIGASHI-KU, NAGOYA, JAPAN